


# ***Hydraulics Electrics***

# ***CLAAS***



***CLAAS***

***DOMINATOR 218 MEGA II***

***DOMINATOR 208 MEGA II***

***DOMINATOR 204 MEGA II***

***DOMINATOR 203 MEGA II***

***DOMINATOR 202 MEGA II***

# Contents

## Alpha index

### 1. Oil types, oil pressure, oil change, oil filters, oil pressure, hydraulic pump

Checking oil pressure	1.03
Filter screen, steering, working hydraulics	1.02
Hydraulic pumps	1.03
Oil change	1.02
Oil pressures	1.02
Oil types	1.02
Problems, complete hydraulic system	1.02

### 2. Hydraulic steering system, CLAAS 3-D top sieve

Autopilot solenoid valve	2.12
Circuit diagram	2.02
DANFOSS steering valve	2.06
Pendulum control, 3-D cleaning unit	2.14
Steering cylinder	2.06
Valve block, steering	2.09

### 3. Working hydraulics

3/3 directional control valve, mechanically-operated	3.16
3/3 directional control valve, solenoid-operated	3.08
4/3 directional control valve, solenoid-operated	3.12
Circuit diagram	3.02
Flow control valve, lateral levelling of cutterbar	3.21
Hydraulic cylinder, reel lift	3.24
Hydraulic cylinder, lateral levelling of cutterbar	3.20
Hydraulic cylinder, reel fore and aft	3.26
Lock-up valve	3.14
Oil feed connection	3.18
One way restrictor valve	3.18
Pressure relief valve	3.04

### 4. Front attachments: folding cutterbar, folding maize picker head

6/2 directional contr. valve (solenoid-operated), folding cutterbar	4.06
Circuit diagram, folding cutterbar	4.02
Circuit diagram, Multimaster	4.10
Hydraulic cylinder, cutterbar folding	4.08
Valve block, Multimaster	4.12

### 5. Low pressure hydraulic system

3/2 directional control valve, solenoid-operated	5.06
Circuit diagram	5.02
Hydraulic cylinder	5.08
Hydraulic cylinder, cutterbar engagement/disengagement	5.10
Solenoid-operated valve block with filter	5.04

### 6. LINDE hydraulic ground drive system

Adjustment of servo-control	6.12
Checking hydraulic pressures	6.11
Circuit diagram	6.02
Initial oil fill	6.10
LINDE Pump BPV	6.04
LINDE Motor BMF	6.08
Pressure valves	6.05

### 7. SAUER hydraulic ground drive system

Checking hydraulic pressures	7.10
Circuit diagram	7.02
Fault finding	7.14
Function schematic, hydrostatic ground drive system	7.04
Gauge port arrangement	7.12
Initial oil fill	7.09
Multi-function valve	7.07
SAUER fixed displacement motor	7.08

### 8. CLAAS 4-Trac System

Circuit diagram	8.02
Valve block	8.04

### 9 – 11 Electrics

Air cleaner warning	10.10
Alternator, Diesel engine	9.12
Alternator, Diesel engine	9.08
Auto Contour	11.16
Autopilot	11.30
Battery isolating switch	9.12
Battery isolating switch	9.08
Brake lights	9.20
Brake pad wear indicator	9.20
Cab	9.28
Cable connections	11.44
Cable connections	11.46
Cable connections	11.45
Central electrics (sticker)	11.48
Central electrics (connectors)	11.47
CLAAS 4-Trac System	11.30
Colour code	11.51
Compressor-type air conditioning	9.28
Connection, trailer lighting	9.20
Connection, warning light (D-sign)	9.20
Connection, driver's seat compressor	9.20
Connection, ancillary equipment	9.28
Connection, folding cutterbar lighting	9.20
Connection, CB radio	9.28
Connection, radio	9.20
Contour System	11.06
Cutterbar cylinder setting	11.10
Cutterbar pre-set height	11.12
Cutterbar spring pressure indicator	9.16
Cutterbar raise/lower	11.02
Cutterbar drive	10.04
Cutterbar folding	11.26
Cutterbar reverser	11.04
Cutting height indicator	9.16
Electric wiring diagram	11.53
Engine cut-off system	9.12
Engine starter motor	9.08
Engine starter motor	9.12
Fan speed adjustment	10.06
Fieldwork computer	10.16
Flashers	9.20
Folding cutterbar	11.26
Fuel gauge	9.16
Functions monitor	10.10
Fuses	11.49
Grain tank lamp	9.24
Grain tank fill indicator	9.26
Grain tank unloader swing	10.02
Grain tank unloading engaged/disengaged	10.02
Headlights	9.20
Horn	9.20
Hourmeter	9.16

Key to electric wiring diagram . . . . .	11.52
Key to electric wiring diagram . . . . .	11.51
Lighting, folding cutterbar . . . . .	11.24
Lighting, folding maize picker head . . . . .	11.24
Machine lighting . . . . .	9.20
Main relay circuit . . . . .	9.04
Oil pressure warning . . . . .	9.08
Oil pressure warning, engine cut-off system . . .	9.12
Operations display screen . . . . .	11.42
Parking brake . . . . .	9.20
Parking light . . . . .	9.20
Performance monitor . . . . .	10.14
Programming the Auto Contour System . . . . .	11.22
Rear ladder step safety switch . . . . .	10.02
Rear ladder step safety switch . . . . .	10.04
Rear wheel steering indicator . . . . .	9.16
Rear wheel drive, 4-Trac . . . . .	11.30
Reel speed adjustment . . . . .	10.06
Reel fore and aft . . . . .	11.02
Reel raise-lower . . . . .	11.02
Returns lamp . . . . .	9.24
Rear shining lamp . . . . .	9.24
Reversing horn . . . . .	9.24
Safety switch, grain tank unloading/threshing . .	10.02
Safety switch, grain tank unloading/threshing . .	10.04
Sieve pan lamp . . . . .	9.24
Soybean cutterbar . . . . .	11.25
Starting Diesel engine, automatic engine cut-off . . . . .	9.08
Starting Diesel engine . . . . .	9.08
Straw walker warning . . . . .	10.10
Straw chopper deflector adjustment . . . . .	11.28
Tachometer . . . . .	9.16
Temperature sender/gauge, engine . . . . .	9.08
Testing and measuring electric circuits . . . . .	9.02
Threshing mechanism – main drive . . . . .	10.04
Vehicle information unit . . . . .	11.42
Warning device . . . . .	10.10
Warning beacon . . . . .	9.20
Warning flashers . . . . .	9.20
Windscreen wiper . . . . .	9.28
Work lamps . . . . .	9.24
Yieldmeter . . . . .	10.20

**1**

***Oil types, oil change,  
oil filters, oil pressure,  
hydraulic pump***

<b>Oil type</b>	Multi-grade hydraulic oil HV (ISO VG 46) conforming to DIN 51524 Part 3
<b>Oil change</b>	Biological oil types: see operator's manual
<b>Oil filters</b>	<p>Initially after 100 working hours, thereafter once a year = 500 working hours. Oil level may only be checked with cutterbar cylinders retracted.</p> <p>Working hydraulic system = one oil filter, mesh size 60 µm.  Hydraulic steering system = one oil filter, mesh size 25 µm.  Must be cleaned or changed with every oil change.</p> <p><b>Important:</b> Do not mistake filters with one another. Marker hole must face up. Also see operator's manual.</p>
<b>Oil pressures</b>	<p>Working hydraulic system = 175<sup>+15</sup> bar  Steering system = 115<sup>+15</sup> bar  Low pressure hydraulic system = 19<sup>+2</sup> bar</p>
<b>PROBLEM, COMPLETE HYDRAULIC SYSTEM</b>	Cause: Excessive circulating flow pressure in the circuits (pump maximum circulating oil pressure < 20 bar).
Hydraulic oil overheats	<ul style="list-style-type: none"> <li>– Check spools of directional control valves for correct neutral position (centering)</li> <li>– Check lines and hoses for kinks</li> <li>– Check return flow filters for cleanliness</li> </ul>

## HYDRAULIC PUMP

### Specifications

MEGA 202/203/204/208/218

Speed of double gear pump = 2760 rpm  
Direction of rotation = anti-clockwise

Capacity:

Working hydraulic system Pump 1 = 12 cm<sup>3</sup>  
Hydraulic steering system Pump 2 = 6 cm<sup>3</sup>

### Checking pressures

Working hydraulic system

**NOTE:** Only check hydraulic oil pressures when oil is at operating temperature (approx. 50° C in tank) and with diesel engine at fast idle.

- Connect oil pressure measuring instrument to test connector on pressure relief valve.
- Start diesel engine.
- Fully extend one hydraulic cylinder and hold the lever (or switch) of the appropriate control valve in that position. The hydraulic oil pressure can be read off on the measuring instrument.

Low pressure hydraulic system

- Connect oil pressure measuring instrument to test point (3/2 directional control valve block).

Hydraulic steering system

- Start diesel engine.
- Pressure can be read off on measuring instrument.
- Refer to chapter “Hydraulic Steering System”


### PROBLEM

Pump fails to deliver full output

- Pump drive belt not correctly tensioned.
- Pressure-compensating plates corroded/pitted.
- Seal leaking.
- Back-up plate corroded/pitted.  
Pump output can only be accurately measured when a flow meter is used.

**2**

***DANFOSS***  
***hydraulic steering system***  
***CLAAS 3-D top sieve***







## Key to circuit diagram

- 1 – Pump, steering system
- 2 – Pump, working hydraulic system
- 5 – Oil filter – working hydraulic system, mesh size 60 µm
- 6 – Oil filter – steering system, mesh size 25 µm
- 40 – Connection for measuring instrument, hydraulic steering system
- 41 – Valve block, DANFOSS
- 42 – Pressure relief valve 115<sup>+15</sup> bar
- 43 – Double shock valve 200 bar
- 44 – Check valve
- 45 – Solenoid valve, CLAAS Autopilot
- 46 – DANFOSS steering valve
- 47 – Ball-type check valve (emergency steering)
- 48 – Hydraulic cylinder, steering system
- 49 – One-way valve, emergency steering, 0,2 bar
- 50 – One-way valve, emergency steering, 0,2 bar
- 51 – Hydraulic oil cooler
- 52 – 4/3-way directional control valve, pendulum-controlled, 3-D top sieve
- 53 – Hydraulic cylinder, pendulum-controlled, 3-D top sieve

**Right-hand and left-hand turn – V = valve opens only when emergency steering is used.**



0 9 6 4 0



## Description of system

The steering system is fully hydrostatic. This means that the steering motion is transmitted hydraulically with no mechanical linkage between the steering wheel and the rear wheels.

Steering axle  
(depending on version)

Steering cylinder 55 mm dia. cylinder with 24 mm dia. piston rod  
63 mm dia. cylinder with 25 mm dia. piston rod

DANFOSS steering valve and valve block

Steering valve OSPB 125  
Valve block OVP 20

Designations:

O	– Orbitrol
S	– Steering
P	– Pump
B	– Version with multi-splined shaft
125	– Oil displacement in cm <sup>3</sup> per revolution
V	– Valve block
20	– Double shock valve = 200 bar
ON	– Open Centre – non reaction
Open centre	= With steering controls in neutral, the oil from the pump circulates through the steering unit back to the tank
Non reaction	= With steering controls in neutral, shock loads acting the rear wheels will cause no reaction on the steering wheel.

Pressure settings

OVP 20 = Pressure relief valve = 115<sup>+15</sup> bar  
Double shock valve = 200 bar

**NOTE!** The steering units are TUV-approved

## Checking the pressure

- Connect oil pressure gauge to test connector (pressure line feeding steering unit).
- Start diesel engine.
- Turn steering wheel to full lock and hold it there. The gauge will show the hydraulic oil pressure reading.

### Important!

- With all hydraulic control valves in neutral position, hydraulic oil at operating temperature and engine at maximum speed, flow pressure of circulating oil must not exceed approx. 20 bar. Flow pressure of circulating oil has to be taken into account when carrying out initial pressure settings.  
Example: OVP 20
- Setting of pressure relief valve = 115 <sup>+15</sup> bar  
Measured flow pressure of circulating oil = 12 bar  
Required setting = 115 <sup>+15</sup> bar + 12 bar = 132<sup>+15</sup> bar

**NOTE!** If flow pressure of circulating oil is excessive, the system will overheat.

## How the steering unit works

The orbitrol unit consists of a rotor assembly (metering unit) with rotating steering valve (inner and outer spool).

The rotor assembly consists of rotor ring and rotor. The rotor ring is stationary and has 7 cavities. The rotor (6 lobes) revolves around the centreline of the housing as its lobes engage the cavities of the ring. The steering spindle drives the rotor by way of the cardan shaft and also actuates the steering valve. By rotating the rotor inside the ring, cavities are being opened and closed.

Oil flow from the pump is directed by the steering valve into the open cavities. Oil forced out of the rotor unit as cavities are being closed, is directed by the steering valve to one side of the steering cylinder. Oil forced from the opposite end of the steering cylinder flows back to the reservoir.

## Oil displacement

1/7 of a turn of the steering wheel corresponds to 1/7 of a turn of the rotor hub. This displaces oil from 6 cavities. One full turn of the steering wheel equals one complete revolution of the rotor hub which causes the oil to be displaced  $6 \times 7 = 42$  cavities.

## FUNCTION

In the neutral position oil is allowed to flow freely through the valve (P to T). Turning the steering wheel in one direction, causes rotation of the spools against one another. At 1,5° the oil passages begin to allow oil flow to the cavities. At 4° the neutral position passages will be fully opened. Rotation of spools against one another are limited to  $\pm 8^\circ$ .

Feeding oil under pressure to the rotor unit results in:

- Rotation of rotor.
- Metered oil flow to steering cylinder. Oil flow is proportional to movement of steering wheel. The cylinder moves to steer the rear wheels.
- Closing of rotor access passages in valve as steering wheel motion is stopped. Neutral positioning of outer spool and rotor is mechanically assisted by built-in leaf springs.

## Manual steering (emergency steering)

By turning the steering wheel, the inner spool drives the outer spool by way of the cross pin, whereby the rotor within the rotor ring is turned by the cardan shaft. The rotor assembly will then act as a hand pump and pumps oil to the steering cylinder. Oil is sucked from the rotor return line through the open non-return valve (ball valve), located between T and P (reservoir and pump). In this case steering will be harder, but full control of steering is maintained.

Relief valve

- Setting = see section "Checking the pressure"

Double shock valve

- Setting = see "Checking pressure" (reduces shock loads)

## Valve block

One way valve

- connection P in valve block.  
This valve prevents oil from escaping if the pressure hose ruptures.

The return line (connection T) is directly connected to the reservoir by a replenishing line. This provides sufficient oil for prolonged manual (emergency) steering.

A one way valve is installed in the replenishing line and in the return line.

- 0,2 bar one way valve in the replenishing line, direction of flow is from the reservoir to the steering system.
- 1 bar one way valve in the return line to the filter, direction of flow from the steering system to the filter.

## Repairs

A major overhaul of the unit should only be carried out by authorized DANFOSS workshops. Service work should be limited to the installation of new seals and cleaning the steering valve.

### Practical service hints

Assembly tool for O-ring and Kin-ring:  
CLAAS part no. 178 897.0

## Steering valve

- Hold the unit upright when removing the spools, otherwise the pin might slide into an annular groove.
- Renew all seals.
- Install O-ring and Kin-ring by use of assembly tool.
- Install the rotor assembly so that one cavity in the rotor faces the slot of the cardan shaft (see drawing).
- Place the ball of the one-way valve into the correct hole (screw with long pin).
- Fit new washers to screws of end cover. Cross-tighten the screws, working from the first screw to the one opposite. Tighten screws to  $30^{+5}$  Nm.

## Valve block

### Relief valve

- Valve seating is fitted with Loctite.
- One drop of Loctite is applied to the thread of the adjusting screw.
- Before removing the adjusting screw, measure the depth the screw is screwed in so that the same valve rating is obtained when the valve is re-assembled.
- Check valve rating after installation, using measuring instrument.
- Torque on screwed end cap is  $50^{+10}$  Nm

### Double shock valve

- Before removing the adjusting screw measure the depth the screw is turned in so that the same valve setting is obtained when the valve is re-assembled. The pressure cannot be checked on the machine.
- The valve seating is fitted with Loctite.
- Torque on screwed end cap is  $40^{+10}$  Nm.

### One way valve

- Valve seating is fitted with Loctite.

### Screwing valve block to steering unit

- Torque socket head cap screws to  $65^{+5}$  Nm.

### Checking the steering system

(oil at operating temperature, diesel engine running at maximum no-load speed)

- Check tension of pump drive belt.
- Check steering cylinder.

**Note:** The grooved seal may seal off completely in the end position, but may allow leakage in mid-way position.

Disconnect both hydraulic hoses from the steering cylinder and securely plug them with the screw plugs.

Turn the steering wheel with a force of 25 Nm (18.4 ft lb) until resistance is felt. The steering wheel can turn up to 4 revolutions per minute (check in both directions).

If the steering wheel can be turned less than 4 revolutions per minute (past the resistance), the steering valve is O.K., i.e. check the cylinder.

If the steering wheel can be turned more than 4 revolutions per minute (past the resistance), the steering valve is faulty. In that case check:


- a) the shock valve for leakage,
- b) the rotor or spool for wear.

- Ensure that the piston rod of the cylinder is straight.
- Check king pin for smooth movement.
- Check steering column. There must be a clearance of approx. 1 mm between the splined end of the steering spindle and the mating end of the inner spool of the DANFOSS steering unit. (Adjust by positioning shims between the circlip and the steering column.)  
Height clearance of steering spindle = 0,1 – 0,3 mm.
- The steering wheel must automatically return to the neutral position after it has been turned (check with diesel engine stopped.)
- Connect measuring instrument to test connection and check the pressure. If the pressure is too low:
  - a) adjust the pressure setting,
  - b) check the pressure relief valve (probably leaking).
- Check pump with a flow meter.

**NOTE!** Whenever the steering system and/or its lines have been serviced, the hydraulic lines must be bled with the engine running.







## Key

- I – Neutral position
- II – Working position
- M – Solenoid 12 V, 60 % duty cycle continuous-rated, 3,5 A
- V – Pilot valve
- K – One-way valve with piston
- G – Blocking piston
- E – Spring-loaded pin

The solenoid valve is installed between the steering unit and the valve block. The return flow from the steering unit is fed to the solenoid valve through P. In this way the steering unit receives the oil first to ensure that manual steering is always possible. (The graphic representation does not correspond with the original in this point).

The return oil R from the solenoid valve flows straight back to the reservoir. With manual steering (Autopilot switched off) both the spring-loaded one-way valves (K) in the solenoid valve are closed. The pressure developed in the cylinder then builds up at the one-way valves (K).

## FUNCTION

### Neutral (I)

Both solenoids are deenergized. Oil enters at P, passes the spring-loaded pin (E) and is directed left and right to the pistons (G). The flow restricting edges ensure that the oil is equally divided to both sides. Both blocking pistons (G) are opened by the oil flow and the oil flows through to the pilot valves (V). Both pilot valves (V) are opened. The oil can return directly to the reservoir via R.

### Working position (II)

The solenoid valve is energized. The solenoid's core closes the escape drilling of the pilot valve (V). Pressure builds up in the pilot valve (V). The pilot piston closes the bore R. This builds up pressure that moves piston (K) and the blocking piston (G) on the left-hand side. The piston (K) opens the return valve and releases the return flow from the working cylinder to the reservoir (B to R). The piston (G) blocks the connection between P and R. The return valve (right) is opened hydraulically. The oil flows from P to A.

If the other solenoid is switched the effect is exactly as described above, but in the opposite direction.

## PROBLEMS

### Solenoid valve will not operate

Operate the solenoid concerned by hand. This way you can find out whether the hydraulics or the electrics are at fault.

**NOTE!** Raise the rear axle so that the wheels are just off the ground.

Run the diesel engine at full speed.




- Check pilot valve (V). (Plunger sticking or drilling clogged with dirt.)
- Check blocking piston (G) or piston (K).
- Check restrictor drilling (D).

### Steering response considerably reduced (Autopilot is switched off)

- Check one way valve with built-in piston (K).
- Check O-ring of valve housing (K).

### Machine turns to left or right on its own

- Check grooved seal in steering cylinder.
- Check spring of the respective one way valve (K).
- Check plunger in pilot valve.



**Key**

- 1 = control head
- 2 = pendulum
- 3 = container
- 4 = control spool

**FUNCTION**

The oil supply is fed into port P of the control head. In the middle setting of pendulum 2, P is blocked. If the pendulum position changes in relation to the container either to the left or right, the control spool 4 moves. In this manner, depending on the direction of pendulum deflection, P and A are connected as well as B and R or in the other direction P and B are connected as well as A and R.

**3**

***Working hydraulic system***





## Key

- 1 – Pump, steering system
- 2 – Pump, working hydraulic system
- 5 – Oil filter, working hydraulic system, mesh size 60 µm
- 6 – Oil filter, steering system, mesh size 25 µm
- 8 – Pressure relief valve, working hydraulic system
- 9 – Connection for measuring instrument, working hydraulic system
- 10 – Solenoid-operated 3/3 directional control valve, cutterbar up/down
- 12 – Hydraulic cylinders, cutterbar
- 13 – Solenoid-operated 4/3 directional control valve, grain tank unloading tube
- 14 – Lock-up valve, unloading tube
- 15 – Restrictor plate, diameter 0,8 mm
- 16 – Hydraulic cylinder, grain tank unloading tube
- 17 – Solenoid-operated 3/3 directional control valve, reel up/down or snapping plate adjustment (maize picker head)
- 18 – Restrictor plate, 1,2 mm diameter
- 19 – Quick-release coupling
- 20 – Double-acting hydraulic cylinder, reel up/down
- 21 – Single-acting hydraulic cylinder, reel up/down
- 22 – Solenoid-operated 4/3 directional control valve, lateral levelling of cutterbar
- 23 – Quick-release couplings
- 24 – Lock-up valve
- 25 – Shut-off valve
- 26 – Hydraulic cylinders, lateral levelling of cutterbar
- 27 – Flow control valve
- 28 – Flow control valve
- 29 – Solenoid-operated 4/3 directional control valve, reel fore and aft adjustment or folding the snapping units (maize picker head)
- 30 – Quick-release couplings
- 31 – Lock-up valve
- 32 – Restrictor plates, 1,2 mm diameter, reel fore and aft adjustment
- 33 – Hydraulic cylinders, reel fore and aft adjustment
- 34 – Solenoid-operated 3/3 directional control valve, drum speed variation
- 35 – Hydraulic cylinder, drum speed variation
- 36 – One-way restrictor valve



**Pressure relief valve**



16981

**Pressure relief valve**

**Specifications**

Spring-loaded seated valve with damping, directly controlled.  
Valve setting = 175<sup>+15</sup> bar, adjustable by shims 10 x 16 x 0.5.  
Valve seating secured with self-locking fluid.  
When dismantling the valve use special wrench for slotted nuts part No.181934.2 and heat the housing.  
Torque setting = 30 Nm  
Springs = up to 200 bar – 3.6 mm dia. – L = 64 mm free length.


**PROBLEM**

Little or no pressure build-up at test point

- Spring setting incorrect.
- Spring broken.

Pressure raised above rated setting

- Valve seat loose.



## Key

- I = Neutral position
- II = Raise
- III = Lower
- 1 = Pilot control valve, raise
- 2 = Pilot control valve, lower
- 3 = Restrictor, 0,6 mm dia.
- 4 = Drop rate restrictor (adjustable)
- 5 = Delivery valve
- 6 = Return valve
- 7 = Control spool

## Specifications

Pilot-controlled unit, one way valves prevent leakback of oil.  
Solenoid heads = electrical parts from Uhldingen/Bodensee  
(12 V, 3,5 A, 60 % duty cycle)  
The solenoid heads have plus, ground contact is provided via the switch in the ground speed control lever.  
Diameter of balls in the pilot control valves = 4,5 mm  
Diameter of needles in the pilot control valves = 1,2 mm dia. – 8,8 mm long  
Restrictor bore = 0,6 mm  
Spool fit = 7 – 10 µm

The drop rate restrictor (Item 4) is no longer used for the function raise/lower reel. The housing bore is closed with a screw plug.

## FUNCTION

### Neutral (I)

Both solenoids are deenergized. Oil is allowed from P to S. The oil flow from P forces the split spool back, against the pressure of the spring. The spring cavity is connected with connection R through the pilot valve “raise”. One ball is thereby forced against its seating by the flow of oil from P. A needle between the two balls keeps the other ball in the open position.

Connection A is blocked by the delivery valve, the return valve and the ball in the pilot valve “lower”. The cavity behind the plunger that opens the return valve is connected with the connection R by way of the unseated ball in the pilot valve “lower” (ball-needle).

### Raise (II)

The solenoid of the pilot valve “raise” is being energized. The solenoid pin seats the ball. The needle moves and unseats the other ball. Flow is now allowed from P to either end of the split spool. But because of the difference in surface area and because of the pressure exerted by the spring, the spool is moved towards P. This closes passage S. Oil flows through the centre holes of the spool and through the delivery valve to A.

When the valve is deenergized, the spring seats the ball and the needle unseats the opposite ball. The fluid pressure on the spring-loaded end of the split spool decreases slowly as the oil passes through the 0,6 mm restrictor. The unit returns to its neutral mode.

### Position "lower" (III)

The solenoid of the pilot valve "lower" is being energized. The solenoid pin seats the ball. The needle moves and unseats the other ball. Oil pressure from A operates a plunger (proportional surface area) and opens the return valve. Oil can now flow from A through the open return valve to R.

When the solenoid is deenergized, the spring seats the ball and the needle unseats the opposite ball. The fluid pressure in front of the plunger decreases. This closes the outlet valve. Drop speed can be adjusted with the adjustable restrictor.

## PROBLEM

Front attachment drops

- Check delivery valve in solenoid valve.
- Check condition of seating of return valve cone and of return valve O-ring.
- Check ball seating in the pilot valve "lower".

Front attachment cannot be raised by means of solenoid valve

- Check that the master switch RAISE/LOWER is switched on.
- Check if the solenoid is switched (see wiring diagram).
- Check if the spool 7 in the solenoid valve sticks.
- Check needle and ball seating in pilot valve "raise".
- Check iron core in solenoid.

Front attachment keeps raising a little bit or raises to full height after the push button switch "raise" has been operated

- 0,6 mm dia. restrictor in solenoid valve clogged.
- Sticking spool in solenoid valve.

Front attachment cannot be lowered with solenoid valve

**CAUTION!** Front attachment can only be lowered with the engine running.

- Check that the master switch RAISE/LOWER is switched on.
- Check if the solenoid is switched.
- Inspect the needle in the pilot valve "lower".
- Check that the drop rate restrictor is open.
- Check iron core in solenoid.
- Check return valve 6.



This as a preview PDF file from **best-manuals.com**



Download full PDF manual at **best-manuals.com**