

318D and 320D Skid Steer Loader Operation and Test (EH Controls)

OPERATION & TEST TECHNICAL MANUAL

318D and 320D Skid Steer Loader Operation and Test (EH Controls)


TM11406 14MAR19 (ENGLISH)

Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

TX,INTR,MB52 -19-12SEP97-1/1

We need your help to continually improve our technical publications. Please copy this page and FAX or mail your comments, ideas and improvements.

FAX NUMBER: 1-563-589-5800 (USA)

Page Number: _____

Ideas, Comments:

Phone: _____

Email Address: _____

THANK YOU!

TX, TM, FAX -19-03JUL01-1/1

Contents

Section 9000—General Information

Group 01—Safety

Section 9900—Dealer Fabricated Tools

Group 99—Dealer Fabricated Tools

Section 9001—Diagnostic Trouble Codes (DTCs)

Group 10—Engine Control Unit (ECU) Diagnostic Trouble Codes

Group 20—Engagement and Monitor Unit (EMU) Diagnostic Trouble Codes

Group 30—Hydraulic Control Unit (HCU) Diagnostic Trouble Codes

Group 40—Left Joystick Controller (JSL)

Group 50—Right Joystick Controller (JSR)

Section 9005—Operational Checkout Procedure

Group 10—Operational Checkout Procedure

Section 9010—Engine

Group 05—Theory of Operation

Group 15—Diagnostic Information

Group 25—Tests

Section 9015—Electrical System

Group 05—System Information

Group 10—System Diagrams

Group 15—Sub-System Diagnostics

Group 16—Monitor Operation

Group 20—References

Section 9020—Power Train

Group 05—Theory of Operation

Group 15—Diagnostic Information

Group 25—Tests

Section 9025—Hydraulic System

Group 05—Theory of Operation

Group 15—Diagnostic Information

Group 25—Tests

Section 9026—Hydrostatic System

Group 05—Theory of Operation

Group 15—Diagnostic Information

Group 25—Tests

Section 9031—Heating and Air Conditioning

Group 05—Theory of Operation

Group 15—Diagnostic Information

Group 25—Tests

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication.

The right is reserved to make changes at any time without notice.

COPYRIGHT © 2019
DEERE & COMPANY
Moline, Illinois

All rights reserved.
A John Deere ILLUSTRATION™ Manual
Previous Editions

Copyright © 2009, 2010, 2011, 2012, 2013, 2014, 2015, 2016, 2017, 2018

Section 9000 General Information

Contents

	Page
Group 01—Safety	
Recognize Safety Information	9000-01-1
Follow Safety Instructions.....	9000-01-1
Operate Only If Qualified	9000-01-1
Wear Protective Clothing.....	9000-01-2
Avoid Unauthorized Machine	
Modifications.....	9000-01-2
Inspect Machine	9000-01-2
Stay Clear of Moving Parts.....	9000-01-2
Avoid High-Pressure Fluids	9000-01-3
Avoid High-Pressure Oils	9000-01-3
Work In Ventilated Area.....	9000-01-4
Prevent Fires	9000-01-4
Prevent Battery Explosions	9000-01-5
Handle Chemical Products Safely.....	9000-01-5
Decommissioning — Proper	
Recycling and Disposal of Fluids	
and Components	9000-01-6
Prepare for Emergencies.....	9000-01-6
Clean Debris from Machine	9000-01-7
Use Steps and Handholds	
Correctly	9000-01-7
Start Only From Operator's Seat	9000-01-7
Use and Maintain Seat Belt.....	9000-01-7
Prevent Unintended Machine	
Movement.....	9000-01-8
Avoid Work Site Hazards.....	9000-01-8
Keep Riders Off Machine	9000-01-9
Avoid Backover Accidents	9000-01-9
Avoid Machine Tip Over	9000-01-9
Operating on Slopes.....	9000-01-10
Operating Or Traveling On Public	
Roads	9000-01-10
Inspect and Maintain ROPS	9000-01-10
Add and Operate Attachments	
Safely.....	9000-01-10
Park and Prepare for Service	
Safely.....	9000-01-11
Service Cooling System Safely	9000-01-11
Remove Paint Before Welding or	
Heating	9000-01-12
Make Welding Repairs Safely	9000-01-12
Drive Metal Pins Safely	9000-01-12
Service Tires Safely.....	9000-01-13
Handle Cab Door Safely.....	9000-01-13

Recognize Safety Information

This is the safety alert symbol. When this symbol is noticed on the machine or in this manual, be alert for the potential of personal injury.

Follow the precautions and safe operating practices highlighted by this symbol.

A signal word — DANGER, WARNING, or CAUTION — is used with the safety alert symbol. DANGER identifies the most serious hazards.

On the machine, DANGER signs are red in color, WARNING signs are orange, and CAUTION signs are yellow. DANGER and WARNING signs are located near specific hazards. General precautions are on CAUTION labels.



T133555 —UN—15APR13

T133588 —19—28AUG00

TX03679,00016CC -19-03JAN07-1/1


Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.



TS201 —UN—15APR13

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.

DX,READ -19-16JUN09-1/1

Operate Only If Qualified

Do not operate this machine unless the operator's manual has been read carefully, and you have been qualified by supervised training and instruction.

Operator should be familiar with the job site and surroundings before operating. Try all controls and

machine functions with the machine in an open area before starting to work.

Know and observe all safety rules that may apply to every work situation and work site.

TX03679,00016FA -19-03JAN07-1/1


Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS206 —UN—15APR13

DX,WEAR -19-10SEP90-1/1

Avoid Unauthorized Machine Modifications

John Deere recommends using only genuine John Deere replacement parts to ensure machine performance. Never substitute genuine John Deere parts with alternate parts not intended for the application as these can create hazardous situations or hazardous performance. Non-John Deere parts, or any damage or malfunctions resulting from their use, are not covered by any John Deere warranty.

Modifications of this machine, or addition of unapproved products or attachments, may affect machine stability or

reliability, and may create a hazard for the operator or others near the machine. The installer of any modification which may affect the electronic controls of this machine is responsible for establishing that the modification does not adversely affect the machine or its performance.

Always contact an authorized dealer before making machine modifications that change the intended use, weight or balance of the machine, or that alter machine controls, performance, or reliability.

AM40430,00000A9 -19-01JUL15-1/1

Inspect Machine

Inspect machine carefully each day by walking around it before starting.

Inspect and Clean the Polycarbonate Windows. See Inspect and Clean Polycarbonate Windows. (Section 4-1.)

Keep all guards and shields in good condition and properly installed. Fix damage and replace worn or broken parts immediately. Pay special attention to hydraulic hoses and electrical wiring.



T6607AQ —UN—15APR13


TX03679,0001734 -19-17DEC14-1/1

Stay Clear of Moving Parts

Entanglements in moving parts can cause serious injury.

Stop engine before examining, adjusting or maintaining any part of machine with moving parts.

Keep guards and shields in place. Replace any guard or shield that has been removed for access as soon as service or repair is complete.



T133592 —UN—15APR13

TX03679,00016D2 -19-03JAN07-1/1

Avoid High-Pressure Fluids

Inspect hydraulic hoses periodically – at least once per year – for leakage, kinking, cuts, cracks, abrasion, blisters, corrosion, exposed wire braid or any other signs of wear or damage.


Replace worn or damaged hose assemblies immediately with John Deere approved replacement parts.

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar



with this type of injury should reference a knowledgeable medical source. Such information is available in English from Deere & Company Medical Department in Moline, Illinois, U.S.A., by calling 1-800-822-8262 or +1 309-748-5636.

DX,FLUID -19-12OCT11-1/1


X9811 —UN—23AUG88

Avoid High-Pressure Oils

This machine uses a high-pressure hydraulic system. Escaping oil under pressure can penetrate the skin causing serious injury.

Never search for leaks with your hands. Protect hands. Use a piece of cardboard to find location of escaping oil. Stop engine and relieve pressure before disconnecting lines or working on hydraulic system.

If hydraulic oil penetrates your skin, see a doctor immediately. Injected oil must be removed surgically within hours or gangrene may result. Contact a knowledgeable medical source or the Deere & Company Medical Department in Moline, Illinois, U.S.A.



TX03679,00016D3 -19-03NOV08-1/1


T133509 —UN—15APR13

T133840 —UN—20SEP00

Work In Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



TS220 —UN—15APR13

DX,AIR -19-17FEB99-1/1

Prevent Fires

Handle Fuel Safely: Store flammable fluids away from fire hazards. Never refuel machine while smoking or when near sparks or flame.

Clean Machine Regularly: Keep trash, debris, grease and oil from accumulating in engine compartment, around fuel lines, hydraulic lines, exhaust components, and electrical wiring. Never store oily rags or flammable materials inside a machine compartment.

Maintain Hoses and Wiring: Replace hydraulic hoses immediately if they begin to leak, and clean up any oil spills. Examine electrical wiring and connectors frequently for damage.

Keep A Fire Extinguisher Available: Always keep a multipurpose fire extinguisher on or near the machine. Know how to use extinguisher properly.



T133553 —UN—07SEP00



T133554 —UN—07SEP00



T133552 —UN—15APR13

TX03679,00016F5 -19-03NOV08-1/1

Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204 —UN—15APR13

DX, SPARKS -19-03MAR93-1/1

Handle Chemical Products Safely

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)




TS1132 —UN—15APR13

DX, MSDS, NA -19-03MAR93-1/1

Decommissioning — Proper Recycling and Disposal of Fluids and Components

Safety and environmental stewardship measures must be taken into account when decommissioning a machine and/or component. These measures include the following:

- Use appropriate tools and personal protective equipment such as clothing, gloves, face shields or glasses, during the removal or handling of objects and materials.
- Follow instructions for specialized components.
- Release stored energy by lowering suspended machine elements, relaxing springs, disconnecting the battery or other electrical power, and releasing pressure in hydraulic components, accumulators, and other similar systems.
- Minimize exposure to components which may have residue from agricultural chemicals, such as fertilizers and pesticides. Handle and dispose of these components appropriately.
- Carefully drain engines, fuel tanks, radiators, hydraulic cylinders, reservoirs, and lines before recycling components. Use leak-proof containers when draining fluids. Do not use food or beverage containers.
- Do not pour waste fluids onto the ground, down a drain, or into any water source.
- Observe all national, state, and local laws, regulations, or ordinances governing the handling or disposal of waste fluids (example: oil, fuel, coolant, brake fluid);



TS1133 —UN—15APR13

filters; batteries; and, other substances or parts. Burning of flammable fluids or components in other than specially designed incinerators may be prohibited by law and could result in exposure to harmful fumes or ashes.

- Service and dispose of air conditioning systems appropriately. Government regulations may require a certified service center to recover and recycle air conditioning refrigerants which could damage the atmosphere if allowed to escape.
- Evaluate recycling options for tires, metal, plastic, glass, rubber, and electronic components which may be recyclable, in part or completely.
- Contact your local environmental or recycling center, or your John Deere dealer for information on the proper way to recycle or dispose of waste.


DX,DRAIN -19-01JUN15-1/1

Prepare for Emergencies

Be prepared if an emergency occurs or a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 —UN—15APR13

TX03679,000174B -19-03NOV08-1/1


Clean Debris from Machine

Keep engine compartment, radiator, batteries, hydraulic lines, exhaust components, fuel tank, and operator's station clean and free of debris.

Clean any oil spills or fuel spills on machine surfaces.

Temperature in engine compartment may go up immediately after engine is stopped. **BE ON GUARD FOR FIRES DURING THIS PERIOD.**

Open access door(s) to cool the engine faster, and clean engine compartment.




T6669AG —UN—15APR13

OUT4001,00000E3 -19-20AUG09-1/1

Use Steps and Handholds Correctly

Prevent falls by facing the machine when getting on and off. Maintain 3-point contact with steps and handrails. Never use machine controls as handholds.

Use extra care when mud, snow, or moisture present slippery conditions. Keep steps clean and free of grease or oil. Never jump when exiting machine. Never mount or dismount a moving machine.



T133468 —UN—15APR13

TX03679,00016F2 -19-24APR13-1/1

Start Only From Operator's Seat

Avoid unexpected machine movement. Start engine only while sitting in operator's seat. Ensure all controls and working tools are in proper position for a parked machine.

Never attempt to start engine from the ground. Do not attempt to start engine by shorting across the starter solenoid terminals.



T133715 —UN—15APR13

TX03679,0001799 -19-22APR10-1/1

Use and Maintain Seat Belt

Use seat belt when operating machine. Remember to fasten seat belt when loading and unloading from trucks and during other uses.

Examine seat belt frequently. Be sure webbing is not cut or torn. Replace seat belt immediately if any part is damaged or does not function properly.

The complete seat belt assembly should be replaced every 3 years, regardless of appearance.



**USE
SEAT
BELT**

T133716 —19—17APR13

TX03679,00016DD -19-03NOV08-1/1

Prevent Unintended Machine Movement

Be careful not to accidentally actuate controls. Follow these steps during work interruptions, before allowing coworkers to approach the machine, before standing up, leaving the operator's seat, or exiting the machine:

- Lower equipment to the ground
- Press park brake switch (1) to position P to engage park brake
- Stop the engine
- Raise interlocking seat bar

1— Park Brake Switch



TX1064905A —UN—23SEP09

OUT4001,0000467 -19-28SEP09-1/1

Avoid Work Site Hazards

Avoid contact with gas lines, buried cables, and water lines. Call utility line location services to identify all underground utilities before starting work.

Prepare work site properly. Avoid operating near structures or objects that could fall onto the machine. Clear away debris that could move unexpectedly if run over.


Avoid boom or attachment contact with overhead obstacles or overhead electrical lines. Never move machine closer than 3 m (10 ft) plus twice the line insulator length to overhead wires.

Keep bystanders clear at all times. Keep bystanders away from raised booms, attachments, and unsupported loads. Avoid swinging or raising booms, attachments, or loads over or near personnel. Use barricades or a signal person to keep vehicles and pedestrians away. Use a signal person if moving machine in congested areas or where visibility is restricted. Always keep signal person in view. Coordinate hand signals before starting machine.

Operate only on solid footing with strength sufficient to support machine. Be especially alert working near embankments or excavations.

Avoid working under over-hanging embankments or stockpiles that could collapse under or on machine.

Reduce machine speed when operating with tool on or near ground when obstacles may be hidden (e.g., during snow removal or clearing mud, dirt, etc.). At high speeds hitting obstacles (rocks, uneven concrete, or manholes)



Contact With Electrical Lines



Operate on Solid Footing

can cause a sudden stop. Always wear seat belt. On units equipped with shoulder belts always wear both the seat and shoulder belt and **do not lean forward** while operating.

T192984 —UN—26AUG03

TX1064889 —UN—02OCT09


OUT4001,00004A4 -19-01DEC15-1/1

Keep Riders Off Machine

Only allow operator on machine.

Riders are subject to injury. They may fall from machine, be caught between machine parts, or be struck by foreign objects.

Riders may obstruct operator's view or impair their ability to operate machine safely.



Keep Riders Off Machine

VD76477,0000094 -19-02SEP15-1/1


T192977—UN—26AUG03

Avoid Backover Accidents

Before moving machine, be sure that all bystanders or vehicles are clear of machine path. Turn around and look directly for best visibility. Keep windows clean.

Be certain reverse warning alarm is working properly.

Use a signal person when backing if view is obstructed or when in close quarters. Keep signal person in view at all times. Use prearranged hand signals to communicate.



Avoid Backover Accidents

VD76477,0000095 -19-24MAY16-1/1

T192978—UN—26AUG03

Avoid Machine Tip Over

Use seat belt at all times.

Do not jump if the machine tips. Operator will be unlikely to jump clear and the machine may crush operator.

Load and unload from trucks or trailers carefully.

Ensure that truck is wide enough and on a firm level surface. Use loading ramps and attach them properly to truck bed.

Be careful on slopes. Avoid sharp turns. Balance loads so weight is evenly distributed and load is stable. Carry tools and loads close to the ground to aid in visibility and lower center of gravity. Use extra care on wet, soft, rocky, or frozen ground.


Know the capacity of the machine. Do not overload. Be careful with heavy loads. Using oversize buckets or lifting heavy objects reduces machine stability.

Ensure solid footing. Use extra care in soft ground conditions or on structures that may not uniformly support the wheels, especially when raising the boom. Do not operate close to banks or open excavations that may cave in and cause machine to tip or fall.



Use Seat Belt

**USE
SEAT
BELT**



Avoid Machine Tip Over

VD76477,0000096 -19-25MAY18-1/1

T133716—19—17APR13

T192979—UN—26AUG03


Operating on Slopes

Avoid side slope travel whenever possible. When working on steep slopes, travel as straight up and down as possible and keep the heavy end of the vehicle uphill to prevent machine tip over.

Carry the load as low as possible for maximum stability and visibility.

Select low speed before starting down slope. The slope on which you can operate safely will be limited by ground condition and the load being handled.

Be alert to wind direction and velocity.



Operating On Slopes-Wheeled



TX1063677 —UN—01SEP09

OUT4001,0000470 -19-25MAY18-1/1

Operating Or Traveling On Public Roads

Machines that work near vehicle traffic or travel slower than normal highway speeds must have proper lighting and markings to assure they are visible to other drivers.

Install additional lights, beacons, slow moving vehicle (SMV) emblems, or other devices and use as required to make the machine visible and identify it as a work machine. Check state and local regulations to assure compliance. Keep these devices clean and in working condition.



T141891 —UN—15APR13

TX03679,00017C8 -19-14JUN01-1/1

Inspect and Maintain ROPS

A damaged roll-over protective structure (ROPS) should be replaced, not reused.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting.

If ROPS was loosened or removed for any reason, inspect it carefully before operating the machine again.

To maintain the ROPS:

- Replace missing hardware using correct grade hardware.
- Check hardware torque.
- Check isolation mounts for damage, looseness or wear; replace them if necessary.
- Check ROPS for cracks or physical damage.

TX03679,000179F -19-20APR01-1/1

Add and Operate Attachments Safely

Always verify compatibility of attachments by contacting your authorized dealer. Adding unapproved attachments may affect machine stability or reliability, and may create a hazard for others near the machine.

Ensure that a qualified person is involved in attachment installation. Add guards to machine if operator protection

is required or recommended. Verify that all connections are secure and attachment responds properly to controls.

Carefully read attachment manual and follow all instructions and warnings. In an area free of bystanders and obstructions, carefully operate attachment to learn its characteristics and range of motion.

TX03679,00016F0 -19-24JAN07-1/1

Park and Prepare for Service Safely



Warn others of service work. Always park and prepare machine for service or repair properly.

- Park machine on a level surface and lower equipment to the ground.
- Engage park brake.
- Stop engine and remove key.
- Attach a "DO NOT OPERATE" tag in an obvious place in the operator's station.

Securely support machine or attachment before working under it.

- Do not support machine with any hydraulically actuated tools or attachments.
- Do not support machine with cinder blocks or wooden pieces that may crumble or crush.
- Do not support machine with a single jack or other devices that may slip out of place.
- Always install boom lock before working on or around this machine with the loader boom raised.

Understand service procedures before beginning repairs. Keep service area clean and dry. Use two people whenever the engine must be running for service work.



T133332 —19—17APR13


TS229 —UN—23AUG88

DW90712,00001D1 -19-21AUG09-1/1

Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



TS281 —UN—15APR13

DX,RCAP -19-04JUN90-1/1

Remove Paint Before Welding or Heating


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 100 mm (4 in.) from area to be affected by heating. If paint cannot be removed, wear an approved respirator before heating or welding.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.



Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.

DX,PAINT -19-24JUL02-1/1

TS220 —UN—15APR13

Make Welding Repairs Safely

IMPORTANT: Disable electrical power before welding. Turn off main battery switch or disconnect positive battery cable. Separate harness connectors to engine and vehicle microprocessors.

Avoid welding or heating near pressurized fluid lines. Flammable spray may result and cause severe burns if pressurized lines fail as a result of heating. Do not let heat go beyond work area to nearby pressurized lines.

Remove paint properly. Do not inhale paint dust or fumes. Use a qualified welding technician for structural repairs.



Make sure there is good ventilation. Wear eye protection and protective equipment when welding.


TX03679,00016D5 -19-31AUG07-1/1

T133547 —UN—15APR13

Drive Metal Pins Safely

Always wear protective goggles or safety glasses and other protective equipment before striking hardened parts. Hammering hardened metal parts such as pins and bucket teeth may dislodge chips at high velocity.

Use a soft hammer or a brass bar between hammer and object to prevent chipping.



TX03679,0001745 -19-25SEP00-1/1

T133738 —UN—15APR13

Service Tires Safely


Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



TS211 —UN—15APR13

DX,RIM -19-24AUG90-1/1

Handle Cab Door Safely

When servicing machine, be aware that cab door (1) is breakable.

Keep door closed if cab needs to be raised for service. Be aware of surroundings so that door does not come in contact with any objects.

Use care if cab door needs to be removed. To prevent damage to the door, handle with care and store in a secure location.

1— Cab Door



TX1063683A —UN—08SEP09

OUT4001,0000472 -19-28OCT09-1/1

Section 9001

Diagnostic Trouble Codes (DTCs)

Contents

	Page		Page
Group 10—Engine Control Unit (ECU)			
Diagnostic Trouble Codes			
Engine Control Unit (ECU)		000647.16 — Reversing Fan Switch	
Diagnostic Trouble Codes	9001-10-1	Active Too Long.....	9001-10-11
000029.03 — Foot Throttle Sensor Out		Manual Purge Mode Switch Active Too	
of Range High	9001-10-1	Long Diagnostic Procedure.....	9001-10-12
Foot Throttle Sensor Out of Range		000647.30 — Fan Coil Output Driver	
High Diagnostic Procedure	9001-10-1	Unknown Fault	9001-10-12
000029.04 — Foot Throttle Sensor Out		Fan Coil Output Driver Unknown Fault	
of Range Low	9001-10-2	Diagnostic Procedure.....	9001-10-13
Foot Throttle Sensor Out of Range		000676.05 — Glow Plug Relay Output	
Low Diagnostic Procedure	9001-10-2	Out of Range Low	9001-10-13
000029.14 — Foot Throttle Sensor		Glow Plug Relay Output Out of Range	
(Out of Range High).....	9001-10-3	Low Diagnostic Procedure	9001-10-13
000091.03 — Hand Throttle Sensor		000676.06 — Glow Plug Relay Output	
Out of Range High	9001-10-3	Out of Range High	9001-10-14
Hand Throttle Sensor Out of Range		Glow Plug Relay Output Out of Range	
High Diagnostic Procedure	9001-10-3	High Diagnostic Procedure	9001-10-14
000091.04 — Hand Throttle Sensor		001110.31 — Engine Protection Has	
Out of Range Low	9001-10-4	Shut Down Engine	9001-10-15
Hand Throttle Sensor Out of Range		001321.05 — Starter Relay Output Out	
Low Diagnostic Procedure	9001-10-4	of Range Low	9001-10-15
000091.14 — Hand Throttle Sensor		Starter Relay Output Out of Range	
(Out of Range High).....	9001-10-5	Low Diagnostic Procedure	9001-10-15
000100.03 — Engine Oil Pressure		001321.06 — Starter Relay Output Out	
High.....	9001-10-5	of Range High	9001-10-16
Engine Oil Pressure Out of Range High		Starter Relay Output Out of Range	
Diagnostic Procedure.....	9001-10-5	Low Diagnostic Procedure	9001-10-16
000107.00 — Engine Air Filter Switch		001321.16 — Starter Relay Output	
Data Above Normal.....	9001-10-6	Moderately High Value	9001-10-18
Engine Air Filter Switch Data		001508.00 — Hydraulic Oil	
Above Normal Diagnostic		Temperature Data Above	
Procedure.....	9001-10-6	Normal.....	9001-10-18
000171.03 — Ambient Air Temperature		Hydraulic Oil Temperature Data	
Out of Range High	9001-10-7	Above Normal Diagnostic	
Ambient Air Temperature Out of Range		Procedure.....	9001-10-18
High Diagnostic Procedure	9001-10-7	001508.03 — Hydraulic Oil	
000171.04 — Ambient Air Temperature		Temperature Out of Range	
Out of Range Low	9001-10-8	High.....	9001-10-18
Ambient Air Temperature Out of Range		Hydraulic Oil Temperature Out	
Low Diagnostic Procedure	9001-10-8	of Range High Diagnostic	
000237.13 — Vehicle Identification		Procedure.....	9001-10-18
Number	9001-10-9	001508.04 — Hydraulic Oil	
000647.05 — Fan Coil Output Driver		Temperature Out of Range	
Out of Range Low	9001-10-9	Low.....	9001-10-19
Fan Coil Output Driver Out of Range		Hydraulic Oil Temperature Out	
Low Diagnostic Procedure	9001-10-9	of Range Low Diagnostic	
000647.06 — Fan Coil Output Driver		Procedure.....	9001-10-19
Out of Range High	9001-10-10	001713.00 — Hydraulic Filter	
Fan Coil Output Driver Out of Range		Restriction Switch Data Above	
High Diagnostic Procedure	9001-10-10	Normal.....	9001-10-20

Continued on next page

Page	Page
Hydraulic Filter Restriction Switch Data Above Normal Diagnostic Procedure.....9001-10-20	000234.14 — Software Mismatch.....9001-20-10
002023.09 — No EMU on CAN Bus Abnormal Data Rate.....9001-10-21	000920.05 — Alarm Output Out of Range Low.....9001-20-10
No EMU Data on CAN Bus Abnormal Data Range Diagnostic Procedure.....9001-10-21	Alarm Output Out of Range Low Diagnostic Procedure.....9001-20-10
522826.05 — Fan Reversing Coil Output Out of Range Low.....9001-10-22	000920.06 — Alarm Output Out of Range High.....9001-20-11
Fan Reversing Coil Output Out of Range Low Diagnostic Procedure.....9001-10-22	Alarm Output Out of Range High Diagnostic Procedure.....9001-20-12
522826.06 — Fan Reversing Coil Output Out of Range High.....9001-10-23	001196.11 — Anti Theft Unknown Fault.....9001-20-13
Fan Reversing Coil Output Out of Range High Diagnostic Procedure.....9001-10-23	Anti Theft Unknown Fault Diagnostic Procedure.....9001-20-13
Group 20—Engagement and Monitor Unit (EMU) Diagnostic Trouble Codes	001504.04 — Seat Switch Input Out of Range Low.....9001-20-13
Engagement and Monitor Unit (EMU) Diagnostic Trouble Codes.....9001-20-1	Seat Switch Input Out of Range Low Diagnostic Procedure.....9001-20-13
000070.02 — Park Brake Release Input Erratic or Bad Data.....9001-20-1	001550.05 — AC Compressor Clutch Output Out of Range Low.....9001-20-14
Park Brake Release Input Erratic or Bad Data Diagnostic Procedure.....9001-20-1	AC Compressor Clutch Output Out of Range Low Diagnostic Procedure.....9001-20-14
000070.04 — Park Brake Release Input Out of Range Low.....9001-20-3	001550.06 — AC Compressor Clutch Output Out of Range High.....9001-20-15
Park Brake Release Input Out of Range Low Diagnostic Procedure.....9001-20-3	AC Compressor Clutch Output Out of Range High Diagnostic Procedure.....9001-20-15
000096.03 — Fuel Level Sensor Out of Range High.....9001-20-4	002000.09 — No ECU Data on CAN Bus Abnormal Data Range.....9001-20-17
Fuel Level Sensor Out of Range High Diagnostic Procedure.....9001-20-4	No ECU Data on CAN Bus Abnormal Data Range Diagnostic Procedure.....9001-20-17
000096.04 — Fuel Level Sensor Out of Range Low.....9001-20-5	002228.09 — No HCU Data on CAN Bus Abnormal Data Range.....9001-20-17
Fuel Level Sensor Out of Range Low Diagnostic Procedure.....9001-20-5	No HCU Data on CAN Bus Abnormal Data Range Diagnostic Procedure.....9001-20-17
000158.00 — System Voltage Data Above Normal.....9001-20-6	003413.04 — Door Switch Input Out of Range Low.....9001-20-18
System Voltage Data Above Normal Diagnostic Procedure.....9001-20-6	Seat Switch Input Out of Range Low Diagnostic Procedure.....9001-20-18
000158.01 — System Voltage Data Below Normal.....9001-20-7	003597.03 — 5 Volt Sensor Supply 1 Out of Range High.....9001-20-19
System Voltage Data Below Normal Diagnostic Procedure.....9001-20-7	Sensor Supply Voltage High Diagnostic Procedure—Manual Control Machines.....9001-20-19
000162.04 — 2-Speed Switch Input Out of Range Low.....9001-20-8	Sensor Supply Voltage High Diagnostic Procedure—EH Control Machines.....9001-20-20
Switch Input Low Diagnostic Procedure—Manual Control Machines.....9001-20-8	003597.04 — 5 Volt Sensor Supply 1 Out of Range Low.....9001-20-21
Switch Input Low Diagnostic Procedure—EH Control Machines.....9001-20-9	Sensor Supply Voltage Low Diagnostic Procedure—Manual Control Machines.....9001-20-21
	Sensor Supply Voltage Low Diagnostic Procedure—EH Control Machines.....9001-20-22

Continued on next page

Page	Page
520850.04 — Over Ride Switch Input Out of Range Low9001-20-22	Hydraulic Valve Power 3 Out of Range High Diagnostic Procedure—Manual Control Machines9001-20-37
Over Ride Switch Input Out of Range Low Diagnostic Procedure9001-20-22	Hydraulic Valve Power 3 Out of Range High Diagnostic Procedure—EH Control Machines9001-20-38
521050.04 — Aux Flow On-Off Switch Input Out of Range Low9001-20-23	523218.06 — Propel Valve Power 2 to HCU Out of Range High.....9001-20-39
Switch Input Low Diagnostic Procedure—Manual Control Machines9001-20-23	Propel Valve Power 2 to HCU Out of Range High Diagnostic Procedure.....9001-20-39
Switch Input Low Diagnostic Procedure—EH Control Machines9001-20-24	523219.06 — Hydraulic Valve Power 1 Out of Range High9001-20-40
522379.05 — Park Brake Release Output Out of Range Low9001-20-25	Hydraulic Valve Power 1 Out of Range High Diagnostic Procedure—Manual Control Machines9001-20-41
Park Brake Release Output Out of Range Low Diagnostic Procedure.....9001-20-25	Hydraulic Valve Power 1 Out of Range High Diagnostic Procedure—EH Control Machines9001-20-42
522379.06 — Park Brake Release Output Out of Range High.....9001-20-27	523693.03 — Aux Hyd Channel 1 Input Out of Range High9001-20-43
Park Brake Release Output Out of Range High Diagnostic Procedure.....9001-20-27	Aux Hyd Channel 1 Input High Diagnostic Procedure—Manual Control Machines9001-20-43
522398.02 — Park Brake Run Switch Input Erratic or Bad Data.....9001-20-28	Aux Hyd Channel 1 Input High Diagnostic Procedure—EH Control Machines9001-20-44
Park Brake Release Input Erratic or Bad Data Diagnostic Procedure.....9001-20-28	523693.04 — Aux Hyd Channel 1 Input Out of Range Low9001-20-45
522398.04 — Park Brake Run Switch Input Out of Range Low9001-20-30	Aux Hyd Channel 1 Input Low Diagnostic Procedure—Manual Control Machines9001-20-45
Park Brake Release Input Out of Range Low Diagnostic Procedure9001-20-30	Aux Hyd Channel 1 Input Low Diagnostic Procedure—EH Control Machines9001-20-46
522820.05 — High Flow Driver Out of Range Low9001-20-31	523694.03 — Aux Hyd Channel 2 Input Out of Range High9001-20-47
High Flow Driver Out of Range Low Diagnostic Procedure.....9001-20-31	Aux Hyd Channel 2 Input High Diagnostic Procedure—Manual Control Machines9001-20-47
522820.06 — High Flow Driver Out of Range High9001-20-33	Aux Hyd Channel 2 Input High Diagnostic Procedure—EH Control Machines9001-20-48
High Flow Driver Out of Range High Diagnostic Procedure.....9001-20-33	523694.04 — Aux Hyd Channel 2 Input Out of Range Low9001-20-49
522826.04 — VSF Purge Switch Input Out of Range Low9001-20-33	Aux Hyd Channel 2 Input Low Diagnostic Procedure—Manual Control Machines9001-20-49
VSF Purge Switch Input Out of Range Low Diagnostic Procedure9001-20-34	Aux Hyd Channel 2 Input Low Diagnostic Procedure—EH Control Machines9001-20-50
522827.04 — VSF Auto Switch Input Out of Range Low9001-20-34	523694.12 — Aux Hyd Channel 2 Input Device Fault9001-20-51
VSF Purge Switch Input Out of Range Low Diagnostic Procedure9001-20-34	Aux Hyd Channel 2 Input Device Fault Diagnostic Procedure.....9001-20-51
522828.04 — Creep Mode Switch Input Out of Range Low9001-20-35	523822.04 — High Flow Switch Input Out of Range Low9001-20-51
Creep Mode Switch Input Out of Range Low Diagnostic Procedure9001-20-35	
522859.04 — Lap Bar Switch Input Out of Range Low9001-20-36	
Lap Bar Switch Input Out of Range Low Diagnostic Procedure9001-20-36	
523217.06 — Hydraulic Valve Power 3 Out of Range High9001-20-37	

Continued on next page

Page	Page
High Flow Switch Input Out of Range Low Diagnostic Procedure9001-20-51	001594.02 — Left Speed Sensor Input Erratic or Bad Data.....9001-30-4
523917.05 — Two Speed Output Out of Range Low9001-20-52	Left Speed Sensor Input Erratic or Bad Data Diagnostic Procedure9001-30-4
Two Speed Output Out of Range Low Diagnostic Procedure9001-20-52	001594.14 — Left Speed Sensor Input9001-30-6
523917.06 — Two Speed Output Out of Range High9001-20-53	Left Speed Sensor Input Diagnostic Procedure.....9001-30-6
Two Speed Output Out of Range High Diagnostic Procedure9001-20-53	001595.00 — Right Speed Sensor Input Data Above Normal9001-30-7
523935.05 — Aux Hyd Extend Output Out of Range Low9001-20-55	Right Speed Sensor Input Data Above Normal Diagnostic Procedure.....9001-30-7
Aux Hyd Extend Output Out of Range Low Diagnostic Procedure9001-20-55	001595.01 — Right Speed Sensor Input Data Below Normal9001-30-8
523935.06 — Aux Hyd Extend Output Out of Range High9001-20-56	Right Speed Sensor Input Data Below Normal Diagnostic Procedure.....9001-30-8
Aux Hyd Extend Output Out of Range High Diagnostic Procedure9001-20-56	001595.02 — Right Speed Sensor Input Erratic or Bad Data.....9001-30-9
523941.05 — Aux Hyd Retract Output Out of Range Low9001-20-58	Right Speed Sensor Input Erratic or Bad Data Diagnostic Procedure.....9001-30-10
Aux Hyd Retract Output Out of Range Low Diagnostic Procedure9001-20-59	001595.14 — Right Speed Sensor Input9001-30-11
523941.06 — Aux Hyd Retract Output Out of Range High9001-20-60	Right Speed Sensor Input Diagnostic Procedure.....9001-30-11
Aux Hyd Retract Output Out of Range High Diagnostic Procedure9001-20-60	002201.09 — Right Joystick CAN Data Abnormal Data Rate.....9001-30-12
524225.04 — Remote Start Input Out of Range Low9001-20-61	Right Joystick CAN Data Abnormal Data Rate Diagnostic Procedure.....9001-30-12
Remote Start Input Out of Range Low Diagnostic Procedure9001-20-61	002213.09 — Left Joystick CAN Data Abnormal Data Rate.....9001-30-13
524264.11 — Checksum Error Unknown Fault9001-20-62	Left Joystick CAN Data Abnormal Data Rate Diagnostic Procedure9001-30-13
Checksum Error Unknown Fault Diagnostic Procedure.....9001-20-62	002660.07 — Right Joystick X-axis Mechanical Fault9001-30-13
Group 30—Hydraulic Control Unit (HCU)	Right Joystick X-axis Mechanical Fault Diagnostic Procedure9001-30-13
Diagnostic Trouble Codes	002661.07 — Right Joystick Y-axis Mechanical Fault9001-30-14
Hydraulic Control Unit (HCU)	Right Joystick Y-axis Mechanical Fault Diagnostic Procedure9001-30-14
Diagnostic Trouble Codes9001-30-1	002697.07 — Left Joystick X-axis Mechanical Fault9001-30-14
000168.03 — Unswitched Power Input Out of Range High9001-30-1	Left Joystick X-axis Mechanical Fault Diagnostic Procedure9001-30-14
Unswitched Power Input Out of Range High Diagnostic Procedure9001-30-1	002698.07 — Left Joystick Y-axis Mechanical Fault9001-30-15
000168.04 — Unswitched Power Input Out of Range Low9001-30-1	Left Joystick Y-axis Mechanical Fault Diagnostic Procedure9001-30-15
Unswitched Power Input Out of Range Low Diagnostic Procedure9001-30-1	003597.03 — 5 Volt Sensor Supply 1 Out of Range High9001-30-15
001594.00 — Left Speed Sensor Input Data Above Normal.....9001-30-2	5 Volt Sensor Supply 1 Out of Range High Diagnostic Procedure9001-30-15
Left Speed Sensor Input Data Above Normal Diagnostic Procedure.....9001-30-2	003597.04 — 5 Volt Sensor Supply 1 Out of Range Low9001-30-17
001594.01 — Left Speed Sensor Input Data Below Normal9001-30-3	
Left Speed Sensor Input Data Below Normal Diagnostic Procedure.....9001-30-3	

Continued on next page

Page	Page
5 Volt Sensor Supply 1 Out of Range Low Diagnostic Procedure9001-30-17	522447.16 — Right Pump Fwd Sol Current Moderately High Value9001-30-30
520194.13 — Machine Model ID Wrong or Missing Calibrate Error9001-30-18	Right Pump Fwd Sol Current Moderately High Value Diagnostic Procedure.....9001-30-31
520194.14 — Machine Model ID Wrong or Missing9001-30-18	522448.05 — Right Pump Rev Sol Current Out of Range Low9001-30-32
520652.05 — Bucket Curl Solenoid Current Out of Range Low9001-30-19	Right Pump Rev Sol Current Out of Range Low Diagnostic Procedure.....9001-30-32
Bucket Curl Solenoid Current Out of Range Low Diagnostic Procedure.....9001-30-19	522448.06 — Right Pump Rev Sol Current Out of Range High9001-30-33
520652.06 — Bucket Curl Solenoid Current Out of Range High9001-30-20	Right Pump Rev Sol Current Out of Range High Diagnostic Procedure.....9001-30-33
Bucket Curl Solenoid Current Out of Range High Diagnostic Procedure.....9001-30-20	522448.16 — Right Pump Rev Sol Current Moderately High Value9001-30-34
520652.16 — Bucket Curl Solenoid Current Moderately High Value9001-30-21	Right Pump Rev Sol Current Moderately High Value Diagnostic Procedure.....9001-30-34
Bucket Curl Solenoid Current Moderately High Value Diagnostic Procedure.....9001-30-21	522449.05 — Left Pump Rev Sol Current Out of Range Low9001-30-35
520653.05 — Bucket Dump Solenoid Current Out of Range Low9001-30-22	Left Pump Rev Sol Current Out of Range Low Diagnostic Procedure.....9001-30-35
Bucket Dump Solenoid Current Out of Range Low Diagnostic Procedure.....9001-30-22	522449.06 — Left Pump Rev Sol Current Out of Range High9001-30-36
520653.06 — Bucket Dump Solenoid Current Out of Range High9001-30-23	Left Pump Rev Sol Current Out of Range High Diagnostic Procedure.....9001-30-36
Bucket Dump Solenoid Current Out of Range High Diagnostic Procedure.....9001-30-23	522449.16 — Left Pump Rev Sol Current Moderately High Value9001-30-37
520653.16 — Bucket Dump Solenoid Current Moderately High Value9001-30-24	Left Pump Rev Sol Current Moderately High Value Diagnostic Procedure.....9001-30-38
Bucket Dump Solenoid Current Moderately High Value Diagnostic Procedure.....9001-30-25	522450.05 — Left Pump Fwd Sol Current Out of Range Low9001-30-39
520849.03 — Float Switch Input Out of Range High9001-30-25	Left Pump Fwd Sol Current Out of Range Low Diagnostic Procedure.....9001-30-39
Float Switch Input Out of Range High Diagnostic Procedure.....9001-30-26	522450.06 — Left Pump Fwd Sol Current Out of Range High9001-30-40
520849.04 — Float Switch Input Out of Range Low9001-30-27	Left Pump Fwd Sol Current Out of Range High Diagnostic Procedure.....9001-30-40
Float Switch Input Out of Range Low Diagnostic Procedure.....9001-30-27	522450.16 — Left Pump Fwd Sol Current Moderately High Value9001-30-41
522447.05 — Right Pump Fwd Sol Current Out of Range Low9001-30-28	Left Pump Fwd Sol Current Moderately High Value Diagnostic Procedure.....9001-30-41
Right Pump Fwd Sol Current Out of Range Low Diagnostic Procedure.....9001-30-28	523217.03 — Hydraulic Valve Power 3 to HCU Out of Range High.....9001-30-42
522447.06 — Right Pump Fwd Sol Current Out of Range High9001-30-29	
Right Pump Fwd Sol Current Out of Range High Diagnostic Procedure.....9001-30-29	

Continued on next page

Page	Page
Hydraulic Valve Power 3 to HCU Out of Range High Diagnostic Procedure.....9001-30-42	Boom Up Solenoid Current Moderately High Value Diagnostic Procedure.....9001-30-55
523217.04 — Hydraulic Valve Power 3 to HCU Out of Range Low9001-30-43	523426.05 — Hyd Port Lock Solenoid Current Out of Range Low9001-30-56
Hydraulic Valve Power 3 to HCU Out of Range Low Diagnostic Procedure.....9001-30-43	Hyd Port Lock Solenoid Current Out of Range Low Diagnostic Procedure.....9001-30-56
523218.03 — Propel Valve Power 2 to HCU Out of Range High.....9001-30-44	523426.06 — Hyd Port Lock Solenoid Current Out of Range High9001-30-57
Propel Valve Power 2 to HCU Out of Range High Diagnostic Procedure.....9001-30-44	Hyd Port Lock Solenoid Current Out of Range High Diagnostic Procedure.....9001-30-57
523218.04 — Propel Valve Power 2 to HCU Out of Range Low9001-30-45	524264.11 — Checksum Error Unknown Fault9001-30-58
Propel Valve Power 2 to HCU Out of Range Low Diagnostic Procedure.....9001-30-45	Checksum Error Unknown Fault Diagnostic Procedure.....9001-30-58
523219.03 — Hydraulic Valve Power 1 to HCU Out of Range High.....9001-30-46	Group 40—Left Joystick Controller (JSL)
Hydraulic Valve Power 1 to HCU Out of Range High Diagnostic Procedure.....9001-30-46	Left Joystick Controller (JSL) Diagnostic Trouble Codes9001-40-1
523219.04 — Hydraulic Valve Power 1 to HCU Out of Range Low9001-30-47	002697.03 — Left Joystick X-axis Out of Range High9001-40-1
Hydraulic Valve Power 1 to HCU Out of Range Low Diagnostic Procedure.....9001-30-47	Left Joystick X-axis Out of Range High Diagnostic Procedure.....9001-40-1
523411.05 — Boom Down Solenoid Current Out of Range Low9001-30-48	002697.04 — Left Joystick X-axis Out of Range Low9001-40-1
Boom Down Solenoid Current Out of Range Low Diagnostic Procedure.....9001-30-48	Left Joystick X-axis Out of Range Low Diagnostic Procedure.....9001-40-1
523411.06 — Boom Down Solenoid Current Out of Range High9001-30-49	002697.13 — Left Joystick X-axis Calibrate Error.....9001-40-2
Boom Down Solenoid Current Out of Range High Diagnostic Procedure.....9001-30-49	Left Joystick X-axis Calibrate Error Diagnostic Procedure.....9001-40-2
523411.16 — Boom Down Solenoid Current Moderately High Value9001-30-51	002697.14 — Left Joystick X-axis Error9001-40-2
Boom Down Solenoid Current Moderately High Value Diagnostic Procedure.....9001-30-51	Left Joystick X-axis Error Diagnostic Procedure.....9001-40-2
523414.05 — Boom Up Solenoid Current Out of Range Low9001-30-52	002698.03 — Left Joystick Y-axis Out of Range High9001-40-2
Boom Up Solenoid Current Out of Range Low Diagnostic Procedure.....9001-30-52	Left Joystick Y-axis Out of Range High.....9001-40-2
523414.06 — Boom Up Solenoid Current Out of Range High9001-30-53	002698.04 — Left Joystick Y-axis Out of Range Low9001-40-3
Boom Up Solenoid Current Out of Range High Diagnostic Procedure.....9001-30-53	Left Joystick Y-axis Out of Range Low.....9001-40-3
523414.16 — Boom Up Solenoid Current Moderately High Value9001-30-55	002698.13 — Left Joystick Y-axis Calibrate Error.....9001-40-3
	Left Joystick Y-axis Calibrate Error Diagnostic Procedure.....9001-40-3
	002698.14 — Left Joystick Y-axis Error9001-40-4
	Left Y-axis Error Diagnostic Procedure.....9001-40-4
	Group 50—Right Joystick Controller (JSR)
	Right Joystick Controller (JSR) Diagnostic Trouble Codes9001-50-1

Continued on next page

	Page
002660.03 — Right Joystick X-axis	
Out of Range High	9001-50-1
Right Joystick X-axis Out of Range	
High Diagnostic Procedure	9001-50-1
002660.04 — Right Joystick X-axis	
Out of Range Low	9001-50-1
Right Joystick X-axis Out of Range	
Low Diagnostic Procedure	9001-50-1
002660.13 — Right Joystick X-axis	
Calibrate Error	9001-50-2
Right Joystick X-axis Calibrate Error	
Diagnostic Error	9001-50-2
002660.14 — Right Joystick X-axis	
Error	9001-50-2
Right Joystick X-axis Error Diagnostic	
Procedure	9001-50-2
002661.03 — Right Joystick Y-axis	
Out of Range High	9001-50-3
Right Joystick Y-axis Out of Range	
High Diagnostic Procedure	9001-50-3
002661.04 — Right Joystick Y-axis	
Out of Range Low	9001-50-3
Right Joystick Y-axis Out of Range	
Low Diagnostic Procedure	9001-50-3
002661.13 — Right Joystick Y-axis	
Calibrate Error	9001-50-4
Right Joystick Y-axis Calibrate Error	
Diagnostic Procedure	9001-50-4
002661.14 — Right Joystick Y-axis	
Error	9001-50-4
Right Joystick Y-axis Error Diagnostic	
Procedure	9001-50-4

Engine Control Unit (ECU) Diagnostic Trouble Codes

Group 10

Engine Control Unit (ECU) Diagnostic Trouble Codes

The diagnostic trouble code number is indicated by a suspect parameter number (SPN) and a failure mode indicator (FMI) number. In the example 000744.04, 000744 is the SPN and 04 is the FMI number.

Diagnostic trouble codes can be displayed using the engagement and monitor unit (EMU) or by using the

*Service ADVISOR is a trademark of Deere & Company
PowerTech E is a trademark of Deere & Company*

Service ADVISOR™ diagnostic application. See [Reading Diagnostic Trouble Codes \(DTCs\)](#). (Group 9015-16.)

For in-depth diagnostics on machine specific ECU diagnostic trouble codes, see specific code diagnostic procedures in this group. Additional engine control unit DTC diagnostic procedures for John Deere PowerTech E™ engines are located in the component technical manual (CTM), [PowerTech™ E 2.4L and 3.0L Diesel Engines Component Technical Manual](#). (CTM101019.)

KK70125,000043E -19-17NOV09-1/1

000029.03 — Foot Throttle Sensor Out of Range High

Input from engine speed control pedal (B19) is shorted to power (5 volts or greater).

KK70125,0000440 -19-16NOV09-1/5

Foot Throttle Sensor Out of Range High Diagnostic Procedure

KK70125,0000440 -19-16NOV09-2/5

1 Short to Power Check

Key switch OFF.

Disconnect engine control unit (ECU) J2 connector (X16). See [Main Harness \(W3\) Component Location](#). (Group 9015-10.)

Disconnect engine speed control pedal (B19) connector.

Turn key switch ON.

Using a multimeter, check for voltage on wire E34 WHT between pin F3 of ECU J2 connector (X16) and machine ground.

Is voltage indicated?

YES: Short to power in wire harness. Repair or replace harness. See [Main Harness \(W3\) Wiring Diagram](#). (Group 9015-10.)

NO: Go to Connector Check.

KK70125,0000440 -19-16NOV09-3/5

2 Connector Check

Turn key switch OFF.

Check ECU J2 connector (X16) and engine speed control pedal (B19) connector for any damage, corrosion, or debris that could cause short to power condition for E34 WHT wire.

Are connectors in good condition and free of corrosion and debris?

YES: Go to Wire Check.

NO: Repair or replace connector. See [Main Harness \(W3\) Wiring Diagram](#). (Group 9015-10.)

Continued on next page

KK70125,0000440 -19-16NOV09-4/5

Engine Control Unit (ECU) Diagnostic Trouble Codes

3 Wire Check

Key switch OFF.

ECU J2 connector (X16) disconnected.

Engine speed control pedal (B19) disconnected.

Using a multimeter, check for continuity between pin F3 (wire E34 WHT) of ECU J2 connector (X16) and other pins in same connector.

Is continuity indicated between any circuits?

YES: Short circuit in wire harness. Repair or replace harness. [See Main Harness \(W3\) Wiring Diagram.](#) (Group 9015-10.)

NO: Engine speed control pedal (B19) malfunction. Replace pedal sensor.

KK70125,0000440 -19-16NOV09-5/5

000029.04 — Foot Throttle Sensor Out of Range Low

Input from engine speed control pedal (B19) is open or shorted to ground.

KK70125,0000441 -19-16NOV09-1/4

Foot Throttle Sensor Out of Range Low Diagnostic Procedure

KK70125,0000441 -19-16NOV09-2/4

1 Connector Check

Key switch OFF.

Check engine control unit (ECU) J2 connector (X16) and engine speed control pedal (B19) connector for corrosion, loose fit, bent/pushed out terminals or crimp malfunctions. [See Main Harness \(W3\) Component Location.](#) (Group 9015-10.)

Are connectors in good condition?

YES: Go to Wire Harness Check.

NO: Repair or replace connector(s) or terminal(s) as needed.

KK70125,0000441 -19-16NOV09-3/4

2 Wire Harness Check

Key switch OFF.

Disconnect ECU J2 connector (X16).

Disconnect engine speed control pedal (B19).

Using a multimeter, check continuity of wire E34 WHT between pin F3 of ECU J2 connector (X16) and engine speed control pedal (B19) connector.

Is continuity indicated?

YES: Go to next step in this check.

NO: Open circuit in wire harness. Repair or replace harness. [See Main Harness \(W3\) Wiring Diagram.](#) (Group 9015-10.)

Check for continuity to ground at pin F3 (wire E34 WHT) of ECU J2 connector (X16).

Is continuity to ground indicated?

YES: Short to ground in wire harness. Repair or replace harness. [See Main Harness \(W3\) Wiring Diagram.](#) (Group 9015-10.)

NO: Engine speed control pedal (B19) malfunction. Replace pedal sensor.

KK70125,0000441 -19-16NOV09-4/4

000029.14 — Foot Throttle Sensor (Out of Range High)

Engine speed control pedal (B19) is or has been out of range high. Sensor will not reset code until

returned to slow idle (zero) position or the key switch is cycled. Return engine speed control pedal (B19) to slow idle position or cycle key switch.

KK70125,0000442 -19-16NOV09-1/1

000091.03 — Hand Throttle Sensor Out of Range High

Input from engine speed control dial (B18) is shorted to power (5 volts or greater).

KK70125,0000443 -19-16NOV09-1/5

Hand Throttle Sensor Out of Range High Diagnostic Procedure

KK70125,0000443 -19-16NOV09-2/5

1 Short to Power Check

Key switch OFF.

Disconnect engine control unit (ECU) J2 connector (X16). [See Main Harness \(W3\) Component Location.](#) (Group 9015-10.)

Disconnect engine speed control dial (B18) connector. [See Cab Harness \(W2\) Component Location.](#) (Group 9015-10.)

Turn key switch ON.

Using a multimeter, check for voltage on wire E33 WHT between pin A4 of ECU J2 connector (X16) and machine ground.

Is voltage indicated?

YES: Short to power in wire harness. Repair or replace harness. [See Cab Harness \(W2\) Wiring Diagram.](#) [See Main Harness \(W3\) Wiring Diagram.](#) (Group 9015-10.)

NO: Go to Connector Check.

KK70125,0000443 -19-16NOV09-3/5

2 Connector Check

Turn key switch OFF.

Check ECU J2 connector (X16), cab harness-to-main harness 47-pin connector (X2), and engine speed control dial (B18) connector for any damage, corrosion, or debris that could cause short to power condition for E33 WHT wire.

Are connectors in good condition and free of corrosion and debris?

YES: Go to Wire Check.

NO: Repair or replace connector. [See Cab Harness \(W2\) Wiring Diagram.](#) [See Main Harness \(W3\) Wiring Diagram.](#) (Group 9015-10.)

Continued on next page

KK70125,0000443 -19-16NOV09-4/5

3 Wire Check

Key switch OFF.

ECU J2 connector (X16) disconnected.

Engine speed control dial (B18) disconnected.

Using a multimeter, check for continuity between pin A4 (wire E33 WHT) of ECU J2 connector (X16) and other pins in same connector.

Is continuity indicated between any circuits?

YES: Short circuit in wire harness. Repair or replace harness. [See Cab Harness \(W2\) Wiring Diagram](#). [See Main Harness \(W3\) Wiring Diagram](#). (Group 9015-10.)

NO: Engine speed control dial (B18) malfunction. Replace dial sensor.

KK70125,0000443 -19-16NOV09-5/5

000091.04 — Hand Throttle Sensor Out of Range Low

Input from engine speed control dial (B18) is open or shorted to ground.

KK70125,0000444 -19-16NOV09-1/4

Hand Throttle Sensor Out of Range Low Diagnostic Procedure

KK70125,0000444 -19-16NOV09-2/4

1 Connector Check

Key switch OFF.

Check engine control unit (ECU) J2 connector (X16) and engine speed control dial (B18) connector for corrosion, loose fit, bent/pushed out terminals or crimp malfunctions. [See Main Harness \(W3\) Component Location](#). [See Cab Harness \(W2\) Component Location](#). (Group 9015-10.)

Are connectors in good condition?

YES: Go to Wire Harness Check.

NO: Repair or replace connector(s) or terminal(s) as needed.

Continued on next page

KK70125,0000444 -19-16NOV09-3/4

2 Wire Harness Check	<p>Key switch OFF.</p> <p>Disconnect ECU J2 connector (X16). Disconnect engine speed control dial (B18). Using a multimeter, check continuity of wire E33 WHT between pin A4 of ECU J2 connector (X16) and engine speed control dial (B18) connector. Is continuity indicated?</p>	<p>YES: Go to next step in this check.</p> <p>NO: Open circuit in wire harness. Repair or replace harness. See Cab Harness (W2) Wiring Diagram. See Main Harness (W3) Wiring Diagram. (Group 9015-10.)</p>
	<p>Check for continuity to ground at pin A4 (wire E33 WHT) of ECU J2 connector (X16).</p> <p>Is continuity to ground indicated?</p>	<p>YES: Short to ground in wire harness. Repair or replace harness. See Cab Harness (W2) Wiring Diagram. See Main Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Engine speed control dial (B18) malfunction. Replace dial sensor.</p>

KK70125,0000444 -19-16NOV09-4/4

000091.14 — Hand Throttle Sensor (Out of Range High)

Engine speed control dial (B18) is or has been out of range high. Sensor will not reset code until

returned to slow idle (zero) position or the key switch is cycled. Return engine speed control dial (B18) to slow idle position or cycle key switch.

KK70125,0000445 -19-16NOV09-1/1

000100.03 — Engine Oil Pressure High

Input from engine oil pressure switch (B6) is open or shorted to power.

KK70125,00009D2 -19-14JUN16-1/6

Engine Oil Pressure Out of Range High Diagnostic Procedure

KK70125,00009D2 -19-14JUN16-2/6

1 Connector Check	<p>Turn key switch OFF.</p> <p>Check engine control unit (ECU) J1 connector (X15) and engine oil pressure switch (B6) connector for any damage, corrosion, or debris that could cause short to power condition for N01 YEL wire. See Main Harness (W3) Wiring Diagram. (Group 9015-10.) Are connectors in good condition and free of corrosion and debris?</p>	<p>YES: Go to Component Check.</p> <p>NO: Repair or replace connector.</p>
--------------------------	--	--

Continued on next page

KK70125,00009D2 -19-14JUN16-3/6

Engine Control Unit (ECU) Diagnostic Trouble Codes

2 Component Check	Perform engine oil pressure check. See Engine Oil Pressure Check. (CTM101019.)	YES: Continue check.
	Is engine oil pressure within specified range?	NO: Replace engine oil pressure regulating valve.
	Turn key switch OFF. Disconnect engine oil pressure switch (B6). ECU J1 connector (X15) connected. Using a multimeter, check continuity between engine oil pressure switch terminal and machine ground. Is continuity to ground through switch indicated?	YES: Go to Continuity Check. NO: Replace engine oil pressure switch (B6).

KK70125,00009D2 -19-14JUN16-4/6

3 Continuity Check	Turn key switch OFF. Disconnect engine oil pressure switch (B6). See Main Harness (W3) Component Location. (Group 9015-10.) Check continuity between E3 of ECU J1 connector (X15) and machine ground. Is continuity indicated?	YES: Go to Wire Harness Check. NO: Circuit is open. Repair or replace harness.
---------------------------	---	---

KK70125,00009D2 -19-14JUN16-5/6

4 Wire Harness Check	Turn key switch OFF. ECU J1 connector (X15) disconnected. Check for continuity between pin E3 (wire N01 YEL) of ECU J1 connector (X15) and other pins in the same connector. Is continuity indicated between any circuits?	YES: Short circuit in wire harness. Repair or replace harness. See Main Harness (W3) Wiring Diagram. (Group 9015-10.) NO: Checks complete.
-----------------------------	---	---

KK70125,00009D2 -19-14JUN16-6/6

000107.00 — Engine Air Filter Switch Data Above Normal

Air filter restricted, air filter restriction switch (B1) malfunction, or short circuit in wire harness.

KK70125,0000446 -19-16NOV09-1/6

Engine Air Filter Switch Data Above Normal Diagnostic Procedure

KK70125,0000446 -19-16NOV09-2/6

1 Air Filter Restriction Check	Check air intake system for excessive debris or flow restrictions. See Engine Intake and Exhaust Component Location. (Group 9010-15.) Is engine air intake system restricted?	YES: Replace air filters as needed. See Replace Primary Engine Air Filter. See Replace Secondary Engine Air Filter. (Operator's Manual.) NO: Go to Component Check.
---------------------------------------	--	--

Continued on next page

KK70125,0000446 -19-16NOV09-3/6

Engine Control Unit (ECU) Diagnostic Trouble Codes

2 Component Check

Turn key switch OFF.

Disconnect air filter restriction switch (B1). [See Main Harness \(W3\) Component Location](#). (Group 9015-10.)

Check for continuity between pins on air filter restriction switch (B1).

Is continuity indicated?

YES: Replace air filter restriction switch (B1).

NO: Go to Short Circuit Check.

KK70125,0000446 -19-16NOV09-4/6

3 Short Circuit Check

Key switch OFF.

Air filter restriction switch (B1) disconnected.

Disconnect engine control unit (ECU) J2 connector (X16).

Check for continuity between wires F01 YEL and G01 BLK at air filter restriction switch (B1) connector.

Is continuity indicated?

YES: Short circuit in wire harness. Repair or replace harness. [See Main Harness \(W3\) Wiring Diagram](#). (Group 9015-10.)

NO: Go to next step in this check.

Key switch OFF.

Air filter restriction switch (B1) disconnected.

Check circuit F01 YEL for ground at pin A on air filter restriction switch (B1) connector.

Is ground present?

YES: Short to ground in wire F01 YEL. Repair or replace harness. [See Main Harness \(W3\) Wiring Diagram](#). (Group 9015-10.)

NO: Go to Wire Check.

KK70125,0000446 -19-16NOV09-5/6

4 Wire Check

Key switch OFF.

ECU J2 connector (X16) disconnected.

Air filter restriction switch (B1) disconnected.

Check for continuity between pin E3 (wire F01 YEL) of ECU J2 connector (X16) and other pins in same connector.

Is continuity indicated between any circuits?

YES: Short circuit in wire harness. Repair or replace harness. [See Main Harness \(W3\) Wiring Diagram](#). (Group 9015-10.)

NO: Checks complete.

KK70125,0000446 -19-16NOV09-6/6

000171.03 — Ambient Air Temperature Out of Range High

Open circuit in wire harness to ambient air temperature sensor (B24), either signal or ground; ambient air temperature sensor (B24) malfunction.

KK70125,0000447 -19-16NOV09-1/5

Ambient Air Temperature Out of Range High Diagnostic Procedure

Continued on next page

KK70125,0000447 -19-16NOV09-2/5

Engine Control Unit (ECU) Diagnostic Trouble Codes

1 Connector Check

Key switch OFF.

Check engine control unit (ECU) J2 connector (X16) and ambient air temperature sensor (B24) connector for corrosion, loose fit, bent/pushed out terminals or crimp malfunctions. [See Main Harness \(W3\) Component Location.](#) (Group 9015-10.)

Are connectors in good condition?

YES: Go to Wire Harness Check.

NO: Repair or replace connector(s) or terminal(s) as needed.

KK70125,0000447 -19-16NOV09-3/5

2 Wire Harness Check

Key switch OFF.

Disconnect ECU J2 connector (X16).

Disconnect ambient air temperature sensor (B24).

Using a multimeter, check continuity of wire X04 YEL between pin B4 of ECU J2 connector (X16) and ambient air temperature sensor (B24) connector.

Check continuity of wire R05 BLK between pin C3 of ECU J2 connector (X16) and ambient air temperature sensor (B24) connector.

Is continuity indicated?

YES: Go to next step in this check.

NO: Open circuit in wire harness. Repair or replace harness. [See Main Harness \(W3\) Wiring Diagram.](#) (Group 9015-10.)

KK70125,0000447 -19-16NOV09-4/5

3 Component Check

Turn key switch OFF.

Check resistance through ambient air temperature sensor (B24). [See Electrical Component Specifications.](#) (Group 9015-20.)

Is sensor resistance within specifications?

YES: Checks complete.

NO: Replace ambient air temperature sensor (B24).

KK70125,0000447 -19-16NOV09-5/5

000171.04 — Ambient Air Temperature Out of Range Low

Short to ground in signal circuit from ambient air temperature sensor (B24) or sensor malfunction.

KK70125,0000448 -19-16NOV09-1/5

Ambient Air Temperature Out of Range Low Diagnostic Procedure

KK70125,0000448 -19-16NOV09-2/5

1 Connector Check

Key switch OFF.

Check engine control unit (ECU) J2 connector (X16) and ambient air temperature sensor (B24) connector for corrosion, loose fit, bent/pushed out terminals or crimp malfunctions. [See Main Harness \(W3\) Component Location.](#) (Group 9015-10.)

Are connectors in good condition?

YES: Go to Wire Harness Check.

NO: Repair or replace connector(s) or terminal(s) as needed.

Continued on next page

KK70125,0000448 -19-16NOV09-3/5

2 Wire Harness Check

Key switch OFF.

Disconnect ECU J2 connector (X16).

Disconnect ambient air temperature sensor (B24).

Using a multimeter, check for continuity to ground at pin B4 (wire X04 YEL) of ECU J2 connector (X16).

Is continuity to ground indicated?

YES: Short to ground in wire harness. Repair or replace harness. See [Main Harness \(W3\) Wiring Diagram](#). (Group 9015-10.)

NO: Go to Component Check.

KK70125,0000448 -19-16NOV09-4/5

3 Component Check

Turn key switch OFF.

Check resistance through ambient air temperature sensor (B24). See [Electrical Component Specifications](#). (Group 9015-20.)

Is sensor resistance within specifications?

YES: Checks complete.

NO: Replace ambient air temperature sensor (B24).

KK70125,0000448 -19-16NOV09-5/5

000237.13 — Vehicle Identification Number

The software versions (major software revision number) between the engine control unit (ECU) and other machine controllers do not match.

Code is usually a result of a new or different controller being installed on a machine.

Program machine controllers with latest software for the machine in which they are installed.

KK70125,0000449 -19-16DEC10-1/1

000647.05 — Fan Coil Output Driver Out of Range Low

Open circuit in the wire harness to hydraulic fan speed solenoid (Y30).

KK70125,000044B -19-16NOV09-1/5

Fan Coil Output Driver Out of Range Low Diagnostic Procedure

NOTE: Machines without optional reversing fan use fan speed solenoid harness (W9) to connect from main harness (W3) to hydraulic fan speed solenoid (Y30).

KK70125,000044B -19-16NOV09-2/5

1 Connector Check

Key switch OFF.

Check engine control unit (ECU) J2 connector (X16), hydraulic fan speed solenoid (Y30) connector, and main harness-to-fan speed solenoid harness 2-pin connector (X39) (if not equipped with reversing fan) for corrosion, loose fit, bent/pushed out terminals or crimp malfunctions. See [Main Harness \(W3\) Component Location](#). See [Fan Speed Solenoid Harness \(W9\) Component Location](#). (Group 9015-10.)

Are connectors in good condition?

YES: Go to Wire Harness Check.

NO: Repair or replace connector(s) or terminal(s) as needed.

Continued on next page

KK70125,000044B -19-16NOV09-3/5

2 Wire Harness Check

Key switch OFF.

Disconnect ECU J2 connector (X16).

Disconnect hydraulic fan speed solenoid (Y30).

Using a multimeter, check continuity of wire E42 WHT between pin J4 of ECU J2 connector (X16) and hydraulic fan speed solenoid (Y30) connector.

Check continuity of wire R50 BLK between pins C1 and D2 of ECU J2 connector (X16) and hydraulic fan speed solenoid (Y30) connector.

Is continuity indicated?

YES: Go to Component Check.

NO: Open circuit in wire harness. Repair or replace harness. [See Main Harness \(W3\) Wiring Diagram.](#) [See Fan Speed Solenoid Harness \(W9\) Wiring Diagram.](#) (Group 9015-10.)

KK70125,000044B -19-16NOV09-4/5

3 Component Check

Key switch OFF.

Check resistance through hydraulic fan speed solenoid (Y30). [See Electrical Component Specifications.](#) (Group 9015-20.)

Is solenoid resistance within specifications?

YES: Checks complete.

NO: Replace hydraulic fan speed solenoid (Y30).

KK70125,000044B -19-16NOV09-5/5

000647.06 — Fan Coil Output Driver Out of Range High

Open circuit or short to ground in the wire harness to hydraulic fan speed solenoid (Y30).

KK70125,000044C -19-16NOV09-1/5

Fan Coil Output Driver Out of Range High Diagnostic Procedure

NOTE: Machines without optional reversing fan use fan speed solenoid harness (W9) to connect from main harness (W3) to hydraulic fan speed solenoid (Y30).

KK70125,000044C -19-16NOV09-2/5

1 Connector Check

Key switch OFF.

Check engine control unit (ECU) J2 connector (X16), hydraulic fan speed solenoid (Y30) connector, and main harness-to-fan speed solenoid harness 2-pin connector (X39) (if not equipped with reversing fan) for corrosion, loose fit, bent/pushed out terminals or crimp malfunctions. [See Main Harness \(W3\) Component Location.](#) [See Fan Speed Solenoid Harness \(W9\) Component Location.](#) (Group 9015-10.)

Are connectors in good condition?

YES: Go to Wire Harness Check.

NO: Repair or replace connector(s) or terminal(s) as needed.

Continued on next page

KK70125,000044C -19-16NOV09-3/5

This as a preview PDF file from **best-manuals.com**



Download full PDF manual at **best-manuals.com**