

848H Skidder Repair

TECHNICAL MANUAL 848H Skidder Repair

TM10289 27AUG09 (ENGLISH)

For complete service information also see:

848H Skidder Operation and Test	TM10287
848H Skidder Operator's Manual	OMT230201
POWERTECH™ 4.5 L and 6.8 L Diesel Engines—Base Engine	CTM104
PowerTech Plus™ 4.5L & 6.8L Diesel Engines—Level 14 Electronic Fuel System With Denso HPCR	CTM320
Alternators and Starting Motors.....	CTM77
TeamMate™ IV 1200 - 1400 Series Inboard Planetary Axles	CTM442
40 and 4000 Winches	CTM25
60 and 6000 Winches	CTM41
DF180 Series Powershift Transmission Repair Manual	CTM308

**Worldwide Construction
And Forestry Division**

LITHO IN U.S.A.

Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

.0004E4A -19-08SEP08-1/1

Introduction

Contents

SECTION 00—General Information

- Group 0001—Safety Information
- Group 0003—Torque Values

SECTION 01—Wheels

- Group 110—Powered Wheels and Fastenings

SECTION 02—Axle

- Group 0200—Removal and Installation
- Group 0225—Input Drive Shafts and U-Joints
- Group 0260—Hydraulic System

SECTION 03—Transmission

- Group 0300—Removal and Installation
- Group 0315—Controls
- Group 0325—Input Drive Shafts and U-Joints
- Group 0350—Gears, Shafts and Power Shift Clutches
- Group 0360—Hydraulic System

SECTION 04—Engine

- Group 0400—Removal and Installation

SECTION 05—Engine Auxiliary Systems

- Group 0505—Cold Weather Starting Aids
- Group 0510—Cooling Systems
- Group 0520—Intake System
- Group 0530—Exhaust System
- Group 0560—External Fuel Supply

SECTION 06—Torque Converter

- Group 0600—Remove and Install
- Group 0641—Torque Converter Housing

SECTION 09—Steering System

- Group 0930—Secondary Steering
- Group 0960—Hydraulic System
- Group 0962—Dual Mode Steering

SECTION 10—Service Brakes

- Group 1015—Controls Linkage
- Group 1060—Hydraulic System

SECTION 11—Park Brake

- Group 1111—Active Elements
- Group 1160—Hydraulic System

SECTION 17—Frame, Chassis, or Supporting Structures

- Group 1740—Frame Installation
- Group 1746—Frame Bottom Guards

SECTION 18—Operator's Station

- Group 1800—Removal and Installation
- Group 1810—Operator Enclosure
- Group 1821—Seat and Seat Belt
- Group 1830—Heating and Air Conditioning

SECTION 19—Sheet Metal and Styling

- Group 1910—Hood or Engine Enclosure

SECTION 20—Safety, Convenience, and Miscellaneous

- Group 2003—Pressurized Water System
- Group 2004—Horn and Warning Devices

SECTION 21—Main Hydraulic System

- Group 2160—Hydraulic System

SECTION 30—Winch

- Group 3000—Removal and Installation
- Group 3015—Controls Linkage
- Group 3025—Input Drive Shafts and U-Joints
- Group 3050—Drive and Clutch

SECTION 32—Stacking Blades

- Group 3201—Blades
- Group 3215—Controls Linkage
- Group 3260—Hydraulic System

SECTION 38—Grapple

- Group 3803—Grapple Mechanism
- Group 3815—Controls Linkage
- Group 3840—Frames
- Group 3860—Hydraulic System

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2009
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright © 2007, 2008, 2009

00

01

02

03

04

05

06

09

10

11

00

SECTION 99—Dealer Fabricated Tools
Group 9900—Dealer Fabricated Tools

01

02

03

04

05

06

09

10

11

Contents

17

18

19

20

21

30

32

38

99

INDX

Contents

17

18

19

20

21

30

32

38

99

INDX

Section 00 General Information

Contents

	Page	Page
Group 0001—Safety Information		
Recognize Safety Information	00-0001-1	
Follow Safety Instructions	00-0001-1	
Operate Only If Qualified	00-0001-1	
Wear Protective Equipment	00-0001-2	
Avoid Unauthorized Machine Modifications	00-0001-2	
Inspect Machine	00-0001-2	
Stay Clear of Moving Parts	00-0001-3	
Avoid High-Pressure Oils	00-0001-3	
Avoid High-Pressure Fluids	00-0001-4	
Do Not Use Starting Fluid	00-0001-4	
Beware of Exhaust Fumes	00-0001-4	
Prevent Fires	00-0001-5	
Prevent Battery Explosions	00-0001-5	
Handle Chemical Products Safely	00-0001-6	
Dispose of Waste Properly	00-0001-6	
Prepare for Emergencies	00-0001-6	
Use Steps and Handholds Correctly	00-0001-7	
Start Only From Operator's Seat	00-0001-7	
Use and Maintain Seat Belt	00-0001-7	
Prevent Unintended Machine Movement	00-0001-8	
Avoid Work Site Hazards	00-0001-8	
Operate Machine Safely	00-0001-9	
Keep Riders Off Machine	00-0001-9	
Avoid Backover Accidents	00-0001-10	
Avoid Machine Tip Over	00-0001-10	
Operating on Slopes	00-0001-11	
Operating or Traveling On Public Roads	00-0001-11	
Inspect and Maintain ROPS	00-0001-11	
Keep the Operator Protective Structure (OPS) in Place	00-0001-12	
Add and Operate Attachments Safely	00-0001-12	
Park and Prepare for Service Safely	00-0001-13	
Service Cooling System Safely	00-0001-13	
Remove Paint Before Welding or Heating	00-0001-14	
Make Welding Repairs Safely	00-0001-14	
Drive Metal Pins Safely	00-0001-15	
Group 0003—Torque Values		
Hardware Torque Specifications	00-0003-1	
Keeping ROPS Installed Properly	00-0003-1	
Torque Value Metric Bolt and Cap Screw	00-0003-2	
Additional Metric Cap Screw Torque Values	00-0003-3	
Torque Value Unified Inch Bolt and Cap Screw	00-0003-5	
Check Oil Lines And Fittings	00-0003-6	
Service Recommendations for 37° Flare and 30° Cone Seat Connectors	00-0003-7	
Service Recommendations for O-Ring Boss Fittings	00-0003-8	
Service Recommendations For Flat Face O-Ring Seal Fittings	00-0003-10	
Service Recommendations for Metric Series Four Bolt Flange Fitting	00-0003-11	
Service Recommendations For Inch Series Four Bolt Flange Fittings	00-0003-12	

Contents

00

Recognize Safety Information

This is the safety alert symbol. When you see this symbol on your machine or in this manual, be alert for the potential of personal injury.

Follow the precautions and safe operating practices highlighted by this symbol.

A signal word — DANGER, WARNING, or CAUTION — is used with the safety alert symbol. DANGER identifies the most serious hazards.

On your machine, DANGER signs are red in color, WARNING signs are orange, and CAUTION signs are yellow. DANGER and WARNING signs are located near specific hazards. General precautions are on CAUTION labels.



T1133555 -UN-28AUG00

T1133588 -19-28AUG00

TX03679,00016CC -19-03NOV08-1/1

Follow Safety Instructions

Read the safety messages in this manual and on the machine. Follow these warnings and instructions carefully. Review them frequently.

Be sure all operators of this machine understand every safety message. Replace operator's manual and safety labels immediately if missing or damaged.



T1133556 -UN-24AUG00

TX03679,00016F9 -19-01OCT07-1/1

Operate Only If Qualified

Do not operate this machine unless you have read the operator's manual carefully and you have been qualified by supervised training and instruction.

Familiarize yourself with the job site and your surroundings before operating. Try all controls and

machine functions with the machine in an open area before starting to work.

Know and observe all safety rules that may apply to your work situation and your work site.

TX03679,00016FA -19-03NOV08-1/1


00
0001
2

Wear Protective Equipment

Guard against injury from flying pieces of metal or debris; wear goggles or safety glasses.

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear suitable hearing protection such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



T5206 -UN-23AUG88

TX03679,00016D0 -19-03NOV08-1/1

Avoid Unauthorized Machine Modifications

John Deere recommends using only genuine John Deere replacement parts to ensure machine performance. Never substitute genuine John Deere parts with alternate parts not intended for the application as these can create hazardous situations or hazardous performance. Non-John Deere Parts, or any damage or failures resulting from their use are not covered by any John Deere warranty.

Modifications of this machine, or addition of unapproved products or attachments, may affect machine stability or reliability, and may create a hazard

for the operator or others near the machine. The installer of any modification which may affect this machine is responsible for establishing that the modification does not adversely affect the machine or its performance. This applies to all aspects of the machine, including electronic controls.

Always contact an authorized dealer before making machine modifications that change the intended use, weight or balance of the machine, or that alter machine controls, performance or reliability.

AM40430,0000084 -19-01OCT07-1/1

Inspect Machine

Inspect machine carefully each day by walking around it before starting.

Keep all guards and shields in good condition and properly installed. Fix damage and replace worn or broken parts immediately. Pay special attention to hydraulic hoses and electrical wiring.



T6607AQ -UN-18OCT88


TX03679,0001734 -19-03NOV08-1/1

Stay Clear of Moving Parts

Entanglements in moving parts can cause serious injury.

Stop engine before examining, adjusting or maintaining any part of machine with moving parts.

Keep guards and shields in place. Replace any guard or shield that has been removed for access as soon as service or repair is complete.



T133592 -UN-12SEP01

TX03679,00016D2 -19-03NOV08-1/1

Avoid High-Pressure Oils


This machine uses a high-pressure hydraulic system. Escaping oil under pressure can penetrate the skin causing serious injury.

Never search for leaks with your hands. Protect hands. Use a piece of cardboard to find location of escaping oil. Stop engine and relieve pressure before disconnecting lines or working on hydraulic system.

If hydraulic oil penetrates your skin, see a doctor immediately. Injected oil must be removed surgically within hours or gangrene may result. Contact a knowledgeable medical source or the Deere & Company Medical Department in Moline, Illinois, U.S.A.



T133509 -UN-17MAR06



T133840 -UN-20SEP00

TX03679,00016D3 -19-03NOV08-1/1


00
0001
4

Avoid High-Pressure Fluids

This machine uses a high-pressure hydraulic system. Escaping fluid under pressure can penetrate the skin causing serious injury.

Never search for leaks with your hands. Protect hands. Use a piece of cardboard to find location of escaping fluid. Stop engine and relieve pressure before disconnecting lines or working on hydraulic system.

If hydraulic fluid penetrates your skin, see a doctor immediately. Injected fluid must be removed surgically within hours or gangrene may result. Contact a knowledgeable medical source or the Deere & Company Medical Department in Moline, Illinois, U.S.A.



T133509 -UN-17MAR06

T133840 -UN-20SEP00

TX03679,00016D3 -19-30OCT00-1/1

Do Not Use Starting Fluid

IMPORTANT: Avoid an explosion or fire. Machine is equipped with electrical cold start assist system. Do not use starting fluid of any type on the machine.

This machine is equipped with a Tier III engine. Fire, explosion or engine damage will result from using starting fluids of any type on this machine.




T145705 -UN-18SEP01

OOU1065,00001B6 -19-11JUN08-1/1

Beware of Exhaust Fumes

Prevent asphyxiation. Engine exhaust fumes can cause sickness or death.

If you must operate in a building, provide adequate ventilation. Use an exhaust pipe extension to remove the exhaust fumes or open doors and windows to bring outside air into the area.



T133546 -UN-24AUG00

TX03679,00016D4 -19-01OCT07-1/1

Prevent Fires


Handle Fuel Safely: Store flammable fluids away from fire hazards. Never refuel machine while smoking or when near sparks or flame.

Clean Machine Regularly: Keep trash, debris, grease and oil from accumulating in engine compartment, around fuel lines, hydraulic lines and electrical wiring. Store rags and other combustible materials in a safe, fireproof location. Use only nonflammable products for cleaning the machine or components.

Maintain Hoses and Wiring: Replace hydraulic hoses immediately if they begin to leak, and clean up any oil spills. Examine electrical wiring and connectors frequently for damage.

Remove Debris and Clean the Surrounding Area: Before starting repair work, such as welding, clear the area of any debris or flammable material.

Keep a Fire Extinguisher Available: Always keep a multipurpose fire extinguisher on or near the machine. Know how to use extinguisher properly.



T133552 -UN-14SEP00

T133553 -UN-07SEP00

T133554 -UN-07SEP00

TX03679,0001808 -19-01OCT07-1/1

Prevent Battery Explosions

Battery gas can explode. Keep sparks, lighted matches, and open flame away from the top of battery.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204 -UN-23AUG88


TX03679,000174A -19-01OCT07-1/1

00
0001
6

Handle Chemical Products Safely

Exposure to hazardous chemicals can cause serious injury. Under certain conditions, lubricants, coolants, paints and adhesives used with this machine may be hazardous.

If uncertain about safe handling or use of these chemical products, contact your authorized dealer for a Material Safety Data Sheet (MSDS). The MSDS describes physical and health hazards, safe use procedures, and emergency response techniques for chemical substances. Follow MSDS recommendations to handle chemical products safely.



T133580 -UN-25AUG00

TX03679,00016D7 -19-01OCT07-1/1


Dispose of Waste Properly

Improper disposal of waste can threaten the environment. Fuel, oils, coolants, filters and batteries used with this machine may be harmful if not disposed of properly.

Never pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants can damage the atmosphere. Government regulations may require using a certified service center to recover and recycle used refrigerants.

If uncertain about the safe disposal of waste, contact your local environmental or recycling center or your dealer for more information.



T133567 -UN-25AUG00


TX03679,0001733 -19-01OCT07-1/1

Prepare for Emergencies

Be prepared if an emergency occurs or a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.




TS291 -UN-23AUG88

TX03679,000174B -19-01OCT07-1/1

Use Steps and Handholds Correctly

Prevent falls by facing the machine when you get on and off. Maintain 3-point contact with steps and handrails. Never use machine controls as handholds.

Use extra care when mud, snow, or moisture present slippery conditions. Keep steps clean and free of grease or oil. Never jump when exiting machine. Never mount or dismount a moving machine.



T133468 -UN-30AUG00

TX03679,00016F2 -19-03OCT07-1/1

Start Only From Operator's Seat

Avoid unexpected machine movement. Start engine only while sitting in operator's seat. Ensure all controls and working tools are in proper position for a parked machine.

Never attempt to start engine from the ground. Do not attempt to start engine by shorting across the starter solenoid terminals.



T133715 -UN-07SEP00

TX03679,0001799 -19-03OCT07-1/1

Use and Maintain Seat Belt

Use seat belt when operating machine. Remember to fasten seat belt when loading and unloading from trucks and during other uses.

Examine seat belt frequently. Be sure webbing is not cut or torn. Replace seat belt immediately if any part is damaged or does not function properly.

The complete seat belt assembly should be replaced every three years, regardless of appearance.



**USE
SEAT
BELT**

T133716 -19-14SEP00


TX03679,00016DD -19-03OCT07-1/1

00
0001
8

Prevent Unintended Machine Movement

Be careful not to accidentally actuate controls. Move transmission out of gear and lower all equipment to the ground during work interruptions. Follow these steps before allowing coworkers to approach the machine, before standing up, leaving the operator's seat, or exiting the machine:

- Lower equipment to the ground
- Move transmission gear selector to neutral position
- Press park brake switch (2) to "on"
- Stop the engine



1—Differential Lock Switch
2—Park Brake Switch

TX1020560 -UN-11APR07

MD46667,00002A3 -19-17APR07-1/1

Avoid Work Site Hazards


Plan your operation before starting work. Check skidding trails and landings for stumps, large rocks, drop-offs, muddy areas and standing water. Carefully examine overhead for trees and branches that might fall or strike the operator's station. Take precautions to avoid these hazards.

Be sure co-workers and bystanders are clear of machine before operating. Keep co-workers a safe distance away when skidding, because logs may kick-out unexpectedly.

Use extra care if you must drive over logs or saplings that may be dislodged or spring-up against the machine or bystanders.

Do not operate under low-hanging electrical wires. Contact may cause serious injury or death by electrocution.

Reduce machine speed when operating with tool on or near ground when obstacles may be hidden (e.g., during snow removal or clearing mud, dirt, etc). At high speeds, hitting obstacles (rocks, uneven concrete or manholes) can cause a sudden stop. Always wear your seat belt.



T146611 -UN-22OCT01

TX03679,000180B -19-07FEB08-1/1


Operate Machine Safely

Wear the seat belt when operating this machine. Do not operate the machine if all elements of the operator protective structure (OPS) are not in place and in good repair.

Use extra care around landings where bystanders are more likely to be present. Do not skid logs past people that are not a safe distance away from logs that may swing or kick-out.

Use extra care when backing-up with logs attached. Make sure the de-limbing grate is in good repair and bystanders are a safe distance away.

Be careful when operating in muddy or frozen conditions because the machine may slide or tip more easily. Avoid side slopes when possible. Drive straight up or down slopes to reduce the possibility of tipping.



T146610 -UN-22OCT01


TX03679.000180A -19-03OCT07-1/1

Keep Riders Off Machine

Only allow operator on machine.

Riders are subject to injury. They may fall from machine, be caught between machine parts, or be struck by foreign objects.

Riders may obstruct operator's view or impair his ability to operate machine safely.



T145263 -UN-06SEP01

TX03679.0001800 -19-03OCT07-1/1


00
0001
10

Avoid Backover Accidents

Before moving machine, be sure all persons are clear of machine path. Turn around and look directly for best visibility. Use mirror to assist in checking around machine. Keep windows and mirror clean, adjusted, and in good repair.

Be certain reverse warning alarm is working properly.

Use a signal person when backing if view is obstructed or when in close quarters. Keep signal person in view at all times. Use prearranged hand signals to communicate.



T145264 -JUN-06SEP01

TX03679,0001801 -19-03OCT07-1/1

Avoid Machine Tip Over

Use seat belt at all times.

Do not jump if the machine tips. You will be unlikely to jump clear and the machine may crush you.

Load and unload from trucks or trailers carefully. Be sure truck is wide enough and on a firm level surface. Use loading ramps and attach them properly to truck bed.



Be careful on slopes. Avoid sharp turns. Avoid stumps, rocks and drop-offs when possible. Use extra care on soft, uneven or frozen ground.

Do not overload. Know the capacity of the machine. Be careful with heavy loads which may affect machine stability.

Ensure solid footing. Use extra care in soft ground conditions that may not uniformly support the wheels. Do not operate close to banks that may cave in and cause machine to tip or fall.



USE SEAT BELT



T133716 -19-14SEP00

T145266 -JUN-06SEP01


T146612 -JUN-06NOV01

TX03679,0001802 -19-03OCT07-1/1

Operating on Slopes

Avoid side slope travel whenever possible. When working on steep slopes, travel as straight up and down as possible to prevent machine tip over.

Select low gear before starting down slope. The slope on which you can operate safely will be limited by ground condition and the load being handled. Use service brakes to control speed.





T145730 -UN-20SEP01

TX03679,0001803 -19-03OCT07-1/1

Operating or Traveling On Public Roads

Machines that work near vehicle traffic or travel slower than normal highway speeds must have proper lighting and markings to assure they are visible to other drivers.

Install additional lights, beacons, slow moving vehicle (SMV) emblems, or other devices and use as required to make the machine visible and identify it as a work machine. Check state and local regulations to assure compliance. Keep these devices clean and in working condition.



T141881 -UN-22MAY01

TX03679,00017C8 -19-03OCT07-1/1

Inspect and Maintain ROPS

A damaged roll-over protective structure (ROPS) should be replaced, not reused.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting.

If ROPS was loosened or removed for any reason, inspect it carefully before operating the machine again.

To maintain the ROPS:

- Replace missing hardware using correct grade hardware.
- Check hardware torque.
- Check isolation mounts for damage, looseness or wear; replace them if necessary.
- Check ROPS for cracks or physical damage.

TX03679,000179F -19-03OCT07-1/1

00
0001
12

Keep the Operator Protective Structure (OPS) in Place

It is important to keep the operator protective structure (OPS) in place (doors, screens, windows, windshield, etc.) to minimize hazards from whipping or intruding objects. To maintain OPS protection, replace damaged parts immediately.

Replace 3-piece hard-coated polycarbonate windshield only with LEXAN® Margard 5000 or equivalent.

The protection offered by OPS will be impaired if OPS is subjected to structural damage, is involved in an overturn incident, or is altered by welding, bending, drilling, or cutting. Damaged OPS components should be replaced, not reused.

Keep all bolts and attaching hardware tight.

LEXAN is a trademark of General Electric Corporation

TX,90,JC297 -19-03OCT07-1/1

Add and Operate Attachments Safely

Always verify compatibility of attachments by contacting your authorized dealer. Adding unapproved attachments may affect machine stability or reliability, and may create a hazard for others near the machine.

Ensure that a qualified person is involved in attachment installation. Add guards to machine if operator protection is required or recommended. Verify

that all connections are secure and attachment responds properly to controls.

Carefully read attachment manual and follow all instructions and warnings. In an area free of bystanders and obstructions, carefully operate attachment to learn its characteristics and range of motion.

TX03679,00016F0 -19-03OCT07-1/1

Park and Prepare for Service Safely

Warn others of service work. Always park and prepare your machine for service or repair properly.


- Park machine on a level surface and lower equipment to the ground.
- Engage park brake.
- Stop engine and remove key.
- Install articulation locking bar.
- Attach a "Do Not Operate" tag in an obvious place in the operator's station.

IMPORTANT: Engine side panels may be warm immediately after machine shut down and gloves may need to be worn.

Support machine or attachment before working under it.

- Do not support machine with any hydraulically actuated tools or attachments.
- Do not support machine with cinder blocks or wooden pieces that may crumble or crush.
- Do not support machine with a single jack or other devices that may slip out of place.

Understand service procedures before beginning repairs. Keep service area clean and dry. Use two people whenever the engine must be running for service work.



T133332 -19-14DEC01

TS229 -JUN-23AUG88

OUTJ003.00007AB -19-17AUG06-1/1

Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.



TS281 -JUN-23AUG88

DX,RCAP -19-04JUN90-1/1


00
0001
14

Remove Paint Before Welding or Heating

Hazardous fumes can be generated when paint is heated by welding or using a torch. Dust from sanding or grinding paint can also be hazardous.

Remove paint to at least 76 mm (3 in.) from area to be heated. Wear an approved respirator when sanding or grinding paint. If a solvent or paint stripper is used, wash area with soap and water. Remove solvent or paint stripper containers from work area and allow fumes to disperse at least 15 minutes before welding or heating.

Work outside or in a well-ventilated area. Dispose of waste, paint and solvents properly.



T133546 -UN-24AUG00

TX03679,0001732 -19-06SEP00-1/1

Make Welding Repairs Safely

IMPORTANT: Disable electrical power before welding. Turn off main battery switch or disconnect positive battery cable. Separate harness connectors to engine and vehicle microprocessors.

Avoid welding or heating near pressurized fluid lines. Flammable spray may result and cause severe burns if pressurized lines fail as a result of heating. Do not let heat go beyond work area to nearby pressurized lines.

Remove paint properly. Do not inhale paint dust or fumes. Use a qualified welding technician for structural repairs. Make sure there is good ventilation. Wear eye protection and protective equipment when welding.




T133547 -UN-31AUG00

TX03679,00016D5 -19-04JUN07-1/1

Drive Metal Pins Safely

Always wear protective goggles or safety glasses and other protective equipment before striking hardened parts. Hammering hardened metal parts such as pins and bucket teeth may dislodge chips at high velocity.

Use a soft hammer or a brass bar between hammer and object to prevent chipping.



T133738 -JUN-14SEP00

00
0001
15

OUO1065.0000090 -19-03NOV08-1/1

Safety Information

00
0001
16

Hardware Torque Specifications

Check cap screws and nuts to be sure they are tight. If hardware is loose, tighten to torque shown on the following charts unless a special torque is specified.

04T,90,K271 -19-08AUG91-1/1

Keeping ROPS Installed Properly

CAUTION: Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.


IMPORTANT: Do not over-tighten cap screws as clevis will be deformed.

Install lock nuts (A) onto cap screws (B) until full thread engagement is achieved so nut, washers (C), and head of cap screw are flush against each clevis.

Tighten pin locking cap screws (D) to specification.

Keeping ROPS Installed Properly—Specification

Pin Locking Cap Screw—Torque 130 Nm (95 lb-ft)



T129546C -UN-31MAR00



T129547D -UN-03APR00


- A—Lock Nut (2 used)
- B—Cap Screw (2 used)
- C—Washer (As required)
- D—Pin Locking Cap Screw (2 used)

CED,OUO1079,98 -19-26MAY00-1/1

Torque Values

00
0003
2

Metric Bolt and Cap Screw Torque Values



Top—Property Class and Head Markings; Bottom—Property Class and Nut Markings

TORQ2 -UN-07/SEP99

METRIC BOLT AND CAP SCREW TORQUE VALUES—Tolerance is $\pm 10\%$ unless otherwise specified								
Thread Size	Class 4.8		Class 8.8 or 9.8		Class 10.9		Class 12.9	
	Lubricated ^a N•m (lb-ft)	Dry ^b N•m (lb-ft)	Lubricated ^a N•m (lb-ft)	Dry ^b N•m (lb-ft)	Lubricated ^a N•m (lb-ft)	Dry ^b N•m (lb-ft)	Lubricated ^a N•m (lb-ft)	Dry ^b N•m (lb-ft)
M6	4.7 (3.5)	6 (4.4)	9 (6.6)	11.5 (8.5)	13 (9.5)	16.5 (12.2)	15.5 (11.5)	19.5 (14.5)
M8	11.5 (8.5)	14.5 (10.7)	22 (16)	28 (20.5)	32 (23.5)	40 (29.5)	37 (27.5)	47 (35)
M10	23 (17)	29 (21)	43 (32)	55 (40)	63 (46)	80 (59)	75 (55)	95 (70)
M12	40 (29.5)	50 (37)	75 (55)	95 (70)	110 (80)	140 (105)	130 (95)	165 (120)
M14	63 (46)	80 (59)	120 (88)	150 (110)	175 (130)	220 (165)	205 (150)	260 (190)
M16	100 (74)	125 (92)	190 (140)	240 (175)	275 (200)	350 (255)	320 (235)	400 (300)
M18	135 (100)	170 (125)	265 (195)	330 (245)	375 (275)	475 (350)	440 (325)	560 (410)
M20	190 (140)	245 (180)	375 (275)	475 (350)	530 (390)	675 (500)	625 (460)	790 (580)
M22	265 (195)	330 (245)	510 (375)	650 (480)	725 (535)	920 (680)	850 (625)	1080 (800)
M24	330 (245)	425 (315)	650 (480)	820 (600)	920 (680)	1150 (850)	1080 (800)	1350 (1000)
M27	490 (360)	625 (460)	950 (700)	1200 (885)	1350 (1000)	1700 (1250)	1580 (1160)	2000 (1475)
M30	660 (490)	850 (625)	1290 (950)	1630 (1200)	1850 (1350)	2300 (1700)	2140 (1580)	2700 (2000)
M33	900 (665)	1150 (850)	1750 (1300)	2200 (1625)	2500 (1850)	3150 (2325)	2900 (2150)	3700 (2730)
M36	1150 (850)	1450 (1075)	2250 (1650)	2850 (2100)	3200 (2350)	4050 (3000)	3750 (2770)	4750 (3500)

^a "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.
^b "Dry" means plain or zinc plated without any lubrication.



CAUTION: Use only metric tools on metric hardware. Other tools may not fit properly. Tool may slip and cause injury.

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical property class.

Fasteners should be replaced with the same or higher property class. If higher property class fasteners are used, these should only be tightened to the strength of the original.

Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.


Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

Additional Metric Cap Screw Torque Values

⚠ CAUTION: Use only metric tools on metric hardware. Other tools may not fit properly. They may slip and cause injury.

Check tightness of cap screws periodically. Torque values listed are for general use only. Do not use these values if a different torque value or tightening procedure is listed for a specific application.

T6873AA



T6873AA -JUN-18OCT88

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

T6873AB



T6873AB -JUN-18OCT88

Make sure fastener threads are clean and you properly start thread engagement. This will prevent them from failing when tightening.

Tighten cap screws having lock nuts to approximately 50 percent of amount shown in chart.

T6873AC



T6873AC -JUN-18OCT88

Continued on next page

04T,90,M170 -19-29SEP99-1/2

Torque Values

00
0003
4


METRIC CAP SCREW TORQUE VALUES ^a						
Nominal Dia	T-Bolt		H-Bolt		M-Bolt	
	N•m	lb-ft	N•m	lb-ft	N•m	lb-ft
8	29	21	20	15	10	7
10	63	46	45	33	20	15
12	108	80	88	65	34	25
14	176	130	137	101	54	40
16	265	195	206	152	78	58
18	392	289	294	217	118	87
20	539	398	392	289	167	125
22	735	542	539	398	216	159
24	931	687	686	506	274	202
27	1372	1012	1029	759	392	289
30	1911	1410	1421	1049	539	398
33	2548	1890	1911	1410	735	542
36	3136	2314	2401	1772	931	687
^a Torque tolerance is ±10%.						

04T.90.M170 -19-29SEP99-2/2

Torque Values

00
0003
5

Unified Inch Bolt and Cap Screw Torque Values



Top—SAE Grade and Head Markings; Bottom—SAE Grade and Nut Markings

UNIFIED INCH BOLT AND CAP SCREW TORQUE VALUES—Tolerance is $\pm 10\%$ unless otherwise specified								
Thread Size	Grade 1 (No Mark)		Grade 2 ^a (No Mark)		Grade 5, 5.1 or 5.2		Grade 8 or 8.2	
	Lubricated ^b N•m (lb-ft)	Dry ^c N•m (lb-ft)	Lubricated ^b N•m (lb-ft)	Dry ^c N•m (lb-ft)	Lubricated ^b N•m (lb-ft)	Dry ^c N•m (lb-ft)	Lubricated ^b N•m (lb-ft)	Dry ^c N•m (lb-ft)
1/4	3.8 (2.8)	4.7 (3.5)	6 (4.4)	7.5 (5.5)	9.5 (7)	12 (9)	13.5 (10)	17 (12.5)
5/16	7.7 (5.7)	9.8 (7.2)	12 (9)	15.5 (11.5)	19.5 (14.5)	25 (18.5)	28 (20.5)	35 (26)
3/8	13.5 (10)	17.5 (13)	22 (16)	27.5 (20)	35 (26)	44 (32.5)	49 (36)	63 (46)
7/16	22 (16)	28 (20.5)	35 (26)	44 (32.5)	56 (41)	70 (52)	80 (59)	100 (74)
1/2	34 (25)	42 (31)	53 (39)	67 (49)	85 (63)	110 (80)	120 (88)	155 (115)
9/16	48 (35.5)	60 (45)	76 (56)	95 (70)	125 (92)	155 (115)	175 (130)	220 (165)
5/8	67 (49)	85 (63)	105 (77)	135 (100)	170 (125)	215 (160)	240 (175)	305 (225)
3/4	120 (88)	150 (110)	190 (140)	240 (175)	300 (220)	380 (280)	425 (315)	540 (400)
7/8	190 (140)	240 (175)	190 (140)	240 (175)	490 (360)	615 (455)	690 (510)	870 (640)
1	285 (210)	360 (265)	285 (210)	360 (265)	730 (540)	920 (680)	1030 (760)	1300 (960)
1-1/8	400 (300)	510 (375)	400 (300)	510 (375)	910 (670)	1150 (850)	1450 (1075)	1850 (1350)
1-1/4	570 (420)	725 (535)	570 (420)	725 (535)	1280 (945)	1630 (1200)	2050 (1500)	2600 (1920)
1-3/8	750 (550)	950 (700)	750 (550)	950 (700)	1700 (1250)	2140 (1580)	2700 (2000)	3400 (2500)
1-1/2	990 (730)	1250 (930)	990 (730)	1250 (930)	2250 (1650)	2850 (2100)	3600 (2650)	4550 (3350)

^a Grade 2 applies for hex cap screws (not hex bolts) up to 6 in. (152 mm) long. Grade 1 applies for hex cap screws over 6 in. (152 mm) long, and for all other types of bolts and screws of any length.

^b "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings.

^c "Dry" means plain or zinc plated without any lubrication.

DO NOT use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.

Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.

Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.

Make sure fastener threads are clean and that you properly start thread engagement. This will prevent them from failing when tightening.

Tighten plastic insert or crimped steel-type lock nuts to approximately 50 percent of the dry torque shown in the chart, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value.

TOR01A -UN-27SEP99

00
0003
6

Check Oil Lines And Fittings

⚠ CAUTION: Escaping fluid under pressure can penetrate the skin causing serious injury. Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure. Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.


If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury may call the Deere & Company Medical Department in Moline, Illinois, or other knowledgeable medical source.

Check all oil lines, hoses, and fittings regularly for leaks or damage. Make sure all clamps are in position and tight. Make sure hoses are not twisted or touching moving machine parts. If abrasion or wear occurs, replace immediately.

Tubing with dents may cause the oil to overheat. If you find tubing with dents, install new tubing immediately.

IMPORTANT: Tighten fittings as specified in torque chart.

When you tighten connections, use two wrenches to prevent bending or breaking tubing and fittings.




X9811 -UN-08DEC08

TX,90,DH1559 -19-01AUG94-1/1

Service Recommendations for 37° Flare and 30° Cone Seat Connectors

1. Inspect flare and flare seat. They must be free of dirt or obvious defects.
2. Defects in tube flare cannot be repaired. Overtightening a defective flared fitting will not stop leaks.
3. Align tube with fitting before attempting to start nut.
4. Lubricate male threads with hydraulic fluid or petroleum jelly.
5. Index angle fittings and tighten by hand.
6. Tighten fitting or nut to torque value shown on torque chart. Do not allow hoses to twist when tightening fittings.



T6234AC -JUN-18OCT88

STRAIGHT FITTING OR SPECIAL NUT TORQUE CHART		
Thread Size	N•m	lb-ft
3/8 - 24 UNF	8	6
7/16 - 20 UNF	12	9
1/2 - 20 UNF	16	12
9/16 - 18 UNF	24	18
3/4 - 16 UNF	46	34
7/8 - 14 UNF	62	46
1-1/16 - 12 UN	102	75
1-3/16 - 12 UN	122	90
1-5/16 - 12 UN	142	105
1-5/8 - 12	190	140
1-7/8 - 12 UN	217	160

NOTE: Torque tolerance is $\pm 10\%$.


T82,BHMA,EL -19-29SEP99-1/1

00
0003
8

Service Recommendations for O-Ring Boss Fittings

Straight Fitting

1. Inspect O-ring boss seat for dirt or defects.
2. Lubricate O-ring with petroleum jelly. Place electrical tape over threads to protect O-ring. Slide O-ring over tape and into O-ring groove of fitting. Remove tape.
3. Tighten fitting to torque value shown on chart.



T6243AE -JUN-18OCT88

Continued on next page

04T,90,K66 -19-29SEP99-1/2

Torque Values


00
0003
9

Angle Fitting

1. Back-off lock nut (A) and back-up washer (B) completely to head-end (C) of fitting.
2. Turn fitting into threaded boss until back-up washer contacts face of boss.
3. Turn fitting head-end counterclockwise to proper index (maximum of one turn).

NOTE: Do not allow hoses to twist when tightening fittings.

4. Hold fitting head-end with a wrench and tighten locknut and back-up washer to proper torque value.



T6620AB -JUN-19OCT88

STRAIGHT FITTING OR SPECIAL NUT TORQUE CHART

Thread Size	N•m	lb-ft
3/8-24 UNF	8	6
7/16-20 UNF	12	9
1/2-20 UNF	16	12
9/16-18 UNF	24	18
3/4-16 UNF	46	34
7/8-14 UNF	62	46
1-1/16-12 UN	102	75
1-3/16-12 UN	122	90
1-5/16-12 UN	142	105
1-5/8-12 UN	190	140
1-7/8-12 UN	217	160

NOTE: Torque tolerance is $\pm 10\%$.

04T,90,K66 -19-29SEP99-2/2

Torque Values

00
0003
10

Service Recommendations For Flat Face O-Ring Seal Fittings

1. Inspect the fitting sealing surfaces and O-ring. They must be free of dirt or defects. fittings, use backup wrench on straight hose couplings.
2. Lubricate O-rings and install into groove using petroleum jelly to hold in place. **IMPORTANT: Tighten fittings to 150% of listed torque value if indexing is necessary or if fitting is attached to an actuating devise.**
3. Index angle fittings and tighten by hand pressing joint together to insure O-ring remains in place. **Tighten fittings to 50% of listed torque value if used in aluminum housing.**
4. Tighten fitting or nut to torque value shown on the chart. Do not allow hoses to twist when tightening


FLAT FACE O-RING SEAL FITTING TORQUE*						
Nomial Tube O.D.		Thread Size	Swivel Nut		Bulkhead Nut	
mm	in.	in.	N•m	lb-ft	N•m	lb-ft
6.35	0.250	9/16-18	16	12	12	9
9.52	0.375	11/16-16	24	18	24	18
12.70	0.500	13/16-16	50	37	46	34
15.88	0.625	1-14	69	51	62	46
19.05	0.750	1 3/16-12	102	75	102	75
22.22	0.875	1 3/16-12	102	75	102	75
25.40	1.000	1 7/16-12	142	105	142	105
31.75	1.250	1 11/16-12	190	140	190	140
38.10	1.500	2-12	217	160	217	160

*Torque tolerance is +15 -20% unless otherwise specified.

Stud End O-ring Seal Torque for Straight and Adjustable Fittings*				
Thread Size	Straight Hex Size	Locknut Hex Size	Straight Fitting or Locknut Toque	
Inch	Inch	Inch	N•m	lb-ft
3/8-24	5/8	9/16	12	9
7/16-20	5/8	5/8	21	15
1/2-20	3/4	11/16	26	19
9/16-18	3/4	3/4	34	25
3/4-16	7/8	15/16	73	55
7/8-14	1 1/16	1 1/16	104	76
1 1/16-12	1 1/4	1 3/8	176	130
1 3/16-12	1 3/8	1 1/2	230	170
1 5/16-12	1 1/2	1 5/8	285	210

*Torque tolerance is +15 -20% unless otherwise specified.

Service Recommendations for Metric Series Four Bolt Flange Fitting



A—Sealing Surface

B—Split Flange

C—Pinched O-Ring

D—Single Piece Flange

1. Clean sealing surfaces (A). Inspect. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If defects cannot be polished out, replace component.
2. Install the correct O-ring (and backup washer if required) into groove using petroleum jelly to hold it in place.
3. Split flange: Loosely assemble split flange (B) halves. Make sure split is centrally located and perpendicular to the port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring (C).
4. Single piece flange (D): Place hydraulic line in center of flange and install four cap screws. Flange must be centrally located on port. Hand tighten cap screws to hold flange in place. Do not pinch O-ring.
5. After components are properly positioned and cap screws are hand tightened, tighten one cap screw,

then tighten the diagonally opposite cap screw. Tighten two remaining cap screws. Tighten all cap screws as specified in the chart below.

DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT over tighten.

TORQUE CHART ^a		
Thread ^b	N•m	lb-ft
M6	12	9
M8	30	22
M10	57	42
M12	95	70
M14	157	116
M16	217	160
M18	334	246
M20	421	318


^aTolerance $\pm 10\%$. The torques given are enough for the given size connection with the recommended working pressure. Increasing cap screw torque beyond these amounts will result in flange and cap screw bending and connection failures.

^bMetric standard thread.

T6890BB -JUN-01MARGO

00
0003
12

Service Recommendations For Inch Series Four Bolt Flange Fittings



A—Sealing Surface B—Split Flange C—Pinched O-Ring D—Single Piece Flange

1. Clean sealing surfaces (A). Inspect. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If defects cannot be polished out, replace component.
2. Install O-ring (and backup washer if required) into groove using petroleum jelly to hold it in place.
3. Split flange: Loosely assemble split flange (B) halves. Make sure split is centrally located and perpendicular to port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring (C).
4. Single piece flange (D): Place hydraulic line in center of flange and install cap screws. Flange must be centrally located on port. Hand tighten cap screws to hold flange in place. Do not pinch O-ring.
5. Tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten two remaining cap screws. Tighten all cap screws as specified in the chart below.

DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT over tighten.

TORQUE CHART					
Nominal Flange Size	Cap Screw Size	N•m		lb-ft	
		Min	Max	Min	Max
1/2	5/16-18 UNC	20	31	15	23
3/4	3/8-16 UNC	28	54	21	40
1	3/8-16 UNC	37	54	27	40
1-1/4	7/16-14 UNC	47	85	35	63
1-1/2	1/2-13 UNC	62	131	46	97
2	1/2-13 UNC	73	131	54	97
2-1/2	1/2-13 UNC	107	131	79	97
3	5/8-11 UNC	158	264	117	195
3-1/2	5/8-11 UNC	158	264	117	195
4	5/8-11 UNC	158	264	117	195
5	5/8-11 UNC	158	264	117	195

T6890BB -UN-01MAR90

Section 01 Wheels

Contents

Page

Group 110—Powered Wheels and Fastenings

Wheel Remove and Install01-110-1
Tire Remove and Install01-110-3
Dual Wheel Installation01-110-5

01

Contents

01

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com