

**1023E and 1025R
Compact Utility Tractors
(Serial No. NP000001-)
(North America)**



JOHN DEERE

OPERATOR'S MANUAL

**1023E, 1025R Compact Utility
Tractors (North America)**

OMTR122816 ISSUE E2 (ENGLISH)

CALIFORNIA

Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

If this product contains a gasoline engine:

⚠ WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

The State of California requires the above two warnings.

Additional Proposition 65 Warnings can be found in this manual.

John Deere Augusta Works
North America Edition
PRINTED IN U.S.A.



* D C Y *



* 0 M T R 1 2 2 8 1 6 *

Introduction

Foreword

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages. (See your John Deere dealer to order.)

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction of forward travel.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I. N.) in the Specification or Identification Numbers section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate or statement which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

THE TIRE MANUFACTURER'S warranty supplied with your machine may not apply outside the U.S.

If you are not the original owner of this machine, it is in your interest to contact your local John Deere dealer to inform them of this unit's serial number. This will help John Deere notify you of any issues or product improvements.

Contents

	Page		Page
General Information			
Product View	00-1	Transport Tractor Safely	00A-16
Trademarks	00-1	Service Cooling System Safely	00A-16
Glossary of Terms	00-2	Service Accumulator Systems Safely	00A-17
Regions and Country Versions	00-2	Service Tires Safely	00A-17
Machine Overview	00-3	Service Front-Wheel Drive Tractor Safely	00A-17
Safety			
Recognize Safety Information	00A-1	Tightening Wheel Retaining Bolts/Nuts	00A-17
Understand Signal Words	00A-1	Avoid High-Pressure Fluids	00A-18
Follow Safety Instructions	00A-1	Do Not Open High-Pressure Fuel System	00A-18
Prepare for Emergencies	00A-1	Store Attachments Safely	00A-18
Wear Protective Clothing	00A-2	Decommissioning — Proper Recycling and Disposal of Fluids and Components	00A-18
Protect Against Noise	00A-2	Safety Signs	
Handle Fuel Safely—Avoid Fires	00A-2	Replace Safety Signs	00B-1
Handle Starting Fluid Safely	00A-2	Use Seat Belt Properly - OOS	00B-1
Fire Prevention	00A-3	Use Seat Belt Properly - Cab	00B-2
In Case of Fire	00A-3	Operator's Manual	00B-2
Avoid Static Electricity Risk When Refueling	00A-4	Folding ROPS	00B-3
Keep ROPS Installed Properly	00A-4	Canopy or Sunshade	00B-3
Use Foldable ROPS and Seat Belt Properly	00A-4	Rotating Blades	00B-3
Stay Clear of Rotating Drivelines	00A-5	PTO Shield	00B-4
Use Steps and Handholds Correctly	00A-5	Starter	00B-4
Read Operator's Manuals for ISOBUS		Controls and Instruments	
Controllers	00A-6	Front Console Controls	10-1
Use Seat Belt Properly	00A-6	Foot-Operated Controls	10-2
Operating the Tractor Safely	00A-6	Right-Hand Console Controls	10-3
Avoid Backover Accidents	00A-7	Left-Hand Console Controls	10-4
Limited Use in Forestry Operation	00A-7	Differential, MFWD, Rate-of-Drop, and Seat Controls	10-5
Operating the Loader Tractor Safely	00A-8	Instrument Control Panel	10-6
Keep Riders Off Machine	00A-8	Cab Controls (if Equipped)	10-7
Instructional Seat	00A-8	Engine Operation	
Use Safety Lights and Devices	00A-9	Operate Key Switch	20-1
Use a Safety Chain	00A-9	Operate Hand Throttle	20-1
Transport Towed Equipment at Safe Speeds	00A-9	Operate Fuel Shutoff Valve	20-1
Use Caution on Slopes, Uneven Terrain, and Rough Ground	00A-10	Start the Engine	20-1
Freeing a Mired Machine	00A-10	Cold Weather Starting Aids	20-2
Avoid Contact with Agricultural Chemicals	00A-11	Warm and Idle the Engine	20-2
Handle Agricultural Chemicals Safely	00A-11	To Start a Stalled Engine	20-3
Handling Batteries Safely	00A-12	Stop Engine	20-3
Avoid Heating Near Pressurized Fluid Lines	00A-13	Air Intake, Fuel, Coolant, and Exhaust Operation	
Remove Paint Before Welding or Heating	00A-13	Fill the Fuel Tank	30-1
Handle Electronic Components and Brackets Safely	00A-13	Use Fuel Gauge	30-1
Practice Safe Maintenance	00A-14	Electrical and Lighting Operation	
Avoid Hot Exhaust	00A-14	Use Light Switch	40-1
Clean Exhaust Filter Safely	00A-14	Use Turn Signal Switch	40-1
Work In Ventilated Area	00A-15		
Support Machine Properly	00A-15		
Prevent Machine Runaway	00A-16		
Park Machine Safely	00A-16		

Continued on next page

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

Contents

	Page		Page
Work Light (If Equipped)	40-1	Tire Combinations	80-3
Beacon Light (If Equipped)	40-1	Front and Rear Tire Capacity	80-3
Drivetrain Operation		Ballast	
Drive Machine	50-1	Ballast Machine	80A-1
Transmission Operation		Implement Codes	80A-1
Operate the Hydrostatic Transmission	50A-1	Use Optional Rear Cast Iron Wheel Weights	80A-1
Use Cruise Control (If Equipped)	50A-1	Use Optional Rear Ballast Box	80A-1
MFWD and Front Axle Operation		Use Liquid Weight in Tires	80A-1
Use Mechanical Front Wheel Drive (MFWD)	50B-1	Use Optional Front Weights	80A-2
Differential and Rear Axle Operation		Additional Equipment Operation	
Use Differential Lock (Traction Assist)	50C-1	Additional Equipment Operation	80B-1
Power Take Off (PTO) Operation		Operator Station Operation	
Stay Clear of Rotating Drivelines	50D-1	Enter and Exit Machine	90-1
Use the PTO Safely	50D-1	Adjust Seat	90-1
Check PTO Driveshaft Length	50D-2	Use Seat Belt	90-1
Operate Rear and Mid PTO (Operator on Seat)	50D-2	Raise and Lower ROPS	90-1
Operate Rear PTO (Operator off Seat)	50D-3	Doors	90-2
Operate Reverse Implement Option (RIO)	50D-4	Windows	90-2
Adjust Height-of-Cut (If Equipped)	50D-4	Cab Heater Control	90-3
Steering and Brake Operation		Front Windshield Wiper	90-3
Operate Brake Pedal	60-1	Rear Windshield Wiper (If Equipped)	90-4
Operate Park Brake	60-1	Transport and Storage	
Adjust Tilt Steering Wheel (If Equipped)	60-1	Transport Machine on Trailer	100-1
Hydraulics Operation		Transport Machine	100-1
Warm Hydraulic System Oil	70-1	Push or Tow Machine	100-1
Hydraulics Information	70-1	Tow Loads	100-2
Hitch and Drawbar Operation		Use Safety Chain	100-2
Operate Attachments	70A-1	Store Safety	100-2
Operate 3-Point Hitch	70A-1	Prepare Machine for Storage	100-2
Operate Rate-of-Drop	70A-1	Prepare Fuel and Engine for Storage	100-3
Use Draft Link and Center Link	70A-2	Remove Machine from Storage	100-3
Level Implement Front-to-Rear	70A-2	Maintenance Intervals	
Level Implement Side-to-Side	70A-2	Service Your Machine	200-1
Adjust Implement Side-to-Side Sway	70A-3	Service Interval Charts	200-1
Operate Rear Hitch	70A-3	Service Interval Charts	200-1
Use Front 3-Point Hitch (If equipped)	70A-3	Test the Safety Interlock System Before Startup	200-2
Operate Optional iMatch Quick-Attach Hitch System	70A-7	Avoid Damage to Plastic and Painted Surfaces	200-3
Selective Control Valve Operation		Clean Plastic Surfaces	200-3
Avoid High-Pressure Fluids	70B-1	Clean and Repair Metal Surfaces	200-4
Connect Implement Hydraulic Hoses	70B-1	Fuel, Lubricants, and Coolant	
Operate Hydraulic Dual Selective Control Valve (SCV)	70B-1	Diesel Fuel	200A-1
Operate Selective Control Valve (SCV) Lock Lever	70B-2	Handling and Storing Diesel Fuel	200A-1
Operate Third Function Selective Control Valve (If Equipped)	70B-2	Testing Diesel Fuel	200A-2
Wheels and Tires Operation		Minimizing the Effect of Cold Weather on Diesel Engines	200A-2
Tire Labeling, Ascertain the Load Capacity of Tires	80-1	Alternative and Synthetic Lubricants	200A-3
Select Tire Inflation Pressure	80-2	Engine Oil	200A-3
		Diesel Engine Coolant	200A-3
		Operating in Warm Temperature Climates	200A-4
		Additional Information About Diesel Engine Coolants and John Deere COOL-GARD™ II Coolant Extender	200A-4
		Testing Diesel Engine Coolant	200A-5
		Transmission and Hydraulic Oil	200A-5
		Front Axle and MFWD Oil	200A-6

	Page		Page
Grease	200A-6	Power Take Off (PTO) Maintenance	
Maintenance—As Required		PTO Maintenance	250D-1
Service—As Required	200B-1	Steering and Brake Maintenance	
Controls and Instruments Maintenance		Steering Maintenance	260-1
Controls and Instruments Maintenance	210-1	Brake Maintenance	260-1
Engine Maintenance		Hydraulics Maintenance	
Daily Startup Procedure	220-1	Hydraulic Maintenance	270-1
Required Emission-Related Information	220-1	Hitch and Drawbar Maintenance	
Avoid Fumes	220-1	Lubricate 3-Point Hitch	270A-1
Check Engine Oil Level	220-1	Selective Control Valve Maintenance	
Change Engine Oil and Filter	220-2	Check Selective Control Valve	270B-1
Clean Dust Unloading Valve	220-3	Wheels and Tires Maintenance	
Service the Alternator Belt	220-3	Check Wheel Bolts and Hardware	280-1
Clean Front and Side Grille Screens	220-4	Remove and Install Wheels	280-1
Clean Engine Compartment	220-4	Check Tire Pressure	280-1
Air, Fuel, Coolant and Exhaust Maintenance		Tire Inflation Pressure Chart	280-1
Service Air Filter Elements	230-1	Select Front Tire Rolling Direction	280-2
Service Cab Air Filter	230-1	Lift Points for Jacking up the Tractor	280-2
Check Air Filter Hose	230-2	Ballast Maintenance	
Check and Drain Water Separator	230-2	Match Ballast to Work Load	280A-1
Replace Fuel Filter	230-3	Additional Equipment Maintenance	
Fuel Injection Pump	230-4	Additional Equipment Maintenance	280B-1
Fuel Injection Nozzles	230-4	Operator Station Maintenance	
Drain and Flush Fuel Tank	230-4	Raise and Lower Hood	290-1
Check Coolant Level	230-4	Remove and Install Side Panels	290-1
Drain and Flush Cooling System	230-4	Inspect ROPS for Loose Hardware	290-2
Fill Cooling System	230-5	Troubleshooting	
Check Radiator Hoses and Clamps	230-6	Engine	300-1
Clean Radiator, Fuel, and Transmission Cooling Fins	230-6	Electrical System	300-3
Electrical and Lighting Maintenance		Machine	300-4
Service Electrical	240-1	Brakes	300-6
Service the Battery Safely	240-1	Steering	300-6
Remove and Install Battery	240-1	On-Board Diagnostics	
Clean Battery and Terminals	240-2	Service Alert and Information Display	300A-1
Use Booster Battery	240-2	Specifications	
Replace Headlight Bulb	240-2	Engine Specifications	400-1
Replace Tail/Turn Light Bulb	240-3	Drivetrain Specifications	400-1
Replace Warning Light Bulb	240-3	Hydraulic System Specifications	400-1
Replace Fuses and Relays	240-4	Electrical System Specifications	400-2
Drivetrain Maintenance		Fluid Capacities	400-2
Drivetrain Maintenance	250-1	Ground Speeds	400-2
Transmission Maintenance		Dimensions	400-2
Check Transmission Oil Level	250A-1	Height from Ground	400-2
Change Transmission Oil and Filter	250A-1	Ground Clearance	400-3
Remove and Install Oil Suction Screen	250A-2	Turning Radius	400-3
MFWD and Front Axle Maintenance		Machine Weight	400-3
Check Front Axle Oil Level	250B-1	3-Point Hitch Specification	400-3
Change Front Axle Oil	250B-1	Coupling Devices	400-3
Lubricate MFWD Driveshaft	250B-2	How to Calculate Maximum Permissible Download on Trailer Hitch	400-4
Lubricate Main Driveshaft	250B-2	Differential and Rear Axle Maintenance	
Differential and Rear Axle Maintenance		Rear Axle	250C-1

Contents

Page

How to Calculate Permissible Mass	400-4
Unified Inch Bolt and Screw Torque Values	400-5
Metric Bolt and Screw Torque Values	400-6

Identification Numbers

Product Identification Information	400A-1
Record Identification Numbers	400A-1

Certification and Warranty

Product Warranty	400B-1
John Deere, California and U.S. EPA Emission Control System Warranty (Non- Road Diesel)	400B-1
Emission System Warranty	400B-3
Tire Warranty	400B-4
Limited Battery Warranty	400B-4

Service Records

Every 10 Hour or Daily Service	500-1
Every 50 Hour Service	500-1
Every 200 Hour Service	500-1
Every 400 Hour Service	500-2
Every 600 Hour Service	500-2
Yearly Service	500-2
Every 1000 Hour Service	500-2
Every 2000 Hour Service or Every Two Years ...	500-3
Every 6000 Hour Service or Every Six Years ...	500-3
Service as Required	500-3
Change of Ownership	500-4
Change of Ownership	500-4
Change of Ownership	500-5

General Information

Product View



Open Operator Station

LVP11888—UN—29JUN21

PR59899.000100A-19-29JUN21

Trademarks

Trademarks	
GreenStar™	Trademark of Deere & Company
iMatch™	Trademark of Deere & Company
Quik-Tatch™	Trademark of Deere & Company
Cool-Gard™	Trademark of Deere & Company
Cool-Gard™ II	Trademark of Deere & Company
Plus-50™	Trademark of Deere & Company
Torq-Gard™	Trademark of Deere & Company
Hy-Gard™	Trademark of Deere & Company


UP00731.00000CC-19-18NOV16

Glossary of Terms

Abbreviation	Description
MFWD	Mechanical Front-Wheel Drive
OBD	On-Board Diagnostic
PTO	Power Take-Off
RIO	Reverse Implement Option
ROPS	Roll-Over Protective Structure
SCV	Selective Control Valve

DN39857,000069D-19-18MAR22

Regions and Country Versions



RXA0150915—UN—01FEB16

R1—Asia and Sub-Saharan Africa
 R1A—Far East, Sri Lanka, and Pakistan
 R1B—China
 R1C—India
 R1D—Sub-Saharan Africa
 R2—Europe, North Africa, Mid East, CIS
 R2A—European Union (EU 28+)
 R2B—North Africa and North Middle East (NANME)
 R2C—Commonwealth of Independent States (CIS)

R3—Central and South America
 R3A—Latin America (JDLA)
 R3B—Brazil
 R3C—Mexico
 R3D—Argentina
 R4—North America
 R4A—USA and Canada
 R4B—Oceania (Australia and New Zealand)

Regions 1, 2 and 3 equipment is traditionally manufactured with Economic Commission for Europe (ECE) features or systems.

Region 4 equipment is traditionally manufactured with Society of Automotive Engineers (SAE) features or systems.

Drive and signal lighting, traffic signs, safety signs, and braking features are some of the systems that differ between ECE and SAE. For example, Text-Free (pictorial only) safety signs are used for ECE while Text with Picture safety signs are used on SAE. When identifying equipment information by regions, countries, trade federations, industry standards, or governmental regulations, refer to the region map provided.


NOTE: Australia and New Zealand (R4B) are available as either region 4 and/or region 2 configurations, only using text-free safety signs.

GS25068,0001DB8-19-14JAN19

Machine Overview

IMPORTANT: READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may be available in other languages. See your John Deere dealer for specific language requirements and to place an order.)

Review manual sections for Controls and Instruments identification, Steering and Brakes, Transmission, and Transportation before operation on the road or in the field.



A—Front Console Controls
B—Right Side Controls

C—Rear Implement Interface
D—Left Side Controls

LV27367—UN—06FEB17

Operating the Machine Introduction:

See relevant section in the operator manual for operating procedures.

- Sit in the operator seat and fasten seat belt.
- Start engine.
- Turn on lights or signals as required.
- To move machine, operate the transmission.
- Use steering and brakes as required.
- Activate features and implements as required.

Preliminary Overview

Inspect the machine before operation, use the following list as a reminder. Detailed operation and service information is available in this operator manual.

- Review manual and machine for safety information and safety signs.
- Review manual for proper operation, adjustment, and service.
- Review manual for engine and drivetrain operations. (throttles, brakes, steering, transmission gears, MFWD, and Differential Lock.)
- Review manual for control devices (hitch, hydraulic, and electrical).
- Review manual for regular lubrication points and intervals.
- Check for visual signs of leaks, damage, failures, and flats.
- Prepare machine hardware, fuel, fluids, lubricants, air, and daily maintenance.
- Check and prepare implements or attachments according to implement or attachment operator manuals.

Using this Manual:


The information provided in this manual is divided into sections. The sections are organized with the typical machine features or functional systems together. These sections are identified at the top of each page. Specific information within each section is organized into modules. These modules are enclosed in boxes and the main modules are identified with a heading at the top left. Page numbers identify the section as well as the number of the page in the section.

By reviewing this manual frequently you learn which section to turn to for specific information. For example, the safety information is covered at the beginning, the operation of all features and systems is covered in the first half of the manual. Maintenance intervals are in the middle of the manual, the maintenance of all the features and systems is covered in the second half of the manual. The specifications are covered at the end.

A detailed table of contents appears before safety

information and there is an alphabetical index at the very end of the manual.

The Operator's Manual content flows as sequential reading down one column of text and graphic then over to the top of the next column as shown.



W28329—UN—18OCT17
UP00731.0000570-19-16APR18

Safety

Recognize Safety Information



T81389—UN—28JUN13

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.

DX,ALERT-19-29SEP98

Follow Safety Instructions



TS201—UN—15APR13

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.

DX,READ-19-16JUN09

Understand Signal Words



▲ WARNING

▲ CAUTION

TS187—19—30SEP88

DANGER; The signal word DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.


WARNING; The signal word WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION; The signal word CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury. CAUTION may also be used to alert against unsafe practices associated with events which could lead to personal injury.

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards. DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

DX,SIGNAL-19-05OCT16

Prepare for Emergencies



TS291—UN—15APR13


Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.

DX,FIRE2-19-03MAR93

Wear Protective Clothing



TS206—UN—15APR13

Wear close fitting clothing and safety equipment appropriate to the job.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.

DX.WEAR2-19-03MAR93

Handle Fuel Safely—Avoid Fires



TS202—UN—23AUG88

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.


Use only an approved fuel container for transporting flammable liquids.

Never fill fuel container in pickup truck with plastic bed liner. Always place fuel container on ground before refueling. Touch fuel container with fuel dispenser nozzle before removing can lid. Keep fuel dispenser nozzle in contact with fuel container inlet when filling.

Do not store fuel container where there is an open flame, spark, or pilot light such as within a water heater or other appliance.

DX.FIRE1-19-12OCT11

Protect Against Noise



TS207—UN—23AUG88

There are many variables that affect the sound level range, including machine configuration, condition and maintenance level of the machine, ground surface, operating environmental, duty cycles, ambient noise, and attachments.

Exposure to loud noise can cause impairment or loss of hearing.

Always wear hearing protection. Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

DX.NOISE-19-03OCT17

Handle Starting Fluid Safely



TS1356—UN—18MAR92

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.

Do not use starting fluid on an engine equipped with glow plugs or an air intake heater.

DX,FIRE3-19-14MAR14

Fire Prevention

To reduce the risk of fire, your tractor should be regularly inspected and cleaned.

- Birds and other animals may build nests or bring other flammable materials into the engine compartment or onto the exhaust system. The tractor should be inspected and cleaned prior to the first use each day.
- A build up of grass, crop material and other debris may occur during normal operation. This is especially true when operating in very dry conditions or conditions where airborne crop material or crop dust is present. Any such build up must be removed to ensure proper machine function and to reduce the risk of fire. The tractor must be inspected and cleaned periodically throughout the day.
- Regular and thorough cleaning of the tractor combined with other routine maintenance procedures listed in the Operator's Manual greatly reduce the risk of fire and the chance of costly downtime.
- Do not store fuel container where there is an open flame, spark, or pilot light such as within a water heater or other appliance.
- Check fuel lines, tank, cap, and fittings frequently for damage, cracks or leaks. Replace if necessary.

Follow all operational and safety procedures posted on the machine and the Operator's Manual. Be careful of hot engine and exhaust components during inspection and cleaning. Before carrying out any inspection or cleaning, always shut OFF the engine, place the transmission in PARK or set parking brake, and remove the key. Removal of the key will prevent others from starting the tractor during inspection and cleaning.

DX,WW,TRACTOR,FIRE,PREVENTION-19-12OCT11

In Case of Fire



TS227—UN—15APR13

CAUTION: Avoid personal injury.

Stop machine immediately at the first sign of fire. Fire may be identified by the smell of smoke or sight of flames. Because fire grows and spreads rapidly, get off the machine immediately and move safely away from the fire. Do not return to the machine! The number one priority is safety.

Call the fire department. A portable fire extinguisher can put out a small fire or contain it until the fire department arrives; but portable extinguishers have limitations. Always put the safety of the operator and bystanders first. If attempting to extinguish a fire, keep your back to the wind with an unobstructed escape path so you can move away quickly if the fire cannot be extinguished.

Read the fire extinguisher instructions and become familiar with their location, parts, and operation before a fire starts. Local fire departments or fire equipment distributors may offer fire extinguisher training and recommendations.

If your extinguisher does not have instructions, follow these general guidelines:


1. Pull the pin. Hold the extinguisher with the nozzle pointing away from you, and release the locking mechanism.
2. Aim low. Point the extinguisher at the base of the fire.
3. Squeeze the lever slowly and evenly.
4. Sweep the nozzle from side-to-side.

DX,FIRE4-19-22AUG13

Avoid Static Electricity Risk When Refueling



RG22142—UN—17MAR14



RG21992—UN—21AUG13

The removal of sulfur and other compounds in Ultra-Low Sulfur Diesel (ULSD) fuel decreases its conductivity and increases its ability to store a static charge.


Refineries may have treated the fuel with a static dissipating additive. However, there are many factors that can reduce the effectiveness of the additive over time.

Static charges can build up in ULSD fuel while it is flowing through fuel delivery systems. Static electricity discharge when combustible vapors are present could result in a fire or explosion.

Therefore, it is important to ensure that the entire system used to refuel your machine (fuel supply tank, transfer pump, transfer hose, nozzle, and others) is properly grounded and bonded. Consult with your fuel or fuel system supplier to ensure that the delivery system is in compliance with fueling standards for proper grounding and bonding practices.

DX,FUEL,STATIC,ELEC-19-12JUL13

Keep ROPS Installed Properly



TS212—UN—23AUG88

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.


The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.

The seat is part of the ROPS safety zone. Replace only with John Deere seat approved for your tractor.

Any alteration of the ROPS must be approved by the manufacturer.

DX,ROPS3-19-12OCT11

Use Foldable ROPS and Seat Belt Properly



TS1729—UN—24MAY13

Avoid crushing injury or death during rollover.

- If this machine is equipped with a foldable rollover protective structure (ROPS), keep the ROPS in the fully extended and locked position. USE a seat belt when you operate with a ROPS in the fully extended position.
 - Hold the latch and pull the seat belt across the body.
 - Insert the latch into the buckle. Listen for a click.
 - Tug on the seat belt to make sure that the belt is securely fastened.


- Snug the seat belt across the hips.
- If this machine is operated with the ROPS folded (for example, to enter a low building), drive with extreme caution. DO NOT USE a seat belt with the ROPS folded.
- Return the ROPS to the raised, fully extended position as soon as the machine is operated under normal conditions.

DX,FOLDROPS-19-22AUG13

Stay Clear of Rotating Drivelines



TS1644—UN—22AUG95



H96219—UN—29APR10

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Only use power take-off driveshafths with adequate guards and shields.

Wear close fitting clothing. Stop the engine and be sure that PTO driveline is stopped before making

adjustments, connections, or cleaning out PTO driven equipment.

Do not install any adapter device between the tractor and the primary implement PTO driveshaft that will allow a 1000 rpm tractor shaft to power a 540 rpm implement at speeds higher than 540 rpm.

Do not install any adapter device that results in a portion of the rotating implement shaft, tractor shaft, or the adapter to be unguarded. The tractor master shield shall overlap the end of the splined shaft and the added adaptor device as outlined in the table.

The angle at which the primary implement PTO driveshaft can be inclined may be reduced depending on the shape and size of the tractor master shield and the shape and size of the guard of the primary implement PTO driveshaft.


Do not raise implements high enough to damage the tractor master shield or guard of primary implement PTO driveshaft. Detach the PTO driveline shaft if it is necessary to increase implement height. (See Attching/ Detaching PTO Driveline)

When using Type 3/4 PTO, inclination and turning angles may be reduced depending on type of PTO master shield and coupling rails.

PTO Type	Diameter	Splines	n ± 5 mm (0.20 in.)
1	35 mm (1.378 in.)	6	85 mm (3.35 in.)
2	35 mm (1.378 in.)	21	85 mm (3.35 in.)
3	45 mm (1.772 in.)	20	100 mm (4.00 in.)
4	57.5 mm (2.264 in.)	22	100 mm (4.00 in.)

DX,PTO-19-28FEB17

Use Steps and Handholds Correctly



T133468—UN—15APR13

Prevent falls by facing the machine when getting on and off. Maintain 3-point contact with steps, handholds, and handrails.

Use extra care when mud, snow, or moisture present slippery conditions. Keep steps clean and free of grease

or oil. Never jump when exiting machine. Never mount or dismount a moving machine.

DX,WW,MOUNT-19-12OCT11


Read Operator's Manuals for ISOBUS Controllers

In addition to GreenStar™ Applications, this display can be used as a display device for any ISOBUS Controller that meets ISO 11783 standard. This includes capability to control ISOBUS implements. When used in this manner, information and control functions placed on the display are provided by the ISOBUS Controller and are the responsibility of the ISOBUS Controller manufacturer. Some of these functions could pose a hazard to either the operator or a bystander. Read the Operator's Manual provided by the ISOBUS Controller manufacturer and observe all safety messages in manual and on ISOBUS Controller product prior to use.

NOTE: ISOBUS refers to the ISO Standard 11783

DX,WW,ISOBUS-19-15JUL15

Use Seat Belt Properly



TS1729—UN—24MAY13

Avoid crushing injury or death during rollover.

This machine is equipped with a rollover protective structure (ROPS). USE a seat belt when you operate with a ROPS.

- Hold the latch and pull the seat belt across the body.
- Insert the latch into the buckle. Listen for a click.
- Tug on the seat belt latch to make sure that the belt is securely fastened.
- Snug the seat belt across the hips.

Replace entire seat belt if mounting hardware, buckle, belt, or retractor show signs of damage.

Inspect seat belt and mounting hardware at least once a year. Look for signs of loose hardware or belt damage,

such as cuts, fraying, extreme or unusual wear, discoloration, or abrasion. Replace only with replacement parts approved for your machine. See your John Deere dealer.

DX,ROPS1-19-22AUG13

Operating the Tractor Safely

You can reduce the risk of accidents by following these simple precautions:

- Use your tractor only for jobs it was designed to perform, for example, pushing, pulling, towing, actuating, and carrying a variety of interchangeable equipment designed to conduct agricultural work.
- Operators must be mentally and physically capable of accessing the operator's station and/or controls, and operating the machine properly and safely.
- Never operate machine when distracted, fatigued, or impaired. Proper machine operation requires the operator's full attention and awareness.
- This tractor is not intended to be used as a recreational vehicle.
- Read this operator's manual before operating the tractor and follow operating and safety instructions in the manual and on the tractor.
- Follow operation and ballasting instructions found in the operator's manual for your implements/ attachments, such as front loaders.
- Follow the instructions outlined in the operator's manual of any mounted or trailed machinery or trailer. Do not operate a combination of tractor-machine or tractor-trailer unless all instructions have been followed.
- Make sure that everyone is clear of machine, attached equipment, and work area before starting engine or operation.
- Stay clear of the three-point linkage and pickup hitch (if equipped) when controlling them.
- Keep hands, feet, and clothing away from power-driven parts.

Driving Concerns

- Never get on or off a moving tractor.
- Complete any required training prior to operating vehicle.
- Keep all children and nonessential personnel off tractors and all equipment.
- Never ride on a tractor unless seated on a John Deere approved seat with a seat belt.
- Keep all shields/guards in place.
- Use appropriate visual and audible signals when operating on public roads.
- Move to side of road before stopping.
- Reduce speed when turning, applying individual

brakes, or operating around hazards on rough ground or steep slopes.

- Stability degrades when attached implements are at high position.
- Couple brake pedals together for road travel.
- Pump brakes when stopping on slippery surfaces.
- Regularly clean fenders and fender valances (mud flaps) if installed. Remove dirt before driving on public roadways.

Heated and Ventilated Operator's Seat

- An overheated seat heater can cause a burn injury or damage to the seat. To reduce the risk of burns, use caution when using the seat heater for extended periods of time, especially if the operator cannot feel temperature change or pain to the skin. Do not place objects on the seat, such as a blanket, cushion, cover, or similar item, which can cause the seat heater to overheat.

Towing Loads

- Be careful when towing and stopping heavy loads. Stopping distance increases with speed and weight of towed loads, and on slopes. Towed loads with or without brakes that are too heavy for the tractor or are towed too fast can cause loss of control.
- Consider the total weight of the equipment and its load.
- Hitch towed loads only to approved couplings to avoid rearward upset.

Parking and Leaving the Tractor

- Before dismounting, shut off SCVs, disengage PTO, stop engine, lower implements/attachments to ground, place implement/attachment control devices in neutral, and securely engage park mechanism, including the park pawl and park brake. In addition, if the tractor is left unattended, remove key.
- Leaving transmission in gear with engine off will NOT prevent the tractor from moving.
- Never go near an operating PTO or an operating implement.
- Wait for all movement to stop before servicing machinery.

Common Accidents

Unsafe operation or misuse of the tractor can result in accidents. Be alert to hazards of tractor operation.

The most common accidents involving tractors are:

- Tractor rollover
- Collisions with motor vehicles
- Improper starting procedures
- Entanglement in PTO shafts
- Falling from tractor

- Crushing and pinching during hitching

DX,WW,TRACTOR-19-08MAY19

Avoid Backover Accidents



PC10857XW—UN—15APR13

Before moving machine, be sure that all persons are clear of machine path. Turn around and look directly for best visibility. Use a signal person when backing if view is obstructed or when in close quarters.

Do not rely on a camera to determine if personnel or obstacles are behind the machine. The system can be limited by many factors including maintenance practices, environmental conditions, and operating range.

DX,AVOID,BACKOVER,ACCIDENTS-19-30AUG10


Limited Use in Forestry Operation

The intended use of John Deere tractors when used in forestry operations is limited to tractor-specific applications like transport, stationary work such as log splitting, propulsion, or operating implements with PTO, hydraulic, or electrical systems.

These are applications where normal operation does not present a risk of falling or penetrating objects. Any forestry applications beyond these applications, such as forwarding and loading, requires fitment of application-specific components including Falling Object Protective Structure (FOPS) and/or Operative Protective Structures (OPS). Contact John Deere dealer for special components.

DX,WW,FORESTRY-19-12OCT11

Operating the Loader Tractor Safely



TS1692—UN—09NOV09

When operating a machine with a loader application, reduce speed as required to ensure good tractor and loader stability.

To avoid tractor rollover and damage to front tires and tractor, do not carry load with your loader at a speed over 10 km/h (6 mph).

To avoid tractor damage do not use a front loader or a sprayer tank if the tractor is equipped with a 3 Meter Front Axle.

Never allow anyone to walk or work under a raised loader.

Do not use loader as a work platform.

Do not lift or carry anyone on loader, in bucket, or on implement or attachment.


Lower loader to ground before leaving operators station.

The Rollover Protective Structure (ROPS) or cab roof, if equipped, may not provide sufficient protection from load falling onto the operators station. To prevent loads from falling onto the operators station, always use appropriate implements for specific applications (that is, manure forks, round bale forks, round bale grippers, and clammers).

Ballast tractor in accordance to Ballast Recommendations in PREPARE TRACTOR section.

DX,WW,LOADER-19-18SEP12

Keep Riders Off Machine



TS290—UN—23AUG88

Only allow the operator on the machine. Keep riders off.

Riders on machine are subject to injury such as being struck by foreign objects and being thrown off of the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.

DX,RIDER-19-03MAR93

Instructional Seat




TS1730—UN—24MAY13

The instructional seat, if so equipped, has been provided only for training operators or diagnosing machine problems.

DX,SEAT,NA-19-22AUG13

Use Safety Lights and Devices




TS951—UN—12APR90

Prevent collisions between other road users, slow moving tractors with attachments or towed equipment, and self-propelled machines on public roads. Frequently check for traffic from the rear, especially in turns, and use turn signal lights.

Use headlights, flashing warning lights, and turn signals day and night. Follow local regulations for equipment lighting and marking. Keep lighting and marking visible, clean, and in good working order. Replace or repair lighting and marking that has been damaged or lost. An implement safety lighting kit is available from your John Deere dealer.

DX.FLASH-19-07JUL99

Use a Safety Chain



TS217—UN—23AUG88

A safety chain will help control drawn equipment should it accidentally separate from the drawbar.


Using the appropriate adapter parts, attach the chain to the tractor drawbar support or other specified anchor location. Provide only enough slack in the chain to permit turning.

See your John Deere dealer for a chain with a strength

rating equal to or greater than the gross weight of the towed machine. Do not use safety chain for towing.

DX.CHAIN-19-03MAR93

Transport Towed Equipment at Safe Speeds



TS1686—UN—27SEP06

Do not exceed the maximum transport speed. This towing unit may be capable of operating at transport speeds that exceed the maximum allowable transport speed for towed implements.

Before transporting a towed implement, determine from signs on the implement or information provided in the implement's operator manual the maximum transport speed. Never transport at speeds that exceed the implement's maximum transport speed. Exceeding the implement's maximum transport speed can result in:

- Loss of control of the towing unit/implement combination
- Reduced or no ability to stop during braking
- Implement tire failure
- Damage to the implement structure or its components

Implements shall be equipped with brakes if the maximum fully loaded weight is greater than 1500 kg (3307 lbs) and greater than 1.5 times the weight of the towing unit.

Example: Implement mass is 1600 kg (3527 lbs) and towing unit mass is 1600 kg (3527 lbs), example implement is not required to have brakes.

Implements without brakes: Do not transport at speeds greater than 32 km/h (20 mph).


Implements with brakes:

- If the manufacturer does not specify a maximum transport speed, do not tow at speeds greater than 40 km/h (25 mph).
- When transporting at speeds up to 40 km/h (25 mph) the fully loaded implement must weigh less than 4.5 times the towing unit weight.
- When transporting at speeds between 40—50 km/h (25—31 mph) the fully loaded implement must weigh less than 3.0 times the towing unit weight.

When towing a trailer, become familiar with the braking characteristics and ensure the compatibility of the tractor/trailer combination in regard to the deceleration rate.

DX,TOW1-19-28FEB17

Use Caution on Slopes, Uneven Terrain, and Rough Ground



RXA0103437—UN—01JUL09

Avoid holes, ditches, and obstructions which cause the tractor to tip, especially on slopes. Avoid sharp uphill turns.

Driving forward out of a ditch, mired condition, or up a steep slope could cause the tractor to tip over rearward. Back out of these situations if possible.

Danger of overturn increases greatly with narrow tread setting, at high speed.

Not all conditions that can cause a tractor to overturn are listed. Be alert for any situation in which stability may be compromised.

Slopes are a major factor related to loss-of-control and tip-over accidents, which can result in severe injury or death. Operation on all slopes requires extra caution.

Uneven terrain or rough ground can cause loss-of-control and tip-over accidents, which can result in severe injury or death. Operation on uneven terrain or rough ground requires extra caution.

Never drive near the edge of a gully, drop-off, ditch, steep embankment, or a body of water. The machine could suddenly roll over if a wheel goes over the edge or the ground caves in


Choose a low ground speed so you will not have to stop or shift while on a slope.

Avoid starting, stopping, or turning on a slope. If the tires lose traction, disengage the PTO and proceed slowly, straight down the slope.

Keep all movement on slopes slow and gradual. Do not make sudden changes in speed or direction, which could cause the machine to roll over.

DX,WW,SLOPE-19-28FEB17

Freeing a Mired Machine



TS1645—UN—15SEP95



TS263—UN—23AUG88

Attempting to free a mired machine can involve safety hazards such as the mired tractor tipping rearward, the towing tractor overturning, and the tow chain or tow bar (a cable is not recommended) failing and recoiling from its stretched condition.

Back your tractor out if it gets mired down in mud. Unhitch any towed implements. Dig mud from behind the rear wheels. Place boards behind the wheels to provide a solid base and try to back out slowly. If necessary, dig mud from the front of all wheels and drive slowly ahead.

If necessary to tow with another unit, use a tow bar or a long chain (a cable is not recommended). Inspect the chain for flaws. Make sure all parts of towing devices are of adequate size and strong enough to handle the load.

Always hitch to the drawbar of the towing unit. Do not

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com