

644J Loader Operation and Test

(Serial No. 611232-)

TECHNICAL MANUAL 644J Loader Operation and Test (S.N. 611232—)

TM10231 14JAN08 (ENGLISH)

For complete service information also see:

644J Loader Repair Manual (S.N. 611232—)	TM10246
644J Loader Operator's Manual (S.N. 611232—)	OMT229851
Alternators and Starting Motors.....	CTM77
POWERTECH™ 4.5 L and 6.8 L Diesel Engines—Base Engine	CTM104
TeamMate™ IV 1200 and 1400 Series Inboard Planetary Axles	CTM442
POWERTECH Plus™ 4.5L & 6.8L Diesel Engines—Level 14 Electronic Fuel System With Denso HPCR	CTM320
Super Caddy Oil Cleanup Procedure	CTM310
JDLink™ / ZXLink™ Machine Monitoring System	CTM10006

Worldwide Construction
And Forestry Division

LITHO IN U.S.A

Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.



This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

TX,INTR,DU2141 -19-22MAR97-1/1

Introduction

Contents

SECTION 9000—General Information

Group 01—Safety Information

SECTION 9001—Diagnostic Trouble Codes (DTC)

Group 10—CAN Monitor Unit (CMU) Diagnostic Trouble Codes

Group 20—Engine Control Unit (ECU) Diagnostic Trouble Codes

Group 30—Transmission Control Unit (TCU) Diagnostic Trouble Codes

Group 40—Flex Load Controller (FLC) Diagnostic Trouble Codes

Group 50—Sealed Switch Module (SSM) Diagnostic Trouble Codes

SECTION 9005—Operational Checkout Procedure

Group 10—Operational Checkout Procedure

SECTION 9010—Engine

Group 05—Theory Of Operation

Group 15—Diagnostic Information

Group 25—Tests

SECTION 9015—Electrical System

Group 05—System Information

Group 10—System Diagrams

Group 15—Sub-System Diagnostics

Group 20—References

SECTION 9020—Power Train

Group 05—Theory of Operation

Group 15—Diagnostic Information

Group 20—Adjustments

Group 25—Tests

SECTION 9025—Hydraulic System

Group 05—Theory Of Operation

Group 15—Diagnostic Information

Group 20—Adjustments

Group 25—Test

SECTION 9031—Heating And Air Conditioning

Group 05—Theory Of Operation

Group 15—Diagnostic Information

Group 25—Tests

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2008
DEERE & COMPANY
Moline, Illinois
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright © 2007

9000

9001

9005

9010

9015

9020

9025

9031

INDX

Contents

9000

9001

9005

9010

9015

9020

9025

9031

INDX

Section 9000

General Information

Contents

	Page
Group 01—Safety Information	
Recognize Safety Information	9000-01-1
Follow Safety Instructions	9000-01-1
Operate Only If Qualified.	9000-01-2
Wear Protective Equipment.	9000-01-2
Avoid Unauthorized Machine	
Modifications	9000-01-2
Add Cab Guarding For Special Uses	9000-01-3
Inspect Machine	9000-01-3
Stay Clear of Moving Parts	9000-01-3
Avoid High-Pressure Fluids.	9000-01-4
Avoid High-Pressure Oils	9000-01-4
Beware of Exhaust Fumes	9000-01-5
Prevent Fires.	9000-01-5
Prevent Battery Explosions	9000-01-5
Handle Chemical Products Safely	9000-01-6
Dispose of Waste Properly	9000-01-6
Prepare for Emergencies.	9000-01-6
Use Steps and Handholds Correctly	9000-01-7
Start Only From Operator's Seat.	9000-01-7
Use and Maintain Seat Belt.	9000-01-7
Prevent Unintended Machine Movement.	9000-01-8
Avoid Work Site Hazards	9000-01-9
Use Special Care When Operating	
Loader.	9000-01-10
Keep Riders Off Machine	9000-01-10
Avoid Backover Accidents.	9000-01-11
Avoid Machine Tip Over	9000-01-11
Operating on Slopes	9000-01-12
Operating or Traveling On Public Roads	9000-01-12
Inspect and Maintain ROPS	9000-01-13
Add and Operate Attachments Safely	9000-01-13
Prevent Unintended Detonation of Explosive	
Devices	9000-01-13
Park And Prepare For Service Safely	9000-01-14
Service Cooling System Safely	9000-01-14
Remove Paint Before Welding or	
Heating	9000-01-15
Make Welding Repairs Safely	9000-01-16
Drive Metal Pins Safely.	9000-01-16

Contents

9000

Recognize Safety Information

This is the safety alert symbol. When you see this symbol on your machine or in this manual, be alert for the potential of personal injury.

Follow the precautions and safe operating practices highlighted by this symbol.

A signal word — DANGER, WARNING, or CAUTION — is used with the safety alert symbol. DANGER identifies the most serious hazards.

On your machine, DANGER signs are red in color, WARNING signs are orange, and CAUTION signs are yellow. DANGER and WARNING signs are located near specific hazards. General precautions are on CAUTION labels.



T133555 -JUN-28AUG00

T133588 -19-28AUG00

TX03679,00016CC -19-01OCT07-1/1

Follow Safety Instructions

Read the safety messages in this manual and on the machine. Follow these warnings and instructions carefully. Review them frequently. Keep safety signs in good condition. Replace missing or damaged safety signs. Replacement safety signs are available from your authorized John Deere dealer.

Be sure all operators of this machine understand every safety message. Replace operator's manual and safety labels immediately if missing or damaged.



T133556 -JUN-24AUG00

TX03679,00016F9 -19-18OCT07-1/1

Operate Only If Qualified

Do not operate this machine unless you have read the operator's manual carefully and you have been qualified by supervised training and instruction.

Familiarize yourself with the job site and your surroundings before operating. Try all controls and

machine functions with the machine in an open area before starting to work.

Know and observe all safety rules that may apply to your work situation and your work site.


TX03679,00016FA -19-01OCT07-1/1

Wear Protective Equipment

Guard against injury from flying pieces of metal or debris; wear goggles or safety glasses.

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear suitable hearing protection such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



TS206 -UN-23AUG88

TX03679,00016D0 -19-01OCT07-1/1

Avoid Unauthorized Machine Modifications

John Deere recommends using only genuine John Deere replacement parts to ensure machine performance. Never substitute genuine John Deere parts with alternate parts not intended for the application as these can create hazardous situations or hazardous performance. Non-John Deere Parts, or any damage or failures resulting from their use are not covered by any John Deere warranty.

Modifications of this machine, or addition of unapproved products or attachments, may affect

machine stability or reliability, and may create a hazard for the operator or others near the machine. The installer of any modification which may affect the electronic controls of this machine is responsible for establishing that the modification does not adversely affect the machine or its performance.


Always contact an authorized John Deere dealer before making machine modifications that change the intended use, weight or balance of the machine, or that alter machine controls, performance or reliability.

AM40430,00000A9 -19-14JAN08-1/1

Add Cab Guarding For Special Uses

Special work situations or machine attachments may create an environment with falling or flying objects. Loading logs, using fork attachments, or operating in waste management applications requires special work tools. Added cab guarding to protect the operator may also be required.

Use load-clamping grapples to keep bulky loads from falling and add special screens or guarding when objects may be directed toward the cab. Contact your authorized John Deere dealer for information on devices intended to protect the operator from falling or flying objects in special work situations.



T141893 -JUN-04MAY01

TX03679,00017C6 -19-18OCT07-1/1

Inspect Machine

Inspect machine carefully each day by walking around it before starting.

Keep all guards and shields in good condition and properly installed. Fix damage and replace worn or broken parts immediately. Pay special attention to hydraulic hoses and electrical wiring.



T6607AQ -JUN-18OCT88


TX03679,0001734 -19-01OCT07-1/1

Stay Clear of Moving Parts

Entanglements in moving parts can cause serious injury.

Stop engine before examining, adjusting or maintaining any part of machine with moving parts.

Keep guards and shields in place. Replace any guard or shield that has been removed for access as soon as service or repair is complete.



T133592 -JUN-12SEP01

TX03679,00016D2 -19-01OCT07-1/1


Avoid High-Pressure Fluids

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



X9811 -UN-23AUG88

DX,FLUID -19-03MAR93-1/1

Avoid High-Pressure Oils


This machine uses a high-pressure hydraulic system. Escaping oil under pressure can penetrate the skin causing serious injury.

Never search for leaks with your hands. Protect hands. Use a piece of cardboard to find location of escaping oil. Stop engine and relieve pressure before disconnecting lines or working on hydraulic system.

If hydraulic oil penetrates your skin, see a doctor immediately. Injected oil must be removed surgically within hours or gangrene may result. Contact a knowledgeable medical source or the Deere & Company Medical Department in Moline, Illinois, U.S.A.



T133509 -UN-17MAR06




T133840 -UN-20SEP00

TX03679,00016D3 -19-01OCT07-1/1

Beware of Exhaust Fumes

Prevent asphyxiation. Engine exhaust fumes can cause sickness or death.

If you must operate in a building, provide adequate ventilation. Use an exhaust pipe extension to remove the exhaust fumes or open doors and windows to bring outside air into the area.



T133546 -JUN-24AUG00

TX03679,00016D4 -19-03JAN07-1/1



Prevent Fires

Handle Fuel Safely: Store flammable fluids away from fire hazards. Never refuel machine while smoking or when near sparks or flame.

Clean Machine Regularly: Keep trash, debris, grease and oil from accumulating in engine compartment, around fuel lines, hydraulic lines and electrical wiring. Never store oily rags or flammable materials inside a machine compartment.

Maintain Hoses and Wiring: Replace hydraulic hoses immediately if they begin to leak, and clean up any oil spills. Examine electrical wiring and connectors frequently for damage.

Keep A Fire Extinguisher Available: Always keep a multipurpose fire extinguisher on or near the machine. Know how to use extinguisher properly.



T133552 -JUN-14SEP00

T133553 -JUN-07SEP00

T133554 -JUN-07SEP00

TX03679,00016F5 -19-08MAR07-1/1

Prevent Battery Explosions

Battery gas can explode. Keep sparks, lighted matches, and open flame away from the top of battery.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204 -JUN-23AUG88


TX03679,000174A -19-03JAN07-1/1

9000
01
6

Handle Chemical Products Safely

Exposure to hazardous chemicals can cause serious injury. Under certain conditions, lubricants, coolants, paints and adhesives used with this machine may be hazardous.

If uncertain about safe handling or use of these chemical products, contact your authorized John Deere dealer for a Material Safety Data Sheet (MSDS) or go to internet website <http://www.jdmsds.com>. The MSDS describes physical and health hazards, safe use procedures, and emergency response techniques for chemical substances. Follow MSDS recommendations to handle chemical products safely.



T133580 -UN-25AUG00

TX03679,00016D7 -19-14JAN08-1/1


Dispose of Waste Properly

Improper disposal of waste can threaten the environment. Fuel, oils, coolants, filters and batteries used with this machine may be harmful if not disposed of properly.

Never pour waste onto the ground, down a drain, or into any water source.

Air conditioning refrigerants can damage the atmosphere. Government regulations may require using a certified service center to recover and recycle used refrigerants.

If uncertain about the safe disposal of waste, contact your local environmental or recycling center or your dealer for more information.



T133567 -UN-25AUG00


TX03679,0001733 -19-28NOV06-1/1

Prepare for Emergencies

Be prepared if an emergency occurs or a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.




TS291 -UN-23AUG88

TX03679,000174B -19-31JAN07-1/1

Use Steps and Handholds Correctly

Prevent falls by facing the machine when you get on and off. Maintain 3-point contact with steps and handrails. Never use machine controls as handholds.

Use extra care when mud, snow, or moisture present slippery conditions. Keep steps clean and free of grease or oil. Never jump when exiting machine. Never mount or dismount a moving machine.



T133468 -JUN-30AUG00

TX03679,00016F2 -19-25JAN07-1/1

Start Only From Operator's Seat

Avoid unexpected machine movement. Start engine only while sitting in operator's seat. Ensure all controls and working tools are in proper position for a parked machine.

Never attempt to start engine from the ground. Do not attempt to start engine by shorting across the starter solenoid terminals.



T133715 -JUN-07SEP00

TX03679,0001799 -19-03JAN07-1/1

Use and Maintain Seat Belt

Use seat belt when operating machine. Remember to fasten seat belt when loading and unloading from trucks and during other uses.

Examine seat belt frequently. Be sure webbing is not cut or torn. Replace seat belt immediately if any part is damaged or does not function properly.

The complete seat belt assembly should be replaced every 3 years, regardless of appearance.



**USE
SEAT
BELT**

T133716 -19-14SEP00

TX03679,00016DD -19-20MAR07-1/1


9000
01
8

Prevent Unintended Machine Movement

When coworkers are present, disable hydraulics.

Lower all equipment to the ground during work interruptions. Lock transmission control in neutral, engage park brake and stop engine before allowing anyone to approach the machine.

Follow these same precautions before standing up, leaving the operator's seat, or exiting the machine.



T142001 -UN-15MAY01

TX03679,00017C7 -19-08MAR07-1/1

Avoid Work Site Hazards

Avoid contact with gas lines, buried cables and water lines. Call utility line location services to identify all underground utilities before starting work.

Prepare work site properly. Avoid operating near structures or objects that could fall onto the machine. Clear away debris that could move unexpectedly if run over.


Avoid boom or attachment contact with overhead obstacles or overhead electrical lines. Never move machine closer than 3 m (10 ft) plus twice the line insulator length to overhead wires.

Keep bystanders clear at all times. Use barricades or a signal person to keep vehicles and pedestrians away. Use a signal person if moving machine in congested areas or where visibility is restricted. Always keep signal person in view. Coordinate hand signals before starting machine.


Operate only on solid footing with strength sufficient to support machine. Be especially alert working near embankments or excavations.

Avoid working under over-hanging embankments or stockpiles that could collapse under or on machine.


Reduce machine speed when operating with tool on or near ground when obstacles may be hidden (e.g., during snow removal or clearing mud, dirt, etc.). At high speeds hitting obstacles (rocks, uneven concrete or manholes) can cause a sudden stop. Always wear your seatbelt.



T141894 -JUN-15JUN01



T141670 -JUN-24APR01



T141672 -JUN-04MAY01

DP99999,0000048 -19-12OCT06-1/1

9000
01
10


Use Special Care When Operating Loader

Never use the loader to lift people. Do not allow anyone to ride in the bucket or use the bucket as a work platform.


Operate carefully with raised loads. Raising the load reduces machine stability, especially on side slopes or an unstable surface. Drive and turn slowly with a raised load.

Ensure that objects in the bucket are secure. Do not attempt to lift or carry objects that are too big or too long to fit inside the bucket unless secured with an adequate chain or other device. Keep bystanders away from raised loads.

Be careful when lifting objects. Never attempt to lift objects too heavy for your machine. Assure machine stability and hydraulic capability with a test lift before attempting other maneuvers. Use an adequate chain or sling and proper rigging techniques to attach and stabilize loads. Never lift an object above or near another person.



T141957 -UN-15MAY01



T141902 -UN-07MAY01


TX03768,0000B70 -19-14MAY01-1/1

Keep Riders Off Machine

Only allow operator on machine.

Riders are subject to injury. They may fall from machine, be caught between machine parts, or be struck by foreign objects.

Riders may obstruct operator's view or impair his ability to operate machine safely.



T141671 -UN-04MAY01


TX03679,000179B -19-20APR01-1/1

Avoid Backover Accidents

Before moving machine, be sure all persons are clear of machine path. Turn around and look directly for best visibility. Use mirrors to assist in checking all around machine. Keep windows and mirrors clean, adjusted, and in good repair.

Be certain reverse warning alarm is working properly.

Use a signal person when backing if view is obstructed or when in close quarters. Keep signal person in view at all times. Use prearranged hand signals to communicate.



T141673 -JUN-04MAY01

TX03679,000179C -19-20APR01-1/1

Avoid Machine Tip Over

Use seat belt at all times.

Do not jump if the machine tips. You will be unlikely to jump clear and the machine may crush you.

Load and unload from trucks or trailers carefully. Be sure truck is wide enough and on a firm level surface. Use loading ramps and attach them properly to truck bed.



Be careful on slopes. Avoid sharp turns. Balance loads so weight is evenly distributed and load is stable. Carry tools and loads close to the ground to aid visibility and lower center of gravity. Use extra care on soft, rocky or frozen ground.

Know the capacity of the machine. Do not overload. Be careful with heavy loads. Using oversize buckets or lifting heavy objects reduces machine stability.

Ensure solid footing. Use extra care in soft ground conditions that may not uniformly support the wheels, especially when raising the boom. Do not operate close to banks or open excavations that may cave in and cause machine to tip or fall.



**USE
SEAT
BELT**



T133716 -19-14SEP00

T141676 -JUN-04MAY01

T141672 -JUN-04MAY01

TX03679,000179D -19-02MAY01-1/1


9000
01
12

Operating on Slopes

Avoid side slope travel whenever possible. Drive up steep slope in forward and down in reverse.

Select low gear speed before starting down slope. The grade of the slope will be limited by ground condition and load being handled.

Use service brakes to control speed. Sudden brake application with a loaded bucket on downhill side could cause machine to tip forward.





T141681 -UN-30APR01

TX03679,000179E -19-14MAY01-1/1

Operating or Traveling On Public Roads

Machines that work near vehicle traffic or travel slower than normal highway speeds must have proper lighting and markings to assure they are visible to other drivers.

Install additional lights, beacons, slow moving vehicle (SMV) emblems, or other devices and use as required to make the machine visible and identify it as a work machine. Check state and local regulations to assure compliance. Keep these devices clean and in working condition.



T141891 -UN-22MAY01

TX03679,00017C8 -19-02MAR07-1/1

Inspect and Maintain ROPS

A damaged roll-over protective structure (ROPS) should be replaced, not reused.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting.

If ROPS was loosened or removed for any reason, inspect it carefully before operating the machine again.

To maintain the ROPS:

- Replace missing hardware using correct grade hardware.
- Check hardware torque.
- Check isolation mounts for damage, looseness or wear; replace them if necessary.
- Check ROPS for cracks or physical damage.

TX03679,000179F -19-07SEP06-1/1

Add and Operate Attachments Safely

Always verify compatibility of attachments by contacting your authorized dealer. Adding unapproved attachments may affect machine stability or reliability, and may create a hazard for others near the machine.

Ensure that a qualified person is involved in attachment installation. Add guards to machine if operator protection is required or recommended. Verify



that all connections are secure and attachment responds properly to controls.

Carefully read attachment manual and follow all instructions and warnings. In an area free of bystanders and obstructions, carefully operate attachment to learn its characteristics and range of motion.

TX03679,00016F0 -19-24JAN07-1/1

Prevent Unintended Detonation of Explosive Devices

Avoid serious injury or death from an explosion hazard. Deactivate all cellular or radio frequency devices on equipment stored or operating in an area, such as a blasting zone, where the use of radio transmitting devices are prohibited.



TX1023216 -UN-07MAY07

VD76477,0001543 -19-08JAN08-1/1

9000
01
14

Park And Prepare For Service Safely


Warn others of service work. Always park and prepare your machine for service or repair properly.

- Park machine on a level surface and lower equipment to the ground.
- Engage park brake.
- Stop engine and remove key.
- Install articulation locking bar.
- Attach a “Do Not Operate” tag in an obvious place in the operator’s station.

Securely support machine or attachment before working under it.

- Do not support machine with boom, bucket, or other hydraulically actuated equipment.
- Do not support machine with cinder blocks or wooden pieces that may crumble or crush.
- Do not support machine with a single jack or other devices that may slip out of place.

Understand service procedures before beginning repairs. Keep service area clean and dry. Use two people whenever the engine must be running for service work.



TI133332 -19-14DEC01

TS229 -UN-23AUG88


TX03679,00017A0 -19-18SEP01-1/1

Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Do not service radiator through the radiator cap. Only fill through the surge tank filler cap.

Shut off engine. Only remove surge tank filler cap when cool enough to touch with bare hands. Slowly loosen cap to relieve pressure before removing completely.



TS281 -UN-23AUG88

OOU6043,0001B26 -19-11OCT06-1/1

Remove Paint Before Welding or Heating

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.


Remove paint before heating:

- Remove paint a minimum of 100 mm (4 in.) from area to be affected by heating. If paint cannot be removed, wear an approved respirator before heating or welding.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.

Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.



TS220 -JUN-23AUG88

DX,PAINT -19-24JUL02-1/1

9000
01
16

Make Welding Repairs Safely

IMPORTANT: Disable electrical power before welding. Turn off main battery switch or disconnect positive battery cable. Separate harness connectors to engine and vehicle microprocessors.



Avoid welding or heating near pressurized fluid lines. Flammable spray may result and cause severe burns if pressurized lines fail as a result of heating. Do not let heat go beyond work area to nearby pressurized lines.


Remove paint properly. Do not inhale paint dust or fumes. Use a qualified welding technician for structural repairs. Make sure there is good ventilation. Wear eye protection and protective equipment when welding.

T133547 -UN-31AUG00

TX03679,00016D5 -19-12SEP07-1/1

Drive Metal Pins Safely

Always wear protective goggles or safety glasses and other protective equipment before striking hardened parts. Hammering hardened metal parts such as pins and bucket teeth may dislodge chips at high velocity.



Use a soft hammer or a brass bar between hammer and object to prevent chipping.

T133738 -UN-14SEP00

TX03679,0001745 -19-17JUL07-1/1

Section 9001

Diagnostic Trouble Codes (DTC)

Contents

9001

	Page		Page
Group 10—CAN Monitor Unit (CMU) Diagnostic Trouble Codes			
CAN Monitor Unit (CMU) Diagnostic Trouble Codes	9001-10-1		
000829.05 — Fuel Level Open or Short	9001-10-1	Ambient Air Short to Ground Diagnostic Procedure	9001-20-5
Fuel Level Sensor Open or Short Diagnostic Procedure	9001-10-1	000627.01 — ECU Unswitch Short to GND	9001-20-7
002000.09 — Missing Message From ECU	9001-10-3	Engine Control Unit (ECU) Unswitched Short to Ground Diagnostic Procedure.	9001-20-7
ECU Signal Missing from CMU Diagnostic Procedure	9001-10-4	000676.05 — Engine Heat Open or Short.	9001-20-8
002003.09 — Missing Message From TCU	9001-10-6	Engine Heat Open or Short Diagnostic Procedure	9001-20-8
TCU Signal Missing from CMU Diagnostic Procedure	9001-10-6	001253.13 — Injector Cal Required	9001-20-9
002033.09 — Missing Message From FLC	9001-10-8	Injector Calibration Required Diagnostic Procedure	9001-20-10
FLC Signal Missing from CMU Diagnostic Procedure	9001-10-8	002003.09 — CAN Comm Lost for TCU	9001-20-10
002140.09 — Missing Message From SSM	9001-10-10	CAN Communication Lost for TCU Diagnostic Procedure	9001-20-10
SSM Signal Missing from CMU Diagnostic Procedure	9001-10-10	002033.09 — CAN Comm Lost for FLC	9001-20-12
002367.04 — Left Turn Switch Short to Ground	9001-10-11	CAN Communication Lost for FLC Diagnostic Procedure	9001-20-12
Left Turn Switch Short to Ground Diagnostic Procedure	9001-10-12		
002369.04 — Right Turn Switch Short to Ground	9001-10-13	Group 30—Transmission Control Unit (TCU) Diagnostic Trouble Codes	
Right Turn Switch Short to Ground Diagnostic Procedure	9001-10-13	Transmission Control Unit (TCU) Diagnostic Trouble Codes	9001-30-1
524250.31 — Inspect Park Brake	9001-10-15	002023.09 — CAN Comm Lost for CMU	9001-30-1
Inspect Park Brake Diagnostic Procedure	9001-10-15	CAN Signal Missing from CMU Diagnostic Procedure	9001-30-2
		002033.09 — CAN Comm Lost for FLC	9001-30-4
		CAN Signal Missing from FLC Diagnostic Procedure	9001-30-4
		522344.00 — Converter Overtemp	9001-30-6
		Transmission Oil Temperature Too High Diagnostic Procedure.	9001-30-6
		522350.15 — Input Torque Overload	9001-30-7
		Input Torque Overload Diagnostic Procedure	9001-30-7
		522364.07 — Trans Clutch Calibr Failed.	9001-30-8
		Transmission Clutch Calibration Failed Diagnostic Procedure.	9001-30-9
		522364.13 — Trans Clutch Calibr Fault	9001-30-10
		Transmission Clutch Calibration Fault Diagnostic Procedure.	9001-30-10
		522365.13 — Limp Home Mode	9001-30-10
		Limp Home Mode Requested Diagnostic Procedure	9001-30-11
Continued on next page			

Contents

	Page		Page
522366.13 — Application Invalid	9001-30-11	522379.05 — Park Brake Solenoid Open	
Application Invalid Diagnostic Procedure	9001-30-12	Circuit	9001-30-37
522367.13 — TCU Configuration Invalid	9001-30-12	Park Brake Solenoid Open Circuit Diagnostic	
TCU Configuration Invalid Diagnostic		Procedure	9001-30-37
Procedure	9001-30-13	522382.03 — Backup Alarm Short to	
522368.02 — Memory Failure	9001-30-13	Power	9001-30-38
TCU Memory Failure Diagnostic		Backup Alarm Short to Power Diagnostic	
Procedure	9001-30-14	Procedure	9001-30-39
522369.03 — Remote Display Short to		522382.04 — Backup Alarm Short to	
Power	9001-30-14	Gnd	9001-30-42
Remote Display Short to Power Diagnostic		Backup Alarm Short to Ground Diagnostic	
Procedure	9001-30-15	Procedure	9001-30-42
522369.04 — Remote Display Short to		522382.05 — Backup Alarm Open	
Ground	9001-30-17	Circuit	9001-30-45
Remote Display Short to Ground Diagnostic		Backup Alarm Open Circuit Diagnostic	
Procedure	9001-30-17	Procedure	9001-30-45
522370.02 — TCU VP2 Short Circuit	9001-30-18	522383.02 — Clutch KR Slippage	9001-30-47
TCU Valve Power Supply 2 Short Circuit		Clutch KR Slippage Diagnostic	
Diagnostic Procedure	9001-30-19	Procedure	9001-30-47
522371.02 — TCU VP1 Short Circuit	9001-30-20	522383.03 — Clutch Rev Sol Short to	
TCU Valve Power Supply 1 Short Circuit		Power	9001-30-49
Diagnostic Procedure	9001-30-21	Clutch Reverse Solenoid Short to Power	
522373.03 — Power Supply High		Diagnostic Procedure	9001-30-49
Voltage	9001-30-21	522383.04 — Clutch Rev Sol Short to	
Power Supply High Voltage Diagnostic		Gnd	9001-30-51
Procedure	9001-30-22	Clutch Reverse Solenoid Short to Ground	
522373.04 — Power Supply Low		Diagnostic Procedure	9001-30-52
Voltage	9001-30-23	522383.05 — Clutch Rev Sol Open	
Power Supply Low Voltage Diagnostic		Circuit	9001-30-55
Procedure	9001-30-23	Clutch Reverse Solenoid Open Circuit	
522374.03 — Sensor Supply Short to		Diagnostic Procedure	9001-30-56
Power	9001-30-24	522386.02 — Clutch KV Slippage	9001-30-57
Sensor Supply Short to Power Diagnostic		Clutch KV Slippage Diagnostic	
Procedure	9001-30-24	Procedure	9001-30-58
522374.04 — Sensor Supply Short to		522386.03 — Clutch Fwd Sol Short to	
Gnd	9001-30-26	Power	9001-30-60
Sensor Supply Short to Ground Diagnostic		Clutch Forward Solenoid Short to Power	
Procedure	9001-30-26	Diagnostic Procedure	9001-30-60
522375.00 — Trans Oil Filter Restricted	9001-30-28	522386.04 — Clutch Fwd Sol Short to	
Transmission Oil Filter Restricted Diagnostic		Gnd	9001-30-62
Procedure	9001-30-28	Clutch Forward Solenoid Short to Ground	
522376.00 — Trans Oil Temp Max		Diagnostic Procedure	9001-30-63
Value	9001-30-30	522386.05 — Clutch Fwd Sol Solenoid	
Transmission Oil Temperature Maximum		Open	9001-30-66
Value Diagnostic Procedure	9001-30-30	Clutch Forward Solenoid Open Circuit	
522379.03 — Park Brake Solenoid Short		Diagnostic Procedure	9001-30-67
to Power	9001-30-31	522389.02 — Clutch K4 Slippage	9001-30-68
Park Brake Solenoid Short to Power		Clutch K4 Slippage Diagnostic	
Diagnostic Procedure	9001-30-31	Procedure	9001-30-69
522379.04 — Park Brake Solenoid Short		522389.03 — Clutch K4 Sol Short to	
to Gnd	9001-30-34	Power	9001-30-71
Park Brake Solenoid Short to Ground			
Diagnostic Procedure	9001-30-34		

Continued on next page

Contents

Page	Page		
Clutch K4 Control Solenoid Short to Power Diagnostic Procedure	9001-30-71	522399.05 — Clutch K1 Sol Open Circuit	9001-30-110
522389.04 — Clutch K4 Sol Short to Gnd	9001-30-73	Transmission Clutch K1 Control Solenoid Open Circuit Diagnostic Procedure	9001-30-111
Clutch K4 Control Solenoid Short to Ground Diagnostic Procedure	9001-30-74	522401.02 — Trans Speed Sensor Fault	9001-30-112
522389.05 — Clutch K4 Sol Open Circuit	9001-30-77	Transmission Output Speed Sensor Fault Diagnostic Procedure	9001-30-113
Clutch K4 Control Solenoid Open Circuit Diagnostic Procedure	9001-30-78	522401.03 — Output Shaft Open or Short	9001-30-114
522392.02 — Clutch K3 Slippage	9001-30-79	Output Shaft Open or Short Diagnostic Procedure	9001-30-114
Clutch K3 Slippage Diagnostic Procedure	9001-30-79	522401.04 — Output Shaft Short to Gnd	9001-30-117
522392.03 — Clutch K3 Sol Short to Power	9001-30-82	Output Shaft Short to Ground Diagnostic Procedure	9001-30-117
Clutch K3 Control Solenoid Short to Power Diagnostic Procedure	9001-30-82	522401.12 — Output Shaft Fault	9001-30-119
522392.04 — Clutch K3 Sol Short to Gnd	9001-30-84	Output Shaft Fault Diagnostic Procedure	9001-30-119
Clutch K3 Control Solenoid Short to Ground Diagnostic Procedure	9001-30-85	522401.15 — Output Shaft Overspeed	9001-30-120
522392.05 — Clutch K3 Sol Open Circuit	9001-30-88	Output Shaft Overspeed Diagnostic Procedure	9001-30-120
Clutch K3 Control Solenoid Open Circuit Diagnostic Procedure	9001-30-89	522402.03 — Clutch Speed Open or Short	9001-30-121
522395.02 — Clutch K2 Slippage	9001-30-90	Clutch Speed Open or Short Diagnostic Procedure	9001-30-121
Clutch K2 Slippage Diagnostic Procedure	9001-30-90	522402.04 — Clutch Speed Short to Gnd	9001-30-125
522395.03 — Clutch K2 Sol Short to Power	9001-30-93	Clutch Speed Short to Ground Diagnostic Procedure	9001-30-125
Transmission Clutch K2 Control Solenoid Short to Power Diagnostic Procedure	9001-30-93	522402.12 — Clutch Speed Sensor Fault	9001-30-128
522395.04 — Clutch K2 Sol Short to Gnd	9001-30-95	Clutch Speed Sensor Fault Diagnostic Procedure	9001-30-128
Transmission Clutch K2 Control Solenoid Short to Ground Diagnostic Procedure	9001-30-96	522403.03 — Conv Output Spd Open or Short	9001-30-129
522395.05 — Clutch K2 Sol Open Circuit	9001-30-99	Converter Output Speed Open or Short Diagnostic Procedure	9001-30-129
Transmission Clutch K2 Control Solenoid Open Circuit Diagnostic Procedure	9001-30-100	522403.04 — Conv Output Spd Short to Gnd	9001-30-133
522399.02 — Clutch K1 Slippage	9001-30-101	Converter Output Speed Short to Ground Diagnostic Procedure	9001-30-133
Transmission Clutch K1 Slippage Diagnostic Procedure	9001-30-102	522403.12 — Conv Output Spd Fault	9001-30-136
522399.03 — Clutch K1 Sol Short to Power	9001-30-104	Converter Output Speed Fault Diagnostic Procedure	9001-30-136
Transmission Clutch K1 Control Solenoid Short to Power Diagnostic Procedure	9001-30-104	522404.03 — Conv Input Spd Open or Short	9001-30-137
522399.04 — Clutch K1 Sol Short to Gnd	9001-30-106	Converter Input Speed Open or Short Diagnostic Procedure	9001-30-137
Transmission Clutch K1 Control Solenoid Short to Ground Diagnostic Procedure	9001-30-107	522404.04 — Conv Input Spd Short to Gnd	9001-30-141

Continued on next page

9001

9001

Page

Page

Torque Converter Input Speed Short to Ground Diagnostic Procedure9001-30-141

522404.12 — Conv Input Spd Fault9001-30-144

Converter Input Speed Fault Diagnostic Procedure9001-30-144

522406.03 — Trans Oil Temp Open or Short9001-30-145

Transmission Oil Temperature Sensor Open or Short Diagnostic Procedure . . .9001-30-145

522406.04 — Trans Oil Temp Short to Gnd9001-30-150

Transmission Oil Temperature Sensor Short to Ground Diagnostic Procedure9001-30-150

522407.03 — Clutch Cutoff Short to Power9001-30-154

Clutch Cut-Off Sensor Short to Power Diagnostic Procedure9001-30-154

522407.04 — Clutch Cutoff Open or Short9001-30-156

Clutch Cut-Off Sensor Open or Short Diagnostic Procedure9001-30-156

522409.05 — 2nd FNR Open Circuit9001-30-158

2nd TCL Open Circuit Diagnostic Procedure (Pilot Control Joystick)9001-30-158

522409.12 — 2nd FNR Mult Inputs9001-30-159

2nd TCL Missing Inputs Diagnostic Procedure9001-30-159

522411.05 — 1st FNR Open Circuit9001-30-161

1st TCL Open Circuit Diagnostic Procedure (Steering Column Shifter) . . .9001-30-161

1st TCL Open Circuit Diagnostic Procedure (Pilot Control Joystick)9001-30-163

522411.12 — 1st FNR Mult Inputs9001-30-164

1st TCL Multiple Inputs Diagnostic Procedure (Steering Column Shifter) . . .9001-30-164

1st TCL Multiple Inputs Diagnostic Procedure (Pilot Control Joystick)9001-30-167

522412.12 — Gear Selection Error9001-30-169

Gear Selection Error Diagnostic Procedure9001-30-169

522419.02 — Clutch Cutoff Disabled9001-30-171

Clutch Cut-Off Disabled Diagnostic Procedure9001-30-172

522420.02 — Manual Downshift Disabled9001-30-173

Manual Downshift Disabled Diagnostic Procedure9001-30-173

522421.02 — Auto To 1st Disabled9001-30-174

Auto To 1st Disabled Diagnostic Procedure9001-30-174

524048.00 — Trans Output Torque Exceeded9001-30-175

Trans Output Torque Exceeded Diagnostic Procedure9001-30-175

524049.00 — Trans Input Torque Exceeded9001-30-176

Trans Input Torque Exceeded Diagnostic Procedure9001-30-176

524287.00 — Configure Machine Model9001-30-177

Configure Machine Model Diagnostic Procedure9001-30-177

Group 40—Flex Load Controller (FLC) Diagnostic Trouble Codes

Flex Load Controller (FLC) Diagnostic Trouble Codes9001-40-1

000117.01 — Brake Pressure Low9001-40-1

Brake Pressure Low Diagnostic Procedure9001-40-1

000167.16 — Alternator High Voltage9001-40-3

Alternator High Voltage Diagnostic Procedure9001-40-3

000167.18 — Alternator Low Voltage9001-40-4

Alternator Low Voltage Diagnostic Procedure9001-40-4

000168.16 — High Battery Voltage9001-40-5

High Battery Voltage Diagnostic Procedure9001-40-5

000168.18 — Low Battery Voltage9001-40-6

Low Battery Voltage Diagnostic Procedure9001-40-6

000444.05 — 12V Cntr Tap Open or Short9001-40-7

12 Volt Center Tap Open or Short Diagnostic Procedure9001-40-7

000444.18 — Battery Voltage Imbalance . . .9001-40-9

Battery Voltage Imbalance Diagnostic Procedure9001-40-10

000544.19 — Refer Torq Mis-Match9001-40-11

Reference Torque MisMatch Diagnostic Procedure9001-40-11

000628.12 — Controller Not Programmed9001-40-11

Controller Not Programmed Diagnostic Procedure9001-40-12

000774.04 — JS Upshift Short to Gnd9001-40-12

Joystick Upshift Short to Ground Diagnostic Procedure9001-40-12

000774.10 — JS Upshift Button Stuck9001-40-14

Joystick Upshift Button Stuck Diagnostic Procedure9001-40-14

Continued on next page

Contents

	Page		Page
000775.04 — JS Downshift Short to Gnd	9001-40-15	001079.04 — FLC Sensor 1 Voltage Low	9001-40-46
Joystick Downshift Short to Ground Diagnostic Procedure.	9001-40-15	FLC Sensor 1 Voltage Low Diagnostic Procedure	9001-40-47
000775.10 — JS Downshift Button Stuck	9001-40-17	001080.04 — FLC Sensor 2 Voltage Low	9001-40-48
Joystick Downshift Button Stuck Diagnostic Procedure	9001-40-17	FLC Sensor 2 Voltage Low Diagnostic Procedure	9001-40-49
000785.03 — Pilot Solenoid Short to Power	9001-40-18	001638.00 — Hydraulic Oil High Temp	9001-40-50
Pilot Solenoid Short to Power Diagnostic Procedure	9001-40-18	Hydraulic Oil High Temperature Diagnostic Procedure	9001-40-50
000785.05 — Pilot Solenoid Open Circuit	9001-40-20	001638.04 — Hyd Oil Temp Circuit Short to Gnd	9001-40-51
Pilot Solenoid Open Circuit Diagnostic Procedure	9001-40-20	Hydraulic Oil Temperature Circuit Short to Ground Diagnostic Procedure	9001-40-51
000785.06 — Pilot Solenoid High Current	9001-40-22	001713.01 — Hyd Oil Filter Restricted	9001-40-53
Pilot Solenoid High Current Diagnostic Procedure	9001-40-22	Hydraulic Oil Filter Restricted Diagnostic Procedure	9001-40-53
000880.03 — Brake Lights Short to Power	9001-40-24	001762.03 — Hyd Pressure Short to Power	9001-40-55
Brake Lights Short to Power Diagnostic Procedure	9001-40-24	Hydraulic Pressure Short to Power Diagnostic Procedure	9001-40-55
000880.05 — Brake Lights Open Circuit	9001-40-26	001762.04 — Hyd Pressure Open or Short	9001-40-57
Brake Lights Open Circuit Diagnostic Procedure	9001-40-27	Hydraulic Pressure Open or Short Diagnostic Procedure	9001-40-57
000880.06 — Brake Lights High Current.	9001-40-29	002000.09 — CAN Comm Lost for ECU	9001-40-60
Brake Lights High Current Diagnostic Procedure	9001-40-29	CAN Communication Lost For ECU Diagnostic Procedure.	9001-40-60
000977.03 — Rev Fan Solenoid Short to Power	9001-40-31	002003.09 — CAN Comm Lost for TCU	9001-40-62
Reverse Fan Solenoid Short to Power Diagnostic Procedure.	9001-40-32	CAN Communication Lost for TCU Diagnostic Procedure	9001-40-62
000977.05 — Rev Fan Sol Open Circuit	9001-40-34	002023.09 — CAN Comm Lost for CMU.	9001-40-64
Reverse Fan Solenoid Open Circuit Diagnostic Procedure.	9001-40-35	CAN Communication Lost for CMU Diagnostic Procedure.	9001-40-64
000977.06 — Rev Fan Sol High Current.	9001-40-37	002140.09 — CAN Comm Lost for SSM	9001-40-66
Reverse Fan Solenoid High Current Diagnostic Procedure.	9001-40-37	CAN Communication Lost for SSM Diagnostic Procedure	9001-40-66
001045.04 — Brake Lt Sw Shorted to Gnd	9001-40-39	002350.05 — Drive Lamps Open or Short	9001-40-67
Brake Light Switch Shorted to Ground Diagnostic Procedure.	9001-40-40	Drive Lamps Open or Short Diagnostic Procedure	9001-40-68
001069.02 — Tire Size Incorrect.	9001-40-41	002350.06 — Drive Lamps High Current.	9001-40-70
Tire Size Incorrect Diagnostic Procedure.	9001-40-41	Drive Lamps High Current Diagnostic Procedure	9001-40-71
001071.31 — Fan Speed Sol Circuit Fault	9001-40-42	002355.05 — Front Work Lts Open or Short	9001-40-72
Fan Speed Solenoid Circuit Fault Diagnostic Procedure	9001-40-42	Auxiliary Lights Open or Short Diagnostic Procedure	9001-40-73
001075.00 — Fuel Pump On Too Long.	9001-40-46	002355.06 — Front Work Lts High Current	9001-40-77
Fuel Pump On Too Long Diagnostic Procedure	9001-40-46		

Continued on next page

9001

Contents

	Page		Page
Auxiliary Lights High Current Diagnostic		002386.06 — Beacon Light High	
Procedure	9001-40-77	Current	9001-40-129
002356.05 — Front Work Lts Open or		Beacon Light High Current diagnostic	
Short	9001-40-80	Procedure	9001-40-130
Front Work Lights Open or Short Diagnostic		002697.02 — JS Mag Out of Range	9001-40-131
Procedure	9001-40-80	Joystick Magnitude Out of Range Diagnostic	
002356.06 — Front Work Lts High		Procedure	9001-40-131
Current	9001-40-84	002875.04 — 4-Way Flash Sw Short to	
Front Work Lights High Current Diagnostic		Gnd	9001-40-132
Procedure	9001-40-84	4-Way Flasher Switch Short to Ground	
002362.05 — Rear Work Lts Open or		Diagnostic Procedure.	9001-40-132
Short	9001-40-87	299261.02 — Machine Config Invalid	9001-40-133
Rear Work Lights Open or Short Diagnostic		Machine Configuration Invalid Diagnostic	
Procedure	9001-40-87	Procedure	9001-40-134
002362.06 — Rear Work Lts High		522431.02 — Memory Test Failure	9001-40-134
Current	9001-40-91	Memory Test Failure Diagnostic	
Rear Work Lights High Current Diagnostic		Procedure	9001-40-134
Procedure	9001-40-91	522432.05 — R Wiper H-Spd Open	
002368.03 — Left Turn Lts Circuit Short to		Circuit	9001-40-135
Power	9001-40-94	Rear Wiper High-Speed Open Circuit	
Left Turn Lights Circuit Short to Power		Diagnostic Procedure.	9001-40-135
Diagnostic Procedure.	9001-40-94	522432.06 — R Wiper H-Spd High	
002368.05 — Left Turn Lts Open Circuit.	9001-40-98	Current	9001-40-136
Left Turn Lights Open Circuit Diagnostic		Rear Wiper High-Speed High Current	
Procedure	9001-40-99	Diagnostic Procedure.	9001-40-137
002368.06 — Left Turn Lts Circuit High		522433.05 — R Wiper L-Spd Open or	
Current	9001-40-102	Short	9001-40-138
Left Turn Lights Circuit High Current		Rear Wiper Low-Speed Open or Short	
Diagnostic Procedure.	9001-40-102	Diagnostic Procedure.	9001-40-139
002370.03 — Right Turn Lts Short to		522433.06 — R Wiper L-Spd High	
Power	9001-40-106	Current	9001-40-141
Right Turn Lights Short to Power Diagnostic		Rear Wiper Low-Speed High Current	
Procedure	9001-40-107	Diagnostic Procedure.	9001-40-142
002370.05 — Right Turn Lts Open		522434.05 — F Wiper L-Spd Open or	
Circuit	9001-40-109	Short	9001-40-143
Right Turn Lights Open Circuit Diagnostic		Front Wiper Low-Speed Open or Short	
Procedure	9001-40-110	Diagnostic Procedure.	9001-40-144
002370.06 — Right Turn Lts High		522434.06 — F Wiper L-Spd High	
Current	9001-40-112	Current	9001-40-146
Right Turn Lights High Current Diagnostic		Front Wiper Low-Speed High Current	
Procedure	9001-40-112	Diagnostic Procedure.	9001-40-147
002378.03 — Marker/Tail Lts Short to		522435.05 — F Wiper H-Spd Open	
Power	9001-40-116	Circuit	9001-40-148
Marker/Tail Lights Short to Power Diagnostic		Front Wiper High-Speed Open Circuit	
Procedure	9001-40-117	Diagnostic Procedure.	9001-40-149
002378.05 — Marker/Tail Lts Open		522435.06 — F Wiper H-Spd High	
Circuit	9001-40-121	Current	9001-40-150
Marker/Tail Lights Open Circuit Diagnostic		Front Wiper High-Speed High Current	
Procedure	9001-40-122	Diagnostic Procedure.	9001-40-151
002378.06 — Marker/Tail Lts High		522436.03 — Bucket Pos Short to	
Current	9001-40-125	Power	9001-40-152
Marker/Tail Lights High Current Diagnostic			
Procedure	9001-40-125		

Continued on next page

Contents

	Page		Page
Bucket Position Short to Power Diagnostic Procedure	9001-40-153	No Voltage to FLC on VP4 Diagnostic Procedure	9001-40-180
522436.04 — Bucket Pos Open or Short	9001-40-155	523217.05 — No Voltage to FLC on VP3	9001-40-182
Bucket Position Open or Short Diagnostic Procedure	9001-40-156	No Voltage to FLC on VP3 Diagnostic Procedure	9001-40-182
522437.04 — RTDig Switch 1 Short to Gnd	9001-40-158	523218.05 — No Voltage to FLC on VP2	9001-40-183
Return-to-dig Switch 1 Short to Ground Diagnostic Procedure.	9001-40-159	No Voltage to FLC on VP2 Diagnostic Procedure	9001-40-183
522438.03 — Pin Disc Sol Short to Power	9001-40-160	523219.05 — No Voltage to FLC on VP1	9001-40-185
Pin Disconnect Solenoid Short to Power Diagnostic Procedure.	9001-40-161	No Voltage to FLC on VP1 Diagnostic Procedure	9001-40-185
522438.05 — Pin Disc Sol Open Circuit	9001-40-163	523436.17 — FLC Watchdog Timed Out	9001-40-186
Pin Disconnect Solenoid Open Circuit Diagnostic Procedure.	9001-40-164	FLC Watchdog Timed Out Diagnostic Procedure	9001-40-186
522438.06 — Pin Disc Sol High Current	9001-40-165	523577.03 — 2nd Steer Pump Short to Power	9001-40-187
Pin Disconnect Solenoid High Current Diagnostic Procedure.	9001-40-166	Secondary Steering Pump Short to Power Diagnostic Procedure.	9001-40-187
522796.05 — R Washer Pump Open Circuit	9001-40-168	523577.05 — 2nd Steer Pump Open Circuit	9001-40-189
Rear Washer Pump Open Circuit Diagnostic Procedure	9001-40-169	Secondary Steering Pump Open Circuit Diagnostic Procedure.	9001-40-190
522796.06 — R Washer Pump High Current	9001-40-170	523577.06 — 2nd Steer Pump High Current	9001-40-192
Rear Washer Pump High Current Diagnostic Procedure	9001-40-170	Secondary Steer Pump High Current Diagnostic Procedure.	9001-40-192
522797.05 — F Washer Pump Open Circuit	9001-40-172	523786.03 — Boom Position Short to Power	9001-40-194
Front Washer Pump Open Circuit Diagnostic Procedure	9001-40-172	Boom Position Short to Power Diagnostic Procedure	9001-40-195
522797.06 — F Washer Pump High Current	9001-40-173	523786.04 — Boom Position Open or Short	9001-40-196
Front Washer Pump High Current Diagnostic Procedure	9001-40-174	Boom Position Open or Short Diagnostic Procedure	9001-40-197
523137.04 — Steering Press Sw Shrt to Gnd	9001-40-175	523840.01 — Brake Pressure Low-Front	9001-40-199
Steering Pressure Switch Short to Ground Diagnostic Procedure.	9001-40-176	Brake Pressure Low-Front Diagnostic Procedure	9001-40-200
523214.05 — No Voltage to FLC on VP6	9001-40-177	523840.03 — Ft Brake Pressure Short to Power	9001-40-200
No Voltage to FLC on VP6 Diagnostic Procedure	9001-40-177	Front Brake Pressure Sensor Short to Power Diagnostic Procedure.	9001-40-200
523215.05 — No Voltage to FLC on VP5	9001-40-178	523840.04 — Ft Brake Pressure Open or Short	9001-40-202
No Voltage to FLC on VP5 Diagnostic Procedure	9001-40-179	Front Brake Pressure Sensor Open or Short Diagnostic Procedure.	9001-40-202
523216.05 — No Voltage to FLC on VP4	9001-40-180		

Continued on next page

9001

Page

Page

523911.31 — Hyd Pwr Sol Circuit
 Fault9001-40-203

523948.03 — Ride Contrl Sol Short to
 Power9001-40-204

Ride Control Solenoid Short to Power
 Diagnostic Procedure9001-40-204

523948.05 — Ride Contrl Sol Open
 Circuit9001-40-206

Ride Control Solenoid Open Circuit
 Diagnostic Procedure9001-40-206

523948.06 — Ride Contrl Sol High
 Current9001-40-207

Ride Control Solenoid High Current
 Diagnostic Procedure9001-40-208

524265.19 — Check Sum Error9001-40-209

Check Sum Error Diagnostic
 Procedure9001-40-210

**Group 50—Sealed Switch Module (SSM) Diagnostic
 Trouble Codes**

Sealed Switch Module (SSM) Diagnostic
 Trouble Codes9001-50-1

000628.12 — Controller Not Programmed. . .9001-50-1

Controller Not Programmed Diagnostic
 Procedure9001-50-2

000629.12 — SSM Watchdog Time Out . . .9001-50-2

SSM Watchdog Time Out Diagnostic
 Procedure9001-50-2

000639.12 — SSM Lost Message9001-50-3

SSM Lost Message Diagnostic Procedure . .9001-50-3

000639.19 — SSM Lost CAN
 Communications9001-50-4

SSM Lost CAN Communications Diagnostic
 Procedure9001-50-5

002033.09 — SSM Lost Communications . .9001-50-6

SSM Lost Communications Diagnostic
 Procedure9001-50-6

523523.10 — Rear Wiper Keypad Stuck . . .9001-50-8

Rear Wiper Keypad Stuck Diagnostic
 Procedure9001-50-8

523524.10 — Front Wiper Keypad Stuck . . .9001-50-9

Front Wiper Keypad Stuck Diagnostic
 Procedure9001-50-9

523525.10 — Front Washer Keypad
 Stuck9001-50-10

Front Washer Keypad Stuck Diagnostic
 Procedure9001-50-10

523526.10 — Reverse Fan Keypad
 Stuck9001-50-11

Reverse Fan Keypad Stuck Diagnostic
 Procedure9001-50-11

523527.10 — Pin Disconnect Keypad
 Stuck9001-50-12

Pin Disconnect Keypad Stuck Diagnostic
 Procedure9001-50-13

523528.10 — A/C Keypad Stuck9001-50-14

A/C Keypad Stuck Diagnostic Procedure . .9001-50-14

523529.10 — Work Lights Keypad
 Stuck9001-50-15

Work Lights Keypad Stuck Diagnostic
 Procedure9001-50-15

523530.10 — Beacon Light Keypad
 Stuck9001-50-16

Beacon Light Keypad Stuck Diagnostic
 Procedure9001-50-16

523532.10 — Spin Control Keypad
 Stuck9001-50-17

Spin Control Keypad Stuck Diagnostic
 Procedure9001-50-17

523533.10 — Clutch Cut-Off Keypad
 Stuck9001-50-18

Clutch Cut-Off Keypad Stuck Diagnostic
 Procedure9001-50-19

523534.10 — Pilot Enable Keypad
 Stuck9001-50-20

Pilot Enable Keypad Stuck Diagnostic
 Procedure9001-50-20

523535.10 — Ride Control Keypad
 Stuck9001-50-21

Ride Control Keypad Stuck Diagnostic
 Procedure9001-50-21

523536.10 — Auto Transmission Keypad
 Stuck9001-50-22

Auto Transmission Keypad Stuck Diagnostic
 Procedure9001-50-22

523537.10 — Drive Lights Keypad
 Stuck9001-50-23

Drive Lights Keypad Stuck Diagnostic
 Procedure9001-50-23

523538.10 — Keypad Not Used9001-50-24

Keypad Not Used Diagnostic Procedure . .9001-50-25

523607.10 — Return to Dig Keypad
 Stuck9001-50-26

Return-to-Dig Keypad Stuck Diagnostic
 Procedure9001-50-26

523608.10 — BHKO Keypad Stuck9001-50-27

Boom Height Kickout Keypad Stuck
 Diagnostic Procedure9001-50-27

523609.10 — RTCarry Keypad Stuck9001-50-28

Return-to-Carry Keypad Stuck Diagnostic
 Procedure9001-50-28

523610.10 — Rear Washer Keypad
 Stuck9001-50-29

Continued on next page

Contents

Page

Rear Washer Keypad Stuck Diagnostic
Procedure9001-50-29

9001

Contents

9001

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

The diagnostic trouble code number is indicated by a Suspect Parameter Number (SPN) and a Failure Mode Indicator (FMI) number. In the example **829.05**, 829 is the SPN and 05 is the FMI number.

To view diagnostic trouble codes, use one of the following methods:

- Service ADVISOR™ system. See Reading Diagnostic Trouble Codes with Service ADVISOR Diagnostic Application. (Group 9015-20.)
- CAN Monitor Unit (CMU). See CAN Monitor Unit (CMU) Menu Structure—Service Mode. (Group 9015-20.)

Note: For in-depth diagnostics on all CMU diagnostic trouble codes, see specific code diagnostic procedure. (Group 9001-10.)

Service ADVISOR is a trademark of Deere & Company

AA95137,00008F4 -19-20AUG07-1/1

000829.05 — Fuel Level Open or Short

Fuel level sensor circuit is open or short to power.

AA95137,00008F5 -19-05JUN07-1/1

Fuel Level Sensor Open or Short Diagnostic Procedure

Alarm Level:

No Warning Lamp

-- -1/1

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

9001
10
2

<p>1 Component Check</p>	<p>Turn key switch OFF.</p> <p>Disconnect fuel level sensor (B17). See Engine Harness (W6) Component Location. (Group 9015-10.)</p> <p>Measure resistance across sensor pins.</p> <p align="center">Specification</p> <p>Fuel Level Sensor (B17)—Resistance..... 168—192 ohms at 100% fill (full) 91—109 ohms at 50% fill 4—16 ohms at 0% fill (empty)</p> <p>Is resistance within specifications?</p>	<p>YES: Go to Open Circuit Check.</p> <p>NO: Fuel level sensor (B17) malfunction. Replace sensor.</p>
---------------------------------	---	---

-- -1/1

<p>2 Open Circuit Check</p>	<p>Turn key switch OFF.</p> <p>Disconnect fuel level sensor (B17) and CAN monitor unit (CMU) connector (X48). See Engine Harness (W6) Component Location and see Front Console Harness (W4) Component Location. (Group 9015-10.)</p> <p>Check circuit Y02 YEL for continuity between pin B on fuel level sensor (B17) connector and pin N on CMU connector (X48).</p> <p>Check circuit R02 BLK for continuity between pin A on fuel level sensor (B17) connector and pin F on CMU connector (X48).</p> <p>Is continuity indicated?</p>	<p>YES: Go to Short Circuit Check.</p> <p>NO: Go to next step in this check.</p>
	<p>Key switch OFF and fuel level sensor (B17) disconnected.</p> <p>Disconnect connector (X4). See Engine Harness (W6) Component Location. (Group 9015-10.)</p> <p>Check circuit Y02 YEL for continuity between pin B on fuel level sensor (B17) connector and pin 32 on engine harness side of connector (X4).</p> <p>Check circuit R02 BLK for continuity between pin A on fuel level sensor (B17) connector and pin 21 on engine harness side of connector (X4).</p> <p>Is continuity indicated?</p>	<p>YES: Go to next step in this check.</p> <p>NO: Open circuit in engine harness (W6). Repair circuit without continuity or replace engine harness. See Engine Harness (W6) Wiring Diagram. (Group 9015-10.)</p>
	<p>Key switch OFF.</p> <p>Disconnect connector (X30) and CMU connector (X48). See Front Console Harness (W4) Component Location. (Group 9015-10.)</p> <p>Check circuit Y02 YEL for continuity between pin N on CMU connector (X48) and pin 31 on front console harness side of connector (X30). See Load Center Harness (W3) Wiring Diagram and see Front Console Harness (W4) Wiring Diagram. (Group 9015-10.)</p> <p>Check circuit R02 BLK for continuity between pin F on CMU connector (X48) and pin 7 on front console harness side of connector (X30).</p> <p>Is continuity indicated?</p>	<p>YES: Open circuit in load center harness (W3). Repair circuit without continuity or replace load center harness.</p> <p>NO: Open circuit in front console harness (W4). Repair circuit without continuity or replace front console harness.</p>

-- -1/1

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

3 Short Circuit Check	<p>Turn key switch OFF.</p> <p>Disconnect fuel level sensor (B17). See Engine Harness (W6) Component Location. (Group 9015-10.)</p> <p>Turn key switch ON.</p> <p>Check circuit Y02 YEL for voltage between pin B on fuel level sensor (B17) connector and machine ground.</p> <p>Is system voltage present (approximately 24 volts)?</p>	<p>YES: Go to next step in this check.</p> <p>NO: Go to Reprogram Controller.</p>
	<p>Turn key switch OFF.</p> <p>Disconnect connector (X30). See Front Console Harness (W4) Component Location. (Group 9015-10.)</p> <p>Turn key switch ON.</p> <p>Check circuit Y02 YEL for voltage between pin 31 on front console harness side of connector (X30) and machine ground. See Front Console Harness (W4) Wiring Diagram. (Group 9015-10.)</p> <p>Is system voltage present (approximately 24 volts)?</p>	<p>YES: Circuit Y02 YEL is short to power in front console harness (W4). Repair circuit Y02 YEL or replace harness.</p> <p>NO: Go to next step in this check.</p>
	<p>Turn key switch OFF.</p> <p>Disconnect connector (X4). See Load Center Harness (W3) Component Location. (Group 9015-10.)</p> <p>Turn key switch ON.</p> <p>Check circuit Y02 YEL for voltage between pin 32 on load center harness side of connector (X4) and machine ground. See Load Center Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p>Is system voltage present (approximately 24 volts)?</p>	<p>YES: Circuit Y02 YEL is short to power in load center harness (W3). Repair circuit Y02 YEL or replace harness.</p> <p>NO: Circuit Y02 YEL is short to power in engine harness (W6). Repair circuit Y02 YEL or replace harness.</p> <p style="text-align: right;">-- -1/1</p>
4 Reprogram Controller	<p>Reprogram CAN monitor unit (CMU).</p> <p>Check for active codes.</p> <p>Is CMU code 000829.05 present?</p>	<p>YES: Replace controller.</p> <p>NO: Checks complete.</p> <p style="text-align: right;">-- -1/1</p>

9001
10
3

002000.09 — Missing Message From ECU

The CAN monitor unit (CMU) is not receiving a CAN signal from the engine control unit (ECU).

AA95137,00008F6 -19-09APR07-1/1

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

ECU Signal Missing from CMU Diagnostic Procedure

Alarm Level:

No Warning Lamp

---1/1

1 Controller Sensors Check

Turn key switch ON.

View engine control unit (ECU) monitored sensor outputs by accessing the Diagnostics / Engine Sensors / Display All menu on the CAN monitor unit (CMU). See CAN Monitor Unit (CMU) Menu Structure—Service Mode. (Group 9015-20.)

Does the monitor show a reading for all sensors?

YES: Go to Reprogram CAN Monitor Unit.

NO: Go to Fuse Check.

---1/1

2 Fuse Check

Turn key switch OFF.

Remove fuses (F3 and F10). See Fuse and Relay Specifications. (Group 9015-10.)

Check continuity of fuses (F3 and F10).

Is continuity indicated?

YES: Go to Circuit Check.

NO: Replace fuse(s) without continuity. See Fuse and Relay Specifications. (Group 9015-10.)

---1/1

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

3 Circuit Check	<p>Turn key switch OFF.</p> <p>Disconnect ECU connector (X24). See Load Center Harness (W3) Component Location. (Group 9015-10.)</p> <p>Turn key switch ON.</p> <p>Check circuit P10 RED for voltage between pin E3 on ECU connector (X24) and machine ground. See Load Center Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p>Check circuit P03 RED for voltage between pin B1 on ECU connector (X24) and machine ground.</p> <p>Check circuit P03 RED for voltage between pin B2 on ECU connector (X24) and machine ground.</p> <p>Is system voltage (approximately 24 volts) present?</p>	<p>YES: Go to next step in this check.</p> <p>NO: Open circuit in load center harness (W3). Repair circuit without voltage or replace harness.</p>
	<p>Turn key switch OFF.</p> <p>ECU connector (X24) disconnected.</p> <p>Check circuit G11 BLK for ground at pins C2 and C3 on ECU connector (X24). See Load Center Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p>Is ground present?</p>	<p>YES: Go to CAN Circuit Check.</p> <p>NO: Circuit G11 BLK open circuit in load center harness (W3). Repair circuit G11 BLK or replace harness.</p>
4 CAN Circuit Check	<p>Perform CAN Circuit Test. (Group 9015-20.)</p> <p>Does CAN circuit test good?</p>	<p>YES: Go to Reprogram Engine Control Unit.</p> <p>NO: Repair CAN circuit.</p>
5 Reprogram Engine Control Unit	<p>Reprogram engine control unit (ECU).</p> <p>Check for active codes.</p> <p>Is CMU code 002000.09 present?</p>	<p>YES: Replace ECU.</p> <p>NO: Checks complete.</p>
6 Reprogram CAN Monitor Unit	<p>Reprogram CAN monitor unit (CMU).</p> <p>Check for active codes.</p> <p>Is CMU code 002000.09 present?</p>	<p>YES: Replace CMU.</p> <p>NO: Checks complete.</p>

9001
10
5

--1/1

--1/1

--1/1

--1/1

002003.09 — Missing Message From TCU

The CAN monitor unit (CMU) is not receiving a CAN signal from transmission control unit (TCU).

AA95137,00008F7 -19-09APR07-1/1

TCU Signal Missing from CMU Diagnostic Procedure

Alarm Level:

No Warning Lamp

---1/1

1 Controller Sensors Check

Turn key switch ON.

View transmission control unit (TCU) monitored sensor outputs by accessing the Diagnostics / Transmission / Display All menu on the CAN monitor unit (CMU). See CAN Monitor Unit (CMU) Menu Structure—Service Mode. (Group 9015-20.)

Does the monitor show reading for all sensors?

YES: Go to Reprogram CAN Monitor Unit.

NO: Go to Fuse Check.

---1/1

2 Fuse Check

Turn key switch OFF.

Remove fuses (F18 and F28). See Fuse and Relay Specifications. (Group 9015-10.)

Check continuity of fuses (F18 and F28).

Is continuity indicated?

YES: Go to Circuit Check.

NO: Replace fuse(s) without continuity.

---1/1

9001
10
6

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

<p>3 Circuit Check</p>	<p>Turn key switch OFF.</p> <p>Disconnect TCU connector (X23). See Load Center Harness (W3) Component Location. (Group 9015-10.)</p> <p>Turn keys switch ON.</p> <p>Check circuit P18 RED for voltage between pin 23 on TCU connector (X23) and machine ground. See Load Center Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p>Check circuit P28 RED for voltage between pin 45 on TCU connector (X23) and machine ground.</p> <p>Check circuit P28 RED for voltage between pin 68 on TCU connector (X23) and machine ground.</p> <p>Is system voltage (approximately 24 volts) present?</p>	<p>YES: Go to next step in this check.</p> <p>NO: Open circuit in load center harness (W3). Repair circuit without voltage or replace harness.</p>
	<p>Turn key switch OFF.</p> <p>TCU connector (X23) disconnected.</p> <p>Check circuit G01 BLK for ground at pins 1 and 2 on TCU connector (X23). See Load Center Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p>Is ground present?</p>	<p>YES: Go to CAN Circuit Check.</p> <p>NO: Circuit G01 BLK open circuit in load center harness (W3). Repair circuit G01 BLK or replace harness.</p>
<p>4 CAN Circuit Check</p>	<p>Perform CAN Circuit Test. (Group 9015-20.)</p> <p>Does CAN circuit test good?</p>	<p>YES: Go to Reprogram Transmission Control Unit.</p> <p>NO: Repair CAN circuit.</p>
<p>5 Reprogram Transmission Control Unit</p>	<p>Reprogram transmission control unit (TCU).</p> <p>Check active codes.</p> <p>Is CMU code 002003.09 present?</p>	<p>YES: Replace TCU.</p> <p>NO: Checks complete.</p>
<p>6 Reprogram CAN Monitor Unit</p>	<p>Reprogram CAN monitor unit (CMU).</p> <p>Check active codes.</p> <p>Is CMU code 002003.09 present?</p>	<p>YES: Replace CMU.</p> <p>NO: Checks complete.</p>

9001
10
7

--1/1

--1/1

--1/1

--1/1

002033.09 — Missing Message From FLC

The CAN monitor unit (CMU) is not receiving a CAN signal from flex load controller (FLC).

AA95137,00008F8 -19-05JUN07-1/1

FLC Signal Missing from CMU Diagnostic Procedure

Alarm Level:

No Warning Lamp

---1/1

1 Controller Sensors Check

Turn key switch ON.

View flex load controller (FLC) monitored sensor outputs by accessing the Diagnostics / Hydraulic / Display All menu on the CAN monitor unit (CMU). See CAN Monitor Unit (CMU) Menu Structure—Service Mode. (Group 9015-20.)

Does the monitor show a reading for all sensors?

YES: Go to Reprogram CAN Monitor Unit.

NO: Go to Fuse Check.

---1/1

2 Fuse Check

Turn key switch OFF.

Remove fuses (F15 and F21). See Fuse and Relay Specifications. (Group 9015-10.)

Check continuity of fuses (F15 and F21).

Is continuity indicated?

YES: Go to Circuit Check.

NO: Replace fuse(s) without continuity.

---1/1

9001
10
8

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

3 Circuit Check	<p>Turn key switch OFF.</p> <p>Disconnect FLC connector (X41). See Load Center Harness (W3) Component Location. (Group 9015-10.)</p> <p>Turn key switch ON.</p> <p>Check circuit P21 RED for voltage between pin L1 on FLC connector (X41) and machine ground. See Load Center Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p>Check circuit P15 RED for voltage between pin M1 on FLC connector (X41) and machine ground.</p> <p>Is system voltage (approximately 24 volts) present?</p>	<p>YES: Go to next step in this check.</p> <p>NO: Open circuit in load center harness. Repair circuit without voltage or replace harness.</p>
	<p>Turn key switch OFF.</p> <p>FLC connector (X41) disconnected.</p> <p>Check for ground at pins M2 and L2 (circuit G01 BLK) on FLC connector (X41). See Load Center Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p>Is ground present?</p>	<p>YES: Go to CAN Circuit Check.</p> <p>NO: Circuit G01 BLK open circuit in load center harness (W3). Repair circuit G01 BLK or replace harness.</p>
4 CAN Circuit Check	<p>Perform CAN Circuit Test. (Group 9015-20.)</p> <p>Does CAN circuit test good?</p>	<p>YES: Go to Reprogram Flex Load Controller.</p> <p>NO: Repair CAN circuit.</p>
5 Reprogram Flex Load Controller	<p>Reprogram flex load controller (FLC).</p> <p>Check for active codes.</p> <p>Is CMU code 002033.09 present?</p>	<p>YES: Replace FLC.</p> <p>NO: Checks complete.</p>
6 Reprogram CAN Monitor Unit	<p>Reprogram CAN monitor unit (CMU).</p> <p>Check for active codes.</p> <p>Is CMU code 002033.09 present?</p>	<p>YES: Replace CMU.</p> <p>NO: Checks complete.</p>

9001
10
9

---1/1

---1/1

---1/1

---1/1

002140.09 — Missing Message From SSM

The CAN monitor unit (CMU) is not receiving a CAN signal from the sealed switch module (SSM).

AA95137,00008FA -19-09APR07-1/1

SSM Signal Missing from CMU Diagnostic Procedure

Alarm Level:

No Warning Lamp

--1/1

1 Button Check

Turn key switch ON.

Access the sealed switch module (SSM) test by accessing the Diagnostics / Switch Module menu on the CAN monitor unit (CMU). See CAN Monitor Unit (CMU) Menu Structure—Service Mode. (Group 9015-20.)

Push the buttons on the SSM.

Do the corresponding squares on the CMU window come on when the buttons are pushed?

YES: CMU is communicating with the SSM. Go to Reprogram CAN Monitor Unit.

NO: Go to Fuse Check.

--1/1

2 Fuse Check

Turn key switch OFF.

Remove fuse (F13). See Fuse and Relay Specifications. (Group 9015-10.)

Check continuity of fuse (F13).

Is continuity indicated?

YES: Go to Circuit Check.

NO: Replace fuse (F13).

--1/1

9001
10
10

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

3 Circuit Check	Turn key switch OFF. Disconnect SSM connector (X53). See Load Center Harness (W3) Component Location. (Group 9015-10.) Turn key switch ON. Check circuit P13 RED for voltage between pin 1 on SSM connector (X53) and machine ground. See Load Center Harness (W3) Wiring Diagram. (Group 9015-10.) Is system voltage (approximately 24 volts) present?	YES: Go to next step in this check. NO: Circuit P13 open circuit on load center harness (W3). Repair circuit P13 RED or replace harness.
	Turn key switch OFF. SSM connector (X53) disconnected. Check circuit G01 BLK for ground at pin 2 on SSM connector (X53). See Load Center Harness (W3) Wiring Diagram. (Group 9015-10.) Is ground present?	YES: Go to CAN Circuit Check. NO: Circuit G01 BLK open circuit in load center harness (W3). Repair circuit G01 BLK or replace harness.
4 CAN Circuit Check	Perform CAN Circuit Test. (Group 9015-20.) Does CAN circuit test good?	YES: Go to Reprogram Sealed Switch Module. NO: Repair CAN circuit.
5 Reprogram Sealed Switch Module	Reprogram sealed switch module (SSM). Check for active codes. IS CMU code 002140.09 present?	YES: Replace controller. NO: Checks complete.
6 Reprogram CAN Monitor Unit	Reprogram CAN monitor unit (CMU). Check for active codes. Is CMU code 002140.09 present?	YES: Replace controller. NO: Checks complete.

9001
10
11

002367.04 — Left Turn Switch Short to Ground

Left turn input signal is short to ground.

AA95137.00008FB -19-09APR07-1/1

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

Left Turn Switch Short to Ground Diagnostic Procedure

Alarm Level:

No Warning Lamp

---1/1

1 Component Check

Turn key switch OFF.

Disconnect turn switch (S25) connector. See Front Console Harness (W4) Component Location. (Group 9015-10.)

Put turn switch (S25) in the LEFT turn position.

Check for continuity between pins E and F on switch.

Is continuity indicated?

YES: Go to Short Circuit Check.

NO: Turn switch (S25) malfunction. Replace switch.

---1/1

2 Short Circuit Check

Turn key switch OFF.

Disconnect turn switch (S25) connector. See Front Console Harness (W4) Component Location. (Group 9015-10.)

Check circuit L07 BRN for ground at pin E on turn switch (S25) connector. See Front Console Harness (W4) Wiring Diagram. (Group 9015-10.)

Is ground present?

YES: Go to next step in this check.

NO: Go to Reprogram Controller.

Key switch OFF and turn switch (S25) disconnected.

Disconnect CMU connector (X48). See Front Console Harness (W4) Component Location. (Group 9015-10.)

Check circuit L07 BRN for ground at pin E on turn switch (S25) connector. See Front Console Harness (W4) Wiring Diagram. (Group 9015-10.)

Is ground present?

YES: Circuit L07 BRN short to ground on front console harness (W4). Repair circuit L07 BRN or replace harness.

NO: Go to Continuity Check.

---1/1

9001
10
12

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

<p>3 Continuity Check</p>	<p>Turn manual battery disconnect (S2) OFF.</p> <p>Disconnect turn switch (S25) and CMU connector (X48). See Front Console Harness (W4) Component Location. (Group 9015-10.)</p> <p>Check continuity between pin R (circuit L07 BRN) on CMU connector (X48) and all other pins on CMU connector (X48). See Front Console Harness (W4) Wiring Diagram. (Group 9015-10.)</p> <p>Is continuity indicated?</p>	<p>YES: Circuit L07 BRN is short to circuit with continuity indicated on front frame harness (W4). Repair circuit L07 BRN or replace harness.</p> <p>NO: Go to Reprogram Controller.</p> <p align="right">-- -1/1</p>
----------------------------------	--	---

9001
10
13

<p>4 Reprogram Controller</p>	<p>Reprogram CAN monitor unit (CMU).</p> <p>Check for active codes.</p> <p>Is CMU code 002367.04 present?</p>	<p>YES: Replace controller.</p> <p>NO: Checks complete.</p> <p align="right">-- -1/1</p>
--------------------------------------	---	--

002369.04 — Right Turn Switch Short to Ground

The right turn input signal is short to ground.

AA95137.00008FC -19-09APR07-1/1

Right Turn Switch Short to Ground Diagnostic Procedure

Alarm Level:

No Warning Lamp

-- -1/1

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

9001
10
14

<p>1 Component Check</p>	<p>Turn key switch OFF.</p> <p>Disconnect turn switch (S25) connector. See Front Console Harness (W4) Component Location. (Group 9015-10.)</p> <p>Put turn switch (S25) in the RIGHT turn position.</p> <p>Check for continuity between pins D and F on switch.</p> <p>Is continuity indicated?</p>	<p>YES: Go to Short Circuit Check.</p> <p>NO: Turn switch (S25) malfunction. Replace switch.</p> <p style="text-align: right;">---1/1</p>
<p>2 Short Circuit Check</p>	<p>Turn key switch OFF.</p> <p>Disconnect turn switch (S25) connector. See Front Console Harness (W4) Component Location. (Group 9015-10.)</p> <p>Check circuit L10 BRN for ground at pin D on turn switch (S25) connector.</p> <p>Is ground present?</p> <hr/> <p>Key switch OFF and turn switch (S25) disconnected.</p> <p>Disconnect CMU connector (X48). See Front Console Harness (W4) Component Location. (Group 9015-10.)</p> <p>Check circuit L10 BRN for ground at pin D on turn switch (S25) connector. See Front Console Harness (W4) Wiring Diagram. (Group 9015-10.)</p> <p>Is ground present?</p>	<p>YES: Go to next step in this check.</p> <p>NO: Go to Reprogram Controller.</p> <hr/> <p>YES: Circuit L10 BRN is short to ground on front frame harness (W4). Repair circuit L10 BRN or replace harness.</p> <p>NO: Go to Continuity Check.</p> <p style="text-align: right;">---1/1</p>
<p>3 Continuity Check</p>	<p>Turn manual battery disconnect (S2) OFF.</p> <p>Turn switch (S25) disconnected and CMU connector (X48) disconnected.</p> <p>Check continuity between pin S (circuit L10 BRN) on CMU connector (X48) and all other pins on CMU connector (X48).</p> <p>Is continuity indicated?</p>	<p>YES: Circuit L10 BRN is short to circuit with continuity indicated on front frame harness (W4). Repair circuit L10 BRN or replace harness. See Front Console Harness (W4) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to Reprogram Controller.</p> <p style="text-align: right;">---1/1</p>
<p>4 Reprogram Controller</p>	<p>Reprogram CAN monitor unit (CMU).</p> <p>Check for active codes.</p> <p>Is CMU code 002369.04 present?</p>	<p>YES: Replace controller.</p> <p>NO: Checks complete.</p> <p style="text-align: right;">---1/1</p>

524250.31 — Inspect Park Brake

The CAN monitor unit (CMU) indicates that the park brake has been applied and the machine speed was 15.5 miles an hour or more.



CAUTION: The park brake should be checked before operation of vehicle due to possible park brake damage. CMU code 524250.31 will stay active and park brake indicator light will flash (regardless of park brake position) until code is cleared. For more information on the park brake operation, see Transmission Control Unit (TCU) Circuit Theory of Operation. (Group 9015-15.)

AA95137,0000938 -19-31MAY07-1/1

Inspect Park Brake Diagnostic Procedure

-- 1/1

<p>1 Component Check</p>	<p>Check operation of park brake. Perform Park Brake Check. See Operational Checkout. (Group 9005-10.)</p> <p>Does park brake test good?</p>	<p>YES: Checks complete.</p> <p>NO: See Park Brake Diagnose Malfunctions.</p>
---------------------------------	--	---

-- 1/1

CAN Monitor Unit (CMU) Diagnostic Trouble Codes

9001
10
16

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com