



ENGINE REPAIR MANUAL

ENGINE

ISUZU

4LE2

TIER 3

CNH America, LLC reserves the right to make improvements in design or changes in specifications at any time without incurring any obligation to install them on units previously sold.

All data given in this publication is subject to production variations. Dimensions and weights are only approximate. Illustrations do not necessarily show products in standard condition. For exact information about any particular product, please consult your Dealer

| REVISION HISTORY | | | |
|------------------|------------|--------------------------|-------------|
| Issue | Issue Date | Applicable Machines | Remarks |
| First Edition | 01April 08 | Isuzu 4LE2 Tier 3 Engine | 87495896 NA |

General Information

General Information

Table of Contents


| | |
|-------------------------------|-------|
| General Information | 0A-2 |
| Service Precautions | 0A-2 |
| Reading the Model | 0A-7 |
| General Information | 0A-8 |
| Recommended Lubricant | 0A-14 |
| List of Trouble Symptom | 0A-15 |
| Repair Standard | 0A-24 |

General Information

Service Precautions


In order to carry out work safely

1. Always use an engine stand when taking the engine down from the vehicle.
Do not place the engine directly onto the ground, or place in a manner that interferes with the oil pan.
2. If you are working together with others, always pay attention to each other's safety.
3. If you are repairing any part of the electrical system, always remove the minus side cable from the battery terminal before starting work. If you are removing the battery cover, always remove the cover in a place that is away from sources of fire/heat.




4. Do not perform painting work or leave the engine running for long periods of time in an enclosed or badly ventilated indoor workshop.


5. Always use the correct specialized tool indicated in the instructions. Using the incorrect tool may cause damage to the parts or injury to the person using the tool.




6. All regular tools, gauges and special tools should be regularly inspected, and prepared before starting work. Do not use bent spanners, hammers with damaged edges, chipped chisels, or any other faulty or damaged tools.



7. Always pay close attention to safety and handling requirements when using grinders, cranes, welders, and other such equipment. Moreover, always wear the correct protective garments and use the necessary safety tools for the job in hand.



8. Always check that there are no fuel leaks when performing maintenance work on the fuel system. (It may cause a fire.)



9. Pay close attention to the risk of ignition if you are handling parts that carry a high voltage. Furthermore, any oil or grease spilt onto rubber parts must be wiped off immediately, as it will cause deterioration of the rubber.



Replacement parts and part numbers

1. Always replace packing, oil seals, O-rings, caulking lock nuts, folding lock plates, split pins and other such parts with brand new parts.
2. The parts numbers contained in this manual may not represent the supply condition of the parts, and the part numbers may be changed due to revisions. Therefore, parts should always be checked against a parts catalogue before use.

0A-4 General Information

Liquid gasket

- Each time you disassemble parts that use liquid gasket, completely remove the old gasket residue from each of the parts and matching sections using a scraper, then clean each of the parts to completely remove oil, water, and dirt etc. from the various surfaces by a cloth. Using the specified type of liquid gasket, apply new liquid gasket to each of the surfaces before reassembling the parts.
- In order to make it easier to clean liquid gasket surfaces, apply gasket remover liquid (Pando- 391D made by ThreeBond Co., Ltd.) and leave the part to stand for approximately 10 minutes, after which the old liquid gasket residue will be easier to remove.
However, this should not be used on resin components or painted components.

- Please take care not to apply too much or too little liquid gasket.
Also, you should always re-apply the liquid gasket upon itself when you start and finish application.
- Make sure that there are no gaps when reinstalling the liquid gasket parts to each other. If there are gaps between the two parts, re-apply the liquid gasket. Some parts, especially the oil pan, use the same size studs as a guide to eliminate the need for knock pin positioning etc.
- Re-install these parts within 5 minutes of applying the liquid gasket.
If more than 5 minutes passes, remove the previous liquid gasket and re-apply it.
- Please wait for at least 30 minutes since the last part is installed before starting the engine.

Liquid gasket

| | Applied area | | Use conditions | | Liquid gasket name |
|---|-------------------------------|---------------------|-----------------------|--------------------|--------------------|
| | Parts | Matching parts | Seal object | Application groove | |
| 1 | Rocker bracket | Cylinder head | Engine oil (10W — 30) | Equipped | TB 1207B |
| 2 | Air inlet pipe | Cylinder head cover | Air | Equipped | TB 1207C |
| 3 | Timing case | Cylinder block | Engine oil (10W — 30) | Equipped | TB 1207B |
| 4 | Housing cover; injection pump | Cylinder block | Engine oil (10W — 30) | None | TB 1207C |
| 5 | Solenoid; fuel cut | Cylinder block | Engine oil (10W — 30) | Equipped | TB 1207C |
| 6 | Retainer; oil seal | Cylinder block | Engine oil (10W — 30) | Equipped | TB 1207B |
| 7 | Housing ASM; PCV | Cylinder head cover | Blow-by gas | None | TB 1207C |
| 8 | Indicator; air cleaner | Air cleaner | Air | None | (Seal tape) |

- Always use the liquid gasket products listed above, or a liquid gasket identical to the ones listed above.
- Use the correct quantity of liquid gasket. Always follow the handling instructions for each product.

Application procedure


1. Wipe the contact surfaces clean of all water, oil or grease. The contact surfaces should be dry.
2. Apply a regular bead width of liquid gasket to one of the contact surfaces. Make sure that the bead does not break at this point.

Note:

If there are special regulations concerning the application procedure in the repair document, please follow those regulations.

Work procedure

1. Wipe the joint surfaces of the bolt, bolt hole, and threads clean of water, grease, and oil. The contact surfaces should be dry.
2. Apply Loctite to the top 1/3 of the screw.
3. Tighten the bolt to the specified torque.



Important:

After tightening the bolt, do not apply excessive torque or try to rotate the bolt until at least one hour has passed, and the Loctite has hardened.

Procedure for using the plastigauge

| Type | Measurable range mm {in} |
|--------------|-------------------------------|
| PG-1 (Green) | 0.025 — 0.076 {0.001 — 0.003} |
| PR-1 (Red) | 0.051 — 0.152 {0.002 — 0.006} |
| PB-1 (Blue) | 0.102 — 0.229 {0.004 — 0.009} |



Example: Procedure for measuring the clearance between the connecting rod bearing and crank pin.

- Clean the connecting rod and bearing, and install the bearing to the rod.
- Cut the plastigauge to the same width as the crank pin, and while avoiding the oil hole of the crank pin lay the gauge parallel to the pin.
- Line up the marks on the connecting rod and cap, and install the crank pin. Apply molybdenum disulfide to the thread section and seating surface of the tightening bolt, and rotate both cap and bolt to the correct torque.

Important:

Do not move the connecting rod while using the plastigauge.

- Gently remove the cap and connecting rod, and measure the crushed width of the plastigauge (clearance between rod and pin) using the scale printed on the bag.



0A-6 General Information



Example: Measuring the clearance between the crank bearing and crank journal

- Clean the clamp face of the cylinder block and crankcase bearing, and also the bearing, and install the cylinder block to the crankcase.
- Gently rest the crankshaft on the cylinder block, and rotate it approximately 30 degree to stabilize it.
- Cut the plastigauge to the same size as the journal width, and while avoiding the oil hole of the journal lay the gauge parallel to the journal.
- Gently rest the crankcase on the cylinder block, apply molybdenum disulfide to the thread section and seating surface of the tightening bolt, and tighten in sequence to the correct torque.

Important:


Do not rotate the crankshaft while using the plastigauge.

- Gently remove the crankcase, and measure the crushed width of the plastigauge (clearance between bearing and journal) using the scale printed on the bag.



Reading the Model

Engine number stamping position



General Information

Terminology, description of abbreviations

Terminology definitions

Maintenance standard

The generic name for reference values required for maintenance, such as nominal dimension, assembly specification, and limit.

Nominal dimension

Shows the standard value at the point of manufacture that does not include the common difference.

Assembly specification

Shows the standard value after assembling, repairing, or adjusting.

Service limit

When this value (dimensions) is reached, it shows that the part has reached its full limit and must be replaced or repaired.

Wear

Shows the difference between the dimension of non-worn part (nominal dimension unless there is such part) and that of the most worn part (the dimension of worn part).

Uneven wear

Shows the difference between the maximum and the minimum wear amount.

Front/Rear, Right/Left, Top/Bottom

These show each orientations of parts installed to the vehicle when looking from the vehicle's forward direction.

Unit

Units written to SI conventions (mainly torque, pressure, force)

[Example] Length: mm, Torque: N·m {kgf·m}

Warning

Items that carry the warning mark pose a danger to life or threat of serious injury if not strictly observed.

Caution

Items that carry the caution mark may cause injury or lead to accidents if not strictly observed.

Important

Items that carry the important mark may cause the vehicle to break down, or may prevent the guaranteed normal operation of the system or related parts if not strictly observed.

Note

Items that should receive special mention within a work procedure.

Description of abbreviations

| Abbreviation | Description |
|--------------|---|
| AC | Alternating Current |
| ACC | Accessory |
| ACG | Alternating Current Generator |
| API | American Petrol Institute |
| ASM (Assy) | Assembly |
| ATDC | After Top Dead Center |
| BAT, BATT | Battery |
| BRG, Brg | Bearing |
| BKT, BRKT | Bracket |
| BTDC | Before Top Dead Center |
| CO | Carbon Oxide |
| CONN | Connector |
| CPU | Central Processing Unit |
| C/U | Control Unit |
| DC | Direct Current |
| DI | Direct Injection |
| ECU | Engine Control Unit/Electronic Control Unit |
| ECM | Engine Control Module |
| EGR | Exhaust Gas Recirculation |
| Exh, EXH | Exhaust |
| Ft, FRT | Front |
| FWD | Forward |
| F/C | Fuel Cut |
| GND | Ground |
| IC | Integrated Circuit |
| ID Plate | Identification Plate |
| IN | Intake, Inlet |
| ISO | International Organization for Standardization |
| I/PUMP | Injection Pump |
| JIS | Japanese Industrial Standard |
| L/H, LH | Left Hand |
| M/V | Magnetic Valve |
| NOx | Nitrogen Oxide |
| N-TDC | Number - Top Dead Center |
| OPT | Option |
| P | Pole(S) |
| PCV | Pump Control Valve/Positive Crankcase Ventilation |

| Abbreviation | Description |
|--------------|--|
| PM | Particulate Matter |
| PS | Pre-Stroke |
| PTO | Power Take Off |
| QOS | Quick On System |
| Rr, RR | Rear |
| R/H, RH | Right Hand |
| R/L | Relay |
| STD | Standard |
| SW | Switch |
| TICS | Timing & Injection rate Control System |
| VGS Turbo | Variable Geometry turbocharger System |
| W/L | Warning Lamp |

SI (International System of Units)

With regards the conversion to SI (International System of Units)

The introduction of the SI systems aims to internationally unify the metric system and the various units used by different countries (traditional weights and measures, the foot pound method etc.), and to curb the confusion that occurs between the different units (conversion calculations etc.).

The new calculating method which adopted SI units was completely adopted in Japan in 1992, and is standardized by JIS-Z-8203.

All of the units in this manual are written in line with the International System of Units SI units, and conventional units are written in { } brackets.

SI

Abbreviation of French word "Le Systeme International d'Unites"

Connection between main SI units and conventional units

| | SI | Conventional unit | Item, unit conversion |
|-----------------------------------|----------------|-----------------------------|--|
| Length | m | m | Same as the conventional unit |
| Weight (Mass) | kg | kg | Same as the conventional unit |
| Force | N | * kg, kgf | 1 kgf = 9.80665 N |
| Torque | N·m | * kg·m, kgf·m | 1 kgf·m = 9.80665 N·m |
| Pressure | Pa | * kg/cm ² , mmHg | 1 kgf/cm ² = 9.80665 kPa, 1 mmHg = 133.3 Pa |
| Power output, horsepower | W | PS | 1 PS = 0.74 kW |
| Capacity, air volume displacement | m ³ | Liter, L, cc | 1 Liter = 1 dm ³ , 1 cc = 1 m Liter = 1 cm ³ |
| Fuel consumption | g/(kW·h) | g/(PS·h) | 1 g/(PS·h) = 1.360 g/(kW·h) |

*1 Published service data may conveniently use kg for force and mass (weight) instead of kgf.

*2 Some conversion results may be rounded off to 1 or 2 decimal places.

Converting expressions of quantity

When converting, prefixes such as k (kilo) or m (milli) are used.

| | | | |
|---|-------|------------------|-----------|
| M | Mega | 10 ⁶ | 1,000,000 |
| k | Kilo | 10 ³ | 1,000 |
| h | Hecto | 10 ² | 100 |
| d | Deci | 10 ⁻¹ | 0.1 |
| c | Centi | 10 ⁻² | 0.01 |
| m | Milli | 10 ⁻³ | 0.001 |
| μ | Micro | 10 ⁻⁶ | 0.000001 |

- 200 kgf/cm² = 19,620 kPa = 19.6 MPa
- 40 mmHg = 5,332 Pa = 5.3 kPa

Conversion formula

Length

- km × 0.6214 = mile
- m × 3.281 = ft
- mm × 0.03937 = in

Pressure

- kPa × 0.0101972 = kg/cm²
- kPa × 0.145038 = psi
- MPa × 10.197162 = kg/cm²
- MPa × 145.03774 = psi

Tightening torque

- N·m × 0.101972 = kg·m
- N·m × 0.737562 = lb·ft

Speed

- km/h × 0.6214 = MPH

Temperature

- °C × 1.8 + 32 = °F

0A-10 General Information

Table of Isuzu standard tightening torque

The tightening torque values in the table below apply to all situations unless a special tightening torque is specified.

Isuzu standard bolts, nuts


| N·m {kgf·m} | | | | |
|-------------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|
| Strength classification | 4.8 4T | | 7T | |
| Shape of bolt head | Hexagon head bolt | Flange bolt | Hexagon head bolt | Flange bolt |
| *M10 × 1.5 | 19.6 — 33.3 {2.0 — 3.4} | 22.3 — 37.2 {2.3 — 3.8} | 27.5 — 45.1 {2.8 — 4.6} | 30.3 — 50.4 {3.1 — 5.1} |
| M12 × 1.25 | 49.0 — 73.5 {5.0 — 7.5} | 54.9 — 82.3 {5.6 — 8.4} | 60.8 — 91.2 {6.2 — 9.3} | 68.1 — 102.1 {6.9 — 10.4} |
| *M12 × 1.75 | 45.1 — 68.6 {4.6 — 7.0} | 51.0 — 76.5 {5.2 — 7.8} | 56.9 — 84.3 {5.8 — 8.6} | 62.7 — 94.0 {6.4 — 9.6} |
| M14 × 1.5 | 76.5 — 114.7 {7.8 — 11.7} | 83.0 — 124.5 {8.5 — 12.7} | 93.2 — 139.3 {9.5 — 14.2} | 100.8 — 151.1 {10.3 — 15.4} |
| *M14 × 2 | 71.6 — 106.9 {7.3 — 10.9} | 77.2 — 115.8 {7.9 — 11.8} | 88.3 — 131.4 {9.0 — 13.4} | 94.9 — 142.3 {9.7 — 14.5} |
| M16 × 1.5 | 104.0 — 157.0 {10.6 — 16.0} | 115.6 — 173.3 {11.8 — 17.7} | 135.3 — 204.0 {13.8 — 20.8} | 150.1 — 225.2 {15.3 — 23.0} |
| *M16 × 2 | 100.0 — 149.1 {10.2 — 15.2} | 109.4 — 164.2 {11.2 — 16.7} | 129.4 — 194.2 {13.2 — 19.8} | 142.5 — 213.8 {14.5 — 21.8} |
| M18 × 1.5 | 151.0 — 225.6 {15.4 — 23.0} | — | 195.2 — 293.2 {19.9 — 29.9} | — |
| *M18 × 2.5 | 151.0 — 225.6 {15.4 — 23.0} | — | 196.1 — 294.2 {20.0 — 30.0} | — |
| M20 × 1.5 | 206.0 — 310.0 {21.0 — 31.6} | — | 269.7 — 405.0 {27.5 — 41.3} | — |
| *M20 × 2.5 | 190.2 — 286.4 {19.4 — 29.2} | — | 249.1 — 374.6 {25.4 — 38.2} | — |
| M22 × 1.5 | 251.1 — 413.8 {25.6 — 42.2} | — | 362.8 — 544.3 {37.0 — 55.5} | — |
| *M22 × 2.5 | 217.7 — 327.5 {22.2 — 33.4} | — | 338.3 — 507.0 {34.5 — 51.7} | — |
| M24 × 2 | 358.9 — 539.4 {36.6 — 55.0} | — | 430.5 — 711.0 {43.9 — 72.5} | — |
| *M24 × 3 | 338.3 — 507.0 {34.5 — 51.7} | — | 406.0 — 608.0 {41.4 — 62.0} | — |

The * mark indicates where soft materials have been used for internal thread sections, such as castings.

| N·m {kgf·m} | | | | |
|-------------------------|-----------------------------|-----------------------------|-----------------------------|-----------------------------|
| Strength classification | 8.8 | | 9.8 9T | |
| Shape of bolt head | Hexagon head bolt | Flange bolt | Hexagon head bolt | Flange bolt |
| M6 × 1 | 5.6 — 11.2 {0.6 — 1.1} | 6.6 — 12.2 {0.6 — 1.2} | — | — |
| M8 × 1.25 | 13.4 — 25.7 {1.4 — 2.6} | 15.3 — 28.4 {1.6 — 2.9} | 16.7 — 30.4 {1.7 — 3.1} | 18.1 — 33.6 {1.9 — 3.4} |
| M10 × 1.25 | 31.3 — 52.5 {3.2 — 5.4} | 35.4 — 58.9 {3.6 — 6.1} | 37.3 — 62.8 {3.8 — 6.4} | 42.3 — 70.5 {4.3 — 7.2} |
| *M10 × 1.5 | 31.3 — 51.4 {3.2 — 5.2} | 34.5 — 57.5 {3.5 — 5.8} | 36.3 — 59.8 {3.7 — 6.1} | 40.1 — 66.9 {4.1 — 6.8} |
| M12 × 1.25 | 69.3 — 104.0 {7.1 — 10.6} | 77.7 — 116.5 {7.9 — 11.9} | 75.5 — 113.8 {7.7 — 11.6} | 85.0 — 127.5 {8.7 — 13.0} |
| *M12 × 1.75 | 64.8 — 96.1 {6.6 — 9.8} | 71.4 — 107.2 {7.3 — 10.9} | 71.6 — 106.9 {7.3 — 10.9} | 79.5 — 119.2 {8.1 — 12.2} |
| M14 × 1.5 | 106.2 — 158.8 {10.8 — 16.2} | 114.9 — 172.3 {11.7 — 17.6} | 113.8 — 170.6 {11.6 — 17.4} | 123.4 — 185.1 {12.6 — 18.9} |
| *M14 × 2 | 100.6 — 149.8 {10.3 — 15.3} | 108.2 — 162.2 {11.1 — 16.6} | 106.9 — 160.0 {10.9 — 16.3} | 115.5 — 173.3 {11.8 — 17.7} |
| M16 × 1.5 | 154.3 — 232.5 {15.7 — 23.7} | 171.1 — 256.7 {17.4 — 26.2} | 160.0 — 240.3 {16.3 — 24.5} | 176.9 — 265.3 {18.0 — 27.1} |
| *M16 × 2 | 147.6 — 221.4 {15.0 — 22.6} | 162.5 — 243.8 {16.6 — 24.9} | 153.0 — 229.5 {15.6 — 23.4} | 168.5 — 252.7 {17.2 — 25.8} |
| M18 × 1.5 | 222.5 — 334.3 {22.7 — 34.1} | — | 229.5 — 345.2 {23.4 — 35.2} | — |
| *M18 × 2.5 | 223.6 — 335.4 {22.8 — 34.2} | — | 230.5 — 346.2 {23.6 — 35.3} | — |
| M20 × 1.5 | 307.4 — 461.7 {31.4 — 47.1} | — | 316.8 — 475.6 {32.3 — 48.5} | — |
| *M20 × 2.5 | 284.0 — 472.1 {29.0 — 43.5} | — | 293.2 — 440.3 {29.2 — 44.9} | — |
| M22 × 1.5 | 413.6 — 620.5 {42.2 — 63.3} | — | 424.6 — 636.5 {43.3 — 64.9} | — |
| *M22 × 2.5 | 385.7 — 578.0 {39.3 — 58.9} | — | 394.2 — 592.3 {40.0 — 60.4} | — |
| M24 × 2 | 490.8 — 810.5 {50.0 — 82.7} | — | 554.1 — 830.6 {56.5 — 84.7} | — |
| *M24 × 3 | 462.8 — 693.1 {47.2 — 70.7} | — | 520.7 — 781.6 {53.1 — 79.7} | — |

The * mark indicates where soft materials have been used for internal thread sections, such as castings.

Designations for Isuzu standard bolt heads



LNW20AMF000401

Name

- | | |
|--|--|
| 1. Hexagon Head Bolt (4.8, 4T) | 9. Hexagon Head Bolt (Nonthermal Refined 8.8) |
| 2. Hexagon Head Bolt (4.8, 4T) | 10. Hexagon Head Bolt (Nonthermal Refined 8.8) |
| 3. Flange Bolt (4.8, 4T) | 11. Flange Bolt (8.8) |
| 4. Flange Bolt (4.8, 4T) | 12. Flange Bolt (8.8) |
| 5. Hexagon Head Bolt (7T) | 13. Hexagon Head Bolt (9.8, 9T) |
| 6. Flange Bolt (7T) | 14. Hexagon Head Bolt (9.8, 9T) |
| 7. Hexagon Head Bolt (Thermal Refined 8.8) | 15. Flange Bolt (9.8, 9T) |
| 8. Hexagon Head Bolt (Thermal Refined 8.8) | 16. Flange Bolt (9.8, 9T) |

Flare nut

| | Pipe diameter | Tightening torque (for medium and large size vehicles) | Width across flats of flare nut (mm) | |
|---|---------------|--|---|-----|
| | | | Old | New |
| Flare nut tightening torque (service standard value) N·m {kgf·m} | φ 4.76 mm | 12.8 — 18.6 {1.3 — 1.9} | 14 | 14 |
| | φ 6.35 mm | 23.5 — 49 {2.4 — 5.0} | 17 | 17 |
| | φ 8.0 mm | 23.5 — 49 {2.4 — 5.0} | 19 | 17 |
| | φ 10.0 mm | 44.1 — 93.2 {4.5 — 9.5} | 22 | 19 |
| | φ 12.0 mm | 58.8 — 137.3 {6.0 — 14.0} | 27 | 24 |
| | φ 15.0 mm | 78.5 — 156.9 {8.0 — 16.0} | 30 | 30 |

Taper screw from connectors (brass)

| N·m {kgf·m} | | | | |
|-------------|---------------------------|---------------------------|---------------------------|---------------------------|
| Screw size | PT (R) 1/8 | PT (R) 1/4 | PT (R) 3/8 | PT (R) 1/2 |
| — | 2.0 — 14.7 {0.2 — 1.5} | 4.9 — 15.7 {0.5 — 1.6} | 9.8 — 16.7 {1.0 — 1.7} | 9.8 — 17.7 {1.0 — 1.8} |


About angle method tightening

Though the general and current way to tighten bolts and nuts is torque indication, using this way results in large unevenness of shaft power to indicated torque. Therefore, bolts may be damaged at upper limit when you try to ensure minimal shaft power.

To ensure shaft power with small unevenness, it is necessary to tighten bolts measuring stretch amount of bolts, but this is actually impossible. So the angle method focuses on screw pitch as equivalent to bolt stretch, and controls using the screw rotation amount. The method can reduce the unevenness of shaft power by tightening to plastic range.

How to tighten


1. Apply molybdenum disulfide or engine oil to the threads and the seating surface of the bolt following the instruction.
2. Tighten all bolts to the pre-indicated tightening torque.
3. Draw lines on the surface of the parts you tighten: the lines which pass through the bolt's center (A — B: bolt side) (C — D: parts side) and the line at the specified tightening angle from the bolt's center (E — F).



Name

1. Specified Tightening Torque

4. Tighten the bolt with wrench until the line on the bolt (A — B) aligns with the specified angle line (E — F on the surface of the parts).



Be sure to check the mark to see whether you tighten the bolt to the specified angle or not. If you fail this, you may tighten the bolt by the angle method again by accident and damage the bolt. Take extreme care.

Important:

- Follow the instructed order to tighten bolts.
- Do not retighten if you tighten by the angle method.

Bolt angle gauge (380300009), the tool for tightening bolts by the angle method, is set.

Special tool classification

A; Essential tool

Servicing operation cannot be done with any other tools than the essential tool.

B; Recommend tool

Servicing work can be done with a general-purpose tool commercially available. However, it is advisable to use the recommended tool as much as possible for a reduced work time and an improved safety in work operations.

C; Available tool

Although it takes a more working time, servicing operations can be made with a tool commercially available as substitute for the available tool.

0A-14 General Information


Recommended Lubricant

Engine oil and garde

Refer to the Operator's Manual.


List of Trouble Symptom

Engine does not start




Note: "Bring it to a specialty shop" means that defective parts of the injection pump and electricals must be brought to a specialty shop for repair. (This note is applicable to all the following procedures.)


Engine speed lacks smoothness (Unstable engine rotation)




Output shortage (insufficient output)




Overheat




Exhaust fault (Abnormal exhaust gas)




Battery over discharge




Oil pressure is too low



Fuel consumption deteriorates (too much consumption)




Oil consumption deteriorates (Oil consumption too much)



(*) Worn bore, and worn or broken ring
(Measure compression pressure, and check entrance of dust)

Engine knocking



0A-24 General Information

Repair Standard

1. This table specifies the repair standard for **4LE2X model** "ISUZU diesel engine".
2. This repair standard consists of items to be checked, nominal dimension, assembly specifications, service limit, and repairing procedure.
 - "Nominal dimension" is the standard value at the time of manufacture.
 - "Assembly specification" is the target value after repairing (at assembling). It may differ in some degree from "assembly dimension" of the new engine.
 - "Service limit" is the limit value of wear, etc. which must not be exceeded. When it is reached, the part should be repaired or replaced.
 - "Repairing procedure" indicates general methods to repair.
 - The unit for the numbers in the table are all "**millimeter {inch}**" if not otherwise specified.
3. If the whole engine is requested for repair, "check the locations which need to be repaired" first by "the bench test" or something. Then perform the minimum overhaul. If a part of engine is requested for repair, perform repairing based on this "repair standard".
4. This repair standard may be changed in the value, specification, and others without notice due to "design change" of the engine.

Time to overhaul the engine

| Item to be checked | Standard value | Service limit | Repairing procedure | Remarks |
|--|----------------|---------------|----------------------|--|
| Compression pressure of the cylinder (MPa {psi}) | 3.04 {441} | 2.5 {363} | Overhaul the engine. | Coolant temperature: 70 — 85°C {158 — 185°F} Engine speed: approx. 250 rpm Vary depending on altitude. |
| Fuel consumption rate (L/h) | 100 % | 140 % | | |
| Lubricant consumption rate (L/h) | 100 % | 200 % | | |

Cylinder block

| Item to be checked | Standard value | Service limit | Repairing procedure | Remarks |
|--|-------------------------|---------------|--|--|
| Wear of the cylinder bore Measurement position: 13 {0.512} lower from the top surface of the cylinder block | φ85 {3.3465} | φ85.2 {3.354} | Perform boring along the oversize piston, then perform honing. | |
| Distortion of upper surface of the cylinder block | 0.075 {0.00295} or less | 0.15 {0.006} | Repair with a surface grinder. | Maximum amount of repaired value; 0.3 {0.012} The total amount of repaired values of the cylinder head and of the cylinder block. |
| Water pressure test (three minutes) (kPa {psi}) | 490 {71} | | Repair or replace the one with water leakage. | |

Cylinder head

| Item to be checked | | Standard value | Service limit | Repairing procedure | Remarks |
|--|-----------|---|---------------|--|--|
| Valve seat depression | IN | 0.7 {0.028} | 1.2 {0.047} | Replace the valve and insert. | Valve seat angle is 45° |
| | EX | 0.9 {0.035} | 1.5 {0.059} | | |
| Contact width of the valve seat | | 2.0 {0.079} | 2.5 {0.098} | Repair with the valve seat cutter. | Wrap the contact surface sufficiently after repair. |
| Distortion (flatness) of the under surface (installation surface) of the cylinder head | | 0.075 {0.00295} or less | 0.15 {0.006} | Repair with a surface grinder. | Maximum amount of repaired value; 0.3 {0.012} The total amount of repaired values of the cylinder block and of the cylinder head. |
| Distortion of exhaust manifold installation surface | | 0.05 {0.002} or less | 0.2 {0.008} | Repair. | |
| Water pressure test (three minutes) (kPa {psi}) | | 490 {71} | | Repair or replace the one with water leakage. | |
| Tightening torque of the cylinder head bolt: (N·m {kgf·m/lb·ft}) (Angle method) | M12 × 1.5 | 83.4 — 93.2 {8.5 — 9.5/61.5 — 68.7} ↓ 60° — 90° | | <ul style="list-style-type: none"> - Clean the seating surface and thread of the bolt. - Apply engine oil to the seating surface and thread of the bolt. - Never retighten after angle method tightening. | |
| | M8 × 1.25 | 24.5 — 34.3 {2.5 — 3.5/18.1 — 25.3} | | | |

Piston

| Item to be checked | | Standard value | Service limit | Repairing procedure | Remarks |
|--|-------------|----------------------------------|------------------|---|---------|
| Clearance with the cylinder Grade position from the top surface: 54.85 {2.159} | | 0.040 — 0.085 {0.0016 — 0.0033} | | | |
| Clearance between piston pins and piston pin holes | | 0.004 — 0.017 {0.00016 — 0.0007} | | If significant knocking sound occurs, replace the piston pin or the piston. | |
| Wear of the pin | | φ27 {1.063} | φ26.970 {1.0618} | | |
| Piston ring end gap | Top ring | 0.20 — 0.35 {0.008 — 0.014} | 1.5 {0.059} | Replace piston ring. When overhauling the engine, replace the piston ring. | |
| | Second ring | 0.35 — 0.50 {0.014 — 0.020} | | | |
| | Oil ring | 0.20 — 0.40 {0.008 — 0.016} | 1.0 {0.039} | | |

0A-26 General Information

Piston ring

| Item to be checked | | Standard value | Service limit | Repairing procedure | Remarks |
|---|-------------|--------------------------------------|---------------|---------------------------------|--|
| Clearance between the piston ring groove and the ring | Top ring | 0.085 — 0.105 {0.0033 — 0.0041} | 0.2 {0.008} | Replace the ring or the piston. | When assembling the ring to the piston, be sure to assemble with the mark of the ring facing upward. Inverse assembly makes oil consumption deteriorate. The oil ring is independent of top or bottom. |
| | Second ring | 0.050 — 0.085 {0.0020 — 0.0033} | 0.15 {0.006} | | |
| | Oil ring | 0.030 — 0.070 {0.00120 — 0.00276} | 0.15 {0.006} | | |
| The ring end direction | | | | 180° alternate | |

Connecting rod

| Item to be checked | Standard value | Service limit | Repairing procedure | Remarks |
|---|---|---------------|---|---|
| Play of the small end and the piston boss between front and back direction (one side) | 1.0 {0.039} | | | Reference value |
| Tension of the connecting rod bearing | Extrusion 0.055 — 0.085 {0.00217 — 0.00330} | | Use the one with extrusion and tension, and be careful about sticking of rear side. | |
| Clearance between the connecting rod bearing and crank pin | 0.026 — 0.067 {0.0010 — 0.0026} | 0.1 {0.0039} | Replace the bearing. | Be careful with the precision of the crank pin. |
| Contact surface of the connecting rod bearing and crank pin | | | Replace the one with defective contact or abrasion. | |
| Clearance between the small end bushing and the piston pin | 0.008 — 0.020 {0.00031 — 0.00080} | 0.05 {0.002} | Replace the bushing or the pin. | Clearance should be wide enough to turn smoothly with its big end held. |
| Axial play of the connecting rod and the crank pin | 0.20 — 0.33 {0.008 — 0.013} | 0.35 {0.014} | | |
| Center distance between the big end and small end | 133.5 {5.256} | | | Reference value |
| Torsion of holes on the big end and small end (L = per 100 mm {3.937 in}) | 0.05 {0.002} or less | 0.2 {0.008} | Repair or replace. | |
| Parallelism of holes on the big end and small end (L = per 100 mm {3.937 in}) | 0.05 {0.002} or less | 0.15 {0.006} | Repair or replace. | |
| Tightening torque of the bearing cap bolt (N·m {kgf·m/lb·ft}) | 23 — 26 {2.3 — 2.7/17.0 — 19.2} → 100° — 115° | | Apply engine oil to the thread of the bolt and the seating surface of the nut, and tighten. | |

Crankshaft

| Item to be checked | Standard value | Service limit | Repairing procedure | Remarks |
|---|--|---------------|---|--|
| Uneven wear of the journal and the pin | | 0.05 {0.002} | Replace the crankshaft. | |
| Wear of the journal | $\phi 60$ {2.362} | 0.14 {0.0055} | Replace the crankshaft. | |
| Wear of the pin | $\phi 46$ {1.811} | 0.13 {0.005} | Replace the crankshaft. | |
| Finishing precision of the journal and the pin (taper and ellipse) | 0.007 {0.00028} for both ellipse and taper | | | |
| Tension of the journal bearing | Extrusion 0.02 — 0.06 {0.0008 — 0.00236} | | Use the one with extrusion and tension, and be careful about sticking of rear side. | |
| Clearance between the journal and the bearing | 0.029 — 0.072 {0.0011 — 0.0028} | 0.11 {0.0043} | Replace the bearing. | |
| Axial play of the crankshaft | 0.058 — 0.208 {0.0023 — 0.0082} | 0.3 {0.012} | Replace the thrust bearing. | Measure at the front of the thrust in No.2 journal portion of the crankshaft. |
| Crankshaft runout | 0.025 {0.00098} or less | 0.05 {0.002} | Replace. | |
| Ring gear | | | Chamfer the warped ones and replace the remarkably damaged ones. | |
| Balance of the crankshaft (N·cm {gf·cm/on·in}) | 0.20 {20/ 0.2778} or less | | Check the dynamic balance. | (Reference value) At both ends of the journal |
| Tightening torque of the crank bearing cap bolt (N·m {kgf·m/lb·ft}) | 83.4 — 93.2 {8.5 — 9.5/ 61.5 — 68.7} | | Apply engine oil to the thread and the seating surface of the bolt, and tighten. | Be sure that there is no scratch or foreign object pinched on the bearing cap match surface. |
| Wear of the oil seal in the crankshaft rear part | | | Replace the oil seal when there is oil leakage. | Be careful with the oil seal collapsed. (Apply oil sufficiently before assembly.) |

Camshaft

| Item to be checked | Standard value | Service limit | Repairing procedure | Remarks |
|-----------------------------------|-----------------------|----------------------|---------------------------------|---------------------------------------|
| Uneven wear of the center journal | | 0.05 {0.002} | Repair or replace the camshaft. | |
| Wear of the center journal | $\phi 52$ {2.047} | $\phi 51.92$ {2.044} | Replace the camshaft. | |
| Camshaft runout | 0.02 {0.0008} or less | 0.1 {0.0039} | Replace the camshaft. | |
| Height of the cam | Inlet | 6.13 {0.241} | Replace the camshaft. | Repair light stepped wear of the cam. |
| | Exhaust | 6.43 {0.253} | | |

0A-28 General Information

Timing gear

| Item to be checked | | Standard value | Service limit | Repairing procedure | Remarks |
|--|-------------------------|---|---------------|-------------------------------------|---------|
| Backlash of the timing gear | Crank gear/Idle gear | 0.04 {0.0016} | 0.2 {0.008} | Replace the gear. | |
| | Idle gear/Camshaft gear | 0.03 {0.0012} | 0.2 {0.008} | | |
| Clearance between the crank gear and the crankshaft | | -0.004 — +0.050 {-0.00016 — +0.0020} | | | |
| Clearance between the camshaft gear and camshaft | | 0 — 0.042 {0 — 0.0017} | | | |
| Clearance between the idle gear bushing and shaft | | 0.025 — 0.085 {0.00098 — 0.00330} | 0.2 {0.008} | Replace the idle gear or the shaft. | |
| Uneven wear of the idle gear shaft | | | 0.1 {0.0039} | Replace the gear shaft. | |
| Play between front and back direction of the idle gear | | 0.058 — 0.115 {0.0023 — 0.0045} | 0.2 {0.008} | Replace the thrust collar. | |

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com