

# 6095B, 6110B, 6120B, 6135B, and 6140B Tractors

(Serial No. 500185 (6095B) - )  
(Serial No. 500643 (6110B) - )  
(Serial No. 500017 (6120B) - )  
(Serial No. 500161 (6135B) - )  
(Serial No. 500012 (6140B) - )



**JOHN DEERE**

## OPERATOR'S MANUAL

### 6095B, 6110B, 6120B, 6135B, and 6140B Tractors

OMSU59780 ISSUE H1 (ENGLISH)

#### CALIFORNIA

#### Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

If this product contains a gasoline engine:

#### **WARNING**

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

The State of California requires the above two warnings.

Additional Proposition 65 Warnings can be found in this manual.

**John Deere (Tianjin) Co., Ltd.**  
PRINTED IN U.S.A.



\* D C Y \*



\* 0 0 8 7 9 5 5 U S O M S U 0 0 \*

# Introduction

---

## Foreword

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages (see your John Deere dealer to order).

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing the direction of forward travel.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I. N.) in the Specification or Identification Numbers section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.

SETTING FUEL DELIVERY BEYOND PUBLISHED factory specifications or otherwise overpowering will result in loss of warranty protection for this machine.

BEFORE DELIVERING THIS MACHINE, your dealer performed a predelivery inspection. After operating for

the first 100 hours, schedule an after-sale inspection with your dealer to ensure best performance.


All tractors comply with the enterprise standard Q/12 JDTW 003—2018.

THIS TRACTOR IS DESIGNED SOLELY for use in customary agricultural or similar operations ("INTENDED USE"). Use in any other way is considered as contrary to the intended use. The manufacturer accepts no liability for damage or injury resulting from this misuse, and these risks must be borne solely by the user. Compliance with and strict adherence to the conditions of operation, service and repair as specified by the manufacturer also constitute essential elements for the intended use.

THIS TRACTOR SHOULD BE OPERATED, serviced and repaired only by persons familiar with all its particular characteristics and acquainted with the relevant safety rules (accident prevention). The accident prevention regulations, all other generally recognized regulations on safety and occupational medicine and the road traffic regulations must be observed at all times. Any arbitrary modifications carried out on this tractor will relieve the manufacturer of all liability for any resulting damage or injury.

If you are not the original owner of this machine, it is in your interest to contact your local John Deere dealer to inform them of this unit's serial number. This will help John Deere notify you of any issues or product improvements.

## Download Instructions



Instructions, manuals, and other documents may be downloaded at [www.techpubs.deere.com](http://www.techpubs.deere.com). Scanning the QR code on a mobile device will route to the site automatically.

Les instructions, les manuels et autres documents peuvent être téléchargés à cette adresse: [www.techpubs.deere.com](http://www.techpubs.deere.com). Scanner le QR code via un appareil mobile mène automatiquement au site.

Istruzioni, manuali e altri documenti possono essere scaricati su [www.techpubs.deere.com](http://www.techpubs.deere.com). La scansione del codice QR su un dispositivo portatile indirizza automaticamente al sito.

Anleitungen, Handbücher und andere Dokumente können unter [www.techpubs.deere.com](http://www.techpubs.deere.com) heruntergeladen werden. Durch Scannen des QR-Codes mit einem Mobilgerät wird man automatisch zur Webseite weitergeleitet.

Las instrucciones, los manuales y otros documentos se pueden descargar en [www.techpubs.deere.com](http://www.techpubs.deere.com). Al escanear el código QR en un dispositivo móvil, se abrirá automáticamente el sitio web.

Instruções, manuais e outros documentos podem ser baixados em [www.techpubs.deere.com](http://www.techpubs.deere.com). A leitura do código QR em um dispositivo móvel levará você automaticamente para o site.

Инструкции, руководства и другие документы можно загрузить на странице [www.techpubs.deere.com](http://www.techpubs.deere.com). Сканирование QR-кода на мобильном устройстве будет автоматически отправлять на сайт.

# Contents

	Page		Page
<b>General Information</b>			
Product View .....	00-1	Prevent Machine Runaway .....	00A-16
Trademarks .....	00-1	Park Machine Safely .....	00A-16
Glossary of Terms .....	00-2	Transport Tractor Safely .....	00A-16
Regions and Country Versions .....	00-3	Service Cooling System Safely .....	00A-17
Machine Overview .....	00-4	Service Accumulator Systems Safely .....	00A-17
Look for Supplemental Information .....	00-5	Service Tires Safely .....	00A-17
<b>Safety</b>			
Recognize Safety Information .....	00A-1	Service Front-Wheel Drive Tractor Safely .....	00A-17
Understand Signal Words .....	00A-1	Tightening Wheel Retaining Bolts/Nuts .....	00A-18
Follow Safety Instructions .....	00A-1	Avoid High-Pressure Fluids .....	00A-18
Prepare for Emergencies .....	00A-1	Do Not Open High-Pressure Fuel System .....	00A-18
Wear Protective Clothing .....	00A-2	Store Attachments Safely .....	00A-18
Protect Against Noise .....	00A-2	Decommissioning — Proper Recycling and Disposal of Fluids and Components .....	00A-19
Handle Fuel Safely—Avoid Fires .....	00A-2	<b>Safety Signs</b>	
Handle Starting Fluid Safely .....	00A-2	Replace Damaged or Missing Safety Signs .....	00B-1
Fire Prevention .....	00A-3	<b>Controls and Instruments</b>	
In Case of Fire .....	00A-3	Tractor Controls-Front Console .....	10-1
Avoid Static Electricity Risk When Refueling .....	00A-4	Left-Hand and Right-Hand Side .....	10-3
Keep ROPS Installed Properly .....	00A-4	Electrical Device Controls .....	10-4
Use Foldable ROPS and Seat Belt Properly .....	00A-4	Instrument Panel .....	10-5
Stay Clear of Rotating Drivelines .....	00A-5	<b>Operating Engine</b>	
Use Steps and Handholds Correctly .....	00A-5	Before Starting the Engine .....	20-1
Read Operator's Manuals for ISOBUS Controllers .....	00A-5	Before Starting Engine (Option) .....	20-2
Use Seat Belt Properly .....	00A-6	Key Switch Positions .....	20-2
Vibration .....	00A-6	Start the Engine .....	20-3
Operating the Tractor Safely .....	00A-6	Cold Weather Starting .....	20-3
Avoid Backover Accidents .....	00A-7	Using Engine Coolant Heater .....	20-4
Limited Use in Forestry Operation .....	00A-7	Check Instruments After Starting .....	20-4
Operating the Loader Tractor Safely .....	00A-8	Change Engine Speeds .....	20-5
Keep Riders Off Machine .....	00A-8	Warm Up the Engine .....	20-6
Passenger Seat .....	00A-8	Restart Stalled Engine .....	20-6
Use Safety Lights and Devices .....	00A-9	Avoid Idling the Engine .....	20-6
Transport Towed Equipment at Safe Speeds .....	00A-9	Observe Engine Work and Idle Speeds .....	20-6
Towing Trailers/Implements Safely .....	00A-10	Use Tachometer/Hour Meter .....	20-6
Use Caution on Slopes, Uneven Terrain, and Rough Ground .....	00A-10	Stop the Engine .....	20-7
Freeing a Mired Machine .....	00A-11	Stop the Engine (Option) .....	20-8
Avoid Contact with Agricultural Chemicals .....	00A-11	<b>Air Intake, Fuel, Coolant, and Exhaust Operation</b>	
Handle Agricultural Chemicals Safely .....	00A-11	Fill Fuel Tank .....	30-1
Handling Batteries Safely .....	00A-12	<b>Electrical and Lighting Operation</b>	
Avoid Heating Near Pressurized Fluid Lines .....	00A-13	Light Switch Positions (Fixed Steering Column) .....	40-1
Remove Paint Before Welding or Heating .....	00A-13	Light Switch Positions (Tiltable and Telescopic Steering Column) .....	40-1
Handle Electronic Components and Brackets Safely .....	00A-13	Use Headlights and Floodlights .....	40-2
Practice Safe Maintenance .....	00A-14	High Beam Indicator .....	40-3
Avoid Hot Exhaust .....	00A-14		
Clean Exhaust Filter Safely .....	00A-14		
Work In Ventilated Area .....	00A-15		
Support Machine Properly .....	00A-16		

Continued on next page

*Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.*

## Contents

	Page		Page
Use Tail Lights and Warning Lights .....	40-3	Operate SCV Control Levers .....	70B-3
Use Turn Signals .....	40-4	SCV Selection Table .....	70B-5
Use Cab Light .....	40-6	Match Tractor Power to Implement .....	70B-5
Operate Rotating Beacon Light (if equipped) .....	40-6		
Operate Identification Lights (if equipped) .....	40-6		
<b>Drivetrain Operation</b>		<b>Wheels and Tires Operation</b>	
Select a Gear .....	50-1	Service Tires Safely .....	80-1
<b>Transmission Operation</b>		Check Implement-to-Tire Clearance .....	80-1
Operator Training Required .....	50A-1	Tire Pressures .....	80-1
Operate Transmission .....	50A-1	Tire Inflation Pressure Guidelines .....	80-1
Operate Transmission (Option) .....	50A-2	Tire Pressures .....	80-2
Shift Transmission .....	50A-3	Tire Combinations—MFWD .....	80-3
High/Low Split-Shift Feature .....	50A-4	Jack up Tractor—Lifting Points .....	80-3
Stop Tractor .....	50A-4	Tighten Wheel/Axle Hardware Correctly .....	80-4
<b>MFWD and Front Axle Operation</b>		Tighten Bolts—MFWD Axle .....	80-5
Operate Mechanical Front-Wheel Drive .....	50B-1	Tighten Bolts—Rear Axle .....	80-5
<b>Differential and Rear Axle Operation</b>		Tread Settings—MFWD Axle .....	80-6
Use Differential Lock .....	50C-1	Tread Settings—Multi-Position Rear Wheels .....	80-7
<b>Power Take-off (PTO) Operation</b>		Check Toe-In .....	80-9
Reversible PTO Stub Shaft .....	50D-1	Adjust Toe-In .....	80-9
Attach PTO-Driven Implement .....	50D-1	Front Fender Adjustment (MFWD axle, if equipped) .....	80-10
Operate Tractor PTO .....	50D-2		
Adjust PTO Clutch Operating Rod .....	50D-3	<b>Ballast</b>	
<b>Steering and Brake Operation</b>		Plan for Maximum Productivity .....	80A-1
Adjust Steering Stop .....	60-1	Select Ballast Carefully .....	80A-1
Use Brakes .....	60-2	Determine Maximum Rear Ballast .....	80A-1
<b>Hydraulics Operation</b>		Determine Maximum Front Ballast .....	80A-2
Open Center Hydraulic System .....	70-1	Use Cast Iron Weights .....	80A-2
Warm Hydraulic System Oil .....	70-1	Install Rear Cast Iron Weights .....	80A-2
<b>Hitch and Drawbar Operation</b>		<b>Additional Equipment</b>	
3-Point Hitch Components .....	70A-1	Additional Equipment Operation .....	80B-1
Prepare Implement .....	70A-2	<b>Operator Station Operation</b>	
Rockshaft Control Lever .....	70A-3	Operator Station - General Information .....	90-1
Use Rockshaft Position Control .....	70A-3	Avoid Contact with Agricultural Chemicals .....	90-1
Set Position Control Lever Stop .....	70A-4	Clean Vehicle of Hazardous Pesticides .....	90-2
Use Rockshaft Draft Control .....	70A-4	Seat Adjustments .....	90-2
Adjust Rockshaft Rate-of-Drop .....	70A-5	Use Seat Belt .....	90-2
Attach Implements to 3-Point Hitch .....	70A-6	Adjust Steering Wheel .....	90-2
Adjust Stabilizer Bar .....	70A-7	Open Windows .....	90-3
Adjust Sway Chains (If Equipped) .....	70A-8	Open Door .....	90-3
Leveling Hitch .....	70A-8	RH Emergency Exit (if equipped) .....	90-3
Adjust Implement Float .....	70A-9	Sun Visor .....	90-4
Observe Drawbar Load Limitations .....	70A-9	Adjust Blower Speed (with HVAC) .....	90-4
Use Swinging Drawbar .....	70A-10	Control Temperature (with HVAC) .....	90-4
Proper Use of Drawbar .....	70A-10	Deice, Demist, or Defrost Windshield .....	90-4
Adjust Drawbar Length .....	70A-10	Optimize A/C and Heater Performance .....	90-5
Stay Clear of Rotating Drivelines .....	70A-10	Operate Windshield Wiper and Washer .....	90-5
<b>Selective Control Valve Operation</b>		Toolbox Location .....	90-6
Connect Cylinder Hoses .....	70B-1	Use Three-Pole Outlet .....	90-6
Disconnect Cylinder Hoses .....	70B-1	<b>Transport and Storage</b>	
Reconnect Hoses Under Pressure .....	70B-2	Use Safety Lights and Devices .....	100-1
Use Correct Hose Tips .....	70B-2	Use a Safety Chain .....	100-1
SCV Control Levers and Couplers .....	70B-3	Drive Tractor on Roads .....	100-1
		Transport Tractor Safely .....	100-3
		Complete Set .....	100-3
		Towed Mass .....	100-4
		Tow Tractor .....	100-4
		Transporting on Flat-Bed Carrier .....	100-4
		Tractor Storage .....	100-5
		Remove Tractor from Storage .....	100-6

## Contents

	Page		Page
<b>Maintenance Intervals</b>		<b>Air Intake, Fuel, Coolant, and Exhaust Maintenance</b>	
Service Interval Chart - Daily or 10 Hours - 50 Hours - 250 Hours - 500 Hours - Annually or 1000 Hours - Two Years or 2000 Hours-5000 Hours / Five Years .....	200-1	Service Air Cleaner (6095B model) .....	230-1
Service after First 100 Hours .....	200-2	Inspect Air Cleaner Elements (6095B model) ....	230-1
Service Tractor Safely .....	200-2	Store Air Cleaner Elements (6095B model) .....	230-2
Observe Service Intervals .....	200-2	Replace Primary and Secondary Elements of Air Cleaner (6095B model) .....	230-2
Use Correct Lubricant .....	200-3	Check Air Intake System (6095B model) .....	230-2
Service Daily Before Start-Up .....	200-3	Check Hoses and Hose Clamps for Tightness (6095B model) .....	230-3
Additional Service Information .....	200-4	Service Air Cleaner (6110B, 6120B, 6135B, and 6140B models) .....	230-4
<b>Fuels, Lubricants, and Coolants</b>		Replace Primary Elements of Air Cleaner (6110B, 6120B, 6135B, and 6140B models) .....	230-5
Handle Fuel Safely—Avoid Fires .....	200A-1	Replace Secondary Elements of Air Cleaner (6110B, 6120B, 6135B, and 6140B models) .....	230-6
Handle Fluids Safely—Avoid Fires .....	200A-1	Check Air Intake System (6110B, 6120B, 6135B, and 6140B models) .....	230-6
Handling and Storing Diesel Fuel .....	200A-1	Check Hoses and Hose Clamps for Tightness (6110B, 6120B, 6135B, and 6140B models) .....	230-7
Cold Weather Operation .....	200A-1	Clean Engine Crankcase Vent Tube .....	230-8
Hot Weather Operation .....	200A-2	Engine Cooling System Components .....	230-8
Diesel Fuel .....	200A-2	Front Grille, Side Grille, Radiator and Oil Cooler Cleaning .....	230-9
Lubricity of Diesel Fuel .....	200A-3	Use Lubricant Correctly .....	230-10
Testing Diesel Fuel .....	200A-3	Check Coolant Level .....	230-11
Fill Fuel Tank .....	200A-3	Check Cooling System for Leaks .....	230-11
Alternative and Synthetic Lubricants .....	200A-3	Flush Cooling System .....	230-12
Lubricant Storage .....	200A-4	Deaerate Cooling System .....	230-13
Diesel Engine Break-In Oil — Non-Emissions Certified and Certified Tier 1, Tier 2, Tier 3, Stage I, Stage II, and Stage III .....	200A-4	Bleed Fuel System .....	230-13
Diesel Engine Oil — Tier 3 and Stage IIIA .....	200A-5	Drain Water and Sediment From Fuel Filters and Water Separators .....	230-15
Extended Diesel Engine Oil Service Intervals ..	200A-5	Drain Water and Sediment from Fuel Tank .....	230-15
Oil Filters .....	200A-5	Clean Primary Fuel Filter and Water Separator .....	230-16
Diesel Engine Coolant (engine with wet sleeve cylinder liners) .....	200A-5	Replace Secondary Fuel Filter and Water Separator .....	230-16
John Deere COOL-GARD™ II Coolant Extender .....	200A-6	Replace Final Fuel Filter and Water Separator .....	230-17
Transmission and Hydraulic Oil .....	200A-7	Do Not Modify Fuel System .....	230-17
MFWD Front Axle Housing Oil .....	200A-7	<b>Electrical and Lighting Maintenance</b>	
MFWD Wheel Hub Oil .....	200A-8	Observe Electrical Service Precautions .....	240-1
Multipurpose Extreme Pressure (EP) Grease ..	200A-8	Use Booster Battery .....	240-1
<b>As Required Maintenance</b>		Battery Access .....	240-1
As Required Maintenance .....	200B-1	Charge Battery .....	240-2
Wash Machine After Unloading .....	200B-1	Clean Battery .....	240-2
<b>Controls and Instruments Maintenance</b>		Check Battery Condition .....	240-2
Controls and Instruments Maintenance .....	210-1	Remove Battery .....	240-3
<b>Engine Maintenance</b>		Battery Replacement Specifications .....	240-3
Observe Engine Operation Closely .....	220-1	Service Battery .....	240-3
Open Hood .....	220-1	Alternator/Fan Belt Replacement .....	240-4
Use Correct Lubricant .....	220-1	Adjust Headlights .....	240-4
Check Engine Oil Level .....	220-1	Aim Headlights .....	240-5
Change Engine Oil and Filter .....	220-2	Replace Headlight Bulbs .....	240-5
Change Engine Oil Filter (if equipped with loader frames) .....	220-2	Replace Flood Light Bulb .....	240-6
Adjust Hand Throttle Friction .....	220-3	Replace Front Turn Signal Bulb .....	240-6
Check Engine Idle Speed .....	220-3	Replace Tail Light/Rear Turn Signal/Brake Light Bulbs .....	240-7
<b>Break-In Service</b>		Starter Wiring Connections .....	240-7
During the First 10 Hours of Operation: .....	220A-1	Locate Fuses .....	240-7
After the First 50 Hours of Operation: .....	220A-1		
After the First 100 Hours of Operation: .....	220A-1		

## Contents

	Page		Page
Locate Relays .....	240-8	Clean Cab Air Filters .....	290-2
Fuse Size and Function .....	240-8	Service Air-Conditioning System .....	290-3
Relay Size and Function .....	240-9	Air-Conditioning System - Instruction for Starting up the Air-Conditioning Compressor .....	290-4
<b>Drive Train Maintenance</b>		<b>Troubleshooting</b>	
Use Correct Transmission/Hydraulic Filter Element .....	250-1	Engine Troubleshooting .....	300-1
Check Neutral Start System .....	250-1	Transmission Troubleshooting .....	300-4
<b>Transmission Maintenance</b>		Hydraulic System Troubleshooting .....	300-4
Check Transmission/Hydraulic System Oil Level .....	250A-1	Brakes Troubleshooting .....	300-5
Replace Transmission/Hydraulic Oil Filter .....	250A-1	Rockshaft and 3-Point Hitch Troubleshooting .....	300-5
Change Transmission/Hydraulic System Oil .....	250A-2	Hydraulic Cylinders Troubleshooting .....	300-6
<b>MFWD and Front Axle Maintenance</b>		Electrical System Troubleshooting .....	300-6
Lubricate Steering Spindles .....	250B-1	<b>Specifications</b>	
Lubricate MFWD Front Axle .....	250B-1	Machine Specifications .....	400-1
Lubricate MFWD Front Axle Pivot Pins .....	250B-1	Machine Dimensions and Weights .....	400-2
Lubricate MFWD Drive Shaft .....	250B-2	Sound Level .....	400-3
Check MFWD Axle Housing Oil Level .....	250B-2	Ground Speeds .....	400-4
Check MFWD Wheel Hub Oil Level .....	250B-2	Metric Bolt and Screw Torque Values .....	400-6
Change MFWD Front Axle Housing Oil .....	250B-3	Unified Inch Bolt and Screw Torque Values .....	400-7
Change MFWD Wheel Hub Oil .....	250B-4	<b>Identification Numbers</b>	
<b>Differential and Rear Axle Maintenance</b>		Eurasian Economic Union .....	400A-1
Lubricate Rear Axle Bearings .....	250C-1	Identification Plates .....	400A-1
<b>Power Take Off (PTO) Maintenance</b>		Record Tractor Serial Number .....	400A-1
Lubricate PTO Stub Shaft .....	250D-1	Record MFWD Front Axle Serial Number .....	400A-1
<b>Steering and Brake Maintenance</b>		Record Engine Serial Number .....	400A-2
Adjust Brake Pedal Free Play .....	260-1	Record Transmission Serial Number .....	400A-2
Adjust Clutch Pedal Free Play .....	260-2	Record ROPS Serial Number .....	400A-2
<b>Hydraulics Maintenance</b>		<b>Service Records</b>	
Hydraulics Maintenance .....	270-1	Daily or 10 Hours, 50, 250, 500 Hours Service Chart .....	500-1
Warm Transmission-Hydraulic System Oil .....	270-1	Annually or 1000 Hour Service Chart .....	500-2
<b>Hitch and Drawbar Maintenance</b>		2000, 5000 Hour Service Chart .....	500-2
Lubricate 3-Point Hitch Links .....	270A-1	As Required Service Chart .....	500-3
<b>Selective Control Valve Maintenance</b>			
Check Selective Control Valve .....	270B-1		
<b>Wheels and Tires Maintenance</b>			
Loose Hardware Inspection .....	280-1		
Inspect Tires .....	280-1		
<b>Ballasting Maintenance</b>			
Measure Rear Wheel Slip—Manually .....	280A-1		
Ballast Front End for Transport .....	280A-1		
Install Rear Cast Iron Weights .....	280A-2		
<b>Additional Equipment Maintenance</b>			
Additional Equipment Maintenance .....	280B-1		
<b>Operator Station Maintenance</b>			
Keep Cab Protection System Installed Properly .....	290-1		
Check Seat Belt .....	290-1		

# General Information

## Product View



John Deere 6135B Tractor

CPA0004364—UN—26APR18

*NOTE: Tractor shown has optional equipment.*

CP00606,00012E4-19-25APR18

## Trademarks

Trademarks	
AutoTrac™	Trademark of Deere & Company
Bio Hy-Gard™	Trademark of Deere & Company
Break-In Plus™	Trademark of Deere & Company
Break-In™	Trademark of Deere & Company
COOL-GARD™	Trademark of Deere & Company
CoolScan™	Trademark of Deere & Company
GREASE-GARD™	Trademark of Deere & Company
GreenStar™	Trademark of Deere & Company
Hy-Gard™	Trademark of Deere & Company
Oilscan™	Trademark of Deere & Company
Plus-50™	Trademark of Deere & Company
PowrReverser™	Trademark of Deere & Company
Roll-Gard™	Trademark of Deere & Company
SERVICEGARD™	Trademark of Deere & Company
TEFLON®	Trademark of Du Pont Co.
Torq-Gard™	Trademark of Deere & Company
StarFire™	Trademark of Deere & Company



CP00606,00012E5-19-18APR18



## Glossary of Terms

ITEM	ABBREVIATION	DESCRIPTION
Accessory	ACC	Secondary electrical system
Air Conditioning	A/C	System used for cooling the air in the cab
Alternating Current	AC	Electrical current that reverses its direction at regularly recurring intervals
Charge Air Cooler	CAC	A device used for cooling compressed intake air
Controller Area Network	CAN	A communication system linking on-board electronics
Chassis Control Unit	CCU	Computerized system for the tractor monitoring
Cold Cranking Amperes	CCA	Battery capability to perform during cold-weather operation
Direct Current	DC	Electrical current flowing in one direction only
Forward	FWD	Direction of movement
Forward-Neutral-Reverse	FNR	Abbreviation
Gallons per Minute	gpm	Amount of fluid displaced over a period of one minute
Heating, Ventilating, and Air Conditioning	HVAC	Abbreviation
High-Pressure Common Rail	HPCR	Abbreviation
Ignition	IGN	Control for starting and stopping the tractor
Instrument Cluster Control Unit	ICC	Computerized system used to control instrument cluster functions
International Standards Organization	ISO	Standards organization
Left-Hand	LH or L-H	Abbreviation
Liquid Crystal Display	LCD	A technology used for displaying information
Manifold Air Pressure	MAP	Air Pressure measured at engine air intake
Mechanical	Mech or MECH	Abbreviation
Mechanical Front Wheel Drive	MFWD	A mechanically powered front axle
Negative	Neg (—)	Electrical Ground Circuit
Number	No.	Abbreviation
Open Operator Station	OOS	Abbreviation
Positive	Pos (+)	Charged part of an electrical circuit
Potentiometer	POT	A device used to vary electrical voltage
PowrReverser™	PR	3-speed gear case, 4-speed range box, and 2 directional clutch pack with the electrohydraulic shuttle shift
Power Take-Off	PTO	Abbreviation
PowerTech™ E	PTE	Electronically controlled fuel injection
Product Identification Number	PIN	Serial number relating to tractor identification
Pulse-Width-Modulation	PWM	Method of controlling electrical signals
Region 1	R1	Asian Region
Reverse	Rev	Direction of movement
Revolutions per Minute	rpm	Abbreviation
Right-Hand	RH or R-H	Abbreviation
Roll-Over Protective Structure	ROPS	Abbreviation
Selective Control Valve	SCV	Device used to control remote hydraulic functions
Specification	Spec	Abbreviation
Three-Point Hitch	3 PT	Abbreviation
Transmission	Trans	Abbreviation
Voltage (Volts)	V	Abbreviation

Regions and Country Versions



RXA0150915—UN—01FEB16

- R1—Asia and Sub-Saharan Africa
- R1A—Far East, Sri Lanka, and Pakistan
- R1B—China
- R1C—India
- R1D—Sub-Saharan Africa
- R2—Europe, North Africa, Mid East, CIS
- R2A—European Union (EU 28+)
- R2B—North Africa and North Middle East (NANME)
- R2C—Common Wealth of Independent States (CIS)

- R3—Central and South America
- R3A—Latin America (JDLA)
- R3B—Brazil
- R3C—Mexico
- R3D—Argentina
- R4—North America
- R4A—USA and Canada
- R4B—Oceania (Australia and New Zealand)

Regions 1, 2 and 3 equipment is traditionally manufactured with Economic Commission for Europe (ECE) features or systems.


Region 4 equipment is traditionally manufactured with Society of Automotive Engineers (SAE) features or systems.

Drive and signal lighting, traffic signs, safety signs, and braking features are some of the systems that differ between ECE and SAE. For example, Text-Free (pictorial only) safety signs are used for ECE while Texts with picture safety signs are used on SAE. Use information aloft, if equipment information can identify by regions, countries, trade federations, industry standards, or governmental regulations.

CP00606,00012E7-19-18APR18

## Machine Overview

**IMPORTANT: READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage.**



A—Front Console Controls (standard)  
B—Front Console Controls (premium)  
C—Left Side Controls

D—Right Side Controls  
E—Rear Hitch

CPA0005140—UN—24JAN18

### Operate the machine introduction:

- Sit in the operator seat and fasten seat belt.
- Start engine. (See Operating Engine section.)

- Turn on lights or signals as required. (See Electrical and Lighting Operation section.)
- Move machine by operating transmission. (See Transmission Operation section.)

- Use steering and brakes as required. (See Steering and Brake Operation section.)
- Activate features and implements as required. (See Operational sections.)

down one column of text and graphic then over to the top of the next column as shown.

### Preliminary overview

Before operation, inspect items per following list as a reminder. Detailed operation and service information is available in Operational and Maintenance sections.

- Review manual and machine for safety information and safety signs.
- Review manual for proper operation, adjustment, and service.
- Review manual for engine and drivetrain operations. (throttles, brakes, steering, transmission gears, MFWD, and Differential Lock.)
- Review manual for control devices (hitch, hydraulic, and electrical).
- Review manual for regular lubrication points and intervals.
- Check for visual signs of leaks damage, failures, and flats.
- Prepare machine hardware, fuel, fluids, lubricants, air, and daily maintenance.
- Check and prepare implements or attachments according to implement or attachment Operator Manuals.

### Using this manual:

The information provided in this manual is divided into sections. The sections organization classifies by typical machine features or functional systems. These sections are identified at the top of each page. Specific information within each section is organized into modules. These modules are enclosed in boxes and a heading at the top left identifies the main modules. Page numbers identify the section as well as the number of the page in the section.

Review guideline for sections as following list

- Safety information is at the beginning
- Operation of all features and systems are in the first half of the manual
- Maintenance Intervals are in the middle of the manual
- Maintenance of all the features and systems are in the second half of the manual,
- Specifications are at the end

A detailed table of contents appears before Safety information and there is an alphabetical index at the very end of the manual.

Operator's Manual content flows as sequential reading



Sequential Reading

W28329—UN—18OCT17

LG70251,00014B5-19-19SEP18

### Look for Supplemental Information

Occasionally new or revised information will become available after manuals are printed. To get this up-to-date information in your hands, publication supplements are prepared and supplied to the field in the machine literature package.

Supplements can be supplied in the following forms and are usually identified with one of these titles:

- Directions Sheet
- Installation Instructions
- Publications Supplement

Before your initial review of the manual, look through the machine literature package to see if any supplemental information has been provided. If supplied, review this information to determine which procedures are impacted or modified by the revised instructions. Pay close attention to “CAUTION” and “IMPORTANT” statements. CAUTION statements address your safety, the safety of others and safe operation of the machine. IMPORTANT statements refer to machine adjustment, servicing and care.

Manuals are revised annually, at that time the supplemental information is incorporated directly into the manual, thereby eliminating the supplement.

JB06590,00006B4-19-22,JUL08

# Safety

## Recognize Safety Information



T81389—UN—28JUN13

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.

DX,ALERT-19-29SEP98

## Follow Safety Instructions



TS201—UN—15APR13

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.

DX,READ-19-16JUN09

## Understand Signal Words



**▲ WARNING**

**▲ CAUTION**

TS187—19—30SEP88

**DANGER;** The signal word DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.


**WARNING;** The signal word WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

**CAUTION;** The signal word CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury. CAUTION may also be used to alert against unsafe practices associated with events which could lead to personal injury.

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards. DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

DX,SIGNAL-19-05OCT16

## Prepare for Emergencies



TS291—UN—15APR13


Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.

DX,FIRE2-19-03MAR93

### Wear Protective Clothing



TS206—UN—15APR13

Wear close fitting clothing and safety equipment appropriate to the job.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.

DX.WEAR2-19-03MAR93

### Handle Fuel Safely—Avoid Fires



TS202—UN—23AUG88

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.

Use only an approved fuel container for transporting flammable liquids.

Never fill fuel container in pickup truck with plastic bed liner. Always place fuel container on ground before refueling. Touch fuel container with fuel dispenser nozzle before removing can lid. Keep fuel dispenser nozzle in contact with fuel container inlet when filling.

Do not store fuel container where there is an open flame, spark, or pilot light such as within a water heater or other appliance.

DX.FIRE1-19-12OCT11

### Protect Against Noise



TS207—UN—23AUG88

There are many variables that affect the sound level range, including machine configuration, condition and maintenance level of the machine, ground surface, operating environmental, duty cycles, ambient noise, and attachments.

Exposure to loud noise can cause impairment or loss of hearing.

**Always wear hearing protection.** Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

DX.NOISE-19-03OCT17

### Handle Starting Fluid Safely



TS1356—UN—18MAR92

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.

Do not use starting fluid on an engine equipped with glow plugs or an air intake heater.

DX,FIRE3-19-14MAR14

## Fire Prevention

To reduce the risk of fire, your tractor should be regularly inspected and cleaned.

- Birds and other animals may build nests or bring other flammable materials into the engine compartment or onto the exhaust system. The tractor should be inspected and cleaned prior to the first use each day.
- A build up of grass, crop material and other debris may occur during normal operation. This is especially true when operating in very dry conditions or conditions where airborne crop material or crop dust is present. Any such build up must be removed to ensure proper machine function and to reduce the risk of fire. The tractor must be inspected and cleaned periodically throughout the day.
- Regular and thorough cleaning of the tractor combined with other routine maintenance procedures listed in the Operator's Manual greatly reduce the risk of fire and the chance of costly downtime.
- Do not store fuel container where there is an open flame, spark, or pilot light such as within a water heater or other appliance.
- Check fuel lines, tank, cap, and fittings frequently for damage, cracks or leaks. Replace if necessary.

Follow all operational and safety procedures posted on the machine and the Operator's Manual. Be careful of hot engine and exhaust components during inspection and cleaning. Before carrying out any inspection or cleaning, always shut OFF the engine, place the transmission in PARK or set parking brake, and remove the key. Removal of the key will prevent others from starting the tractor during inspection and cleaning.

DX,WW,TRACTOR,FIRE,PREVENTION-19-12OCT11

## In Case of Fire



TS227—UN—15APR13

### **CAUTION: Avoid personal injury.**

Stop machine immediately at the first sign of fire. Fire may be identified by the smell of smoke or sight of flames. Because fire grows and spreads rapidly, get off the machine immediately and move safely away from the fire. Do not return to the machine! The number one priority is safety.

Call the fire department. A portable fire extinguisher can put out a small fire or contain it until the fire department arrives; but portable extinguishers have limitations. Always put the safety of the operator and bystanders first. If attempting to extinguish a fire, keep your back to the wind with an unobstructed escape path so you can move away quickly if the fire cannot be extinguished.

Read the fire extinguisher instructions and become familiar with their location, parts, and operation before a fire starts. Local fire departments or fire equipment distributors may offer fire extinguisher training and recommendations.

If your extinguisher does not have instructions, follow these general guidelines:


1. Pull the pin. Hold the extinguisher with the nozzle pointing away from you, and release the locking mechanism.
2. Aim low. Point the extinguisher at the base of the fire.
3. Squeeze the lever slowly and evenly.
4. Sweep the nozzle from side-to-side.

DX,FIRE4-19-22AUG13

## Avoid Static Electricity Risk When Refueling



RG22142—UN—17MAR14



RG21992—UN—21AUG13

The removal of sulfur and other compounds in Ultra-Low Sulfur Diesel (ULSD) fuel decreases its conductivity and increases its ability to store a static charge.


Refineries may have treated the fuel with a static dissipating additive. However, there are many factors that can reduce the effectiveness of the additive over time.

Static charges can build up in ULSD fuel while it is flowing through fuel delivery systems. Static electricity discharge when combustible vapors are present could result in a fire or explosion.

Therefore, it is important to ensure that the entire system used to refuel your machine (fuel supply tank, transfer pump, transfer hose, nozzle, and others) is properly grounded and bonded. Consult with your fuel or fuel system supplier to ensure that the delivery system is in compliance with fueling standards for proper grounding and bonding practices.

DX,FUEL,STATIC,ELEC-19-12JUL13

## Keep ROPS Installed Properly



TS212—UN—23AUG88

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.


The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.

The seat is part of the ROPS safety zone. Replace only with John Deere seat approved for your tractor.

Any alteration of the ROPS must be approved by the manufacturer.

DX,ROPS3-19-12OCT11

## Use Foldable ROPS and Seat Belt Properly



TS1729—UN—24MAY13

Avoid crushing injury or death during rollover.

- If this machine is equipped with a foldable rollover protective structure (ROPS), keep the ROPS in the fully extended and locked position. USE a seat belt when you operate with a ROPS in the fully extended position.
  - Hold the latch and pull the seat belt across the body.
  - Insert the latch into the buckle. Listen for a click.
  - Tug on the seat belt to make sure that the belt is securely fastened.




- Snug the seat belt across the hips.
- If this machine is operated with the ROPS folded (for example, to enter a low building), drive with extreme caution. DO NOT USE a seat belt with the ROPS folded.
- Return the ROPS to the raised, fully extended position as soon as the machine is operated under normal conditions.

DX,FOLDROPS-19-22AUG13

### Stay Clear of Rotating Drivelines



TS1644—UN—22AUG95



H96219—UN—29APR10

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure that PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.

Do not install any adapter device between the tractor


and the primary implement PTO drive shaft that will allow a 1000 rpm tractor shaft to power a 540 rpm implement at speeds higher than 540 rpm.

Do not install any adapter device that results in a portion of the rotating implement shaft, tractor shaft, or the adapter to be unguarded. The tractor master shield shall overlap the end of the splined shaft and the added adaptor device as outlined in the table.

PTO Type	Diameter	Splines	n ± 5 mm (0.20 in)
1	35 mm (1.378 in)	6	85 mm (3.35 in)
2	35 mm (1.378 in)	21	85 mm (3.35 in)

N400041,0003662-19-09AUG17

### Use Steps and Handholds Correctly



T133468—UN—15APR13

Prevent falls by facing the machine when getting on and off. Maintain 3-point contact with steps, handholds, and handrails.

Use extra care when mud, snow, or moisture present slippery conditions. Keep steps clean and free of grease or oil. Never jump when exiting machine. Never mount or dismount a moving machine.

DX,WW,MOUNT-19-12OCT11

### Read Operator's Manuals for ISOBUS Controllers


In addition to GreenStar™ Applications, this display can be used as a display device for any ISOBUS Controller that meets ISO 11783 standard. This includes capability to control ISOBUS implements. When used in this manner, information and control functions placed on the display are provided by the ISOBUS Controller and are the responsibility of the ISOBUS Controller manufacturer. Some of these functions could pose a hazard to either the operator or a bystander. Read the Operator's Manual provided by the ISOBUS Controller manufacturer and observe all safety messages in manual and on ISOBUS Controller product prior to use.

GreenStar is a trademark of Deere & Company

NOTE: ISOBUS refers to the ISO Standard 11783

DX,WW,ISOBUS-19-15JUL15

## Use Seat Belt Properly



TS1729—UN—24MAY13

Avoid crushing injury or death during rollover.

This machine is equipped with a rollover protective structure (ROPS). USE a seat belt when you operate with a ROPS.

- Hold the latch and pull the seat belt across the body.
- Insert the latch into the buckle. Listen for a click.
- Tug on the seat belt latch to make sure that the belt is securely fastened.
- Snug the seat belt across the hips.

Replace entire seat belt if mounting hardware, buckle, belt, or retractor show signs of damage.

Inspect seat belt and mounting hardware at least once a year. Look for signs of loose hardware or belt damage, such as cuts, fraying, extreme or unusual wear, discoloration, or abrasion. Replace only with replacement parts approved for your machine. See your John Deere dealer.

DX,ROPS1-19-22AUG13

## Vibration

All operator's seats approved by John Deere are component type-approved in accordance with 78/764/EEC or (EU) 1322/2014 Annex XIV, being allocated an average of the vibration acceleration actually measured at the seat ( $a_{ws}$ ), equivalent to  $\leq 1.25 \text{ m/s}^2$ .

This value must NOT be used to calculate vibration stress as per 2002/44/EC! Local John Deere dealers can provide assistance in assessing vibration stress.

Measures to reduce vibration may include:

- Appropriate style of driving, e.g. not too fast
- Suspended front axle
- Suspended cab

- Correctly adjusted operator's seat
- Correct tire pressure

DX,VIBRATION,EU-19-28FEB17

## Operating the Tractor Safely

You can reduce the risk of accidents by following these simple precautions:

- Use your tractor only for jobs it was designed to perform, for example, pushing, pulling, towing, actuating, and carrying a variety of interchangeable equipment designed to conduct agricultural work.
- Operators must be mentally and physically capable of accessing the operator's station and/or controls, and operating the machine properly and safely.
- Never operate machine when distracted, fatigued, or impaired. Proper machine operation requires the operator's full attention and awareness.
- This tractor is not intended to be used as a recreational vehicle.
- Read this operator's manual before operating the tractor and follow operating and safety instructions in the manual and on the tractor.
- Follow operation and ballasting instructions found in the operator's manual for your implements/ attachments, such as front loaders.
- Follow the instructions outlined in the operator's manual of any mounted or trailed machinery or trailer. Do not operate a combination of tractor-machine or tractor-trailer unless all instructions have been followed.
- Make sure that everyone is clear of machine, attached equipment, and work area before starting engine or operation.
- Stay clear of the three-point linkage and pickup hitch (if equipped) when controlling them.
- Keep hands, feet, and clothing away from power-driven parts.

## Driving Concerns

- Never get on or off a moving tractor.
- Complete any required training prior to operating vehicle.
- Keep all children and nonessential personnel off tractors and all equipment.
- Never ride on a tractor unless seated on a John Deere approved seat with a seat belt.
- Keep all shields/guards in place.
- Use appropriate visual and audible signals when operating on public roads.
- Move to side of road before stopping.
- Reduce speed when turning, applying individual brakes, or operating around hazards on rough ground or steep slopes.

- Stability degrades when attached implements are at high position.
- Couple brake pedals together for road travel.
- Pump brakes when stopping on slippery surfaces.
- Regularly clean fenders and fender valances (mud flaps) if installed. Remove dirt before driving on public roadways.

#### Heated and Ventilated Operator's Seat

- An overheated seat heater can cause a burn injury or damage to the seat. To reduce the risk of burns, use caution when using the seat heater for extended periods of time, especially if the operator cannot feel temperature change or pain to the skin. Do not place objects on the seat, such as a blanket, cushion, cover, or similar item, which can cause the seat heater to overheat.

#### Towing Loads

- Be careful when towing and stopping heavy loads. Stopping distance increases with speed and weight of towed loads, and on slopes. Towed loads with or without brakes that are too heavy for the tractor or are towed too fast can cause loss of control.
- Consider the total weight of the equipment and its load.
- Hitch towed loads only to approved couplings to avoid rearward upset.

#### Parking and Leaving the Tractor

- Before dismounting, shut off SCVs, disengage PTO, stop engine, lower implements/attachments to ground, place implement/attachment control devices in neutral, and securely engage park mechanism, including the park pawl and park brake. In addition, if the tractor is left unattended, remove key.
- Leaving transmission in gear with engine off will NOT prevent the tractor from moving.
- Never go near an operating PTO or an operating implement.
- Wait for all movement to stop before servicing machinery.

#### Common Accidents

Unsafe operation or misuse of the tractor can result in accidents. Be alert to hazards of tractor operation.

The most common accidents involving tractors are:

- Tractor rollover
- Collisions with motor vehicles
- Improper starting procedures
- Entanglement in PTO shafts
- Falling from tractor
- Crushing and pinching during hitching

DX,WW,TRACTOR-19-08MAY19

#### Avoid Backover Accidents



PC10857XW—UN—15APR13

Before moving machine, be sure that all persons are clear of machine path. Turn around and look directly for best visibility. Use a signal person when backing if view is obstructed or when in close quarters.

Do not rely on a camera to determine if personnel or obstacles are behind the machine. The system can be limited by many factors including maintenance practices, environmental conditions, and operating range.

DX,AVOID,BACKOVER,ACCIDENTS-19-30AUG10


#### Limited Use in Forestry Operation

The intended use of John Deere tractors when used in forestry operations is limited to tractor-specific applications like transport, stationary work such as log splitting, propulsion, or operating implements with PTO, hydraulic, or electrical systems.

These are applications where normal operation does not present a risk of falling or penetrating objects. Any forestry applications beyond these applications, such as forwarding and loading, requires fitment of application-specific components including Falling Object Protective Structure (FOPS) and/or Operative Protective Structures (OPS). Contact John Deere dealer for special components.

DX,WW,FORESTRY-19-12OCT11

## Operating the Loader Tractor Safely



TS1692—UN—09NOV09

When operating a machine with a loader application, reduce speed as required to ensure good tractor and loader stability.

To avoid tractor rollover and damage to front tires and tractor, do not carry load with your loader at a speed over 10 km/h (6 mph).

To avoid tractor damage do not use a front loader or a sprayer tank if the tractor is equipped with a 3 Meter Front Axle.

Never allow anyone to walk or work under a raised loader.

Do not use loader as a work platform.

Do not lift or carry anyone on loader, in bucket, or on implement or attachment.


Lower loader to ground before leaving operators station.

The Rollover Protective Structure (ROPS) or cab roof, if equipped, may not provide sufficient protection from load falling onto the operators station. To prevent loads from falling onto the operators station, always use appropriate implements for specific applications (that is, manure forks, round bale forks, round bale grippers, and clampers).

Ballast tractor in accordance to Ballast Recommendations in PREPARE TRACTOR section.

DX,WW,LOADER-19-18SEP12

## Keep Riders Off Machine



TS290—UN—23AUG88

Only allow the operator on the machine. Keep riders off.

Riders on machine are subject to injury such as being struck by foreign objects and being thrown off of the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.

DX,RIDER-19-03MAR93

## Passenger Seat




TS1730—UN—24MAY13

The passenger seat is intended only for transport of a passenger in on-road operations (that is, transport from farm to field).

If it is necessary to transport a passenger, the passenger seat is the only means of transporting a passenger provided by John Deere.

DX,SEAT,EU-19-28FEB17

## Use Safety Lights and Devices




TS951—UN—12APR90

Prevent collisions between other road users, slow moving tractors with attachments or towed equipment, and self-propelled machines on public roads. Frequently check for traffic from the rear, especially in turns, and use turn signal lights.

Use headlights, flashing warning lights, and turn signals day and night. Follow local regulations for equipment lighting and marking. Keep lighting and marking visible, clean, and in good working order. Replace or repair lighting and marking that has been damaged or lost. An implement safety lighting kit is available from your John Deere dealer.

DX.FLASH-19-07JUL99

## Transport Towed Equipment at Safe Speeds



TS1686—UN—27SEP06

Do not exceed the maximum transport speed. This towing unit may be capable of operating at transport speeds that exceed the maximum allowable transport speed for towed implements.

Before transporting a towed implement, determine from signs on the implement or information provided in the implement's operator manual the maximum transport speed. Never transport at speeds that exceed the implement's maximum transport speed. Exceeding the implement's maximum transport speed can result in:

- Loss of control of the towing unit/implement combination
- Reduced or no ability to stop during braking
- Implement tire failure
- Damage to the implement structure or its components

Implements shall be equipped with brakes if the maximum fully loaded weight is greater than 1500 kg (3307 lbs) and greater than 1.5 times the weight of the towing unit.

**Example: Implement mass is 1600 kg (3527 lbs) and towing unit mass is 1600 kg (3527 lbs), example implement is not required to have brakes.**

**Implements without brakes:** Do not transport at speeds greater than 32 km/h (20 mph).


### Implements with brakes:

- If the manufacturer does not specify a maximum transport speed, do not tow at speeds greater than 40 km/h (25 mph).
- When transporting at speeds up to 40 km/h (25 mph) the fully loaded implement must weigh less than 4.5 times the towing unit weight.
- When transporting at speeds between 40—50 km/h (25—31 mph) the fully loaded implement must weigh less than 3.0 times the towing unit weight.

When towing a trailer, become familiar with the braking characteristics and ensure the compatibility of the tractor/trailer combination in regard to the deceleration rate.

DX.TOW1-19-28FEB17

## Towing Trailers/Implements Safely



TS216—UN—23AUG88

Stopping distance increases with speed and mass of trailer/implement, and when transporting on slopes. Towed mass with or without brakes that is too heavy for the tractor or is towed too fast can cause loss of control. Consider the total weight of the equipment and its load.

When towing a trailer, become familiar with the braking characteristics and ensure the compatibility of the tractor/trailer combination in regard to the deceleration rate.

Stay clear of area between tractor and trailed vehicle.


Trailer/Implement Brake System	Top Speed
Unbraked . . . . .	25 km/h (15.5 mph)
Independent . . . . .	25 km/h (15.5 mph)
Overrun brake . . . . .	25 km/h (15.5 mph)
Single-line hydraulic brake . . . . .	25 km/h (15.5 mph)
Dual-line hydraulic brake . . . . .	40 km/h (25 mph)
Single-line air brake . . . . .	25 km/h (15.5 mph)
Dual-line air brake . . . . .	Maximum design speed

There may be legal limits in force that restrict travel speeds to figures lower than those quoted here.

Use additional caution when towing loads under adverse surface conditions, when turning, and on inclines.

DX,TOW3,EU-19-28FEB17

## Use Caution on Slopes, Uneven Terrain, and Rough Ground



RXA0103437—UN—01JUL09

Avoid holes, ditches, and obstructions which cause the tractor to tip, especially on slopes. Avoid sharp uphill turns.

Driving forward out of a ditch, mired condition, or up a steep slope could cause the tractor to tip over rearward. Back out of these situations if possible.

Danger of overturn increases greatly with narrow tread setting, at high speed.

Not all conditions that can cause a tractor to overturn are listed. Be alert for any situation in which stability may be compromised.

Slopes are a major factor related to loss-of-control and tip-over accidents, which can result in severe injury or death. Operation on all slopes requires extra caution.

Uneven terrain or rough ground can cause loss-of-control and tip-over accidents, which can result in severe injury or death. Operation on uneven terrain or rough ground requires extra caution.

Never drive near the edge of a gully, drop-off, ditch, steep embankment, or a body of water. The machine could suddenly roll over if a wheel goes over the edge or the ground caves in


Choose a low ground speed so you will not have to stop or shift while on a slope.

Avoid starting, stopping, or turning on a slope. If the tires lose traction, disengage the PTO and proceed slowly, straight down the slope.

Keep all movement on slopes slow and gradual. Do not make sudden changes in speed or direction, which could cause the machine to roll over.

DX,WW,SLOPE-19-28FEB17

## Freeing a Mired Machine



TS1645—UN—15SEP95



TS263—UN—23AUG88

Attempting to free a mired machine can involve safety hazards such as the mired tractor tipping rearward, the towing tractor overturning, and the tow chain or tow bar (a cable is not recommended) failing and recoiling from its stretched condition.


Back your tractor out if it gets mired down in mud. Unhitch any towed implements. Dig mud from behind the rear wheels. Place boards behind the wheels to provide a solid base and try to back out slowly. If necessary, dig mud from the front of all wheels and drive slowly ahead.

If necessary to tow with another unit, use a tow bar or a long chain (a cable is not recommended). Inspect the chain for flaws. Make sure all parts of towing devices are of adequate size and strong enough to handle the load.

Always hitch to the drawbar of the towing unit. Do not hitch to the front pushbar attachment point. Before moving, clear the area of people. Apply power smoothly to take up the slack: a sudden pull could snap any towing device causing it to whip or recoil dangerously.

DX.MIRED-19-07JUL99

## Avoid Contact with Agricultural Chemicals



TS220—UN—15APR13



TS272—UN—23AUG88


This enclosed cab does not protect against inhaling vapor, aerosol or dust. If pesticide use instructions require respiratory protection, wear an appropriate respirator inside the cab.

Before leaving the cab, wear personal protective equipment as required by the pesticide use instructions. When re-entering the cab, remove protective equipment and store either outside the cab in a closed box or some other type of sealable container or inside the cab in a pesticide resistant container, such as a plastic bag.

Clean your shoes or boots to remove soil or other contaminated particles prior to entering the cab.

DX.CABS-19-25MAR09

## Handle Agricultural Chemicals Safely



TS220—UN—15APR13



A34471

A34471—UN—11OCT88

Chemicals used in agricultural applications such as fungicides, herbicides, insecticides, pesticides, rodenticides, and fertilizers can be harmful to your health or the environment if not used carefully.

Always follow all label directions for effective, safe, and legal use of agricultural chemicals.

Reduce risk of exposure and injury:

- Wear appropriate personal protective equipment as recommended by the manufacturer. In the absence of manufacturer's instructions, follow these general guidelines:
  - Chemicals labeled '**Danger**': Most toxic. Generally require use of goggles, respirator, gloves, and skin protection.
  - Chemicals labeled '**Warning**': Less toxic. Generally require use of goggles, gloves, and skin protections.
  - Chemicals labeled '**Caution**': Least toxic. Generally require use of gloves and skin protection.
- Avoid inhaling vapor, aerosol or dust.
- Always have soap, water, and towel available when working with chemicals. If chemical contacts skin, hands, or face, wash immediately with soap and water. If chemical gets into eyes, flush immediately with water.
- Wash hands and face after using chemicals and before eating, drinking, smoking, or urination.
- Do not smoke or eat while applying chemicals.
- After handling chemicals, always bathe or shower and change clothes. Wash clothing before wearing again.
- Seek medical attention immediately if illness occurs during or shortly after use of chemicals.
- Keep chemicals in original containers. Do not transfer chemicals to unmarked containers or to containers used for food or drink.
- Store chemicals in a secure, locked area away from human or livestock food. Keep children away.
- Always dispose of containers properly. Triple rinse


empty containers and puncture or crush containers and dispose of properly.

DX,WW,CHEM01-19-24AUG10

## Handling Batteries Safely



TS204—UN—15APR13



TS203—UN—23AUG88

Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded (-) battery clamp first and replace grounded clamp last.

Sulfuric acid in battery electrolyte is poisonous and



strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

**Avoid hazards by:**

- Filling batteries in a well-ventilated area
- Wearing eye protection and rubber gloves
- Avoiding use of air pressure to clean batteries
- Avoiding breathing fumes when electrolyte is added
- Avoiding spilling or dripping electrolyte
- Using correct battery booster or charger procedure.

**If acid is spilled on skin or in eyes:**

1. Flush skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush eyes with water for 15—30 minutes. Get medical attention immediately.

**If acid is swallowed:**

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 qt.).
3. Get medical attention immediately.

**WARNING:** Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**

DX,WW,BATTERIES-19-02DEC10

**Avoid Heating Near Pressurized Fluid Lines**



TS953—UN—15MAY90

Flammable spray can be generated by heating near pressurized fluid lines, resulting in severe burns to yourself and bystanders. Do not heat by welding, soldering, or using a torch near pressurized fluid lines or other flammable materials. Pressurized lines can accidentally burst when heat goes beyond the immediate flame area.

DX,TORCH-19-10DEC04

**Remove Paint Before Welding or Heating**



TS220—UN—15APR13

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 100 mm (4 in.) from area to be affected by heating. If paint cannot be removed, wear an approved respirator before heating or welding.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.

Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.

DX,PAINT-19-24JUL02

**Handle Electronic Components and Brackets Safely**



TS249—UN—23AUG88

Falling while installing or removing electronic

components mounted on equipment can cause serious injury. Use a ladder or platform to easily reach each mounting location. Use sturdy and secure footholds and handholds. Do not install or remove components in wet or icy conditions.

If installing or servicing a RTK base station on a tower or other tall structure, use a certified climber.

If installing or servicing a global positioning receiver mast used on an implement, use proper lifting techniques and wear proper protective equipment. The mast is heavy and can be awkward to handle. Two people are required when mounting locations are not accessible from the ground or from a service platform.

DX,WW,RECEIVER-19-24AUG10

Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.

Falling while cleaning or working at height can cause serious injury. Use a ladder or platform to easily reach each location. Use sturdy and secure footholds and handholds.

DX,SERV-19-28FEB17

## Practice Safe Maintenance



TS218—UN—23AUG88


Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing away from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed.

## Avoid Hot Exhaust



RG17488—UN—21AUG09

Servicing machine or attachments with engine running can result in serious personal injury. Avoid exposure and skin contact with hot exhaust gases and components.

Exhaust parts and streams become very hot during operation. Exhaust gases and components reach temperatures hot enough to burn people, ignite, or melt common materials.

DX,EXHAUST-19-20AUG09

## Clean Exhaust Filter Safely



TS227—UN—15APR13



TS271—UN—23AUG88


Always make sure that engine is stopped while hauling machine on a truck or trailer.

Contact with exhaust components while still hot can result in serious personal injury.

Avoid contact with these components until cooled to safe temperatures.

If service procedure requires engine to be running:

- Only engage power-driven parts required by service procedure
- Ensure that other people are clear of operator station and machine



TS1693—UN—09DEC09

Keep hands, feet, and clothing away from power-driven parts.

Always disable movement (neutral), set the parking brake or mechanism and disconnect power to attachments or tools before leaving the operator's station.

Shut off engine and remove key (if equipped) before leaving the machine unattended.

DX,EXHAUST,FILTER-19-12JAN11



TS1695—UN—07DEC09


During exhaust filter cleaning operations, the engine may run at elevated idle and hot temperatures for an extended period of time. Exhaust gases and exhaust filter components reach temperatures hot enough to burn people, or ignite or melt common materials.

Keep machine away from people, animals, or structures which may be susceptible to harm or damage from hot exhaust gases or components. Avoid potential fire or explosion hazards from flammable materials and vapors near the exhaust. Keep exhaust outlet away from people and anything that can melt, burn, or explode.

Closely monitor machine and surrounding area for smoldering debris during and after exhaust filter cleaning.

Adding fuel while an engine is running can create a fire or explosion hazard. Always stop engine before refueling machine and clean up any spilled fuel.

## Work In Ventilated Area




TS220—UN—15APR13

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.

DX,AIR-19-17FEB99

## Support Machine Properly



TS229—UN—23AUG88


Always lower the attachment or implement to the ground before you work on the machine. If the work requires that the machine or attachment be lifted, provide secure support for them. If left in a raised position, hydraulically supported devices can settle or leak down.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

When implements or attachments are used with a machine, always follow safety precautions listed in the implement or attachment operator's manual.

DX,LOWER-19-24FEB00

## Park Machine Safely




TS230—UN—24MAY89

Before working on the machine:

- Lower all equipment to the ground.
- Stop the engine and remove the key.
- Disconnect the battery ground strap.
- Hang a "DO NOT OPERATE" tag in operator station.

DX,PARK-19-04JUN90

## Transport Tractor Safely



RXA0103709—UN—01JUL09


A disabled tractor is best transported on a flatbed carrier. Use chains to secure the tractor to the carrier. The axles and tractor frame are suitable attachment points.

Before transporting the tractor on a low-loader truck or flatbed rail wagon, make sure that the hood is secured over the tractor engine and that doors, roof hatch (if equipped) and windows are properly closed.

Never tow a tractor at a speed greater than 10 km/h (6 mph). An operator must steer and brake the tractor under tow.

DX,WW,TRANSPORT-19-19AUG09

## Prevent Machine Runaway



TS177—UN—11JAN89


Avoid possible injury or death from machinery runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear if normal circuitry is bypassed.

**NEVER** start engine while standing on ground. Start engine only from operator's seat, with transmission in neutral or park.

DX,BYPAS1-19-29SEP98

### Service Cooling System Safety



TS281—UN—15APR13

Explosive release of fluids from pressurized cooling system can cause serious burns.

Shut off engine. Only remove filler cap when cool enough to touch with bare hands. Slowly loosen cap to first stop to relieve pressure before removing completely.

DX,WW,COOLING-19-19AUG09

### Service Accumulator Systems Safely



TS281—UN—15APR13

Escaping fluid or gas from systems with pressurized accumulators that are used in air conditioning, hydraulic, and air brake systems can cause serious injury. Extreme heat can cause the accumulator to burst, and pressurized lines can be accidentally cut. Do not weld or use a torch near a pressurized accumulator or pressurized line.

Relieve pressure from the pressurized system before removing accumulator.

Relieve pressure from the hydraulic system before removing accumulator. Never attempt to relieve hydraulic system or accumulator pressure by loosening a fitting.

Accumulators cannot be repaired.

DX,WW,ACCLA2-19-22AUG03

### Service Tires Safely



RXA0103438—UN—11JUN09

Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.


When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims, or missing lug bolts and nuts.

Wheels and tires are heavy. When handling wheels and tires use a safe lifting device or get an assistant to help lift, install, or remove.

DX,WW,RIMS-19-28FEB17

### Service Front-Wheel Drive Tractor Safely



L124 515


L124515—UN—06AUG94

When servicing front-wheel drive tractor with the rear wheels supported off the ground and rotating wheels by engine power, always support front wheels in a similar manner. Loss of electrical power or transmission hydraulic system pressure will engage the front driving wheels, pulling the rear wheels off the support if front

wheels are not raised. Under these conditions, front drive wheels can engage even with switch in disengaged position.

DX,WW,MFWD-19-19AUG09

## Tightening Wheel Retaining Bolts/Nuts



L124 516

L124516—UN—03JAN95

Torque wheel retaining bolts/nuts at the intervals specified in section Break-In Period and Service.

DX,WW,WHEEL-19-12OCT11

## Avoid High-Pressure Fluids



X9811—UN—23AUG88

Inspect hydraulic hoses periodically – at least once per year – for leakage, kinking, cuts, cracks, abrasion, blisters, corrosion, exposed wire braid or any other signs of wear or damage.

Replace worn or damaged hose assemblies immediately with John Deere approved replacement parts.

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.


Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any

fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available in English from Deere & Company Medical Department in Moline, Illinois, U.S.A., by calling 1-800-822-8262 or +1 309-748-5636.

DX,FLUID-19-12OCT11

## Do Not Open High-Pressure Fuel System



TS1343—UN—18MAR92

High-pressure fluid remaining in fuel lines can cause serious injury. Do not disconnect or attempt repair of fuel lines, sensors, or any other components between the high-pressure fuel pump and nozzles on engines with High Pressure Common Rail (HPCR) fuel system.

Only technicians familiar with this type of system can perform repairs. (See your John Deere dealer.)

DX,WW,HPCR1-19-07JAN03

## Store Attachments Safely



TS219—UN—23AUG88

Stored attachments such as dual wheels, cage wheels, and loaders can fall and cause serious injury or death.

Securely store attachments and implements to prevent falling. Keep playing children and bystanders away from storage area.

DX,STORE-19-03MAR93

This as a preview PDF file from [best-manuals.com](http://best-manuals.com)



Download full PDF manual at [best-manuals.com](http://best-manuals.com)