

NEW HOLLAND


T8010

T8020

T8030

T8040

REPAIR MANUAL




REPAIR MANUAL

T8010

T8020

T8030

T8040



NEW HOLLAND

AGRICULTURE

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

NOTE: Engine repair information is not contained within this tractor Repair Manual. For engine repair, refer to publication number 87515682 for the 8.3 & 9.0L 6 Cylinder, 24 Valve CNH Engine with High Pressure Common Rail Fuel System.

STANDARD TORQUE SPECIFICATIONS	SECTION 00, CHAPTER 1
TORQUE SPECIFICATIONS - METRIC HARDWARE	00-1-4
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS	00-1-5
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS	00-1-6
SAFETY, GENERAL INFORMATION, MAINTENANCE SCHEDULE	SECTION 00, CHAPTER 2
SAFETY	00-2-3
GENERAL INFORMATION	00-2-5
LUBRICATION/MAINTENANCE CHART	00-2-6
SYSTEM CAPACITIES	00-2-7
ENGINE REMOVAL AND INSTALLATION	SECTION 10, CHAPTER 1
ENGINE REMOVAL	10-1-3
ENGINE INSTALLATION	10-1-10
FUEL TANK / FUEL SENDER REMOVAL AND INSTALLATION	SECTION 10, CHAPTER 2
SPECIAL TORQUES	3001-3
FUEL TANK REMOVAL AND INSTALLATION	3001-3
FUEL LEVEL SENDER REMOVAL AND INSTALLATION.....	3001-10
HOOD REMOVAL	SECTION 10, CHAPTER 3
HOOD REMOVAL	10-3-3
HOOD INSTALLATION	10-3-5
COOLING SYSTEM MODULE REMOVAL AND INSTALLATION	SECTION 10, CHAPTER 4
COOLING MODULE REMOVAL	10-4-3
COOLING MODULE INSTALLATION	10-4-7
VISCOUS FAN DRIVE TEST	SECTION 10, CHAPTER 5
REQUIRED TOOLS	10-5-3
DIAGNOSTIC PROCEDURE	10-5-4
FAN SPEED TEST	10-5-7
POWERSHIFT TRANSMISSION SYSTEM - HOW IT WORKS AND TROUBLESHOOTING	SECTION 21, CHAPTER 1
TRANSMISSION SYSTEM INTRODUCTION	21-1-3
TRANSMISSION SYSTEM CONTROLS	21-1-5
TRANSMISSION SYSTEM COMPONENTS	21-1-6
TRANSMISSION LUBE AND DISTRIBUTION TUBES	21-1-8
POWERSHIFT TRANSMISSION CLUTCH LAYOUT	21-1-10
POWERSHIFT VALVE CLUTCH ENGAGEMENTS	21-1-11
POWER FLOW (FORWARD SPEEDS)	21-1-12
POWER FLOW (REVERSE SPEEDS)	21-1-30
POWER FLOW (FORWARD CREEPER DRIVE SPEEDS)	21-1-34
POWER FLOW (REVERSE CREEPER DRIVE SPEEDS)	21-1-40
INCHING VALVE OPERATION	21-1-42
INSTRUMENTATION CLUSTER - TRANSMISSION LEAKAGE CHECK	21-1-46
MASTER CLUTCH PRESSURE CHECK	21-1-49
FRONT FRAME TO SPEED TRANSMISSION SPLIT	SECTION 21, CHAPTER 2
SPECIAL TOOLS	21-2-3
SPECIAL TORQUES	21-2-3
FRONT FRAME TO SPEED TRANSMISSION SPLIT	21-2-4

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

SPEED TO RANGE TRANSMISSION SPLIT	SECTION 21, CHAPTER 3
SPECIAL TOOLS	21-3-3
SPECIAL TORQUES	21-3-3
SPEED TO RANGE TRANSMISSION SPLIT	21-3-4
Removal	21-3-4
Installation	21-3-7
SPEED TRANSMISSION	SECTION 21, CHAPTER 4
SPECIFICATIONS	21-4-4
SPECIAL TORQUES	21-4-4
TROUBLESHOOTING AFTER SPEED TRANSMISSION REPAIR	21-4-4
SPECIAL TOOLS	21-4-5
SPEED TRANSMISSION WITH CREEP OPTION	21-4-6
ASSEMBLING THE COUNTERSHAFT WITH CREEPER SPEED CLUTCH	21-4-14
TRANSMISSION ASSEMBLY WITH CREEP OPTION	21-4-78
TRANSMISSION ASSEMBLY WITHOUT CREEP OPTION	21-4-80
RANGE TRANSMISSION TO REAR FRAME SPLIT	SECTION 21, CHAPTER 5
SPECIAL TOOLS	21-5-3
SPECIAL TORQUES	21-5-3
RANGE TRANSMISSION TO REAR FRAME SPLIT	21-5-4
Disassembly	21-5-4
Assembly	21-5-7
RANGE TRANSMISSION INCLUDING FWD CLUTCH/PARK BRAKE	SECTION 21, CHAPTER 6
SPECIFICATIONS	21-6-3
TROUBLESHOOTING AFTER RANGE TRANSMISSION REPAIR	21-6-3
SPECIAL TORQUES	21-6-3
SPECIAL TOOLS	21-6-4
RANGE TRANSMISSION	21-6-5
Removing the Shaft Master Clutch	21-6-5
Removing the Input Shaft, Countershaft and Mechanical Front Drive (FWD) / Park Brake Assembly	21-6-7
Disassembly of the Master Clutch	21-6-12
Exploded View of the Master Clutch	21-6-14
Assembly of the Master Clutch	21-6-15
Disassembly of the Range Transmission Input Shaft	21-6-16
Exploded View of the Range Transmission Input Shaft	21-6-22
Assembly of the Range Transmission Input Shaft	21-6-23
Cross-Section of Input Shaft	21-6-32
Disassembly of the Range Transmission Countershaft	21-6-33
Exploded View of the Range Transmission Countershaft	21-6-37
Assembly of the Range Transmission Countershaft	21-6-38
Front Wheel Drive (FWD) - Emergency Brake Disassembly	21-6-45
Exploded View of FWD and Emergency Brake	21-6-51
Assembly of the FWD / Emergency Brake	21-6-52
Exploded View of the Range Transmission Countershaft, Input Shaft, and FWD Input Shaft	21-6-66
Installing the Range Transmission Countershaft, Input Shaft, and FWD Input Shaft into the Range Transmission Housing	21-6-67
SETTING THE END PLAY OF THE RANGE TRANSMISSION COUNTERSHAFT AND INPUT SHAFT	21-6-73
Installing the Range Input Master Clutch	21-6-75
TRANSMISSION CONTROL VALVES AND INCHING VALVE	SECTION 21, CHAPTER 7
SPECIAL TORQUES	21-7-3
POWERSHIFT TRANSMISSION CONTROL VALVES	21-7-3
TRANSMISSION CONTROL VALVE CONFIGURATION	21-7-4
INCHING VALVE	21-7-15

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

REAR FRAME	SECTION 21, CHAPTER 8
SPECIFICATIONS	21-8-3
SPECIAL TORQUES	21-8-3
SPECIAL TOOLS	21-8-3
DIFFERENTIAL	21-8-4
Removal	21-8-4
Disassembly	21-8-10
PINION SHAFT	21-8-14
Removal and Disassembly	21-8-14
Assembly and Installation	21-8-16
DIFFERENTIAL ASSEMBLY	21-8-24
DIFFERENTIAL INSTALLATION	21-8-29
ADJUSTING THE DIFFERENTIAL PRELOAD	21-8-35
ADJUSTING THE RING AND PINION BACKLASH	21-8-37
BEVEL PINION AND GEAR TOOTH CONTACT CHECK	21-8-38
HYDRAULIC PUMP DRIVE	SECTION 21, CHAPTER 9
SPECIAL TORQUES	21-9-3
SPECIFICATIONS	21-9-3
PUMP DRIVE	21-9-3
Removal	21-9-3
Disassembly	21-9-4
Assembly	21-9-7
Installation	21-9-12
FRONT WHEEL DRIVE CONTROL SYSTEM - HOW IT WORKS	SECTION 25, CHAPTER 1
FRONT WHEEL DRIVE (FWD)	25-1-3
ELECTRONIC FRONT WHEEL DRIVE (FWD) CONTROL	25-1-5
FRONT WHEEL DRIVE (FWD) CONTROL MODES	25-1-7
FRONT WHEEL DRIVE (FWD) FUNCTIONAL TESTS	25-1-8
TROUBLESHOOTING	25-1-10
DIFFERENTIAL LOCK CONTROL SYSTEM - HOW IT WORKS	SECTION 25, CHAPTER 2
DIFFERENTIAL LOCK	25-2-3
ELECTRONIC DIFFERENTIAL LOCK CONTROL	25-2-5
DIFFERENTIAL LOCK CONTROL MODES	25-2-7
DIFFERENTIAL LOCK CONTROL	25-2-8
DIFFERENTIAL LOCK FUNCTIONAL TESTS	25-2-9
TROUBLESHOOTING	25-2-12
TROUBLESHOOTING	25-2-14
PTO/DIFFERENTIAL LOCK VALVE CIRCUIT	25-2-15
FRONT WHEEL DRIVE OUTPUT SHAFT	SECTION 25, CHAPTER 3
SPECIAL TORQUES	25-3-3
FWD OUTPUT SHAFT	25-3-4
FWD Output Shaft Removal	25-3-4
FWD Output Shaft Disassembly	25-3-5
FWD Output Shaft Assembly	25-3-9
FRONT WHEEL DRIVE DRIVE SHAFT	SECTION 25, CHAPTER 4
SPECIAL TORQUES	25-4-3
FWD DRIVE SHAFT	25-4-4

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

SUSPENSION FWD AXLE SYSTEM - HOW IT WORKS AND TROUBLESHOOTING ..SECTION 25, CHAPTER 5	
SUSPENDED FWD AXLE OPERATION	25-5-3
SUSPENDED MFD AXLE- CALIBRATION MODE	25-5-9
ERROR TABLE	25-5-11
SUSPENDED FWD AXLE- MANUAL OPERATION MODE (TEST MODE)	25-5-13
SUSPENDED FWD AXLE- DEMONSTRATION MODE	25-5-16
SUSPENSION FWD AXLE REMOVAL	SECTION 25, CHAPTER 6
SUSPENDED FWD AXLE	25-6-3
Removal	25-6-3
Installation	25-6-5
SUPERSTEER AXLE REMOVAL AND INSTALLATION	SECTION 25, CHAPTER 7
SPECIAL TORQUES	25-7-3
SPECIAL TOOLS	25-7-3
FRONT AXLE REMOVAL	25-7-4
FRONT AXLE INSTALLATION	25-7-7
LIMITED SLIP FWD DIFFERENTIAL	SECTION 25, CHAPTER 8
SPECIFICATIONS	25-8-2
SPECIAL TORQUES	25-8-2
SPECIAL TOOLS	25-8-2
DIFFERENTIAL CARRIER ASSEMBLY REMOVAL	25-8-3
DIFFERENTIAL DISASSEMBLY	25-8-4
Pinion Disassembly	25-8-8
DIFFERENTIAL ASSEMBLY	25-8-11
DIFFERENTIAL CARRIER ASSEMBLY	25-8-15
Pinion Position and Assembly	25-8-15
Shim Pack Thickness Chart	25-8-16
Setting The Pinion Depth	25-8-17
Adjusting Bearing Preload	25-8-20
DIFFERENTIAL INSTALLATION	25-8-22
Checking Backlash	25-8-23
Ring Gear and Pinion Tooth Pattern Interpretation	25-8-25
Installation of Carrier Assembly to Axle Housing	25-8-27
LOCKING FWD DIFFERENTIAL	SECTION 25, CHAPTER 9
SPECIFICATIONS	25-9-3
SPECIAL TORQUES	25-9-3
SPECIAL TOOLS	25-9-3
REMOVAL OF THE FRONT DIFFERENTIAL CARRIER ASSEMBLY	25-9-4
REMOVAL OF THE FRONT DIFFERENTIAL FROM THE CARRIER HOUSING	25-9-5
DISASSEMBLY OF THE DIFFERENTIAL	25-9-7
PINION DISASSEMBLY	25-9-9
ASSEMBLY OF THE DIFFERENTIAL	25-9-12
DIFFERENTIAL CARRIER ASSEMBLY	25-9-16
SETTING THE PINION DEPTH	25-9-18
ADJUSTING BEARING PRELOAD	25-9-21
DIFFERENTIAL INSTALLATION	25-9-23

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

FWD PLANETARY HUB, STEERING KNUCKLE AND AXLE DRIVE SHAFT	SECTION 25, CHAPTER 10
SPECIFICATIONS	25-10-3
SPECIAL TORQUES	25-10-3
SPECIAL TOOLS	25-10-3
PLANETARY HUB DISASSEMBLY	25-10-4
STEERING KNUCKLE AND KINGPIN DISASSEMBLY	25-10-9
AXLE DRIVE SHAFT DISASSEMBLY	25-10-13
AXLE SHAFT ASSEMBLY	25-10-14
KINGPIN ASSEMBLY	25-10-16
STEERING KNUCKLE ASSEMBLY	25-10-20
PLANETARY HUB ASSEMBLY	25-10-25
Ten Bolt Axle Only	25-10-30
Twelve Bolt Axle Only	25-10-34
All Axles	25-10-39
SUSPENSION FWD AXLE.....	SECTION 25, CHAPTER 11
SPECIAL TORQUES	25-11-2
SUSPENSION FWD AXLE	25-11-3
Disassembly	25-11-3
Assembly	25-11-13
Position Sensor Adjustment	25-11-25
SUPERSTEER AXLE VERTICAL CONTROL LINKAGE	SECTION 25, CHAPTER 12
SPECIAL TORQUES	25-12-3
VERTICAL LINK DISASSEMBLY AND REPAIR	25-12-3
Vertical Link Removal	25-12-3
Roller Replacement	25-12-4
Articulation Bearing Removal and Installation	25-12-5
REAR AXLE AND PLANETARIES	SECTION 27, CHAPTER 1
SPECIAL TOOLS	27-1-3
SPECIAL TORQUES	27-1-5
SPECIFICATIONS	27-1-5
GENERAL INFORMATION	27-1-5
REAR AXLE	27-1-6
AXLE HOUSING DISASSEMBLY	27-1-9
PLANETARY DISASSEMBLY	27-1-11
DIFFERENTIAL CARRIER SEAL REPLACEMENT	27-1-13
PLANETARY ASSEMBLY - THREE PIN	27-1-14
PLANETARY ASSEMBLY - FOUR PIN	27-1-15
AXLE HOUSING ASSEMBLY	27-1-18
HOW TO DETERMINE RAM PRESSURE	27-1-23
AXLE INSTALLATION	27-1-26
AXLE SEAL WEAR SLEEVE INSTALLATION (4-Inch Axle Only)	27-1-30
POWER TAKE OFF CONTROL SYSTEM - HOW IT WORKS	SECTION 31, CHAPTER 1
POWER TAKE OFF	31-1-3
ELECTRONIC PTO CONTROL	31-1-4
PTO SYSTEM CONTROL	31-1-7
PTO CONTROL MODES	31-1-8
PTO VALVE OIL SUPPLY	31-1-10
PTO DIFFERENTIAL LOCK VALVE	31-1-11
TROUBLESHOOTING	31-1-12

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

PTO CLUTCH ASSEMBLY - SINGLE, REVERSIBLE AND DUAL SPEED	SECTION 31, CHAPTER 2
SPECIAL TOOLS	31-2-3
SPECIAL TORQUES	31-2-3
PTO CLUTCH ASSEMBLY	31-2-4
General	31-2-4
PTO CLUTCH SERVICE	31-2-4
Removal	31-2-4
Disassembly	31-2-6
Assembly	31-2-16
Exploded View of PTO Clutch	31-2-16
Cross Section of PTO Clutch and Output Shaft Assembly	31-2-31
SINGLE SPEED REVERSIBLE SHAFT PTO	31-2-32
Disassembly	31-2-32
Assembly	31-2-35
Exploded View of PTO Output Shaft and Driven Gear Assembly	31-2-35
SINGLE SPEED REVERSIBLE SHAFT PTO DRIVEN GEAR	31-2-39
Removal	31-2-39
Assembly	31-2-41
Reversible PTO Output Shaft Bearing Adjustment	31-2-43
SINGLE SPEED REVERSIBLE SHAFT PTO	31-2-45
Cross Section of PTO Output Shaft Assembly	31-2-45
 BRAKE VALVE	 SECTION 33, CHAPTER 1
SPECIAL TORQUES	33-2-2
BRAKE VALVE	33-2-3
Removal	33-2-3
Disassembly	33-2-4
Assembly	33-2-6
Installation	33-2-8
 BRAKE CYLINDERS	 SECTION 33, CHAPTER 2
SPECIAL TORQUES	33-2-3
SPECIFICATIONS	33-2-3
BRAKE CYLINDERS	33-2-3
Disassembly	33-2-3
Assembly	33-2-5
 HYDRAULIC SCHEMATIC POSTER - EUROPEAN	 87518877
 HOW TO READ SYMBOLS IN A HYDRAULIC SCHEMATIC	 SECTION 35, CHAPTER 1
HOW TO READ SYMBOLS IN A HYDRAULIC SCHEMATIC	35-1-3
SIMPLE SCHEMATIC	35-1-13
COMMON SYMBOLS	35-1-15

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

HYDRAULIC SYSTEM - HOW IT WORKS WITH TROUBLESHOOTING	SECTION 35, CHAPTER 2
GENERAL INTRODUCTION	35-2-3
REAR CHARGE/LUBE PUMP PRESSURE TEST	35-2-19
REGULATED SYSTEM PRESSURE TEST AND ADJUSTMENT PROCEDURE	35-2-21
FRONT/REGULATED SYSTEM PUMP FLOW TEST	35-2-25
STEERING RELIEF PRESSURE TEST AND ADJUSTMENT PROCEDURE	35-2-27
STEERING SYSTEM PROBLEMS	35-2-29
PRIORITY AND REGULATOR VALVE	35-2-31
PFC AXIAL PISTON PUMP	35-2-34
PFC PUMP HIGH PRESSURE STANDBY CHECK AND ADJUSTMENT PROCEDURE	35-2-42
PFC PISTON PUMP FLOW TEST	35-2-43
PFC PISTON PUMP FLOW COMPENSATOR SETTING	35-2-44
STANDARD PUMP COMPENSATOR VALVE INSPECTION	35-2-46
PFC PUMP OPERATIONAL PROBLEMS	35-2-47
PTO AND DIFFERENTIAL LOCK VALVE.....	SECTION 35, CHAPTER 3
SPECIAL TORQUES	35-3-2
SPECIFICATIONS	35-3-2
PTO AND DIFFERENTIAL LOCK VALVE	35-3-3
REMOTE VALVE AND COUPLER SERVICE.....	SECTION 35, CHAPTER 4
SPECIAL TORQUES	35-4-2
REMOTE VALVE AND COUPLER SERVICE	35-4-3
REMOTE VALVE REMOVAL AND SERVICE	35-4-5
REMOTE COUPLERS	35-4-13
REMOTE HYDRAULIC SYSTEM - HOW IT WORKS AND TROUBLESHOOTING	SECTION 35, CHAPTER 5
REMOTE HYDRAULIC SYSTEM INTRODUCTION	35-5-3
REMOTE VALVE SYSTEM COMPONENTS	35-5-5
REMOTE VALVE SYSTEM CONTROLS	35-5-10
REMOTE VALVE OPERATION	35-5-14
REMOTE VALVE PROBLEMS AND WHERE TO LOOK	35-5-23
REMOTE VALVE PROPORTIONAL CURRENT CONTROL (PCC) SOLENOID OPERATION	35-5-25
REMOTE VALVE SYSTEM TESTING	35-5-26
REMOTE VALVE HIGH PRESSURE TEST	35-5-27
PFC PUMP HIGH PRESSURE STANDBY CHECK AND ADJUSTMENT PROCEDURE	35-5-28
PFC PISTON PUMP FLOW TEST	35-5-29
STANDARD PUMP COMPENSATOR VALVE INSPECTION	35-5-30
REMOTE VALVE SIGNAL CHECK AND HITCH SIGNAL CHECK	35-5-31
REMOTE VALVE COUPLER TEST	35-5-32
LOAD CHECK INSPECTION	35-5-33
OPERATIONAL PROBLEMS	35-5-34
PRIORITY AND REGULATOR VALVE	SECTION 35, CHAPTER 6
SPECIAL TORQUES	35-6-3
PRIORITY VALVE AND REGULATOR	35-6-4
Removal	35-6-4
Disassembly	35-6-6
Assembly	35-6-9
Installation	35-6-12
CROSS SECTION OF PRIORITY AND REGULATOR VALVE	35-6-14
CHARGE PUMP.....	SECTION 35, CHAPTER 7
Removal	35-7-3
Installation	35-7-4

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

PFC PISTON PUMP AND HYDRAULIC FILTER	SECTION 35, CHAPTER 8
SPECIAL TORQUES	35-8-3
PFC PISTON PUMP	35-8-3
Removal	35-8-3
Installation	35-8-4
HITCH SYSTEM - HOW IT WORKS	SECTION 35, CHAPTER 9
THREE POINT HITCH	35-9-3
ELECTRONIC HITCH CONTROL	35-9-4
ELECTRONIC HITCH CONTROL SYSTEM FEATURES	35-9-7
HITCH CONTROL VALVE	35-9-14
SETUP / ADJUSTMENT SEQUENCE	35-9-22
HITCH CONTROL VALVE	SECTION 35, CHAPTER 10
HITCH CONTROL VALVE	35-10-3
Removal	35-10-3
Disassembly	35-10-5
Assembly	35-10-7
Installation	35-10-9
HITCH CONTROL VALVE CROSS SECTION	35-10-11
TRACTOR HITCH	SECTION 35, CHAPTER 11
SPECIAL TORQUES	35-11-3
TRACTOR HITCH	35-11-3
EDC PIN ASSEMBLY	35-11-20
POTENTIOMETER (HITCH POSITION SENSOR)	35-11-21
CAM SWAY LIMITER	35-11-23
CAM BUMPERS FOR DRAFT ARM	35-11-25
DRAWBAR, HIGH VERTICAL CAPACITY	35-11-26
STEERING COLUMN AND STEERING HAND PUMP	SECTION 41, CHAPTER 1
SPECIAL TOOLS	41-1-2
SPECIAL TORQUES	41-1-3
STEERING COLUMN REMOVAL	41-1-3
STEERING HAND PUMP SERVICE	41-1-6
STEERING COLUMN ASSEMBLY	41-1-8
WHEEL TOE IN SETTING SUPERSTEER FWD AXLE	SECTION 41, CHAPTER 2
WHEEL TOE IN SETTING	41-2-3
WHEEL TOE IN SETTING DIAGRAM	41-2-9
SPECIAL TOOL LAYOUT DRAWINGS	41-2-10

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

A/C TROUBLESHOOTING	SECTION 50, CHAPTER 1
SAFETY PROCEDURES	50-1-5
SPECIAL TOOLS	50-1-6
A/C THERMAL OPERATION	50-1-7
A/C SYSTEM COMPONENTS	50-1-9
Cab HVAC Box Components - Automatic Temperature Control	50-1-9
Chassis Components	50-1-11
AUTOMATIC TEMPERATURE CONTROL (ATC) OPERATION	50-1-12
Operation Modes	50-1-15
Automatic Mode	50-1-15
Defog Mode	50-1-15
Automatic Operation Summary	50-1-16
Defog/Dehumidify Operation Summary	50-1-17
ATC Fault Codes	50-1-18
ATC Fault Code 111	50-1-18
ATC Fault Code 112	50-1-19
ATC Fault Code 115	50-1-19
ATC Fault Code 116	50-1-20
ATC Fault Code 120	50-1-20
ATC Fault Code 121	50-1-21
ATC Fault Code 122	50-1-21
ATC Fault Code 125	50-1-22
ATC Fault Code 126	50-1-22
ATC Fault Code 127	50-1-23
ATC Fault Code 128	50-1-23
ATC Fault Code 129	50-1-24
ATC Fault Code 130	50-1-24
ATC Fault Code 131	50-1-25
ATC Fault Code 132	50-1-25
ATC Fault Code 133	50-1-26
ATC Fault Code 134	50-1-26
Locating System Problems Without Fault Codes	50-1-27
Controller-Based Resistance Tests	50-1-27
ATC Controller Test (Connector J8 Test Points)	50-1-29
ATC Field Reported Symptoms/Causes	50-1-32
Compressor And Clutch	50-1-33
Operational Check	50-1-33
Electrical Test	50-1-36
Compressor Clutch Control Circuit Test Procedure	50-1-36
Service Note: Adjusting Clutch Air Gap	50-1-38
High And Low Pressure Switch Clutch Latching Circuit	50-1-39
Background	50-1-39
Possible Failure Modes - Fault Codes 129 and 134	50-1-40
Electrical Test	50-1-41
High Pressure Switch and Circuit Test	50-1-41
Low Pressure Switch and Circuit Test	50-1-42
Heater Control Valve	50-1-43
Operational Check	50-1-43
Electrical Test	50-1-44
Heater Control Valve Power, Signal and Ground Test	50-1-44
Blower Speed And Temperature Control Potentiometers	50-1-45
Background	50-1-45
Possible Failure Modes - Fault Codes 120, 121	50-1-45
Electrical Test	50-1-46
Common Control Potentiometer and Circuit Test Procedure	50-1-46

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

BLOWER AND BLOWER SPEED DRIVER	50-1-47
Background	50-1-47
Power, Signal and Ground Circuit	50-1-47
Possible Failure Modes	50-1-47
Blower Motor/Blower Driver Power, Signal and Ground Test	50-1-48
Cab And Evaporator Temperature Sensors	50-1-49
Background	50-1-49
Electrical Test	50-1-51
Power Circuit	50-1-51
Possible Failure Modes - Fault Codes 111, 115 and 116	50-1-52
Cab Temperature Sensor and Circuit Test	50-1-53
Evaporator Temperature Sensor and Circuit Test	50-1-54
Controller Power, Ground, And ATC Switch	50-1-56
Background	50-1-56
Power and Ground Circuit	50-1-56
Possible Failure Modes	50-1-56
Controller Power Supply and Ground Test	50-1-56
ATC Switch and Circuit Test	50-1-57
Defog/Defrost Switch and Circuit Test	50-1-57
Cab Pressurizer Blower	50-1-58
Background	50-1-58
Power and Ground	50-1-58
Cab Pressurizer Blower & Relay Power Supply and Ground Test	50-1-58
ACCESSING THE HVAC BOX	50-1-59
STANDARD AIR CONDITIONING (STD) TROUBLESHOOTING	50-1-60
Standard A/C Operation	50-1-61
Smart Pressure Switch Cycling System	50-1-61
Standard A/C Controls and Their Function	50-1-62
Symptom-Based Standard A/C Troubleshooting	50-1-63
Standard Controller Test	50-1-65
Compressor And Clutch	50-1-67
Operational Check	50-1-67
Electrical Test – Compressor Clutch	50-1-70
Clutch Relay Power Supply and Ground Test	50-1-71
Service Note: Adjusting Clutch Air Gap	50-1-72
High And Low Pressure Switch Clutch Latching Circuit	50-1-73
Background	50-1-73
Possible Failure Modes - Flashing Pressure Warning Lamp	50-1-74
Electrical Test – Pressure Switches	50-1-75
High Pressure Switch and Circuit Test	50-1-75
Low Pressure Switch and Circuit Test	50-1-76
Heater Control Valve	50-1-77
Operational Check	50-1-77
Electrical Test	50-1-78
Temperature Control Potentiometer	50-1-79
Background	50-1-79
Electrical Test	50-1-79
Blower Speed Switch And Blower Motor	50-1-80
Background	50-1-80
Power and Ground Circuit	50-1-80
Possible Failure Modes	50-1-80
Blower Speed Switch and Power Circuit Test	50-1-81
Blower Motor Power, and Control Circuit Test	50-1-81

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

Evaporator Temperature Sensor	50-1-83
Background	50-1-83
Electrical Test – Sensor	50-1-83
Power Circuit	50-1-84
Service Note: Too Little Cooling/Too Much Heating without Symptoms	50-1-84
Evaporator Temperature Sensor and Circuit Test	50-1-84
Controller Power, Ground And A/C Switch	50-1-86
Background	50-1-86
Power and Ground Circuit	50-1-86
Possible Failure Modes	50-1-86
Controller Power Supply and Ground Test	50-1-86
A/C Switch and Circuit Test	50-1-87
Cab Pressurizer Blower	50-1-88
Background	50-1-88
Power and Ground	50-1-88
Cab Pressurizer Blower & Relay Power Supply and Ground Test	50-1-89

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

AIR CONDITIONER SYSTEM SERVICE	SECTION 50, CHAPTER 2
SPECIFICATIONS	50-2-4
SPECIAL TORQUES	50-2-4
SPECIAL TOOLS	50-2-4
SAFETY PROCEDURES	50-2-9
AIR CONDITIONER SYSTEM REFRIGERANT RECOVERY	50-2-10
RECOVERING PURE 134A REFRIGERANT	50-2-12
RECOVERING CONTAMINATED REFRIGERANT WITH OEM1691	50-2-16
Preparing the Tank	50-2-16
Recovery Process	50-2-20
AIR CONDITIONER SYSTEM EVACUATION AND RECHARGING	50-2-26
AIR CONDITIONING TEMPERATURE/PRESSURE CHART	50-2-33
A/C SYSTEM FLUSHING PROCEDURE	50-2-34
Required Tools	50-2-35
Precautions	50-2-36
Component Flushing Procedure with Power Flush 17550	50-2-37
Complete Circuit Flushing Procedure with Power Flush 17550	50-2-41
Back Flushing the Thermal Expansion Valve or Refrigerant Line	50-2-46
Post Flushing Procedures	50-2-48
Flushing Solvent Disposal	50-2-50
LEAK DETECTION	50-2-51
Electronic Testing with OEM1437	50-2-52
Fluorescent Leak Detection	50-2-53
Fluorescent Dye Injection	50-2-53
Fluorescent Leak Testing	50-2-59
A/C SYSTEM COMPONENTS	50-2-60
Cab HVAC Box Components - Automatic Temperature Control	50-2-60
Cab HVAC Components - Standard Systems	50-2-62
Chassis Components	50-2-64
A/C COMPRESSOR CLUTCH	50-2-65
Clutch Removal	50-2-65
Exploded View of Clutch	50-2-71
Compressor Clutch Replacement	50-2-71
A/C COMPRESSOR	50-2-79
Oil Level Check or Adjustment	50-2-79
Compressor Removal	50-2-82
Compressor Installation	50-2-85
CONDENSER AND RECEIVER-DRIER	50-2-87
Condenser	50-2-87
Receiver-Drier	50-2-88
ACCESSING THE HVAC BOX	50-2-90
THERMAL EXPANSION VALVE TESTING	50-2-92
THERMAL EXPANSION VALVE REPLACEMENT	50-2-93
EVAPORATOR AND CAB TEMPERATURE SENSOR LOCATION	50-2-95
BLOWER MOTOR REPLACEMENT	50-2-96
HEATER CONTROL VALVE REPLACEMENT	50-2-97
EVAPORATOR/HEATER ASSEMBLY	50-2-98
Evaporator/Heater Assembly Removal	50-2-98
Evaporator/Heater Assembly Installation	50-2-101
Post Replacement Procedures	50-2-104
EVAPORATOR/HEATER ASSEMBLY SEALING AND CLEANING	50-2-105
BLOWER AND EVAPORATOR REFERENCE ILLUSTRATION	50-2-106
CONTROLLER AND BLOWER SPEED DRIVER REPLACEMENT	50-2-107
ATC Controller	50-2-107
Standard A/C Controller	50-2-107
Blower Speed Driver (ATC Units Only)	50-2-108
CAB AIR FILTER SERVICE	50-2-109

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

CAB RECIRCULATION AIR FILTER SERVICE	50-2-110
CAB PRESSURIZATION TEST	50-2-111
CAB PRESSURIZER MOTOR REPLACEMENT	50-2-113
VISCOUS FAN DRIVE	50-2-116
ELECTRICAL SCHEMATIC POSTER - EUROPEAN	87389711
ELECTRICAL SYSTEM - HOW IT WORKS AND TROUBLESHOOTING	SECTION 55, CHAPTER 1
SPECIAL TOOLS	55-1-4
FUSES AND RELAY IDENTIFICATION	55-1-5
Cab Fuses/Relay Location	55-1-5
Engine Compartment Fuse/Relay Identification (Power Distribution Box)	55-1-5
Fuse Identification	55-1-6
Relays	55-1-7
INSTRUMENTATION AND CONTROLS	55-1-8
CONNECTOR AND COMPONENT LOCATIONS	55-1-12
ELECTRICAL CONNECTORS	55-1-34
ELECTRICAL SYSTEMS SCHEMATICS AND DIAGNOSTICS	55-1-141
Power Distribution System Circuit Operation	55-1-141
Power Distribution Circuit Troubleshooting	55-1-141
Power Distribution Schematic	55-1-141
POWER DISTRIBUTION SYMPTOM CHART	55-1-142
Diagnostic Tests	55-1-143
AUDIO SYSTEM	55-1-145
Audio System Circuit Operation	55-1-145
Audio System Circuit Troubleshooting	55-1-145
Audio System Symptom Chart	55-1-145
Audio System Diagnostic Tests	55-1-147
CHARGING SYSTEM	55-1-151
Charging System Circuit Operation	55-1-151
Charging System Circuit Troubleshooting	55-1-151
Charging System Symptom Chart	55-1-152
Charging System Diagnostic Tests	55-1-153
EXTERIOR LIGHTING SYSTEM	55-1-157
Exterior Lighting System Circuit Operation	55-1-157
Exterior Lighting System Circuit Troubleshooting	55-1-157
Exterior Lighting System Symptom Chart	55-1-158
Exterior Lighting System Diagnostic Tests	55-1-158
INSTRUMENTATION AND WARNING SYSTEM	55-1-163
Instrumentation and Warning System Circuit Troubleshooting	55-1-163
Instrumentation and Warning System Symptom Chart	55-1-163
Instrumentation and Warning System Diagnostic Tests	55-1-164
INTERIOR LIGHTING AND HORN SYSTEM	55-1-167
Interior Lighting and Horn System Circuit Operation	55-1-167
Interior Lighting and Horn System Circuit Troubleshooting	55-1-167
Interior Lighting and Horn System Symptom Chart	55-1-168
Interior Lighting and Horn System Diagnostic Tests	55-1-168
POWER MIRROR SYSTEM	55-1-172
Power Mirror Circuit Operation	55-1-172
Power Mirror Circuit Troubleshooting	55-1-172
Power Mirror System Symptom Chart	55-1-173
Power Mirror System Diagnostic Tests	55-1-175

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

POWER SEAT SYSTEM	55-1-184
Power Seat System Circuit Operation	55-1-184
Power Seat System Circuit Troubleshooting	55-1-184
Power Seat System Symptom Chart	55-1-185
Power Seat System Diagnostic Tests	55-1-186
STARTING SYSTEM	55-1-190
Starting System Circuit Operation	55-1-190
Starter Motor Circuit Troubleshooting	55-1-190
Starting System Symptom Chart	55-1-190
Starting System Diagnostic Tests	55-1-192
WIPER/WASHER SYSTEM	55-1-197
Wiper/Washer System Circuit Operation	55-1-197
Wiper/Washer System Circuit Troubleshooting	55-1-197
Wiper/Washer System Symptom Chart	55-1-198
Wiper/Washer System Diagnostic Tests	55-1-199
INSTRUMENTATION CONTROLLER FAULT CODES	SECTION 55, CHAPTER 2
FAULT CODE INST 1015	55-2-4
FAULT CODE INST 3010	55-2-6
FAULT CODE INST 3020	55-2-7
FAULT CODE INST 3022	55-2-7
FAULT CODE INST 5010	55-2-7
FAULT CODE INST 5011	55-2-8
FAULT CODE INST 10031	55-2-9
FAULT CODE INST 10032	55-2-9
FAULT CODE INST 10033	55-2-9
FAULT CODE INST 10034	55-2-10
FAULT CODE INST 10035	55-2-10
FAULT CODE INST 10036	55-2-10
FAULT CODE INST 10037	55-2-11
FAULT CODE INST 10038	55-2-11
FAULT CODE INST 11011	55-2-12
FAULT CODE INST 12011	55-2-13
FAULT CODE INST 12043	55-2-15
FAULT CODE INST 12051	55-2-17
FAULT CODE INST 12071	55-2-19
FAULT CODE INST 12091	55-2-21
FAULT CODE INST 12111	55-2-23
FAULT CODE INST 13010	55-2-25
FAULT CODE INST 13011	55-2-26
FAULT CODE INST 13012	55-2-27
FAULT CODE INST 13021	55-2-28
FAULT CODE INST 13022	55-2-29
FAULT CODE INST 13040	55-2-30
FAULT CODE INST 13051	55-2-31
FAULT CODE INST 13052	55-2-32
FAULT CODE INST 53001	55-2-33
FAULT CODE INST 53005	55-2-33
FAULT CODE INST 65535	55-2-33

AUX/HITCH/PTO FAULT CODES -

TRACTOR MULTI-FUNCTION (TMF) CONTROLLER	SECTION 55, CHAPTER 3
AUX/HITCH/PTO FAULT CODE 2	55-3-7
AUX/HITCH/PTO FAULT CODE 4	55-3-8
AUX/HITCH/PTO FAULT CODE 5	55-3-9
AUX/HITCH/PTO FAULT CODE 7	55-3-10
AUX/HITCH/PTO FAULT CODE 11	55-3-11
AUX/HITCH/PTO FAULT CODE 12	55-3-13
AUX/HITCH/PTO FAULT CODE 14	55-3-14
AUX/HITCH/PTO FAULT CODE 15	55-3-15
AUX/HITCH/PTO FAULT CODE 17	55-3-16
AUX/HITCH/PTO FAULT CODE 18	55-3-17
AUX/HITCH/PTO FAULT CODE 19	55-3-18
AUX/HITCH/PTO FAULT CODE 21	55-3-18
AUX/HITCH/PTO FAULT CODE 22	55-3-19
AUX/HITCH/PTO FAULT CODE 23	55-3-20
AUX/HITCH/PTO FAULT CODE 24	55-3-21
AUX/HITCH/PTO FAULT CODE 25	55-3-22
AUX/HITCH/PTO FAULT CODE 26	55-3-23
AUX/HITCH/PTO FAULT CODE 28	55-3-24
AUX/HITCH/PTO FAULT CODE 29	55-3-24
AUX/HITCH/PTO FAULT CODE 30	55-3-25
AUX/HITCH/PTO FAULT CODE 31	55-3-26
AUX/HITCH/PTO FAULT CODE 32	55-3-28
AUX/HITCH/PTO FAULT CODE 33	55-3-29
AUX/HITCH/PTO FAULT CODE 34	55-3-29
AUX/HITCH/PTO FAULT CODE 35	55-3-30
AUX/HITCH/PTO FAULT CODE 37	55-3-31
AUX/HITCH/PTO FAULT CODE 41	55-3-31
AUX/HITCH/PTO FAULT CODE 42	55-3-32
AUX/HITCH/PTO FAULT CODE 43	55-3-32
AUX/HITCH/PTO FAULT CODE 44	55-3-32
AUX/HITCH/PTO FAULT CODE 45	55-3-32
AUX/HITCH/PTO FAULT CODE 47	55-3-33
AUX/HITCH/PTO FAULT CODE 48	55-3-33
AUX/HITCH/PTO FAULT CODE 50	55-3-34
AUX/HITCH/PTO FAULT CODE 51	55-3-34
AUX/HITCH/PTO FAULT CODE 52	55-3-35
AUX/HITCH/PTO FAULT CODE 53	55-3-35
AUX/HITCH/PTO FAULT CODE 54	55-3-36
AUX/HITCH/PTO FAULT CODE 55	55-3-37
AUX/HITCH/PTO FAULT CODE 56	55-3-38
AUX/HITCH/PTO FAULT CODE 57	55-3-39
AUX/HITCH/PTO FAULT CODE 58	55-3-40
AUX/HITCH/PTO FAULT CODE 59	55-3-41
AUX/HITCH/PTO FAULT CODE 60	55-3-41
AUX/HITCH/PTO FAULT CODE 61	55-3-42
AUX/HITCH/PTO FAULT CODE 62	55-3-42
AUX/HITCH/PTO FAULT CODE 63	55-3-42
AUX/HITCH/PTO FAULT CODE 64	55-3-43
AUX/HITCH/PTO FAULT CODE 65	55-3-43
AUX/HITCH/PTO FAULT CODE 66	55-3-44
AUX/HITCH/PTO FAULT CODE 80	55-3-44
AUX/HITCH/PTO FAULT CODE 81	55-3-45
AUX/HITCH/PTO FAULT CODE 82	55-3-46
AUX/HITCH/PTO FAULT CODE 83	55-3-47
AUX/HITCH/PTO FAULT CODE 86	55-3-48

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

AUX/HITCH/PTO FAULT CODE 87	55-3-49
AUX/HITCH/PTO FAULT CODE 88	55-3-50
AUX/HITCH/PTO FAULT CODE 89	55-3-50
AUX/HITCH/PTO FAULT CODE 90	55-3-51
AUX/HITCH/PTO FAULT CODE 92	55-3-51
AUX/HITCH/PTO FAULT CODE 93	55-3-52
AUX/HITCH/PTO FAULT CODE 94	55-3-52
AUX/HITCH/PTO FAULT CODE 98	55-3-53
AUX/HITCH/PTO FAULT CODE 99	55-3-53
AUX/HITCH/PTO FAULT CODE 106	55-3-54
AUX/HITCH/PTO FAULT CODE 107	55-3-54
AUX/HITCH/PTO FAULT CODE 108	55-3-55
AUX/HITCH/PTO FAULT CODE 109	55-3-55
AUX/HITCH/PTO FAULT CODE 110	55-3-56
AUX/HITCH/PTO FAULT CODE 111	55-3-56
AUX/HITCH/PTO FAULT CODE 112	55-3-57
AUX/HITCH/PTO FAULT CODE 113	55-3-58
AUX/HITCH/PTO FAULT CODE 114	55-3-59
AUX/HITCH/PTO FAULT CODE 115	55-3-60
AUX/HITCH/PTO FAULT CODE 116	55-3-61
AUX/HITCH/PTO FAULT CODE 120	55-3-62
AUX/HITCH/PTO FAULT CODE 123	55-3-62
AUX/HITCH/PTO FAULT CODE 124	55-3-63
AUX/HITCH/PTO FAULT CODE 125	55-3-64
AUX/HITCH/PTO FAULT CODE 126	55-3-65
AUX/HITCH/PTO FAULT CODE 127	55-3-66
AUX/HITCH/PTO FAULT CODE 128	55-3-67
AUX/HITCH/PTO FAULT CODE 129	55-3-68
AUX/HITCH/PTO FAULT CODE 130	55-3-69
AUX/HITCH/PTO FAULT CODE 131	55-3-70
AUX/HITCH/PTO FAULT CODE 132	55-3-71
AUX/HITCH/PTO FAULT CODE 133	55-3-72
AUX/HITCH/PTO FAULT CODE 134	55-3-73
AUX/HITCH/PTO FAULT CODE 135	55-3-74
AUX/HITCH/PTO FAULT CODE 136	55-3-75
AUX/HITCH/PTO FAULT CODE 137	55-3-76
AUX/HITCH/PTO FAULT CODE 138	55-3-77
AUX/HITCH/PTO FAULT CODE 139	55-3-78
AUX/HITCH/PTO FAULT CODE 140	55-3-79
AUX/HITCH/PTO FAULT CODE 141	55-3-80
AUX/HITCH/PTO FAULT CODE 142	55-3-81
AUX/HITCH/PTO FAULT CODE 147	55-3-82
AUX/HITCH/PTO FAULT CODE 148	55-3-82
AUX/HITCH/PTO FAULT CODE 149	55-3-83
AUX/HITCH/PTO FAULT CODE 150	55-3-83
AUX/HITCH/PTO FAULT CODE 151	55-3-84
AUX/HITCH/PTO FAULT CODE 152	55-3-86
AUX/HITCH/PTO FAULT CODE 153	55-3-86
AUX/HITCH/PTO FAULT CODE 154	55-3-87
AUX/HITCH/PTO FAULT CODE 155	55-3-87
AUX/HITCH/PTO FAULT CODE 156	55-3-88
AUX/HITCH/PTO FAULT CODE 157	55-3-88
AUX/HITCH/PTO FAULT CODE 158	55-3-89
AUX/HITCH/PTO FAULT CODE 159	55-3-89
AUX/HITCH/PTO FAULT CODE 160	55-3-90
AUX/HITCH/PTO FAULT CODE 161	55-3-91
AUX/HITCH/PTO FAULT CODE 162	55-3-92

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

AUX/HITCH/PTO FAULT CODE 163	55-3-93
AUX/HITCH/PTO FAULT CODE 164	55-3-94
AUX/HITCH/PTO FAULT CODE 165	55-3-95
AUX/HITCH/PTO FAULT CODE 166	55-3-96
AUX/HITCH/PTO FAULT CODE 167	55-3-97
AUX/HITCH/PTO FAULT CODE 168	55-3-98
AUX/HITCH/PTO FAULT CODE 169	55-3-99
AUX/HITCH/PTO FAULT CODE 170	55-3-100
AUX/HITCH/PTO FAULT CODE 171	55-3-101
AUX/HITCH/PTO FAULT CODE 172	55-3-101
AUX/HITCH/PTO FAULT CODE 173	55-3-102
AUX/HITCH/PTO FAULT CODE 174	55-3-103
AUX/HITCH/PTO FAULT CODE 175	55-3-104
AUX/HITCH/PTO FAULT CODE 178	55-3-106
AUX/HITCH/PTO FAULT CODE 179	55-3-107
AUX/HITCH/PTO FAULT CODE 180	55-3-108

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

TRANSMISSION CONTROLLER FAULT CODES	SECTION 55, CHAPTER 4
FAULT CODE TRANS 11	55-4-5
FAULT CODE TRANS 12	55-4-6
FAULT CODE TRANS 24	55-4-7
FAULT CODE TRANS 37	55-4-8
FAULT CODE TRANS	55-4-9
FAULT CODE TRANS 47	55-4-10
FAULT CODE TRANS 48	55-4-12
FAULT CODE TRANS 49	55-4-13
FAULT COE TRANS 50	55-4-14
FAULT CODE TRANS 51	55-4-15
FAULT CODE TRANS 52	55-4-16
FAULT CODE TRANS 53	55-4-17
FAULT CODE TRANS 54	55-4-19
FAULT CODE TRANS 59	55-4-21
FAULT CODE TRANS 60	55-4-22
FAULT CODE TRANS 66	55-4-23
FAULT CODE TRANS 67	55-4-24
FAULT CODE TRANS 68	55-4-25
FAULT CODE TRANS 69	55-4-26
FAULT CODE TRANS 70	55-4-27
FAULT CODE TRANS 72	55-4-27
FAULT CODE TRANS 73	55-4-28
FAULT CODE TRANS 74	55-4-28
FAULT CODE TRANS 77	55-4-29
FAULT CODE TRANS 78	55-4-30
FAULT CODE TRANS 79	55-4-31
FAULT CODE TRANS 80	55-4-32
FAULT CODE TRANS 81	55-4-34
FAULT CODE TRANS 82	55-4-36
FAULT CODE TRANS 83	55-4-36
FAULT CODE TRANS 103	55-4-37
FAULT CODE TRANS 104	55-4-38
FAULT CODE TRANS 105	55-4-39
FAULT CODE TRANS 106	55-4-40
FAULT CODE TRANS 107	55-4-41
FAULT CODE TRANS 108	55-4-42
FAULT CODE TRANS 109	55-4-43
FAULT CODE TRANS 110	55-4-44
FAULT CODE TRANS 111	55-4-45
FAULT CODE TRANS 112	55-4-46
FAULT CODE TRANS 113	55-4-47
FAULT CODE TRANS 114	55-4-48
FAULT CODE TRANS 115	55-4-49
FAULT CODE TRANS 116	55-4-50
FAULT CODE TRANS 117	55-4-51
FAULT CODE TRANS 118	55-4-52
FAULT CODE TRANS 119	55-4-53
FAULT CODE TRANS 120	55-4-54
FAULT CODE TRANS 121	55-4-55
FAULT CODE TRANS 122	55-4-56
FAULT CODE TRANS 123	55-4-57
FAULT CODE TRANS 124	55-4-58
FAULT CODE TRANS 125	55-4-59
FAULT CODE TRANS 126	55-4-59
FAULT CODE TRANS 127	55-4-59
FAULT CODE TRANS 128	55-4-60

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

FAULT CODE TRANS 129	55-4-60
FAULT CODE TRANS 130	55-4-60
FAULT CODE TRANS 131	55-4-61
FAULT CODE TRANS 132	55-4-61
FAULT CODE TRANS 133	55-4-61
FAULT CODE TRANS 134	55-4-62
FAULT CODE TRANS 135	55-4-63
FAULT CODE TRANS 136	55-4-65
FAULT CODE TRANS 137	55-4-67
FAULT CODE TRANS 138	55-4-68
FAULT CODE TRANS 139	55-4-69
FAULT CODE TRANS 140	55-4-70
FAULT CODE TRANS 141	55-4-71
FAULT CODE TRANS 142	55-4-72
FAULT CODE TRANS 143	55-4-72
FAULT CODE TRANS 144	55-4-73
FAULT CODE TRANS 145	55-4-74
FAULT CODE TRANS 147	55-4-75
FAULT CODE TRANS 148	55-4-77

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

ARMREST CONTROLLER FAULT CODES	SECTION 55, CHAPTER 5
FAULT CODE ARM 19	55-5-4
FAULT CODE ARM 29	55-5-5
FAULT CODE ARM 39	55-5-6
FAULT CODE ARM 49	55-5-7
FAULT CODE ARM 59	55-5-8
FAULT CODE ARM 69	55-5-9
FAULT CODE ARM 79	55-5-10
FAULT CODE ARM 89	55-5-11
FAULT CODE ARM 99	55-5-12
FAULT CODE ARM 109	55-5-13
FAULT CODE ARM 119	55-5-14
FAULT CODE ARM 129	55-5-15
FAULT CODE ARM 139	55-5-16
FAULT CODE ARM 149	55-5-17
FAULT CODE ARM 159	55-5-18
FAULT CODE ARM 169	55-5-19
FAULT CODE ARM 1029	55-5-20
FAULT CODE ARM 1039	55-5-21
FAULT CODE ARM 1049	55-5-22
FAULT CODE ARM 1059	55-5-23
FAULT CODE ARM 1069	55-5-24
FAULT CODE ARM 1079	55-5-25
FAULT CODE ARM 1089	55-5-26
FAULT CODE ARM 1099	55-5-27
FAULT CODE ARM 1109	55-5-28
FAULT CODE ARM 1119	55-5-29
FAULT CODE ARM 1129	55-5-30
FAULT CODE ARM 8011	55-5-30
FAULT CODE ARM 9011	55-5-31
FAULT CODE ARM 9012	55-5-31
FAULT CODE ARM 9013	55-5-32
FAULT CODE ARM 9014	55-5-32
FAULT CODE ARM 9015	55-5-33
FAULT CODE ARM 9021	55-5-33
FAULT CODE ARM 9031	55-5-34
FAULT CODE ARM 9041	55-5-34
FAULT CODE ARM 10091	55-5-35
FAULT CODE ARM 12013	55-5-36
FAULT CODE ARM 12081	55-5-38
FAULT CODE ARM 65535	55-5-39

T8010/T8020/T8030/T8040 MASTER TABLE OF CONTENTS

CONTROLLER CONFIGURATION AND CALIBRATION	SECTION 55, CHAPTER 6
FAULT CODE RETRIEVAL	55-6-3
INSTRUMENTATION PROGRAMMING	55-6-5
Radar Calibration	55-6-9
Controller Configuration	55-6-12
INSTRUMENTATION DISPLAY SYMPTOM BASED FAULTS	55-6-17
ARMREST CONTROLLER CONFIGURATION AND CALIBRATION	55-6-19
TRANSMISSION CONTROLLER CONFIGURATION AND CALIBRATION	55-6-28
When Calibration is Required	55-6-28
Clutch Calibration Procedure	55-6-39
Calibration Error Messages	55-6-43
Front Suspension Calibration	55-6-48
REMOTE (AUX) SYSTEM CALIBRATION	55-6-55
Aux Cal Menu	55-6-61
HITCH SYSTEM CALIBRATION	55-6-64
PTO SYSTEM CONFIGURATION	55-6-74
 PEDAL AND PEDAL SWITCH ADJUSTMENTS.....	 SECTION 90, CHAPTER 1
TABLE OF CONTENTS	90-1-2
INCHING PEDAL SWITCH ADJUSTMENT	90-1-3
BRAKE PEDAL ADJUSTMENTS	90-1-3
 CAB RAISE/REMOVAL AND INSTALLATION.....	 SECTION 90, CHAPTER 2
SPECIAL TORQUES	90-2-3
SPECIAL TOOLS	90-2-3
CAB RAISE PROCEDURE	90-2-4
CAB LOWERING PROCEDURE	90-2-7
CAB REMOVAL	90-2-10
CAB INSTALLATION	90-2-17

Section 00

Chapter 1

STANDARD TORQUE SPECIFICATION

TABLE OF CONTENTS

TORQUE SPECIFICATIONS - METRIC HARDWARE	00-1-4
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS	00-1-5
TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS	00-1-6

TORQUE SPECIFICATIONS - DECIMAL HARDWARE

Use the torques in this chart when special torques are not given. These torques apply to fasteners with both UNC and UNF threads as received from suppliers dry, or when lubricated with engine oil. Not applicable if special graphites, Molydisulfide greases, or other extreme pressure lubricants are used.

Grade 5 Bolts, Nuts, and Studs		
  		
Size	Pound-Inches	Newton metres
1/4 inch	108 to 132	12 to 15
5/16 inch	204 to 252	23 to 28
3/8 inch	420 to 504	48 to 57
Size	Pound-Feet	Newton metres
7/16 inch	54 to 64	73 to 87
1/2 inch	80 to 96	109 to 130
9/16 inch	110 to 132	149 to 179
5/8 inch	150 to 180	203 to 244
3/4 inch	270 to 324	366 to 439
7/8 inch	400 to 480	542 to 651
1.0 inch	580 to 696	787 to 944
1-1/8 inch	800 to 880	1085 to 1193
1-1/4 inch	1120 to 1240	1519 to 1681
1-3/8 inch	1460 to 1680	1980 to 2278
1-1/2 inch	1940 to 2200	2631 to 2983

Grade 8 Bolts, Nuts, and Studs		
  		
Size	Pound-Inches	Newton metres
1/4 inch	144 to 180	16 to 20
5/16 inch	288 to 348	33 to 39
3/8 inch	540 to 648	61 to 73
Size	Pound-Feet	Newton metres
7/16 inch	70 to 84	95 to 114
1/2 inch	110 to 132	149 to 179
9/16 inch	160 to 192	217 to 260
5/8 inch	220 to 264	298 to 358
3/4 inch	380 to 456	515 to 618
7/8 inch	600 to 720	814 to 976
1.0 inch	900 to 1080	1220 to 1465
1-1/8 inch	1280 to 1440	1736 to 1953
1-1/4 inch	1820 to 2000	2468 to 2712
1-3/8 inch	2380 to 2720	3227 to 3688
1-1/2 inch	3160 to 3560	4285 to 4827
NOTE: Use thick nuts with Grade 8 bolts.		

TORQUE SPECIFICATIONS - METRIC HARDWARE

Use the following torques when specifications are not given.

These values apply to fasteners with coarse threads as received from supplier, plated or unplated, or when lubricated with engine oil. These values do not apply if graphite or Molydisulfide grease or oil is used.

Grade 8.8 Bolts, Nuts, and Studs		
		
Size	Pound-Inches	Newton metres
M4	24 to 36	3 to 4
M5	60 to 72	7 to 8
M6	96 to 108	11 to 12
M8	228 to 276	26 to 31
M10	456 to 540	52 to 61
Size	Pound-Feet	Newton metres
M12	66 to 79	90 to 107
M14	106 to 127	144 to 172
M16	160 to 200	217 to 271
M20	320 to 380	434 to 515
M24	500 to 600	675 to 815
M30	920 to 1100	1250 to 1500
M36	1600 to 1950	2175 to 2600

Grade 10.9 Bolts, Nuts, and Studs		
		
Size	Pound-Inches	Newton metres
M4	36 to 48	4 to 5
M5	84 to 96	9 to 11
M6	132 to 156	15 to 18
M8	324 to 384	37 to 43
Size	Pound-Feet	Newton metres
M10	54 to 64	73 to 87
M12	93 to 112	125 to 150
M14	149 to 179	200 to 245
M16	230 to 280	310 to 380
M20	450 to 540	610 to 730
M24	780 to 940	1050 to 1275
M30	1470 to 1770	2000 to 2400
M36	2580 to 3090	3500 to 4200

Grade 12.9 Bolts, Nuts, and Studs



Usually the torque values specified for grade 10.9 fasteners can be used satisfactorily on grade 12.9 fasteners.

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Tube OD Hose ID	Thread Size	Pound- Inches	Newton metres
37 Degree Flare Fitting			
1/4 inch 6.4 mm	7/16-20	72 to 144	8 to 16
5/16 inch 7.9 mm	1/2-20	96 to 192	11 to 22
3/8 inch 9.5 mm	9/16-18	120 to 300	14 to 34
1/2 inch 12.7 mm	3/4-16	180 to 504	20 to 57
5/8 inch 15.9 mm	7/8-14	300 to 696	34 to 79
Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres
3/4 inch 19.0 mm	1-1/16-12	40 to 80	54 to 108
7/8 inch 22.2 mm	1-3/16-12	60 to 100	81 to 135
1.0 inch 25.4 mm	1-5/16-12	75 to 117	102 to 158
1-1/4 inch 31.8 mm	1-5/8-12	125 to 165	169 to 223
1-1/2 inch 38.1 mm	1-7/8-12	210 to 250	285 to 338

Tube OD Hose ID	Thread Size	Pound- Inches	Newton metres
Straight Threads with O-ring			
1/4 inch 6.4 mm	7/16-20	144 to 228	16 to 26
5/16 inch 7.9 mm	1/2-20	192 to 300	22 to 34
3/8 inch 9.5 mm	9/16-18	300 to 480	34 to 54
1/2 inch 12.7 mm	3/4-16	540 to 804	57 to 91
Tube OD Hose ID	Thread Size	Pound- Feet	Newton metres
5/8 inch 15.9 mm	7/8-14	58 to 92	79 to 124
3/4 inch 19.0 mm	1-1/16-12	80 to 128	108 to 174
7/8 inch 22.2 mm	1-3/16-12	100 to 160	136 to 216
1.0 inch 25.4 mm	1-5/16-12	117 to 187	159 to 253
1-1/4 inch 31.8 mm	1-5/8-12	165 to 264	224 to 357
1-1/2 inch 38.1 mm	1-7/8-12	250 to 400	339 to 542

Split Flange Mounting Bolts		
Size	Pound- Inches	Newton metres
5/16-18	180 to 240	20 to 27
3/8-16	240 to 300	27 to 34
7/16-14	420 to 540	47 to 61
Size	Pound- Feet	Newton metres
1/2-13	55 to 65	74 to 88
5/8-11	140 to 150	190 to 203

TORQUE SPECIFICATIONS - STEEL HYDRAULIC FITTINGS

Nom. SAE Dash Size	Tube OD	Thread Size	Pound- Inches	Newton metres	Thread Size	Pound- Inches	Newton metres
O-ring Face Seal End					O-ring Boss End Fitting or Lock Nut		
-4	1/4 inch 6.4 mm	9/16-18	120 to 144	14 to 16	7/16-20	204 to 240	23 to 27
-6	3/8 inch 9.5 mm	11/16-16	216 to 240	24 to 27	9/16-18	300 to 360	34 to 41
-8	1/2 inch 12.7 mm	13/16-16	384 to 480	43 to 54	3/4-16	540 to 600	61 to 68
					Thread Size	Pound- Feet	Newton metres
-10	5/8 inch 15.9 mm	1-14	552 to 672	62 to 76	7/8-14	60 to 65	81 to 88
Nom. SAE Dash Size	Tube OD	Thread Size	Pound- Feet	Newton metres	1-1/16-12	85 to 90	115 to 122
					1-3/16-12	95 to 100	129 to 136
-12	3/4 inch 19.0 mm	1-3/16-12	65 to 80	90 to 110	1-5/16-12	115 to 125	156 to 169
-14	7/8 inch 22.2 mm	1-3/16-12	65 to 80	90 to 110	1-5/8-12	150 to 160	203 to 217
-16	1.0 inch 25.4 mm	1-7/16-12	92 to 105	125 to 140	1-7/8-12	190 to 200	258 to 271
-20	1-1/4 inch 31.8 mm	1-11/16-12	125 to 140	170 to 190			
-24	1-1/2 inch 38.1 mm	2-12	150 to 180	200 to 254			

Section 00

Chapter 2

SAFETY, GENERAL INFORMATION, MAINTENANCE SCHEDULE

TABLE OF CONTENTS

SAFETY	00-2-3
GENERAL INFORMATION	00-2-5
LUBRICATION/MAINTENANCE CHART	00-2-6
SYSTEM CAPACITIES	00-2-7

SAFETY



THIS SAFETY ALERT SYMBOL INDICATES IMPORTANT SAFETY MESSAGES IN THIS MANUAL. WHEN YOU SEE THIS SYMBOL, CAREFULLY READ THE MESSAGE THAT FOLLOWS AND BE ALERT TO THE POSSIBILITY OF PERSONAL INJURY OR DEATH.

M171B

To prevent injury always follow the Warning, Caution and Danger notes in this section and throughout the manual.

Put the warning tag shown below on the key for the key switch when servicing or repairing the machine. One warning tag is supplied with each machine. Additional tags are available from your service parts supplier.

Before servicing a machine, park the machine on hard level ground. Turn off the engine, apply the parking brake and remove the key from the key switch. Put blocks in front of and behind either the front or rear wheels.

DO NOT
OPERATE

Reason _____

Signed by _____

DO NOT REMOVE
THIS TAG!

See Other Side

Case Part No _____ Printed in U.S.A.

201L95



WARNING: Read the operator's manual to familiarize yourself with the correct control functions.

M489



WARNING: Operate the machine and equipment controls from the seat position only. Any other method could result in serious injury.

M490



WARNING: This machine is for one operator, no riders allowed.

M491A



WARNING: Before starting engine study Operator's Manual safety messages. Read all safety signs on machine. Clear the area of other persons. Learn and practice safe use of controls before operating. It is your responsibility to understand and follow manufacturers instructions on machine operation, service, and to observe pertinent laws and regulations. Operator and Repair Manuals may be obtained from your equipment dealer.

M103A



WARNING: If you wear clothing that is too loose or do not use the correct safety equipment for your job, you can be injured. Always wear clothing that will not catch on objects. Extra safety equipment that can be required includes hard hat, safety shoes, ear protection, eye or face protection, heavy gloves and reflective clothing.

M492



WARNING: When working in the area of the fan belt with the engine running, avoid loose clothing if possible, and use extreme caution.

M493



WARNING: When doing checks and tests on the equipment hydraulics, follow the procedures as they are written. DO NOT change the procedure.

M494



WARNING: When putting the hydraulic cylinders on this machine through the necessary cycles to check operation or to remove air from a circuit, make sure all people are out of the way.

M495



WARNING: Always wear heat protective gloves to prevent burning your hands when handling heated parts.

SM121A



WARNING: Lower all attachments to the ground or use stands to safely support the attachments before you do any maintenance or service.

M496



WARNING: Hydraulic oil or diesel fuel leaking under pressure can penetrate the skin and cause infection or other injury.

To Prevent Personal Injury:

Relieve all pressure, before disconnecting fluid lines. Before applying pressure, make sure all connections are tight and components are in good condition.

Never use your hand to check for suspected leaks under pressure.

Use a piece of cardboard or wood for this purpose. If injured by leaking fluid, see your doctor immediately.

SM171A



WARNING: When removing hardened pins such as a pivot pin, or a hardened shaft, use a soft head (brass or bronze) hammer or use a driver made from brass or bronze and a steel head hammer.

M497



WARNING: When using a hammer to remove and install pivot pins or separate parts using compressed air or using a grinder, wear eye protection that completely encloses the eyes (approved goggles or other approved eye protectors).

M498



WARNING: Use suitable floor (service) jacks or chain hoist to raise wheels or tracks off the floor. Always block machine in placed with suitable safety stands.

M499



WARNING: When servicing or repairing the machine. Keep the shop floor and operator's compartment and steps free of oil, water, grease, tools, etc. Use an oil absorbing material and or shop cloths as required. Use safe practices at all times.

M500



WARNING: Some components of this machine are very heavy. Use suitable lifting equipment or additional help as instructed in the Repair Manual.

M501



WARNING: Engine exhaust fumes can cause death. If it is necessary to start the engine in a closed place, remove the exhaust fumes from the area with an exhaust pipe extension. Open the door and get outside air into the area.

M502



WARNING: When the battery electrolyte is frozen, the battery can explode if (1), you try to charge the battery, or (2), you try to jump start and run the engine. To prevent the battery electrolyte from freezing, try to keep the battery at full charge. If you do not follow these instructions, you or others in the area can be injured.

M503



WARNING: Batteries contain acid and explosive gas. Explosions can result from sparks, flames or wrong cable connections. To connect the jumper cables correctly to the battery of this machine see the Operator's Manual. Failure to follow these instructions can cause serious injury or death.

M504

GENERAL INFORMATION

Cleaning

Clean all metal parts except bearings, in mineral spirits or by steam cleaning. Do not use caustic soda for steam cleaning. After cleaning, dry and put oil on all parts. Clean oil passages with compressed air.

Inspection

Check all parts when the parts are disassembled. Replace all parts that have excessive wear or are damaged. Small scoring or grooves can be removed with a hone or crocus cloth. Complete visual inspection for indications of wear, pitting and the replacement of parts necessary will prevent early failures.

Bearings

Clean bearings with a good clean solvent and permit to air dry. **DO NOT DRY BEARINGS WITH COMPRESSED AIR.** Check bearings for smooth easy action. If the bearing has a loose fit or rough action, the bearing must be replaced.

Needle Bearings

Before you press needle bearings into a bore, always remove any metal protrusions in the bore or the edge of the bore. Before you press bearings into position, put petroleum jelly on the inside and outside diameter of the bearing.

Gears

Check all gears for excessive wear or damage. Replace gears as necessary.

Oil Seals, O-rings and Gaskets

Always install new oil seals, O-rings and gaskets. Put petroleum jelly on seals and O-rings.

Shafts

Check all shafts for excessive wear or damage. Check the bearing and oil seal surfaces on the shafts for excessive wear or damage. Replace shafts as necessary.

Service Parts

Always install genuine New Holland service parts. When ordering refer to the Parts Catalog for the correct part number of the genuine New Holland replacement items. Failures due to the use of other than genuine New Holland replacement parts are not covered by warranty.

Lubrication

Use only the oils and lubrication specified in the Operator's or Repair Manual. Failures due to the use of non specified oils and lubricants are not covered by warranty.

LUBRICATION/MAINTENANCE CHART

Service Interval	Maintenance Requirement	Check	Grease	Change	Clean	Drain
When Warning Message Displays	Air Cleaner Element				X	
Every 10 Hours Or Daily	Engine Oil Level	X				
	Transmission Oil Level	X				
	Coolant Reservoir Level	X				
Every 50 Hours	Engine Primary Fuel Filter - Drain Water					X
	Engine Coolant Level – Deaeration Tank	X				
	SuperSteer Axle Linkage Pins		X			
Every 100 Hours	Front Hitch (If Equipped)		X			
Every 300 Hours	Battery Water Level (Note E)	X				
	Engine Air Intake Hoses	X				
	*Engine Oil And Filter			X		
	Front And Rear Wheel Bolt Torques	X				
	Front Weight And Rear Wheel Weight Bolt Torques	X				
	Front Axle And Rear Hitch (Note A)		X			
	Fuel Tank - Drain Water					X
	Differential And Planetary Oil Level (Note B)	X				
	Transmission Oil Pressure	X				
	Reversible 1000 RPM PTO Shaft (Note D)		X			
Every 600 Hours	Engine Coolant Antifreeze Protection	X				
	Engine Coolant Filter			X		
	Engine Coolant Hoses And Clamps	X				
	Engine Fuel Filters			X		
	Changeable PTO Internal Splines		X			
Every 1200 Hours Or Annually	Differential and Planetary Oil			X		
	Engine Primary And Secondary Air Filter			X		
	Engine Air Precleaner				X	
Every 1500 Hours	Transmission Oil, Filter(s) and Breather			X		
Every 2100 Hours	Engine Fuel Injection Nozzles (Note C)	X				
	Engine Coolant And Coolant Conditioner			X		
	Engine Valve Adjustment (Note C)	X				
Every 3000 Hours	Engine Crankshaft Dampener (Note C)	X				
As Required	Cab Air And Recirculation Filters			X	X	
	Cab Air Filter Dust Valve	X				
	Engine Primary Air Filter				X	
	Grill Screens, Radiator, Condenser/Fuel Cooler, Oil Cooler, Air to Air Cooler				X	
	Fan Belt Replacement			X		
	Tire Pressure	X				
	Coupler Spillage Collection Bottle				X	

* Engine oil change interval may be affected by the sulfur content of the fuel. See Engine Oil Change in this manual.

Note A - In severe or wet conditions, interval is every 10 hours or daily.

Note B - Perform initial service in first 50 hours of operation.

Note C - Dealer must perform this service.

Note D - Every 300 PTO hours or twice a year.

Note E - If operated in ambient temperatures of 90° F (32° C) or greater, the battery fluid should be checked every 100 hours or once a week, whichever comes first.

SYSTEM CAPACITIES

SYSTEM	U.S. MEASURE	METRIC MEASURE	IMPERIAL MEASURE
Engine Oil No Filter Change With Filter Change	5 Gal 5-1/2 Gal	19 L 21L	4.2 Gal 4.5 Gal
Cooling System All	7 Gal	26.5 L	5.8 Gal
Trans / Hydraulic System	45-1/2 Gal	172 L	38 Gal
Front Wheel Drive			
^A 10 Bolt Axle			
Differential – Standard and Suspended FWD	13.0 Qts ^B	12.3 L	21.6 Pints
Differential – SuperSteer FWD	14.0 Qts ^C	13.25 L	23.3 Pints
Planetary - Each	3 Pints	1.4 L	2.5 Pints
^A 12 Bolt Axle			
Differential – Standard and Suspended FWD	12.5 Qts ^D	11.8 L	20.8 Pints
Differential – SuperSteer FWD	14.0 Qts ^C	13.25 L	23.3 Pints
Planetary - Each	7.0 Pints	3.3 L	5.8 Pints
Fuel Tank All	178 Gal	674L	148 Gal
^A = Bolt quantity can be determined by observing the wheel ends. ^B = 25 pints New Holland Ambra Hypoide 140 Gear Oil, SAE 85W140, plus 1 pint New Holland Limited Slip Additive (B96606) for 13 quarts total. ^C = 27 pints New Holland Ambra Hypoide 140 Gear Oil, SAE 85W140, plus 1 pint New Holland Limited Slip Additive (B96606) for 14 quarts total. ^D = 24 pints New Holland Ambra Hypoide 140 Gear Oil, SAE 85W140, plus 1 pint New Holland Limited Slip Additive (B96606) for 12.5 quarts total.			

This Page Left Blank.

Section 10

Chapter 1

ENGINE REMOVAL AND INSTALLATION


TABLE OF CONTENTS

ENGINE REMOVAL	10-1-3
ENGINE INSTALLATION	10-1-10

ENGINE REMOVAL


NOTE: Make note of where any wire harness and hose tie straps are removed during disassembly so they can be properly installed during assembly.

STEP 1



Park the tractor on a hard, level surface. Put the transmission shift lever in PARK. Turn off the engine and remove the key. Place blocks in front of and behind the rear wheels.

STEP 2



Remove the battery cover. Disconnect the negative cable (-) then the positive cable (+).

STEP 3

Remove the hood. See Hood Removal Section in this Repair Manual.


STEP 4

Evacuate the A/C system. See A/C Service Section in this Repair Manual.

STEP 5


Remove the cooling module. See Cooling Module Section in this Repair Manual.

STEP 6




Remove the exhaust shield mounting hardware (1) and remove the shield (2).

STEP 7



Remove the air cleaner aspirator hose (1). Disconnect the exhaust pipe at the turbo. (2).


STEP 8



RD05N102

Properly support the muffler. Remove the mounting hardware and remove the muffler / exhaust elbow assembly.


STEP 11



RD05N105

Tag and remove the heater supply hose (1) and return hose (2).


STEP 9



RD05N103

Disconnect the turbo to charge-air cooler pipe (1) at the turbo (2) and remove.


STEP 12



RD05N106

Disconnect the A/C high pressure switch (1). Disconnect the A/C compressor clutch harness (2).


STEP 10



RD05N104

Remove the starter cables.


STEP 13



RD05N107


Remove and tag the alternator harness wires.

STEP 14




Remove the harness clamp (1). Remove the compressor clutch harness (2) from the clamp. Reinstall the mounting bolt. Remove the ground wire (3) and reinstall the mounting bolt.

STEP 15




Remove the high (1) and low (2) pressure A/C line. Discard the O-rings. Cap all fittings.

STEP 16




Remove the air cleaner restriction switch harness.

STEP 17




Disconnect the coolant fill tube (1) at the deaeration tank hose (2) and the engine block (3). Remove the tube.

STEP 18




Loosen the air cleaner to turbo inlet hose clamp.

STEP 19




Disconnect the alternator wire harness connector. This connector is located on the left side near the hood support.

STEP 20





Remove the four air cleaner housing mounting nuts (1). Remove the air cleaner assembly. Remove the alternator wire harness (2) with the air cleaner assembly.

STEP 21




Remove the deaeration tank to recovery bottle hose (1) and engine to deaeration tank air bleed hose (2).

STEP 22




Remove the charge-air cooler to intake manifold tube bushing bolt (1). Remove the charge-air cooler to intake manifold pipe clamp (2). Remove the pipe. Discard the O-ring located at the intake manifold.

STEP 23




Disconnect the suspended axle position pot harness (1) if equipped. Remove the engine ECM (Electronic Control Module) power connector (2) and the throttle position connector (3).

STEP 24




Remove the engine heater grid power cable.

STEP 27




Properly support the hood / deaeration tank mounting assembly.

STEP 25




Remove the washer bottle from its mounting bracket. Tag and remove the front washer hose and electrical connector (1). Repeat for the rear (2) if required.

STEP 28




Remove right rear support bracket bolt.

STEP 26




Tag and remove the right (1) and left (2) brake switch connectors.

STEP 29




If installed, remove the windshield step mounting bolts (1) and remove the step (2).

STEP 30




Remove the fuel supply hose.

STEP 33




Disconnect the high (1) and low (2) pressure A/C lines.

STEP 31




Remove the two support mounting bolts.

STEP 34




Remove the hydraulic oil cooling lines.

STEP 32




Raise the assembly slightly to gain access to the main engine connector (1) and disconnect. Continue to raise and remove from the engine.

STEP 35




Remove the two right rear tube / hose / air cleaner bracket assembly mounting bolts.

STEP 36




Remove the A / C tube exhaust shield.

STEP 37




Remove the right front mounting bolts.

STEP 38





Remove the left front mounting bolts (1) and spacer (2).

STEP 39



Properly support the hose / tube / air cleaner support bracket assembly and remove from the engine.


STEP 40




Properly support the engine. Place a small amount of tension on the hoist. Remove the six engine mounting bolts. Move the engine forward to disengage from the transmission. Remove the engine from the front frame.

ENGINE INSTALLATION

STEP 41




RD05N135



RI02C011

Apply a thin coat of anti seize lubricant to the transmission input shaft splines. Properly support the engine and lift into place. Align the splines on the shaft with the engine flywheel dampener and slide into place. Install the mounting bolts. Tighten the two M20 bolts (1) to a torque of 430 to 485 Nm (315 to 355 lb. ft.) Tighten the four M16 bolts (2) to a torque of 221 to 250 Nm (160 to 180 lb. ft.).


STEP 42



RD05N133

Set the hose / tube / air cleaner support bracket assembly in place on top of the engine.

STEP 43




RD05N132

Set the spacer (1) into place and install the mounting bolts (2).


NOTE: *DO NOT* tighten the bracket mounting hardware at this time.

STEP 44




Install the right front mounting bolts.

STEP 45




Install the right rear mounting bolts. Tighten ALL bracket mounting bolts at this time.

STEP 46




Install the heat shield (1). Install and tighten mounting bolts (2).

STEP 47




Install new O-rings on the fittings and tighten the hydraulic cooling lines.

STEP 48




Install new O-rings on the fittings and tighten the A / C lines.

STEP 49



Properly support the hood / deaeration tank mounting assembly and set into place at the rear of the engine.


STEP 50



RD05N126

Connect the engine wire harness connector.


STEP 53



RD05N123

If removed, install the windshield step (1) and tighten the bolts (2).


STEP 51



RD05N125

Install the support mounting bolts and tighten to a torque of 310 to 380 Nm (230 to 280 lb. ft.).


STEP 54



RD05N122

Install and tighten the right rear support bolt.


STEP 52



RD05N124

Install the fuel supply hose.


STEP 55



RD05N120

Install the right (1) and left (2) brake switch connectors.


STEP 56



RD05N119

Install the front washer hose and electrical connector (1) and rear (2) if equipped. Install the bottle onto the bracket (3).


STEP 59



RD05N134

Install a new O-ring on the charge-air cooler to intake manifold tube assembly. Install the tube.


STEP 57



RD05N118


Install the engine grid heater power cable.

STEP 60




RD05N114

STEP 58



RD05N116

Install the throttle position connector (1) and the ECM power connector (2). If equipped, connect the suspended axle position pot connector (3).



RD05N115

Install the bushing bolt (1). Install the clamp (2). Tighten all hardware.

This as a preview PDF file from **best-manuals.com**



Download full PDF manual at **best-manuals.com**