





Service Manual

425, 428 Compact Excavator

425 S/N AACJ11001 & Above
425 S/N A9K311001 & Above
428 S/N A9K411001 & Above



MAINTENANCE SAFETY



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0807



Safety Alert Symbol: This symbol with a warning statement, means: "Warning, be alert! Your safety is involved!" Carefully read the message that follows.


CORRECT



P-90216

- ⚠ Never service the Bobcat Excavator without instructions.


CORRECT



B-19964

- ⚠ Use the correct procedure to lift and support the excavator.


CORRECT



B-19959

- ⚠ Cleaning and maintenance are required daily.

WRONG



B-19965

- ⚠ Have good ventilation when welding or grinding painted parts.
- ⚠ Wear dust mask when grinding painted parts. Toxic dust and gas can be produced.


WRONG



B-19960

- ⚠ Vent exhaust to outside when engine must be run for service.
- ⚠ Exhaust system must be tightly sealed. Exhaust fumes can kill without warning.


WRONG



B-19966

- ⚠ Always lower the bucket and blade to the ground before doing any maintenance.
- ⚠ Never modify equipment or add attachments not approved by Bobcat Company.


WRONG



B-19962

- ⚠ Stop, cool and clean engine of flammable materials before checking fluids.
- ⚠ Never service or adjust machine with the engine running unless instructed to do so in the manual.
- ⚠ Avoid contact with leaking hydraulic fluid or diesel fuel under pressure. It can penetrate the skin or eyes.
- ⚠ Never fill fuel tank with engine running, while smoking, or when near open flame.

WRONG



B-19958

- ⚠ Keep body, jewelry and clothing away from moving parts, electrical contact, hot parts and exhaust.
- ⚠ Wear eye protection to guard from battery acid, compressed springs, fluids under pressure and flying debris when engines are running or tools are used. Use eye protections approved for type of welding.
- ⚠ Keep tailgate closed except for service. Close and latch tailgate before operating the excavator.

WRONG



B-19798

- ⚠ Lead-acid batteries produce flammable and explosive gases.
- ⚠ Keep arcs, sparks, flames and lighted tobacco away from batteries.
- ⚠ Batteries contain acid which burns eyes or skin on contact.
- ⚠ Wear protective clothing. If acid contacts body, flush well with water. For eye contact flush well and get immediate medical attention.

Maintenance procedures which are given in the Operation & Maintenance Manual can be performed by the owner/operator without any specific technical training. Maintenance procedures which are **not** in the Operation & Maintenance Manual must be performed **ONLY BY QUALIFIED BOBCAT SERVICE PERSONNEL**. Always use genuine Bobcat replacement parts. The Service Safety Training Course is available from your Bobcat dealer.

MSW28-0409



Bobcat®

ALPHABETICAL INDEX

| | | | |
|--|--------------|--|--------------|
| AIR CLEANER | 60-01 | HEATER COIL | 70-01 |
| AIR CLEANER SERVICE | 10-01 | HEATER SYSTEM..... | 70-01 |
| ALTERNATOR | 50-01 | HEATER UNIT..... | 70-01 |
| ALTERNATOR BELT..... | 10-01 | HEATER VALVE | 70-01 |
| ARM | 40-01 | HORN | 40-01 |
| ARM CYLINDER | 20-01 | HYDRAULIC CONTROL VALVE | 20-01 |
| | | HYDRAULIC CONNECTION SPECS | SPEC-01 |
| BATTERY..... | 50-01 | HYDRAULIC FLUID SPECIFICATIONS..... | SPEC-01 |
| BLADE | 30-01 | HYDRAULIC FILTER..... | 20-01 |
| BLADE CONTROL..... | 40-01 | HYDRAULIC PUMP | 20-01 |
| BLADE CYLINDER | 20-01 | HYDRAULIC RESERVOIR..... | 20-01 |
| BLOWER FAN | 70-01 | HYDRAULIC SYSTEM | 10-01 |
| BOOM | 40-01 | HYDRAULIC SYSTEM INFORMATION | 20-01 |
| BOOM CYLINDER..... | 20-01 | HYDRAULIC X-CHANGE VALVE | 20-01 |
| BOOM SWING CYLINDER..... | 20-01 | | |
| BOOM SWING PEDAL | 40-01 | LEFT CONTROL LEVER (JOYSTICK) | 20-01 |
| BUCKET | 40-01 | LEFT CONSOLE | 40-01 |
| BUCKET CYLINDER | 20-01 | LEFT SIDE COVER..... | 40-01 |
| | | LIFTING AND BLOCKING THE EXCAVATOR | 10-01 |
| CAB..... | 40-01 | LIFTING THE EXCAVATOR | 10-01 |
| CAMSHAFT AND TIMING GEARS..... | 60-01 | LIGHTS..... | 50-01 |
| CANOPY | 40-01 | LUBRICATION SYSTEM | 60-01 |
| CASE DRAIN FILTER | 20-01 | LUBRICATING THE EXCAVATOR | 10-01 |
| CLAMP..... | 40-01 | | |
| CLAMP CYLINDER | 20-01 | MAGNETIC LOCKOUT SENSOR | 50-01 |
| CONVERSIONS | SPEC-01 | MAIN RELIEF VALVE | 20-01 |
| CONTROL PATTERN SELECTOR VALVE | 20-01 | MANIFOLD ASSEMBLY / ACCUMULATOR | 20-01 |
| COUNTERWEIGHT | 40-01 | MOTION ALARM SYSTEM (IF EQUIPPED) | 20-01 |
| CRANKSHAFT AND PISTONS | 60-01 | | |
| CROSSPORT RELIEF VALVES | 20-01 | NON-PRESSURIZED ACCUMULATOR | 20-01 |
| CYLINDER HEAD..... | 60-01 | | |
| | | OIL COOLER..... | 20-01 |
| DIAGNOSTICS SERVICE CODES..... | 50-01 | OPERATOR CAB (ROPS/TOPS) | 10-01 |
| DIRECT TO TANK VALVE | 20-01 | | |
| | | PIVOT PINS | 10-01 |
| ELECTRICAL SYSTEM INFORMATION | 50-01 | PORT RELIEF VALVES..... | 20-01 |
| ENGINE COOLING SYSTEM | 10-01, 60-01 | PRESSURE REDUCING VALVE..... | 20-01 |
| ENGINE INFORMATION | 60-01 | | |
| ENGINE LUBRICATION SYSTEM..... | 10-01 | REGULAR MAINTENANCE | 70-01 |
| ENGINE SPEED CONTROL | 60-01 | RIGHT CONTROL LEVER (JOYSTICK) | 20-01 |
| EXCAVATOR SPECIFICATIONS | SPEC-01 | RIGHT CONSOLE | 40-01 |
| EXCAVATOR STORAGE AND RETURN TO SERVICE | 10-01 | RIGHT SIDE COVER | 10-01, 40-01 |
| | | | |
| FLOOR MAT AND FLOOR PANELS | 40-01 | | |
| FLYWHEEL AND HOUSING..... | 60-01 | | |
| FUEL LEVEL SENDER..... | 50-01 | | |
| FUEL SYSTEM | 10-01, 60-01 | | |
| FUEL TANK..... | 40-01 | | |

Continued On Next Page

ALPHABETICAL INDEX (CONT'D)

| | |
|--|--------------|
| SEAT AND SEAT MOUNT | 40-01 |
| SEAT BELT | 10-01 |
| SERVICE SCHEDULE | 10-01 |
| SLEW LOCK VALVE | 20-01 |
| SPARK ARRESTOR MUFFLER | 10-01, 60-01 |
| STARTER | 50-01 |
| STOPPING THE ENGINE AND LEAVING THE EXCAVATOR | 10-01 |
| SWING CIRCLE GEAR | 30-01 |
| SWING FRAME | 40-01 |
| SWING MOTOR | 20-01 |
| SWING MOTOR DRIVE CARRIER | 20-01 |
| SWIVEL JOINT | 20-01 |
| TAILGATE | 10-01, 40-01 |
| TORQUE SPECIFICATIONS FOR BOLTS | SPEC-01 |
| TRACK FRAME COMPONENTS | 30-01 |
| TRANSPORTING THE EXCAVATOR ON A TRAILER | 10-01 |
| TRAVEL LEVER / PEDALS | 40-01 |
| TRAVEL MOTOR | 10-01, 20-01 |
| TROUBLESHOOTING | 70-01 |
| UPPERSTRUCTURE | 40-01 |
| UPPERSTRUCTURE SLEW LOCK | 10-01, 40-01 |
| X-CHANGE | 40-01 |
| X-CHANGE (HYDRAULIC) | 40-01 |

CONTENTS

| | |
|--------------------------------------|---------|
| FOREWORD..... | II |
| SAFETY INSTRUCTIONS | IV |
| FIRE PREVENTION | VI |
| SERIAL NUMBER LOCATIONS | VIII |
| DELIVERY REPORT..... | IX |
| EXCAVATOR IDENTIFICATION | X |
| SAFETY AND MAINTENANCE..... | 10-01 |
| HYDRAULIC SYSTEM | 20-01 |
| UNDERCARRIAGE..... | 30-01 |
| UPPERSTRUCTURE & SWING SECTION | 40-01 |
| ELECTRICAL SYSTEM AND ANALYSIS | 50-01 |
| ENGINE SERVICE | 60-01 |
| HEATER | 70-01 |
| SPECIFICATIONS..... | SPEC-01 |

**SAFETY AND
MAINTENANCE**

**HYDRAULIC
SYSTEM**

UNDERCARRIAGE

**UPPERSTRUCTURE
& SWING
SECTION**

**ELECTRICAL
SYSTEM AND
ANALYSIS**

**ENGINE
SERVICE**

HEATER


SPECIFICATIONS

FOREWORD


This manual is for the Bobcat excavator mechanic. It provides necessary servicing and adjustment procedures for the Bobcat excavator and its component parts and systems. Refer to the Operation & Maintenance Manual for operating instructions, starting procedure, daily checks, etc.

A general inspection of the following items must be made after the excavator has had service or repair:

1. Check that the ROPS/TOPS/FOPS is in good condition and is not modified.




9. Safety treads must be in good condition.




2. Check that ROPS/TOPS mounting hardware is tightened and is Bobcat approved.




10. Check for correct function of indicator lamps.



3. The seat belt must be correctly installed, functional and in good condition.




11. Check hydraulic fluid level, engine oil level and fuel supply.




4. Machine signs (decals) must be legible and in the correct location.




12. Inspect for fuel, oil or hydraulic fluid leaks.



5. Travel levers, control levers and foot pedals must return to neutral. Check that the pedal locks are in working order.




13. Lubricate the excavator.




6. Check for correct function of the work lights.




14. Check the condition of the battery and cables.




7. Enclosure door latches must open and close freely.




15. Inspect the air cleaner for damage or leaks. Check the condition of the element.



8. Attachment locking pins must function correctly and be in good condition.




16. Check the electrical charging system.



FW EXC-0509 SM

17. Check tracks for wear and tension. Use only approved tracks.




18. Inspect for loose or broken parts or connections.



19. Check for any field modification not completed.




20. Operate the machine and check all functions.



21. Check the control console interlocks for correct function.




22. Inspect the X-Change™ for wear or damage. Repair or replace damaged parts.



23. Check function or condition of all equipped options and accessories (examples: special applications kit, motion alarm, etc.).



24. Recommend to the owner that all necessary corrections be made before the machine is returned to service.



**CALIFORNIA
PROPOSITION 65 WARNING**

Diesel engine exhaust and some of its constituents are known to the state of California to cause cancer, birth defects and other reproductive harm.

SAFETY INSTRUCTIONS



Safety Alert Symbol

This symbol with a warning statement means:
“Warning, be alert! Your safety is involved!”
Carefully read the message that follows.



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903

IMPORTANT

This notice identifies procedures which must be followed to avoid damage to the machine.

I-2019-0284



DANGER

The signal word DANGER on the machine and in the manuals indicates a hazardous situation which, if not avoided, will result in death or serious injury.

D-1002-1107



WARNING

The signal word WARNING on the machine and in the manuals indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.

W-2044-1107

The following publications provide information on the safe use and maintenance of the Bobcat machine and attachments:

- The Delivery Report is used to assure that complete instructions have been given to the new owner and that the machine is in safe operating condition.
- The Operation & Maintenance Manual delivered with the machine or attachment contains operating information as well as routine maintenance and service procedures. It is a part of the machine and can be stored in a container provided on the machine. Replacement Operation & Maintenance Manuals can be ordered from your Bobcat dealer.
- Machine signs (decals) instruct on the safe operation and care of your Bobcat machine or attachment. The signs and their locations are shown in the Operation & Maintenance Manual. Replacement signs are available from your Bobcat dealer.
- An Operator's Handbook fastened to the operator cab. It's brief instructions are convenient to the operator. The handbook is available from your dealer in an English edition or one of many other languages. See your Bobcat dealer for more information on translated versions.
- The AEM Safety Manual delivered with the machine gives general safety information.
- The Service Manual and Parts Manual are available from your dealer for use by mechanics to do shop-type service and repair work.
- The Compact Excavator Operator Training Course is available through your local dealer or at www.training.bobcat.com or www.bobcat.com. This course is intended to provide rules and practices of correct operation of the Bobcat excavator. The course is available in English and Spanish versions.
- Service Safety Training Courses are available from your Bobcat dealer or at www.training.bobcat.com or www.bobcat.com. They provide information for safe and correct service procedures.
- The Bobcat compact excavator Safety Video is available from your Bobcat dealer or at www.training.bobcat.com or www.bobcat.com.

SI EXC-0308 SM

SAFETY INSTRUCTIONS (CONT'D)

The dealer and owner / operator review the recommended uses of the product when delivered. If the owner / operator will be using the machine for a different application(s) he or she must ask the dealer for recommendations on the new use.



Cutting or drilling concrete containing sand or rock containing quartz may result in exposure to silica dust. Do not exceed Permissible Exposure Limits (PEL) to silica dust as determined by OSHA or other job site Rules and Regulations. Use a respirator, water spray or other means to control dust. Silica dust can cause lung disease and is known to the state of California to cause cancer.

Call Before You Dig
Dial 811 (USA Only)
1-888-258-0808 (USA & Canada)

When you call, you will be directed to a location in your state / province, or city for information about buried lines (telephone, cable TV, water, sewer, gas, etc.).

FIRE PREVENTION



Maintenance

The machine and some attachments have components that are at high temperatures under normal operating conditions. The primary source of high temperatures is the engine and exhaust system. The electrical system, if damaged or incorrectly maintained, can be a source of arcs or sparks.

Flammable debris (leaves, straw, etc.) must be removed regularly. If flammable debris is allowed to accumulate, it can cause a fire hazard. Clean often to avoid this accumulation. Flammable debris in the engine compartment is a potential fire hazard.

The operator's area, engine compartment and engine cooling system must be inspected every day and cleaned if necessary to prevent fire hazards and overheating.

All fuels, most lubricants and some coolants mixtures are flammable. Flammable fluids that are leaking or spilled onto hot surfaces or onto electrical components can cause a fire.

Operation

Do not use the machine where exhaust, arcs, sparks or hot components can contact flammable material, explosive dust or gases.

Electrical



Check all electrical wiring and connections for damage. Keep the battery terminals clean and tight. Repair or replace any damaged part or wires that are loose or frayed.

Battery gas can explode and cause serious injury. Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting. Do not jump start or charge a frozen or damaged battery. Keep any open flames or sparks away from batteries. Do not smoke in battery charging area.

Hydraulic System

Check hydraulic tubes, hoses and fittings for damage and leakage. Never use open flame or bare skin to check for leaks. Hydraulic tubes and hoses must be properly routed and have adequate support and secure clamps. Tighten or replace any parts that show leakage.

Always clean fluid spills. Do not use gasoline or diesel fuel for cleaning parts. Use commercial nonflammable solvents.

Fueling



Stop the engine and let it cool before adding fuel. No smoking! Do not refuel a machine near open flames or sparks. Fill the fuel tank outdoors.

Starting

Do not use ether or starting fluids on any engine that has glow plugs. These starting aids can cause explosion and injure you or bystanders.

Use the procedure in the Operation & Maintenance Manual for connecting the battery and for jump starting.

Spark Arrestor Exhaust System

The spark arrestor exhaust system is designed to control the emission of hot particles from the engine and exhaust system, but the muffler and the exhaust gases are still hot.

Check the spark arrestor exhaust system regularly to make sure it is maintained and working properly. Use the procedure in the Operation & Maintenance Manual for cleaning the spark arrestor muffler (if equipped).

FIRE PREVENTION (CONT'D)


Welding And Grinding

Always clean the machine and attachment, disconnect the battery, and disconnect the wiring from the Bobcat controllers before welding. Cover rubber hoses, battery and all other flammable parts. Keep a fire extinguisher near the machine when welding.

Have good ventilation when grinding or welding painted parts. Wear dust mask when grinding painted parts. Toxic dust or gas can be produced.

Dust generated from repairing nonmetallic parts such as hoods, fenders or covers can be flammable or explosive. Repair such components in a well ventilated area away from open flames or sparks.

Fire Extinguishers




Know where fire extinguishers and first aid kits are located and how to use them. Inspect the fire extinguisher and service the fire extinguisher regularly. Obey the recommendations on the instructions plate.

SERIAL NUMBER LOCATIONS

Always use the serial number of the excavator when requesting service information or when ordering parts. Early or later models (identification made by serial number) may use different parts, or it may be necessary to use a different procedure in doing a specific service operation.

Excavator Serial Number

Figure 1



The excavator serial number plate (Item 1) is located on the frame of the machine in the location shown **[Figure 1]**.

Explanation of Excavator Serial Number:

XXXX XXXXX


Module 2. - Production

Module 1. - Model / Engine Combination

1. The four digit Model/Engine Combination Module number identifies the model number and engine combination.
2. The five digit Production Sequence Number identifies the order which the excavator is produced.

Engine Serial Number

Figure 2



The engine serial number (Item 1) is located on the engine in the location shown **[Figure 2]**.

Figure 3



The diagram illustrates a document layout for a delivery report. The document is organized into several distinct sections:

- DELIVERY REPORT:** Located in the top right corner, this section includes a header and several lines of text.
- WARNING:** Positioned below the 'DELIVERY REPORT' section on the left, it features a bold header and multiple lines of text.
- Main Text Area:** To the right of the 'WARNING' section, there is a large area containing multiple lines of text.
- Bottom Section:** At the bottom left, there is another section with multiple lines of text.

The entire document is enclosed within a rectangular border, and the layout is designed to be clear and organized.

The delivery report must be filled out by the dealer and signed by the owner or operator when the Bobcat Excavator is delivered. An explanation of the form must be given to the owner. Make sure it is filled out completely **[Figure 3]**.

EXCAVATOR IDENTIFICATION



B-23467
B-23469

† BUCKET - Several different buckets and other attachments are available from the Bobcat Excavator.

● ROPS, TOPS - (Roll Over Protective Structure / Tip Over Protective Structure) as standard equipment. The ROPS/TOPS meets SAE J1040, ISO 3471 and ISO 12117.

| | |
|--|----------|
| AIR CLEANER SERVICE | 10-60-1 |
| Daily Check | 10-60-1 |
| Replacing Filter Elements | 10-60-2 |
| ALTERNATOR BELT | 10-140-1 |
| Belt Adjustment | 10-140-1 |
| Belt Replacement | 10-140-1 |
| ENGINE COOLING SYSTEM | 10-70-1 |
| Checking Level | 10-70-2 |
| Cleaning | 10-70-1 |
| Removing And Replacing Coolant | 10-70-3 |
| ENGINE LUBRICATION SYSTEM | 10-90-1 |
| Checking And Adding Engine Oil | 10-90-1 |
| Engine Oil Chart | 10-90-1 |
| Removing And Replacing Oil Filter | 10-90-2 |
| EXCAVATOR STORAGE AND RETURN TO SERVICE | 10-170-1 |
| Storage | 10-170-1 |
| Return To Service | 10-170-1 |
| FUEL SYSTEM | 10-80-1 |
| Biodiesel Blend Fuel | 10-80-1 |
| Draining The Fuel Tank | 10-80-5 |
| Filling The Fuel Tank | 10-80-2 |
| Fuel Filters | 10-80-3 |
| Fuel Specifications | 10-80-1 |
| Removing Air From The Fuel System | 10-80-5 |
| HYDRAULIC SYSTEM | 10-100-1 |
| Checking And Adding Fluid | 10-100-1 |
| Hydraulic Fluid Chart | 10-100-1 |
| Removing And Replacing The Case Drain Filter | 10-100-2 |
| Removing And Replacing The Hydraulic Filter | 10-100-2 |
| Removing And Replacing The Hydraulic Fluid | 10-100-3 |
| LIFTING AND BLOCKING THE EXCAVATOR | 10-10-1 |
| Procedure | 10-10-1 |
| LIFTING THE EXCAVATOR | 10-12-1 |
| Procedure | 10-12-1 |
| LUBRICATING THE EXCAVATOR | 10-110-1 |
| Lubrication Locations | 10-110-1 |

Continued On Next Page

SAFETY AND MAINTENANCE (CONT'D)

| | |
|---|----------|
| OPERATOR CAB (ROPS / TOPS) | 10-20-1 |
| Cab Door | 10-20-1 |
| Description | 10-20-1 |
| Front Window | 10-20-2 |
| Front Wiper | 10-20-3 |
| Heating, Ventilation, and Air Conditioning Duct | 10-20-5 |
| Right Side Window | 10-20-4 |
| Window Washer Reservoir | 10-20-3 |
| PIVOT PINS | 10-160-1 |
| Inspection And Maintenance | 10-160-1 |
| RIGHT SIDE COVER | 10-41-1 |
| Opening And Closing | 10-41-1 |
| SEAT BELT | 10-150-1 |
| Inspection And Maintenance | 10-150-1 |
| SERVICE SCHEDULE | 10-50-1 |
| Chart | 10-50-1 |
| SPARK ARRESTOR MUFFLER | 10-130-1 |
| Cleaning Procedure | 10-130-1 |
| STOPPING THE ENGINE AND LEAVING THE EXCAVATOR .. | 10-180-1 |
| Emergency Exits | 10-180-2 |
| Procedure | 10-180-1 |
| TAILGATE | 10-40-1 |
| Opening And Closing | 10-40-1 |
| TRANSPORTING THE EXCAVATOR ON A TRAILER | 10-30-1 |
| Fastening | 10-30-1 |
| Loading And Unloading | 10-30-1 |
| TRAVEL MOTOR | 10-120-1 |
| Checking And Adding Oil | 10-120-1 |
| Removing And Replacing Oil | 10-120-1 |
| UPPERSTRUCTURE SLEW LOCK | 10-11-1 |
| Operation | 10-11-1 |

TIGHTEN ALL HARDWARE PER SIZE TO GRADE 5 TORQUE (SEE STANDARD TORQUE SPECIFICATIONS FOR BOLTS, SECTION SPEC-01) UNLESS OTHERWISE SPECIFIED.

SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE AND STANDARD ITEMS MAY VARY.

LIFTING AND BLOCKING THE EXCAVATOR

Procedure

Always park the machine on a level surface.

Figure 10-10-1



Raise one side of the machine (approximately 4 in.) using the boom and arm as shown in **[Figure 10-10-1]**.

Raise the blade fully and install jackstands under the blade and the track frame. Lower the boom until all machine weight is on the jackstands.

Stop the engine.

WARNING

Put jackstands under the blade and rear corners of the undercarriage before working under the machine. Failure to block up the machine may allow it to move or fall and result in injury or death.

W-2218-1195

WARNING

AVOID INJURY

Keep fingers and hands out of pinch points when checking the track tension.

W-2142-0903




WARNING



UPPERSTRUCTURE SLEW LOCK

Operation

Figure 10-11-1



Push down on the front (Item 1) [Figure 10-11-1] of the foot pedal to engage the upperstructure swing lock.

Push down on the rear (Item 2) [Figure 10-11-1] to disengage the upperstructure slew lock.

NOTE: Upperstructure must be in the straight forward or straight rearward position for upperstructure to lock.




Bobcat®

LIFTING THE EXCAVATOR

Procedure

Figure 10-12-1




Fully extend the cylinders of the bucket, arm, and boom so that the excavator is in the position as shown [Figure 10-12-1].

Raise the blade all the way.

Put all the control levers in neutral.

Figure 10-12-2



Fasten chains to the ends of the blade (Item 1) [Figure 10-12-1] and [Figure 10-12-2] and up to a lifting fixture above the canopy/cab. The lifting fixture must extend over the sides of the canopy/cab to prevent the chains from hitting the ROPS/TOPS.

Install a 1 in. (25 mm) bolt and nut (Grade 5 or 8) through the holes at the boom (Item 2) [Figure 10-12-1] and [Figure 10-12-2]. Fasten a chain from the bolt to the lift fixture.

WARNING

AVOID INJURY OR DEATH

- Use a lifting fixture with sufficient capacity for the weight of the excavator plus any added attachments.
- Maintain center of gravity and balance when lifting.
- Do not swing boom or upperstructure. Engage the upperstructure slew lock.
- Never lift with operator on machine.

W-2202-0607



Bobcat®

OPERATOR CAB (ROPS / TOPS)

Description

The excavator has an optional operator cab (ROPS/TOPS) (Roll Over Protective Structure/Tip Over Protective Structure). The ROPS/TOPS meets SAE J1040, ISO 3471 and ISO 12117.

An enclosed cab (ROPS/TOPS) is an Option or can be installed as a Field Accessory.

Both the cab and canopy provide operator protection if the excavator is tipped over. The seat belt must be worn for ROPS /TOPS protection.


WARNING

Never modify operator cab by welding, grinding, drilling holes or adding attachments unless instructed to do so by Bobcat Company. Changes to the cab can cause loss of operator protection from rollover and falling objects, and result in injury or death.

W-2069-0200

Cab Door


Figure 10-20-1



The cab door can be locked (Item 1) [Figure 10-20-1] with the same key as the starter switch.

Push the door all the way open (Item 2) [Figure 10-20-1] until the latch engages to hold the door in the open position.

Figure 10-20-2



When the door is in the open position, push down on the latch (Item 1) [Figure 10-20-2] and close the door.


From inside the cab, open the door using handle (Item 2) [Figure 10-20-2].

OPERATOR CAB (ROPS / TOPS) (CONT'D)

Front Window


Opening The Front Window

Figure 10-20-3



Retract the two top window latch pins (Item 1) [Figure 10-20-3].

Figure 10-20-4



Turn the two top latches (Item 1) [Figure 10-20-4] to the unlocked position.


Figure 10-20-5



Use both window grab handles to pull the top of the window in [Figure 10-20-5].

Continue moving the window in and up over the operator's head until the window is fully raised.

Figure 10-20-6



When the window is fully raised, the latch (Item 1) will close on the bracket. Turn the two top latches (Item 2) [Figure 10-20-6] to the locked position.

Closing The Front Window

Support the window while releasing both window latch pins and placing the pins in the unlocked position [Figure 10-20-6].

Support the window using the left grab handle and pull down on the latch (Item 1) [Figure 10-20-5] to release the window.

Use both window grab handles to pull the window down [Figure 10-20-5].

Rotate the top latches (Item 1) [Figure 10-20-4] to the locked position (Item 1) [Figure 10-20-3].

OPERATOR CAB (ROPS / TOPS) (CONT'D)

Front Wiper


Figure 10-20-7



The front window is equipped with a wiper (Item 1) [Figure 10-20-7] and washer.

Window Washer Reservoir

Figure 10-20-8




The window washer reservoir (Item 1) [Figure 10-20-8] is located under the right side cover.

OPERATOR CAB (ROPS / TOPS) (CONT'D)

Right Side Window


Opening The Right Rear Window

Figure 10-20-9



Pull forward on the latch / handle (Item 1) [Figure 10-20-9].

Figure 10-20-10




Pull the latch / handle (Item 1) [Figure 10-20-10] forward to open the window.

Closing The Right Rear Window

Push the handle back to close the window.


Opening The Right Front Window

Figure 10-20-11



Pull back on the latch / handle (Item 1) [Figure 10-20-11].

Figure 10-20-12



Pull the latch / handle (Item 1) [Figure 10-20-12] back to open the window.

Closing The Right Front Window

Push the handle forward to close the window.


OPERATOR CAB (ROPS / TOPS) (CONT'D)

Heating, Ventilation, and Air Conditioning Duct

NOTE: The air conditioner duct can be ordered and used on heater models.

There are two HVAC ducts that the operator can choose to install.

Figure 10-20-13



The small duct (Item 1) [Figure 10-20-13] is standard for heater use.


The large duct (Item 1) [Figure 10-20-14] is standard for models that have air conditioner available.

NOTE: This duct (Item 1) [Figure 10-20-14] can be removed for improved operator visibility.

Installation

Remove the screw and pull straight up to remove the duct (Item 1) [Figure 10-20-13].


Figure 10-20-14



Place the air conditioning duct (Item 1) on the housing and over the locking stud (Item 2) [Figure 10-20-14].

Reinstall the screw (Item 3) [Figure 10-20-14].

Figure 10-20-15



Fully seat the duct and rotate the lock (Item 1) [Figure 10-20-15].



Bobcat®

TRANSPORTING THE EXCAVATOR ON A TRAILER

Loading And Unloading

When transporting the machine, observe the rules, motor vehicle laws, and vehicle limit ordinances. Use a transport and towing vehicle of adequate length and capacity.

Secure the parking brakes and block the wheels of the transport vehicle.

Align the ramps with the center of the transport vehicle. Secure the ramps to the truck bed and be sure ramp angle does not exceed 15 degrees.

Use metal loading ramps with a slip resistant surface.

Use ramps that are the correct length and width and can support the weight of the machine.

The rear of the trailer must be blocked or supported when loading or unloading the excavator to prevent the front of the transport vehicle from raising.

Determine the direction of the track movement before moving the machine (blade forward).

Engage the slew lock.

Figure 10-30-1



Move the machine forward onto the transport vehicle [Figure 10-30-1].

Do not change direction of the machine while it is on the ramps.

Lower the boom, arm, bucket, and blade to the transport vehicle.

Stop the engine and remove the key (if equipped).

Put blocks at the front and rear of the tracks.

Fastening

Figure 10-30-2





Figure 10-30-3



Fasten chains to the front corners of the blade (Item 1) [Figure 10-30-2] and to the tie down loop at the rear of the track frame (Item 1) [Figure 10-30-3] to prevent it from moving when going up or down slopes or during sudden stops.

Use chain binders to tighten the chains and then safely tie the chain binder levers to prevent loosening.



WARNING

AVOID SERIOUS INJURY OR DEATH

Adequately designed ramps of sufficient strength are needed to support the weight of the machine when loading onto a transport vehicle. Wood ramps can break and cause personal injury.

W-2058-0807



Bobcat®

TAILGATE

Opening And Closing

WARNING

AVOID INJURY OR DEATH

Never service or adjust the machine when the engine is running unless instructed to do so in the manual.

W-2012-0497


WARNING

Keep the rear door closed when operating the machine. Failure to do so could seriously injure a bystander.

W-2020-1285

Opening


Figure 10-40-1



Pull outward on the latch (Item 1) [Figure 10-40-1] and lift the tailgate up.

NOTE: The tailgate can be locked using the start key.

Figure 10-40-2



Hold the tailgate up and pull outward on the latch (Item 1) [Figure 10-40-2]. Slowly lower the tailgate until the latch is locked and holds the tailgate open.

Closing

Lift up slightly on the tailgate and push inward on the latch (Item 1) [Figure 10-40-2]. Slowly lower the tailgate until the tailgate is fully closed.



Bobcat®

RIGHT SIDE COVER

Opening And Closing



WARNING


AVOID INJURY OR DEATH

Never service or adjust the machine when the engine is running unless instructed to do so in the manual.

W-2012-0497

Opening


Figure 10-41-1



Pull outward on the latch (Item 1) [Figure 10-41-1] and lift the side cover up.

NOTE: The side cover can be locked using the start key.

Figure 10-41-2



Hold the side cover up and pull outward on the latch (Item 1) [Figure 10-41-2]. Slowly lower the side cover until the latch is locked and holds the side cover open.

Closing

Lift up slightly on the side cover and push inward on the latch (Item 1) [Figure 10-41-2]. Slowly lower the side cover until the side cover is fully closed.



Bobcat®

SERVICE SCHEDULE

Chart

Maintenance work must be done at regular intervals. Failure to do so will result in excessive wear and early failures. The service schedule is a guide for correct maintenance of the Bobcat Excavator.



WARNING

Instructions are necessary before operating or servicing machine. Read and understand the Operation & Maintenance Manual, Operator's Handbook and signs (decals) on machine. Follow warnings and instructions in the manuals when making repairs, adjustments or servicing. Check for correct function after adjustments, repairs or service. Untrained operators and failure to follow instructions can cause injury or death.

W-2003-0903

| SERVICE SCHEDULE | | HOURS | | | | | |
|--|--|---------------|----|-----|-----|-----|--------|
| ITEM | SERVICE REQUIRED | 8-10 | 50 | 100 | 250 | 500 | ■ 1000 |
| Engine Coolant | Check coolant level. Add premixed coolant as needed. | | | | | | |
| Engine Oil | Check the engine oil level and add as needed. | | | | | | |
| Hydraulic Fluid, Hoses and Tubelines, Reservoir Breather Cap | Check the hydraulic fluid level and add as needed. Check for damage and leaks. Repair or replace as needed. | | | | | | |
| Engine Air Filter and Air System | Check condition indicator and empty dust cup as needed. Check air system for leaks. | | | | | | |
| Tracks | Check and adjust track tension as needed. | | | | | | |
| Indicators and Lights | Check for correct operation of all indicators and lights. | | | | | | |
| Operator Canopy/Cab | Check condition. Check mounting hardware. | | | | | | |
| Seat Belt | Check condition. Check mounting hardware. | | | | | | |
| Safety Signs and Safety Treads | Check for damaged signs (decals) and safety treads. Replace any signs or safety treads that are damaged or worn. | | | | | | |
| Pivot Points | Grease all machinery pivot points. | | | | | | |
| * Cab Heater Air Filter | Clean the filter as needed. | | | | | | |
| Console Lockout | Check console lockout for proper operation. | | | | | | |
| X-Change | Lubricate and inspect for damage or loose parts. | | | | | | |
| Swing Circle and Pinion | Grease two fittings. | | | | | | |
| Fuel Tank & Filter | Drain water and sediment from fuel tank and fuel filter. | | | | | | |
| Battery | Check battery, cables, connections and electrolyte level. Add distilled water as needed. | | | | | | |
| Spark Arrestor Muffler | Clean the spark chamber. | | | | | | |
| Fuel Filters | Replace fuel filter. | | ● | | | | |
| Travel Motor | Check the oil level in both travel motors. | | | | | | |
| Inline Fuel Filter | Replace inline fuel filter. | | | | | | |
| Engine Oil and Filter | Replace oil and filter. Use CD or better grade oil and Bobcat filter. | | ▼ | | | | |
| Alternator Belt | Check condition of belt and adjust as needed. | | | ^ | | | |
| Radiator, Oil Cooler | Clean debris from the radiator fins. | | | | | | |
| Primary Hydraulic Filter and reservoir breather | Replace the primary hydraulic filter and reservoir breather. | | | ^ | | | |
| Case Drain Filter | Replace the case drain filter. | | | ^ | | | |
| Alternator & Starter | Check the alternator and starter connections. | | | ^ | | | |
| Engine Valves | Check and adjust the engine valve clearance. | | | | | | |
| Hydraulic System | Replace the hydraulic fluid and filters. Clean the reservoir. | | | | | | |
| Travel Motor | Replace the lubricant in both travel motors. | | | ^ | | | |
| Coolant | Drain and flush the cooling system. Replace the coolant. | Every 2 years | | | | | |

* If Equipped

● Change after the first 50 hours, then as scheduled.

▼ First oil and filter change must occur at 50 hours; then as scheduled.

^ Check after the first 100 hours, then as scheduled.

■ Or every 12 months.



Bobcat®

This as a preview PDF file from **best-manuals.com**



Download full PDF manual at **best-manuals.com**