



NEW HOLLAND

TC35A TC35DA
TC40A TC40DA
TC45A TC45DA

**REPAIR
MANUAL**



NEW HOLLAND

SERVICE

TC35A, TC35DA, TC40A, TC40DA, TC45A, TC45DA REPAIR MANUAL COMPLETE CONTENTS

SECTION 00 - GENERAL INFORMATION	2
SECTION 10 - ENGINE	3
SECTION 18 - CLUTCH	10
SECTION 21 - TRANSMISSION	12
SECTION 23 - DRIVELINE	14
SECTION 25 - FWD FRONT AXLE	15
SECTION 27 - DIFFERENTIAL, REAR AXLE	18
SECTION 29 - HYDROSTATIC TRANSMISSION	19
SECTION 31 - POWER TAKE-OFF (PTO) SYSTEMS	22
SECTION 33 - BRAKES	25
SECTION 35 - HYDRAULIC SYSTEM	25
SECTION 41 - STEERING	29
SECTION 44 - 2WD FRONT AXLE	31
SECTION 50 - CLIMATE CONTROL	31
SECTION 55 - ELECTRICAL	35
SECTION 90 - PLATFORM	53

The following pages are the collation of the contents pages from each section and chapter of the TC35A - TC45DA Repair manual. Complete Repair part # 87618714.

The sections used through out all New Holland product Repair manuals may not be used for each product. Each Repair manual will be made up of one or several books. Each book will be labeled as to which sections are in the overall Repair manual and which sections are in each book.

The sections listed above are the sections utilized for the TC35A - TC45DA Tractors.

SECTION 00 - GENERAL INFORMATION

BOOK 1 - 87054260

Chapter 1 - General Information

CONTENTS

Section	Description	Page
00 000	Introduction	2
	Safety	3
	Technical Information	4
	Safety Precautions	5
	Safety Decals - TC35A, TC40A, TC45A	8
	Instruction Decals - TC35A, TC40A, TC45A	9
	Safety Decals - TC35DA, TC40DA, TC45DA	12
	Instruction Decals - TC35DA, TC40DA, TC45DA	13
	International Symbols	17
	Specifications - TC35A, TC40A, TC45A	18
	General Dimensions - TC35A, TC40A, TC45A	25
	Specifications - TC35DA, TC40DA, TC45DA	31
	General Dimensions - TC35DA, TC40DA, TC45DA	37
	Minimum Hardware Tightening Torques	41
	Special Tools	43
	Lubricants	44
00 400	Recommended Lubricants	44
	Adjustments	45
	Tire Inflation Pressure - Adjustments	45
00 100	Pre-Season and Pre-Delivery Checklist	46

SECTION 10 - ENGINE

BOOK 1 - 87054260

Chapter 1 - Engine

CONTENTS

Section	Description	Page
	Specifications	6
	Metric Bolt Torque Specifications	15
	Special Tools	16
	Compression Test and Tools	17
	Description of Operation	18
	Troubleshooting	19
	Cylinder Head and Valve Train Components	23
	Cylinder Block Assembly	23
	Separating the Tractor at the Clutch Housing/Engine - 12x12 Transmission	25
	Removal	25
	Separating the Tractor at the HST Housing/Engine - HST Transmission	29
	Removal	29
	Separating the Tractor at the HST Engine Frame	33
	Installation	35
	Attaching the 12x12 Transmission to the Engine	42
	Attaching the HST to the Engine	46
	Overhaul	54
	Engine	54
	Fuel Injector and Glow Plug	54
	Removal	54
	Oil Pressure Switch	54
	Temperature Sending Switch and Alternator	54
	Removal	54
	Fan, Water Pump and External Oil Tube	55
	Removal	55
	Air Inlet Manifold	55
	Removal	55
	Rocker Arm Shaft and Support Bracket	56
	Removal	56
10 101	Cylinder Head	56
	Removal	56
	Valve Tappet	57
	Removal	57

SECTION 10 - ENGINE

BOOK 1 - 87054260

Chapter 1 - Engine (Continued)

CONTENTS

Section	Description	Page
	Fuel Shutoff Solenoid	57
	Removal	57
10 106	Engine Timing Gear Cover, Timing Gears, and Cam Shaft	57
	Timing Gear Cover Removal	57
10 106	Timing Gears and Cam Shaft	60
	Removal	60
10 102	Oil Sump	61
	Removal	61
	Oil Suction Pipe and Strainer	61
	Removal	61
10 110	Balancer Assembly	62
	Removal	62
10 105	Connecting Rods, Bearings, and Pistons, Rings	62
	Removal	62
10 103	Flywheel	63
	Removal	63
10 103	Backplate and Oil Seal	63
	Removal	63
	Crankshaft - Main Bearings	63
	Removal	63
10 101	Cylinder Head	64
	Disassembly	64
	Inspection and Repair	64
	Valve Seats	65
	Valves	66
	Valve Guides	67
	Valve Springs	68
	Rocker Arms	68
	Push Rods	69
	Cylinder Head	69
	Assembly	69
	Cylinder Block	70

SECTION 10 - ENGINE

BOOK 1 - 87054260

Chapter 1 - Engine (Continued)

CONTENTS

Section	Description	Page
	Pistons	70
	Disassembly and Inspection	70
	Piston Rings	73
	Connecting Rods	73
	Connecting Rod Bearing	75
	Clearance Check	75
	Pistons, Rings, and Connecting Rod	76
	Assembly	76
10 103	Crankshaft - Main Bearing and Thrust Washer	77
	Removal and Inspection	77
	Crankshaft	78
	Bearing (Bushing)	79
	Replacement	79
	Main Bearing	80
	Assembly	80
	Port Block	81
	Removal	81
	Installation	81
10 106	Timing Gear	82
	Camshaft	82
	Disassembly	82
	Inspection	82
	Assembly	83
10 103	Flywheel	83
10 102	Timing Gear Housing	84
10 102	Front Oil Seal and Steering Pump Seal	84
	Replacement	84
10 103	Crankshaft and Bearing Holder	85
	Installation	85
	Rear Oil Seal and Backplate	85
	Installation	85
	Flywheel	86
	Installation	86

SECTION 10 - ENGINE

BOOK 1 - 87054260

Chapter 1 - Engine (Continued)

CONTENTS

Section	Description	Page
10 105	Pistons and Connecting Rods	86
	Installation	86
10 110	Balancer Assembly	87
	Installation	87
	Balancer Shims	87
	Oil Suction Pipe and Suction Strainer	88
	Installation	88
	Oil Sump	84
	Installation	88
10 106	Camshaft and Camshaft Gear	88
	Installation	88
10 106	Idler Gear, Oil Pump, and Injection Timing	89
	Installation	89
	Timing Gear Cover	89
	Installation	89
	Crankshaft Pulley	90
	Installation	90
	Fuel Injection Pump	90
	Installation	90
	Hydraulic Oil Pump	91
	Installation	91
	Power Steering Pump	91
	Installation	91
10 101	Head Gasket Selection	92
	Selection Chart	92
	Cylinder Head	92
	Installation	92
10 106	Valve Clearance	93
	Adjustment	93
	Valve Cover	94
	Installation	94
	Water Pump and Cooling Fan	94
	Installation	94

SECTION 10 - ENGINE

BOOK 1 - 87054260

Chapter 1 - Engine (Continued)

CONTENTS

Section	Description	Page
	External Oil Tube	94
	Assembly	94
	Glow Plug and Connector	95
	Installation	95
	Fuel Injector	95
	Installation	95
10 218	Fuel Piping	95
	Installation	95
	Alternator and Temperature Sender Switch	96
	Installation	96
	Exhaust Manifold	96
	Installation	96
10 304	Description of Operation - Engine Lubrication System	97
10 206	Oil Filter	101
	Construction and Function	101
	Maintenance	101
10 304	Oil Pump	101
	Removal	102
	Inspection	102
	Installation and Adjustment	102
	Engine Oil Pressure	103
	Check	103
	Oil Pressure Relief Valve	104
	Removal	104
	Installation	104
	Oil Consumption	104
10 400	Description of Operation - Cooling System	105
	Maintenance	107
	Coolant	107
	Radiator Cap	107
10 402	Thermostat	108
10 402	Water Pump	108
10 414	Cooling Fan	108

SECTION 10 - ENGINE

BOOK 1 - 87054260

Chapter 1 - Engine (Continued)

CONTENTS

Section	Description	Page
	Overhaul - Cooling System	109
10 406	Radiator	109
	Removal	109
	Inspection and Repair	110
	Installation	110
10 402	Water Pump	111
	Removal	111
	Inspection and Repair	113
	Installation	113
10 402	Thermostat	114
	Removal	114
	Inspection and Repair	114
	Installation	115
	Cab Heater	115
	Installation	115

SECTION 10 - ENGINE

BOOK 1 - 87054260

Chapter 2 - Fuel Systems

CONTENTS

Section	Description	Page
	Specifications	3
	Standards for Adjusting Injection Pump	3
	Torque Specifications	4
	Special Tools	4
	Description of Operation	5
10 242	Injection Pump	5
	Troubleshooting - General	7
	Troubleshooting - Fuel Injectors	10
	Troubleshooting - Governor	11
10 244	Fuel Variation Mechanism	12
	Delivery Valve Assembly	13
10 244	CTD (Compact Timing Device)	13
10 236	Pumping Elements	15
10 214	Delivery Valves	15
10 242	Injection Pump	17
	Removal	17
	Repair	19
	Installation	19
	Calibration/Adjustments	20
10 230	Fuel Pump	20
	Installation	20
	Spill-Timing Procedure	21
	Fuel Screw/High Idle	25
	Adjustment	25
10 230	Fuel Pump	26
	Auto Bleed	26
	Description of Operation	27
10 230	Governor	27
	Disassembly	29
	Assembly	30
	Adjustments	32

SECTION 10 - ENGINE

BOOK 1 - 87054260

Chapter 2 - Fuel Systems (Continued)

CONTENTS

Section	Description	Page
10 218	Injectors	33
	Removal	34
	Disassembly	35
	Assembly/Adjustment	35
	Engine Breather Valve	36
	Removal	37
	Installation	37
	Troubleshooting - Engine Breather Valve	38

SECTION 18 - CLUTCH

BOOK 1 - 87054260

Chapter 1 - Clutch

CONTENTS

Section	Description	Page
18 000	Specifications	3
	Bolt Torques	4
	Special Tools	4
	Description of Operation	5
	Troubleshooting	7
	Overhaul	8
	Separating the Tractor at the Clutch Housing/Engine	8
	Removal	8
18 110	Clutch	14
	Removal	14
	Inspection	14
	Assembly	15
	Attaching the 12x12 Transmission to the Engine	16

SECTION 18 - CLUTCH

BOOK 1 - 87054260

Chapter 1 - Clutch (Continued)

CONTENTS

Section	Description	Page
18 110	Clutch Related Components	22
	Pilot Bearing	22
	Removal	22
	Installation	22
	Damper Disc	22
	Removal	23
	Inspection	23
	Installation	23
	Flywheel Dimensions	24
	Clutch Release Bearing	25
	Removal	25
	Inspection	25
	Installation	26
	Clutch Linkage Components	26
18 100	Cross Shaft Bushings	26
	Disassembly	26
	Assembly	27
	Pedal Bushings	28
	Removal	28
	Disassembly	28
	Assembly	28
	Installation	28
	Pedal	29
	Adjustment	29
	Maximum Travel Adjustment	29

SECTION 21 - TRANSMISSION

BOOK 2 - 87054261

Chapter 1 - 12 x 12 Synchronized Shuttle Shift Gear Transmission

CONTENTS

Section	Description	Page
21 000	Specifications	3
	Metric Bolt Torque Specifications	4
	Special Tools	5
	Description of Operation	6
	Cross Section - 12 x 12 Transmission	8
	Powerflow	9
	Troubleshooting	13
	Overhaul	14
21 114	Separating the Tractor at the Clutch Housing/Engine	14
21 110 10	Removal	14
	Clutch Housing	20
	Disassembly	20
	Main Transmission	24
21 148 63	Retainer Cover	24
	Disassembly	24
21 148 63	Main Shift Rails and Shift Forks	25
	Disassembly	25
21 148 63	Main Shaft	28
	Disassembly	28
21 148 63	Range Shift Rail and Shift Fork	31
	Disassembly	31
21 148 63	Range Gear Countershaft	32
	Disassembly	32
21 148 63	Input Shaft	33
	Disassembly	33
21 148 63	Reverse Idler Shaft	34
	Disassembly	34
21 148 63	Shuttle Shift Rail and Fork	36
	Disassembly	36
21 148 63	Main Countershaft	37
	Disassembly	37
21 148 63	Synchronizers	39
	Disassembly	39

SECTION 21 - TRANSMISSION

BOOK 2 - 87054261

Chapter 1 - 12 x 12 Synchronized Shuttle Shift Gear Transmission (Continued)

CONTENTS

Section	Description	Page
	Main Transmission Components	40
	Inspection	40
	Synchronizers	40
	Assembly	40
	Main Countershaft	41
	Assembly	41
	Shuttle Shift Rail and Fork	42
	Assembly	42
	Reverse Idler Shaft	44
	Assembly	44
21 148 63	Input Shaft	46
	Assembly	46
21 148 63	Main Countershaft End Float	47
	Assembly	47
21 148 63	Range Gear Countershaft	48
	Assembly	48
21 148 63	Range Shift Rail and Fork	49
	Assembly	49
21 148 63	Main Shaft	50
	Assembly	50
21 148 63	Main Shaft End Float	53
	Assembly	53
21 148 63	Main Shaft Gears End Float	54
	Assembly	54
	Main Shift Rails and Forks	55
	Assembly	55
	Retainer Cover	58
	Assembly	58
21 110 10	Clutch Housing	59
	Assembly	59
	Attaching the 12 X 12 Transmission to the Engine	64
21 130	Transmission Shift Levers	70

SECTION 21 - TRANSMISSION

BOOK 2 - 87054261

Chapter 1 - 12 x 12 Synchronized Shuttle Shift Gear Transmission (Continued)

CONTENTS

Section	Description	Page
	Main Shift Control Lever	71
	Removal	71
	Installation	71
	Main Shift Lever	72
	Adjustment	72
	Shuttle Shift Control Lever	73
	Removal	73
	Installation	73

SECTION 23 - DRIVELINE

BOOK 2 - 87054261

Chapter 1 - Driveline

CONTENTS

Section	Description	Page
23 000	Bolt Torque Specifications	2
	Special Tools	3
	Description of Operation	4
	Front Wheel Drive Take Off Gearbox	4
	Sensitrack	5
	Automatic Position (Engaged)	6
	Automatic Position (Disengaged)	6
	Full Time Front Wheel Drive (Locked Down)	6
	Supersteer™ Front Axle	7
	Troubleshooting	9
	Lubrication	9
	Overhaul	10
	Front Wheel Drive Take Off Gearbox	10

SECTION 23 - DRIVELINE

BOOK 2 - 87054261

Chapter 1 - Driveline (Continued)

CONTENTS

Section	Description	Page
	Removal	10
	Disassembly	12
	Inspection	12
	Assembly	12
	Installation	12
23 260	Sensitrack	14
	Removal	14
	Disassembly	16
	Inspection	23
	Assembly	23
23 260	Installation	31
	Cable Adjustment	33

SECTION 25 - FWD FRONT AXLE

BOOK 2 - 87054261

Chapter 1 - FWD Front Axle, Supersteer™ and Sensitrack™

CONTENTS

Section	Description	Page
	Specifications	3
	Front to Rear Axle Ratio	3
	Bolt Torque Specifications	6
	Special Tools	6
25 100	Description of Operation - FWD Front Axle	7
	FWD Front Axle	7
	Troubleshooting	8
	Lubrication	10

SECTION 25 - FWD FRONT AXLE

BOOK 2 - 87054261

Chapter 1 - FWD Front Axle, Supersteer™ and Sensitrack™ (Continued)

CONTENTS

Section	Description	Page
	Overhaul – Standard FWD Axle	11
	Standard FWD Axle	11
	Removal	11
	Installation	11
25 108	Gear Reduction Drop Box	12
	Disassembly	12
25 102	Front Axle and Differential	15
	Disassembly	15
	Drive Pinion	16
	Disassembly	16
	Front Axle	17
	Inspection	17
	Differential	17
	Inspection	17
	Gear Reduction – Drop Box	17
	Inspection	17
	Drive Pinion	18
	Assembly	18
	Differential Gear	18
	Assembly	18
	Axle and Differential	19
	Assembly	19
	Differential Case Bearing Preload	20
	Check and Adjustment	20
	Ring Gear-to-Pinion Backlash	20
	Check and Adjustment	20
25 108	Gear Reduction Box	23
	Assembly	23
	Ring Gear-to-Pinion Backlash	25
	Check and Adjustment	25
	Bevel Gear-to-Pinion Backlash	26
	Check	26
	Description and Operation – Supersteer™/Sensitrack™	27
25 100	Supersteer™	27

SECTION 25 - FWD FRONT AXLE

BOOK 2 - 87054261

Chapter 1 - FWD Front Axle, Supersteer™ and Sensitrack™ (Continued)

CONTENTS

Section	Description	Page
	Sensitrack™	28
	Automatic Position (Engaged)	29
	Automatic Position (Disengaged)	30
	Full Time Front Wheel Drive (Locked Down)	30
	Supersteer™ Front Axle	30
	Overhaul - Supersteer™ Axle	33
25 100	Supersteer™ Axle	35
	Removal	35
	Gear Reduction-Drop Box	40
	Disassembly	40
25 102	Front Axle and Differential	42
	Disassembly	42
	Drive Pinion	43
	Disassembly	43
	Front Axle	44
	Inspection	44
	Differential	44
	Inspection	44
	Gear Reduction-Drop Box	44
	Inspection	44
	Drive Pinion	45
	Assembly	45
	Differential Gear	45
	Assembly	45
25 102	Axle and Differential	46
	Assembly	46
	Differential Case Bearing Preload	47
	Check and Adjustment	47
	Ring Gear-to-Pinion Backlash	47
	Check and Adjustment	47
25 108	Gear Reduction Box	50
	Assembly	50
	Bevel Gear-to-Pinion Backlash	52
	Check	52
	Supersteer™ Axle	53
	Installation	53

SECTION 27 - DIFFERENTIAL, REAR AXLE

BOOK 2 - 87054261

Chapter 1 - Differential, Rear Axle

CONTENTS

Section	Description	Page
27 000	Specifications	2
	Bolt Torque Specifications	3
	Special Tools	3
	Description of Operation	4
27 110	Differential	6
27 110	Differential Lock	6
27 126	Rear Axle	7
	Overhaul	8
27 106	Differential	8
	Removal	8
	Disassembly	10
	Inspection	10
	Assembly	11
	Installation	11
	Drive Pinion	13
	Removal	13
	Disassembly	13
	Inspection	14
	Assembly	14
27 126	Rear Axle	17
	Removal	17
	Disassembly	18
	Inspection	21
	Assembly	22
27 126	Final Pinion	26
	Removal	26
	Disassembly	27
	Inspection	29
	Assembly	30
	Installation	32

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 3 - 87054262

Chapter 1 - Hydrostatic Transmission

CONTENTS

Section	Description	Page
	Specifications	4
	Metric Bolt Torque Specifications	6
	Special Tools	6
29 202	Description of Operation	7
	Power Flow	8
	High Range	8
	Low Range	9
	Oil Flow	10
	Neutral Position	10
	Forward Position	11
	Reverse Position	12
29 212	Variable Displacement Pump	13
29 212	Two Position Displacement Motor	14
29 134	Hi/Lo Speed Control/Control Pod	15
	Hi/Lo Speed Control	15
29 200	Foot Control Pedals	16
	Troubleshooting	18
	Charge Pump Relief Valve	20
	Test	20
	Pressure Testing and Adjustments	21
	High Pressure Relief Valve	21
	Hi/Low Pressure Test	23
	Separating the Tractor	25
	TC35DA, TC40DA, and TC45DA w/HST Transmission	25
	Separating at the HST Housing/Engine	25
	Separating the HST Housing at the Gearbox	32
	Attaching the HST Housing to the Gearbox	34
	Attaching the HST to the Engine	37
29 202	Hydrostatic Transmission	44
	Disassembly	44
	Charge Pump	44
	Removal	44

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 3 - 87054262

Chapter 1 - Hydrostatic Transmission (Continued)

CONTENTS

Section	Description	Page
29 130	Port Block	45
	Removal	45
	Cylinder Block Assembly	46
	Removal	46
	Motor Swash Plate	46
	Removal	46
	Input and Output Shaft	47
	Removal	47
	Pump Swash Plate	47
	Removal	47
29 130	Port Block	48
	Removal	48
	Inspection	48
	Piston	49
	Assembly	49
	Charge Pump	50
	Assembly	50
	Swash Plate	50
	Assembly	50
	Pump Shaft (Input Shaft)	51
	Assembly	51
	Charge Pump	51
	Assembly	51
29 218	Cylinder Block Assembly for Pump	51
	Assembly for Pump	51
	Motor Shaft	52
	Assembly	52
29 218	Cylinder Block Assembly for Motor	52
	Assembly for Motor	52
	Port Block	53
29 130	Assembly	53
	Installation	54

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 3 - 87054262

Chapter 1 - Hydrostatic Transmission (Continued)

CONTENTS

Section	Description	Page
	Hydrostatic Transmission	55
	Assembly	55
29 204	Check Valve	55
	Disassembly	55
	Inspection	55
	Assembly	55
	Description and Operation - Gearbox	56
29 300	Gearbox	56
	Gearbox Identification	57
	Overhaul - Gearbox	58
	Gearbox	58
	Removal	58
	Disassembly	59
	Inspection	63
	Assembly	64
	Installation	67
29 214	Hi/Lo Solenoid Valve	69
	Removal	71
	Disassembly	71
	Inspection	72
	Testing	72
	Assembly	73
	Adapter Block	74
	Removal	74
	Disassembly	75
	Inspection	76
	Assembly	76
	Cruise Control	77
	Electromagnet Air Gap Adjustment	78
	Adjustment	78

SECTION 29 - HYDROSTATIC TRANSMISSION

BOOK 3 - 87054262

Chapter 2 - Adjustment

CONTENTS

Section	Description	Page
	HST Pedals	2
	Stop Adjustment	2
	HST Cruise Control Magnet	3
	Adjustment	3
29 200	HST Foot Control Pedals	4
29 200	Neutral Adjustment	4
	HST Pedals Return Spring	5
	Adjustment	5

SECTION 31 - POWER TAKE-OFF (PTO) SYSTEMS

BOOK 3 - 87054262

Chapter 1 - Power Take-Off (PTO) Systems

CONTENTS

Section	Description	Page
	Specifications	3
	PTO Hydraulic System	3
	PTO Clutch	3
	Metric Bolt Torque Specifications	4
	Special Tools	5
31 000	Description of Operation	6
31 110	Rear PTO	7
	Power Flow Diagram for the 12x12 Synchronized Shuttle Shift Transmission	7
	Power Flow Diagram for the Hydrostatic Transmission (HST)	8
31 120	Power Flow Diagram for Tractors Equipped with a Mid PTO Kit	9
31 104	Hydraulic Fluid Flow	10
	PTO Clutch Assembly	10
	Troubleshooting	13

SECTION 31 - POWER TAKE-OFF (PTO) SYSTEMS

BOOK 3 - 87054262

Chapter 1 - Power Take-Off (PTO) Systems (Continued)

CONTENTS

Section	Description	Page
	Pressure Testing	14
	Test Procedure (Below Serial Number - See Chart)	14
	Test Procedure (Serial Number and Above - See Chart)	15
	Overhaul	17
31 104 82	PTO System Diverter Valve Assembly	17
	Removal	17
	Disassembly	17
	Inspection	18
	Assembly	18
	Installation	19
31 104 82	PTO Clutch Control Valve (BSN)	20
	Removal	20
	Spool	21
	Removal	21
	Inspection	21
	Assembly	21
	Clutch Control Relief Valve	23
	Disassembly	23
	Inspection	23
	Assembly	23
	Installation	24
31 104 82	PTO Clutch Control Valve (ASN)	25
	Removal	25
	Disassembly	26
	Inspection	26
	Assembly	26
	Installation	28
31 114 62	PTO Clutch	29
	Removal	29
31 114 68	Disassembly	32
31 114 62	Installation	34
	Assembly	36
	Installation	40

SECTION 31 - POWER TAKE-OFF (PTO) SYSTEMS

BOOK 3 - 87054262

Chapter 1 - Power Take-Off (PTO) Systems (Continued)

CONTENTS

Section	Description	Page
31 114 42	PTO System System for 12x12 Synchronized Shuttle Shift Transmission	44
	Removal	44
	PTO Input Shaft	44
	Removal	44
	Disassembly	45
	Inspection	45
	Assembly	45
	Installation	46
31 114 46	PTO Countershaft and Rear PTO Shaft	46
	Removal	46
31 114 46	Countershaft	48
	Disassembly	48
	Inspection	49
	Assembly	49
	Installation	51
31 114 00	PTO System for Hydrostatic Transmission (HST)	53
	Removal	53
31 114 42	PTO Input Shaft	53
	Removal	53
	Disassembly	54
	Inspection	54
	Assembly	54
	Installation	55
31 114 46	PTO Countershaft and Rear PTO Shaft	55
	Removal	55
31 114 42	Disassembly	59
	Inspection	60
	Assembly	60
31 114 19	Installation	63
31 120 00	Mid PTO Countershaft and Drop Box	66
	Removal	63
	Disassembly	71
	Inspection	73
	Assembly	74
	Installation	75

SECTION 33 - BRAKES

BOOK 3 - 87054262

Chapter 1 - Brakes

CONTENTS

Section	Description	Page
	Specifications	2
	Bolt Torque Specifications	3
	Description of Operation	4
33 120	Brakes	4
33 110	Parking Brake	6
33 120	Overhaul	7
	Brakes	7
	Removal and Disassembly	7
	Inspection	9
	Assembly and Installation	10
	Adjustment	12

SECTION 35 - HYDRAULIC SYSTEM

BOOK 3 - 87054262

Chapter 1 - Hydraulic System

CONTENTS

Section	Description	Page
	Specifications	4
	Metric Bolt Torque Specifications	5
	Special Tools	6
35 100	Description of Operation	7
	Flow Priority	8
	Hydraulic System	9
	Hydraulic Fluid Filter	9
35 080	Combination System Relief - Diverter Valve Manifold Assembly	10
35 200	Control Valve Assembly (HPL)	11
	Fluid Flow	12

SECTION 35 - HYDRAULIC SYSTEM

BOOK 3 - 87054262

Chapter 1 - Hydraulic System (Continued)

CONTENTS

Section	Description	Page
35 210	Neutral Position	12
35 210	Raising Position	13
35 210	Lowering Position	14
	Bypass Spool - Fluid Flow	15
35 200	Closed Position	15
35 200	Open Position	15
35 183	Flow Control Valve	16
35 108	Single Lever - Position Control	16
35 108	Neutral Position to Raise	17
	Raise Position to Neutral Position	17
	Neutral Position to Lowering Position	17
35 112	Dual Lever Position Control (Draft Control)	18
	Top Link Sensing Raise	18
	Top Link Sensing Lower	19
	Varying Draft Control Settings	19
35 124	Combining Position and Draft Control Settings	20
	Troubleshooting	21
	Pressure Testing	23
	Main System Relief Valve	23
	Inlet Restriction	25
	Pump Efficiency	26
35 110	Overhaul - Hydraulic System	27
35 110	Lift Cylinder	27
	Removal	27
	Disassembly	31
	Inspection and Repair	33
	Assembly	33
	Installation	35
	Flow Control Valve	37
	Removal	37
	Disassembly	37
	Inspection	37
	Assembly	37
	Installation	37

SECTION 35 - HYDRAULIC SYSTEM

BOOK 3 - 87054262

Chapter 1 - Hydraulic System (Continued)

CONTENTS

Section	Description	Page
35 200	Hydraulic Control Valve	38
	Removal	38
	Disassembly	38
	Inspection	39
	Assembly	39
	Installation	41
35 180	Combination System Relief and Diverter Valve Assembly	42
	Removal	42
	Disassembly	42
	Inspection	43
	Assembly	43
	Installation	44
35 182	PTO System Diverter Valve	45
	Removal	45
	Disassembly	45
	Inspection	46
	Assembly	46
	Installation	47
35 124	Adjustments	48
	HPL Linkage	48
	Adjustment Procedure	48
	Control Lever	48
	Adjustment Procedure	48
	Description of Operation - Hydraulic Pump and Filter	49
35 304	Hydraulic Pump and Filter	49
35 304	Hydraulic Pump	50
	Removal	50
	Disassembly	52
	Inspection and Repair	52
	Assembly	53
	Installation	54
35 300	Sump Tube and Screen Filter	56
	Removal	56
	Disassembly	57

SECTION 35 - HYDRAULIC SYSTEM

BOOK 3 - 87054262

Chapter 1 - Hydraulic System (Continued)

CONTENTS

Section	Description	Page
	Inspection	57
	Assembly	57
	Description of Operation - Remote Valves	59
35 204	Remote Valves	59
	Rear (Single-Spool) Remote Valve	60
	Front (Double-Spool) Remote Valve	60
	Rear (Single-spool) Remote System	62
	Fluid Flow	62
	Neutral Position	62
	Remote Cylinder Extending	63
	Remote Cylinder Retracting	64
	Front Remote (Two Spool) Loader Control Valve Fluid Flow Diagrams	65
	Bucket Control	65
	Neutral/Lift Control-Neutral	65
	Dumping/Lift Control-Neutral	66
	Dumping REGEN/ Lift Control-Neutral	67
	Roll Back/Lift Control-Neutral	68
	Neutral/Lift Control-Raising	69
	Neutral/Lift Control-Lowering	70
	Neutral/Lift Control-Float	71
35 204	Overhaul	72
	Rear (Single-Spool) Remote Valve	72
	Removal	72
	Disassembly	73
	Inspection and Repair	73
	Assembly	73
	Front (Double Spool) Remote Valve	74
	Removal	74
	Disassembly	76
	Inspection and Repair	76
	Assembly	76
	Installation	76

SECTION 41 - STEERING

BOOK 4 - 87056433

Chapter 1 - Steering

CONTENTS

Section	Description	Page
41 000	Specifications	2
	Metric Bolt Torque Specifications	3
	Special Tools	4
	Description of Operation	5
	Supersteer™	5
41 204	Power Steering Control Motor	10
	Spool and Sleeve	10
	Rotor and Fixed Ring	10
	Check Valve	10
	Drive Shaft	10
	Pressure Relief Valve	10
41 206	Power Steering Pump	10
41 216	Steering Cylinders	10
	Supersteer™	10
41 216	2WD and Standard 4WD	12
41 206	Supersteer™	13
	Fluid Flow - Neutral Position	13
41 200	Fluid Flow - Left Turn	14
41 200	Fluid Flow - Right Turn	15
41 200	Manual Operation	16
41 200	Power Steering Operation - 2WD and Standard 4WD	17
	Fluid Flow - Neutral Position	17
41 200	Fluid Flow - Left Turn	18
41 200	Fluid Flow - Right Turn	19
41 200	Manual Operation - 2WD and Standard 4WD	20
	Troubleshooting	21
	Pressure Testing	23
	Pump, Steering Motor, and Relief Valve	23
	Test Results	23
	Steering Cylinder	24
	Test Results	24

SECTION 41 - STEERING

BOOK 4 - 87056433

Chapter 1 - Steering (Continued)

CONTENTS

Section	Description	Page
	Lubrication	25
	Lubricate Every 50 Hours	25
	Overhaul	25
41 204	Steering Control Motor	26
	Removal	26
	Disassembly	27
	Inspection	33
	Assembly	33
	Installation	42
41 216	Steering Cylinder - 4WD and Supersteer™	43
	Removal	43
41 216	Steering Cylinder - 2WD	43
	Removal	44
	Disassembly	47
	Inspection	48
	Assembly	49
41 216	Steering Cylinder - 4WD and Supersteer™	53
	Installation	53
41 216	Steering Cylinder - 2WD	55
	Installation	55
41 206	Pump and Reservoir Tank	57
	Pump Removal	57
	Disassembly	58
	Inspection and Repair	58
	Assembly	58
41 206	Pump Installation	59
	Power Steering Tubes	60

SECTION 44 - 2WD FRONT AXLE

BOOK 4 - 87056433

Chapter 1 - 2WD Front Axle

CONTENTS

Section	Description	Page
44 100	Specifications	2
	Bolt Torque Specifications	2
44 101	Description of Operation	3
	Troubleshooting	4
	Overhaul	5
	Front Axle	5
	Removal	5
	Disassembly	6
	Inspection	9
	Assembly	10
44 103	Installation	12

SECTION 50 - CLIMATE CONTROL

BOOK 4A - 87618715

Chapter 1 - Climate Control - TC40DA-TC45DA With Cab

CONTENTS

Section	Description	Page
	Specifications	4
	Compressor	4
	Refrigerant	4
	Refrigerant Oil	4
	Low Pressure Switch	4
	High Pressure Switch	4
	Special Tools	5

SECTION 50 - CLIMATE CONTROL

BOOK 4A - 87618715

Chapter 1 - Climate Control - TC40DA-TC45DA With Cab (Continued)

CONTENTS

Section	Description	Page
	Description and Operation	6
	Compressor	6
	Condenser	6
	Evaporator	6
	Expansion Valve	7
	Receiver/Drier	8
	Heater	8
	Heater System	9
	HVAC Control Panel	10
	Cab Air Filter	10
	Cleaning Cab Air Filter	11
	Compressor Protection Switches	11
	High-Pressure Cutout Switch	11
	Low-Pressure Cutout Switch	11
	Component Location	12
	Cab and Engine Bay	12
	Cab Roof	13
	Troubleshooting	14
	Expansion Valve - Testing	16
	Temperature/Pressure Chart	16
	Service Precautionary Statements	17
	Leak Testing	17
	Refilling	17
	Contaminants	17
	General	17
	Preventing Mixing of Service Equipment	18
	Refrigerant Extraction and Recycling Equipment	18
	Using Extraction Equipment	18
	Using Recycling Equipment	19
	Recycling vs. Reclaiming	19
	Containment of Air Conditioning Refrigerants	19
	Recovery	19
	Flushing	20

SECTION 50 - CLIMATE CONTROL

BOOK 4A - 87618715

Chapter 1 - Climate Control - TC40DA-TC45DA With Cab (Continued)

CONTENTS

Section	Description	Page
	Recharging/Refilling	20
	Using a Manifold Gauge Set	20
	Checking Refrigerant for Excess Air	21
	Containers for Storing Recycled Refrigerant	22
	Disposal of Empty or Near-empty Disposable Containers	22
	Applicable SAE Standards	22
	Related SAE Standards	22
	Manifold Gauges and Interpretations	23
	Performance Test Examples	23
	Evacuating the Refrigerant	34
	Vacuum Test	37
	Pressure Test	40
	Leakage Test	41
	Charging	41
	Overhaul	43
	Belt Replacement	43
	Specification	43
	HVAC Controls	43
	Removal	43
	Installation	44
	Heater Valve	44
	Removal	44
	Installation	45
	Condenser	45
	Removal	45
	Installation	47
	Receiver/Drier	49
	Removal	49
	Installation	50
	Evaporator/Heater Core Replacement	50
	Removal	50

SECTION 50 - CLIMATE CONTROL

BOOK 4A - 87618715

Chapter 1 - Climate Control - TC40DA-TC45DA With Cab (Continued)

CONTENTS

Section	Description	Page
	Disassembly	52
	Assembly	52
	Installation	53
	Expansion Valve	54
	Removal	54
	Installation	55
	Temperature Sensor	56
	Removal	56
	Installation	57
	Blower Motor/Blower Motor Resistor	58
	Removal	58
	Disassembly	60
	Assembly	60
	Installation	60
	Low Pressure Switch	62
	Replacement	62
	High Pressure Switch	62
	Replacement	62
	A/C Compressor	63
	Removal	63
	Compressor Assembly Torques	65
	Compressor Breakdown	66
	Clutch Breakdown	67
	Compressor Repaired Internally and Reinstalled in the System	67
	Sanden Compressor Replaced by a New Sanden Compressor of the Same Type	68
	Clutch Head Repair	69
	Keyed Shaft Armature Removal	69
	Rotor Assembly Removal	70
	Field Coil Assembly Removal	70
	Field Coil Assembly Installation	70

SECTION 50 - CLIMATE CONTROL

BOOK 4A - 87618715

Chapter 1 - Climate Control - TC40DA-TC45DA With Cab (Continued)

CONTENTS

Section	Description	Page
	Rotor Assembly Installation	71
	Armature Assembly Installation	71
	Replacement of Shaft Seal	72
	Cylinder Head Removal	75
	Valve Plate Removal	76
	Valve Plate and Cylinder Head Installation	76

SECTION 55 - ELECTRICAL

BOOK 4 - 87056433

Chapter 1 - Electrical

CONTENTS

Section	Description	Page
	Bolt Torque Specifications	5
55 100	Description of Operation	6
	Component Location and Function	6
55 100	Wiring Harnesses	8
	Grounds	8
	Electrical System Components	9
	Battery	9
	Checking the Electrolyte Level	10
	Removal	10
	Installation	10

SECTION 55 - ELECTRICAL

BOOK 4 - 87056433

Chapter 1 - Electrical (Continued)

CONTENTS

Section	Description	Page
	Main Fuse	11
	Replacement	11
	Fuse Block	12
	Key Switch	13
	Removal	13
	Terminal Identification	14
	Testing	14
	Stop Position (Not Shown)	14
	Heat/ Accessory/ Run Position	14
	Start Position	15
	Light Switch (Road Lights)	15
	Removal	16
	Terminal Identification and Testing	17
	Work Light Switch	18
	Removal	18
	Forward Position "On"	19
55 404	Headlight	20
	Replacement	20
55 404	Taillight	21
	Hazard Light Switch	22
	Removal	22
	Testing	23
	"Off" Position	23
	"On" Position	23
	Installation	24
55 408	Transmission Range Safety Switch (HST and Gear)	25
	Removal	25
	Testing	26
	Extended Position	26
	Retracted Position (Not Shown)	26
	Installation	26

SECTION 55 - ELECTRICAL

BOOK 4 - 87056433

Chapter 1 - Electrical (Continued)

CONTENTS

Section	Description	Page
55 408	Rear (Main) PTO Safety Switch	27
	Testing	27
	Extended Position	27
	Retracted Position	28
55 408	Mid PTO Safety Switch (Optional for 35DA, 45DA, and 40DA Models Only)	28
	Removal	28
	Testing	28
	Extended Position	28
	Retracted Position	29
55 408	Seat Safety Switch	29
	Removal	30
	Testing	30
	Extended Position	30
	Retracted Position	30
55 408	Parking Brake Safety Switch	31
	Testing	31
	Extended Position	31
	Retracted Position	31
	Relays	32
	(DA) Series Relay Panel Identification	32
	(A) Series Relay Panel Identification	33
	Testing-Micro Relays	34
	“HI”, “LOW”, Cruise Control, Fuel Shutoff, PTO Safety, and Glow Plug Lamp Relays ..	34
	Replacement	34
	Headlight and Neutral Start Relays	35
	Replacement	35
	Glow Plug Power Relay	37
	Replacement	37
	Diodes	38
	Module Testing	39
	Diode Testing	40

SECTION 55 - ELECTRICAL

BOOK 4 - 87056433

Chapter 1 - Electrical (Continued)

CONTENTS

Section	Description	Page
	Operator Safety Module	41
	Removal	41
	Testing	42
	Glow Plug Timer	43
	Testing	44
55 201	Engine Glow Plugs	44
	Removal	45
	Testing	46
	Installation	46
	Hazard Flasher/Turn Signal Control Module	47
	Removal	48
	Testing	49
	Installation	52
55 410	Fuel Level Sending Unit	53
	Removal	53
	Testing	54
	Installation	55
	Fuel Shutoff Solenoid	56
	Removal	56
	Testing	57
	Installation	57
55 414	Engine Oil Pressure Switch	58
	Testing	58
	Engine Coolant Temperature Sending Unit	59
	Testing	59
	Hi/Low Transmission Range Switch	61
	Testing	61
	Optional Testing	63
	Hi/Low Transmission Range Solenoid	64
	Removal	65
	Testing	65
	Installation	66

SECTION 55 - ELECTRICAL

BOOK 4 - 87056433

Chapter 1 - Electrical (Continued)

CONTENTS

Section	Description	Page
	Electric Cruise Control Switch (HST)	67
	Removal	67
	Testing	68
	Installation	68
	Cruise Control Magnet (HST)	69
	Removal	69
	Testing	69
	Installation	69
	Cruise Control Brake Release Switch	71
	Removal	71
	Testing	71
	Extended Position (Not Shown)	71
	Retracted Position	72
	Installation	72

SECTION 55 - ELECTRICAL

BOOK 4 - 87056433

Chapter 2 - Schematics

CONTENTS

Section	Description	Page
	Complete Wiring Schematic	2
	Safety Start Circuit (Operator Present)	18
	Safety Start Circuit (Operator Not Present)	22
	Safe Operation Circuit (Operator Present)	26
	Safe Operation Circuit (Operator Not Present)	30
	Glow Plug Circuit	34
	Road Lights Circuit	38
	Work Lights Circuit	42
	Hazard Flasher Circuit	46
	Right Turn Signal Circuit	50
	Left Turn Signal Circuit	54
	PTO Indicator Light Circuit	58
	Engine Coolant Temperature Circuit	62
	Engine Low Oil Pressure Indicator Light Circuit	64
	Fuel Level Circuit	66
	Parking Brake Indicator Light Circuit	68
	Tachometer Circuit	70
	Auxiliary Power Socket Circuit	72
	Cruise Control Circuit (HST Transmission)	74
	HST Range "LOW" Shift Circuit	78
	HST Range "HIGH" Shift Circuit	82
	Charging Circuit	86

SECTION 55 - ELECTRICAL

BOOK 4 - 87056433

Chapter 3 - Instrument Panel

CONTENTS

Section	Description	Page
	Component Operation and Servicing	2
	Instrument Panel	2
	Removal	4
	Component Testing and Replacement	4
	Fuel Gauge	4
	Testing	4
	Replacement	5
	Temperature Gauge	6
	Testing	6
	Replacement	6
	Tachometer	7
	Testing	7
	Replacement	8
	Instrument Panel Indicator and Illumination Lights	10
	Bulb Identification Chart	10
	Bulb Replacement	11

SECTION 55 - ELECTRICAL

BOOK 4 - 87056433

Chapter 4 - Alternator and Starter

CONTENTS

Section	Description	Page
	Alternator Specifications	3
	Alternator Troubleshooting	4
	Charging System	6
	Alternator	6
	Description of Operation	6
	Charging Circuit	7
	Principle of IC Regulator	7
	Preliminary Alternator Tests	9
	Alternator Drive Belt	9
	Alternator Output	9
	Alternator Removal	11
	Alternator Disassembly	11
	Alternator Component Testing and Inspection	15
	Stator	15
	Rotor	16
	Rectifier Assembly	17
	Alternator Brushes	18
	Alternator Bearings	18
	Drive Pulley	19
	Alternator Frames	19
	Assembly	19
	Alternator Bench Check	23
	Installation	24
	Starter Motor Specifications	25
	Starter Motor Troubleshooting	26
	Starting System	28
	Description of Operation	28

SECTION 55 - ELECTRICAL

BOOK 4 - 87056433

Chapter 4 - Alternator and Starter (Continued)

CONTENTS

Section	Description	Page
	Starter Components	28
	Starter Motor Assembly	28
	Starter Solenoid	29
	Pinion Clutch	29
	Removal	30
	Disassembly	31
	Inspection	35
	Electrical Testing	38
	Armature	38
	Brush Holder	39
	Field Coil	39
	Starter Solenoid	40
	Assembly	43
	No Load Test	48
	Installation	48

SECTION 55 - ELECTRICAL

BOOK 4A - 87618715

Chapter 5 - Electrical - TC40DA-TC45DA With Cab

CONTENTS

Section	Description	Page
	Bolt Torque Specifications	5
55 100	Description of Operation	6
	Component Location and Function	6
55 100	Wiring Harnesses	8
	Grounds	8
	Electrical System Components	9
	Battery	9
	Checking the Electrolyte Level	10
	Removal	10
	Installation	10
	Main Fuse	11
	Replacement	11
	Fuse Blocks	12
	Key Switch	14
	Removal	14
	Terminal Identification	15
	Testing	15
	Stop Position (Not Shown)	15
	Heat/ Accessory/ Run Position	15
	Start Position	15
	Installation	16
	Multifunction Stalk Switch (Lights, Turn Signals, Horn)	16
	Removal	17
	Switch Testing	17
	Installation	17
	Work Light Switch	18
	Removal	18
	Forward Position "On"	19
	Installation	19

SECTION 55 - ELECTRICAL

BOOK 4A - 87618715

Chapter 5 - Electrical - TC40DA-TC45DA With Cab (Continued)

CONTENTS

Section	Description	Page
55 404	Headlight	20
	Replacement	20
55 404	Taillight/Rear Flasher Light	21
	Front Flasher Warning Light/Turn Signals	22
	Cab Work Lights	22
	Hazard Light Switch	23
	Removal	23
	Testing	24
	“Off” Position	24
	“On” Position	24
	Installation	25
55 408	Transmission Range Safety Switch	26
	Removal	26
	Testing	27
	Extended Position	27
	Retracted Position (Not Shown)	27
	Installation	27
55 408	Rear (Main) PTO Safety Switch	28
	Removal	28
	Testing	28
	Extended Position (PTO “ON”)	28
	Retracted Position (PTO “OFF”)	29
	Installation	29
55 408	Mid PTO Safety Switch (Optional)	29
	Removal	29
	Testing	29
	Extended Position	29
	Retracted Position	30
	Installation	30
55 408	Seat Safety Switch	31

SECTION 55 - ELECTRICAL

BOOK 4A - 87618715

Chapter 5 - Electrical - TC40DA-TC45DA With Cab (Continued)

CONTENTS

Section	Description	Page
	Description	31
	Removal	31
	Testing	32
	Extended Position	32
	Retracted Position	32
	Installation	32
55 408	Parking Brake Safety Switch	33
	Testing	33
	Extended Position	33
	Retracted Position	33
	Relays	34
	(DA) Series Relay Panel Identification	34
	Removal	35
	Testing-Micro Relays	35
	“HI”, “LOW”, Cruise Control, Fuel Shutoff, PTO Safety, Glow Plug Lamp, Flasher Cutoff, Park Brake Interface, Front Work Lights, and HVAC Relays	35
	Replacement	35
	Testing	36
	Headlight, High Beam, Neutral Start, and Cab Power Relays	36
	Replacement	36
	Glow Plug Power Relay	38
	Testing	38
	Installation (All Relays)	38
	Diodes	39
	Module Testing	40
	Diode Testing	41
	Operator Safety Module	42
	Removal	42
	Testing	43
	Installation	43
	Park Brake Safety Alarm (Buzzer)	44
	Removal	44

SECTION 55 - ELECTRICAL

BOOK 4A - 87618715

Chapter 5 - Electrical - TC40DA-TC45DA With Cab (Continued)

CONTENTS

Section	Description	Page
	Testing	44
	Installation	46
	Glow Plug Timer	46
	Removal	46
	Testing	47
	Installation	47
55 201	Engine Glow Plugs	48
	Removal	48
	Testing	49
	Installation	49
	Hazard Flasher/Turn Signal Control Module	50
	Removal	50
	Testing	52
	Installation	54
55 410	Fuel Level Sending Unit	55
	Removal	55
	Testing	56
	Installation	57
	Fuel Shutoff Solenoid	58
	Removal	58
	Testing	58
	Installation	59
55 414	Engine Oil Pressure Switch	60
	Testing	60
	Engine Coolant Temperature Sending Unit	61
	Testing	61
	Hi/Low Transmission Range Switch (HST)	63
	Testing	63
	Optional Joystick Switch Testing	65
	Hi/Low Transmission Range Solenoid (HST)	66
	Removal	67
	Testing	67

SECTION 55 - ELECTRICAL

BOOK 4A - 87618715

Chapter 5 - Electrical - TC40DA-TC45DA With Cab (Continued)

CONTENTS

Section	Description	Page
	Installation	68
	Electric Cruise Control Switch (HST)	69
	Removal	69
	Testing	70
	Installation	70
	Cruise Control Magnet (HST)	71
	Removal	71
	Testing	72
	Installation	72
	Cruise Control Brake Release Switch (HST)	73
	Removal	73
	Testing	73
	Extended Position	73
	Retracted Position	73
	Installation	74
	Cab to Tractor Harness Main Connectors	75

SECTION 55 - ELECTRICAL

BOOK 4A - 87618715

Chapter 6 - Schematics - TC40DA-TC45DA With Cab

CONTENTS

Section	Description	Page
	Electrical Schematic Diagram	2
	Safety Start Circuit (Operator Present or Not Present)	28
	Safe Operation Operator Present Circuit	32
	Safe Operation Operator Not Present Circuit	36
	Safety Alarm Circuit (Key "Off" And Park Brake "Off")	40
	Safety Alarm Circuit (Key "On", Rear PTO "On", Operator Not Present and Park Brake "On")	42
	Safety Alarm Circuit (Key "On", Rear PTO "On", Operator Not Present and Park Brake "Off")	46
	Glow Plug Circuit	50
	Headlights Circuit (Position, Low And High Beams)	54
	Front Work Lights Circuit	58
	Cab Work Lights Circuit	62
	Interior Cab Lights Circuit	66
	Hazard Flasher Lights Circuit	68
	Right Turn Signal Circuit	72
	Left Turn Signal Circuit	76
	HVAC Circuit	80
	Auxiliary Power Socket Circuit	84
	Front and Rear Wiper Circuit	86
	Horn Circuit	90
	Cruise Control Circuit (HST Transmission)	92
	HST Range "Low" Shift Circuit	96
	HST Range "High" Shift Circuit	100
	Charging Circuit	104
	PTO Indicator Light Circuit	108
	Park Brake Indicator Light Circuit	112
	Engine Coolant Temperature Circuit	116
	Engine Low Oil Pressure Indicator Light Circuit	118
	Fuel Level Circuit	120
	Tachometer Circuit	122
	Beacon Circuit	124
	Radio Circuit	128

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com