


890A  
Excavator



**TECHNICAL MANUAL**



# 890A EXCAVATOR TECHNICAL MANUAL TM-1263 (JUN-86)

## SECTION AND GROUP CONTENTS

### SECTION I—GENERAL INFORMATION

- Group I—Introduction and Safety Information
- Group II—General Specifications
- Group III—Cap Screw Torque Values
- Group IV—Lubrication

### SECTION 01—TRACKS

- Group 0130—Track Systems

### SECTION 02—AXLES AND SUSPENSION SYSTEMS

- Group 0250—Axle Shafts, Bearings and Reduction Gears
- Group 0260—Hydraulic Systems

### SECTION 04—ENGINE

- Group 0400—Removal and Installation
- Group 0401—Crankshaft and Main Bearings
- Group 0402—Camshaft and Valve Actuating Means
- Group 0403—Connecting Rods and Pistons
- Group 0404—Cylinder Block
- Group 0407—Oiling System
- Group 0408—Ventilating System
- Group 0409—Cylinder Head and Valves
- Group 0410—Exhaust Manifold

### SECTION 04—ENGINE—Continued

- Group 0413—Fuel Injection System
- Group 0414—Intake Manifold
- Group 0416—Turbocharger
- Group 0417—Water Pump
- Group 0418—Thermostats, Housing and Water Piping
- Group 0419—Oil Cooler
- Group 0420—Fuel Filter
- Group 0422—Starting Motor and Fastenings
- Group 0429—Fan Drive
- Group 0433—Flywheel, Housing and Fastenings

### SECTION 05—ENGINE AUXILIARY SYSTEMS

- Group 0505—Cold Weather Starting Aids
- Group 0510—Cooling Systems
- Group 0515—Speed Controls
- Group 0520—Intake System
- Group 0560—External Fuel Supply Systems

### SECTION 16—ELECTRICAL SYSTEMS

- Group 1671—Batteries, Support, and Cables
- Group 1672—Alternator, Regulator and Charging System Wiring
- Group 1674—Wiring Harness and Switches
- Group 1676—Instruments and Indicators

*All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice. Whenever applicable, specifications and design information are in accordance with SAE and ICED standards.*

Copyright© 1986  
DEERE & COMPANY  
Moline, Illinois  
All Rights Reserved  
A JOHN DEERE ILLUSTRATION  
Previous Edition  
Copyright© 1982 Deere & Company

T28;1263 09 130686

## SECTION AND GROUP CONTENTS—CONTINUED

### **SECTION 17—FRAME, CHASSIS, OR SUPPORTING STRUCTURE**

Group 1740—Frame Installation

Group 1749—Chassis Weights

### **SECTION 18—OPERATOR'S STATION**

Group 1810—Operator Enclosure

Group 1830—Heating and Air Conditioning

### **SECTION 19—SHEET METAL AND STYLING**

Group 1927—Fenders

### **SECTION 33—EXCAVATOR**

Group 3302—Buckets

Group 3340—Frames

Group 3360—Hydraulic System

### **SECTION 43—SWING, ROTATION OR PIVOTING SYSTEM**

Group 4311—Brakes

Group 4350—Mechanical Drive Elements

Group 3260—Hydraulic System

### **SECTION 90—SYSTEM TESTING**

Group 9005—General Information—Seven Basic  
Steps of Diagnosis and Testing

Group 9010—Engine

Group 9015—Electrical System

Group 9025—Hydraulic System

Group 9030—Miscellaneous Components

Group 9031—Heating and Air Conditioning

### **SECTION 99—SPECIAL TOOLS**

# INTRODUCTION AND SAFETY INFORMATION

## INTRODUCTION

This technical manual is part of a twin concept of service.

### FOS Manuals - for reference

### Technical Manuals - for actual service

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

*Fundamentals of Service (FOS) Manuals* cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

*Technical Manuals* are concise service guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed by an experienced service technician.



30A:T85958, T2&amp;I 1101, 130582

## FEATURES OF THIS TECHNICAL MANUAL

- John Deere ILLUSTRATION format emphasizing detailed pictures and fewer words in easy-to-use modules.
- Removal and installation groups preceding some repair groups.
- A section of system diagnostic testing.
- Table of contents of all sections at the front of the manual and a listing of all groups and headings at the front of each section.
- Special tools and specifications listed at the front of each group they are used in.
- Special tools illustrated in numerical order at end of manual.
- Alphabetical listing of all major components, specifications, and special tools.
- Safety rules, general specifications, and lubrication specifications.

This technical manual was planned and written for you - an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it when you need to know correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.



30A:T85959 T2&amp;I 1115 130582

**SAFETY AND YOU**




**CAUTION:** This safety symbol is used for important safety messages. When you see this symbol, follow the safety message to avoid personal injury.



30A:T81389 T28:1 1102 260881


Be prepared for an accident or fire.  
Know where the first aid kit and fire extinguisher are.  
Know how to use them.  
Know where to get help.



T27504N

30A:T27504 N T28:1 1103 260581

Wear safety equipment.



T73432

30A:T73432 T28:1 1104 260881

Wear fairly tight clothing.



T45672


30A:T45672 T28:1 1105 260581

*Introduction and Safety Information*



**CAUTION:** Escaping fluid under pressure can have sufficient force to penetrate the skin, causing serious injury. Before disconnecting lines, be sure connections are tight and lines, pipes and hoses are not damaged. Use a piece of cardboard or wood, rather than hands, to search for leaks.

If injured by escaping fluid, see a doctor at once. Serious infection or reaction can develop if proper medical treatment is not administered immediately.




30A:T80991 T28:1 1106 260881

**KEEP SHOP AND STORAGE AREA CLEAN**

Maintenance area should be well-ventilated.

Keep maintenance area clean and dry.

Store flammable materials in a cool and well-ventilated area out of reach of unauthorized personnel.



30A:T27508 N T28:1 1107 260881

Introduction and Safety Information

**FOLLOW SAFE WORKING CONDITIONS**

Do not work on the equipment unless you are approved to do so. Then be sure you know the correct procedure.

Do not work on equipment while it is being operated.

Keep hands away from moving parts.

When the engine is running, do not work on equipment unless the procedure is approved.

If you must work on the machine with the engine running, ALWAYS USE TWO service technicians. One must be at the controls. The other must be within sight of the operator.

Put a support under all raised equipment.


Park the machine across a slope, or use blocks to hold it in place.

Do not lift heavy parts by yourself. Use a hoist or jack.


**TAKE CARE! WATCH OUT FOR OTHER PEOPLE IN THE AREA.**

When you drill, grind or hammer metal, wear safety glasses.

X WRONG



RIGHT



30A.T32709 H, \*82412 T26: 1108 260881



### OBSERVE SERVICE PRECAUTIONS

Keep ALL equipment free of dirt and oil.

Clean oil, grease, mud, ice or snow from the operator's station, steps and hand rails.


Do not remove the radiator cap unless the engine is cool. First, loosen the cap slowly to the stop. Then release all pressure in the cooling system before you remove the cap.

Check the exhaust system regularly for leaks.

Release hydraulic pressure before you work on the hydraulic system. See page I-II-06.


When you check hydraulic pressure, be sure to use the correct test gauge.

Before you work on the fuel system, close the fuel shutoff valve.



30A782345 T30: 1109 091281

Do not work under a raised bucket. Lower the bucket to the ground, or put blocks under the bucket.



30A782343 T28: 1110 260881


### CHECK SAFETY EQUIPMENT ON MACHINE

All protective parts (shields, guards, ROPS, etc.) should be in good condition and fastened in place.

Check for leaks in all systems:

- Air intake system
- Engine oil system
- Hydraulic system
- Fuel system
- Cooling system


RIGHT



30A782323 T28: 1113 260881

### AVOID EXPLOSIONS OR FIRE

- Do not smoke while you fill the fuel tank.
- Do not smoke while you work with material that will start on fire easily.
- Stop the engine before you fill the fuel tank.
- Do not fill fuel tank if engine is hot.
- Do not use gasoline or diesel fuel for cleaning parts. Use solvents that will not start on fire.



30A762411 T281 1132 260861

### OBSERVE BATTERY PRECAUTIONS

- Do not put metal objects across terminals to check the battery charge.
- When you charge a battery, be sure there is enough ventilation.
- Keep sparks and flames away from batteries.
- Do not smoke near battery.
- Before you work on the electrical system, or make major repairs, turn off the battery disconnect switch.



30A727500 T281 1113 260861

### BEFORE YOU WORK ON THE HYDRAULIC SYSTEM


Follow these steps before you work on any part of the hydraulic system:

1. Park the excavator on level ground.
2. Lower hydraulic pressure:
  - Lower bucket to ground.
  - Stop engine.
  - Move control levers until boom and bucket do not move.
3. Push valve levers in all the way to stop oil flow.
4. Loosen the reservoir filler cap slowly to release pressure.
5. Open the diffuser vent. Turn it counterclockwise.

- IMPORTANT: After you finish:**
- Close diffuser vent.
  - Pull levers out.



**CAUTION: Do not walk or stand on sloping fenders or other sheet metal to service the excavator.**



30A782340 T281 1114 260861

## Group II GENERAL SPECIFICATIONS

### 890A EXCAVATOR

(Specifications and design subject to change without notice. Wherever applicable, specifications are in accordance with PCSA and SAE Standards. Except where otherwise noted, these specifications are based on a unit equipped with 107-in. (2.72 m) dipperstick, 39-in. (991 mm) bucket, 30-in. (750 mm) track shoes, and standard equipment.)

<b>Power (@2100 engine rpm):</b>	<b>SAE</b>	<b>DIN</b>
Gross .....	225 hp(168 kW)	
Net .....	210 hp(157 kW)	213 PS

Net engine flywheel power is for an engine equipped with fan, air cleaner, water pump, lubricating oil pump, alternator, and muffler. Gross engine power is without fan. Power ratings are under SAE standard conditions of 500-ft. (150 m) altitude and 85°F (29.5°C) temperature, and DIN 6270 conditions (non-corrected). No derating is required up to 10,000 ft. (3000 m) altitude.

**Engine:** John Deere turbocharged 6-cylinder, valve-in-head, 4-stroke cycle.

Bore and stroke	.... 5.12 x 5.00 in. (130 x 127 mm)
Piston displacement	..... 619 cu. in. (10.145 L)
Compression ratio	..... 15.2:1
Max. torque @ 1300 rpm	..... .810 lb-ft (1098 N·m) (112 kg-m)

Lubrication	..... Pressure system w/full-flow filter
Cooling	Pressurized w/thermostat and fixed bypass
Air cleaner w/restriction indicator	..... Dry
Electrical system	..... 24 volts w/alternator
Batteries (2) 12-volt	. Reserve capacity:180 minutes each

#### Hydraulic System:

Three open-center pumps mounted in line are coupled directly to the flywheel. The total flow is 163 gpm (10.3 L/s) at rated engine rpm. System operating pressure is 2900 psi (20 000 kPa)(204 kg/cm<sup>2</sup>) for the propel circuit and 2900 psi (20 000 kPa) (204 kg/cm<sup>2</sup>) for the digging circuit.

Relief valves:

Boom (2)	... 3260 psi (22 483 kPa) (229.3 kg/cm <sup>2</sup> )
Crowd (2)	... 3260 psi (22 483 kPa) (229.3 kg/cm <sup>2</sup> )
Bucket (2)	... 3260 psi (22 483 kPa) (229.3 kg/cm <sup>2</sup> )

Oil filtration:

- Two 149-micron suction screens
- Two 10-micron filters in return lines
- Three 25-micron high pressure filters

<b>Cylinders:</b>	<b>Bore</b>	<b>Stroke</b>
Boom (2)	.... 7.0 in. (178 mm)	62.87 in. (1597 mm)
Crowd	..... 7.0 in. (178 mm)	78.17 in. (1986 mm)
Bucket	..... 7.0 in. (178 mm)	40.51 in. (1029 mm)
Boom cylinder rods	..... 3.75 in. (95 mm dia.)	
Crowd and bucket cylinder rods	..... 4.50 in. (114 mm dia.)	

All cylinders have phenolic wear rings. Boom, crowd and bucket cylinders have a built-in hydraulic cushion at each end of the stroke. Full-width hydraulic oil cooler matched with engine coolant radiator.

#### Operating Information:

Swing speed	..... 6.1 rpm
Gradability	..... 70 percent
Travel	..... 0 to 2.2 mph (3.5 km/h)
Locked in low	..... 0 to 0.95 mph (1.5 km/h)
Optional track shoes	..... 36 in. (0.9 m)

#### Digging Information:

Bucket rating (SAE heaped)	..... 1½ yd. <sup>3</sup> (1.2 m <sup>3</sup> )
Lift capacity	..... 24,200 lb. (108 kN <sup>2</sup> ) at 20 ft. (6 m)
Bucket penetrating force	..... 38,160 lb. (170 kN)
Arm crowd force	..... 30,310 lb. (135 kN)
Maximum reach at ground level	.. 36.75 ft. (11.2 m)
Maximum dump height	..... 19.75 ft. (6 m)
Digging depth	..... 25 ft. (7.6 m)

## General Specifications

### Swing mechanism:

Swing ..... 360-degree, internal drive, continuous  
Turntable bearing ..... Single row, ball  
Case-hardened ring and pinion gears run in lubricant.

### Undercarriage:

Propel motors (one for each track) .... High-torque, variable-speed, axial-piston hydraulic motors with planetary drive. Multiple-disk brakes automatically release while propelling, and apply when stationary. Independent drive to each track permits counterrotation.

Undercarriage, car body, and track frame .... Each track frame is a formed, reinforced U-channel. Track frames are joined by reinforced boxed car body with swing bearing mount.

**Track Chain** ..... Sealed track chain

**Track Adjustment** ..... Hydraulic

**Buckets:** High-strength steel, ribbed and plated bottom section.

### Cab:

Steel, with urethane sound-proofing on ceiling and side walls, and cushioned neoprene floor mat. Safety glass on all sides and top. Front and rear windows open. Front window can be stored overhead.

### Seat:

Fully adjustable heavy-duty cloth, foam-rubber cushioned seat.

### Controls:

Pilot-operated two-lever for boom, crowd, bucket, and swing. Pilot-operated right and left pedals control forward and rearward movement of right and left tracks respectively.

Nominal Width	Bite Width	Capacity		Weight
		SAE	Struck	
39 in. (991 mm)	42 in. (1067 mm)	1½ cu. yd. (1.15 m³)	1¼ cu. yd. (0.96 m³)	2550 lb. (1157 kg)
45 in. (1143 mm)	47 in. (1194 mm)	1¾ cu. yd. (1.43 m³)	1½ cu. yd. (1.15 m³)	2670 lb. (1211 kg)
51 in. (1295 mm)	54 in. (1372 mm)	2¼ cu. yd. (1.62 m³)	1¾ cu. yd. (1.34 m³)	2820 lb. (1279 kg)
<b>Heavy-duty</b>				
33 in. (838 mm)	37 in. (940 mm)	1½ cu. yd. (1.15 m³)	1¼ cu. yd. (0.96 m³)	3050 lb. (1383 kg)
39 in. (991 mm)	44 in. (1118 mm)	1¾ cu. yd. (1.43 m³)	1½ cu. yd. (1.15 m³)	3575 lb. (1622 kg)
45 in. (1143 mm)	50 in. (1270 mm)	2 cu. yd. (1.53 m³)	1½ cu. yd. (1.15 m³)	3660 lb. (1660 kg)

### Track Shoes:

Width	Shoes	Ground Contact	Ground Pressure
30 in. (750 mm)	Triple-bar semigrouzers	9723 sq. in. (62 731 cm²)	8.92 psi (61.5 kPa) (0.63 kg/cm²)
36 in. (900 mm) (optional)	Triple-bar semigrouzers	11,668 sq. in. (75 278 cm²)	7.74 psi (53.4 kPa) (0.54 kg/cm²)

## General Specifications

### Boom and Arm

Internally reinforced tapered box construction with heat-treated steel bushings. Machined and bored after welding for accurate alignment. All pivot points are sealed to allow extended lubrication intervals.

### Servicing and Vandal Protection:

Swingaway service doors expose built-in platforms for easy access to engine and hydraulic systems. Cab and access covers to fuel tank, radiator, and hydraulic reservoir lock with switch key.

<b>Capacities:</b>	<b>U.S.</b>	<b>Imp.</b>	<b>Liters</b>
Fuel tank .....	140 gal.	117 gal.	530
Cooling system .....	16 gal.	13.3 gal.	61
Engine lubrication, including filter .....	32 qt.	26.7 qt.	30.3
Hydraulic system .....	165 gal.	137 gal.	625
Planetary propel drive (each) .....	21 qt.	17.5 qt.	20.0
Swing drive (each) .....	8 qt.	6.7 qt.	7.5

### Operating Weights (without bucket)

	<b>lb.</b>	<b>(kg)</b>
Total weight—with narrow track .....	85,059	(38 598)
—with wide track .....	88,650	(40 210)
Boom .....	7,450	(3 380)
Arm—108 in. (2.7 m) .....	5,080	(2 300)
—140 in. (3.6 m) .....	5,490	(2 490)
Main Counterweight .....	12,810	(5 810)
Auxiliary Counterweight .....	3,050	(1 380)


### Additional Standard Equipment:

Electric hour meter  
 Alternator charge indicator light  
 Hydraulic oil filter pressure warning light  
 Engine overheating warning light  
 Gauges (internal illuminated):  
     Engine coolant temperature  
     Hydraulic oil temperature  
     Engine oil pressure  
     Fuel  
 Key switch  
 Cold weather starting aid  
 Horn  
 Positive-position hand throttle  
 12,810 lb. (5 810 kg) counterweight  
 Counterweight removal system  
 Track guides  
 Cab with heater  
 Floor mat  
 Lifting hook  
 Tinted roof window

### Special Equipment:


36-in. (900 mm) triple-bar semigrouser shoes  
 Bucket side cutters  
 Fire extinguisher  
 Engine water heater  
 Window protection group  
 Air conditioner  
 Auxiliary counterweight—3,050 lb. (1 380 kg)  
 Two electric cab fans  
 Vandal protection

# General Specifications



## Digging Depth and Reach:

- 140 in. (3.56 m) arm
- 107 in. (2.72 m) arm



30A-T85057, T86161 T281 1108 240382

**CAP SCREW TORQUE VALUES****CUSTOMARY TORQUE SPECIFICATIONS**

NOTE: Wrench torque tolerance is  $\pm 10\%$ .

Cap Screw in.	Plain Head*		Three Dashes*		Six Dashes*	
	(lb-ft.)	N-m	(lb-ft.)	N-m	(lb-ft.)	N-m
1/4	-----	-----	(10)	14	(14)	19
5/16	-----	-----	(20)	27	(30)	41
3/8	-----	-----	(35)	47	(50)	68
7/16	(35)	47	(55)	75	(80)	108
1/2	(55)	75	(85)	115	(120)	163
9/16	(75)	102	(130)	176	(175)	237
5/8	(105)	142	(170)	230	(240)	325
3/4	(185)	251	(300)	407	(425)	576
7/8	(160)	217	(445)	603	(685)	929
1	(250)	339	(670)	908	(1030)	1396
1-1/8	(330)	447	(910)	1234	(1460)	1979
1-1/4	(480)	651	(1250)	1695	(2060)	2793

All torques are dry torque unless noted.

\*Dashes identify the grade of hardware.

T28:1 III04 170582

**METRIC TORQUE SPECIFICATIONS**

NOTE: Wrench torque tolerance is  $\pm 10\%$ .

Cap Screw Diameter	Property Class 8.8*		Property Class 10.9*	
	(lb-ft)	N-m	(lb-ft)	N-m
M5	(4.4)	6.0	(6.3)	8.5
M6	(7.4)	10.0	(10.7)	14.5
M8	(18.1)	24.5	(25.8)	35.0
M10	(36.1)	49.0	(51.6)	70.0
M12	(62.7)	85.0	(89.2)	121.0
M16	(154.9)	210.0	(221.2)	300.0
M20	(265.5)	360.0	(368.7)	500.0
M24	(457.2)	620.0	(634.2)	860.0
M30	(885.0)	1200.0	(1224.2)	1660.0
M36	(1541.3)	2090.0		

All torques are dry torque unless noted.

\*Numbers identify the grade of hardware.

T28:1 III10 140582

*Cap Screw Torque Values*



## GENERAL INFORMATION

When you service the excavator, check the periodic service chart inside the left, front fender. A copy of this chart is below. The 890A Operator's Manual has details for excavator service.

### PERIODIC SERVICES

REFER TO OPERATOR'S MANUAL FOR MORE DETAILED INFORMATION

INTERVAL HOURS	ITEM NO.	COMPONENTS	SERVICE POINTS	DESCRIPTION OF SERVICE	CAPACITY OR MEASUREMENT	APPROVED SERVICE MATERIAL
10 OR DAILY	1	RADIATOR	1	CHECK COOLANT LEVEL	BOTTOM OF TUBE IN WICK	ANTI-FREEZE OR BURNER COOLANT JO-HO UNICOL OR EQUIVALENT
	2	HYDRAULIC RESERVOIR	1	CHECK OIL LEVEL	BOTTOM OF WINDOW WITH CYLINDER PLUNGER EXTENDED	SEE CHART BELOW
	3	ENGINE CRANKCASE	1	CHECK OIL LEVEL	TOP MARK ON DIPSTICK	SEE CHART BELOW
	4	AIR CLEANER	1	CHECK RESTRICTION INDICATOR	TOP MARK ON DIPSTICK	JO FILTERS
50	5	BUCKET CYLINDER HEAD	1	GREASE FITTING	2 SHOTS	SAE MFC
	6	BUCKET LINKAGE	8	GREASE FITTINGS	2 SHOTS	SAE MFC
	7	ROOM TO MAIN FRAME PIN	1	GREASE FITTINGS	1 SHOTS	SAE MFC
	8	ROOM CYLINDER HEADS	2	GREASE FITTINGS	1 SHOTS	SAE MFC
	9	ROOM CYLINDER HEADS	2	GREASE FITTINGS	1 SHOTS	SAE MFC
	10	ROOM CYLINDER HEADS	2	GREASE FITTINGS	1 SHOTS	SAE MFC
	11	ROOM CYLINDER HEADS	2	GREASE FITTINGS	1 SHOTS	SAE MFC
100	12	HYDRAULIC RESERVOIR	1	CHECK OIL LEVEL	BOTTOM OF CHECK HOLE	TEROSOL OR SOLVENT JO-HO UNICOL OR EQUIVALENT
	13	SWING GEARBOXES	2	CHECK OIL LEVEL	BOTTOM OF CHECK HOLE	JO DEAR GUARD OR EQUIVALENT
	14	TRACKS	2	CHECK TENSION	3/4 IN. (19 mm) - 1 1/2 IN. (38 mm) NO. 1 (NO. 10 BELT) TENSION	
200	15	ENGINE CRANKCASE**	1	DRAIN AND REFILL	40 QT (38L)	SEE CHART BELOW
	16	HYDRAULIC RESERVOIR	1	DRAIN AND REFILL	87 GAL (326 L) RESERVOIR (200 GAL (757 L) TOTAL)	JO-HO UNICOL OR EQUIVALENT
	17	TRACK GEARBOXES	2	DRAIN AND REFILL	4 QT (3.8 L)	JO DEAR GUARD OR EQUIVALENT
	18	HYDRAULIC OIL RETURN FILTERS***	4	REPLACE ELEMENT		JO FILTERS
	19	HYDRAULIC OIL HIGH PRESSURE FILTERS***	3	REPLACE ELEMENT		JO FILTERS
	20	HYDRAULIC OIL PILOT CONTROL FILTER	1	REPLACE ELEMENT		JO FILTER
	21	ENGINE COOLANT FILTER****	1	REPLACE CONDITIONER FILTER		JO CONDITIONER FILTER
	22	FUEL TANK PUMP	1	DRAIN WATER AND SEDIMENT		
	23	AIR CLEANER HOSE GAPPING & FALLS*****	1	CHECK HOSE AND CONNECTIONS		JO CONDITIONER FILTER
	24	COOLING SYSTEM	1	DRAIN, FLUSH AND REFILL WITH ANTI-FREEZE OR WATER. REPLACE CONDENSER COOLANT FILTER		JO CONDITIONER FILTER
500	25	FUEL FILTERS	2	REPLACE ELEMENTS	4 SHOTS EACH	JO FILTERS
	26	SWING GEARBOX	2	REPLACE ELEMENTS	20 LB (9 kg)	SAE 10W-30
	27	SWING GEARBOX	2	REPLACE ELEMENTS	20 LB (9 kg)	SAE 10W-30
	28	TRACK ACCUMULATORS	2	DRAIN AND REFILL	4 QT (3.8 L)	JO DEAR GUARD OR EQUIVALENT
1000	29	AIR CLEANER	1	REPLACE ELEMENTS	31 QT (30 L)	JO FILTERS
	30	TRACK GEARBOXES	2	DRAIN AND REFILL	4 QT (3.8 L)	JO DEAR GUARD OR EQUIVALENT
	31	HYDRAULIC RESERVOIR	1	DRAIN, FLUSH, CLEAN, DIPSTICK SENSORS AND REFILL	87 GAL (326 L) RESERVOIR (200 GAL (757 L) TOTAL)	JO-HO UNICOL OR EQUIVALENT
	32	ENGINE CRANKCASE VENT TUBE	1	REMOVE AND CLEAN		
	33	ENGINE VALVE LASH	16	CHECK AND ADJUST. SEE JO DEALER		
	34	ENGINE SPEED	1	CHECK AND ADJUST. SEE JO DEALER		
	35	CABLE PULLEY BATTERIES	2	GREASE FITTINGS	2 SHOTS	SAE MFC
	36	CABLE PULLEY BATTERIES	4	ADD WATER AND CHECK TERMINALS		DEIONIZED WATER
	37	CAR AIR FILTERS	2	CLEAN OR REPLACE ELEMENTS		JO FILTERS
	<p>*** SEE HOW TO CLEAN IN 1.300C            ** DRAIN WATER FROM GREASE SUMP WHEN NO WATER ABOVE TRACKS            *** MEASURE BETWEEN CENTER ROLLER AND CHAIN            **** CHANGE FILTERS AFTER FIRST 50 HOURS AND 50 HOURS AFTER EACH            MAJOR HYDRAULIC SYSTEM REPAIR            ***** CHANGE OIL AND FILTERS AFTER FIRST 100 ENGINE HOURS            ***** SEE OPERATOR'S MANUAL FOR ADJUSTING BELT TENSION            ***** CHANGE OIL FILTER AFTER FIRST 100 HOURS OF COOLANT CHANGE</p>					

ENGINE OIL			
AIR TEMP	JOHN DEERE SUFFRICE OIL	SINGLE VISCOUSITY OIL SAE SERVICE CD/SC	MULTI- VISCOUSITY OIL SAE SERVICE CODE
ABOVE 137°F (58°C)	SAE 30	SAE 30	NOT RECOMMENDED
37°F TO 107°F (3°C TO 42°C)	SAE 15W 30	SAE 15W 30	SAE 15W 30
BELOW 37°F (3°C)	SAE 10W 30	SAE 10W 30	SAE 10W 30

TRACK ACCUMULATOR	
AIR TEMP	DRY NITROGEN PRESSURE
ABOVE 107°F (42°C)	150 PSI (10.34 BAR)
0° TO 87°F (-18°C TO 31°C)	100 PSI (7.03 BAR)
BELOW 0°F (-18°C)	150 PSI (10.34 BAR)

## Lubrication

### Engine Oils

Use John Deere TORQ-GARD SUPREME® engine oil in the engine crankcase.

Use John Deere TORQ-GARD SUPREME SAE 10W-20 oil or equivalent during the first 100 hours of operation for break-in.

Oils other than John Deere TORQ-GARD SUPREME must have one of the following specifications:

#### Single Viscosity Oils

API Service CD/SC  
MIL-L-2104C  
Series 3

#### Multi-Viscosity Oils

API Service CC/SE  
MIL-L-46152

### Oils and Air Temperature

SAE ENGINE OILS			
Air Temperature	John Deere TORQ-GARD SUPREME Oil	Other Oils	
		Single Viscosity Oil	Multi-Viscosity Oil
Above 32°F (0°C)	30	30	Not recommended.
32°F to -10°F (0°C to -23°C)	10W-20	10W	10W-30
Below -10°F (-23°C)	5W-20	5W	5W-20

If you use SAE 5W-20 or SAE 5W oil, your engine may use more oil. Check the oil level often.

### Storing and Handling Lubricants

Store lubricants in clean containers in an area protected from dust, moisture, and other contamination.

When you handle lubricants, use clean containers.

### Hydraulic Oils

If you operate excavator at air temperatures above -13°F (25°C), use John Deere Hydraulic Oil (J14C) or equivalent.

For air temperatures between -31°F (-35°C) and 77°F (25°C), use SAE 5W-20 engine oil, CC/SE, MIL-L-46152.

*NOTE: See your John Deere dealer for special arctic lubricants.*

### Track Rollers and Idlers, Swing and Track Gearboxes

Use a multi-purpose GL-5 gear oil, SAE 80W-90, MIL-L-2105C.

### Greases

Use John Deere Multi-Purpose Grease or an equivalent for all grease fittings except where noted.

### Swing Bearing

Use Shell Alvania EP-2 or one of the following or an equivalent:

- Sunoco 742 EP grease
- Esso Unirex EP2 grease
- American Amolith 2EP grease
- Conoco Super Stay Conolith EP2 grease
- Gulf Crown EP2 grease
- Mobil Mobilux EP2 grease
- Phillips Philube EP2 grease
- Texaco Multifax EP2 grease
- Standard Dura-Lith EP2 grease

### Swinging Gear

Use Texaco Texclad 2 or equivalent.

# Section 01 TRACKS

## CONTENTS

### GROUP 0130 - TRACK SYSTEMS

Special Tools .....	0130-01
Guide Specifications .....	0130-01
Guide and Slide Specification .....	0130-02
Roller Specifications .....	0130-02
Track Shoe Specifications .....	0130-03
Track Chain Specifications .....	0130-03
Sprocket Specification .....	0130-05
Idler Specification .....	0130-05
Track Adjuster Specifications .....	0130-05
Accumulator Specifications .....	0130-06
Remove and Install Track Guides .....	0130-08
Remove and Install Track Guides and Slides .....	0130-09
Measure Roller Wear .....	0130-11
Remove Track Rollers .....	0130-11
Disassemble Track Roller .....	0130-12
Inspect Metal Face Seals .....	0130-14
Cross Section of Track Roller .....	0130-17
Assemble Track Roller .....	0130-18
Install Metal Face Seals to Assemble Track Rollers .....	0130-19
Test Track Roller for Oil Leakage .....	0130-24
Install Track Rollers .....	0130-24
Measure Grouser Wear .....	0130-25
Remove and Install Track Shoes .....	0130-26
Measure Track Link for Wear .....	0130-27
Measure Bushing for Wear .....	0130-28
Measure Track Pitch .....	0130-28

### GROUP 0130 - TRACK SYSTEMS - Continued

Remove Track Chain .....	0130-29
Disassemble Track Chain .....	0130-32
Assemble Track Chain .....	0130-34
Install Track Chain .....	0130-38
Adjust Track Chain Tension .....	0130-42
Remove and Install Sprocket .....	0130-43
Measure Front Idler Wear .....	0130-44
Remove Idler .....	0130-45
Disassemble Idler .....	0130-46
Inspect Metal Face Seals .....	0130-47
Cross Section of Idler .....	0130-51
Assemble Idler .....	0130-52
Install Metal Face Seals to Assemble Idler .....	0130-52
Test Idler for Oil Leakage .....	0130-57
Install Front Idler .....	0130-57
Remove Track Adjuster .....	0130-59
Disassemble Track Adjuster .....	0130-59
Cross Section of Track Adjuster .....	0130-62
Assemble Track Adjuster .....	0130-63
Install Track Adjuster .....	0130-65
Adjust Track Adjuster Relief Valve .....	0130-67
Remove Accumulator .....	0130-71
Disassemble Accumulator .....	0130-73
Cross Section of Accumulator .....	0130-80
Assemble Accumulator .....	0130-81
Charge Accumulator .....	0130-86
Accumulator Leakage Test .....	0130-89
Install Accumulator .....	0130-90



**SPECIAL TOOLS**


*NOTE: Order tools from your SERVICE-GARD™ Catalog, unless otherwise indicated.*

<b>Number</b>	<b>Name</b>	<b>Use</b>
D-01031AA	200-Ton Track Press	Disassemble and assemble track chain.
D-01043AA	Load Positioning Sling	Used With Master Pin Pusher to remove master pin.
D-01047AA	17½ and 30-Ton Puller Set	Remove and install bushings, seals and roller end brackets.
D-01063AA	100-Ton Master Pin Pusher	Remove and install master pin.
D-01065AA	Tooling Set for 200-Ton Track Press	Disassemble and assemble track chain.
D-01087AA	Master Accessory Kit for Hydraulic Analyzer	Fittings for adjusting track adjuster relief valve.
D-01168AA	Spring Compression Tester	Test track adjuster relief valve spring.
D-01182AA	20-Ton Floor Stands	Supports the unit.
D-05227ST	Undercarriage Inspection Service Tool	Measure wear on undercarriage components.
D-15028NU	Universal Pressure Test Kit	Test oil leakage of roller and idler.
D-15041NU	Nitrogen Accumulator Charging Kit	To charge accumulator.
JD-342	Idler Bushing Plate	Remove and install bushings in rollers and idlers.
JD-345	Zerk Adapter	To adjust track adjuster relief valve.
JDG-69	Nitrogen Accumulator Holding Tool	Remove and install accumulator.
JDG-127	O-Ring Seal Tool Set	To remove O-rings.
JDG-206	Seal Installation Tool	To install metal face seals.

T28:0130 86 090382

**GUIDE SPECIFICATIONS**


Cap screws torque .....(407 N·m) 300 lb-ft



31A:782826 T28:0130 206 121081

Track Systems


2. Cap screws torque .....(908 N·m) 670 lb-ft



31A782825 T28:0130 207 321083

**GUIDE AND SLIDE SPECIFICATION**


Cap screws torque .....(325 N·m) 240 lb-ft



31A782829 T28:0130 208 321081


**ROLLER SPECIFICATIONS**

1. Outside contact surface of  
new roller .....185 mm (7.28 in.)  
Minimum roller outside surface .....175 mm (6.88 in.)



31A782830 T28:0130 209 321081


2. Cap screws torque .....(576 N·m) 425 lb-ft



31A782830 T28:0130 210 321081

## Track Systems


3. Gap between roller bracket and inside of track frame ..... (0.25 mm) 0.010 in.



31A:T82513 T28:0130 211 121081

### TRACK SHOE SPECIFICATIONS

1. Grouser bar height of new shoe ..... (26.5 mm) 1.04 in.  
 Minimum grouser bar height ..... (12.5 mm) 0.49 in.



31A:T82859 T28:0130 212 121081


2. Track shoe cap screws torque (lubricated) ..... (300 ± 30 N·m) 220 ± 22 lb-ft plus an additional 1/3 turn.  
 After 75 hours of operation ..... (569 N·m) 420 lb-ft minimum



31A:T83569 T28:0130 213 121081

### TRACK CHAIN SPECIFICATIONS


1. Track link height of new chain ..... (125.5 mm) 4.94 in.  
 Minimum link height ..... (114.3 mm) 4.50 in.



31A:T82864 T28:0130 214 121081


Track Systems

- 2. Track bushing outer surface (new bushing) ..... (71.4 mm) 2.81 in.
- Minimum bushing outer surface before turning bushings ..... (68.3 mm) 2.69 in.




31A-T82865 T28-0130 215 121081

- 3. Track pitch of new chain (A) ..... (864.8 mm) 34.05 in.
- Maximum track pitch before turning pins and bushings ..... (877.5 mm) 34.55 in.



31A-T80866 T28-0130 216 121081

- 4. Track tension sag (A) ..... (76 to 127 mm) 3.00 to 5.00 in.




31A-T82919 T28-0130 217 121081



### SPROCKET SPECIFICATION


Cap screws torque ..... (929 ± 93 N·m)  
685 ± 68 lb-ft



31A782561 T28:0130 218 121061

### IDLER SPECIFICATION


Flange height of new idler ..... (23.0 mm)  
0.91 in.  
Maximum flange height ..... (32.8 mm)  
1.29 in.



31A782910 T28:0130 219 121061

### TRACK ADJUSTER SPECIFICATIONS


1. Plug torque ..... (81 ± 8 N·m)  
60 ± 6 lb-ft



31A782555 T28:0130 220 090362


Track Systems

2. Track adjuster relief valve spring  
free length ..... (46.33 ± 0.25 mm)  
1.824 ± 0.010 in.  
Test length at (387 ± 20 N ..... 38.56 mm)  
87 ± 4.4 lb. force ..... 1.518 in.



31A:T83550 T28:0130 221 131081


3. Cap screws torque ..... (407 N-m)  
300 lb-ft



31A:T83551 T28:0130 222 131081

**ACCUMULATOR SPECIFICATIONS**

1. Socket head cap screws torque ..... (88 ± 7 N-m)  
65 ± 5 lb-ft



31A:T82994 T28:0130 223 131081

2. Valve torque ..... (68 N-m) 50 lb-ft



31A:T83005 T28:0130 224 131081

Track Systems

3. Cap screws torque .....(407 N·m) 300 lb-ft




31A:T83C07 T28:0130 225 131081




**CAUTION:** When charging accumulator, use extreme handling care and proper equipment. Follow the steps for charging accumulator used in this group.

4. The accumulator is charged with dry nitrogen gas to  $(8618 \pm 172 \text{ kPa})$   $(86 \pm 1.7 \text{ bar})$   $1250 \pm 25 \text{ psi}$  at  $(20^\circ\text{C})$   $68^\circ\text{F}$ .



31A:T83C06 T28:0130 226 090382

5. Minimum piston extension (C) after track chain tension is properly adjusted .....  $(47.5 \text{ mm})$   
1.87 in.




A—Accumulator Piston  
B—Accumulator Cylinder  
C— $(47.5 \text{ mm})$  1.87 in. Minimum

31A:T83349 T28:0130 257 131081

## Track Systems


### REMOVE AND INSTALL TRACK GUIDES

1. Lower bucket to the ground.
2. Stop the engine.
3. Remove four cap screws, two on each side of track frame.




31A:T62616 T28:0130 69 180981

4. Remove eight cap screws, four on each side of track frame.




31A:T62621 T28:0130 70 180981

5. Remove inner and outer guides.



31A:T62622 T28:0130 71 180981


6. Remove two spacers.
7. Inspect parts for wear or damage; replace if necessary.



31A:T62623 T28:0130 72 180981


## Track Systems

8. Install spacers, guides, cap screws, and lock washers. Tighten eight cap screws to (407 N-m) 300 lb-ft.



31A:T82824 T31:0130 73 180981

9. Install and tighten four cap screws and lock washers to (908 N-m) 670 lb-ft.




31A:T82825 T28:0130 74 180981

### REMOVE AND INSTALL TRACK GUIDES AND SLIDES

1. Turn upper structure to obtain maximum clearance over the guide and slide to be removed.
2. Lower bucket to the ground.
3. Stop the engine.

**⚠ CAUTION: Grease in track adjuster is under extreme pressure.**


4. Turn ball check valve assembly (A) one to three turns counterclockwise to release track tension. DO NOT turn grease fitting to release track tension.



31A:T82685 T28:0130 75 180981


## Track Systems

5. Lift track with chain and hoist.
6. Put blocks under track chain.




31A-T82826 T28:0130 76 180981

7. Remove two cap screws.




31A-T82827 T31:0130 77 180981

8. Remove middle block
9. Remove guide (A), two washers (B), and slide (C).
10. Inspect guide and slide for wear or damage; replace if necessary. Slide must be replaced when track chain bushings start to touch guide.



31A-T82828 T28:0130 78 180981

11. Install slide, washers, and guides.
12. Install cap screws and lock washers. Tighten cap screws to (325 N·m) 240 lb-ft.
13. Remove blocks.
14. Adjust track tension.




31A-T82829 T28:0130 79 180981

### MEASURE ROLLER WEAR

1. Use D-05229ST (3048 mm) 12 in. Spring Caliper from D-052275T Undercarriage Inspection Service Tool Kit to measure track roller tread diameter.
2. Put the caliper around each roller on the tread surface and record each measurement. Roller tread diameter of a new roller is 185 mm (7.28 in.). Minimum recommended roller diameter is 175 mm (6.88 in.).
3. Under some conditions, roller wear is uneven. If this condition exists, the rollers may be exchanged with other rollers providing the sequence of single and double flanges are not changed.


*NOTE: For additional information on measuring track roller tread diameter, see the UNDERCARRIAGE APPRAISAL MANUAL SP-236.*



31A782830 T28:0130 80 180981

### REMOVE TRACK ROLLERS

1. Lower bucket to the ground.
2. Stop the engine.
3. Remove two cap screws to remove track adjuster cover on side of unit from which rollers are to be removed.




31A782831 T28:0130 81 180981



**CAUTION: Grease in track adjuster is under extreme pressure.**

4. Turn ball check valve assembly (A) one to three turns counterclockwise to release track tension. **DO NOT** turn grease fitting to release track tension.




31A782885 T28:0130 82 180981

## Track Systems

5. Remove four cap screws for each roller to be removed.

*NOTE: To remove rollers inside guides, the guides must be removed first.*




31A:T82832 T28:0130 83 180981

6. Lift side of unit high enough to permit roller removal.

7. Install blocks.

**⚠ CAUTION: Each roller weighs approximately (54.4 kg) 120 lb.**

8. Remove roller.



31A:T82833 T28:0130 84 180981

### DISASSEMBLE TRACK ROLLER

The only difference between single and double flange rollers is the roller shell. Disassembly and assembly for each is the same. All roller parts are metric in design.

1. Remove plug using a 6 mm hex wrench to drain oil from roller.




31A:T82834 T28:0130 85 180981




Track Systems

2. Remove spring pin from each end cap bracket.



31A:T82855 T28:0130 87 180981

3. Use bearing puller and hydraulic ram from D-01047AA 17½ and 30-Ton Puller Set to remove both end cap brackets.




A—D-01218AA 17½-Ton Hydraulic Ram  
B—D-01243AA Bearing Puller  
C—End Cap Bracket

31A:T82836 T28:0130 88 180981


**IMPORTANT:** The metal seal rings can be reused if they are not worn. Metal seal rings are to be kept in matched sets to protect the sealing face. Use tape to hold the two used seal rings together.

4. Remove metal seal ring from roller shell.



31A:T82837 T28:0130 89 180981

5. Remove O-ring from roller shell.




31A:T82838 T28:0130 90 180981

Track Systems

6. Remove metal face seal ring (A) and O-ring (B) from end cap bracket.

7. Use tape to hold metal face seal rings together to keep seal rings in original matched sets.

8. Remove metal face seal rings and O-rings from opposite side of roller and other end cap bracket. Use tape to hold metal face seal rings together.




31A:T82839 T28:0130 91 180981

**INSPECT METAL FACE SEALS**

1. Clean metal sealing rings as follows:

a. Remove any corrosion or hardened material that may exist on the metal ring OTHER than the sealing area (A). Use a scraper and/or any stiff bristled fiber brush to remove foreign material.

b. Wash the metal sealing rings with a volatile, non-petroleum base solvent to remove all oil and wipe dry. Use a lint free cloth to remove all traces of oil or grease from all surfaces.





31A:T82840 T28:0130 92 180981

2. To decide if a sealing ring can be reused, the following three conditions must be met:

a. The narrow, highly polished sealing area (E) must be within outer half of the sealing face (D).

b. The sealing area (E) must be uniform and concentric with the inside surface and outside surface of metal seal ring (A).

c. The sealing area (E) must not be chipped, nicked or scratched in any way.



A—Metal Seal Ring  
B—Worn Area  
(shaded portion)  
C—Seal Face

D—Outer Half of  
Sealing Face  
E—Sealing Area  
(dark line)

31A:T85079 T28:0130 93 090382

## Track Systems


3. The two drawings show examples of poor metal seal rings.

Drawing I shows the sealing area (D) within inner half of sealing face.

Drawing II shows the sealing area (D) not concentric with inside and outside surfaces of metal seal ring (A).

A—Metal Seal Ring  
B—Worn Area  
    (shaded portion)


C—Inner Half of  
  Sealing Face  
D—Sealing Area  
    (dark line)



31A:765080 T26:0130 94 090382


### CONTINUE TO DISASSEMBLE TRACK ROLLER

1. Use a pick from JDG-127 O-ring Seal Tool Set to remove O-ring from each end of shaft.
2. Remove shaft.



31A:762841 T26:0130 95 280961

## Track Systems



A—Roller  
B—Bushings (2 used)

C—JD-342 Idler Bushing Plate  
D—5/8 in.-18 Nut


E—D-01303AA Pulling Shaft  
F—D-01267AA Bearing Puller Attachment

G—D-1219AA Hydraulic Ram

3. Install JD-342 Idler Bushing Plate (C) under bushing (B) as shown.
4. Put threaded pulling shaft (E) from D-01241AA Internal Puller through bushing plate (C) and fasten with nut (D).
5. Install hydraulic ram (G) and bearing puller attachment (F) from D-01047AA 17½ and 30-Ton Puller Set on top of roller in pulling position. Connect ram to pulling shaft.
6. Apply pressure until bushing is removed.
7. Turn roller over and repeat above steps to remove other bushing.
8. Inspect roller, bushings, shaft, and brackets for wear or damage; replace if necessary.

31A-TR2681 Y28-0130 06 180981

CROSS SECTION OF TRACK ROLLER



1—Spring Pin (2 used)  
2—End Cap Bracket  
(2 used)


3—O-ring (4 used)  
4—O-ring (2 used)

5—Bushing (2 used)  
6—Shaft  
7—Plug

8—O-ring  
9—Roller  
10—Metal Face Seal (4 used)

31A782519 T28:0130 97 180981

**ASSEMBLE TRACK ROLLER**



A—Roller	C—JD-342 Idler Bushing Plate	E—D-01303AA Pulling Shaft	G—D-1219AA Hydraulic Ram
B—Bushings (2 used)	D—5/8 in.-18 Nut	F—D-01267AA Bearing Puller Attachment	


1. Install JD-342 Idler Bushing Plate (C) under bushing (B).
2. Put pulling shaft (E) through bushing plate (C). Install nut (D).
3. Install hydraulic ram (G) and bearing puller attachment (F) from D-01047AA 17½ and 30-Ton Puller Set on top of roller in pulling position. Connect ram to pulling shaft.
4. Apply pressure to ram until bushing is tight against its shoulder.
5. Turn roller over and repeat above steps to install other bushing.

Track Systems

**INSTALL METAL FACE SEALS TO ASSEMBLE TRACK ROLLERS**

**IMPORTANT:** Metal face seal bores in roller and end cap brackets must be clean, dry and oil free.

1. Remove all dirt, oil and grease from seal bores in roller shell and end cap brackets. Use a wire brush to remove any rust and dirt.




31A:T82842 T28:0130 99 180981

2. Put a new O-ring on each metal seal ring.



31A:T85439 T28:0130 100 090382

3. Install JDG-206 Seal Installation Tool between metal seal ring (A) and O-ring (B).




31A:T85440 T28:0130 250 090382

Track Systems


**NOTE:** To aid seal installation, a volatile non-petroleum base solvent may be placed on rubber seal O-ring (B) and the seal bore retainer lip (C). The solvent **MUST NOT** damage the rubber seal O-ring or leave an oil residue on seal or seal bore.

4. Push metal seal ring and O-ring into roller. After O-ring is pushed past retainer lip (C), turn the installation tool clockwise and counterclockwise to seat O-ring uniformly. Remove installation tool.




A—Metal Face Seal Ring  
B—Rubber Seal O-Ring

C—Retainer Lip  
D—Roller  
E—JDG-206 Seal Installation Tool




31A;T85441; T85442 T28:0130 101 180981

5. Install the other half of the metal seal ring and O-ring in end cap bracket using the same procedure as for the roller.



A—Metal Face Seal Ring  
B—Rubber Seal O-Ring  
C—Retainer Lip

D—End Cap Bracket  
E—JDG-206 Seal Installation Tool




31A;T85443; T85444 T28:0130 102 090382



## Track Systems

6. Make sure the metal seal rings fit square in seal bores. Be sure that distance A, between the top of the metal seal ring and the O-Ring, is uniform around the entire circumference for both seal halves.


7. Install second set of metal face seals in other side of roller and other end cap bracket using above procedures.



31A:782846 T28:0130 103 090382

8. Remove finger prints and foreign material from seal faces with a lint-free tissue.

9. Apply a thin film of oil on each metal sealing face. DO NOT allow any oil on rubber seal O-rings.



31A:782847 T28:0130 104 090382

### CONTINUE TO ASSEMBLE TRACK ROLLER

1. Put petroleum jelly on O-rings. Install O-rings on each end of roller shaft.



31A:782848 T28:0130 105 180981


2. Apply a thin coat of multi-purpose grease in roller shaft bore of both end cap brackets.



31A:782849 T28:0130 106 180981


Track Systems

3. Install roller shaft in end cap bracket. Make sure the flat portion (A) on shaft is toward flat surface (B) on bracket. DO NOT damage O-ring.



31A-T82850 T28:0130 107 180981


4. Put John Deere NEVER-SEEZ® or an equivalent on spring pin. Install spring pin through end cap bracket and shaft.



*NEVER-SEEZ is a trademark of the Never-Seez Compound Corp.*

31A-T82851 T28:0130 108 180981


5. Apply a thin film of oil to roller bushings.  
6. Install shaft and bracket assembly into roller.



31A-T82852 T28:0130 109 180981

## Track Systems

7. Install end cap bracket on shaft. Use a pry bar to align holes.




31A:T82853 T28:0130 110 180981

8. Put John Deere NEVER-SEEZ or an equivalent on spring pin. Install spring pin through end cap bracket and shaft.



31A:T82854 T28:0130 111 180981

9. With oil fill hole 10 to 40° from horizontal, fill roller with recommended oil until oil flows out of fill hole. (See Section I, Group V for type of oil to use.)



31A:T82855 T28:0130 112 090382


10. Install O-ring and plug. Tighten plug.



31A:T82834 T28:0130 113 180981

### TEST TRACK ROLLER FOR OIL LEAKAGE

1. Turn roller several times to seat metal face seals.
2. Remove oil fill plug.
3. Use fittings from D-15028NU Universal Pressure Test Kit to assemble test equipment as shown. Connect a regulator with gauge (F) to valve (E).
4. Apply  $(110 \pm 28 \text{ kPa})$   $(1.1 \pm 0.3 \text{ bar})$   $16 \pm 4 \text{ psi}$  to roller with air.
5. Close valve (E) and wait for minimum of 30 seconds. Make sure oil is not leaking past metal face seals or O-rings. Check gauge (D) to see if roller maintains the correct air pressure.
6. If the roller leaks oil, replace seal or O-ring at location of leak. Fill roller with recommended oil to proper level. Test roller again for oil leakage.
7. Remove test equipment.
8. If oil level falls noticeably and there are no visible leaks, the roller must be replaced due to internal leakage.
9. Install and tighten oil fill plug.



A—0721 O-ring Fitting  
 B—0027 Tee Fitting  
 C—2106 Pressure Hose  
 (2 used)


D—6949 Pressure Gauge  
 E—2495 Snubber Valve  
 F—Regulator with Gauge

31A:782856 T28:0130 114 180981

### INSTALL TRACK ROLLERS


**IMPORTANT:** Alternate single and double flange rollers, starting with a single flange roller next to the idler.

1. Put rollers on track chain with flat portion of roller and shaft pointing up. Align with tapped holes in track frame.



31A:782857 T28:0130 115 090382


2. Lower unit enough to allow cap screws and lock washers to be installed into track frame. Tighten the cap screws to  $(576 \text{ N}\cdot\text{m})$   $425 \text{ lb}\cdot\text{ft}$ . Rollers must be free to turn by hand after tightening cap screws.



31A:782858 T28:0130 116 180981

## Track Systems


3. Minimum clearance (C) between track roller bracket and the inside of track frame should be (0.25 mm) 0.010 in.



A—Roller End Bracket  
B—Track Frame  
C—Frame-to-Bracket Clearance

31A:782513 728:0130 117 180981


4. Install guides, if removed.
5. Adjust track tension.



31A:782553 728:0250 218 180981

### MEASURE GROUSER WEAR

1. Put depth gauge over grouser bar. Depth gauge consists of D-05231ST 300 mm Metric Ruler, D-05265ST 150 mm Metric Ruler and D-05266ST Right Angle Attachment from D-05227ST Undercarriage Inspection Service Tool Kit.
2. Repeat measurement for several grousers to find average height.
3. Standard grouser height on a new shoe is (26.5 mm) 1.04 in. Minimum recommended grouser height is (12.5 mm) 0.49 in.




*NOTE: For additional information on measuring grouser bar height, see the UNDERCARRIAGE APPRAISAL MANUAL SP-326.*

31A:782659 728:0330 119 180981

## REMOVE AND INSTALL TRACK SHOES

1. Remove four cap screws and nuts.




31A, T82860 T28, 0130 120 180981



**CAUTION:** The weight of a 900 mm (36 in.) shoe is 47.6 kg (105 lb.) A 750 mm (30 in.) shoe weight is 31.8 kg (70 lb.).


2. Install a lifting strap to remove shoe.
3. Inspect shoe for cracks or damage; replace if necessary.
4. Mounting surface on track shoes and links must be clean and free of paint.
5. Put oil on cap screw threads and under cap screw head.
6. Install track shoes using cap screws to align shoe on track link.



31A, T82860 T28, 0130 120 180981

## Track Systems

7. Install nuts with rounded corners against link.




31A:T82862 T28:0130 122 180981

8. Tighten cap screws to  $(300 \pm 30 \text{ N}\cdot\text{m})$   $220 \pm 22 \text{ lb}\cdot\text{ft}$ . Turn cap screw an additional  $120^\circ$  (1/3 turn or two flats of cap screw head).

9. Check cap screws after 75 hours of operation. They must have a minimum torque of  $(569 \text{ N}\cdot\text{m})$   $420 \text{ lb}\cdot\text{ft}$ .

10. If cap screws check below  $(569 \text{ N}\cdot\text{m})$   $420 \text{ lb}\cdot\text{ft}$ , remove shoes and clean paint or foreign material from chain and shoe mating surfaces. Assemble shoes following above steps 5 through 9.




31A:T82862 T28:0130 124 180981

### MEASURE TRACK LINK FOR WEAR

1. Measure track link height with a depth gauge from the D-05227ST Undercarriage Inspection Service Tool Kit.
2. Measure additional links of track chain to find average measurement.
3. Link height of a new chain is  $(125.5 \text{ mm})$   $4.94 \text{ in}$ . Minimum recommended link height is  $(114.3 \text{ mm})$   $4.50 \text{ in}$ .

*NOTE: For additional information on measuring link height, see the UNDERCARRIAGE APPRAISAL MANUAL SP-326.*




31A:T82864 T28:0130 124 180981

### MEASURE BUSHING FOR WEAR

1. Measure bushing diameter using a D-17524CI (101.6 mm) 4-in. Spring Caliper from D-05227ST Undercarriage Inspection Service Tool Kit.
2. A bushing wears in two places due to forward and reverse directions. Put caliper around bushing to measure each area of wear.
3. Outside diameter of a new bushing is (71.4 mm) 2.81 in. The minimum recommended bushing outside diameter is (68.3 mm) 2.69 in. before turning bushings.

*NOTE: For additional information on measuring bushing outer diameter, see the UNDERCARRIAGE APPRAISAL MANUAL SP-326.*




31A-T82865 T28:0130 125 180981

### MEASURE TRACK PITCH

1. Measure track pitch using a D-05230ST 3 Meter Steel Tape from D-05227ST Undercarriage Inspection Service Tool Kit.
2. Pull track chain tight. Put tape measure across a four link section as shown. Record the measurement. Measure several other random sections, avoiding four sections either side of the master pin, to determine average chain wear.
3. Distance across a four link section on a new chain is (864.8 mm) 34.05 in. Maximum recommended distance across four links is (877.5 mm) 34.55 in. before turning or replacing pins and bushing.

*NOTE: For additional information on measuring track pitch, see the UNDERCARRIAGE APPRAISAL MANUAL SP-326.*



31A-T82866 T28:0130 126 180981




## REMOVE TRACK CHAIN

1. Remove track adjuster cover from track frame.



**CAUTION: Grease in track adjuster is under extreme pressure.**


2. Turn the ball check valve assembly (A) one to three turns counterclockwise to release track tension. DO NOT turn grease fitting to release track tension.



31A782685 T28:0130 127 180981

3. Lift the side of unit off the ground.

4. Put two D-01182AA 20-Ton Floor Stands under unit.



31A782867 T28:0130 128 180981




**CAUTION: Make sure track clears the floor before rotating it.**

*NOTE: Master pin is identified by drill point in end of pin.*

5. Move track until master pin is over front idler in the position as shown.

6. Remove two track shoes; one on each side of master pin.




31A782686 T28:0130 129 180981

## Track Systems


**IMPORTANT: DO NOT** remove the track master pin with a hammer. This will enlarge the link pin bore requiring installation of a new track link.

7. Remove master pin from track link using a D-01063AA (890 000 N) 100-Ton Master Pin Pusher. Install aligning adapter into Master Pin Pusher C-Frame and fasten with holding screw.



31A:T82607 T28:0130 130 180981

8. Put aligning bushings (A) on forcing pin (B). Install pin and bushings in C-frame.




31A:T82608 T28:0130 131 180981

9. Put master pin pusher and forcing pin in alignment with master pin using D-01043AA Load Positioning Sling and hoist.

10. Turn ram adjusting screw (B) clockwise with crank until forcing pin (A) contacts master pin.

11. Connect hydraulic pump to pin pusher. Activate pump to remove master pin. Turn ram adjusting screw manually with crank to recycle as necessary. Forcing pin replaces master pin in track.



31A:T82609 T82690 T28:0130 132 180981

This as a preview PDF file from [best-manuals.com](http://best-manuals.com)



Download full PDF manual at [best-manuals.com](http://best-manuals.com)