



60 Skid-Steer Loader



JOHN DEERE

TECHNICAL MANUAL

60 Skid-Steer
Loader

TM1185 (01APR81) English

John Deere
Lawn & Grounds Care Division
TM1185 (01APR81)

LITHO IN U.S.A.
ENGLISH



60 SKID-STEER LOADER

Technical Manual
TM-1185 (Apr-81)

CONTENTS

- SECTION 10 - GENERAL
 - Group 05 - Specifications
 - Group 10 - Lubrication and Periodic Service
Serial No. (-120,000)
 - Group 12 - Lubrication and Periodic Service
Serial No. (120,001-)
- SECTION 20 - ENGINE REPAIR Serial No.
(-120,000)
 - Group 05 - Specifications and Tools
 - Group 10 - Engine Separation
 - Group 15 - Cylinder Head, Breather and Valves
 - Group 20 - Piston Assembly and Cylinder Bore
 - Group 25 - Crankcase and Assemblies
- SECTION 25 - ENGINE REPAIR Serial No.
(120,001-)
 - Group 05 - Specifications and Special Tools
 - Group 10 - Engine Removal and Installation
 - Group 15 - Internal Components
- SECTION 30 - FUEL AND AIR REPAIR
 - Group 05 - Specifications
 - Group 10 - Carburetor - Serial No.
(-120,000)
 - Group 12 - Carburetor - Serial No.
(120,001-)
 - Group 15 - Governor - Serial No.
(120,001-)
 - Group 20 - Fuel Tank - Serial No.
(120,001-)
 - Group 25 - Fuel Pump and Fuel Filter
 - Group 30 - Air Cleaner
- SECTION 40 - ELECTRICAL REPAIR
 - Group 05 - Specifications and Special Tools
 - Group 10 - Cranking System - Serial No.
(-120,000)
 - Group 12 - Cranking System - Serial No.
(120,001-)
 - Group 15 - Ignition System - Serial No.
(-120,000)
 - Group 17 - Ignition System - Serial No.
(120,001-)
 - Group 20 - Charging System - Serial No.
(-120,000)
- Group 22 - Charging System - Serial No.
(120,001-)
- Group 25 - Neutral Start Switches
- SECTION 50 - POWER TRAIN REPAIR
 - Group 05 - Specifications and Special Tools
 - Group 10 - Drive Clutch - Serial No.
(-120,000)
 - Group 12 - Drive Clutch - Serial No.
(120,001-)
 - Group 15 - Hydrostatic Pump
 - Group 20 - Hydrostatic Motor
 - Group 25 - Drive Components
- SECTION 60 - STEERING AND BRAKE REPAIR
 - Group 10 - Steering - Serial No.
(-120,000)
 - Group 12 - Steering - Serial No.
(120,001-)
 - Group 15 - Brakes
- SECTION 70 - HYDRAULIC REPAIR
 - Group 05 - Specifications and Special Tools
 - Group 10 - Hydraulic Pump - Serial No.
(020,303)
 - Group 15 - Hydraulic Pump - Serial No.
(020,304-)
 - Group 20 - Hydraulic Cylinders
 - Group 25 - Control Valves
- SECTION 80 - OPERATOR'S STATION
 - Group 10 - ROLL-GARD
 - Group 15 - Floor Plate
 - Group 20 - Seat and Heat Shield
 - Group 25 - Pedal Assembly
- SECTION 220 - ENGINE OPERATION AND TESTS - Serial No.
(-120,000)
 - Group 05 - Specifications and Special Tools
 - Group 10 - System Operations
 - Group 15 - Engine Analysis
 - Group 20 - Diagnosing Malfunctions

(All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice).

Copyright© 1981
DEERE & COMPANY
Previous Editions
Copyright© 1977
DEERE & COMPANY

CONTENTS — Continued

<p>SECTION 225 - ENGINE OPERATION AND TESTS - Serial No. (120,001-)</p> <ul style="list-style-type: none"> Group 05 - Specifications and Special Tools Group 10 - System Operation Group 15 - Engine Analysis Group 20 - Diagnosing Malfunctions <p>SECTION 230 - FUEL SYSTEM OPERATION AND TESTS</p> <ul style="list-style-type: none"> Group 05 - Specifications Group 10 - System Operation - Serial No. - (-120,000) Group 12 - System Operation - Serial No. (120,001-) Group 15 - System Testing - Serial No. (-120,000) Group 17 - System Testing - Serial No. (120,001-) Group 20 - Diagnosing Malfunctions 	<p>SECTION 240 - ELECTRICAL OPERATION AND TESTS</p> <ul style="list-style-type: none"> Group 05 - Specifications and Special Tools Group 10 - Wiring Diagrams Group 15 - Cranking System Group 20 - Ignition System Group 25 - Charging System <p>SECTION 250 - POWER TRAIN OPERATION AND TESTS</p> <ul style="list-style-type: none"> Group 05 - Specifications and Special Tools Group 10 - System Operation Group 15 - System Testing Group 20 - Diagnosing Malfunctions <p>SECTION 270 - HYDRAULIC OPERATION AND TESTS</p> <ul style="list-style-type: none"> Group 05 - Specifications and Special Tools Group 10 - System Operation Group 15 - System Testing Group 20 - Diagnosing Malfunctions
--	--

INTRODUCTION

This technical manual contains service and maintenance information for the John Deere 60 Skid-Steer Loader.

The manual is divided into sections. Each section pertains to a certain component or operational system of the loader. The information is divided into groups within each section.

All sections of this technical manual should be carefully studied by the service technician. Much basic information such as the principles of 4-cycle engine operation, carburetion and ignition have been omitted. Such information can be found in any good library and is recommended reading for the new service technician before consulting this manual for service procedures.

Emphasis is placed on diagnosing malfunctions, analysis and testing. Diagnosing malfunctions lists possible troubles, their causes and how to correct them. Under specific components these troubles are analyzed to help the service technician understand what is causing the problem so it can be corrected rather than just replace parts and have the same problem keep recurring.

Specifications are found at the beginning of each Section for easy reference.




This safety alert symbol identifies important safety messages in this manual. When you see this symbol, be alert to the possibility of personal injury and carefully read the message that follows.

Metric equivalents have been included, where applicable, throughout this technical manual.

FOR YOUR CONVENIENCE

Vertical lines appear in the margins of many of the pages. These lines identify new material and revised information that affects specifications, procedures, and other important instructions.

INTRODUCTION



Use FOS Manuals for Reference



Use Technical Manuals for Actual Service

This technical manual is part of a twin concept of service:

- **FOS Manuals — for reference**
- **Technical Manuals — for actual service**

The two kinds of manuals work as a team to give you both the general background and technical details of shop service.

Fundamentals of Service (FOS) Manuals cover basic theory of operation, *fundamentals* of trouble shooting, *general* maintenance, and *basic* types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced service technicians.

Technical Manuals are concise on-the-job service guides containing only the vital information needed for a specific machine.



When a service technician should refer to a FOS Manual for more information, a FOS symbol like the one at the left is used in the TM to identify the reference.

Some features of this technical manual:

- *Table of contents at front of manual*
- *Exploded views showing parts relationship*
- *Photos showing service techniques*
- *Specifications grouped for easy reference*

This technical manual was planned and written for you — an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it whenever in doubt about correct service procedures or specifications.

Using the technical manual as a guide will reduce error and costly delay. It will also assure you the best in finished service work.

SI UNITS OF MEASURE

Because John Deere sells its products worldwide, U.S. units of measure are shown with their respective Metric equivalents throughout this technical manual. These equivalents are the SI (International System) Units of Measure.

Section 10 GENERAL

CONTENTS

	Page		Page
GROUP 05 - SPECIFICATIONS		GROUP 12 - LUBRICATION AND PERIODIC SERVICE SERIAL NO. (120,001-)	
Engine.....	05-1	Lubricants.....	12- 1
Electrical System.....	05-1	Lubrication.....	12- 2
Travel Speeds.....	05-1	Periodic Services.....	12- 4
Drive Chains.....	05-1	As Required.....	12- 5
Hydraulic System.....	05-2	10 Hours or Daily.....	12- 6
Tires.....	05-2	25 Hours.....	12- 7
Capacities.....	05-2	50 Hours or Weekly.....	12- 7
Hydrostatic System.....	05-3	100 Hours or Quarterly.....	12-10
Operational Specifications.....	05-3	200 Hours or Semi-Annually.....	12-11
Dimensional Specifications.....	05-4	500 Hours or Annually.....	12-14
Bucket and Fork Specifications.....	05-5		
GROUP 10 - LUBRICATION AND PERIODIC SERVICE SERIAL NO. (-120,000)			
Lubricants.....	10- 1		
Lubrication.....	10- 2		
Periodic Services.....	10- 4		
As Required.....	10- 5		
25 Hours or Weekly.....	10- 9		
100 Hours or Quarterly.....	10-12		
200 Hours or Semi-Annually.....	10-13		
500 Hours or Annually.....	10-13		

Group 5 Specifications

ENGINE

	Serial No. (-120,000)	Serial No. (120,001-)
Make.....	Kohler	Kohler
Model.....	K-312S	KT17QS
Cylinders.....	One	Two
Cycle.....	Four	Four
Bore.....	3.50 in. (88.9 mm)	3.125 in. (79.2 mm)
Stroke.....	3.25 in. (82.5 mm)	2.75 in. (69.8 mm)
Displacement.....	31.27 cu. in. (512 cm ³)	42.18 cu. in. (691.4 cm ³)
Horsepower*.....	14 @ 3600 rpm (10.44 kW)	17 @ 3400 rpm (12.58 kW)
Speeds		
Idler.....	1300 rpm	1200 rpm
High (No Load).....	3600 rpm	3400 rpm

*Horsepower rating is established by engine manufacturer in accordance with Standard International Combustion Institute procedure. It is corrected to 60°F and 29.92 inches hg barometric pressure. Laboratory test engines are equipped with an air cleaner and muffler.

ELECTRICAL SYSTEM

	Serial No. (-120,000)	Serial No. (120,001-)
Battery, John Deere.....	AM30094 or TY6024	AM31186
Volts.....	12V 12V	12V
BCI Group.....	U1 U1	22F
Cold Cranking Amps @ 0°F (17.7°C).....	160 200	260
Reserve Capacity @ 25 amps.....	23 32	50
Charging Capacity.....	15 amps	15 amps
System Polarity.....	Negative Ground	Negative Ground
Spark Plug.....	Champion RH-10 or equivalent	Champion RBL15Y or equivalent
Spark Plug Gap.....	0.025 in. (0.64 mm)	0.025 in. (0.64 mm)
Breaker Point Gap.....	0.020 in. (0.508 mm)	0.020 in. (0.508 mm)
Ignition Timing.....	20° BTDC ("S" mark on flywheel)	Align "S" mark on flywheel

TRAVEL SPEEDS

Forward or Reverse..... 0 to 4.2 mph
 Turning radius..... 360 Degrees in its own length

DRIVE CHAINS

Long chain..... 74 links, No. 60 roller chain
 Short chain..... 50 links, No. 60 roller chain

HYDRAULIC SYSTEM

Pump	Serial No. (-020,303)	Serial No. (020,304-)
Type.....	Borg Warner fixed displacement gear pump	Webster Electric fixed displacement gear pump
Displacement.....	0.58 in. ³ /rev. (9.50 cm ³ /rev.)	0.58 in. ³ /rev. (9.50 cm ³ /rev.)
System Relief.....	1500 psi (10 342 kPa) (103.5 bar)	
Control Valve		
Main (Open Center).....	Cessna, two-spool valve, foot-pedal operated	
Auxiliary (Open Center).....	Cessna, single-spool valve. foot-pedal operated	
Filter		
Serial No. (-120,000).....	One 25 micron	
Serial No. (120,001-).....	Mesh screen in reservoir	
Hydraulic Cylinders		
Lift (double acting)		
Bore diameter.....	2 in. (51 mm)	
Rod diameter.....	1 in. (25.4 mm)	
Stroke.....	22 in. (559 mm)	
Tilt (double acting)		
	Serial No. (-020303)	Serial No. (020304-)
Bore diameter.....	2-1/2 in. (63.5 mm)	2 in. (50.8 mm)
Rod diameter.....	1-1/4 in. (31.8 mm)	1 in. (25.4 mm)
Stroke.....	13 in. (330.2 mm)	13-1/8 in. (333.4 mm)

TIRES

Size	Tire Inflation
5.70 x 12.....	30 psi (206.9 kPa) (2.1 bar)
23 x 8.5 x 12.....	35 psi (241.3 kPa) (2.4 bar)

CAPACITIES

	Serial No. (-120,000)	Serial No. (120,001-)
Fuel tank.....	6 U.S. gallons (22.8 L)	5 U.S. gallons (18.9 L)
Engine lubrication oil.....	2 U.S. quarts (1.9 L)	3.5 U.S. pints (1.65 L)
Loader hydraulic system.....	18 U.S. gallons (68.5 L)	18 U.S. gallons (68.5 L)

HYDROSTATIC SYSTEM

Pump
 Type.....Sunstrand variable displacement pump
 Displacement.....0 to 0.913 in.³/rev.
 (0 to 14.967 cm³/rev.)

Motor
 Type.....TRW-Ross fixed displacement gerota motor
 Displacement.....11.80 in.³/rev.
 (193.37 cm³/rev.)

Maximum Operating Pressure.....3000 psi (20 685 kPa) (206.9 bar)


Charge Pump
 Type.....Sunstrand gear pump
 Displacement.....0.330 in.³/rev. (5.41 cm³/rev.)
 Charge pressure.....70 to 150 psi (483 to 1 034 kPa) (4.83 to 10.34 bar)

Filters.....Two 10 micron

OPERATIONAL SPECIFICATIONS

	Serial No. (-120,000)	Serial No. (121,000-)
Tipping load w/35 in. (889 mm) bucket.....	1100 lbs (498.3 kg)	1200 lbs (544.8 kg)
Operating capacity (SAE).....	550 lbs. (249.4 kg)	600 lbs (272.4 kg)
Operating weight.....	1935 lbs (876.6 kg)	2076 lbs (942.5 kg)
Raising time w/full bucket.....	5.7 seconds	5.7 seconds
Lowering time.....	3.8 seconds	3.8 seconds
Dump time.....	2.8 seconds	2.8 seconds
Rollback time.....	1.9 seconds	1.9 seconds

DIMENSIONAL SPECIFICATIONS



M27173

Fig. 1 — Dimensional Specifications

Specifications are in accordance with IEMC Standards.
 Dimensions are with 5.70-12 Tires and 35-Inch (889 mm) Earth Bucket.

A	Overall height (Lift arms raised).....	127 in. (3 226 mm)
B	Height to hinge pin (Maximum).....	97-3/4 in. (2 483 mm)
C	Overall height.....	51 in. (1 295 mm)
D	Overall length (with bucket).....	91-3/4 in. (2 330 mm)
E	Dump angle.....	34°
F	Dump height.....	77-3/4 in. (1 975 mm)
G	Reach at maximum height.....	15-1/2 in. (394 mm)
H	Specified height.....	49-1/2 in. (1 257 mm)
I	Reach (specified height).....	22 in. (559 mm)
J	Reach (bucket on ground).....	39-1/2 in. (1 003 mm)
K	Maximum rollback (fully raised).....	86°
L	Wheelbase.....	29-3/16 in. (741 mm)
M	Digging depth (above ground).....	3/4 in. (19 mm)
N	Height to seat.....	34-1/2 in. (876 mm)
O	Overall height (with operator guard).....	74-1/2 in. (1 892 mm)
P	Overall length (less bucket).....	68-1/2 in (1 740 mm)
Q	Ground clearance.....	6-1/8 in. (156 mm)
R	Maximum grading angle (bucket).....	89°
S	Angle of departure.....	21°
T	Bucket width.....	35 in. (890 mm)
U	Clearance circle, front (less bucket).....	31 in. (787 mm)
V	Clearance circle, front (with bucket).....	56-7/8 in. (1 445 mm)
X	Clearance circle, rear.....	43-1/4 in. (1 098.6 mm)
Y	Overall width (less bucket).....	35-1/4 in. (895.4 mm)
Z	Tread (5.70-12 tires).....	29-1/4 in. (743 mm)

BUCKET AND FORK SPECIFICATIONS

Item	Width	Length	Capacity		Weight
			SAE Struck	SAE Heaped	
Earth Bucket	35 in. (890 mm)	_____	3.5 cu. ft. (0.10 m ³)	4.5 cu. ft. (0.13 m ³)	105 lbs. (47.63 kg)
Earth Bucket	44 in. (1 117.6 mm)	_____	4.5 cu. ft. (0.13 m ³)	5.5 cu. ft. (0.15 m ³)	120 lbs. (54.43 kg)
Utility Bucket	47 in. (1 193.8 mm)	_____	7 cu. ft. (0.20 m ³)	9 cu. ft. (0.25 m ³)	147 lbs. (66.68 kg)
Pallet Fork and Frame	38 in. (965.2 mm)	36 in. (914.4 mm)	_____	_____	220 lbs. (99.79 kg)
Utility Fork	39 in. (990.6 mm)	28 in. (711.7 mm)	_____	_____	155 lbs. (70.31 kg)
Utility Fork	35 in. (889 mm)	28 in. (711.7 mm)	_____	_____	141 lbs. (64.0 kg)

Group 10

LUBRICATION AND PERIODIC SERVICE

SERIAL NO. (-120,000)

LUBRICANTS

Engine Oil

If oil other than Torq-Gard® Supreme is used, it must conform to the following specifications:

<p>Single Viscosity Oils API Service CD/SD MIL-L-2104C* Series 3*</p>	<p>Multi-Viscosity Oils API Service CC/SE, CC/SD or SD MIL-L-46152</p>
--	---

Select oil viscosity depending on the highest expected prevailing temperature for the fill period.

Hydraulic Fluid

Use John Deere All-Weather Hydrostatic Fluid or an equivalent Type "F" Automotive Automatic Transmission Fluid.

Greases

Use John Deere Multi-Purpose Lubricant or equivalent SAE multipurpose-type grease for all grease fittings.

Air Temperature	John Deere Torq-Gard Oil	Other Oils	
		Single Viscosity Oil	Multi-Viscosity Oil
Above 32°F (0°C)	SAE 30	SAE 30	Not recommended
-10°F to 32°F (-23°C to 0°C)	SAE 10W-20	SAE 10W	SAE 10W-30
Below -10°F (-23°C)	SAE 5W-20**	SAE 5W**	SAE 5W-20**

**As further assurance of quality, the oil should be identified as suitable for API Service Designation SD.*

***Some increase in oil consumption may be expected when SAE 5W-20 or SAE 5W oils are used. Check oil level more frequently.*

LUBRICATION



CAUTION: Stop engine before lubricating loader.

Replace missing grease fittings.

SYMBOLS



Lubricate with John Deere Multi-Purpose Lubricant or an equivalent SAE multipurpose-type grease at the hourly intervals indicated on the symbols.



Lubricate periodically with John Deere PT508 or equivalent oil.

LUBRICATION CHART

Component	5 Hours or Daily	Reference
1. Grapple Cylinder Pivot Points	Lubricate grease fittings.	See page 10-10-3.
2. Tilt Cylinder* and Quik-Tatch Pivot Points	Lubricate grease fittings.	See page 10-10-3.
3. Lift Arm and Cylinder Pivot Points	Lubricate grease fittings.	See page 10-10-3.
25 Hours or Weekly		
4. Control Lever Pivot Points	Lubricate grease fittings.	See page 10-10-3.
5. Quik-Tatch Pin	Lubricate grease fittings.	See page 10-10-3.
100 Hours or Quarterly		
6. Lift Arm Stop Pins	Lubricate guide rails and lock shafts.	See page 10-10-3.

* A single tilt cylinder was used until Serial Number 020,303. From Serial Number (020,304-120,000), dual tilt cylinders were used. Lubricate both cylinders per the specifications given here.




Fig. 1 - Lubrication Points

PERIODIC SERVICE

Component	As Required	Reference
1. Carburetor	Adjust.	Page 10-10-5
2. Hydraulic Pump Belt	Check tension.	Page 10-10-6
3. Fuse	Replace.	Page 10-10-6

5 Hours or Daily

4. Air Cleaner	Check element.	Page 10-10-6
5. Engine Crankcase Oil	Check oil level.	Page 10-10-6
6. Brakes	Check tension.	Page 10-10-7, 10-10-9

25 Hours or Weekly

7. Tires	Check inflation.	Page 10-10-9
8. Engine Crankcase Oil	Drain and refill.	Page 10-10-9
9. Hydraulic System	Check oil level.	Page 10-10-9
10. Hydrostatic Pump Belt	Check alignment.	Page 10-10-10
11. Battery	Check electrolyte level.	Page 10-10-10, 10-10-11

100 Hours or Quarterly

12. Hydrostatic Filters (2)	Replace elements.	Page 10-10-12
13. Hydraulic Filter	Replace element.	Page 10-10-12
14. Spark Plug	Clean and regap.	Page 10-10-12

200 Hours or Semi-Annually

15. Air Cleaner	Replace element.	Page 10-10-13
16. Drive Chains	Check and adjust.	Page 10-10-13

500 Hours or Annually

17. Fuel Filter	Replace filter.	Page 10-10-13
18. Hydraulic Reservoir	Drain and refill.	Page 10-10-14
19. Ignition Points and Condensor	Replace.	Page 10-10-14
20. Cylinder Head Bolts	Tighten.	Page 10-10-15
21. Engine Valve Tappets	Adjust clearance.	Page 10-10-15
22. Fuel Tank	Drain and refill.	Page 10-10-15
23. Engine Speed	Check rpm.	Page 10-10-16
24. Carburetor	Clean sediment bowl.	Page 10-10-16

AS REQUIRED

1. Carburetor

⚠ CAUTION: Never smoke when making adjustments to carburetor or fuel system.

NOTE: Idle adjustment and high-speed adjustment must be made at the same time as each affects the other.

Preliminary Adjustment

Disengage drive clutch and set parking brake.

Turn high-speed mixture needle (A) clockwise until closed. Close finger-tight only. Open 2 turns.

Turn idle mixture needle (B) clockwise until closed. Close finger-tight only. Open 1-1/4 turns.

Loosen lock nut (C).

Start engine and raise throttle lever to "FAST" position. Allow engine to warm up.

Turn high-speed mixture needle (A) until engine runs smoothly at full throttle. Keep needle position slightly on rich side (open).

Move throttle lever to "SLOW" position and turn idle mixture needle (B) until engine runs smoothly.


Advance throttle lever quickly to check for uniform acceleration. If engine misses, turn high-speed mixture needle (A) counterclockwise until positive acceleration can be obtained.

Final Adjustment

Move throttle lever to "SLOW" position and set low idle at 1300 rpm by turning idle speed screw (E).

With drive clutch engaged, move throttle lever upward until 3600 rpm has been obtained. Move high-speed stop (D) up and lock in position with lock nut (C).


NOTE: Check engine rpm with a Vibra-Tach or equivalent.



G10794Y

- A - High-Speed Mixture Needle
- B - Idle Mixture Needle
- C - Lock Nut
- D - High-Speed Stop
- E - Idle Speed Screw

Fig. 2 - Adjusting Carburetor



G10794Y

Fig. 3 - Vibration Tachometer

AS REQUIRED—Continued**2. Hydraulic Pump Belt**

1. (Not illustrated.) Remove rear guard.




Fig. 4 - Hydraulic Pump Belt

2. Loosen pump brackets.
3. Tighten pump belt to 1/2-inch (13 mm) deflection at 20 pounds (89 Nm) pressure, midway between sheaves.
4. Tighten pump bracket nuts.
5. (Not illustrated.) Install rear guard.


3. Fuse

Fig. 5 - Fuse Location

The fuse is located on the left-hand side of the engine compartment. A burned-out starter-sole-noid fuse indicates a dead short in the wiring harness.


5 HOURS OR DAILY**4. Air Cleaner**

Fig. 6 - Air Cleaner

Remove wing nut and cover.

Remove element.

Tap element lightly on a hard surface to remove loose dirt. Replace element if dirt does not drop off easily.

IMPORTANT: Do not attempt to clean filter element with liquid cleaner or air hose.

Install cover and wing nut.

5. Engine Crankcase Oil

Fig. 7 - Dipstick

Check crankcase oil level with loader on a level surface and engine stopped.

Add oil as needed to top mark on dipstick.


IMPORTANT: Do not overfill.

6. Brakes

Check tension by depressing brake pedal (A). To remove excess travel and tighten brake, follow minor adjustment procedure.

Minor Adjustment

(Not illustrated.) Raise lift arms and engage lift arm stop pins.



A - Brake Pedal
B - Cotter Pin

C - Brake Link
D - Pedal Assembly

Fig. 8 - Minor Brake Adjustment

Remove cotter pin (B) from brake link (C).

Disconnect brake link from pedal assembly(D).

Turn brake link counterclockwise to reduce excess travel.

NOTE: If above procedure is unsuccessful or brake is pulling to the left or right, perform major adjustment.

Major Adjustment




Fig. 9 - Removing Screens and Roll-Gard

1. Remove safety side screens.
2. Remove Roll-Gard and canopy.
3. Raise lift arms and install cylinder rod stops.
4. Remove foot guard panel.
5. Remove Roll-Gard supports.

5 HOURS OR DAILY – Continued




Fig. 10 - Disconnecting Linkage




Fig. 11 - Removing Floor Plate

6. Disconnect valve linkage from control pedals.
7. Remove control pedal assembly.
8. Remove valve linkage from control valve.
9. Remove cotter pin and disconnect brake link.
10. Remove clamp and boot.
11. Remove hydraulic oil dipstick.

IMPORTANT: Clean floor plate before removing it to prevent foreign material from entering hydraulic system.

12. Carefully remove floor plate to prevent damage to seal gasket.
13. Remove lock nuts and pull ball joint ends out of pivot arms.
14. Turn ball joint ends clockwise equally on both brackets to tighten.
15. Install ball joint ends, lock nuts and assemble loader.

NOTE: Check condition of pads and replace if necessary.





Fig. 12 - Adjusting Linkage Ball Joints

Brake Pad Replacement




G10812Y

Fig. 13 - Replacing Brake Pads

1. Follow disassembly procedure, under major adjustment Steps 1 through 12, pages 10-10-7 and 10-10-8.
2. Remove shoulder bolt from both brake housings.
3. Remove and replace brake pads.

25 HOURS OR WEEKLY


7. Tires



G10756Y

Fig. 14 - Inflating Tires

Check and inflate tires if necessary to 30 psi (207 kPa) (2.1 kg/cm²) for 5.70 x 12 tires and 35 psi (241 kPa) (2.5 kg/cm²) for the 23 x 8.5 x 12 flotation tires.




G10813Y

Fig. 15 - Engine Crankcase Drain Plug

NOTE: Oil must be warm.


1. Remove oil drain plug and drain oil. Replace drain plug.



G10814Y

Fig. 16 - Engine Oil Fill Tube and Dipstick

2. Fill with new oil through dipstick filler neck. Refer to page 10-10-6.



G10758Y

Fig. 17 - Hydraulic Oil Dipstick

NOTE: Loader must be on level surface and lift arms lowered and engine stopped.

The fluid level should be between "F" and "L" on the dipstick.

25 HOURS OR WEEKLY – Continued

10. Hydrostatic Pump Belt

NOTE: Drive clutch must be disengaged.

1. (Not illustrated.) Remove operator's seat and air cleaner.
2. (Not illustrated.) Raise lift arms and engage lift arm stop pins.




Fig. 18 - Aligning Pump Pulleys

3. Remove pulley shield.

IMPORTANT: Do not hammer on pulley or pump shaft.


4. Make certain clearance between pump pulleys and mounting plate is 1/8 inch (3.18 mm). If necessary, loosen two set screws on each hub and slide pulley on shaft. Tighten set screws when properly adjusted.

5. Place straight-edge across face of pump pulley and drive pulley and check vertical alignment.

6. Adjust drive pulley by loosening two set screws on hub and sliding pulley on shaft.

Tighten set screws when aligned with pump pulley.

NOTE: Check drive belt for signs of wear or damage and replace if necessary as follows:



A - Drive Belt
B - Drive Pulley

C - Pump Pulleys

Fig. 19 - Installing Drive Belt

Follow disassembly procedure, Steps 1, 2, 3, 4, and 5.

NOTE: Drive clutch must be disengaged.

Twist drive belt (A) sideways and install it on bottom of drive pulley (B).

Install belt over two pump pulleys (C).

Install pulley shield, air cleaner and seat.

11. Battery

CAUTION: Keep all sparks or open flames away. Battery gas is highly flammable.

Battery acid is harmful on contact with the skin or materials.

Wear eye protection and remove rings, metal watch bands and other metal jewelry.

IMPORTANT: Never weld on the loader unless the battery cables are disconnected from the battery.

Check electrolyte level and add distilled water to the electrolyte as necessary. Electrolyte level should be 1/4 to 1/2 inch (6.4 to 12.7 mm) above plates. DO NOT fill to bottom ledge of filler tubes.

NOTE: Since water and electrolyte will not mix immediately, do not add water in freezing weather unless the engine is to run for 2 or 3 hours to assure solution mixes thoroughly.





Fig. 20 - Battery Cell Cap



A - Electrolyte Level

B - Plates

Fig. 21 - Checking Electrolyte Level

Specific Gravity

To check battery condition, use a battery hydrometer. Check specific gravity of electrolyte in each cell. Charge battery if reading is below 1.215. Replace battery if difference between cells is more than 0.050.

Always correct specific gravity reading for electrolyte temperature variation. Add 0.004 for every 10°F above 80°F. (Add 0.007 for every 10°C above 27°C). Subtract at same rate if electrolyte temperature is below 80°F (27°C). Corrected specific gravity of a fully charged battery is 1.260.

Cleaning Battery

Use a damp cloth to clean battery every 100 hours.

Remove corrosion build-up by brushing on ammonia or a solution of 1 part baking soda and 4 parts water.

Booster Batteries

For additional cold weather starting power, connect an additional 12-volt battery in parallel with loader 12-volt system.

Jumper Cables

IMPORTANT: Battery is NEGATIVE grounded only. Reversing polarity in battery or alternator connections will result in permanent damage to the electrical system.

First, connect the positive (+) terminal of the booster battery to the positive (+) terminal of the loader battery. Connect the second cable to the negative (-) terminal of the booster battery first and then to some point on the loader frame. It is important that this last connection be made away from the loader battery to avoid any fire and explosion hazard caused by sparks.

Removal




Fig. 22 - Battery Cables and Hold-Down


1. Remove negative ground cable.
2. Remove positive cable.
3. Remove battery mounting bracket and lift battery from loader.

Install battery in reverse order. Connect positive cable first, negative cable last.

Coat terminals with petroleum jelly to prevent corrosion.

100 HOURS OR QUARTERLY

12. Hydrostatic Filters



G10820Y

Fig. 23 - Hydrostatic Filters

Remove and replace the two hydrostatic filter elements.

Fill filter half full of hydraulic fluid and moisten rubber gasket prior to installation. Tighten finger-tight.

Operate engine a few minutes. Stop engine and check fluid level. Add fluid so level is between "F" and "L" on dipstick.

13. Hydraulic Filter

Remove and replace hydraulic filter element.

Fill filter half full of hydraulic fluid and moisten rubber gasket prior to installation. Tighten finger-tight.


Operate engine a few minutes. Stop engine and check fluid level. Add fluid so level is between "F" and "L" on dipstick.




G10821Y

Fig. 24 - Hydraulic Filter

14. Spark Plug



G10822Y



G10823


Fig. 25 - Checking Spark Plug Gap

1. Remove wire from plug.
2. Remove, clean and gap plug to 0.025 inch (0.635 mm).
3. Install plug and torque to 22 ft-lbs (30 Nm) (3 kgm).

NOTE: Inspect electrode for deterioration and insulation for cracks. Replace plug if necessary.

200 HOURS OR SEMI-ANNUALLY

15. Air Cleaner




G10800

Fig. 26 - Air Cleaner

Remove and install new element. Refer to item 4, page 10-10-6.

16. Drive Chains

Follow Steps 1 through 12, pages 10-10-7 and 10-10-8.



G10825Y

A - Idler Bolts
B - Idler Sprocket

C - Long Drive Chain

Fig. 27 - Drive Chains

Loosen idler bolts (A) and move idler sprocket (B) up to tighten.

A 1/2-inch (13 mm) deflection with 20 lbs (9 kg) of pressure is required on the long drive chains (C). Tighten idler bolts.


NOTE: Check deflection approximately in the middle of long drive chain.

IMPORTANT: Protect idler sprockets from damage. Use a wood block between pry tool and sprocket.

Reverse disassembly procedure for assembly.

500 HOURS OR ANNUALLY

17. Fuel Filter



G10827Y

Fig. 28 - Fuel Filter

Remove rear guard and fuel filter. Install new in-line fuel filter.

Install rear guard.

500 HOURS OR ANNUALLY – Continued

18. Hydraulic Reservoir

1. (Not illustrated.) Block up rear of loader and engage parking brake.




Fig. 29 - Hydraulic Reservoir Drain Plug

2. Remove drain plug. Drain and flush reservoir with hydraulic fluid. Install plug.




Fig. 30 - Hydraulic Reservoir Dipstick

3. Fill reservoir through dipstick filler neck.

19. Ignition Points and Condenser

Replace points and condenser as follows:




Fig. 31 - Removing Rear Guard

1. Remove rear guard.




Fig. 32 - Breaker Point Cover

2. Remove breaker point cover.
3. Remove wire from terminal.
4. Remove and replace points.
5. Remove and replace condenser.
6. Install wire on terminal.






Fig. 33 - Point Terminal Wire and Condenser



G10833Y



G10834Y

Fig. 34 - Adjusting Breaker Point Gap

7. Loosen point adjustment screw to increase or decrease point gap.


8. Set point gap to 0.020 inch (0.51 mm).

IMPORTANT: Tighten adjustment screw and recheck point gap before installing cover.

9. Install breaker point cover, Fig. 32.

10. Install rear guard, Fig. 31.

20. Cylinder Head Bolts



G10796

G10796


Fig. 35 - Cylinder Head Bolt Torquing Sequence

Tighten head bolts in sequence to 30 ft-lbs (41 Nm) (4.1 kgm).

21. Engine Valve Tappets

Check intake and exhaust valve clearance. See page 20-15-6.

22. Fuel Tank



G10786Y

Fig. 36 - Fuel Tank Drain Plug

Remove drain plug and drain fuel.

Install plug and fill with fresh fuel.

500 HOURS OR ANNUALLY – Continued

23. Engine Speed

With drive clutch disengaged, check low idle (1300 rpm). Check high idle (3600 rpm) with clutch engaged.

24. Carburetor




Fig. 37 - Carburetor Sediment Bowl

Remove and clean carburetor sediment bowl.

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com