


**John Deere
400G
Crawler Bulldozer
Repair**



TECHNICAL MANUAL

TM-1412 (Mar-88)
LITHO IN U.S.A.

400G CRAWLER BULLDOZER TECHNICAL MANUAL TM1412 (Mar-88) REPAIR

SECTION AND GROUP CONTENTS

NOTE: This manual covers machine repair. For Operation and Test information, see TM-1411.

SECTION I—GENERAL INFORMATION

- Group I—Introduction and Safety Information
- Group II—General Specifications
- Group III—Torque Values
- Group IV—Fuels and Lubrication
- Group V—Inspection Procedures

SECTION 01—TRACKS

- Group 0130—Track Systems
 - Track Chain, Track Frame, Carrier Roller, Front Idler, Track Roller and Track Adjuster

SECTION 02—AXLES AND SUSPENSION SYSTEMS

- Group 0250—Axle Shaft, Bearings, and Reduction Gears
 - Final Drive, Steering Brakes, Steering Clutch, Linkage, and Adjustments

SECTION 03—TRANSMISSION

- Group 0315—Controls
- Group 0350—Gears, Shafts, Bearings and Power Shift Clutches
 - Transmission, Clutch Oil Pump, H-L-R Clutches, Valves, Oil Filter, Winch Drive, Drive Shaft, Ring Gear, Linkages and Adjustments
- Group 0360—Hydraulic System
 - Transmission Oil Filter and Transmission Oil Cooler

SECTION 04—ENGINE

- Group 0400—Removal and Installation
 - Engine, Oil Pan, Fuel Injection Pump, Injection Nozzles, Thermostats, Fuel Transfer Pump and Water Pump

SECTION 05—ENGINE AUXILIARY SYSTEMS

- Group 0505—Cold Weather Starting Aid
 - Starting Aid Solenoid and Nozzles
- Group 0510—Cooling System
 - Fan Belt, Blower Fan, Radiator, Oil Cooler, Pump and Radiator Support
- Group 0515—Speed Controls
- Group 0560—External Fuel Supply Systems
 - Fuel Tank

SECTION 07—CLUTCH

- Group 0715—Controls
 - Clutch Pedal Linkage and Adjustment
- Group 0752—Elements
 - Engine Clutch Assembly and Clutch Housing

Continued on next page

All information, illustrations and specifications contained in this technical manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 1988
DEERE & COMPANY
Moline, Illinois
All rights reserved
A JOHN DEERE ILLUSTRATION

SECTION 09—STEERING SYSTEM

Group 0960—Hydraulic System
Steering Valve Spools

SECTION 15—EQUIPMENT ATTACHING

Group 1511—Fairlead

SECTION 16—ELECTRICAL SYSTEM

Group 1671—Batteries, Support, and Cables
Group 1672—Alternator, Regulator, and Charging System Wiring
Group 1673—Lighting System
Group 1674—Wiring Harness and Switches
Group 1676—Instruments and Indicators
Logic Module, Relay, Circuit Breakers, and Switches
Group 1677—Motors and Actuators
Starting Motor

SECTION 17—FRAME, CHASSIS, OR SUPPORTING STRUCTURE

Group 1740—Frames
Side Frames

SECTION 18—OPERATOR'S STATION

Group 1810—Operator Enclosure
Roll-Over Protective Structure (ROPS)
Group 1821—Seat and Seat Belt

SECTION 19—SHEET METAL AND STYLING

Group 1910—Hood or Engine Enclosure
Grille Housing and Cowl

SECTION 30—WINCH

Group 3015—Controls Linkage
Group 3050—Winch Drive and Clutches
Group 3060—Winch Hydraulic System

SECTION 32—BULLDOZER

Group 3201—Blade
Group 3215—Control Linkage
Group 3240—Frames
Group 3260—Hydraulic System
Hydraulic Oil Filter, Reservoir, Hydraulic Pump, Pump Drive, Dozer Valve, Relief Valves and Cylinders

SECTION 40—PTO OR WINCH DRIVE

Group 4051—Gears, Shafts and Bearings
Powershaft and Winch Drive

SECTION 42—GROUND CONDITIONING TOOLS

Group 4201—Teeth and Shanks
Group 4240—Frame
Group 4260—Hydraulic System
Ripper Cylinder

SECTION 99—DEALER FABRICATED TOOLS

INTRODUCTION

This manual is part of a total service support program.

FOS Manuals—reference

Technical Manuals—machine service

Component Manuals—component service

Fundamentals of Service (FOS) Manuals cover basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic types of failures and their causes. FOS Manuals are for training new personnel and for reference by experienced technicians.

Technical Manuals are concise service guides for specific machines. Technical manuals are on-the-job guides containing only the vital information needed by an experienced service technician.

Component Technical Manuals are concise service guides for specific components. Component technical manuals are written as stand alone manuals covering multiple machine applications.



AB6;RW5559 053;INTRO2 030785

FEATURES OF THIS TECHNICAL MANUAL

John Deere ILLUSTRATION format emphasizing illustrations and concise instructions in easy-to-use modules.

Emphasis on diagnosis, analysis, and testing so you can understand the problem and correct it.


Diagnostic information presented with the most logical and easiest to isolate problems first to help you identify the majority of routine failures quickly.

Step-by-step instructions for teardown and assembly.

Summary listing at the beginning of each group of all applicable specifications, wear tolerances, torque values, essential tools, and materials needed to do the job.

An emphasis throughout on safety—so you do the job right without getting hurt.

This technical manual was planned and written for you—an experienced service technician. Keep it in a permanent binder in the shop where it is handy. Refer to it when you need to know correct service procedures or specifications.




AB6;RW5560 053;INTRO3 071085

USING TABS

To fully utilize this technical manual, you must understand how it is organized.

Only two tab colors are used—gray and yellow. Each color represents a different type of information.

Spend a minute reading this now and save many minutes of searching later.




018;T5933AB T82;FLPD I 260785

GRAY TAB SECTIONS

The gray tab sections are repair sections that tell how to repair the components of the various systems.

Repair of a component includes:

- Removal from machine (when necessary)
- Disassembly
- Inspection
- Replacement of parts
- Assembly
- Adjustment
- Installation on machine (when necessary)




018;T5933AC T82;FLPD J 260785

The numbers used for the repair (gray tab) sections are part of an overall service publication numbering system. The numbers identify the same sections in the parts catalog, flat rate manual, service information bulletins, and service training courses.

YELLOW TAB SECTIONS

Each yellow tab section contains information on:

Groups	
05	Theory of Operation
10	System Operational Checks
15	System Diagnostic Information
20	Adjustments
25	Tests




018;T5933AD T82;FLPD K 260785

THREE-STEP PROCEDURE

Use the following three-step procedure to locate the desired information.

1. Determine the type of information you need. Is it repair, operation, or tests?
2. Go to the appropriate section tab:


Gray for Repair
Yellow for Operation or Tests



TYPE OF INFORMATION?

018;T5940AT T82;FLPD L 260785

3. Use the table of contents on the first page of the section to locate the information.




018;T5933AF T82;FLPD M 260785

RECOGNIZE SAFETY INFORMATION

This is the safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



AB6;T81989 053;ALERT 160687

UNDERSTAND SIGNAL WORDS

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

Safety signs with signal word DANGER or WARNING are typically near specific hazards.

General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



WARNING

CAUTION

AB6;TS187 053;SIGNAL 071085


USE HANDHOLDS AND STEPS

Falling is one of the major causes of machine accidents.

When you get on and off the machine, always maintain a three point contact with the steps and handrails and face the machine. Do not use any controls as handholds.

Never jump either on or off the machine. Never mount or dismount a moving machine.

Be careful of slippery conditions on platforms, steps, and handrails when leaving the machine.





018;T6669AF 02T;05 K69 161287

PREVENT MACHINE RUNAWAY

Avoid possible injury or death from machinery runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear if normal circuitry is bypassed.

NEVER start engine while standing on ground. Start engine only from operator's seat, with transmission in neutral or park.



AB6;TS177 053;BYPAS1 210585

SUPPORT RAISED EQUIPMENT

Put a support under all raised equipment. Never work under raised equipment without a support.

If a support is not available, lower equipment to ground.


02T;05 J23 150188

PREPARE FOR EMERGENCIES

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



AB6;TS186 053;FIRE2 080785

HANDLE FUEL SAFELY—AVOID FIRES

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



AB6;TS202 053;FIRE1 230487

HANDLE STARTING FLUID SAFELY

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.




AB6:T6089A U 053;FIRE3 010288

WEAR PROTECTIVE CLOTHING

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.


Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.



AB6:TS206 053;WEAR 230487

PROTECT AGAINST FLYING DEBRIS

When you drive connecting pins in or out, guard against injury from flying pieces of metal or debris; wear goggles or safety glasses.




018:T6642DK 02T;05 J45 190188

AVOID HIGH-PRESSURE FLUIDS

Escaping fluid under pressure can penetrate the skin causing serious injury. Relieve pressure before unhooking hydraulic or other lines. Tighten all connections before applying pressure. Keep hands and body away from pinholes and nozzles which eject fluids under high pressure. Use a piece of cardboard to search for leaks.

If ANY fluid is injected into the skin, it must be surgically removed within a few hours by a doctor familiar with this type injury or gangrene may result.



AB6:X9811 053;FLUID 180987

SERVICE CRAWLER SAFELY

Before servicing crawler:

- Park machine on a level surface.
- Move H-L-R lever to neutral and lock it.
- Move transmission selector lever to neutral.
- Apply brake and engage brake lock.
- Lower all equipment to the ground.
- Turn key switch off to stop engine.
- Release hydraulic pressure by moving control lever(s) until equipment does not move.
- Turn battery disconnect switch off.

Understand service procedure before doing work.

Never lubricate or service machine while it is moving. Keep hands, feet and clothing from power-driven parts.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

Disconnect battery ground cable (—) or turn battery disconnect switch off before making adjustments on electrical systems or welding on machine.

When you work near the track recoil spring, use extreme care. Do not disassemble parts unless you know the correct procedure and have correct tools.

If it is necessary to make checks with the engine running. ALWAYS USE TWO PEOPLE--with the operator at the controls, able to see the person doing the checking.

02T;05 K72 190188

USE A LIFTING DEVICE FOR HEAVY COMPONENTS

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components.

02T;05 K74 120188

REPLACE SAFETY SIGNS



DANGER

EXPLOSIVE GASES

Cigarettes, flames or sparks could cause battery to explode. Always shield eyes and face from battery. Do not charge or use booster cables or adjust post connections without proper instruction and training. Keep vent caps tight and level.

POISON


CAUSES SEVERE BURNS

Contains sulfuric acid. Avoid contact with skin, eyes or clothing. In event of accident, flush with water and call a physician immediately. Keep out of reach of children.

Replace missing or damaged safety signs. See the machine Operator's Manual for correct safety sign placement.

018:T6656C0 02T:05 K75 120188

400G



NOTE: Specifications and design are subject to change without notice. Wherever applicable, specifications, are in accordance with SAE standards. Except where otherwise noted, these specifications are based on a unit with roll-over protective structure, full fuel tank, 175 lb (80 kg) operator and standard equipment.

	U.S.	Metric
A	8 ft 2 in.	2.49 m
B	28 in.	711 mm
C	3 ft	914 mm
D	11 ft 7 in.	3.54 m
E	73 in.	1.85 m
F	7 in.	178 mm
G	90 in.	2.29 m
H	8.5 in.	216 mm
SAE Operating weight with ROPS	11,400 lb	5169 kg

000;T6727DA 05T;115 K48 280188

General Specifications

Engine: John Deere 4-239D

Type 4-stroke cycle, naturally aspirated diesel
 Bore and stroke 4.19 x 4.33 (106.5 x 110 mm)
 Number of cylinders 4
 Displacement 239 cu in. (3.9 L)
 Compression ratio 17.8:1
 Maximum net torque @ 1300 rpm 180 lb ft (244 N·m) (24.9 kgm)
 Lubrication Pressure system with full-flow filter
 Cooling fan Blower
 Air cleaner Dry
 Electrical system 12 volt with alternator
 Batteries Reserve capacity: 180 minutes

Power @ 2100 engine rpm SAE
 Net 60 hp (36 kW)

Transmission H-L-R

Steering Clutches Oil-cooled, hydraulically actuated multiple disk

Brakes Self-adjusting, oil-cooled

Travel Speeds—mph (km/h)

With machine at rated engine speed, travel speed will be:

Gear	High	Low	Reverse
1	1.7 (2.7)	1.2 (1.9)	1.6 (2.6)
2	2.6 (4.2)	1.9 (3.1)	2.5 (4.0)
3	4.0 (6.4)	2.8 (4.5)	3.8 (6.1)
4	6.2 (10.0)	4.4 (7.1)	5.9 (9.5)

Hydraulic system:

Pump Gear, 15 gpm (57 L/min)
 Pressure 2250 psi (15 514 kPa) (155.1 bar)

Tracks (5-roller track frames with track guides):

Grouser 14 in. (356 mm)
 Track shoes, each side 36
 Ground contact area 1939 sq in. (12 510 cm²)
 Ground pressure 5.9 psi (40.7 kPa) (0.407 bar)

Winch:

Drum diameter 6 in. (152 mm)
 Drum capacity (no allowance for looseness or uneven spooling):
 1/2 in. (12.7 mm) cable 159 ft (48.5 m)
 5/8 in. (15.9 mm) cable 105 ft (31.9 m)
 3/4 in. (19 mm) cable 74 ft (22.5 m)

Cable speed (at 2500 rpm engine speed with 5/8 in. (15.9 mm) cable):

With bore drum 119 fpm (36.3 mpm)
 With full drum 186 fpm (56.7 mpm)

Cable pull (at 1300 rpm engine speed):

With bore drum 15,700 lb (7120 kg)
 with full drum 10,020 lb (4544 kg)

Shipping weight:

Winch (without cable) 815 lb (370 kg)
 Fairlead 110 lb (50 kg)
 Drawbar 44 lb (20 kg)

05T;115 K49 221287

General Specifications

DRAIN AND REFILL CAPACITIES

	U.S.	Metric
Fuel tank	31 gal	117.3 L
Cooling system	3.5 gal	12.3 L
Engine oil, including filter	8.5 qt	8.0 L
Hydraulic system (reservoir only), including filter	6.0 gal	22.5 L
Transmission, steering clutch, final drive, including filter		
Steering clutches (each)	3.5 gal	(13.2 L)
Transmission	7.0 gal	(26.5 L)
Winch reservoir	9.0 qt	8.5 L

05T;115 K51. 010288

General Specifications

HARDWARE TORQUE SPECIFICATIONS

Check cap screws and nuts to be sure they are tight. If hardware is loose, tighten to torque shown on the following charts unless a special torque is specified.

T82;SKMA AT 270286

CHECK TRACK SHOE TORQUE

Track shoe cap screws should be checked periodically for tightness.

Tighten cap screws to 110 lb-ft (149 N·m) torque.




NOTE: Replacement hardware should be lubricated and tightened to above specification.

04T;90 K115. 140188

HARDWARE TORQUE VALUES

NOTE: Torque wrench tolerance is ± 10 per cent of specified torque.

Customary Hardware

Cap Screw Size-Inches			
	Grade B	Grade D	Grade F
	lb-ft. (N-m)	lb-ft. (N-m)	lb-ft. (N-m)
1/4	6 (8)	10 (14)	14 (19)
5/16	10 (14)	20 (27)	27 (37)
3/8	20 (27)	35 (47)	50 (68)
7/16	30 (40)	55 (75)	80 (108)
1/2	45 (60)	85 (115)	120 (163)
9/16	70 (95)	120 (160)	170 (230)
5/8	95 (130)	165 (225)	235 (320)
3/4	165 (225)	300 (405)	420 (570)
7/8	170 (230)	450 (610)	675 (915)
1	255 (345)	720 (975)	1015 (1375)
1-1/8		900 (1220)	1430 (1940)
1-1/4		1250 (1700)	2025 (2750)

Seating Torque Values for Set Screws

INCH SCREWS

Screw Size	Seating Torque	
	(Lb-in.)	(Nm)
5	9	1
6	9	1
8	20	2
10	33	4
1/4	87	10
5/16	165	19
3/8	290	33
7/16	430	49
1/2	620	70
9/16	620	70
5/8	1225	138
3/4	2125	240

METRIC SCREWS

Screw Size	Seating Torque
	(Nm)
M3	0.9
M4	2.5
M5	5.0
M6	8.5
M8	20
M10	40
M12	65
M16	160
M20	310
M24	520

METRIC HARDWARE TORQUE CHART

NOTE: Torque wrench tolerance is ± 10 percent of specified torque.

Metric Standard Thread

GRADE SIZE	8.8		10.9	
	Nm	LB FT	Nm	LB FT
M3	1.5	1.0	2.0	1.5
M4	3.5	2.6	5.0	4
M5	7.0	5	10.0	7
M6	12	9	12	12.0
M8	28	20	40	30
M10	55	40	80	59
M12	95	70	140	100
M14	150	110	220	160
M16	235	170	350	260
M20	475	350	675	500
M24	825	610	1170	860
M30	1630	1200	2320	1710
M36	2850	2100	4060	3000

1 Nm = .7376 (lb-ft)

For 9.8 fasteners, use 8.8 torque.


Head Markings - Bolts are marked as shown and with a letter to identify the manufacturer.

PROPERTY		CLASS	
8.8		10.9	
STANDARD	OPTIONAL	STANDARD	OPTIONAL

SERVICE RECOMMENDATIONS FOR O-RING BOSS FITTINGS


Straight Fitting

1. Inspect O-ring boss seat for dirt or defects.
2. Lubricate O-ring with petroleum jelly. Place electrical tape over threads to protect O-ring. Slide O-ring over tape and into O-ring groove of fitting. Remove tape.
3. Tighten fitting to torque value shown on chart.



Angle Fitting

1. Back-off lock nut (A) and back-up washer (B) completely to head-end (C) of fitting.
2. Turn fitting into threaded boss until back-up washer (B) contacts face of boss.
3. Turn fitting head-end (C) counterclockwise to proper index (maximum of one turn).
4. Hold fitting head-end (C) with a wrench and tighten locknut (A) and back-up washer (B) to proper torque value.



NOTE: Do not allow hoses to twist when tightening fittings.

TORQUE VALUE CHART

Thread Size	Torque	
	N·m	(lb-ft)
3/8-24 UNF	8	(6)
7/16-20 UNF	12	(9)
1/2-20 UNF	16	(12)
9/16-18 UNF	24	(18)
3/4-16 UNF	46	(34)
7/8-14 UNF	62	(46)
1-1/16-12 UN	102	(75)
1-3/16-12 UN	122	(90)
1-5/16-12 UN	142	(105)
1-5/8-12 UN	190	(140)
1-7/8-12 UN	217	(160)

NOTE: Torque tolerance is $\pm 10\%$.

SERVICE RECOMMENDATIONS FOR 37° FLARE AND 30° CONE SEAT CONNECTORS

1. Inspect the flare and the flare seat. They must be free of dirt or obvious defects.
2. Defects in the tube flare cannot be repaired. Overtightening a defective flared fitting will not stop leaks.
3. Align the tube with the fitting before attempting to start the nut.
4. Lubricate the male threads with hydraulic fluid or petroleum jelly.
5. Index angle fittings and tighten by hand.
6. Tighten fitting or nut to torque value shown on the chart. Do not allow hoses to twist when tightening fittings.



STRAIGHT FITTING OR SPECIAL NUT TORQUE


Thread Size	Torque N-m	(lb-ft)
3/8-24 UNF	8	(6)
7/16-20 UNF	12	(9)
1/2-20 UNF	16	(12)
9/16-18 UNF	24	(18)
3/4-16 UNF	46	(34)
7/8-14 UNF	62	(46)
1-1/16-12 UN	102	(75)
1-3/16-12 UN	122	(90)
1-5/16-12 UN	142	(105)
1-5/8-12 UN	190	(140)
1-7/8-12 UN	217	(160)

NOTE: Torque tolerance is ± 10%.

018;T6234AC T82;BHMA EL 061186

SERVICE RECOMMENDATIONS FOR FLAT FACE O-RING SEAL FITTINGS

1. Inspect the fitting sealing surfaces. They must be free of dirt or defects.
2. Inspect the O-ring. It must be free of damage or defects.
3. Lubricate O-rings and install into groove using petroleum jelly to hold in place.
4. Push O-ring into the groove with plenty of petroleum jelly so O-ring is not displaced during assembly.
5. Index angle fittings and tighten by hand pressing joint together to insure O-ring remains in place.
6. Tighten fitting or nut to torque value shown on the chart per dash size stamped on the fitting. Do not allow hoses to twist when tightening fittings.



FLAT FACE O-RING SEAL FITTING TORQUE

Nominal Tube mm	O.D. (in.)	Dash Size	Thread Size in.	Swivel Nut Torque		Bulkhead Nut Torque	
				Nm	(lb-ft)	Nm	(lb-ft)
6.35	0.250	-4	9/16-18	16	12	5.0	3.5
9.52	0.375	-6	11/16-16	24	18	9.0	6.5
12.70	0.500	-8	13/16-16	50	37	17.0	12.5
15.88	0.625	-10	1-14	69	51	17.0	12.5
19.05	0.750	-12	1 3/16-12	102	75	17.0	12.5
22.22	0.875	-14	1 3/16-12	102	75	17.0	12.5
25.40	1.000	-16	1 7/16-12	142	105	17.0	12.5
31.75	1.250	-20	1 11/16-12	190	140	17.0	12.5
38.10	1.500	-24	2-12	217	160	17.0	12.5

NOTE: Torque tolerance is +15 -20%.

SAE FOUR BOLT FLANGE FITTING SERVICE RECOMMENDATIONS

1. Inspect the sealing surfaces for nicks or scratches, roughness or out-of-flat condition. Scratches cause leaks. Roughness causes seal wear. Out-of-flat causes seal extrusion. If these defects cannot be polished out, replace the component.



2. Install the correct O-ring (and backup washer if required) into the groove using petroleum jelly to hold it in place.

3. For split flange; loosely assemble split flange halves, being sure that the split is centrally located and perpendicular to the port. Hand tighten cap screws to hold parts in place. Do not pinch O-ring.

4. For single piece flange; put hydraulic line in the center of the flange and install four cap screws. With the flange centrally located on the port, hand tighten cap screws to hold it in place. Do not pinch O-ring.

5. For both single piece flange and split flange, be sure the components are properly positioned and cap screws are hand tight. Tighten one cap screw, then tighten the diagonally opposite cap screw. Tighten the two remaining cap screws. Tighten all cap screws within the specified limits shown in the chart.

DO NOT use air wrenches. DO NOT tighten one cap screw fully before tightening the others. DO NOT overtighten.



SAE FOUR BOLT FLANGE FITTING TORQUE

Nominal Flange Size	Cap Screw Size ¹	Torque ²			
		N·m		(lb-ft)	
		Min.	Max.	Min.	Max.
1/2	5/16 - 18 UNC	20	31	(15)	(23)
3/4	3/8 - 16 UNC	28	54	(21)	(40)
1	M10 10.9	58	88	(43)	(65)
	3/8 - 16 UNC	37	54	(27)	(40)
1-1/4	M12 10.9	104	156	(77)	(115)
	7/16 - 14 UNC	47	85	(35)	(63)
1-1/2	1/2 - 13 UNC	62	131	(46)	(97)
2	1/2 - 13 UNC	73	131	(54)	(97)
2-1/2	1/2 - 13 UNC	107	131	(79)	(97)
3	5/8 - 11 UNC	158	264	(117)	(195)
3-1/2	5/8 - 11 UNC	158	264	(117)	(195)
4	5/8 - 11 UNC	158	264	(117)	(195)
5	5/8 - 11 UNC	158	264	(117)	(195)

1. SAE Grade 5 or better cap screws with plated hardware.

2. Tolerance $\pm 10\%$. The torques given are enough for the given size connection with the recommended working pressure. Torques can be increased to the maximum shown for each cap screw size if desired. Increasing cap screw torque beyond this maximum will result in flange and cap screw bending and connection failures.

018/T6575AG, T6561AG 04T:90 K68. 251187

Torque Values

FUEL SPECIFICATIONS

Use **ONLY** clean, high-quality fuel.

Use Grade No. 2-D fuel above 4°C (40°F).

Use Grade No. 1-D fuel below 4°C (40°F).

Use Grade No. 1-D fuel for all air temperatures at altitudes above 1 500 m (5000 ft).

IMPORTANT: If fuel sulfur content exceeds 0.5 per cent, change the engine oil at one-half the normal interval.

Use fuel with less than 1.0 per cent sulfur. If possible, use fuel with less than 0.5 per cent sulfur.

For maximum filter life, sediment and water should not be more than 0.10 per cent.

The cetane number should be 40 minimum. If you operate your machine where air temperatures are normally low or where altitudes are high, you may need fuel with a higher cetane number.

Cloud Point—For cold weather operation, cloud point should be 6°C (10°F) below lowest normal air temperature.

02T;45 C25. 020487

FUEL STORAGE

NOTE: Diesel fuels stored for a long time may form gum or bacteria and plug filters.

Keep fuel in a clean container in a protected area. Water and sediment must be removed before fuel gets to the engine. Do not use de-icers to remove water from fuel. Do not depend on fuel filters to remove water.


If possible, install a water separator at the storage tank outlet. (See your John Deere dealer).

IMPORTANT: Keep all dirt, scale, water or other foreign material out of fuel.

Store fuel drums on their sides.

02T;45 K8. 180387

ENGINE OIL



Depending upon the expected air temperature range between oil changes, use oil viscosity shown on the temperature chart above.

Additives are not required nor recommended.

John Deere TORQ-GARD SUPREME® engine oil is recommended because it is a specifically balanced formulation to provide maximum engine life. It provides excellent protection against mechanical wear, carbon deposits, and lacquer formation, plus providing superior cold weather starting performance.


If other oils are used, they must have one of the following specifications:

Oil Specification	Use
API Service: CD/SF, CD/SE, CD/SD, CD/SC, or MIL-L-2104C, MIL-L-2104D	Recommended
*API Service CC/SF, CC/SE, CC/SD, CC/SC or *MIL-L-46152, *MIL-L-46152B	For SAE 5W20, SAE 5W30 and arctic oil only, use if recommended oil is not available.
*MIL-L-46167A	For arctic oil only

**Change oil at one-half the normal interval.*

018;T6172AI 02T;45 J15. 270188

TRANSMISSION, STEERING CLUTCHES, FINAL DRIVES, AND HYDRAULIC OIL



Depending upon the expected air temperature range between oil changes, use oil viscosity shown on the temperature chart above.

The following oils are recommended:

John Deere HY-GARD Transmission and Hydraulic Oils.


Engine oil meeting the T02 oil test and one or more of the following API Service CD/SF, CD/SE, CD/SD, CD/SC, CC/SF, CC/SE, CC/SD, CC/SC (MIL-L-2104D, MIL-L-2104C, MIL-L-46152B, MIL-L-46152).

You may also use QUATROL® oils, which are oils that meet John Deere standards, or other oils meeting John Deere Standard J20A or J20B.

Oil meeting MIL-L-46167A may be used as an arctic oil.

018;T6508AQ 02T;45 J12. 161287

WINCH OIL



Depending upon the expected air temperature range between oil changes, use oil viscosity shown on the temperature chart above.

The following oils are recommended:

John Deere HY-GARD[®] Transmission and Hydraulic Oils.

Engine oil meeting one or more of the following: API Service CD/SF, CD/SE, CD/SD, CD/SC, CC/SF, CC/SE, CC/SD, CC/SC (MIL-L-2104D, MIL-L-2104C, MIL-L-46152B, MIL-L-46152B).

You may also use QUATROL[®] oils, which are oils that meet John Deere standards, or other oils meeting John Deere Standard J20A or J20B.

Oil meeting MIL-L-5606A may be used as an arctic oil.


018;T6508AR 02T;45 J13. 161287

TRACK ROLLER, FRONT IDLER, AND CARRIER ROLLER OIL

Use SAE 80W90 gear oil meeting API Service GL-5 (MIL-L-2105B or MIL-L-2105C).

02T;45 J14. 161287

GREASE



Depending on the expected air temperature range during use, use grease shown on chart above.

Greases recommended are:

John Deere Moly High Temperature/EP Grease (preferred)

SAE Multipurpose Grease with Extreme Pressure (EP) performance and containing 3 to 5 per cent molybdenum disulfide (preferred).

SAE multi-purpose EP grease.

Grease meeting MIL-G-10924C specifications may be used as arctic grease.

018;T91371 02T,45 J10. 140188

COOLANT REQUIREMENTS

Coolant solutions used in John Deere Engines must meet the following basic requirements:

- Provide for adequate heat transfer.
- Provide a corrosion—resistant environment within the cooling system.
- Prevent formation of scale or sludge deposits in the cooling system.
- Be compatible with cooling system hose and seal materials.

Provide adequate freeze protection during cold weather operation and boil-over protection in hot weather.

NOTE: In some areas outside United States and Canada, John Deere Engine Cooling Fluid is marketed for use in the engine cooling system. It protects the engine from corrosion and freezing down to -37°C (-35°F).

John Deere Engine Cooling Fluid is ready to use without dilution or mixing. Consult parts catalog and check for local availability. Where available, the cooling fluid is the preferred coolant to use.

02T;45 K32 231187

To meet the requirements, the coolant has to consist of high quality water, the correct type antifreeze, and adequate inhibitors.


1. Water Quality

Preferred—Distilled or deionized

Acceptable—Softened to 170 Parts Per Million (10 Grains per Gallon)

WATER QUALITY SPECIFICATIONS

	Parts Per Million Max.	Grains per Gallon Max.
Chlorides	40	2.5
Sulfates	100	5.8
Total Dissolved Solids	340	20
Total Hardness	170	10



018;T6604AE 02T;45 K33 151287

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com