

624K 4WD Loader Operation and Test

(PIN: 1BZ624K_ _ _C000001—001000)

(PIN: 1BZ624K_ _ _D000001—001000)

OPERATION & TEST TECHNICAL MANUAL

624K 4WD Loader

TM13210X19 20DEC18 (ENGLISH)

Introduction

Foreword

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages. (See your John Deere dealer to order.)

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction of forward travel.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I.N.) in the Machine Numbers section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their

equipment as described in this manual. The warranty is explained on the warranty certificate or statement which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

THE TIRE MANUFACTURER'S warranty supplied with your machine may not apply outside the U.S.

If you are not the original owner of this machine, it is in your interest to contact your local John Deere dealer to inform them of this unit's serial number. This will help John Deere notify you of any issues or product improvements.

DX,IFC7 -19-03APR09-1/1

Manual Identification—READ THIS FIRST!

IMPORTANT: Use only supporting manuals designated for your specific machine. If incorrect manual is chosen, improper service may occur. Verify product identification number (PIN) and engine model number when choosing the correct manual.

Choosing the Correct Supporting Manuals

John Deere four wheel drive (4WD) loaders are available in different machine configurations based on the various markets into which they are sold. Different supporting manuals exist for different machine configurations.

When necessary, product identification numbers (PINs) are listed on the front covers of 4WD loader manuals. These numbers are used to identify the correct supporting manual for your machine.

Product Identification Number

The product identification number (PIN) plate (1) is located on left side of machine frame under the cab door. Each machine has a 17-character PIN (3) shown on this plate.



PIN Plate Location



PIN Plate (17 character)

1— PIN Plate

2— 17 Character PIN

TX1075239A—UN—15APR10

TX1155354—UN—03MAR14

The PIN identifies the producing factory, machine model number, machine option, year of manufacture, engine emission level, and machine serial number.

The following is an example for a 624K machine that meets Tier 2 and Stage II emission levels:

17-Character PIN Example																
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	B	Z	6	2	4	K	Z	-	-	C	1	2	3	4	5	6

- **(1—3) World Code:** Identifies location where machine is manufactured.

1BZ	World Code
1DW	Davenport Works
1T8	Thibodaux Works
1T0	Dubuque Works
1FF	Deere—Hitachi (Kernersville, NC, USA)
1F9	Deere—Hitachi (Indaiatuba, São Paulo, Brazil)
1BZ	Brazil Works (Indaiatuba, São Paulo, Brazil)

- **(4—8) Machine Model Identifier:** Identifies model number.

624K Machine Model Identifier

Z Machine Option Code

Z	Standard Z-Bar
H	High Lift Z-Bar

- **(9) Check Letter:** This is a random character assigned by the factory. This is not used in machine identification.

- Check Letter (variable)

- **(10) Manufacturing Year Code:** Identifies year of machine manufacture.

- Manufacturing Year Code (variable)

D 2013

E 2014

F 2015

G 2016

- **(11) Engine Emission Code:** Represents engine emission certification.

C Engine Emission Code

C Tier 2 and Stage II

D Tier 3 and Stage III A

E Interim Tier 4 and Stage III B

F Tier 4

G Interim Tier 4 and Stage III A (19-56 kW)

H Final Tier 4 and Stage III A (19-37 kW)

J Final Tier 4 and Stage III A (37-56 kW)

K Final Tier 4 (8-19 kW)

- **(12—17) Machine Serial Number:** Identifies machine serial number. This character will change from one machine to another.

123456 Machine Serial Number

Contents

Section 9000—General Information

Group 01—Safety

Section 9001—Diagnostics

Group 10—Engine Control Unit (ECU) Diagnostic
Trouble Codes
Group 20—Transmission Control Unit (TCU) Diagnostic
Trouble Codes
Group 30—Vehicle Control Unit (VCU) Diagnostic
Trouble Codes
Group 40—Sealed Switch Module (SSM) Diagnostic
Trouble Codes
Group 50—Advanced Display Unit (ADU) Diagnostic
Trouble Codes
Group 60—Radar Object Detection (ROD) Diagnostic
Trouble Codes

Section 9005—Operational Checkout Procedure

Group 10—Operational Checkout Procedure

Section 9010—Engine

Group 05—Theory of Operation
Group 15—Diagnostic Information
Group 25—Tests

Section 9015—Electrical System

Group 05—System Information
Group 10—System Diagrams
Group 15—Sub-System Diagnostics
Group 16—Monitor Operation
Group 20—References

Section 9020—Power Train

Group 05—Theory of Operation
Group 15—Diagnostic Information
Group 20—Adjustments
Group 25—Tests

Section 9025—Hydraulic System

Group 05—Theory of Operation
Group 15—Diagnostic Information
Group 20—Adjustments
Group 25—Tests

Section 9031—Heating and Air Conditioning

Group 05—Theory of Operation
Group 15—Diagnostic Information
Group 25—Tests

*Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication.
The right is reserved to make changes at any time without notice.*

COPYRIGHT © 2018
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright © 2014, 2015, 2016, 2017

Section 9000 General Information

Contents

	Page
Group 01—Safety	
Recognize Safety Information	9000-01-1
Follow Safety Instructions.....	9000-01-1
Operate Only If Qualified	9000-01-1
Wear Protective Equipment.....	9000-01-2
Avoid Unauthorized Machine	
Modifications.....	9000-01-2
Inspect Machine	9000-01-2
Stay Clear of Moving Parts.....	9000-01-2
Avoid High-Pressure Fluids	9000-01-3
Avoid High-Pressure Oils	9000-01-3
Work In Ventilated Area.....	9000-01-4
Prevent Fires	9000-01-4
Avoid Static Electricity Risk When	
Refueling	9000-01-5
Clean Debris from Machine.....	9000-01-5
Prevent Battery Explosions	9000-01-5
Handle Chemical Products Safely.....	9000-01-6
Decommissioning — Proper	
Recycling and Disposal of Fluids	
and Components	9000-01-6
Prepare for Emergencies.....	9000-01-7
Add Cab Guarding for Special	
Uses	9000-01-7
Do Not Use Starting Fluid.....	9000-01-7
Use Steps and Handholds	
Correctly	9000-01-7
Start Only From Operator's Seat.....	9000-01-8
Use and Maintain Seat Belt.....	9000-01-8
Prevent Unintended Machine	
Movement.....	9000-01-8
Avoid Work Site Hazards.....	9000-01-9
Use Special Care When Operating	
Loader	9000-01-10
Keep Riders Off Machine	9000-01-10
Avoid Backover Accidents.....	9000-01-10
Avoid Machine Tip Over	9000-01-11
Operating on Slopes.....	9000-01-11
Operating or Traveling On Public	
Roads	9000-01-12
Inspect and Maintain ROPS	9000-01-12
Add and Operate Attachments	
Safely.....	9000-01-12
Park and Prepare for Service	
Safely.....	9000-01-13
Service Cooling System Safely	9000-01-13
Service Tires Safely.....	9000-01-14
Remove Paint Before Welding or	
Heating	9000-01-14
Make Welding Repairs Safely	9000-01-15
Drive Metal Pins Safely	9000-01-15

Recognize Safety Information

This is the safety alert symbol. When you see this symbol on your machine or in this manual, be alert for the potential of personal injury.

Follow the precautions and safe operating practices highlighted by this symbol.

A signal word — DANGER, WARNING, or CAUTION — is used with the safety alert symbol. DANGER identifies the most serious hazards.

On your machine, DANGER signs are red in color, WARNING signs are orange, and CAUTION signs are yellow. DANGER and WARNING signs are located near specific hazards. General precautions are on CAUTION labels.



TX,RECOGNIZE -19-28JUN10-1/1

T133555 —UN—15APR13

T133588 —19—28AUG00

Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Use this operator's manual for correct safety sign placement. Be sure that new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine could impair the function or safety and affect machine life.



If you do not understand any part of this manual and need assistance, contact your John Deere dealer.

TX,FOLLOW -19-20JAN11-1/1

TS201 —UN—15APR13

Operate Only If Qualified

Do not operate this machine unless the operator's manual has been read carefully, and you have been qualified by supervised training and instruction.

Operator should be familiar with the job site and surroundings before operating. Try all controls and

machine functions with the machine in an open area before starting to work.

Know and observe all safety rules that may apply to every work situation and work site.

TX,QUALIFIED -19-18JAN11-1/1


Wear Protective Equipment

Guard against injury from flying pieces or metal or debris; wear goggles or safety glasses.

Wear close fitting clothing and safety equipment appropriate to the job.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear suitable hearing protection such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises. Radio or music headphones are not suitable to use for hearing protection.



TS206—UN—15APR13

TX,WEAR,PE -19-22SEP10-1/1

Avoid Unauthorized Machine Modifications

John Deere recommends using only genuine John Deere replacement parts to ensure machine performance. Never substitute genuine John Deere parts with alternate parts not intended for the application as these can create hazardous situations or hazardous performance. Non-John Deere Parts, or any damage or failures resulting from their use, are not covered by any John Deere warranty.

Modifications of this machine, or addition of unapproved products or attachments, may affect machine stability or

reliability, and may create a hazard for the operator or others near the machine. The installer of any modification which may affect the electronic controls of this machine is responsible for establishing that the modification does not adversely affect the machine or its performance.

Always contact an authorized John Deere dealer before making machine modifications that change the intended use, weight, or balance of the machine, or that alter machine controls, performance, or reliability.

AM40430,00000A9 -19-02JUN15-1/1

Inspect Machine

Inspect machine carefully each day by walking around it before starting.

Keep all guards and shields in good condition and properly installed. Fix damage and replace worn or broken parts immediately. Pay special attention to hydraulic hoses and electrical wiring.



T6607AQ—UN—15APR13


TX,INSPECT -19-08SEP10-1/1

Stay Clear of Moving Parts

Entanglements in moving parts can cause serious injury.

Stop engine before examining, adjusting, or maintaining any part of machine with moving parts.

Keep guards and shields in place. Replace any guard or shield that has been removed for access as soon as service or repair is complete.



T133592—UN—15APR13

TX,MOVING,PARTS -19-20JAN11-1/1

Avoid High-Pressure Fluids

Inspect hydraulic hoses periodically – at least once per year – for leakage, kinking, cuts, cracks, abrasion, blisters, corrosion, exposed wire braid or any other signs of wear or damage.


Replace worn or damaged hose assemblies immediately with John Deere approved replacement parts.

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar



with this type of injury should reference a knowledgeable medical source. Such information is available in English from Deere & Company Medical Department in Moline, Illinois, U.S.A., by calling 1-800-822-8262 or +1 309-748-5636.

DX,FLUID -19-12OCT11-1/1


X9811 —UN—23AUG88

Avoid High-Pressure Oils

This machine uses a high-pressure hydraulic system. Escaping oil under pressure can penetrate the skin causing serious injury.

Never search for leaks with your hands. Protect hands. Use a piece of cardboard to find location of escaping oil. Stop engine and relieve pressure before disconnecting lines or working on hydraulic system.

If hydraulic oil penetrates your skin, see a doctor immediately. Injected oil must be removed surgically within hours or gangrene could result. Contact a knowledgeable medical source or the Deere & Company Medical Department in Moline, Illinois, U.S.A.



TX,HPOILS -19-20JAN11-1/1


T133509 —UN—15APR13

T133840 —UN—20SEP00

Work In Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



TS220 —UN—15APR13

DX,AIR -19-17FEB99-1/1

Prevent Fires

Handle Fluids Safely: All fuels, most lubricants, and some coolant mixtures are flammable. Store flammable fluids away from fire hazards. Never refuel machine while smoking or when near sparks or flame.

Clean Machine Regularly: Keep flammable debris (trash, leaves, twigs, straw, and so forth), grease and oil from accumulating in engine compartment, around fuel lines, hydraulic lines, exhaust components, and electrical wiring. Never store oily rags or flammable materials inside a machine compartment.

Maintain Hoses, Tubes, and Wiring: Replace hoses and tubes immediately if they begin to leak, and clean up any oil spills. Examine electrical wiring and connectors frequently for damage.

Keep A Fire Extinguisher Available: Always keep a multipurpose fire extinguisher on or near the machine. Know how to use an extinguisher properly.

Be Aware of the Operating Environment: Airborne debris may contain sparks or embers. Do not operate near any flame.



T133553 —UN—07SEP00



T133554 —UN—07SEP00



T133552 —UN—15APR13

TX,PREVENT,FIRE -19-09JUN16-1/1


Avoid Static Electricity Risk When Refueling

The removal of sulfur and other compounds in Ultra-Low Sulfur Diesel (ULSD) fuel decreases its conductivity and increases its ability to store a static charge.

Refineries may have treated the fuel with a static dissipating additive. However, there are many factors that can reduce the effectiveness of the additive over time.

Static charges can build up in ULSD fuel while it is flowing through fuel delivery systems. Static electricity discharge when combustible vapors are present could result in a fire or explosion.

Therefore, it is important to ensure that the entire system used to refuel your machine (fuel supply tank, transfer pump, transfer hose, nozzle, and others) is properly grounded and bonded. Consult with your fuel or fuel system supplier to ensure that the delivery system is in compliance with fueling standards for proper grounding and bonding practices.



RG22142 —UN—17MAR14

RG21992 —UN—21AUG13

DX,FUEL,STATIC,ELEC -19-12JUL13-1/1


Clean Debris from Machine

Keep engine compartment, radiator, batteries, hydraulic lines, exhaust components, fuel tank, and operator's station clean and free of debris.

Clean any oil spills or fuel spills on machine surfaces.

Temperature in engine compartment could go up immediately after engine is stopped. **BE ON GUARD FOR FIRES DURING THIS PERIOD.**

Open access door(s) to cool the engine faster, and clean engine compartment.



T6669AG —UN—15APR13

TX,DEBRIS -19-20JAN11-1/1

Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a volt-meter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).



TS204 —UN—15APR13

DX,SPARKS -19-03MAR93-1/1


Handle Chemical Products Safely

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)




TS1132—UN—15APR13

DX,MSDS,NA -19-03MAR93-1/1

Decommissioning — Proper Recycling and Disposal of Fluids and Components

Safety and environmental stewardship measures must be taken into account when decommissioning a machine and/or component. These measures include the following:

- Use appropriate tools and personal protective equipment such as clothing, gloves, face shields or glasses, during the removal or handling of objects and materials.
- Follow instructions for specialized components.
- Release stored energy by lowering suspended machine elements, relaxing springs, disconnecting the battery or other electrical power, and releasing pressure in hydraulic components, accumulators, and other similar systems.
- Minimize exposure to components which may have residue from agricultural chemicals, such as fertilizers and pesticides. Handle and dispose of these components appropriately.
- Carefully drain engines, fuel tanks, radiators, hydraulic cylinders, reservoirs, and lines before recycling components. Use leak-proof containers when draining fluids. Do not use food or beverage containers.
- Do not pour waste fluids onto the ground, down a drain, or into any water source.
- Observe all national, state, and local laws, regulations, or ordinances governing the handling or disposal of waste fluids (example: oil, fuel, coolant, brake fluid);



TS1133—UN—15APR13

- filters; batteries; and, other substances or parts. Burning of flammable fluids or components in other than specially designed incinerators may be prohibited by law and could result in exposure to harmful fumes or ashes.
- Service and dispose of air conditioning systems appropriately. Government regulations may require a certified service center to recover and recycle air conditioning refrigerants which could damage the atmosphere if allowed to escape.
- Evaluate recycling options for tires, metal, plastic, glass, rubber, and electronic components which may be recyclable, in part or completely.
- Contact your local environmental or recycling center, or your John Deere dealer for information on the proper way to recycle or dispose of waste.


DX,DRAIN -19-01JUN15-1/1

Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 —UN—15APR13

DX,FIRE2 -19-03MAR93-1/1

Add Cab Guarding for Special Uses

Special work situations or machine attachments could create an environment with falling or flying objects. Working near an overhead bank, demolition work, using a hydraulic hammer or winch, working in a forestry application or wooded area, or working in a waste management application, for example, could require added guarding to protect the operator.

Additional level II FOPS (falling object protective structure), forestry protection packages, and special screens or guarding should be installed when falling or flying objects could enter or damage the machine. A rear screen should always be used with a winch to protect against a snapping cable. Before operating in any special work environments, follow the operator protection recommendations of the manufacturer of any specialized attachment or equipment. Contact your authorized John Deere dealer for information on protective guarding.

TX,CABGUARD -19-12FEB13-1/1

Do Not Use Starting Fluid

⚠ CAUTION: Avoid an explosion or fire. Machine is equipped with electrical cold start assist system. Do not use starting fluid of any type on the machine.

Fire, explosion, or engine damage will result from using starting fluids of any type on this machine.



Store Safely


T145705 —UN—18SEP01

MB60223,0000031 -19-07FEB14-1/1

Use Steps and Handholds Correctly

Prevent falls by facing the machine when you get on and off. Maintain 3-point contact with steps and handrails. Never use machine controls as handholds.

Use extra care when mud, snow, or moisture present slippery conditions. Keep steps clean and free of grease or oil. Never jump when exiting machine. Never mount or dismount a moving machine.



T133468 —UN—15APR13

TX,STEPS -19-09FEB11-1/1

Start Only From Operator's Seat

Avoid unexpected machine movement. Start engine only while sitting in operator's seat. Ensure that all controls and working tools are in proper position for a parked machine.

Never attempt to start engine from the ground. Do not attempt to start engine by shorting across the starter solenoid terminals.



T133715 —UN—15APR13

TX,SOFOS -19-20JAN11-1/1

Use and Maintain Seat Belt

Use seat belt when operating machine. Remember to fasten seat belt when loading and unloading from trucks and during other uses.

Examine seat belt frequently. Be sure that webbing is not cut or torn. Replace seat belt immediately if any part is damaged or does not function properly.

The complete seat belt assembly should be replaced every three years, regardless of appearance.



**USE
SEAT
BELT**

T133716 —19—17APR13

TX,SEAT,BELT -19-20JAN11-1/1

Prevent Unintended Machine Movement

Lower all equipment to the ground during work interruptions. Place transmission control in neutral, press park brake switch (1) to engage park brake, press pilot enable/boom down switch (2) to disable the hydraulics, and stop engine before allowing anyone to approach the machine.

Follow these same precautions before standing up, leaving the operator's seat, or exiting the machine.

1— Park Brake Switch

2— Pilot Enable/Boom Down Switch



TX1041772A —UN—02MAY08

DP99999,00000A3 -19-28JUN12-1/1

Avoid Work Site Hazards

Avoid contact with gas lines, buried cables, and water lines. Call utility line location services to identify all underground utilities before starting work.

Prepare work site properly. Avoid operating near structures or objects that could fall onto the machine. Clear away debris that could move unexpectedly if run over.


Avoid boom or attachment contact with overhead obstacles or overhead electrical lines. Never move machine closer than 3 m (10 ft.) plus twice the line insulator length to overhead wires.

Keep bystanders clear at all times. Keep bystanders away from raised booms, attachments, and unsupported loads. Avoid swinging or raising booms, attachments, or loads over or near personnel. Use barricades or a signal person to keep vehicles and pedestrians away. Use a signal person if moving machine in congested areas or where visibility is restricted. Always keep signal person in view. Coordinate hand signals before starting machine.


Operate only on solid footing with strength sufficient to support machine. Be especially alert working near embankments or excavations.

Avoid working under overhanging embankments or stockpiles that could collapse under or on machine.

Reduce machine speed when operating with tool on or near ground when obstacles may be hidden (e.g., during snow removal or clearing mud, dirt, etc.). At high speeds hitting obstacles (rocks, uneven concrete, or manholes) can cause a sudden stop. Always wear your seat belt.



Avoid Contact With Gas Line



Avoid Contact With Overhead Electrical Lines



Operate Only on Solid Footing

T141894—UN—15APR13

T141670—UN—24APR01

T141672—UN—04MAY01

DP99999,0000113 -19-23FEB15-1/1


Use Special Care When Operating Loader

Never use the loader to lift people. Do not allow anyone to ride in the bucket or use the bucket as a work platform.

Operate carefully with raised loads. Raising the load reduces machine stability, especially on side slopes or an unstable surface. Drive and turn slowly with a raised load.

Ensure that objects in the bucket are secure. Do not attempt to lift or carry objects that are too big or too long to fit inside the bucket unless secured with an adequate chain or other device. Keep bystanders away from raised loads.

Be careful when lifting objects. Never attempt to lift objects too heavy for your machine. Assure machine stability and hydraulic capability with a test lift before attempting other maneuvers. Use an adequate chain or sling and proper rigging techniques to attach and stabilize loads. Never lift an object above or near another person.



T141957—UN—15APR13

T141902—UN—07MAY01


TX03768,0000B70 -19-24FEB15-1/1

Keep Riders Off Machine

Only allow operator on machine.

Riders are subject to injury. They may fall from machine, be caught between machine parts, or be struck by foreign objects.

Riders may obstruct operator's view or impair his ability to operate machine safely.



Keep Riders Off Machine

T141671—UN—15APR13

TX03679,000179B -19-23FEB15-1/1

Avoid Backover Accidents

Before moving machine, be sure that all persons are clear of machine path. Turn around and look directly for best visibility. Use mirrors to assist in checking all around machine. Keep windows and mirrors clean, adjusted, and in good repair.

Be certain reverse warning alarm is working properly.

Use a signal person when backing if view is obstructed or when in close quarters. Keep signal person in view at all times. Use prearranged hand signals to communicate.

Do not rely on the rear camera and radar object detection systems, if equipped, to determine if personnel are behind the machine. The system has limitations due to maintenance practices, environmental conditions, and operating range.



PC10857XW—UN—15APR13

TX,AVOID,BACKOVER -19-04MAR16-1/1

Avoid Machine Tip Over

Use seat belt at all times.

Do not jump if the machine tips. You will be unlikely to jump clear and the machine may crush you.

Load and unload from trucks or trailers carefully. Be sure truck is wide enough and on a firm level surface. Use loading ramps and attach them properly to truck bed.

Be careful on slopes. Avoid sharp turns. Balance loads so weight is evenly distributed and load is stable. Carry tools and loads close to the ground to aid visibility and lower center of gravity. Use extra care on soft, rocky, or frozen ground.


Know the capacity of the machine. Do not overload. Be careful with heavy loads. Using oversized buckets or lifting heavy objects reduces machine stability.

Ensure solid footing. Use extra care in soft ground conditions that may not uniformly support the wheels, especially when raising the boom. Do not operate close to banks or open excavations that may cave in and cause machine to tip or fall.




Use Seat Belt

USE SEAT BELT



Do Not Jump



Ensure solid footing

TX03679,000179D -19-24FEB15-1/1

T133716—19—17APR13

T141676—UN—04MAY01


T141672—UN—04MAY01

Operating on Slopes

Avoid side slope travel whenever possible. Drive up steep slope in forward and down in reverse.

Select low gear speed before starting down slope. The grade of the slope will be limited by ground condition and load being handled.

Use service brakes to control speed. Sudden brake application with a loaded bucket on downhill side could cause machine to tip forward.



Operating on Slopes



TX03679,000179E -19-24FEB15-1/1

T141681—UN—15APR13

Operating or Traveling On Public Roads

Machines that work near vehicle traffic or travel slower than normal highway speeds must have proper lighting and markings to assure they are visible to other drivers.

Install additional lights, beacon lights, slow moving vehicle (SMV) emblems, or other devices and use as required to make the machine visible and identify it as a work machine. Check state and local regulations to assure compliance. Keep these devices clean and in working condition.



T141891—UN—15APR13

TX,ROADS -19-20JAN11-1/1

Inspect and Maintain ROPS

A damaged rollover protective structure (ROPS) should be replaced, not reused.

The protection offered by ROPS could be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting.

If ROPS was loosened or removed for any reason, inspect it carefully before operating the machine again.

To maintain the ROPS:

- Replace missing hardware using correct grade hardware.
- Check hardware torque.
- Check isolation mounts for damage, looseness, or wear; replace them if necessary.
- Check ROPS for cracks or physical damage.

TX,ROPS -19-20JAN11-1/1

Add and Operate Attachments Safely

Always verify compatibility of attachments by contacting your authorized dealer. Adding unapproved attachments could affect machine stability or reliability and could create a hazard for others near the machine.

Ensure that a qualified person is involved in attachment installation. Add guards to machine if operator protection

is required or recommended. Verify that all connections are secure and attachment responds properly to controls.

Carefully read attachment manual and follow all instructions and warnings. In an area free of bystanders and obstructions, carefully operate attachment to learn its characteristics and range of motion.

TX,ATTACH -19-20JAN11-1/1

Park and Prepare for Service Safely



Warn others of service work. Always park and prepare your machine for service or repair properly.

- Park machine on a level surface and lower equipment to the ground.
- Engage park brake.
- Stop engine.
- Install frame locking bar.
- Attach a DO NOT OPERATE tag in an obvious place in the operator's station.

Securely support machine or attachment before working under it.

- Do not support machine with boom, bucket, or other hydraulically actuated equipment.
- Do not support machine with cinder blocks or wooden pieces that can crumble or crush.
- Do not support machine with a single jack or other devices that could slip out of place.

Understand service procedures before beginning repairs. Keep service area clean and dry. Use two people whenever the engine must be running for service work.



T133332 —19—17APR13

TS229 —UN—23AUG88

TX,PARK,4WD -19-28JUN10-1/1

Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Do not service radiator through the radiator cap. Only fill through the surge tank filler cap. Shut off engine. Only remove surge tank filler cap when cool enough to touch with bare hands. Slowly loosen cap to relieve pressure before removing completely.



TS281 —UN—15APR13

TX,SURGE -19-19JAN11-1/1

Service Tires Safely


Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



TS211 —UN—15APR13

DX,RIM -19-24AUG90-1/1

Remove Paint Before Welding or Heating


Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 100 mm (4 in.) from area to be affected by heating. If paint cannot be removed, wear an approved respirator before heating or welding.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.



TS220 —UN—15APR13

Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.

DX,PAINT -19-24JUL02-1/1

Make Welding Repairs Safely

IMPORTANT: Disable electrical power before welding.
Turn off main battery switch and disconnect positive (+) and negative (-) battery cables.

Do not weld or apply heat on any part of a reservoir or tank that has contained oil or fuel. Heat from welding and cutting can cause oil, fuel, or cleaning solution to create gases which are explosive, flammable, or toxic.

Avoid welding or heating near pressurized fluid lines. Flammable spray may result and cause severe burns if pressurized lines malfunction as a result of heating. Do not let heat go beyond work area to nearby pressurized lines.

Remove paint properly. Do not inhale paint dust or fumes. Use a qualified welding technician for structural repairs.



Heating Near Pressurized Fluid Lines

Make sure there is good ventilation. Wear eye protection and protective equipment when welding.


T133547 —UN—15APR13

MB60223,0000212 -19-02JUL15-1/1

Drive Metal Pins Safely

Always wear protective goggles or safety glasses and other protective equipment before striking hardened parts. Hammering hardened metal parts such as pins and bucket teeth could dislodge chips at high velocity.

Use a soft hammer or a brass bar between hammer and object to prevent chipping.



T133738 —UN—15APR13

TX,PINS -19-20JAN11-1/1

Section 9001 Diagnostics

Contents

	Page		Page
Group 10—Engine Control Unit (ECU)			
Diagnostic Trouble Codes			
Engine Control Unit (ECU)		Friction Invalid Diagnostic	
Diagnostic Trouble Codes	9001-10-1	Procedure.....	9001-20-4
000091.03 — Accelerator Pedal Short		000514.09 — Timeout EEC3	
to Power	9001-10-1	Message.....	9001-20-5
000091.04 — Accelerator Pedal Open		Time out EEC3 Message Diagnostic	
or Short	9001-10-2	Procedure.....	9001-20-5
000091.14 — Accelerator Pedal		000544.02 — Reference Torque	
Sensor Invalid	9001-10-2	Invalid.....	9001-20-6
000170.00 — Engine Air Filter		Reference Torque Invalid Diagnostic	
Restricted	9001-10-2	Procedure.....	9001-20-6
Engine Air Filter Restricted Diagnostic		000544.09 — Timeout Engine	
Procedure.....	9001-10-2	Configuration Message	9001-20-7
000676.03 — Engine Heat Short to		Timeout Engine Configuration Mes-	
Power	9001-10-4	sage Diagnostic Procedure	9001-20-7
000676.05 — Engine Heat Open or		000777.02 — Torque Converter Clutch	
Short.....	9001-10-5	Slippage	9001-20-8
001321.05 — Starter Relay Open		Torque Converter Clutch Slippage	
Circuit.....	9001-10-6	Diagnostic Procedure.....	9001-20-8
001321.06 — Starter Relay High		000777.03 — Torque Converter Lockup	
Current	9001-10-7	Solenoid Short to Power	9001-20-10
001321.09 — Starter Signal		Torque Converter Lockup Solenoid	
Invalid.....	9001-10-8	Short to Power Diagnostic	
002003.09 — CAN Communication		Procedure.....	9001-20-10
Lost for TCU.....	9001-10-8	000777.04 — Torque Converter Lockup	
CAN Communication Lost For TCU		Solenoid Short to Ground.....	9001-20-11
Diagnostic Procedure.....	9001-10-8	Torque Converter Lockup Solenoid	
002033.09 — CAN Communication		Short to Ground Diagnostic	
Lost for VCU.....	9001-10-10	Procedure.....	9001-20-11
CAN Communication Lost for VCU		000777.05 — Torque Converter Lockup	
Diagnostic Procedure.....	9001-10-10	Solenoid Open Circuit	9001-20-12
Group 20—Transmission Control Unit (TCU)		Torque Converter Lockup Solenoid	
Diagnostic Trouble Codes			
Transmission Control Unit (TCU)		Open Circuit Diagnostic	
Diagnostic Trouble Codes	9001-20-1	Procedure.....	9001-20-12
000091.09 — Timeout EEC2		001785.09 — Engine Speed	
Message.....	9001-20-1	Limit Function Does Not Work	
Timeout EEC2 Message Diagnostic		Properly	9001-20-13
Procedure.....	9001-20-1	002033.09 — Controller Area Network	
000161.00 — Input Speed High	9001-20-2	(CAN) Communication Lost for	
000513.02 — Percent Torque		Vehicle Control Unit (VCU).....	9001-20-14
Invalid.....	9001-20-2	Controller Area Network (CAN)	
Percent Torque Invalid Diagnostic		Communication Lost for Vehicle	
Procedure.....	9001-20-2	Control Unit (VCU) Diagnostic	
000513.09 — Timeout EEC1		Procedure.....	9001-20-14
Message.....	9001-20-3	002141.09 — Controller Area	
Timeout EEC1 Message Diagnostic		Network (CAN) Communication	
Procedure.....	9001-20-3	Lost for Sealed Switch Module	
000514.02 — Friction Invalid.....	9001-20-4	(SSM).....	9001-20-16
		Controller Area Network (CAN)	
		Communication Lost for Sealed	
		Switch Module (SSM) Diagnostic	
		Procedure.....	9001-20-16

Continued on next page

Page	Page
004201.03 — Converter Input Speed Sensor Open or Short9001-20-18	Power Supply Low Voltage Diagnostic Procedure.....9001-20-30
004201.04 — Converter Input Speed Sensor Short to Ground9001-20-19	522375.00 — Transmission Oil Filter Restricted9001-20-31
004201.12 — Converter Input Speed Sensor Fault.....9001-20-20	Transmission Oil Filter Restricted Diagnostic Procedure.....9001-20-31
522344.00 — Torque Converter Overtemperature9001-20-20	522376.00 — Transmission Oil Temperature Over Maximum Value9001-20-33
Torque Converter Overtemperature Diagnostic Procedure.....9001-20-20	Transmission Oil Temperature Over Maximum Value Diagnostic Procedure.....9001-20-33
522350.15 — Transmission Input Torque Overload.....9001-20-21	522379.03 — Park Brake Solenoid Short to Power9001-20-34
Transmission Input Torque Overload Diagnostic Procedure.....9001-20-21	Park Brake Solenoid Short to Power Diagnostic Procedure.....9001-20-34
522364.07 — Transmission Clutch Calibration Failed9001-20-22	522379.04 — Park Brake Solenoid Short to Ground.....9001-20-35
Transmission Clutch Calibration Failed Diagnostic Procedure.....9001-20-22	Park Brake Solenoid Short to Ground Diagnostic Procedure.....9001-20-35
522364.13 — Transmission Clutch Calibration Fault9001-20-23	522379.05 — Park Brake Solenoid Open Circuit9001-20-37
Transmission Clutch Calibration Fault Diagnostic Procedure.....9001-20-23	Park Brake Solenoid Open Circuit Diagnostic Procedure.....9001-20-37
522365.13 — Limp Home Mode.....9001-20-24	522382.03 — Backup Alarm Short to Power.....9001-20-38
Limp Home Mode Diagnostic Procedure.....9001-20-24	Backup Alarm Short to Power Diagnostic Procedure.....9001-20-38
522366.12 — Application Invalid.....9001-20-24	522382.04 — Backup Alarm Short to Ground9001-20-38
Application Invalid Diagnostic Procedure.....9001-20-25	Backup Alarm Short to Ground Diagnostic Procedure.....9001-20-39
522367.13 — Transmission Control Unit (TCU) Configuration Invalid.....9001-20-25	522383.02 — Transmission Clutch KR Slippage9001-20-40
Transmission Control Unit (TCU) Configuration Invalid Diagnostic Procedure.....9001-20-25	Transmission Clutch KR Slippage Diagnostic Procedure.....9001-20-40
522368.02 — Transmission Control Unit (TCU) Memory Failure9001-20-26	522383.03 — Transmission Reverse Clutch Solenoid Short to Power9001-20-41
TCU Memory Failure Diagnostic Procedure.....9001-20-26	Transmission Reverse Clutch Solenoid Short to Power Diagnostic Procedure.....9001-20-41
522370.02 — Transmission Control Unit (TCU) Valve Power Supply 2 Short Circuit9001-20-27	522383.04 — Transmission Reverse Clutch Solenoid Short to Ground9001-20-43
Transmission Control Unit (TCU) Valve Power Supply 2 Short Circuit Diagnostic Procedure.....9001-20-27	Transmission Reverse Clutch Solenoid Short to Ground Diagnostic Procedure.....9001-20-43
522371.02 — Transmission Control Unit (TCU) Valve Power Supply 1 Short Circuit9001-20-28	522383.05 — Transmission Reverse Clutch Solenoid Open Circuit.....9001-20-44
Transmission Control Unit (TCU) Valve Power Supply 1 Short Circuit Diagnostic Procedure.....9001-20-28	Transmission Reverse Clutch Solenoid Open Circuit Diagnostic Procedure.....9001-20-44
522373.03 — Power Supply High Voltage9001-20-29	522386.02 — Transmission Clutch KV Slippage9001-20-46
Power Supply High Voltage Diagnostic Procedure.....9001-20-29	Transmission Clutch KV Slippage Diagnostic Procedure.....9001-20-46
522373.04 — Power Supply Low Voltage9001-20-30	

Continued on next page

Page	Page
522386.03 — Transmission Forward Clutch Solenoid Short to Power9001-20-47	522395.03 — Transmission Clutch K2 Solenoid Short to Power9001-20-66
Transmission Forward Clutch Solenoid Short to Power Diagnostic Procedure.....9001-20-47	Transmission Clutch K2 Solenoid Short to Power Diagnostic Procedure.....9001-20-66
522386.04 — Transmission Forward Clutch Solenoid Short to Ground9001-20-49	522395.04 — Transmission Clutch K2 Solenoid Short to Ground.....9001-20-67
Transmission Forward Clutch Solenoid Short to Ground Diagnostic Procedure.....9001-20-49	Transmission Clutch K2 Solenoid Short to Ground Diagnostic Procedure.....9001-20-67
522386.05 — Transmission Forward Clutch Solenoid Open Circuit9001-20-50	522395.05 — Transmission Clutch K2 Solenoid Open Circuit9001-20-69
Transmission Forward Clutch Solenoid Open Circuit Diagnostic Procedure.....9001-20-50	Transmission Clutch K2 Solenoid Open Circuit Diagnostic Procedure.....9001-20-69
522389.02 — Transmission Clutch K4 Slippage9001-20-52	522399.02 — Transmission Clutch K1 Slippage9001-20-70
Transmission Clutch K4 Slippage Diagnostic Procedure.....9001-20-52	Transmission Clutch K1 Slippage Diagnostic Procedure.....9001-20-70
522389.03 — Transmission Clutch K4 Solenoid Short to Power9001-20-53	522399.03 — Transmission Clutch K1 Solenoid Short to Power9001-20-72
Transmission Clutch K4 Solenoid Short to Power Diagnostic Procedure.....9001-20-54	Transmission Clutch K1 Solenoid Short to Power Diagnostic Procedure.....9001-20-72
522389.04 — Transmission Clutch K4 Solenoid Short to Ground.....9001-20-55	522399.04 — Transmission Clutch K1 Solenoid Short to Ground.....9001-20-73
Transmission Clutch K4 Solenoid Short to Ground Diagnostic Procedure.....9001-20-55	Transmission Clutch K1 Solenoid Short to Ground Diagnostic Procedure.....9001-20-73
522389.05 — Transmission Clutch K4 Solenoid Open Circuit9001-20-57	522399.05 — Transmission Clutch K1 Solenoid Open Circuit9001-20-75
Transmission Clutch K4 Solenoid Open Circuit Diagnostic Procedure.....9001-20-57	Transmission Clutch K1 Solenoid Open Circuit Diagnostic Procedure.....9001-20-75
522392.02 — Transmission Clutch K3 Slippage9001-20-58	522401.02 — Transmission Output Shaft Speed Sensor Fault9001-20-76
Transmission Clutch K3 Slippage Diagnostic Procedure.....9001-20-58	Transmission Output Shaft Speed Sensor Fault Diagnostic Procedure.....9001-20-76
522392.03 — Transmission Clutch K3 Solenoid Short to Power9001-20-60	522401.03 — Transmission Output Shaft Open or Short to Power9001-20-77
Transmission Clutch K3 Solenoid Short to Power Diagnostic Procedure.....9001-20-60	Transmission Output Shaft Open or Short to Power Diagnostic Procedure.....9001-20-77
522392.04 — Transmission Clutch K3 Solenoid Short to Ground.....9001-20-61	522401.04 — Transmission Output Shaft Short to Ground9001-20-79
Transmission Clutch K3 Solenoid Short to Ground Diagnostic Procedure.....9001-20-61	Transmission Output Shaft Short to Ground Diagnostic Procedure.....9001-20-79
522392.05 — Transmission Clutch K3 Solenoid Open Circuit9001-20-62	522401.12 — Transmission Output Shaft Fault.....9001-20-81
Transmission Clutch K3 Solenoid Open Circuit Diagnostic Procedure.....9001-20-63	Transmission Output Shaft Fault Diagnostic Procedure.....9001-20-81
522395.02 — Transmission Clutch K2 Slippage9001-20-64	522401.15 — Transmission Output Shaft Overspeed9001-20-82
Transmission Clutch K2 Slippage Diagnostic Procedure.....9001-20-64	Transmission Output Shaft Overspeed Diagnostic Procedure.....9001-20-82
	522402.03 — Clutch Speed Sensor Open or Short.....9001-20-83

Continued on next page

	Page
Internal Clutch Speed Sensor Open or Short Diagnostic Procedure	9001-20-83
522402.04 — Transmission Clutch Speed Sensor Short to Ground	9001-20-84
Transmission Clutch Speed Sensor Short to Ground Diagnostic Procedure.....	9001-20-84
522402.12 — Transmission Clutch Speed Sensor Fault	9001-20-85
Transmission Internal Clutch Speed Sensor Fault Diagnostic Procedure.....	9001-20-85
522407.03 — Transmission Clutch Cut-Off Sensor Short to Power	9001-20-86
Transmission Clutch Cut-Off Sensor Short to Power Diagnostic Procedure.....	9001-20-86
522407.04 — Transmission Clutch Cut-Off Sensor Open or Short to Ground	9001-20-87
Transmission Clutch Cut-Off Sensor Open or Short to Ground Diagnostic Procedure.....	9001-20-87
522409.05 — 2nd FNR (Pilot Control Joystick FNR) Open Circuit.....	9001-20-89
2nd FNR (Pilot Control Joystick FNR) Open Circuit Diagnostic Procedure.....	9001-20-89
522409.12 — 2nd FNR (Pilot Control Joystick FNR) Multiple Inputs	9001-20-91
2nd FNR (Pilot Control Joystick FNR) Multiple Inputs Diagnostic Procedure.....	9001-20-91
522411.05 — 1st FNR Open Circuit.....	9001-20-92
1st FNR (Steering Column FNR) Open Circuit Diagnostic Procedure.....	9001-20-93
1st FNR (Pilot Control Joystick FNR) Open Circuit Diagnostic Procedure.....	9001-20-93
522411.12 — 1st FNR Multiple Inputs	9001-20-95
1st FNR (Steering Column FNR) Multiple Inputs Diagnostic Procedure.....	9001-20-95
1st FNR Multiple Inputs (Pilot Control Joystick FNR) Diagnostic Procedure.....	9001-20-96
522412.12 — Gear Selection Error	9001-20-98
Gear Selection Error Diagnostic Procedure.....	9001-20-98
522419.02 — Transmission Clutch Cut-Off Disabled.....	9001-20-100

	Page
Transmission Clutch Cut-Off Disabled Diagnostic Procedure.....	9001-20-100
522420.02 — Manual Down Shift Disabled	9001-20-101
Manual Downshift Disabled Diagnostic Procedure.....	9001-20-101
522421.02 — Automatic to 1st Disabled	9001-20-102
Automatic to 1st Disabled Diagnostic Procedure.....	9001-20-102
524048.00 — Transmission Output Torque Exceeded	9001-20-102
Transmission Output Torque Exceeded Diagnostic Procedure.....	9001-20-102
524049.00 — Transmission Input Torque Exceeded	9001-20-103
Transmission Input Torque Exceeded Diagnostic Procedure.....	9001-20-103
524287.00 — Configure Machine Model	9001-20-103
Configure Machine Model Diagnostic Procedure.....	9001-20-103
524287.02 — Communication Error	9001-20-104

Group 30—Vehicle Control Unit (VCU) Diagnostic Trouble Codes

Vehicle Control Unit (VCU) Diagnostic Trouble Codes	9001-30-1
000075.00 — Front Axle Oil High Temperature	9001-30-1
Front Axle Oil High Temperature Diagnostic Procedure.....	9001-30-1
000075.04 — Front Axle Oil Temp Sensor Short to Ground	9001-30-2
Front Axle Oil Temp Sensor Short to Ground Diagnostic Procedure.....	9001-30-2
000096.04 — Fuel Level Short to Ground	9001-30-3
Fuel Level Short to Ground Diagnostic Procedure.....	9001-30-3
000096.05 — Fuel Level Open or Short.....	9001-30-4
Fuel Level Open or Short Diagnostic Procedure.....	9001-30-4
000167.16 — Alternator High Voltage	9001-30-6
Alternator High Voltage Diagnostic Procedure.....	9001-30-6
000167.18 — Alternator Low Voltage	9001-30-7
Alternator Low Voltage Diagnostic Procedure.....	9001-30-7
000168.16 — High Battery Voltage	9001-30-7
High Battery Voltage Diagnostic Procedure.....	9001-30-7

Continued on next page

Page	Page
000171.04 — Ambient Air Short to Ground9001-30-9	000785.05 — Pilot Solenoid Open or Short.....9001-30-20
000234.02 — Invalid Transmission Control Unit (TCU) Software Revision9001-30-9	Pilot Solenoid Open or Short Diagnostic Procedure.....9001-30-20
Invalid TCU Software Revision Diagnostic Procedure.....9001-30-9	000785.06 — Pilot Solenoid High Current9001-30-22
000521.00 — Brake Pedal High Voltage9001-30-9	Pilot Solenoid High Current Diagnostic Procedure.....9001-30-22
Brake Pedal High Voltage Diagnostic Procedure.....9001-30-10	000880.03 — Brake Lights Short to Power9001-30-24
000578.00 — Rear Axle Oil High Temperature9001-30-10	Brake Lights Short to Power Diagnostic Procedure.....9001-30-24
Rear Axle Oil High Temperature Diagnostic Procedure.....9001-30-10	000880.05 — Brake Lights Open or Short.....9001-30-25
000578.04 — Rear Axle Oil Temp Sensor Short to Ground9001-30-11	Brake Lights Open or Short Diagnostic Procedure.....9001-30-25
Rear Axle Oil Temp Sensor Short to Ground Diagnostic Procedure.....9001-30-11	000880.06 — Brake Lights High Current9001-30-26
000628.12 — Controller Not Programmed9001-30-12	Brake Lights High Current Diagnostic Procedure.....9001-30-26
Controller Not Programmed Diagnostic Procedure.....9001-30-12	000977.03 — Reversing Fan Solenoid Short to Power9001-30-27
000629.12 — Vehicle Control Unit (VCU) Watchdog Time Out9001-30-13	Reversing Fan Solenoid Short to Power Diagnostic Procedure.....9001-30-27
Vehicle Control Unit (VCU) Watchdog Time Out Diagnostic Procedure.....9001-30-13	000977.05 — Reversing Fan Solenoid Open or Short.....9001-30-28
000639.12 — Vehicle Control Unit (VCU) Controller Area Network (CAN) Failure9001-30-13	Reversing Fan Solenoid Open or Short Diagnostic Procedure.....9001-30-28
Vehicle Control Unit (VCU) Controller Area Network (CAN) Failure Diagnostic Procedure.....9001-30-13	000977.06 — Reversing Fan Solenoid High Current.....9001-30-30
000639.14 — Vehicle Control Unit (VCU) Controller Area Network (CAN) 1 Bus Off9001-30-14	Reversing Fan Solenoid High Current Diagnostic Procedure.....9001-30-30
Vehicle Control Unit (VCU) Controller Area Network (CAN) 1 Bus Off Diagnostic Procedure.....9001-30-14	001069.02 — Tire Size Incorrect9001-30-31
000746.03 — Differential Lock Solenoid Short to Power9001-30-15	Tire Size Incorrect Diagnostic Procedure.....9001-30-31
Differential Lock Solenoid Short to Power Diagnostic Procedure.....9001-30-15	001071.03 — Proportional Fan Solenoid High Side (HS) Short to Power9001-30-32
000746.05 — Differential Lock Solenoid Open9001-30-16	Proportional Fan Solenoid High Side (HS) Short to Power Diagnostic Procedure.....9001-30-32
Differential Lock Solenoid Open Diagnostic Procedure.....9001-30-16	001071.05 — Proportional Fan Solenoid High Side (HS) Open or Short.....9001-30-33
000746.06 — Differential Lock Solenoid High Current.....9001-30-18	Proportional Fan Solenoid High Side (HS) Open or Short Diagnostic Procedure.....9001-30-33
Differential Lock Solenoid High Current Diagnostic Procedure.....9001-30-18	001071.06 — Proportional Fan Solenoid High Side (HS) High Current9001-30-35
000785.03 — Pilot Solenoid Short to Power9001-30-19	Proportional Fan Solenoid High Side (HS) High Current Diagnostic Procedure.....9001-30-35
Pilot Solenoid Short to Power Diagnostic Procedure.....9001-30-19	001071.13 — Proportional Fan Solenoid Out of Calibration9001-30-36

Continued on next page

Page	Page		
001071.16 — Proportional Fan Solenoid Low Side (LS) High Current	9001-30-36	001639.05 — Fan Speed Sensor Open Circuit	9001-30-48
Proportional Fan Solenoid Low Side (LS) High Current Diagnostic Procedure	9001-30-36	Fan Speed Sensor Open Circuit	9001-30-48
001071.17 — Proportional Fan Solenoid Low Side (LS) Open or Short	9001-30-37	001639.07 — Fan Speed Did Not Lower During Reversal	9001-30-50
Proportional Fan Solenoid Low Side (LS) Open or Short Diagnostic Procedure	9001-30-37	001639.08 — Fan Speed Sensor No Signal	9001-30-50
001071.18 — Proportional Fan Solenoid Low Side (LS) Short to Power	9001-30-39	Fan Speed Sensor No Signal Diagnostic Procedure	9001-30-50
Proportional Fan Solenoid Low Side (LS) Short to Power Diagnostic Procedure	9001-30-39	001639.10 — Fan Speed Sensor Fault	9001-30-51
001231.12 — Vehicle Control Unit (VCU) Controller Area Network (CAN) 2 Failure	9001-30-40	Fan Speed Sensor Fault Diagnostic Procedure	9001-30-51
Vehicle Control Unit (VCU) Controller Area Network (CAN) 2 Failure Diagnostic Procedure	9001-30-40	001639.13 — Fan Speed Sensor Out of Calibration	9001-30-53
001231.14 — Vehicle Control Unit (VCU) Controller Area Network (CAN) 2 Bus Off	9001-30-41	001713.01 — Hydraulic Oil Filter Restricted	9001-30-53
Vehicle Control Unit (VCU) Controller Area Network (CAN) 2 Bus Off Diagnostic Procedure	9001-30-41	Hydraulic Oil Filter Restricted Diagnostic Procedure	9001-30-53
001550.03 — Air Conditioner Clutch Short to Power	9001-30-42	001762.03 — Hydraulic Pressure Sensor Short to Power	9001-30-54
Air Conditioner Clutch Short to Power Diagnostic Procedure	9001-30-42	Hydraulic System Pressure Sensor Short to Power Diagnostic Procedure	9001-30-54
001550.06 — Air Conditioner Clutch High Current	9001-30-42	001762.04 — Hydraulic Pressure Sensor Open or Short	9001-30-55
Air Conditioner Clutch High Current Diagnostic Procedure	9001-30-42	Hydraulic System Pressure Sensor Open or Short Diagnostic Procedure	9001-30-55
001638.00 — Hydraulic Oil High Temperature	9001-30-43	001841.03 — Blackout Brake Lights Short to Power	9001-30-56
Hydraulic Oil High Temperature Diagnostic Procedure	9001-30-43	Blackout Brake Lights Short to Power Diagnostic Procedure	9001-30-57
001638.04 — Hydraulic Oil Temperature Sensor Short to Ground	9001-30-44	001841.05 — Blackout Brake Lights Open or Short	9001-30-58
Hydraulic Oil Temperature Sensor Short to Ground Diagnostic Procedure	9001-30-44	Blackout Brake Lights Open or Short Diagnostic Procedure	9001-30-58
001639.02 — Fan Speed Sensor Out of Synchronization	9001-30-46	001841.06 — Blackout Brake Lights High Current	9001-30-59
Fan Speed Sensor Out of Synchronization Diagnostic Procedure	9001-30-46	Blackout Brake Lights High Current Diagnostic Procedure	9001-30-59
001639.04 — Fan Speed Sensor Short to Ground	9001-30-47	001842.03 — Blackout Lights Short to Power	9001-30-60
Fan Speed Sensor Short to Ground Diagnostic Procedure	9001-30-47	Blackout Lights Short to Power Diagnostic Procedure	9001-30-61
		001842.05 — Blackout Lights Open or Short	9001-30-62
		Blackout Lights Open or Short Diagnostic Procedure	9001-30-62
		001842.06 — Blackout Lights High Current	9001-30-64
		Blackout Lights High Current Diagnostic Procedure	9001-30-64
		002000.09 — Controller Area Network (CAN) Communication Lost for Engine Control Unit (ECU)	9001-30-66
		Controller Area Network (CAN) Communication Lost for Engine	

Continued on next page

Page	Page
Control Unit (ECU) Diagnostic Procedure.....9001-30-66	Drive Lamps Open or Short Diagnostic Procedure.....9001-30-79
002003.09 — Controller Area Network (CAN) Communication Lost for Transmission Control Unit (TCU).....9001-30-68	002350.06 — Drive Lamps High Current.....9001-30-81
Controller Area Network (CAN) Communication Lost for Transmission Control Unit (TCU) Diagnostic Procedure.....9001-30-68	Drive Lamps High Current Diagnostic Procedure.....9001-30-81
002033.14 — Flexpower Handshaking Error.....9001-30-69	002355.03 — Front Work Lights Short to Power.....9001-30-82
002040.09 — Controller Area Network (CAN) Communication Lost for Advanced Displaying Unit (ADU).....9001-30-70	Front Work Lights Short to Power.....9001-30-82
Controller Area Network (CAN) Communication Lost for Advanced Displaying Unit (ADU) Diagnostic Procedure.....9001-30-70	002355.05 — Front Work Lights Open or Short.....9001-30-83
002051.09 — Controller Area Network (CAN) Communication Lost for Tire Pressure Monitoring System (TPMS).....9001-30-71	Front Work Lights Open or Short Diagnostic Procedure.....9001-30-83
CAN Communication Lost for TPMS Diagnostic Procedure.....9001-30-71	002355.06 — Front Work Lights High Current.....9001-30-85
002132.09 — Controller Area Network (CAN) Communication Lost for Radar Object Detection (ROD).....9001-30-73	Front Work Lights High Current Diagnostic Procedure.....9001-30-85
Controller Area Network (CAN) Communication Lost for Radar Object Detection (ROD) Diagnostic Procedure.....9001-30-73	002356.03 — Front Work Lights Short to Power.....9001-30-86
002141.09 — Controller Area Network (CAN) Communication Lost for Sealed Switch Module (SSM).....9001-30-74	Front Work Lights Short to Power Diagnostic Procedure.....9001-30-87
Controller Area Network (CAN) Communication Lost for Sealed Switch Module (SSM) Diagnostic Procedure.....9001-30-74	002356.05 — Front Work Lights Open or Short.....9001-30-87
002169.09 — Controller Area Network (CAN) Communication Lost for Ground Speed Radar (RDR).....9001-30-76	Front Work Lights Open or Short Diagnostic Procedure.....9001-30-88
Controller Area Network (CAN) Communication Lost for Ground Speed Radar (RDR) Diagnostic Procedure.....9001-30-76	002356.06 — Front Work Lights High Current.....9001-30-89
002251.09 — Controller Area Network (CAN) Lost for JDLINK.....9001-30-78	Front Work Lights High Current Diagnostic Procedure.....9001-30-89
002350.03 — Drive Lamps Short to Power.....9001-30-78	002359.03 — Machine Work Lights Short to Power.....9001-30-90
Drive Lamps Short to Power Diagnostic Procedure.....9001-30-78	Machine Work Lights Short to Power Diagnostic Procedure.....9001-30-91
002350.05 — Drive Lamps Open or Short.....9001-30-79	002359.05 — Machine Work Lights Open or Short.....9001-30-91
	Machine Work Lights Open or Short Diagnostic Procedure.....9001-30-91
	002359.06 — Machine Work Lights High Current.....9001-30-93
	Machine Work Lights High Current Diagnostic Procedure.....9001-30-93
	002362.03 — Rear Work Lights Short to Power.....9001-30-94
	Rear Work Lights Short to Power Diagnostic Procedure.....9001-30-94
	002362.05 — Rear Work Lights Open or Short.....9001-30-95
	Rear Work Lights Open or Short Diagnostic Procedure.....9001-30-95
	002362.06 — Rear Work Lights High Current.....9001-30-97
	Rear Work Lights High Current Diagnostic Procedure.....9001-30-97
	002367.04 — Left Turn Switch Short to Ground.....9001-30-98
	Left Turn Switch Short to Ground Diagnostic Procedure.....9001-30-98

Continued on next page

Page	Page
002368.03 — Left Turn Lights Short to Power.....9001-30-99	002680.03 — Return-to-Carry (RTC)/Float Detent Short to Power.....9001-30-121
Left Turn Lights Short to Power Diagnostic Procedure.....9001-30-99	Return-to-Carry (RTC)/Float Detent Short to Power Diagnostic Procedure.....9001-30-121
002368.05 — Left Turn Lights Open or Short.....9001-30-100	002680.05 — Return-to-Carry (RTC)/Float Detent Open or Short.....9001-30-122
Left Turn Lights Open or Short Diagnostic Procedure.....9001-30-101	Return-to-Carry (RTC)/Float Detent Open or Short Diagnostic Procedure.....9001-30-122
002368.06 — Left Turn Lights High Current.....9001-30-102	002680.06 — Return-to-Carry (RTC)/Float Detent High Current.....9001-30-123
Left Turn Lights High Current Diagnostic Procedure.....9001-30-102	Return-to-Carry (RTC)/Float Detent High Current Diagnostic Procedure.....9001-30-123
002369.04 — Right Turn Switch Short to Ground.....9001-30-104	002717.03 — Return-to-Dig (RTD) Detent Short to Power.....9001-30-125
Right Turn Switch Short to Ground Diagnostic Procedure.....9001-30-104	Return-to-Dig (RTD) Detent Short to Power Diagnostic Procedure.....9001-30-125
002370.03 — Right Turn Lights Short to Power.....9001-30-105	002717.05 — Return-to-Dig (RTD) Detent Open or Short.....9001-30-125
Right Turn Lights Short to Power Diagnostic Procedure.....9001-30-105	Return-to-Dig (RTD) Detent Open or Short Diagnostic Procedure.....9001-30-126
002370.05 — Right Turn Lights Open or Short.....9001-30-106	002717.06 — Return-to-Dig (RTD) Detent High Current.....9001-30-127
Right Turn Lights Open or Short Diagnostic Procedure.....9001-30-106	Return-to-Dig (RTD) Detent High Current Diagnostic Procedure.....9001-30-127
002370.06 — Right Turn Lights High Current.....9001-30-108	002754.03 — Boom Height Kickout (BHKO) Detent Short to Power.....9001-30-128
Right Turn Lights High Current Diagnostic Procedure.....9001-30-108	Boom Height Kickout (BHKO) Detent Short to Power Diagnostic Procedure.....9001-30-128
002378.03 — Marker/Tail Lights Short to Power.....9001-30-110	002754.05 — Boom Height Kickout (BHKO) Detent Open or Short.....9001-30-129
Marker/Tail Lights Short to Power Diagnostic Procedure.....9001-30-110	Boom Height Kickout (BHKO) Detent Open or Short Diagnostic Procedure.....9001-30-129
002378.05 — Marker/Tail Lights Open Circuit.....9001-30-112	002754.06 — Boom Height Kickout (BHKO) Detent High Current.....9001-30-131
002378.06 — Marker/Tail Lights High Current.....9001-30-113	Boom Height Kickout (BHKO) Detent High Current Diagnostic Procedure.....9001-30-131
Marker/Tail Lights High Current Diagnostic Procedure.....9001-30-113	002875.04 — Hazard Wakeup Short to Ground.....9001-30-132
002386.03 — Beacon Light Short to Power.....9001-30-114	Hazard Wakeup Short to Ground Diagnostic Procedure.....9001-30-132
Beacon Light Short to Power Diagnostic Procedure.....9001-30-114	003509.04 — Vehicle Control Unit (VCU) Sensor 1 Voltage Low.....9001-30-133
002386.06 — Beacon Light High Current.....9001-30-115	Vehicle Control Unit (VCU) Sensor 1 Voltage Low Diagnostic Procedure.....9001-30-133
Beacon Light High Current Diagnostic Procedure.....9001-30-115	
002650.03 — Lockout Fan Solenoid Short to Power.....9001-30-116	
Lockout Fan Solenoid Short to Power Diagnostic Procedure.....9001-30-116	
002650.05 — Lockout Fan Solenoid Open or Short.....9001-30-117	
Lockout Fan Solenoid Open or Short Diagnostic Procedure.....9001-30-117	
002650.06 — Lockout Fan Solenoid High Current.....9001-30-119	
Lockout Fan Solenoid High Current Diagnostic Procedure.....9001-30-119	

Continued on next page

Page	Page
003510.04 — Vehicle Control Unit (VCU) Sensor 2 Voltage Low9001-30-135	Front Wiper Park Short to Ground Diagnostic Procedure.....9001-30-149
Vehicle Control Unit (VCU) Sensor 2 Voltage Low Diagnostic Procedure.....9001-30-135	522431.02 — Memory Test Failure.....9001-30-150
003511.04 — Vehicle Control Unit (VCU) Sensor 3 Voltage Low9001-30-136	Memory Test Failure Diagnostic Procedure.....9001-30-150
Vehicle Control Unit (VCU) Sensor 3 Voltage Low Diagnostic Procedure.....9001-30-136	522432.03 — Rear Wiper High Speed Short to Power9001-30-151
003598.02 — 7 V Supply Voltage Low.....9001-30-137	Rear Wiper High Speed Short to Power Diagnostic Procedure.....9001-30-151
7 V Supply Voltage Low Diagnostic Procedure.....9001-30-138	522432.05 — Rear Wiper High Speed Open Circuit.....9001-30-152
004086.03 — HPM Pressure Sensor Short to Power9001-30-138	Rear Wiper High Speed Open Circuit.....9001-30-152
Hydraulic Power Management (HPM) Pressure Sensor Short to Power Diagnostic Procedure.....9001-30-138	522432.06 — Rear Wiper High Speed High Current.....9001-30-154
004086.04 — HPM Pressure Sensor Open or Short.....9001-30-139	Rear Wiper High Speed High Current Diagnostic Procedure.....9001-30-154
Hydraulic Power Management (HPM) Pressure Sensor (B65) Open or Short Diagnostic Procedure9001-30-139	522433.03 — Rear Wiper Low Speed Short to Power9001-30-155
520194.02 — Invalid Vehicle Identification Number (VIN).....9001-30-141	Rear Wiper Low Speed Short to Power Diagnostic Procedure.....9001-30-155
521948.02 — Engine Tier Level Invalid.....9001-30-141	522433.05 — Rear Wiper Low Speed Open Circuit.....9001-30-156
Engine Tier Level Invalid Diagnostic Procedure.....9001-30-141	Rear Wiper Low Speed Open Circuit Diagnostic Procedure.....9001-30-156
521985.04 — Central Processing Unit (CPU) Switched Power Voltage Low.....9001-30-141	522433.06 — Rear Wiper Low Speed High Current.....9001-30-158
Central Processing Unit (CPU) Switched Power Voltage Low Diagnostic Procedure.....9001-30-142	Rear Wiper Low Speed High Current Diagnostic Procedure.....9001-30-158
522280.01 — Brake Pressure Low.....9001-30-143	522434.03 — Front Wiper Low Speed Short to Power9001-30-159
Brake Pressure Low Diagnostic Procedure.....9001-30-143	Front Wiper Low Speed Short to Power Diagnostic Procedure.....9001-30-159
522341.03 — Heated Mirror Short to Power.....9001-30-144	522434.05 — Front Wiper Low Speed Open Circuit.....9001-30-160
Heated Mirror Short to Power Diagnostic Procedure.....9001-30-144	Front Wiper Low Speed Open Circuit Diagnostic Procedure.....9001-30-160
522341.05 — Heated Mirror Open Circuit.....9001-30-145	522434.06 — Front Wiper Low Speed High Current.....9001-30-161
Heated Mirror Open Circuit Diagnostic Procedure.....9001-30-145	Front Wiper Low Speed High Current Diagnostic Procedure.....9001-30-162
522341.06 — Heated Mirror High Current.....9001-30-147	522435.03 — Front Wiper High Speed Short to Power9001-30-163
Heated Mirror High Current Diagnostic Procedure.....9001-30-147	Front Wiper High Speed Short to Power Diagnostic Procedure.....9001-30-163
522426.04 — Rear Wiper Park Short to Ground9001-30-148	522435.05 — Front Wiper High Speed Open Circuit.....9001-30-163
Rear Wiper Park Short to Ground Diagnostic Procedure.....9001-30-148	Front Wiper High Speed Open Circuit Diagnostic Procedure.....9001-30-163
522427.04 — Front Wiper Park Short to Ground9001-30-149	522435.06 — Front Wiper High Speed High Current.....9001-30-165
	Front Wiper High Speed High Current Diagnostic Procedure.....9001-30-165
	522436.03 — Bucket Position Short to Power9001-30-166
	Bucket Position Short to Power Diagnostic Procedure.....9001-30-166

Continued on next page

Page	Page
522436.04 — Bucket Position Open or Short.....9001-30-167	523219.04 — Switched Power Voltage Low.....9001-30-185
Bucket Position Open or Short Diagnostic Procedure.....9001-30-167	Switched Power Voltage Low Diagnostic Procedure.....9001-30-185
522437.04 — Return-to-Dig (RTD) Switch Short to Ground.....9001-30-169	523440.04 — Unswitched Power Voltage Low.....9001-30-187
Return-to-Dig (RTD) Switch Short to Ground Diagnostic Procedure.....9001-30-169	Unswitched Power Voltage Low Diagnostic Procedure.....9001-30-187
522438.03 — Pin Disconnect Solenoid Short to Power.....9001-30-170	523689.04 — Differential Lock Switch Short to Ground.....9001-30-188
Pin Disconnect Solenoid Short to Power Diagnostic Procedure.....9001-30-170	Differential Lock Switch Short to Ground Diagnostic Procedure.....9001-30-188
522438.05 — Pin Disconnect Solenoid Open or Short.....9001-30-171	523786.03 — Boom Position Sensor Short to Power.....9001-30-189
Pin Disconnect Solenoid Open or Short Diagnostic Procedure.....9001-30-171	Boom Position Sensor Short to Power Diagnostic Procedure.....9001-30-190
522438.06 — Pin Disconnect Solenoid High Current.....9001-30-173	523786.06 — Boom Position Sensor Short to Ground.....9001-30-190
Pin Disconnect Solenoid High Current Diagnostic Procedure.....9001-30-173	Boom Position Sensor Short to Ground Diagnostic Procedure.....9001-30-190
522620.03 — Vehicle Horn Short to Power.....9001-30-174	523837.01 — Brake Pressure Low—Rear.....9001-30-192
Vehicle Horn Short to Power Diagnostic Procedure.....9001-30-174	Brake Pressure Low—Rear Diagnostic Procedure.....9001-30-192
522620.05 — Vehicle Horn Open Circuit.....9001-30-175	523837.03 — Rear Brake Pressure Sensor Short to Power.....9001-30-192
Vehicle Horn Open Circuit Diagnostic Procedure.....9001-30-175	Rear Brake Pressure Sensor Short to Power Diagnostic Procedure.....9001-30-192
522620.06 — Vehicle Horn High Current.....9001-30-176	523837.04 — Rear Brake Pressure Open or Short.....9001-30-193
Vehicle Horn High Current Diagnostic Procedure.....9001-30-176	Rear Brake Pressure Open or Short Diagnostic Procedure.....9001-30-194
522796.03 — Rear Washer Pump Short to Power.....9001-30-177	523840.01 — Brake Pressure Low—Front.....9001-30-195
Rear Washer Pump Short to Power Diagnostic Procedure.....9001-30-177	Brake Pressure Low—Front Diagnostic Procedure.....9001-30-195
522796.05 — Rear Washer Pump Open or Short.....9001-30-178	523840.03 — Front Brake Pressure Sensor Short to Power.....9001-30-196
Rear Washer Pump Open or Short Diagnostic Procedure.....9001-30-178	Front Brake Pressure Sensor Short to Power Diagnostic Procedure.....9001-30-196
522796.06 — Rear Washer Pump High Current.....9001-30-180	523840.04 — Front Brake Pressure Sensor Open or Short.....9001-30-197
Rear Washer Pump High Current Diagnostic Procedure.....9001-30-180	Front Brake Pressure Sensor Open or Short Diagnostic Procedure.....9001-30-197
522797.03 — Front Washer Pump Short to Power.....9001-30-181	523865.04 — Add Truck Switch Short to Ground.....9001-30-199
Front Washer Pump Short to Power Diagnostic Procedure.....9001-30-181	Add Truck Switch Short to Ground Diagnostic Procedure.....9001-30-199
522797.05 — Front Washer Pump Open or Short.....9001-30-182	523867.04 — Counter Switch Short to Ground.....9001-30-200
Front Washer Pump Open or Short Diagnostic Procedure.....9001-30-182	Counter Switch Short to Ground Diagnostic Procedure.....9001-30-200
522797.06 — Front Washer Pump High Current.....9001-30-184	523868.04 — Add Bucket Switch Short to Ground.....9001-30-201
Front Washer Pump High Current Diagnostic Procedure.....9001-30-184	Add Bucket Switch Short to Ground Diagnostic Procedure.....9001-30-201

Continued on next page

	Page
523911.03 — Hydraulic Power Management Solenoid High Side Short to Power	9001-30-202
Hydraulic Power Management (HPM) Solenoid High Side Short to Power Diagnostic Procedure.....	9001-30-202
523911.05 — Hydraulic Power Management Solenoid High Side Open Circuit	9001-30-203
HPM Solenoid High Side Open Circuit Diagnostic Procedure.....	9001-30-204
523911.06 — Hydraulic Power Management Solenoid High Side High Current.....	9001-30-205
Hydraulic Power Management Solenoid High Side High Current Diagnostic Procedure.....	9001-30-205
523911.13 — Hydraulic Power Management System Out of Calibration	9001-30-206
523911.16 — Hydraulic Power Management Solenoid Low Side High Current.....	9001-30-206
Hydraulic Power Management Solenoid Low Side High Current Diagnostic Procedure.....	9001-30-206
523911.17 — Hydraulic Power Management Solenoid Low Side Open Circuit	9001-30-207
Hydraulic Power Management Solenoid Low Side Open Circuit Diagnostic Procedure.....	9001-30-207
523911.18 — Hydraulic Power Management Solenoid Low Side Short to Power	9001-30-209
Hydraulic Power Management Solenoid Low Side Short to Power Diagnostic Procedure.....	9001-30-209
523948.03 — Ride Control Solenoid Short to Power	9001-30-210
Ride Control Solenoid Short to Power Diagnostic Procedure.....	9001-30-211
523948.05 — Ride Control Solenoid Open Circuit	9001-30-211
Ride Control Solenoid Open Circuit Diagnostic Procedure.....	9001-30-211
523948.06 — Ride Control Solenoid High Current.....	9001-30-213
Ride Control Solenoid High Current Diagnostic Procedure.....	9001-30-213
524044.01 — Axle Oil Filter Restricted.....	9001-30-214
Axle Oil Filter Restricted Diagnostic Procedure.....	9001-30-214
524044.03 — Axle Oil Filter Short to Power	9001-30-215
Axle Oil Filter Short to Power Diagnostic Procedure.....	9001-30-215

524250.31 — Inspect Park Brake.....	9001-30-217
Inspect Park Brake Diagnostic Procedure.....	9001-30-217
524265.19 — Checksum Error.....	9001-30-217
Check Sum Error Diagnostic Procedure.....	9001-30-217

Group 40—Sealed Switch Module (SSM) Diagnostic Trouble Codes

Sealed Switch Module (SSM) Diagnostic Trouble Codes	9001-40-1
000629.12 — Sealed Switch Module (SSM) Watchdog Time Out	9001-40-1
SSM Watchdog Time Out Diagnostic Procedure.....	9001-40-1
002033.09 — Controller Area Network (CAN) Communication Lost For Vehicle Control Unit (VCU).....	9001-40-2
CAN Communication Lost for VCU Diagnostic Procedure.....	9001-40-2
002634.04 — Sealed Switch Module (SSM) Ignition Relay Signal Short to Ground	9001-40-3
Sealed Switch Module (SSM) Ignition Relay Signal Short to Ground Diagnostic Procedure.....	9001-40-3
002634.05 — Sealed Switch Module (SSM) Ignition Relay Signal Open Circuit.....	9001-40-4
Sealed Switch Module (SSM) Ignition Relay Signal Open Circuit Diagnostic Procedure.....	9001-40-4
520752.04 — Button 17 Keypad Stuck	9001-40-5
Button 17 Keypad Stuck Diagnostic Procedure.....	9001-40-5
520752.09 — Button 17 Light-Emitting Diode (LED) Message.....	9001-40-6
Button 17 Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-6
520753.04 — Front Washer Keypad Stuck	9001-40-8
Front Washer Keypad Stuck Diagnostic Procedure.....	9001-40-8
520754.04 — Front Wiper Keypad Stuck	9001-40-8
Front Wiper Keypad Stuck Diagnostic Procedure.....	9001-40-8
520754.09 — Lost Front Wiper Light-Emitting Diode (LED) Message.....	9001-40-9
Lost Front Wiper Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-9
520755.04 — Drive Lights Keypad Stuck	9001-40-11

Continued on next page

Page	Page		
Drive Lights Keypad Stuck Diagnostic Procedure.....	9001-40-11	Lost Air Conditioner Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-23
520755.09 — Lost Drive Lights Light-Emitting Diode (LED) Message.....	9001-40-11	523850.04 — Pin Disconnect Keypad Stuck	9001-40-25
Lost Drive Lights Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-11	Pin Disconnect Keypad Stuck Diagnostic Procedure.....	9001-40-25
523335.04 — Work Lights Keypad Stuck	9001-40-13	523850.09 — Lost Pin Disconnect Light-Emitting Diode (LED) Message.....	9001-40-26
Work Lights Keypad Stuck Diagnostic Procedure.....	9001-40-13	Lost Pin Disconnect Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-26
523335.09 — Lost Work Lights Light-Emitting Diode (LED) Message.....	9001-40-14	523852.04 — Spin Control Keypad Stuck	9001-40-27
Lost Work Lights Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-14	Spin Control Keypad Stuck Diagnostic Procedure.....	9001-40-27
523336.04 — Rear Wiper Keypad Stuck	9001-40-15	523852.09 — Lost Spin Control Light-Emitting Diode (LED) Message.....	9001-40-28
Rear Wiper Keypad Stuck Diagnostic Procedure.....	9001-40-15	Lost Spin Control Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-28
523336.09 — Lost Rear Wiper Light-Emitting Diode (LED) Message.....	9001-40-16	523854.04 — Differential Lock Keypad Stuck	9001-40-29
Lost Rear Wiper Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-16	Differential Lock Keypad Stuck Diagnostic Procedure.....	9001-40-29
523338.04 — Rear Washer Keypad Stuck	9001-40-17	523854.09 — Lost Differential Lock Light-Emitting Diode (LED) Message.....	9001-40-30
Rear Washer Keypad Stuck Diagnostic Procedure.....	9001-40-17	Lost Differential Lock Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-30
523339.04 — Axle Disconnect Keypad Stuck	9001-40-18	523855.04 — Return To Carry Keypad Stuck	9001-40-32
Axle Disconnect Keypad Stuck Diagnostic Procedure.....	9001-40-18	Return-to-Carry Keypad Stuck Diagnostic Procedure.....	9001-40-32
523339.09 — Lost Axle Disconnect Light-Emitting Diode (LED) Message.....	9001-40-19	523855.09 — Lost Return To Carry Light-Emitting Diode (LED) Message.....	9001-40-32
Lost Axle Disconnect Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-19	Lost Return-to-Carry Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-32
523340.04 — Button 21 Keypad Stuck	9001-40-20	523856.04 — Boom Height Kick Out Keypad Stuck	9001-40-34
Button 21 Keypad Stuck Diagnostic Procedure.....	9001-40-20	Boom Height Kick Out Keypad Stuck Diagnostic Procedure.....	9001-40-34
523340.09 — Button 21 Light-Emitting Diode (LED) Message.....	9001-40-21	523856.09 — Lost Boom Height Kick Out Light-Emitting Diode (LED) Message.....	9001-40-35
Button 21 Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-21	Lost Boom Height Kick Out Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-35
523849.04 — Air Conditioner Keypad Stuck	9001-40-23	523857.04 — Clutch Cut-Off Keypad Stuck	9001-40-36
Air Conditioner Keypad Stuck Diagnostic Procedure.....	9001-40-23	Clutch Cut-Off Keypad Stuck Diagnostic Procedure.....	9001-40-36
523349.09 — Lost Air Conditioner Light-Emitting Diode (LED) Message.....	9001-40-23		

Continued on next page

	Page
523857.09 — Lost Clutch Cut-Off Light-Emitting Diode (LED) Message.....	9001-40-37
Lost Clutch Cut-Off Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-37
523858.04 — Ride Control Keypad Stuck	9001-40-38
Ride Control Keypad Stuck Diagnostic Procedure.....	9001-40-38
523858.09 — Lost Ride Control Light-Emitting Diode (LED) Message.....	9001-40-39
Lost Ride Control Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-39
523860.04 — Auto Transmission Keypad Stuck.....	9001-40-41
Auto Transmission Keypad Stuck Diagnostic Procedure.....	9001-40-41
523860.09 — Lost Auto Transmission Light-Emitting Diode (LED) Message.....	9001-40-41
Lost Auto Transmission Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-42
523861.04 — Return To Dig Keypad Stuck	9001-40-43
Return-to-Dig Keypad Stuck Diagnostic Procedure.....	9001-40-43
523861.09 — Lost Return To Dig Light-Emitting Diode (LED) Message.....	9001-40-44
Lost Return-to-Dig Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-44
523862.04 — Park Brake Keypad Stuck	9001-40-45
Park Brake Keypad Stuck Diagnostic Procedure.....	9001-40-45
523862.09 — Lost Park Brake Light-Emitting Diode (LED) Message.....	9001-40-46
Lost Park Brake Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-46
523863.04 — Pilot Enable Keypad Stuck	9001-40-47
Pilot Enable Keypad Stuck Diagnostic Procedure.....	9001-40-47
523863.09 — Lost Pilot Enable Light-Emitting Diode (LED) Message.....	9001-40-48
Lost Pilot Enable Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-48
523864.04 — Hazards Keypad Stuck	9001-40-50

	Page
Hazards Keypad Stuck Diagnostic Procedure.....	9001-40-50
523864.09 — Lost Hazard Light-Emitting Diode (LED) Message.....	9001-40-50
Lost Hazard Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-50
523865.04 — Beacon Light Keypad Stuck	9001-40-52
Beacon Light Keypad Stuck Diagnostic Procedure.....	9001-40-52
523865.09 — Lost Beacon Light-Emitting Diode (LED) Message.....	9001-40-53
Lost Beacon Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-53
523867.04 — Ignition Off Keypad Stuck	9001-40-54
Ignition Off Keypad Stuck Diagnostic Procedure.....	9001-40-54
523867.09 — Lost Ignition Off Light-Emitting Diode (LED) Message.....	9001-40-55
523868.04 — Ignition On Keypad Stuck	9001-40-55
Ignition On Keypad Stuck Diagnostic Procedure.....	9001-40-55
523868.09 — Lost Ignition On Light-Emitting Diode (LED) Message.....	9001-40-56
Lost Ignition On Light-Emitting Diode (LED) Message Diagnostic Procedure.....	9001-40-56

**Group 50—Advanced Display Unit (ADU)
Diagnostic Trouble Codes**

Advanced Display Unit (ADU) Diagnostic Trouble Codes	9001-50-1
000158.03 — Switched Power Voltage High.....	9001-50-1
Switched Power Voltage High Diagnostic Procedure.....	9001-50-1
000158.04 — Switched Power Voltage Low.....	9001-50-2
Switched Power Voltage Low Diagnostic Procedure.....	9001-50-2
000168.03 — High Battery Voltage	9001-50-3
High Battery Voltage Diagnostic Procedure.....	9001-50-3
000168.04 — Low Battery Voltage	9001-50-4
Low Battery Voltage Diagnostic Procedure.....	9001-50-4
000442.00 — Display Temp High.....	9001-50-5

Continued on next page

	Page
Display Temp High Diagnostic Procedure.....	9001-50-5
000442.01 — Display Temp Low.....	9001-50-6
Display Temp Low Diagnostic Procedure.....	9001-50-6
001491.11 — LCD Backlight Failure	9001-50-6
LCD Backlight Failure Diagnostic Procedure.....	9001-50-6
003597.02 — 5 Volt Power Supply Invalid.....	9001-50-7
5 Volt Power Supply Invalid Diagnostic Procedure.....	9001-50-7
003598.02 — 1.5 Volt Power Supply Invalid.....	9001-50-7
1.5 Volt Power Supply Invalid Diagnostic Procedure.....	9001-50-7
003599.02 — 3.3 Volt Power Supply Invalid.....	9001-50-8
3.3 Volt Power Supply Invalid Diagnostic Procedure.....	9001-50-8
523436.14 — ADU Watchdog Time Out	9001-50-8
ADU Watchdog Time Out Diagnostic Procedure.....	9001-50-8
523438.31 — Memory Error	9001-50-9
Memory Error Diagnostic Procedure.....	9001-50-9
523651.02 — Memory Stack Overflow	9001-50-9
Memory Stack Overflow Diagnostic Procedure.....	9001-50-9
523773.03 — CAN HIGH Voltage High.....	9001-50-10
CAN HIGH Voltage High Diagnostic Procedure.....	9001-50-10
523773.04 — CAN HIGH Voltage Low.....	9001-50-10
CAN HIGH Voltage Low Diagnostic Procedure.....	9001-50-11
523774.03 — CAN LOW Voltage High.....	9001-50-11
CAN LOW Voltage High Diagnostic Procedure.....	9001-50-11
523774.04 — CAN LOW Voltage Low.....	9001-50-12
CAN LOW Voltage Low Diagnostic Procedure.....	9001-50-12
524076.10 — Information Button Stuck	9001-50-12
Information Button Stuck Diagnostic Procedure.....	9001-50-12
524077.10 — Back Key Button Stuck	9001-50-13
Back Key Button Stuck Diagnostic Procedure.....	9001-50-13
524078.10 — Menu Select Button Stuck	9001-50-13

	Page
Menu Select Button Stuck Diagnostic Procedure.....	9001-50-13
524080.10 — Down Arrow Button Stuck	9001-50-14
Down Arrow Button Stuck Diagnostic Procedure.....	9001-50-14
524082.10 — Up Arrow Button Stuck	9001-50-15
Up Arrow Button Stuck Diagnostic Procedure.....	9001-50-15

**Group 60—Radar Object Detection (ROD)
Diagnostic Trouble Codes**

Radar Object Detection (ROD) Diagnostic Trouble Codes	9001-60-1
000896.12 — ROD Unit Failure.....	9001-60-1
ROD Unit Failure Diagnostic Procedure.....	9001-60-1

Engine Control Unit (ECU) Diagnostic Trouble Codes

Engine Control Unit (ECU) Diagnostic Trouble Codes

The diagnostic trouble code number is indicated by a Suspect Parameter Number (SPN) and a Failure Mode Indicator (FMI) number. In the example **00091.03**, 91 is the SPN and 03 is the FMI number.

Diagnostic trouble codes can be displayed using the advanced display unit (ADU) or by using Service ADVISOR™.

- See Display Unit—Main Menu—Codes. (Operator's Manual.)
- See Reading Diagnostic Trouble Codes with Service ADVISOR™ Diagnostic Application. (Group 9015-20.)

For in-depth diagnostics on machine specific ECU diagnostic trouble codes, see specific code diagnostic procedures in this group. Additional engine control unit DTC diagnostic procedures for John Deere PowerTech Plus™ engines are located in the component technical

*Service ADVISOR is a trademark of Deere & Company
PowerTech Plus is a trademark of Deere & Company*




manual, PowerTech Plus 4.5 L and 6.8 L Diesel Engines—Level 14 Electronic Fuel System with Denso HPCR. (CTM320.)

M44215 —UN—07SEP88

TF19527,0001D20 -19-09SEP15-1/1

00091.03 — Accelerator Pedal Short to Power

Engine control unit (ECU) measures more than 4.75 volts on analog throttle position sensor (B14) circuit.



TX1201079

Accelerator Pedal Circuit

A1—Engine Control Unit (ECU)
B14— Accelerator Pedal Position Sensor

X3—Load Center Harness-to-Engine Harness Connector

X72 (J2)—Engine Control Unit Connector

Alarm Level:

- Warning Indicator

Machine Response:

- None

Circuit Information:

- See Vehicle Control Unit (VCU) Circuit Theory of Operation. (Group 9015-15.)
- See Engine Control Unit (ECU) Circuit Theory of Operation. (Group 9015-15.)

Component Location:

- See Engine Harness (W6) Component Location. (Group 9015-10.)
- See Load Center Harness (W3) Component Location. (Group 9015-10.)

Additional References:

- See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-20.)
- See Service ADVISOR™ Connection Procedure. (Group 9015-20.)

Possible Causes:


1. Circuit is shorted to power.
2. Software malfunction. Program controller.

TX1201079 —UN—10SEP15

TF19527,0001D21 -19-09SEP15-1/1

000091.04 — Accelerator Pedal Open or Short

Voltage is below normal, or shorted to low source.



TX1201079

Accelerator Pedal Circuit

A1—Engine Control Unit (ECU) X3—Load Center Harness-to-Engine Harness Connector X72 (J2)—Engine Control Unit Connector
 B14— Accelerator Pedal Position Sensor

Alarm Level:

- Warning Indicator

Machine Response:

- None

Circuit Information:

- See Vehicle Control Unit (VCU) Circuit Theory of Operation. (Group 9015-15.)
- See Engine Control Unit (ECU) Circuit Theory of Operation. (Group 9015-15.)

Component Location:

- See Engine Harness (W6) Component Location. (Group 9015-10.)
- See Load Center Harness (W3) Component Location. (Group 9015-10.)

Additional References:

- See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-20.)
- See Service ADVISOR™ Connection Procedure. (Group 9015-20.)

Possible Causes:

1. Circuit is open or shorted to ground.
2. Software malfunction. Program controller.

TF19527,0001D22 -19-09SEP15-1/1

000091.14 — Accelerator Pedal Sensor Invalid

Throttle voltage is above or below the specification.

This code is an informative code which tells that the primary analog throttle is either above or below the out of range specification.

To get the engine to change speed, either:

- Set the throttle to the minimum position, then increase it.
- Cycle the ignition key to OFF, then back to ON.

This is a safety feature used to keep the engine from running away after a throttle problem.

TF19527,0001D23 -19-09SEP15-1/1

000170.00 — Engine Air Filter Restricted

Engine air filter is restricted.

TF19527,0001D24 -19-24SEP18-1/7

Engine Air Filter Restricted Diagnostic Procedure

Alarm Level:

Engine Air Filter Icon

Continued on next page


TF19527,0001D24 -19-24SEP18-2/7

Engine Control Unit (ECU) Diagnostic Trouble Codes

<p>1 Intermittent Check</p>	<p>Does DTC periodically “go away”?</p>	<p>YES: DTC is intermittent. See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-20.)</p> <p>NO: Go to Component Check.</p> <p style="text-align: right; font-size: small;">TF19527,0001D24 -19-24SEP18-3/7</p>
<p>2 Engine Air Filter Check</p>	<p>Remove engine air filter.</p> <p>Inspect air filter and intake system.</p> <p>Is air filter or intake system clogged with excessive debris?</p>	<p>YES: Replace engine air filter. See Replace Engine Air Cleaner Elements. (Operator’s Manual.)</p> <p>NO: Go to Short Circuit Check.</p> <p style="text-align: right; font-size: small;">TF19527,0001D24 -19-24SEP18-4/7</p>
<p>3 Component Check</p>	<p>Ignition OFF.</p> <p>Disconnect engine air filter restriction switch (B19) and remove from air filter housing. See Engine Harness (W6) Component Location. (Group 9015-10.)</p> <p>Check for continuity across pins A and B.</p> <p>Is continuity indicated?</p>	<p>YES: Replace air filter restriction switch.</p> <p>NO: Go to Engine Air Filter Check.</p> <p style="text-align: right; font-size: small;">TF19527,0001D24 -19-24SEP18-5/7</p>
<p>4 Short Circuit Check</p>	<p>Ignition OFF.</p> <p>Disconnect engine control unit (ECU) connector (X72) and engine air filter restriction switch (B19). See Engine Harness (W6) Component Location. (Group 9015-10.)</p> <p>Ignition ON, engine OFF.</p> <p>Check circuit M006 PUR for voltage between pin F2 on ECU connector (X72) and all other pins.</p> <p>Is system voltage (approximately 24 volts) present?</p>	<p>YES: Circuit M06 PUR is short to power. Repair circuit or replace harness. See Engine Harness (W6) Wiring Diagram. (Group 9015-10.)</p> <p>NO: Go to Program Controller.</p> <p style="text-align: right; font-size: small;">TF19527,0001D24 -19-24SEP18-6/7</p>
<p>5 Program Controller</p>	<p>Program engine control unit (ECU).</p> <p>Check for active codes.</p> <p>Is ECU code 000107.00 present?</p>	<p>YES: Replace controller.</p> <p>NO: Checks complete.</p> <p style="text-align: right; font-size: small;">TF19527,0001D24 -19-24SEP18-7/7</p>

000676.03 — Engine Heat Short to Power

Glow plugs relay output is short to power when relay is energized by the engine control unit (ECU).



Engine Glow Plug Circuit

- A1—Engine Control Unit (ECU) Connector
- F65— Glow Plugs 50-Amp Fuse
- K5—Glow Plugs Relay
- M1—Starter Motor
- R21— Glow Plug (cylinder 1)
- R22— Glow Plug (cylinder 2)
- R23— Glow Plug (cylinder 3)
- R24— Glow Plug (cylinder 4)
- R25— Glow Plug (cylinder 5)
- R26— Glow Plug (cylinder 6)
- V6—Glow Plug Coil Suppression Diode
- X133— Engine Harness-to-Glow Plug Harness Connector
- X71— Engine Control Unit (ECU) Connector

Alarm Level:

- Warning Indicator

Machine Response:

- None

Circuit Information:

- See Engine Control Unit (ECU) Circuit Theory of Operation. (Group 9015-15.)

Component Location:

- See Engine Harness (W6) Wiring Diagram. (Group 9015-10.)

Diagnostic Test Box Information:

- Not Applicable

Additional References:

- See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-20.)
- See Service ADVISOR™ Connection Procedure. (Group 9015-20.)

Possible Causes:


1. Circuit is shorted to power.
2. Software malfunction. Program controller.

TF19527,0001D25 -19-02MAR18-1/1

XJ1253278—UN—02MAR18

000676.05 — Engine Heat Open or Short

Glow plugs relay output is low when relay is energized by the engine control unit (ECU).



Engine Glow Plug Circuit

- | | | | |
|------------------------------|-----------------------------|---|--|
| A1—Engine Control Unit (ECU) | R22— Glow Plug (cylinder 2) | R26— Glow Plug (cylinder 6) | X71— Engine Control Unit (ECU) Connector |
| F65— Glow Plugs 50-Amp Fuse | R23— Glow Plug (cylinder 3) | V6— Glow Plug Coil Suppression Diode | |
| K5—Glow Plugs Relay | R24— Glow Plug (cylinder 4) | X133— Engine Harness-to-Glow Plug Harness Connector | |
| M1—Starter Motor | R25— Glow Plug (cylinder 5) | | |
| R21— Glow Plug (cylinder 1) | | | |

Alarm Level:

- Warning Indicator

Machine Response:

- None

Circuit Information:

- See Engine Control Unit (ECU) Circuit Theory of Operation. (Group 9015-15.)

Component Location:

- See Engine Harness (W6) Wiring Diagram. (Group 9015-10.)

Diagnostic Test Box Information:

- Not Applicable

Additional References:

- See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-20.)
- See Service ADVISOR™ Connection Procedure. (Group 9015-20.)

Possible Causes:


1. Circuit is open or shorted to ground.
2. Software malfunction. Program controller.

TF19527.0001D26 -19-02MAR18-1/1

XJ1253278—UN—02MAR18

001321.05 — Starter Relay Open Circuit

Current is below normal or open circuit.



TX1201094

Starter Relay Circuit

- | | | |
|--------------------------------------|---|--|
| A1—Engine Control Unit (ECU) | K3—Starter Relay | X17— Vehicle Electrical Center (VEC) Connector |
| A10— Vehicle Electrical Center (VEC) | M1—Starter Motor | X72— Engine Control Unit (ECU) Connector |
| G1—Battery (2 used) | S2— Battery Disconnect Switch | |
| | X3— Load Center Harness-to-Engine Harness Connector | |

Alarm Level:

- Warning Indicator

Machine Response:

- None

Circuit Information:

- See Vehicle Control Unit (VCU) Circuit Theory of Operation. (Group 9015-15.)
- See Engine Control Unit (ECU) Circuit Theory of Operation. (Group 9015-15.)

Component Location:

- See Engine Harness (W6) Component Location. (Group 9015-10.)

- See Load Center Harness (W3) Component Location. (Group 9015-10.)

Diagnostic Test Box Information:

- Not Applicable.

Additional References:

- See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-20.)
- See Service ADVISOR™ Connection Procedure. (Group 9015-20.)

Possible Causes:


1. Circuit is open or shorted to ground.
2. Software malfunction. Program controller.

TF19527,0001D27 -19-09SEP15-1/1

TX1201094 —UN—10SEP15

001321.06 — Starter Relay High Current

Current is above normal.



TX1201094

Starter Relay Circuit

- A1—Engine Control Unit (ECU)
- A10— Vehicle Electrical Center (VEC)
- G1—Battery (2 used)
- K3—Starter Relay
- M1—Starter Motor
- S2—Battery Disconnect Switch
- X3— Load Center Harness-to-Engine Harness Connector
- X17— Vehicle Electrical Center (VEC) Connector
- X72— Engine Control Unit (ECU) Connector

Alarm Level:

- No Warning Indicator

Machine Response:

- None

Circuit Information:

- See Vehicle Control Unit (VCU) Circuit Theory of Operation. (Group 9015-15.)
- See Engine Control Unit (ECU) Circuit Theory of Operation. (Group 9015-15.)

Component Location:

- See Engine Harness (W6) Component Location. (Group 9015-10.)

- See Load Center Harness (W3) Component Location. (Group 9015-10.)

Diagnostic Test Box Information:

- Not Applicable.

Additional References:

- See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-20.)
- See Service ADVISOR™ Connection Procedure. (Group 9015-20.)


Possible Causes:

1. Circuit is shorted to power.
2. Software malfunction. Program controller.

TF19527,0001D28 -19-09SEP15-1/1

001321.09 — Starter Signal Invalid

Starter relay (K3) circuit is receiving an invalid start signal from engine control unit (ECU).



Starter Relay Circuit

- | | | |
|--------------------------------------|---|--|
| A1—Engine Control Unit (ECU) | K3—Starter Relay | X17— Vehicle Electrical Center (VEC) Connector |
| A10— Vehicle Electrical Center (VEC) | M1—Starter Motor | X72— Engine Control Unit (ECU) Connector |
| G1—Battery (2 used) | S2— Battery Disconnect Switch | |
| | X3— Load Center Harness-to-Engine Harness Connector | |

Alarm Level:

- No Warning Indicator

Machine Response:

- None

Circuit Information:

- See Vehicle Control Unit (VCU) Circuit Theory of Operation. (Group 9015-15.)
- See Engine Control Unit (ECU) Circuit Theory of Operation. (Group 9015-15.)

Component Location:

- See Engine Harness (W6) Component Location. (Group 9015-10.)

- See Load Center Harness (W3) Component Location. (Group 9015-10.)

Diagnostic Test Box Information:

- Not Applicable.

Additional References:

- See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-20.)
- See Service ADVISOR™ Connection Procedure. (Group 9015-20.)

Possible Causes:

1. Software malfunction. Program controller.

TF19527,0001D29 -19-09SEP15-1/1

002003.09 — CAN Communication Lost for TCU

CAN communication error; the engine control unit (ECU) has lost communication with the transmission control unit (TCU).

TF19527,0001D2A -19-24SEP18-1/9

CAN Communication Lost For TCU Diagnostic Procedure

Alarm Level:

No Warning Lamp

Continued on next page

TF19527,0001D2A -19-24SEP18-2/9

Engine Control Unit (ECU) Diagnostic Trouble Codes

1 Intermittent Check	Does DTC periodically “go away”?	<p>YES: DTC is intermittent. See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-20.)</p> <p>NO: Go to Controller Sensors Check.</p> <p style="text-align: right; font-size: small;">TF19527.0001D2A -19-24SEP18-3/9</p>
2 Controller Sensors Check	View transmission control unit (TCU) monitored sensor outputs, by accessing the Diagnostics / Transmission Sensors submenu on the advanced display unit (ADU). See Display Unit—Main Menu—Diagnostics—Transmission/Axle . (Operators Manual.) Are all transmission sensor values displayed on the ADU?	<p>YES: Go to Program Engine Control Unit.</p> <p>NO: Go to Fuse Check.</p> <p style="text-align: right; font-size: small;">TF19527.0001D2A -19-24SEP18-4/9</p>
3 Fuse Check	Ignition OFF. Remove fuses (F18 and F28). See Fuse and Relay Specifications . (Group 9015-10.) Check fuses (F18 and F28) for continuity. Is continuity indicated in both fuses?	<p>YES: Go to Voltage Check.</p> <p>NO: Replace fuse(s) without continuity indicated.</p> <p style="text-align: right; font-size: small;">TF19527.0001D2A -19-24SEP18-5/9</p>
4 Voltage Check	Ignition OFF. Disconnect transmission control unit (TCU) connector (X23). See Load Center Harness (W3) Component Location . (Group 9015-10.) Ignition ON, engine OFF. Check for voltage at the following pins on TCU connector (X23): <ul style="list-style-type: none"> • 23—circuit P018 RED • 45—circuit P028 RED • 68—circuit P018 RED Is voltage present at all pins?	<p>YES: Go to Ground Circuit Check.</p> <p>NO: Circuit(s) without voltage is open. Repair circuit or replace harness. See Load Center Harness (W3) Wiring Diagram. (Group 9015-10.)</p> <p style="text-align: right; font-size: small;">TF19527.0001D2A -19-24SEP18-6/9</p>

Continued on next page

Engine Control Unit (ECU) Diagnostic Trouble Codes

5 Ground Circuit Check	Ignition OFF.	
	<p>Disconnect transmission control unit (TCU) connector (X23). <u>See Load Center Harness (W3) Component Location.</u> (Group 9015-10.)</p> <p>Check circuit G001 BLK for ground at pins 1 and 2 on TCU connector (X23).</p> <p>Is ground present at all pins?</p>	<p>YES: Go to CAN Circuit Check.</p> <p>NO: Circuit G001 BLK is open. Repair circuit or replace harness. <u>See Load Center Harness (W3) Wiring Diagram.</u> (Group 9015-10.)</p>
		TF19527,0001D2A -19-24SEP18-7/9

6 CAN Circuit Check	Perform CAN circuit test. <u>See CAN Circuit Test.</u> (Group 9015-20.)	YES: Replace controller.
	Does CAN circuit test good?	NO: Repair CAN circuit.
		TF19527,0001D2A -19-24SEP18-8/9

7 Program Engine Control Unit	Program engine control unit (ECU).	
	<p>Check for active ECU codes.</p> <p>Is code 002003.09 present?</p>	<p>YES: Replace controller.</p> <p>NO: Checks complete.</p>
		TF19527,0001D2A -19-24SEP18-9/9

002033.09 — CAN Communication Lost for VCU	<i>CAN communication error, engine control unit (ECU) has lost communication with vehicle control unit (VCU)</i>
TF19527,0001D2B -19-24SEP18-1/11	

CAN Communication Lost for VCU Diagnostic Procedure
Alarm Level:
No Warning Lamp
TF19527,0001D2B -19-24SEP18-2/11

1 Intermittent Check	Does DTC periodically "go away"?	<p>YES: DTC is intermittent. <u>See Intermittent Diagnostic Trouble Code (DTC) Diagnostics.</u> (Group 9015-20.)</p> <p>NO: Go to Controller Sensors Check.</p>
		TF19527,0001D2B -19-24SEP18-3/11
Continued on next page		

Engine Control Unit (ECU) Diagnostic Trouble Codes

<p>2 Controller Sensors Check</p>	<p>Ignition ON, engine OFF.</p> <p>View vehicle control unit (VCU) monitored outputs by accessing the Diagnostics / Hydraulic Sensors submenu on the advanced display unit (ADU). <u>See Display Unit—Main Menu—Diagnostics—Hydraulic Sensors.</u> (Operators manual.)</p> <p>Does the monitor show a reading for all sensors?</p>	<p>YES: Go to Program Engine Control Unit.</p> <p>NO: Go to Fuse Check.</p> <p style="text-align: right; font-size: small;">TF19527,0001D2B -19-24SEP18-4/11</p>
<p>3 Fuse Check</p>	<p>Ignition OFF.</p> <p>Remove fuses (F15, F20 and F21). <u>See Fuse and Relay Specifications.</u> (Group 9015-10.)</p> <p>Check continuity of fuses (F15, F20 and F21).</p> <p>Is continuity indicated?</p>	<p>YES: Go to Ignition Relay Check.</p> <p>NO: Replace fuse (F15, F20 or F21).</p> <p style="text-align: right; font-size: small;">TF19527,0001D2B -19-24SEP18-5/11</p>
<p>4 Ignition Relay Check</p>	<p>Ignition OFF.</p> <p>Disconnect ignition relay (K4). <u>See Load Center Harness (W3) Component Location.</u> (Group 9015-10.)</p> <p>Apply 24 volts and ground to coil of ignition relay (K4).</p> <p>Check for continuity between remaining pins on ignition relay (K4).</p> <p>Is continuity indicated?</p>	<p>YES: Go to Power Circuit Check.</p> <p>NO: Ignition relay (K4) malfunction. Replace relay.</p> <p style="text-align: right; font-size: small;">TF19527,0001D2B -19-24SEP18-6/11</p>
<p>5 Power Circuit Check</p>	<p>Ignition OFF.</p> <p>Disconnect vehicle control unit (VCU) connectors (X40, X42, and X43). <u>See Load Center Harness (W3) Component Location.</u> (Group 9015-10.)</p> <p>Ignition ON, engine OFF.</p> <p>Check circuit B010 RED for voltage between pin 1 on VCU connector (X43) and machine ground.</p> <p>Check circuit P015 RED for voltage between pin M1 on VCU connector (X40) and machine ground.</p> <p>Check circuit P020 RED for voltage between pin 2 on VCU connector (X42) and machine ground.</p> <p>Check circuit P021 RED for voltage between pins L1 on VCU connector (X40) and machine ground.</p> <p>Is system voltage (approximately 24 volts) present?</p>	<p>YES: Go to Ground Circuit Check.</p> <p>NO: Open circuit in load center harness. Repair circuit with no voltage or replace load center harness. <u>See Load Center Harness (W3) Wiring Diagram.</u> (Group 9015-10.)</p> <p style="text-align: right; font-size: small;">TF19527,0001D2B -19-24SEP18-7/11</p>

Continued on next page

Engine Control Unit (ECU) Diagnostic Trouble Codes

6 Ground Circuit Check

Ignition OFF.

Disconnect vehicle control unit (VCU) connector (X40 and X41). [See Load Center Harness \(W3\) Component Location](#). (Group 9015-10.)

Check circuit G001 BLK for ground at pins F3, L2 and M2 on VCU connector (X40).

Check circuit G001 BLK for ground at pin 2 on VCU connector (X41).

Is ground present?

YES: Go to CAN Circuit Check.

NO: Open circuit in load center harness. Repair or replace harness. [See Load Center Harness \(W3\) Wiring Diagram](#). (Group 9015-10.)

TF19527,0001D2B -19-24SEP18-8/11

7 CAN Circuit Check

Perform CAN circuit test. [See CAN Circuit Test](#). (Group 9015-20.)

Does CAN circuit test good?

YES: Go to Program Vehicle Control Unit.

NO: Repair CAN circuit.

TF19527,0001D2B -19-24SEP18-9/11

8 Program Vehicle Control Unit

Program vehicle control unit (VCU).

Check for active codes.

Is ECU code 002033.09 present?

YES: Replace controller.

NO: Checks complete.

TF19527,0001D2B -19-24SEP18-10/11

9 Program Engine Control Unit

Program engine control unit (ECU).

Check for active codes.

Is ECU code 002033.09 present?

YES: Replace controller.

NO: Checks complete.

TF19527,0001D2B -19-24SEP18-11/11

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com