

6215, 6415, 6615 and 6715 Tractors

(Serial No. 398791-)

OPERATOR'S MANUAL 6215, 6415, 6615 and 6715 Tractors (Serial No. 398791 -)

OMAL162074 Issue G5 (ENGLISCH)

CALIFORNIA Proposition 65 Warning

Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

If this product contains a gasoline engine:

WARNING

The engine exhaust from this product contains chemicals known to the State of California to cause cancer, birth defects or other reproductive harm.

The State of California requires the above two warnings.

John Deere Werke Mannheim
(This manual replaces OMAL162074 A5)
North American Version
LITHO IN U.S.A.



DCY



OMAL162074

Introduction

Foreword

READ THIS MANUAL carefully to learn how to operate and service your machine correctly. Failure to do so could result in personal injury or equipment damage. This manual and safety signs on your machine may also be available in other languages. (See your John Deere dealer to order.)

THIS MANUAL SHOULD BE CONSIDERED a permanent part of your machine and should remain with the machine when you sell it.

MEASUREMENTS in this manual are given in both metric and customary U.S. unit equivalents. Use only correct replacement parts and fasteners. Metric and inch fasteners may require a specific metric or inch wrench.

RIGHT-HAND AND LEFT-HAND sides are determined by facing in the direction of forward travel.

WRITE PRODUCT IDENTIFICATION NUMBERS (P.I.N.) in the Specification or Identification Numbers section. Accurately record all the numbers to help in tracing the machine should it be stolen. Your dealer

also needs these numbers when you order parts. File the identification numbers in a secure place off the machine.

WARRANTY is provided as part of John Deere's support program for customers who operate and maintain their equipment as described in this manual. The warranty is explained on the warranty certificate which you should have received from your dealer.

This warranty provides you the assurance that John Deere will back its products where defects appear within the warranty period. In some circumstances, John Deere also provides field improvements, often without charge to the customer, even if the product is out of warranty. Should the equipment be abused, or modified to change its performance beyond the original factory specifications, the warranty will become void and field improvements may be denied. Setting fuel delivery above specifications or otherwise overpowering machines will result in such action.

THE TIRE MANUFACTURER'S warranty supplied with your machine may not apply outside the U.S.

DX,IFC1 -19-16NOV01-1/1

Contents

	Page		Page
Identification Views		Dome Light	25-6
Identification Views	00-1	Adjusting Steering Wheel	25-6
Safety	05-1	Beacon Light (Option).	25-6
Safety Decals		Back-up Alarm (Option)	25-6
Prevent Machine Runaway	10-1	Step Adjustment	25-7
Use Seat Belt	10-1	Installing Additional Controls	25-7
Operate Tractor Safely	10-2	3-Terminal Power Outlet Socket	25-8
Do Not Modify ROPS	10-2	Service ADVISOR™ - Socket	25-8
Avoid Explosive Gases	10-3		
Stay Clear of PTO	10-3	Break-In Period	
Controls and Instruments		After First 4 and 8 Hours of Operation	30-1
Vehicle Controls	15-1	Within the First 100 Hours of Operation	30-2
Attachment Controls	15-1	After First 100 Hours of Operation	30-3
Heater, Air-Conditioning and Windshield		Prestarting Checks	
Wiper Controls	15-2	Prestarting Check	35-1
Indicator Lights and Displays	15-2	Operating the Engine	
Lights		Positions of Main Switch	40-1
Light Switches	20-1	Starting the Engine	40-2
Work Light Switches	20-1	Cold Weather Starting Aids	40-3
Lights	20-2	Using Auxiliary Heaters	40-3
Use Safety Lights and Devices	20-2	Starting With a Booster Battery	40-4
Operating the Hazard Warning Light Switch	20-3	Fuel Preheater	40-4
Switch for Turn Signal Lights	20-3	Engine Warm-Up Period	40-4
Switch for Horn	20-3	Engines with Turbocharger	40-5
Seven-Terminal Outlet	20-4	Engine Protection	40-5
Operator's Platform and Cab		Towing the Tractor	40-6
Roll-Over Protective Structure	25-1	Parking the Tractor	40-6
Operating Foldable ROPS	25-1	Stopping the Engine	40-6
Seat Belt	25-2	Operating the Tractor	
Avoid Contact with Pesticides	25-2	Reduce Fuel Consumption	45-1
Clean Vehicle of Hazardous Pesticides	25-3	Select Correct Ground Travel Speed	45-3
Comfort Seat (Tractors without Cab)	25-3	Travel Speeds for 6215 and 6415	
Comfort Seat (Tractors with Cab)	25-4	Tractors, SyncroPlus Transmission (12/4)	45-4
Opening Windows	25-4	Travel Speeds for 6615 and 6715	
Windshield Wiper	25-4	Tractors, SyncroPlus Transmission (12/4)	45-5
Blower and Air Louvers	25-5	Travel Speeds, PowrReverser Transmission	
Heater	25-5	(16/16)	45-6
Air Conditioning System	25-5		

Continued on next page

All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2005
DEERE & COMPANY
European Office Mannheim
All rights reserved
A John Deere ILLUSTRATION® Manual
Previous Editions
Copyright © 2003

	Page		Page
Shifting SyncroPlus		Adjusting Front Wheel Tread	65-1
Transmission/PowrReverser Transmission . . .	45-7	Checking Front Wheel Toe-In	65-2
Shift Lever Positions, SyncroPlus		Adjusting Front Wheel Toe-In	65-2
Transmission/PowrReverser Transmission . . .	45-8	Changing Wheels Safely	65-2
Travel Speeds, PowrQuad Transmission		Adjusting Front Wheel Tread With	
(16/16)	45-9	Adjustable Rims	65-3
Shifting the PowrQuad Transmission	45-10	Tighten Front Wheel Attaching Nuts	65-4
Shift Lever Positions, PowrQuad		Check Front Wheel Toe-In	65-4
Transmission	45-11	Adjusting Front Wheel Toe-In	65-4
Engaging Creeper Transmission	45-11	Adjusting the Fender	65-5
Engaging Front Wheel Drive	45-12	Rear Wheel Tread Adjustment With	
Engaging Differential Lock	45-12	Flanged Axle	65-7
Hydraulic Foot Brakes	45-13	Positions of Rims and Wheel Disks	65-8
		Adjusting Wheel Tread With	
Rockshaft and Three-Point Hitch		Rack-and-Pinion Axle	65-9
Rockshaft Control	50-1	Positions of Rims and Wheel Disks with	
Height Adjustment	50-2	Rack-and-Pinion Axle	65-11
Transporting Mounted Implements	50-2	Tread Widths with Rack-and-Pinion Axle	65-11
Adjusting Rate of Implement Drop	50-2	Tire Pressures	65-12
Depth Adjustment	50-2	Service Tires Safely	65-12
Load/Depth Adjustment (If Equipped)	50-3	Tire Combinations	65-13
Direct Actuation	50-4		
Draft Links	50-4	Additional Equipment	
Attaching Three-Point Hitch and Drawn		Selective Control Valves	70-1
Implements	50-5	Adjusting the Kickout Relief Valve	
Leveling the Implement	50-5	Detent - 301 Series SCV	70-2
Center Link Adjustment	50-6	Control Lever for Selective Control Valve	70-3
Lift Links	50-7	Rate of Cylinder Operation	70-3
Adjusting for Vertical Float	50-8	Couplers	70-4
Sway Blocks (If Equipped)	50-8	Hose Unions	70-4
Stabilizer Bar	50-9	Maximum Permissible Oil Withdrawal	70-5
		Oil Withdrawal With Hydraulic Motor	70-5
Power Take-Off		Swinging Drawbar	70-6
PTO Guard	55-1	Correct Use of Drawbar	70-6
Operating Instructions	55-1	Lengthwise Adjustment of Drawbar	70-7
PTO	55-2	High Clearance Drawbar	70-8
Operating Rear PTO	55-3	Use a Safety Chain	70-9
Reversing Rear PTO Shafts	55-4	Vandal Protection	70-10
Attaching PTO-Driven Equipment	55-5		
		Transport	
Ballast		Safely Transporting the Tractor	75-1
Selecting Ballast	60-1	Towing the Tractor	75-1
Ballasting Rear Wheels	60-1	Use Safety Lights and Devices	75-2
Measuring Rear Wheel Slip	60-2	Driving on Public Roads	75-2
Installing Weights on Flanged Axle	60-2		
Filling Tires with Liquid Ballast	60-3	Fuel, Lubricants, Hydraulic Oil and Coolant	
Draining the Tires	60-3	Diesel Fuel	80-1
Front Weights	60-3	Handling and Storing Diesel Fuel	80-2
Using Implement Codes	60-4	Lubricity of Diesel Fuel	80-2
		Bio-Diesel Fuel	80-3
Wheel Treads, Tires		Diesel Engine Break-In Oil	80-4
Adjustable Front Axle (Tractors Without			
Front Wheel Drive)	65-1		

Continued on next page

	Page		Page
Diesel Engine Oil	80-5	Service / Every 500 Hours	
Oil Filters	80-5	Changing Engine Oil	100-1
Diesel Engine Coolant	80-6	Changing Engine Oil Filter Element	100-2
Operating in Warm Temperature Climates	80-7	Changing the Fuel Filter	100-2
Drain Intervals for Diesel Engine Coolant	80-7	Servicing Fuel Tank	100-3
Transmission and Hydraulic Oil	80-8	Lubricating Rear Axle Bearings	100-3
Front-Wheel Drive Axle Oil	80-9	Air Intake Hoses	100-3
Grease	80-10	Checking Engine Ground Connection	100-3
Mixing of Lubricants	80-10	Check Engine Drive Belt for Wear	100-4
Alternative and Synthetic Lubricants	80-11		
Lubricant Storage	80-11	Service / Every 750 Hours	
Lubrication and Periodic Service		Checking Engine Speeds	105-1
Using High Pressure Washers	85-1	Replacing Transmission/Hydraulic System Filter Elements	105-1
Lubrication and Periodic Service	85-1		
Opening the Hood	85-2	Service / Once Every Year	
Access to Battery	85-2	Checking Seat Belt	110-1
Access to Fuses	85-2		
Important Instructions Regarding Alternator	85-3	Service / Every 1500 Hours or 2 Years	
Servicing the Air-Conditioning System (If Equipped) — Warning	85-4	Changing Oil in Front-Wheel Drive Axle and Final Drives	115-1
Daily or Every 10 Hours	85-4	Changing Oil in MFWD Axle Housing	115-1
After the First 100 Hours	85-5	Changing Oil in MFWD Final Drives	115-2
Every 250 Hours	85-5	Change Transmission/Hydraulic Oil	115-2
Every 500 Hours	85-6		
Every 750 Hours	85-6	Service / Every 3000 Hours or 3 Years	
Once Every Year	85-7	Changing Coolant	120-1
Every 1500 Hours or Every Two Years	85-7		
Every 2000 Hours	85-7	Service / As Required	
Every 3000 Hours or Every Three Years	85-8	Air Cleaner	125-1
Every 4500 Hours or Every Five Years	85-8	Cleaning the Primary Filter Element	125-1
As Required	85-9	Cleaning a Dusty Element	125-1
		Secondary (Safety) Element	125-2
Service / Daily or Every 10 Hours		Installation	125-2
Checking Engine Crankcase Oil Level	90-1	Cleaning the Cab Air Filter	125-2
Checking the Fuel Filter	90-1	Checking the Fuel Filter	125-3
Checking on Lights	90-2	Bleeding the Fuel System	125-3
Other Service Jobs	90-2	Lubricate All Lubricating Points	125-3
		Operator's Seat	125-4
Service / Every 250 Hours		Clean Radiator and Condenser (if equipped)	125-4
Checking Transmission/Hydraulic System Oil Level	95-1	Handling Batteries Safely	125-6
Handling Batteries Safely	95-2	Batteries - Checking Specific Gravity	125-7
Checking Electrolyte Level of Batteries	95-3	Starter Motor	125-7
Lubricating Front Axle and Front Wheels	95-3	Replacing the Main Fuses	125-8
Lubricating Front Axle and Drive Shaft	95-4	Replacing the Electric Starting Aid Fuses	125-8
Checking Oil Level in MFWD Axle Housing	95-4	Fuse and Relay Box on Tractors with Open Operator's Station	125-10
Checking Oil Level in MFWD Final Drives	95-5	Fuse and Relay Box on Tractors with Operator's Cab	125-12
Lubricating Three-Point Hitch	95-5	Replacing the Drive Belt	125-16
Neutral Start Circuit	95-5		
Checking Transmission PARK Position	95-6		
Wheel Retaining Bolts/Nuts	95-7		

Continued on next page

Contents

	Page
Troubleshooting	
Hydraulic System	130-1
Engine	130-2
Electrical System	130-4
Storage	
Storage for Long Period	135-1
Removing Tractor From Storage	135-2
Specifications	
Engine	140-1
Transmission	140-1
Hydraulic System	140-2
Weights and Loads.	140-2
Towable Loads.	140-3
Electrical System	140-3
Capacities	140-4
Load Capacity of Tires (Front)	140-5
Load Capacity of Tires (Rear)	140-6
Load Capacity of Tires With Front Loader	140-7
Unified Inch Bolt and Screw Torque Values	140-8
Metric Bolt and Screw Torque Values.	140-9
Limited Battery Warranty	140-10
Emissions Control System Certification Label.	140-11
U.S. EPA Emissions Control Warranty Statement	140-12
Serial Numbers	
Type Plates	145-1
Product Identification Number.	145-1
Engine Identification Number	145-1
Transmission Serial Number.	145-2
Serial Number of Front Wheel Drive Axle.	145-2
Lubrication and Maintenance Records	
250 Hour Service	150-1
500 Hour Service	150-1
750 Hour Service	150-2
1500 Hour Service	150-2
3000 Hour Service	150-3
Crime Prevention Tips	
Keep Proof of Ownership	155-1
Keep Machines Secure	155-1
John Deere Service Keeps You on the Job	
John Deere Is At Your Service	IBC-1

Identification Views

Identification Views



LX1027112

LX1027112 -UN-19AUG02



LX1033475

LX1033475 -UN-08OCT03

Continued on next page

OU12401.00104A8 -19-01AUG03-1/2

Identification Views



LX1033476

LX1033476 -UN-08OCT03

OU12401,00104A8 -19-01AUG03-2/2

Safety

Recognize Safety Information

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



DX,ALERT -19-29SEP98-1/1

T81389 -UN-07DEC88

Understand Signal Words

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards.

DANGER or WARNING safety signs are located near specific hazards. General precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.



DX,SIGNAL -19-03MAR93-1/1

TS187 -19-30SEP88

Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.

If you do not understand any part of this manual and need assistance, contact your John Deere dealer.



DX,READ -19-03MAR93-1/1

TS201 -UN-23AUG88


Stay Clear of Moving Tractor

Always place transmission in PARK before dismounting. Leaving transmission in gear with engine stopped will NOT prevent the tractor from moving.

Be sure everyone is clear of tractor and attached equipment before starting engine. Some movement may occur as engine starts.

Never try to get on or off a moving tractor.

When tractor is left unattended, place in PARK, lower implements to the ground, stop the engine, and remove the key.



TS213 -UN-23AUG88


RX,STAY,CLEAR -19-25JUL89-1/1

Prevent Machine Runaway

Avoid possible injury or death from machinery runaway.

Do not start engine by shorting across starter terminals. Machine will start in gear if normal circuitry is bypassed.

NEVER start engine while standing on ground. Start engine only from operator's seat, with transmission in neutral or park.



TS177 -UN-11JAN89

DX,BYPAS1 -19-29SEP98-1/1


Use Seat Belt Properly (If Equipped)

Use a seat belt when you operate with a roll-over protective structure (ROPS) or cab to minimize chance of injury from an accident such as an overturn.

Do not use a seat belt if operating without a ROPS or cab.

Replace entire seat belt if mounting hardware, buckle, belt or retractor show signs of damage.


Inspect seat belt and mounting hardware at least once a year. Look for signs of loose hardware or belt damage, such as cuts, fraying, extreme or unusual wear, discoloration, or abrasion. Replace only with replacement parts approved for your machine. If there is any doubt, contact your John Deere Dealer.




TS205 -UN-23AUG88

LX,ROPS1 -19-02JAN03-1/1

Operating the Tractor Safely



TS213 -UN-23AUG88



TS276 -UN-23AUG88

Careless use of the tractor can result in unnecessary accidents. Be alert to hazards of tractor operation. Understand causes of accidents and take every precaution to avoid them. Most common accidents are caused from:

- Tractor roll-over
- Improper starting procedures
- Crushing and pinching during hitching
- Collisions with other motor vehicles
- Entanglement in PTO shafts
- Falling from tractor

Avoid accidents by taking the following precautions:

Before leaving the tractor, apply the handbrake and put the transmission in NEUTRAL (or in PARK position, if equipped). Leaving transmission in gear

with engine stopped will NOT prevent tractor from moving.

Be sure everyone is clear of tractor and attached equipment before starting engine.

Never try to get on or off a moving tractor.

When tractor is left unattended, apply the handbrake and put the transmission in NEUTRAL or PARK position, lower implements to the ground, stop the engine and remove the key.

Never go near an operating PTO or an operating implement.

If a seat belt is equipped, always fasten it in a ROPS-equipped tractor.


LX,HAZARD,S -19-02JAN03-1/1

Shift to Low Gear on Hills

Shift to a low gear before descending a steep hill to improve your control of the tractor with little or no braking. Use engine braking to reduce speed before applying tractor brakes. Run-away tractors often tip over. Never coast downhill.

When driving on icy, wet, or graveled surfaces, reduce speed and be sure tractor is properly ballasted to avoid skidding and loss of steering control. For best control, engage front-wheel drive for four-wheel braking.

Additional ballast may be needed for transporting heavy integral implements. When implement is raised, drive slowly over rough ground, regardless of how much ballast is used.



TS216 -UN-23AUG88


LX,DRIVE,SAFE1 -19-01OCT92-1/1

Use Caution on Hillsides

Avoid holes, ditches, and obstructions which may cause tractor roll-over, especially on hillsides. Avoid sharp turns on hills.

Never drive near the edge of a gully or steep embankment.

Driving out of a ditch, mired condition, or up a steep slope could cause tractor to tip over rearward. Back out of these situations if possible.



RW13093 -UN-07DEC88

RX,HILL,SIDE1 -19-22SEP92-1/1

Parking and Leaving the Tractor

Lower mounted implement(s) or equipment to the ground before leaving the tractor.

When leaving the tractor, shut off the engine, apply the handbrake and engage the park lock (if equipped), remove the ignition key and lock the cab (if equipped). Put chock blocks in position.

Never leave tractor unattended while the engine is still running.

Never leave the operator's platform/cab when driving.




LX002510 -JUN-17JAN95

LX,PARK -19-02JAN03-1/1

Keep Riders Off Machine

Only allow the operator on the machine. Keep riders off.

Riders on machine are subject to injury such as being struck by foreign objects and being thrown off of the machine. Riders also obstruct the operator's view resulting in the machine being operated in an unsafe manner.



TS290 -JUN-23AUG88

DX,RIDER -19-03MAR93-1/1

Handle Fuel Safely—Avoid Fires

Handle fuel with care: it is highly flammable. Do not refuel the machine while smoking or when near open flame or sparks.

Always stop engine before refueling machine. Fill fuel tank outdoors.

Prevent fires by keeping machine clean of accumulated trash, grease, and debris. Always clean up spilled fuel.



TS202 -JUN-23AUG88


DX,FIRE1 -19-03MAR93-1/1

Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 -UN-23AUG88

DX,FIRE2 -19-03MAR93-1/1


Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.



TS206 -UN-23AUG88


DX,WEAR -19-10SEP90-1/1

Avoid Contact with Pesticides

This enclosed cab does not protect against inhaling harmful pesticides. If pesticide use instructions require respiratory protection, wear an appropriate respirator inside the cab.

Before leaving the cab, wear personal protective equipment as required by the pesticide use instructions. When re-entering the cab, remove protective equipment and store either outside the cab in a closed box or some other type of sealable container or inside the cab in a pesticide resistant container, such as a plastic bag.

Clean your shoes or boots to remove soil or other contaminated particles prior to entering the cab.



TS220 -UN-23AUG88



TS272 -UN-23AUG88

DX,CABS -19-03MAR93-1/1

Stay Clear of Rotating Drivelines

Entanglement in rotating driveline can cause serious injury or death.

Keep tractor master shield and driveline shields in place at all times. Make sure rotating shields turn freely.

Wear close fitting clothing. Stop the engine and be sure PTO driveline is stopped before making adjustments, connections, or cleaning out PTO driven equipment.




TS1644 -UN-22AUG95

DX,PTO -19-12SEP95-1/1

Use Safety Lights and Devices

Prevent collisions between other road users, slow moving tractors with attachments or towed equipment, and self-propelled machines on public roads. Frequently check for traffic from the rear, especially in turns, and use turn signal lights.

Use headlights, flashing warning lights, and turn signals day and night. Follow local regulations for equipment lighting and marking. Keep lighting and marking visible, clean, and in good working order. Replace or repair lighting and marking that has been damaged or lost. An implement safety lighting kit is available from your John Deere dealer.



TS951 -UN-12APR90


DX,FLASH -19-07JUL99-1/1

Use a Safety Chain

A safety chain will help control drawn equipment should it accidentally separate from the drawbar.

Using the appropriate adapter parts, attach the chain to the tractor drawbar support or other specified anchor location. Provide only enough slack in the chain to permit turning.

See your John Deere dealer for a chain with a strength rating equal to or greater than the gross weight of the towed machine. Do not use safety chain for towing.



TS217 -UN-23AUG88


DX,CHAIN -19-03MAR93-1/1

Safely Transporting the Tractor

A disabled tractor is best transported on a flatbed carrier. Use chains to secure the tractor to the carrier. The axles and tractor frame are suitable attachment points.

Before transporting the tractor on a low-loader truck or flat-bed rail wagon, make sure that the hood is secured over the tractor's engine and that doors, roof hatch (if equipped) and windows are properly closed.

Never tow the tractor at a speed greater than 10 km/h (6 mph). An operator must steer and brake the tractor under tow.



RW13090 -JUN-07DEC88

OU12401.0000CBA -19-02JAN03-1/1


Tow Loads Safely

Stopping distance increases with speed and weight of towed loads, and on slopes. Towed loads with or without brakes that are too heavy for the tractor or are towed too fast can cause loss of control. Consider the total weight of the equipment and its load.

Observe these recommended maximum road speeds, or local speed limits which may be lower:

- If towed equipment does not have brakes, do not travel more than 32 km/h (20 mph) and do not tow loads more than 1.5 times the tractor weight.
- If towed equipment has brakes, do not travel more than 40 km/h (25 mph) and do not tow loads more than 4.5 times the tractor weight.

Ensure the load does not exceed the recommended weight ratio. Add ballast to recommended maximum for tractor, lighten the load, or get a heavier towing unit. The tractor must be heavy and powerful enough with adequate braking power for the towed load. Use additional caution when towing loads under adverse surface conditions, when turning, and on inclines.




TS216 -JUN-23AUG88

DX.TOW -19-02OCT95-1/1

Keep ROPS Installed Properly

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.



TS212 -UN-23AUG88

DX,ROPS3 -19-03MAR93-1/1


Freeing a Mired Machine

Attempting to free a mired machine can involve safety hazards such as the mired tractor tipping rearward, the towing tractor overturning, and the tow chain or tow bar (a cable is not recommended) failing and recoiling from its stretched condition.

Back your tractor out if it gets mired down in mud. Unhitch any towed implements. Dig mud from behind the rear wheels. Place boards behind the wheels to provide a solid base and try to back out slowly. If necessary, dig mud from the front of all wheels and drive slowly ahead.

If necessary to tow with another unit, use a tow bar or a long chain (a cable is not recommended). Inspect the chain for flaws. Make sure all parts of towing devices are of adequate size and strong enough to handle the load.

Always hitch to the drawbar of the towing unit. Do not hitch to the front pushbar attachment point. Before moving, clear the area of people. Apply power smoothly to take up the slack: a sudden pull could snap any towing device causing it to whip or recoil dangerously.



TS1645 -UN-15SEP95



TS263 -UN-23AUG88

DX,MIREDD -19-07JUL99-1/1

Practice Safe Maintenance

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.



T5218 -UN-23AUG88

DX,SERV -19-17FEB99-1/1

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com