

544K 4WD Loader Operation and Test

(PIN: 1DW544K__ _F670308—677548)

OPERATION & TEST TECHNICAL MANUAL

**544K 4WD Loader (PIN: 1DW544K_
_ _F670308—677548)**

TM13363X19 14JUN18 (ENGLISH)


**Worldwide Construction
And Forestry Division**
PRINTED IN U.S.A.

Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When this symbol is seen on the machine or in this manual, be alert for the potential of personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and test sections help to quickly identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

MM16284,00026ED -19-05JUN18-1/1

Manual Identification—READ THIS FIRST!

IMPORTANT: Use only supporting manuals designated for your specific machine. If an incorrect manual is chosen, improper service may occur. Verify product identification number (PIN) when choosing the correct manual.


Choosing the Correct Supporting Manuals

John Deere four wheel drive (4WD) loaders are available in different machine configurations based on the various markets into which they are sold. Different supporting manuals exist for different machine configurations.

When necessary, product identification numbers (PINs) are listed on the front covers of 4WD loader manuals. These numbers are used to identify the correct supporting manual for your machine.

Product Identification Number

The product identification number (PIN) plate (1) is located on the left side of machine in front of the steps. Each machine has a 17-character PIN (2) as shown on this plate.



PIN Plate Location



PIN Plate Example (17-character)

1— PIN Plate

2— 17-Character PIN

TX1189779A —UN—08APR15

TX1190031 —UN—10APR15

The PIN identifies the producing factory, machine model number, machine option, year of manufacture, engine emission level, and machine serial number.

The following is an example for a 544K machine that meets Final Tier 4 emission levels:

17-Character PIN Example																
1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17
1	D	W	5	4	4	K	Z	—	—	F	1	2	3	4	5	6

- **(1—3) World Code:** Identifies location where machine is manufactured.

1DW **World Code** (manufacturing location)

1DW Davenport Works

1T8 Thibodaux Works

1T0 Dubuque Works

- **(4—8) Machine Model Identifier:** Identifies model number.

544K **Machine Model Identifier**

NOTE: Characters 7—8 identify series and major machine configuration options. These characters will change from one machine to another.

Z **Machine Option Code**

Z Standard Z-Bar

H High Lift Z-Bar

P Powerllec

T Tool Carrier

- **(9) Check Letter:** This is a random character assigned by the factory. This is not used in machine identification.

— **Check Letter** (variable)

- **(10) Manufacturing Year Code:** Identifies year of machine manufacture.

— **Manufacturing Year Code** (variable)

E 2014

F 2015

G 2016

H 2017

I 2018

- **(11) Engine Emission Code:** Represents engine emission certification.

F **Engine Emission Code**

C Tier 2 and Stage II

D Tier 3 and Stage III A

E Interim Tier 4 and Stage III B

F Tier 4

G Interim Tier 4 and Stage III A (19-56 kW)

H Final Tier 4 and Stage III A (19-37 kW)

J Final Tier 4 and Stage III A (37-56 kW)

K Final Tier 4 (8-19 kW)

- **(12—17) Machine Serial Number:** Identifies machine serial number. This character will change from one machine to another.

123456 **Machine Serial Number**

WC20922,00051B4 -19-17JAN17-2/2

Contents

Section 9000—General Information

Group 01—Safety

Group 15—Diagnostic Information

Group 20—Adjustments

Group 25—Tests

Section 9001—Diagnostics

Group 10—Engine Control Unit (ECU) Diagnostic
Trouble Codes

Group 20—Transmission Control Unit (TCU) Diagnostic
Trouble Codes

Group 30—Vehicle Control Unit (VCU) Diagnostic
Trouble Codes

Group 40—Sealed Switch Module (SSM) Diagnostic
Trouble Codes

Group 50—Advanced Display Unit (ADU) Diagnostic
Trouble Codes

Group 60—Radar Object Detection (ROD) Diagnostic
Trouble Codes

Group 70—Ground Speed Radar (RDR) Diagnostic
Trouble Codes

Section 9031—Heating and Air Conditioning

Group 05—Theory of Operation

Group 10—System Diagrams

Group 15—Diagnostic Information

Group 25—Tests

Section 9005—Operational Checkout Procedure

Group 10—Operational Checkout Procedure

Section 9010—Engine

Group 05—Theory of Operation

Group 10—System Diagrams

Group 15—Diagnostic Information

Group 20—Adjustments

Group 25—Tests

Section 9015—Electrical System

Group 05—Theory of Operation

Group 10—System Diagrams

Group 15—Diagnostic Information

Group 16—Monitor Operation

Group 17—Diagnostic Test Box

Group 20—Adjustments

Group 25—Tests

Section 9020—Power Train

Group 05—Theory of Operation

Group 10—System Diagrams

Group 15—Diagnostic Information

Group 20—Adjustments

Group 25—Tests

Section 9025—Hydraulic System

Group 05—Theory of Operation

Group 10—System Diagrams

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication.

The right is reserved to make changes at any time without notice.

COPYRIGHT © 2018
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION™ Manual
Previous Editions
Copyright © 2015, 2016, 2017

Section 9000 General Information

Contents

	Page
Group 01—Safety	
Recognize Safety Information	9000-01-1
Follow Safety Instructions.....	9000-01-1
Operate Only If Qualified	9000-01-1
Wear Protective Equipment.....	9000-01-2
Avoid Unauthorized Machine	
Modifications.....	9000-01-2
Inspect Machine	9000-01-2
Stay Clear of Moving Parts.....	9000-01-2
Avoid High-Pressure Fluids	9000-01-3
Avoid High-Pressure Oils	9000-01-3
Work In Ventilated Area.....	9000-01-3
Avoid Static Electricity Risk When	
Refueling	9000-01-4
Prevent Fires	9000-01-4
In Case of Machine Fire	9000-01-5
Prevent Battery Explosions	9000-01-5
Clean Debris from Machine	9000-01-5
Handle Chemical Products Safely.....	9000-01-6
Handle Starting Fluid Safely	9000-01-6
Decommissioning — Proper	
Recycling and Disposal of Fluids	
and Components	9000-01-7
Exhaust Filter Ash Handling and	
Disposal.....	9000-01-7
Prepare for Emergencies.....	9000-01-7
Add Cab Guarding for Special	
Uses	9000-01-8
Park and Prepare for Service	
Safely.....	9000-01-8
Clean Exhaust Filter Safely	9000-01-9
Service Cooling System Safely	9000-01-10
Service Tires Safely.....	9000-01-10
Remove Paint Before Welding or	
Heating	9000-01-11
Make Welding Repairs Safely	9000-01-11
Drive Metal Pins Safely	9000-01-11

Recognize Safety Information

This is the safety alert symbol. When you see this symbol on your machine or in this manual, be alert for the potential of personal injury.

Follow the precautions and safe operating practices highlighted by this symbol.

A signal word — DANGER, WARNING, or CAUTION — is used with the safety alert symbol. DANGER identifies the most serious hazards.

On your machine, DANGER signs are red in color, WARNING signs are orange, and CAUTION signs are yellow. DANGER and WARNING signs are located near specific hazards. General precautions are on CAUTION labels.



▲ DANGER

▲ WARNING

▲ CAUTION

T133555 —UN—15APR13

T133588 —19—28AUG00

TX,RECOGNIZE -19-28JUN10-1/1


Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Use this operator's manual for correct safety sign placement. Be sure that new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine could impair the function or safety and affect machine life.



If you do not understand any part of this manual and need assistance, contact your John Deere dealer.

TS201 —UN—15APR13

TX,FOLLOW -19-20JAN11-1/1

Operate Only If Qualified

Do not operate this machine unless the operator's manual has been read carefully, and you have been qualified by supervised training and instruction.

Operator should be familiar with the job site and surroundings before operating. Try all controls and

machine functions with the machine in an open area before starting to work.

Know and observe all safety rules that may apply to every work situation and work site.

TX,QUALIFIED -19-18JAN11-1/1


Wear Protective Equipment

Guard against injury from flying pieces or metal or debris; wear goggles or safety glasses.

Wear close fitting clothing and safety equipment appropriate to the job.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.

Prolonged exposure to loud noise can cause impairment or loss of hearing. Wear suitable hearing protection such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises. Radio or music headphones are not suitable to use for hearing protection.



TS206—UN—15APR13

TX,WEAR,PE -19-22SEP10-1/1

Avoid Unauthorized Machine Modifications

John Deere recommends using only genuine John Deere replacement parts to ensure machine performance. Never substitute genuine John Deere parts with alternate parts not intended for the application as these can create hazardous situations or hazardous performance. Non-John Deere parts, or any damage or malfunctions resulting from their use, are not covered by any John Deere warranty.

Modifications of this machine, or addition of unapproved products or attachments, may affect machine stability or

reliability, and may create a hazard for the operator or others near the machine. The installer of any modification which may affect the electronic controls of this machine is responsible for establishing that the modification does not adversely affect the machine or its performance.

Always contact an authorized dealer before making machine modifications that change the intended use, weight, or balance of the machine, or that alter machine controls, performance, or reliability.

KR46761,00010A9 -19-03OCT16-1/1

Inspect Machine

Inspect machine carefully each day by walking around it before starting.

Keep all guards and shields in good condition and properly installed. Fix damage and replace worn or broken parts immediately. Pay special attention to hydraulic hoses and electrical wiring.



T6607AQ—UN—15APR13


TX,INSPECT -19-08SEP10-1/1

Stay Clear of Moving Parts

Entanglements in moving parts can cause serious injury.

Stop engine before examining, adjusting, or maintaining any part of machine with moving parts.

Keep guards and shields in place. Replace any guard or shield that has been removed for access as soon as service or repair is complete.



T133592—UN—15APR13

TX,MOVING,PARTS -19-20JAN11-1/1


Avoid High-Pressure Fluids

Escaping fluid under pressure can penetrate the skin causing serious injury.

Avoid the hazard by relieving pressure before disconnecting hydraulic or other lines. Tighten all connections before applying pressure.

Search for leaks with a piece of cardboard. Protect hands and body from high-pressure fluids.

If an accident occurs, see a doctor immediately. Any fluid injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



X9811 —UN—23AUG88


DX,FLUID -19-06OCT16-1/1

Avoid High-Pressure Oils

This machine uses a high-pressure hydraulic system. Escaping oil under pressure can penetrate the skin causing serious injury.

Never search for leaks with your hands. Protect hands. Use a piece of cardboard to find location of escaping oil. Stop engine and relieve pressure before disconnecting lines or working on hydraulic system.

If hydraulic oil penetrates your skin, see a doctor immediately. Injected oil must be removed surgically within hours or gangrene could result. Contact a knowledgeable medical source or the Deere & Company Medical Department in Moline, Illinois, U.S.A.



T133509 —UN—15APR13


T133840 —UN—20SEP00

TX,HPOILS -19-20JAN11-1/1

Work In Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.



TS220 —UN—15APR13

DX,AIR -19-17FEB99-1/1


Avoid Static Electricity Risk When Refueling

The removal of sulfur and other compounds in Ultra-Low Sulfur Diesel (ULSD) fuel decreases its conductivity and increases its ability to store a static charge.

Refineries may have treated the fuel with a static dissipating additive. However, there are many factors that can reduce the effectiveness of the additive over time.

Static charges can build up in ULSD fuel while it is flowing through fuel delivery systems. Static electricity discharge when combustible vapors are present could result in a fire or explosion.

Therefore, it is important to ensure that the entire system used to refuel your machine (fuel supply tank, transfer pump, transfer hose, nozzle, and others) is properly grounded and bonded. Consult with your fuel or fuel system supplier to ensure that the delivery system is in compliance with fueling standards for proper grounding and bonding practices.



RG22142 —UN—17MAR14

RG21992 —UN—21AUG13

DX,FUEL,STATIC,ELEC -19-12JUL13-1/1

Prevent Fires

Handle Fluids Safely: All fuels, most lubricants, and some coolant mixtures are flammable. Store flammable fluids away from fire hazards. Never refuel machine while smoking or when near sparks or flame.

Clean Machine Regularly: Keep flammable debris (trash, leaves, twigs, straw, and so forth), grease and oil from accumulating in engine compartment, around fuel lines, hydraulic lines, exhaust components, and electrical wiring. Never store oily rags or flammable materials inside a machine compartment.

Maintain Hoses, Tubes, and Wiring: Replace hoses and tubes immediately if they begin to leak, and clean up any oil spills. Examine electrical wiring and connectors frequently for damage.

Keep A Fire Extinguisher Available: Always keep a multipurpose fire extinguisher on or near the machine. Know how to use an extinguisher properly.

Be Aware of the Operating Environment: Airborne debris may contain sparks or embers. Do not operate near any flame.



T133553 —UN—07SEP00



T133554 —UN—07SEP00



T133552 —UN—15APR13

TX,PREVENT,FIRE -19-09JUN16-1/1

In Case of Machine Fire

⚠ CAUTION: Avoid personal injury from exposed flames. Maintain safe distance.

- Turn the engine off.
- Turn the battery disconnect switch to the OFF position, if equipped.
- If possible, fight the fire using the portable fire extinguisher or other fire suppression equipment, if equipped.
- Ensure that the fire does not spread to the surrounding area. Do not risk injury. If a fire is too far advanced, do not try to extinguish fire.
- Call for help.



In Case of Machine Fire

CN93077,00000B2 -19-09FEB16-1/1

TS227 —UN—15APR13

Prevent Battery Explosions

Keep sparks, lighted matches, and open flame away from the top of battery. Battery gas can explode.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Do not charge a frozen battery; it may explode. Warm battery to 16°C (60°F).

Keep battery electrolyte levels properly maintained.



Battery Explosions

KR46761,00010B4 -19-26JAN16-1/1

TS204 —UN—15APR13


Clean Debris from Machine

Keep engine compartment, radiator, batteries, hydraulic lines, exhaust components, fuel tank, and operator's station clean and free of debris.

Clean any oil spills or fuel spills on machine surfaces.

Temperature in engine compartment could go up immediately after engine is stopped. **BE ON GUARD FOR FIRES DURING THIS PERIOD.**

Open access door(s) to cool the engine faster, and clean engine compartment.



TX,DEBRIS -19-20JAN11-1/1

T6669AG —UN—15APR13


Handle Chemical Products Safely

Direct exposure to hazardous chemicals can cause serious injury. Potentially hazardous chemicals used with John Deere equipment include such items as lubricants, coolants, paints, and adhesives.

A Material Safety Data Sheet (MSDS) provides specific details on chemical products: physical and health hazards, safety procedures, and emergency response techniques.

Check the MSDS before you start any job using a hazardous chemical. That way you will know exactly what the risks are and how to do the job safely. Then follow procedures and recommended equipment.

(See your John Deere dealer for MSDS's on chemical products used with John Deere equipment.)



TS1132—UN—15APR13

DX,MSDS,NA -19-03MAR93-1/1

Handle Starting Fluid Safely

Starting fluid is highly flammable.

Keep all sparks and flame away when using it. Keep starting fluid away from batteries and cables.

To prevent accidental discharge when storing the pressurized can, keep the cap on the container, and store in a cool, protected location.

Do not incinerate or puncture a starting fluid container.

Do not use starting fluid on an engine equipped with glow plugs or an air intake heater.




TS1356—UN—18MAR92

DX,FIRE3 -19-14MAR14-1/1

Decommissioning — Proper Recycling and Disposal of Fluids and Components

Safety and environmental stewardship measures must be taken into account when decommissioning a machine and/or component. These measures include the following:

- Use appropriate tools and personal protective equipment such as clothing, gloves, face shields or glasses, during the removal or handling of objects and materials.
- Follow instructions for specialized components.
- Release stored energy by lowering suspended machine elements, relaxing springs, disconnecting the battery or other electrical power, and releasing pressure in hydraulic components, accumulators, and other similar systems.
- Minimize exposure to components which may have residue from agricultural chemicals, such as fertilizers and pesticides. Handle and dispose of these components appropriately.
- Carefully drain engines, fuel tanks, radiators, hydraulic cylinders, reservoirs, and lines before recycling components. Use leak-proof containers when draining fluids. Do not use food or beverage containers.
- Do not pour waste fluids onto the ground, down a drain, or into any water source.
- Observe all national, state, and local laws, regulations, or ordinances governing the handling or disposal of waste fluids (example: oil, fuel, coolant, brake fluid);



TS1133 —UN—15APR13

filters; batteries; and, other substances or parts. Burning of flammable fluids or components in other than specially designed incinerators may be prohibited by law and could result in exposure to harmful fumes or ashes.

- Service and dispose of air conditioning systems appropriately. Government regulations may require a certified service center to recover and recycle air conditioning refrigerants which could damage the atmosphere if allowed to escape.
- Evaluate recycling options for tires, metal, plastic, glass, rubber, and electronic components which may be recyclable, in part or completely.
- Contact your local environmental or recycling center, or your John Deere dealer for information on the proper way to recycle or dispose of waste.

DX,DRAIN -19-01JUN15-1/1

Exhaust Filter Ash Handling and Disposal

CAUTION: Under federal, state, and local laws or regulations, exhaust filter ash can be classified as a hazardous waste. Hazardous waste must be disposed of in accordance with all applicable federal, state, and local laws or regulations

governing hazardous waste disposal. Only a qualified service provider should remove ash from the exhaust filter. Personal protective equipment and clothing, maintained in a sanitary and reliable condition, should be used when handling and cleaning exhaust filter. See your authorized dealer for exhaust filter ash handling and disposal.


TX,ASH,DISP -19-20JAN11-1/1

Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291 —UN—15APR13

DX,FIRE2 -19-03MAR93-1/1

Add Cab Guarding for Special Uses

Special work situations or machine attachments could create an environment with falling or flying objects. Working near an overhead bank, demolition work, using a hydraulic hammer or winch, working in a forestry application or wooded area, or working in a waste management application, for example, could require added guarding to protect the operator.

Additional level II FOPS (falling object protective structure), forestry protection packages, and special

screens or guarding should be installed when falling or flying objects could enter or damage the machine. A rear screen should always be used with a winch to protect against a snapping cable. Before operating in any special work environments, follow the operator protection recommendations of the manufacturer of any specialized attachment or equipment. Contact your authorized John Deere dealer for information on protective guarding.

TX,CABGUARD -19-12FEB13-1/1

Park and Prepare for Service Safely


Warn others of service work. Always park and prepare your machine for service or repair properly.

- Park machine on a level surface and lower equipment to the ground.
- Engage park brake.
- Stop engine.
- Install frame locking bar.
- Attach a DO NOT OPERATE tag in an obvious place in the operator's station.

Securely support machine or attachment before working under it.

- Do not support machine with boom, bucket, or other hydraulically actuated equipment.
- Do not support machine with cinder blocks or wooden pieces that can crumble or crush.
- Do not support machine with a single jack or other devices that could slip out of place.

Understand service procedures before beginning repairs. Keep service area clean and dry. Use two people whenever the engine must be running for service work.



T133332 -19-17APR13

TS229 -UN-23AUG88

TX,PARK,4WD -19-28JUN10-1/1

Clean Exhaust Filter Safely

During exhaust filter cleaning operations, the engine may run at elevated idle and hot temperatures for an extended period of time. Exhaust gases and exhaust filter components reach temperatures hot enough to burn people, or ignite or melt common materials.

Keep machine away from people, animals, or structures which may be susceptible to harm or damage from hot exhaust gases or components. Avoid potential fire or explosion hazards from flammable materials and vapors near the exhaust. Keep exhaust outlet away from people and anything that can melt, burn, or explode.

Closely monitor machine and surrounding area for smoldering debris during and after exhaust filter cleaning.

Adding fuel while an engine is running can create a fire or explosion hazard. Always stop engine before refueling machine and clean up any spilled fuel.

Always make sure that engine is stopped while hauling machine on a truck or trailer.

Contact with exhaust components while still hot can result in serious personal injury.

Avoid contact with these components until cooled to safe temperatures.




If service procedure requires engine to be running:

- Only engage power-driven parts required by service procedure
- Ensure that other people are clear of operator station and machine

Keep hands, feet, and clothing away from power-driven parts.

Always disable movement (neutral), set the parking brake or mechanism and disconnect power to attachments or tools before leaving the operator's station.

Shut off engine and remove key (if equipped) before leaving the machine unattended.



STOP

TS227 —UN—15APR13

TS271 —UN—23AUG88

TS1693 —UN—09DEC09


TS1695 —UN—07DEC09

DX,EXHAUST,FILTER -19-12JAN11-1/1

Service Cooling System Safely

Explosive release of fluids from pressurized cooling system can cause serious burns.

Do not service radiator through the radiator cap. Only fill through the surge tank filler cap. Shut off engine. Only remove surge tank filler cap when cool enough to touch with bare hands. Slowly loosen cap to relieve pressure before removing completely.



TS281 —UN—15APR13

TX,SURGE -19-19JAN11-1/1

Service Tires Safely


Explosive separation of a tire and rim parts can cause serious injury or death.

Do not attempt to mount a tire unless you have the proper equipment and experience to perform the job.

Always maintain the correct tire pressure. Do not inflate the tires above the recommended pressure. Never weld or heat a wheel and tire assembly. The heat can cause an increase in air pressure resulting in a tire explosion. Welding can structurally weaken or deform the wheel.

When inflating tires, use a clip-on chuck and extension hose long enough to allow you to stand to one side and NOT in front of or over the tire assembly. Use a safety cage if available.

Check wheels for low pressure, cuts, bubbles, damaged rims or missing lug bolts and nuts.



TS211 —UN—15APR13

DX,RIM -19-24AUG90-1/1

Remove Paint Before Welding or Heating

Avoid potentially toxic fumes and dust.

Hazardous fumes can be generated when paint is heated by welding, soldering, or using a torch.

Remove paint before heating:

- Remove paint a minimum of 100 mm (4 in.) from area to be affected by heating. If paint cannot be removed, wear an approved respirator before heating or welding.
- If you sand or grind paint, avoid breathing the dust. Wear an approved respirator.
- If you use solvent or paint stripper, remove stripper with soap and water before welding. Remove solvent or paint stripper containers and other flammable material from area. Allow fumes to disperse at least 15 minutes before welding or heating.

Do not use a chlorinated solvent in areas where welding will take place.



Do all work in an area that is well ventilated to carry toxic fumes and dust away.

Dispose of paint and solvent properly.

DX,PAINT -19-24JUL02-1/1

TS220 —UN—15APR13

Make Welding Repairs Safely

IMPORTANT: Disable electrical power before welding.
Turn off main battery switch and disconnect positive (+) and negative (-) battery cables.

Do not weld or apply heat on any part of a reservoir or tank that has contained oil or fuel. Heat from welding and cutting can cause oil, fuel, or cleaning solution to create gases which are explosive, flammable, or toxic.

Avoid welding or heating near pressurized fluid lines. Flammable spray may result and cause severe burns if pressurized lines malfunction as a result of heating. Do not let heat go beyond work area to nearby pressurized lines.

Remove paint properly. Do not inhale paint dust or fumes. Use a qualified welding technician for structural repairs.



Heating Near Pressurized Fluid Lines

Make sure there is good ventilation. Wear eye protection and protective equipment when welding.


KR46761,00010AD -19-22JAN16-1/1

T133547 —UN—15APR13

Drive Metal Pins Safely

Always wear protective goggles or safety glasses and other protective equipment before striking hardened parts. Hammering hardened metal parts such as pins and bucket teeth could dislodge chips at high velocity.

Use a soft hammer or a brass bar between hammer and object to prevent chipping.



TX,PINS -19-20JAN11-1/1

T133738 —UN—15APR13

Section 9001 Diagnostics

Contents

	Page		Page
Group 10—Engine Control Unit (ECU)			
Diagnostic Trouble Codes			
Engine Control Unit (ECU)		001761.18 — Diesel Exhaust Fluid is	
Diagnostic Trouble Codes	9001-10-1	Very Low	9001-10-13
000091.03 — Engine Throttle Short to		002003.09 — Controller Area	
Power	9001-10-1	Network (CAN) Communication	
Engine Throttle Short to Power		Lost for Transmission Control Unit	
Diagnostic Procedure	9001-10-1	(TCU)	9001-10-13
000091.04 — Engine Throttle Open or		Controller Area Network (CAN)	
Short	9001-10-2	Communication Lost for	
Engine Throttle Open or Short		Transmission Control Unit (TCU)	
Diagnostic Procedure	9001-10-2	Diagnostic Procedure	9001-10-13
000091.14 — Engine Throttle Sensor		002033.09 — Controller Area Network	
Invalid	9001-10-4	(CAN) Communication Lost for	
000111.01 — Engine Coolant Level		Vehicle Control Unit (VCU)	9001-10-15
Extremely Low	9001-10-4	Controller Area Network (CAN)	
Engine Coolant Level Extremely Low		Communication Lost for Vehicle	
Diagnostic Procedure	9001-10-4	Control Unit (VCU) Diagnostic	
000111.18 — Engine Coolant Very Low		Procedure	9001-10-15
Level	9001-10-5	003031.12 — Diesel Exhaust Fluid	
Engine Coolant Very Low Level		Temperature Sensor Fault	9001-10-17
Diagnostic Procedure	9001-10-5	003353.31 — Alternator Excitation	
000168.01 — Engine Control Unit		Condition Exists	9001-10-18
(ECU) Battery Voltage Low	9001-10-6	Alternator Excitation Condition Exists	
Engine Control Unit (ECU)		Diagnostic Procedure	9001-10-18
Battery Voltage Low Diagnostic		003516.01 — Diesel Exhaust Fluid	
Procedure	9001-10-6	Concentration is Low	9001-10-19
000237.31 — Invalid Vehicle		003516.09 — Diesel Exhaust Fluid	
Identification Number (VIN)	9001-10-7	Tank Header Communication	
Invalid Vehicle Identification Number		Fault	9001-10-19
(VIN) Diagnostic Procedure	9001-10-7	003516.12 — Diesel Exhaust Fluid	
001321.05 — Starter Relay Open		Tank Quality Sensor Fault	9001-10-20
Circuit	9001-10-8	003516.14 — Improper Fluid in Diesel	
Starter Relay Open Circuit Diagnostic		Exhaust Fluid Tank	9001-10-20
Procedure	9001-10-8	003516.16 — Diesel Exhaust Fluid	
001321.06 — Starter Relay High		Concentration is High	9001-10-20
Current	9001-10-8	003517.12 — Diesel Exhaust Fluid	
Starter Relay High Current Diagnostic		Tank Level Sensor Fault	9001-10-21
Procedure	9001-10-9	004490.12 — Humidity Sensor	
001321.09 — Starter Signal		Failure	9001-10-21
Invalid	9001-10-10	Humidity Sensor Failure Diagnostic	
Starter Signal Invalid Diagnostic		Procedure	9001-10-21
Procedure	9001-10-10		
001321.16 — Too Long to Start	9001-10-11	Group 20—Transmission Control Unit (TCU)	
Too Long to Start Diagnostic		Diagnostic Trouble Codes	
Procedure	9001-10-11	Transmission Control Unit (TCU)	
001321.31 — Starter Solenoid Open		Diagnostic Trouble Codes	9001-20-1
Circuit	9001-10-12	000091.09 — Timeout EEC2	
Starter Solenoid Open Circuit		Message	9001-20-1
Diagnostic Procedure	9001-10-12	Timeout EEC2 Message Diagnostic	
001761.01 — Diesel Exhaust Fluid is		Procedure	9001-20-1
Extremely Low	9001-10-13	000161.00 — Input Speed High	9001-20-2

Continued on next page

Page	Page
000513.02 — Percent Torque Invalid.....9001-20-2	002033.09 — Controller Area Network (CAN) Communication Lost for Vehicle Control Unit (VCU).....9001-20-17
Percent Torque Invalid Diagnostic Procedure.....9001-20-2	Controller Area Network (CAN) Communication Lost for Vehicle Control Unit (VCU) Diagnostic Procedure.....9001-20-17
000513.09 — Timeout EEC1 Message.....9001-20-3	002141.09 — Controller Area Network (CAN) Communication Lost for Sealed Switch Module (SSM).....9001-20-20
Timeout EEC1 Message Diagnostic Procedure.....9001-20-3	Controller Area Network (CAN) Communication Lost for Sealed Switch Module (SSM) Diagnostic Procedure.....9001-20-20
000514.02 — Friction Invalid.....9001-20-4	004201.03 — Converter Input Speed Sensor Open or Short.....9001-20-22
Friction Invalid Diagnostic Procedure.....9001-20-4	004201.04 — Converter Input Speed Sensor Short to Ground.....9001-20-23
000514.09 — Timeout EEC3 Message.....9001-20-5	004201.12 — Converter Input Speed Sensor Fault.....9001-20-24
Timeout EEC3 Message Diagnostic Procedure.....9001-20-5	522344.00 — Torque Converter Overtemperature.....9001-20-24
000544.02 — Reference Torque Invalid.....9001-20-6	Torque Converter Overtemperature Diagnostic Procedure.....9001-20-24
Reference Torque Invalid Diagnostic Procedure.....9001-20-6	522350.15 — Transmission Input Torque Overload.....9001-20-25
000544.09 — Timeout Engine Configuration Message.....9001-20-7	Transmission Input Torque Overload Diagnostic Procedure.....9001-20-25
Timeout Engine Configuration Message Diagnostic Procedure.....9001-20-7	522364.07 — Transmission Clutch Calibration Failed.....9001-20-26
000777.02 — Torque Converter Clutch Slippage.....9001-20-8	Transmission Clutch Calibration Failed Diagnostic Procedure.....9001-20-26
Torque Converter Clutch Slippage Diagnostic Procedure.....9001-20-8	522364.13 — Transmission Clutch Calibration Fault.....9001-20-27
000777.03 — Torque Converter Lockup Solenoid Short to Power.....9001-20-10	Transmission Clutch Calibration Fault Diagnostic Procedure.....9001-20-27
Torque Converter Lockup Solenoid Short to Power Diagnostic Procedure.....9001-20-10	522365.13 — Limp Home Mode.....9001-20-28
000777.04 — Torque Converter Lockup Solenoid Short to Ground.....9001-20-11	Limp Home Mode Diagnostic Procedure.....9001-20-28
Torque Converter Lockup Solenoid Short to Ground Diagnostic Procedure.....9001-20-11	522366.12 — Application Invalid.....9001-20-28
000777.05 — Torque Converter Lockup Solenoid Open Circuit.....9001-20-12	Application Invalid Diagnostic Procedure.....9001-20-29
Torque Converter Lockup Solenoid Open Circuit Diagnostic Procedure.....9001-20-12	522367.13 — Transmission Control Unit (TCU) Configuration Invalid.....9001-20-29
000928.03 — Axle Disconnect Solenoid Short to Power.....9001-20-13	Transmission Control Unit (TCU) Configuration Invalid Diagnostic Procedure.....9001-20-29
Axle Disconnect Solenoid Short to Power Diagnostic Procedure.....9001-20-13	522368.02 — Transmission Control Unit (TCU) Memory Failure.....9001-20-30
000928.04 — Axle Disconnect Solenoid High Current.....9001-20-14	TCU Memory Failure Diagnostic Procedure.....9001-20-30
Axle Disconnect Solenoid High Current Diagnostic Procedure.....9001-20-15	522370.02 — Transmission Control Unit (TCU) Valve Power Supply 2 Short Circuit.....9001-20-31
000928.05 — Axle Disconnect Solenoid Open Circuit.....9001-20-16	
Axle Disconnect Solenoid Open Circuit Diagnostic Procedure.....9001-20-16	
001785.09 — Engine Speed Limit Function Does Not Work Properly.....9001-20-17	

Continued on next page

Page	Page
Transmission Control Unit (TCU) Valve Power Supply 2 Short Circuit Diagnostic Procedure.....9001-20-31	522383.04 — Transmission Reverse Clutch Solenoid Short to Ground9001-20-46
522371.02 — Transmission Control Unit (TCU) Valve Power Supply 1 Short Circuit9001-20-32	Transmission Reverse Clutch Solenoid Short to Ground Diagnostic Procedure.....9001-20-46
Transmission Control Unit (TCU) Valve Power Supply 1 Short Circuit Diagnostic Procedure.....9001-20-32	522383.05 — Transmission Reverse Clutch Solenoid Open Circuit.....9001-20-48
522373.03 — Power Supply High Voltage9001-20-33	Transmission Reverse Clutch Solenoid Open Circuit Diagnostic Procedure.....9001-20-48
Power Supply High Voltage Diagnostic Procedure.....9001-20-33	522386.02 — Transmission Clutch KV Slippage9001-20-49
522373.04 — Power Supply Low Voltage9001-20-34	Transmission Clutch KV Slippage Diagnostic Procedure.....9001-20-49
Power Supply Low Voltage Diagnostic Procedure.....9001-20-34	522386.03 — Transmission Forward Clutch Solenoid Short to Power9001-20-51
522375.00 — Transmission Oil Filter Restricted.....9001-20-35	Transmission Forward Clutch Solenoid Short to Power Diagnostic Procedure.....9001-20-51
Transmission Oil Filter Restricted Diagnostic Procedure.....9001-20-35	522386.04 — Transmission Forward Clutch Solenoid Short to Ground9001-20-53
522376.00 — Transmission Oil Temperature Over Maximum Value9001-20-36	Transmission Forward Clutch Solenoid Short to Ground Diagnostic Procedure.....9001-20-53
Transmission Oil Temperature Over Maximum Value Diagnostic Procedure.....9001-20-36	522386.05 — Transmission Forward Clutch Solenoid Open Circuit.....9001-20-54
522379.03 — Park Brake Solenoid Short to Power9001-20-37	Transmission Forward Clutch Solenoid Open Circuit Diagnostic Procedure.....9001-20-54
Park Brake Solenoid Short to Power Diagnostic Procedure.....9001-20-38	522389.02 — Transmission Clutch K4 Slippage9001-20-56
522379.04 — Park Brake Solenoid Short to Ground.....9001-20-38	Transmission Clutch K4 Slippage Diagnostic Procedure.....9001-20-56
Park Brake Solenoid Short to Ground Diagnostic Procedure.....9001-20-39	522389.03 — Transmission Clutch K4 Solenoid Short to Power9001-20-57
522379.05 — Park Brake Solenoid Open Circuit9001-20-40	Transmission Clutch K4 Solenoid Short to Power Diagnostic Procedure.....9001-20-58
Park Brake Solenoid Open Circuit Diagnostic Procedure.....9001-20-40	522389.04 — Transmission Clutch K4 Solenoid Short to Ground.....9001-20-59
522382.03 — Backup Alarm Short to Power9001-20-41	Transmission Clutch K4 Solenoid Short to Ground Diagnostic Procedure.....9001-20-59
Backup Alarm Short to Power Diagnostic Procedure.....9001-20-41	522389.05 — Transmission Clutch K4 Solenoid Open Circuit9001-20-61
522382.04 — Backup Alarm Short to Ground9001-20-42	Transmission Clutch K4 Solenoid Open Circuit Diagnostic Procedure.....9001-20-61
Backup Alarm Short to Ground Diagnostic Procedure.....9001-20-42	522392.02 — Transmission Clutch K3 Slippage9001-20-62
522383.02 — Transmission Clutch KR Slippage9001-20-43	Transmission Clutch K3 Slippage Diagnostic Procedure.....9001-20-62
Transmission Clutch KR Slippage Diagnostic Procedure.....9001-20-43	522392.03 — Transmission Clutch K3 Solenoid Short to Power9001-20-64
522383.03 — Transmission Reverse Clutch Solenoid Short to Power9001-20-45	
Transmission Reverse Clutch Solenoid Short to Power Diagnostic Procedure.....9001-20-45	

Continued on next page

Page	Page
Transmission Clutch K3 Solenoid Short to Power Diagnostic Procedure.....9001-20-64	Transmission Output Shaft Open or Short to Power Diagnostic Procedure.....9001-20-81
522392.04 — Transmission Clutch K3 Solenoid Short to Ground.....9001-20-65	522401.04 — Transmission Output Shaft Short to Ground9001-20-83
Transmission Clutch K3 Solenoid Short to Ground Diagnostic Procedure.....9001-20-65	Transmission Output Shaft Short to Ground Diagnostic Procedure.....9001-20-83
522392.05 — Transmission Clutch K3 Solenoid Open Circuit9001-20-66	522401.12 — Transmission Output Shaft Fault.....9001-20-85
Transmission Clutch K3 Solenoid Open Circuit Diagnostic Procedure.....9001-20-67	Transmission Output Shaft Fault Diagnostic Procedure.....9001-20-85
522395.02 — Transmission Clutch K2 Slippage9001-20-68	522401.15 — Transmission Output Shaft Overspeed9001-20-86
Transmission Clutch K2 Slippage Diagnostic Procedure.....9001-20-68	Transmission Output Shaft Overspeed Diagnostic Procedure.....9001-20-86
522395.03 — Transmission Clutch K2 Solenoid Short to Power9001-20-70	522402.03 — Clutch Speed Sensor Open or Short.....9001-20-87
Transmission Clutch K2 Solenoid Short to Power Diagnostic Procedure.....9001-20-70	Internal Clutch Speed Sensor Open or Short Diagnostic Procedure9001-20-87
522395.04 — Transmission Clutch K2 Solenoid Short to Ground.....9001-20-71	522402.04 — Transmission Clutch Speed Sensor Short to Ground9001-20-88
Transmission Clutch K2 Solenoid Short to Ground Diagnostic Procedure.....9001-20-71	Transmission Clutch Speed Sensor Short to Ground Diagnostic Procedure.....9001-20-88
522395.05 — Transmission Clutch K2 Solenoid Open Circuit9001-20-73	522402.12 — Transmission Clutch Speed Sensor Fault9001-20-89
Transmission Clutch K2 Solenoid Open Circuit Diagnostic Procedure.....9001-20-73	Transmission Internal Clutch Speed Sensor Fault Diagnostic Procedure.....9001-20-89
522399.02 — Transmission Clutch K1 Slippage9001-20-74	522407.03 — Transmission Clutch Cut-Off Sensor Short to Power9001-20-90
Transmission Clutch K1 Slippage Diagnostic Procedure.....9001-20-74	Transmission Clutch Cut-Off Sensor Short to Power Diagnostic Procedure.....9001-20-90
522399.03 — Transmission Clutch K1 Solenoid Short to Power9001-20-76	522407.04 — Transmission Clutch Cut-Off Sensor Open or Short to Ground9001-20-91
Transmission Clutch K1 Solenoid Short to Power Diagnostic Procedure.....9001-20-76	Transmission Clutch Cut-Off Sensor Open or Short to Ground Diagnostic Procedure.....9001-20-91
522399.04 — Transmission Clutch K1 Solenoid Short to Ground.....9001-20-77	522409.05 — 2nd FNR (Pilot Control Joystick FNR) Open Circuit.....9001-20-93
Transmission Clutch K1 Solenoid Short to Ground Diagnostic Procedure.....9001-20-77	2nd FNR (Pilot Control Joystick FNR) Open Circuit Diagnostic Procedure.....9001-20-93
522399.05 — Transmission Clutch K1 Solenoid Open Circuit9001-20-79	522409.12 — 2nd FNR (Pilot Control Joystick FNR) Multiple Inputs9001-20-95
Transmission Clutch K1 Solenoid Open Circuit Diagnostic Procedure.....9001-20-79	2nd FNR (Pilot Control Joystick FNR) Multiple Inputs Diagnostic Procedure.....9001-20-95
522401.02 — Transmission Output Shaft Speed Sensor Fault.....9001-20-80	522411.05 — 1st FNR Open Circuit9001-20-96
Transmission Output Shaft Speed Sensor Fault Diagnostic Procedure.....9001-20-80	1st FNR (Steering Column FNR) Open Circuit Diagnostic Procedure.....9001-20-97
522401.03 — Transmission Output Shaft Open or Short to Power9001-20-81	

Continued on next page

Page	Page
1st FNR (Pilot Control Joystick FNR) Open Circuit Diagnostic Procedure.....9001-20-97	Fuel Level Short to Ground Diagnostic Procedure.....9001-30-3
522411.12 — 1st FNR Multiple Inputs9001-20-99	000096.05 — Fuel Level Open or Short.....9001-30-4
1st FNR (Steering Column FNR) Multiple Inputs Diagnostic Procedure.....9001-20-99	Fuel Level Open or Short Diagnostic Procedure.....9001-30-4
1st FNR Multiple Inputs (Pilot Control Joystick FNR) Diagnostic Procedure.....9001-20-100	000096.10 — Fuel Level Abnormal Rate of Change9001-30-7
522412.12 — Gear Selection Error9001-20-102	000167.16 — Alternator High Voltage9001-30-7
Gear Selection Error Diagnostic Procedure.....9001-20-102	Alternator High Voltage Diagnostic Procedure.....9001-30-7
522419.02 — Transmission Clutch Cut-Off Disabled.....9001-20-104	000167.18 — Alternator Low Voltage9001-30-8
Transmission Clutch Cut-Off Disabled Diagnostic Procedure.....9001-20-104	Alternator Low Voltage Diagnostic Procedure.....9001-30-8
522420.02 — Manual Down Shift Disabled9001-20-105	000168.16 — High Battery Voltage9001-30-8
Manual Downshift Disabled Diagnostic Procedure.....9001-20-105	High Battery Voltage Diagnostic Procedure.....9001-30-8
522421.02 — Automatic to 1st Disabled9001-20-106	000171.04 — Ambient Air Short to Ground9001-30-10
Automatic to 1st Disabled Diagnostic Procedure.....9001-20-106	000234.02 — Invalid Transmission Control Unit (TCU) Software Revision9001-30-10
524048.00 — Transmission Output Torque Exceeded9001-20-106	Invalid TCU Software Revision Diagnostic Procedure.....9001-30-10
Transmission Output Torque Exceeded Diagnostic Procedure.....9001-20-106	000521.00 — Brake Pedal High Voltage9001-30-11
524049.00 — Transmission Input Torque Exceeded9001-20-107	Brake Pedal High Voltage Diagnostic Procedure.....9001-30-11
Transmission Input Torque Exceeded Diagnostic Procedure.....9001-20-107	000578.00 — Rear Axle Oil High Temperature9001-30-11
524287.00 — Configure Machine Model9001-20-107	Rear Axle Oil High Temperature Diagnostic Procedure.....9001-30-11
Configure Machine Model Diagnostic Procedure.....9001-20-107	000578.04 — Rear Axle Oil Temp Sensor Short to Ground9001-30-12
524287.02 — Communication Error9001-20-108	Rear Axle Oil Temp Sensor Short to Ground Diagnostic Procedure.....9001-30-12
Group 30—Vehicle Control Unit (VCU) Diagnostic Trouble Codes	000628.12 — Controller Not Programmed9001-30-13
Vehicle Control Unit (VCU) Diagnostic Trouble Codes9001-30-1	Controller Not Programmed Diagnostic Procedure.....9001-30-13
000075.00 — Front Axle Oil High Temperature9001-30-1	000629.12 — Vehicle Control Unit (VCU) Watchdog Time Out9001-30-14
Front Axle Oil High Temperature Diagnostic Procedure.....9001-30-1	Vehicle Control Unit (VCU) Watchdog Time Out Diagnostic Procedure.....9001-30-14
000075.04 — Front Axle Oil Temp Sensor Short to Ground9001-30-2	000639.12 — Vehicle Control Unit (VCU) Controller Area Network (CAN) Failure9001-30-14
Front Axle Oil Temp Sensor Short to Ground Diagnostic Procedure.....9001-30-2	Vehicle Control Unit (VCU) Controller Area Network (CAN) Failure Diagnostic Procedure.....9001-30-14
000096.04 — Fuel Level Short to Ground9001-30-3	000639.14 — Vehicle Control Unit (VCU) Controller Area Network (CAN) 1 Bus Off9001-30-15

Continued on next page

Page	Page
Vehicle Control Unit (VCU) Controller Area Network (CAN) 1 Bus Off Diagnostic Procedure.....9001-30-15	001069.02 — Tire Size Incorrect.....9001-30-35
000746.03 — Differential Lock Solenoid Short to Power9001-30-16	Tire Size Incorrect Diagnostic Procedure.....9001-30-35
Differential Lock Solenoid Short to Power Diagnostic Procedure.....9001-30-16	001071.03 — Proportional Fan Solenoid High Side (HS) Short to Power9001-30-36
000746.05 — Differential Lock Solenoid Open9001-30-17	Proportional Fan Solenoid High Side (HS) Short to Power Diagnostic Procedure.....9001-30-36
Differential Lock Solenoid Open Diagnostic Procedure.....9001-30-17	001071.05 — Proportional Fan Solenoid High Side (HS) Open or Short.....9001-30-37
000746.06 — Differential Lock Solenoid High Current.....9001-30-19	Proportional Fan Solenoid High Side (HS) Open or Short Diagnostic Procedure.....9001-30-37
Differential Lock Solenoid High Current Diagnostic Procedure.....9001-30-19	001071.06 — Proportional Fan Solenoid High Side (HS) High Current9001-30-39
000785.03 — Pilot Solenoid Short to Power9001-30-20	Proportional Fan Solenoid High Side (HS) High Current Diagnostic Procedure.....9001-30-39
Pilot Solenoid Short to Power Diagnostic Procedure.....9001-30-20	001071.13 — Proportional Fan Solenoid Out of Calibration9001-30-40
000785.05 — Pilot Solenoid Open or Short.....9001-30-21	001071.16 — Proportional Fan Solenoid Low Side (LS) High Current9001-30-40
Pilot Solenoid Open or Short Diagnostic Procedure.....9001-30-21	Proportional Fan Solenoid Low Side (LS) High Current Diagnostic Procedure.....9001-30-40
000785.06 — Pilot Solenoid High Current9001-30-23	001071.17 — Proportional Fan Solenoid Low Side (LS) Open or Short.....9001-30-41
Pilot Solenoid High Current Diagnostic Procedure.....9001-30-23	Proportional Fan Solenoid Low Side (LS) Open or Short Diagnostic Procedure.....9001-30-41
000880.03 — Brake Lights Short to Power9001-30-25	001071.18 — Proportional Fan Solenoid Low Side (LS) Short to Power9001-30-43
Brake Lights Short to Power Diagnostic Procedure.....9001-30-25	Proportional Fan Solenoid Low Side (LS) Short to Power Diagnostic Procedure.....9001-30-43
000880.05 — Brake Lights Open or Short.....9001-30-26	001231.12 — Vehicle Control Unit (VCU) Controller Area Network (CAN) 2 Failure9001-30-44
Brake Lights Open or Short Diagnostic Procedure.....9001-30-26	Vehicle Control Unit (VCU) Controller Area Network (CAN) 2 Failure Diagnostic Procedure.....9001-30-44
000880.06 — Brake Lights High Current9001-30-27	001231.14 — Vehicle Control Unit (VCU) Controller Area Network (CAN) 2 Bus Off9001-30-45
Brake Lights High Current Diagnostic Procedure.....9001-30-27	Vehicle Control Unit (VCU) Controller Area Network (CAN) 2 Bus Off Diagnostic Procedure.....9001-30-45
000920.03 — Alarm Short to Power9001-30-29	001550.03 — Air Conditioner Clutch Short to Power9001-30-46
000920.05 — Alarm Open Circuit.....9001-30-30	Air Conditioner Clutch Short to Power Diagnostic Procedure.....9001-30-46
000920.06 — Alarm Short to Ground9001-30-31	
000977.03 — Reversing Fan Solenoid Short to Power9001-30-31	
Reversing Fan Solenoid Short to Power Diagnostic Procedure.....9001-30-31	
000977.05 — Reversing Fan Solenoid Open or Short.....9001-30-32	
Reversing Fan Solenoid Open or Short Diagnostic Procedure.....9001-30-32	
000977.06 — Reversing Fan Solenoid High Current.....9001-30-34	
Reversing Fan Solenoid High Current Diagnostic Procedure.....9001-30-34	

Continued on next page

Page	Page
001550.06 — Air Conditioner Clutch High Current.....9001-30-46	Blackout Brake Lights Open or Short Diagnostic Procedure.....9001-30-62
Air Conditioner Clutch High Current Diagnostic Procedure.....9001-30-46	001841.06 — Blackout Brake Lights High Current.....9001-30-63
001638.00 — Hydraulic Oil High Temperature.....9001-30-47	Blackout Brake Lights High Current Diagnostic Procedure.....9001-30-63
Hydraulic Oil High Temperature Diagnostic Procedure.....9001-30-47	001842.03 — Blackout Lights Short to Power.....9001-30-64
001638.04 — Hydraulic Oil Temperature Sensor Short to Ground.....9001-30-48	Blackout Lights Short to Power Diagnostic Procedure.....9001-30-65
Hydraulic Oil Temperature Sensor Short to Ground Diagnostic Procedure.....9001-30-48	001842.05 — Blackout Lights Open or Short.....9001-30-66
001639.02 — Fan Speed Sensor Out of Synchronization.....9001-30-50	Blackout Lights Open or Short Diagnostic Procedure.....9001-30-66
Fan Speed Sensor Out of Synchronization Diagnostic Procedure.....9001-30-50	001842.06 — Blackout Lights High Current.....9001-30-68
001639.04 — Fan Speed Sensor Short to Ground.....9001-30-51	Blackout Lights High Current Diagnostic Procedure.....9001-30-68
Fan Speed Sensor Short to Ground Diagnostic Procedure.....9001-30-51	002000.09 — Controller Area Network (CAN) Communication Lost for Engine Control Unit (ECU).....9001-30-70
001639.05 — Fan Speed Sensor Open Circuit.....9001-30-52	Controller Area Network (CAN) Communication Lost for Engine Control Unit (ECU) Diagnostic Procedure.....9001-30-70
Fan Speed Sensor Open Circuit.....9001-30-52	002003.09 — Controller Area Network (CAN) Communication Lost for Transmission Control Unit (TCU).....9001-30-72
001639.07 — Fan Speed Did Not Lower During Reversal.....9001-30-54	Controller Area Network (CAN) Communication Lost for Transmission Control Unit (TCU) Diagnostic Procedure.....9001-30-72
001639.08 — Fan Speed Sensor No Signal.....9001-30-54	002033.14 — Flexpower Handshaking Error.....9001-30-73
Fan Speed Sensor No Signal Diagnostic Procedure.....9001-30-54	002040.09 — Controller Area Network (CAN) Communication Lost for Advanced Displaying Unit (ADU).....9001-30-74
001639.10 — Fan Speed Sensor Fault.....9001-30-55	Controller Area Network (CAN) Communication Lost for Advanced Displaying Unit (ADU) Diagnostic Procedure.....9001-30-74
Fan Speed Sensor Fault Diagnostic Procedure.....9001-30-55	002051.09 — Controller Area Network (CAN) Communication Lost for Tire Pressure Monitoring System (TPMS).....9001-30-75
001639.13 — Fan Speed Sensor Out of Calibration.....9001-30-57	CAN Communication Lost for TPMS Diagnostic Procedure.....9001-30-75
001713.01 — Hydraulic Oil Filter Restricted.....9001-30-57	002132.09 — Controller Area Network (CAN) Communication Lost for Radar Object Detection (ROD).....9001-30-77
Hydraulic Oil Filter Restricted Diagnostic Procedure.....9001-30-57	Controller Area Network (CAN) Communication Lost for Radar Object Detection (ROD) Diagnostic Procedure.....9001-30-77
001762.03 — Hydraulic Pressure Sensor Short to Power.....9001-30-58	
Hydraulic System Pressure Sensor Short to Power Diagnostic Procedure.....9001-30-58	
001762.04 — Hydraulic Pressure Sensor Open or Short.....9001-30-59	
Hydraulic System Pressure Sensor Open or Short Diagnostic Procedure.....9001-30-59	
001841.03 — Blackout Brake Lights Short to Power.....9001-30-60	
Blackout Brake Lights Short to Power Diagnostic Procedure.....9001-30-61	
001841.05 — Blackout Brake Lights Open or Short.....9001-30-62	

Continued on next page

Page	Page
002141.09 — Controller Area Network (CAN) Communication Lost for Sealed Switch Module (SSM).....9001-30-78	002359.05 — Machine Work Lights Open or Short.....9001-30-95
Controller Area Network (CAN) Communication Lost for Sealed Switch Module (SSM) Diagnostic Procedure.....9001-30-78	Machine Work Lights Open or Short Diagnostic Procedure.....9001-30-95
002169.09 — Controller Area Network (CAN) Communication Lost for Ground Speed Radar (RDR).....9001-30-80	002359.06 — Machine Work Lights High Current.....9001-30-97
Controller Area Network (CAN) Communication Lost for Ground Speed Radar (RDR) Diagnostic Procedure.....9001-30-80	Machine Work Lights High Current Diagnostic Procedure.....9001-30-97
002251.09 — Controller Area Network (CAN) Lost for JDLINK9001-30-82	002362.03 — Rear Work Lights Short to Power9001-30-98
002350.03 — Drive Lamps Short to Power9001-30-82	Rear Work Lights Short to Power Diagnostic Procedure.....9001-30-98
Drive Lamps Short to Power Diagnostic Procedure.....9001-30-82	002362.05 — Rear Work Lights Open or Short9001-30-99
002350.05 — Drive Lamps Open or Short.....9001-30-83	Rear Work Lights Open or Short Diagnostic Procedure.....9001-30-99
Drive Lamps Open or Short Diagnostic Procedure.....9001-30-83	002362.06 — Rear Work Lights High Current9001-30-101
002350.06 — Drive Lamps High Current9001-30-85	Rear Work Lights High Current Diagnostic Procedure.....9001-30-101
Drive Lamps High Current Diagnostic Procedure.....9001-30-85	002367.04 — Left Turn Switch Short to Ground9001-30-102
002355.03 — Front Work Lights Short to Power9001-30-86	Left Turn Switch Short to Ground Diagnostic Procedure.....9001-30-102
Front Work Lights Short to Power9001-30-86	002368.03 — Left Turn Lights Short to Power9001-30-103
002355.05 — Front Work Lights Open or Short9001-30-87	Left Turn Lights Short to Power Diagnostic Procedure.....9001-30-103
Front Work Lights Open or Short Diagnostic Procedure.....9001-30-87	002368.05 — Left Turn Lights Open or Short.....9001-30-104
002355.06 — Front Work Lights High Current9001-30-89	Left Turn Lights Open or Short Diagnostic Procedure.....9001-30-105
Front Work Lights High Current Diagnostic Procedure.....9001-30-89	002368.06 — Left Turn Lights High Current9001-30-106
002356.03 — Front Work Lights Short to Power9001-30-90	Left Turn Lights High Current Diagnostic Procedure.....9001-30-106
Front Work Lights Short to Power Diagnostic Procedure.....9001-30-91	002369.04 — Right Turn Switch Short to Ground9001-30-108
002356.05 — Front Work Lights Open or Short9001-30-91	Right Turn Switch Short to Ground Diagnostic Procedure.....9001-30-108
Front Work Lights Open or Short Diagnostic Procedure.....9001-30-92	002370.03 — Right Turn Lights Short to Power9001-30-109
002356.06 — Front Work Lights High Current9001-30-93	Right Turn Lights Short to Power Diagnostic Procedure.....9001-30-109
Front Work Lights High Current Diagnostic Procedure.....9001-30-93	002370.05 — Right Turn Lights Open or Short9001-30-110
002359.03 — Machine Work Lights Short to Power9001-30-94	Right Turn Lights Open or Short Diagnostic Procedure.....9001-30-110
Machine Work Lights Short to Power Diagnostic Procedure.....9001-30-95	002370.06 — Right Turn Lights High Current9001-30-112
	Right Turn Lights High Current Diagnostic Procedure.....9001-30-112
	002378.03 — Marker/Tail Lights Short to Power9001-30-114
	Marker/Tail Lights Short to Power Diagnostic Procedure.....9001-30-114
	002378.05 — Marker/Tail Lights Open Circuit.....9001-30-116

Continued on next page

Page	Page
002378.06 — Marker/Tail Lights High Current9001-30-117	Boom Height Kickout (BHKO) Detent Short to Power Diagnostic Procedure.....9001-30-132
Marker/Tail Lights High Current Diagnostic Procedure.....9001-30-117	002754.05 — Boom Height Kickout (BHKO) Detent Open or Short9001-30-133
002386.03 — Beacon Light Short to Power9001-30-118	Boom Height Kickout (BHKO) Detent Open or Short Diagnostic Procedure.....9001-30-133
Beacon Light Short to Power Diagnostic Procedure.....9001-30-118	002754.06 — Boom Height Kickout (BHKO) Detent High Current.....9001-30-135
002386.06 — Beacon Light High Current9001-30-119	Boom Height Kickout (BHKO) Detent High Current Diagnostic Procedure.....9001-30-135
Beacon Light High Current Diagnostic Procedure.....9001-30-119	002875.04 — Hazard Wakeup Short to Ground9001-30-136
002650.03 — Lockout Fan Solenoid Short to Power9001-30-120	Hazard Wakeup Short to Ground Diagnostic Procedure.....9001-30-136
Lockout Fan Solenoid Short to Power Diagnostic Procedure.....9001-30-120	003509.04 — Vehicle Control Unit (VCU) Sensor 1 Voltage Low9001-30-137
002650.05 — Lockout Fan Solenoid Open or Short.....9001-30-121	Vehicle Control Unit (VCU) Sensor 1 Voltage Low Diagnostic Procedure.....9001-30-137
Lockout Fan Solenoid Open or Short Diagnostic Procedure.....9001-30-121	003510.04 — Vehicle Control Unit (VCU) Sensor 2 Voltage Low9001-30-139
002650.06 — Lockout Fan Solenoid High Current.....9001-30-123	Vehicle Control Unit (VCU) Sensor 2 Voltage Low Diagnostic Procedure.....9001-30-139
Lockout Fan Solenoid High Current Diagnostic Procedure.....9001-30-123	003511.04 — Vehicle Control Unit (VCU) Sensor 3 Voltage Low9001-30-140
002680.03 — Return-to-Carry (RTC)/Float Detent Short to Power9001-30-125	Vehicle Control Unit (VCU) Sensor 3 Voltage Low Diagnostic Procedure.....9001-30-140
Return-to-Carry (RTC)/Float Detent Short to Power Diagnostic Procedure.....9001-30-125	003598.02 — 7 V Supply Voltage Low.....9001-30-141
002680.05 — Return-to-Carry (RTC)/Float Detent Open or Short.....9001-30-126	7 V Supply Voltage Low Diagnostic Procedure.....9001-30-142
Return-to-Carry (RTC)/Float Detent Open or Short Diagnostic Procedure.....9001-30-126	004086.03 — HPM Pressure Sensor Short to Power9001-30-142
002680.06 — Return-to-Carry (RTC)/Float Detent High Current9001-30-127	Hydraulic Power Management (HPM) Pressure Sensor Short to Power Diagnostic Procedure.....9001-30-142
Return-to-Carry (RTC)/Float Detent High Current Diagnostic Procedure.....9001-30-127	004086.04 — HPM Pressure Sensor Open or Short.....9001-30-143
002717.03 — Return-to-Dig (RTD) Detent Short to Power.....9001-30-129	Hydraulic Power Management (HPM) Pressure Sensor (B65) Open or Short Diagnostic Procedure9001-30-143
Return-to-Dig (RTD) Detent Short to Power Diagnostic Procedure.....9001-30-129	520194.02 — Invalid Vehicle Identification Number (VIN).....9001-30-145
002717.05 — Return-to-Dig (RTD) Detent Open or Short.....9001-30-129	521948.02 — Engine Tier Level Invalid.....9001-30-145
Return-to-Dig (RTD) Detent Open or Short Diagnostic Procedure9001-30-130	Engine Tier Level Invalid Diagnostic Procedure.....9001-30-145
002717.06 — Return-to-Dig (RTD) Detent High Current9001-30-131	521985.04 — Central Processing Unit (CPU) Switched Power Voltage Low.....9001-30-145
Return-to-Dig (RTD) Detent High Current Diagnostic Procedure.....9001-30-131	
002754.03 — Boom Height Kickout (BHKO) Detent Short to Power9001-30-132	

Continued on next page

Page	Page
Central Processing Unit (CPU) Switched Power Voltage Low Diagnostic Procedure.....9001-30-146	Front Wiper Low Speed Short to Power Diagnostic Procedure.....9001-30-163
522280.01 — Brake Pressure Low.....9001-30-147	522434.05 — Front Wiper Low Speed Open Circuit.....9001-30-164
Brake Pressure Low Diagnostic Procedure.....9001-30-147	Front Wiper Low Speed Open Circuit Diagnostic Procedure.....9001-30-164
522341.03 — Heated Mirror Short to Power.....9001-30-148	522434.06 — Front Wiper Low Speed High Current.....9001-30-165
Heated Mirror Short to Power Diagnostic Procedure.....9001-30-148	Front Wiper Low Speed High Current Diagnostic Procedure.....9001-30-166
522341.05 — Heated Mirror Open Circuit.....9001-30-149	522435.03 — Front Wiper High Speed Short to Power.....9001-30-167
Heated Mirror Open Circuit Diagnostic Procedure.....9001-30-149	Front Wiper High Speed Short to Power Diagnostic Procedure.....9001-30-167
522341.06 — Heated Mirror High Current.....9001-30-151	522435.05 — Front Wiper High Speed Open Circuit.....9001-30-167
Heated Mirror High Current Diagnostic Procedure.....9001-30-151	Front Wiper High Speed Open Circuit Diagnostic Procedure.....9001-30-167
522426.04 — Rear Wiper Park Short to Ground.....9001-30-152	522435.06 — Front Wiper High Speed High Current.....9001-30-169
Rear Wiper Park Short to Ground Diagnostic Procedure.....9001-30-152	Front Wiper High Speed High Current Diagnostic Procedure.....9001-30-169
522427.04 — Front Wiper Park Short to Ground.....9001-30-153	522436.03 — Bucket Position Short to Power.....9001-30-170
Front Wiper Park Short to Ground Diagnostic Procedure.....9001-30-153	Bucket Position Short to Power Diagnostic Procedure.....9001-30-170
522431.02 — Memory Test Failure.....9001-30-154	522436.04 — Bucket Position Open or Short.....9001-30-171
Memory Test Failure Diagnostic Procedure.....9001-30-154	Bucket Position Open or Short Diagnostic Procedure.....9001-30-171
522432.03 — Rear Wiper High Speed Short to Power.....9001-30-155	522437.04 — Return-to-Dig (RTD) Switch Short to Ground.....9001-30-173
Rear Wiper High Speed Short to Power Diagnostic Procedure.....9001-30-155	Return-to-Dig (RTD) Switch Short to Ground Diagnostic Procedure.....9001-30-173
522432.05 — Rear Wiper High Speed Open Circuit.....9001-30-156	522438.03 — Pin Disconnect Solenoid Short to Power.....9001-30-174
Rear Wiper High Speed Open Circuit.....9001-30-156	Pin Disconnect Solenoid Short to Power Diagnostic Procedure.....9001-30-174
522432.06 — Rear Wiper High Speed High Current.....9001-30-158	522438.05 — Pin Disconnect Solenoid Open or Short.....9001-30-175
Rear Wiper High Speed High Current Diagnostic Procedure.....9001-30-158	Pin Disconnect Solenoid Open or Short Diagnostic Procedure.....9001-30-175
522433.03 — Rear Wiper Low Speed Short to Power.....9001-30-159	522438.06 — Pin Disconnect Solenoid High Current.....9001-30-177
Rear Wiper Low Speed Short to Power Diagnostic Procedure.....9001-30-159	Pin Disconnect Solenoid High Current Diagnostic Procedure.....9001-30-177
522433.05 — Rear Wiper Low Speed Open Circuit.....9001-30-160	522543.03 — Boom Cylinder Rod Pressure Sensor Open or Short.....9001-30-178
Rear Wiper Low Speed Open Circuit Diagnostic Procedure.....9001-30-160	Boom Cylinder Rod Pressure Sensor Open or Short Diagnostic Procedure.....9001-30-178
522433.06 — Rear Wiper Low Speed High Current.....9001-30-162	522543.04 — Boom Cylinder Rod Pressure Sensor Short to Ground.....9001-30-180
Rear Wiper Low Speed High Current Diagnostic Procedure.....9001-30-162	
522434.03 — Front Wiper Low Speed Short to Power.....9001-30-163	

Continued on next page

Page	Page
Boom Cylinder Rod Pressure Sensor Short to Ground Diagnostic Procedure.....9001-30-180	Steering Pressure Sensor Short to Power Diagnostic Procedure.....9001-30-196
522544.03 — Boom Cylinder Head Pressure Sensor Open or Short.....9001-30-181	523137.04 — Steering Pressure Sensor Short to Ground9001-30-197
Boom Cylinder Head Pressure Sensor Open or Short Diagnostic Procedure.....9001-30-181	Steering Pressure Sensor Open or Short Diagnostic Procedure9001-30-197
522544.04 — Boom Cylinder Head Pressure Sensor Short to Ground9001-30-183	523137.05 — Steering Pressure Sensor Open Circuit.....9001-30-199
Boom Cylinder Head Pressure Sensor Short to Ground Diagnostic Procedure.....9001-30-183	Steering Pressure Sensor Open or Short Diagnostic Procedure9001-30-199
522620.03 — Vehicle Horn Short to Power9001-30-184	523137.12 — Steering Pressure Sensor Invalid9001-30-201
Vehicle Horn Short to Power Diagnostic Procedure.....9001-30-184	Steering Pressure Sensor Invalid Diagnostic Procedure.....9001-30-201
522620.05 — Vehicle Horn Open Circuit.....9001-30-185	523219.04 — Switched Power Voltage Low.....9001-30-201
Vehicle Horn Open Circuit Diagnostic Procedure.....9001-30-185	Switched Power Voltage Low Diagnostic Procedure.....9001-30-201
522620.06 — Vehicle Horn High Current9001-30-186	523440.04 — Unswitched Power Voltage Low.....9001-30-203
Vehicle Horn High Current Diagnostic Procedure.....9001-30-186	Unswitched Power Voltage Low Diagnostic Procedure.....9001-30-203
522796.03 — Rear Washer Pump Short to Power9001-30-187	523577.03 — Secondary Steering Pump Shorted to Power9001-30-204
Rear Washer Pump Short to Power Diagnostic Procedure.....9001-30-187	Secondary Steering Pump Shorted to Power Diagnostic Procedure.....9001-30-204
522796.05 — Rear Washer Pump Open or Short.....9001-30-188	523577.05 — Secondary Steering Pump Open or Short Circuit.....9001-30-205
Rear Washer Pump Open or Short Diagnostic Procedure.....9001-30-188	Secondary Steering Pump Open or Short Circuit Diagnostic Procedure.....9001-30-205
522796.06 — Rear Washer Pump High Current9001-30-190	523577.06 — Secondary Steering Pump High Current9001-30-207
Rear Washer Pump High Current Diagnostic Procedure.....9001-30-190	Secondary Steering Pump High Current Diagnostic Procedure.....9001-30-207
522797.03 — Front Washer Pump Short to Power9001-30-191	523689.04 — Differential Lock Switch Short to Ground.....9001-30-208
Front Washer Pump Short to Power Diagnostic Procedure.....9001-30-191	Differential Lock Switch Short to Ground Diagnostic Procedure.....9001-30-208
522797.05 — Front Washer Pump Open or Short.....9001-30-192	523786.03 — Boom Position Sensor Short to Power9001-30-210
Front Washer Pump Open or Short Diagnostic Procedure.....9001-30-192	Boom Position Sensor Short to Power Diagnostic Procedure.....9001-30-210
522797.06 — Front Washer Pump High Current.....9001-30-194	523786.06 — Boom Position Sensor Short to Ground.....9001-30-211
Front Washer Pump High Current Diagnostic Procedure.....9001-30-194	Boom Position Sensor Short to Ground Diagnostic Procedure.....9001-30-211
523137.01 — Steering System Pressure Low9001-30-195	523837.01 — Brake Pressure Low—Rear9001-30-212
Steering System Pressure Low Diagnostic Procedure.....9001-30-195	Brake Pressure Low—Rear Diagnostic Procedure.....9001-30-212
523137.03 — Steering Pressure Sensor Short to Power9001-30-196	523837.03 — Rear Brake Pressure Sensor Short to Power9001-30-213
	Rear Brake Pressure Sensor Short to Power Diagnostic Procedure.....9001-30-213

Continued on next page

Page	Page
523837.04 — Rear Brake Pressure Open or Short.....9001-30-214	Hydraulic Power Management Solenoid Low Side Open Circuit Diagnostic Procedure.....9001-30-228
Rear Brake Pressure Open or Short Diagnostic Procedure.....9001-30-214	523911.18 — Hydraulic Power Management Solenoid Low Side Short to Power9001-30-230
523840.01 — Brake Pressure Low—Front.....9001-30-216	Hydraulic Power Management Solenoid Low Side Short to Power Diagnostic Procedure.....9001-30-230
Brake Pressure Low—Front Diagnostic Procedure.....9001-30-216	523948.03 — Ride Control Solenoid Short to Power9001-30-231
523840.03 — Front Brake Pressure Sensor Short to Power9001-30-217	Ride Control Solenoid Short to Power Diagnostic Procedure.....9001-30-232
Front Brake Pressure Sensor Short to Power Diagnostic Procedure.....9001-30-217	523948.05 — Ride Control Solenoid Open Circuit9001-30-232
523840.04 — Front Brake Pressure Sensor Open or Short9001-30-218	Ride Control Solenoid Open Circuit Diagnostic Procedure.....9001-30-232
Front Brake Pressure Sensor Open or Short Diagnostic Procedure9001-30-218	523948.06 — Ride Control Solenoid High Current.....9001-30-234
523865.04 — Add Truck Switch Short to Ground9001-30-220	Ride Control Solenoid High Current Diagnostic Procedure.....9001-30-234
Add Truck Switch Short to Ground Diagnostic Procedure.....9001-30-220	524044.01 — Axle Oil Filter Restricted9001-30-235
523867.04 — Counter Switch Short to Ground9001-30-221	524044.03 — Axle Oil Filter Short to Power9001-30-235
Counter Switch Short to Ground Diagnostic Procedure.....9001-30-221	524250.31 — Inspect Park Brake.....9001-30-236
523868.04 — Add Bucket Switch Short to Ground9001-30-222	Inspect Park Brake Diagnostic Procedure.....9001-30-236
Add Bucket Switch Short to Ground Diagnostic Procedure.....9001-30-222	524265.19 — Checksum Error9001-30-236
523911.03 — Hydraulic Power Management Solenoid High Side Short to Power9001-30-223	Check Sum Error Diagnostic Procedure.....9001-30-236
Hydraulic Power Management (HPM) Solenoid High Side Short to Power Diagnostic Procedure.....9001-30-223	
523911.05 — Hydraulic Power Management Solenoid High Side Open Circuit9001-30-224	
HPM Solenoid High Side Open Circuit Diagnostic Procedure.....9001-30-225	
523911.06 — Hydraulic Power Management Solenoid High Side High Current.....9001-30-226	
Hydraulic Power Management Solenoid High Side High Current Diagnostic Procedure.....9001-30-226	
523911.13 — Hydraulic Power Management System Out of Calibration9001-30-227	
523911.16 — Hydraulic Power Management Solenoid Low Side High Current.....9001-30-227	
Hydraulic Power Management Solenoid Low Side High Current Diagnostic Procedure.....9001-30-227	
523911.17 — Hydraulic Power Management Solenoid Low Side Open Circuit9001-30-228	

Group 40—Sealed Switch Module (SSM) Diagnostic Trouble Codes

Sealed Switch Module (SSM) Diagnostic Trouble Codes9001-40-1
000629.12 — Sealed Switch Module (SSM) Watchdog Time Out9001-40-1
SSM Watchdog Time Out Diagnostic Procedure.....9001-40-1
002033.09 — Controller Area Network (CAN) Communication Lost for Vehicle Control Unit (VCU).....9001-40-2
CAN Communication Lost for VCU Diagnostic Procedure.....9001-40-2
002634.04 — Sealed Switch Module (SSM) Ignition Relay Signal Short to Ground9001-40-3
Sealed Switch Module (SSM) Ignition Relay Signal Short to Ground Diagnostic Procedure.....9001-40-3
002634.05 — Sealed Switch Module (SSM) Ignition Relay Signal Open Circuit.....9001-40-4
Sealed Switch Module (SSM) Ignition Relay Signal Open Circuit Diagnostic Procedure.....9001-40-4

Continued on next page

Page	Page
520752.04 — Button 17 Keypad Stuck9001-40-5	523339.04 — Axle Disconnect Keypad Stuck9001-40-18
Button 17 Keypad Stuck Diagnostic Procedure.....9001-40-5	Axle Disconnect Keypad Stuck Diagnostic Procedure.....9001-40-18
520752.09 — Button 17 Light-Emitting Diode (LED) Message.....9001-40-6	523339.09 — Lost Axle Disconnect Light-Emitting Diode (LED) Message.....9001-40-19
Button 17 Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-6	Lost Axle Disconnect Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-19
520753.04 — Front Washer Keypad Stuck9001-40-8	523340.04 — Button 21 Keypad Stuck9001-40-20
Front Washer Keypad Stuck Diagnostic Procedure.....9001-40-8	Button 21 Keypad Stuck Diagnostic Procedure.....9001-40-20
520754.04 — Front Wiper Keypad Stuck9001-40-8	523340.09 — Button 21 Light-Emitting Diode (LED) Message.....9001-40-21
Front Wiper Keypad Stuck Diagnostic Procedure.....9001-40-8	Button 21 Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-21
520754.09 — Lost Front Wiper Light-Emitting Diode (LED) Message.....9001-40-9	523849.04 — Air Conditioner Keypad Stuck9001-40-23
Lost Front Wiper Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-9	Air Conditioner Keypad Stuck Diagnostic Procedure.....9001-40-23
520755.04 — Drive Lights Keypad Stuck9001-40-11	523349.09 — Lost Air Conditioner Light-Emitting Diode (LED) Message.....9001-40-23
Drive Lights Keypad Stuck Diagnostic Procedure.....9001-40-11	Lost Air Conditioner Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-23
520755.09 — Lost Drive Lights Light-Emitting Diode (LED) Message.....9001-40-11	523850.04 — Pin Disconnect Keypad Stuck9001-40-25
Lost Drive Lights Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-11	Pin Disconnect Keypad Stuck Diagnostic Procedure.....9001-40-25
523335.04 — Work Lights Keypad Stuck9001-40-13	523850.09 — Lost Pin Disconnect Light-Emitting Diode (LED) Message.....9001-40-26
Work Lights Keypad Stuck Diagnostic Procedure.....9001-40-13	Lost Pin Disconnect Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-26
523335.09 — Lost Work Lights Light-Emitting Diode (LED) Message.....9001-40-14	523852.04 — Spin Control Keypad Stuck9001-40-27
Lost Work Lights Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-14	Spin Control Keypad Stuck Diagnostic Procedure.....9001-40-27
523336.04 — Rear Wiper Keypad Stuck9001-40-15	523852.09 — Lost Spin Control Light-Emitting Diode (LED) Message.....9001-40-28
Rear Wiper Keypad Stuck Diagnostic Procedure.....9001-40-15	Lost Spin Control Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-28
523336.09 — Lost Rear Wiper Light-Emitting Diode (LED) Message.....9001-40-16	523854.04 — Differential Lock Keypad Stuck9001-40-29
Lost Rear Wiper Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-16	Differential Lock Keypad Stuck Diagnostic Procedure.....9001-40-29
523338.04 — Rear Washer Keypad Stuck9001-40-17	523854.09 — Lost Differential Lock Light-Emitting Diode (LED) Message.....9001-40-30
Rear Washer Keypad Stuck Diagnostic Procedure.....9001-40-17	

Continued on next page

Page	Page
Lost Differential Lock Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-30	523861.09 — Lost Return To Dig Light-Emitting Diode (LED) Message.....9001-40-44
523855.04 — Return To Carry Keypad Stuck9001-40-32	Lost Return-to-Dig Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-44
Return-to-Carry Keypad Stuck Diagnostic Procedure.....9001-40-32	523862.04 — Park Brake Keypad Stuck9001-40-45
523855.09 — Lost Return To Carry Light-Emitting Diode (LED) Message.....9001-40-32	Park Brake Keypad Stuck Diagnostic Procedure.....9001-40-45
Lost Return-to-Carry Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-32	523862.09 — Lost Park Brake Light-Emitting Diode (LED) Message.....9001-40-46
523856.04 — Boom Height Kick Out Keypad Stuck9001-40-34	Lost Park Brake Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-46
Boom Height Kick Out Keypad Stuck Diagnostic Procedure.....9001-40-34	523863.04 — Pilot Enable Keypad Stuck9001-40-47
523856.09 — Lost Boom Height Kick Out Light-Emitting Diode (LED) Message.....9001-40-35	Pilot Enable Keypad Stuck Diagnostic Procedure.....9001-40-47
Lost Boom Height Kick Out Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-35	523863.09 — Lost Pilot Enable Light-Emitting Diode (LED) Message.....9001-40-48
523857.04 — Clutch Cut-Off Keypad Stuck9001-40-36	Lost Pilot Enable Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-48
Clutch Cut-Off Keypad Stuck Diagnostic Procedure.....9001-40-36	523864.04 — Hazards Keypad Stuck9001-40-50
523857.09 — Lost Clutch Cut-Off Light-Emitting Diode (LED) Message.....9001-40-37	Hazards Keypad Stuck Diagnostic Procedure.....9001-40-50
Lost Clutch Cut-Off Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-37	523864.09 — Lost Hazard Light-Emitting Diode (LED) Message.....9001-40-50
523858.04 — Ride Control Keypad Stuck9001-40-38	Lost Hazard Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-50
Ride Control Keypad Stuck Diagnostic Procedure.....9001-40-38	523865.04 — Beacon Light Keypad Stuck9001-40-52
523858.09 — Lost Ride Control Light-Emitting Diode (LED) Message.....9001-40-39	Beacon Light Keypad Stuck Diagnostic Procedure.....9001-40-52
Lost Ride Control Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-39	523865.09 — Lost Beacon Light-Emitting Diode (LED) Message.....9001-40-53
523860.04 — Auto Transmission Keypad Stuck9001-40-41	Lost Beacon Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-53
Auto Transmission Keypad Stuck Diagnostic Procedure.....9001-40-41	523867.04 — Ignition Off Keypad Stuck9001-40-54
523860.09 — Lost Auto Transmission Light-Emitting Diode (LED) Message.....9001-40-41	Ignition Off Keypad Stuck Diagnostic Procedure.....9001-40-54
Lost Auto Transmission Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-42	523867.09 — Lost Ignition Off Light-Emitting Diode (LED) Message.....9001-40-55
523861.04 — Return To Dig Keypad Stuck9001-40-43	523868.04 — Ignition On Keypad Stuck9001-40-55
Return-to-Dig Keypad Stuck Diagnostic Procedure.....9001-40-43	Ignition On Keypad Stuck Diagnostic Procedure.....9001-40-55

Continued on next page

Page	Page
523868.09 — Lost Ignition On Light-Emitting Diode (LED) Message.....9001-40-56	Memory Stack Overflow Diagnostic Procedure.....9001-50-9
Lost Ignition On Light-Emitting Diode (LED) Message Diagnostic Procedure.....9001-40-56	523773.03 — CAN HIGH Voltage High.....9001-50-10
Group 50—Advanced Display Unit (ADU) Diagnostic Trouble Codes	CAN HIGH Voltage High Diagnostic Procedure.....9001-50-10
Advanced Display Unit (ADU) Diagnostic Trouble Codes9001-50-1	523773.04 — CAN HIGH Voltage Low.....9001-50-10
000158.03 — Switched Power Voltage High.....9001-50-1	CAN HIGH Voltage Low Diagnostic Procedure.....9001-50-11
Switched Power Voltage High Diagnostic Procedure.....9001-50-1	523774.03 — CAN LOW Voltage High.....9001-50-11
000158.04 — Switched Power Voltage Low.....9001-50-2	CAN LOW Voltage High Diagnostic Procedure.....9001-50-11
Switched Power Voltage Low Diagnostic Procedure.....9001-50-2	523774.04 — CAN LOW Voltage Low.....9001-50-12
000168.03 — High Battery Voltage.....9001-50-3	CAN LOW Voltage Low Diagnostic Procedure.....9001-50-12
High Battery Voltage Diagnostic Procedure.....9001-50-3	524076.10 — Information Button Stuck.....9001-50-12
000168.04 — Low Battery Voltage.....9001-50-4	Information Button Stuck Diagnostic Procedure.....9001-50-12
Low Battery Voltage Diagnostic Procedure.....9001-50-4	524077.10 — Back Key Button Stuck.....9001-50-13
000442.00 — Display Temp High.....9001-50-5	Back Key Button Stuck Diagnostic Procedure.....9001-50-13
Display Temp High Diagnostic Procedure.....9001-50-5	524078.10 — Menu Select Button Stuck.....9001-50-13
000442.01 — Display Temp Low.....9001-50-6	Menu Select Button Stuck Diagnostic Procedure.....9001-50-13
Display Temp Low Diagnostic Procedure.....9001-50-6	524080.10 — Down Arrow Button Stuck.....9001-50-14
001491.11 — LCD Backlight Failure.....9001-50-6	Down Arrow Button Stuck Diagnostic Procedure.....9001-50-14
LCD Backlight Failure Diagnostic Procedure.....9001-50-6	524082.10 — Up Arrow Button Stuck.....9001-50-15
003597.02 — 5 Volt Power Supply Invalid.....9001-50-7	Up Arrow Button Stuck Diagnostic Procedure.....9001-50-15
5 Volt Power Supply Invalid Diagnostic Procedure.....9001-50-7	Group 60—Radar Object Detection (ROD) Diagnostic Trouble Codes
003598.02 — 1.5 Volt Power Supply Invalid.....9001-50-7	Radar Object Detection (ROD) Diagnostic Trouble Codes9001-60-1
1.5 Volt Power Supply Invalid Diagnostic Procedure.....9001-50-7	000896.12 — ROD Unit Failure.....9001-60-1
003599.02 — 3.3 Volt Power Supply Invalid.....9001-50-8	ROD Unit Failure Diagnostic Procedure.....9001-60-1
3.3 Volt Power Supply Invalid Diagnostic Procedure.....9001-50-8	Group 70—Ground Speed Radar (RDR) Diagnostic Trouble Codes
523436.14 — ADU Watchdog Time Out.....9001-50-8	Ground Speed Radar (RDR) Diagnostic Trouble Codes9001-70-1
ADU Watchdog Time Out Diagnostic Procedure.....9001-50-8	000628.12 — Controller Not Programmed.....9001-70-1
523438.31 — Memory Error.....9001-50-9	Controller Not Programmed Diagnostic Procedure.....9001-70-1
Memory Error Diagnostic Procedure.....9001-50-9	523456.18 — Degraded Mode.....9001-70-1
523651.02 — Memory Stack Overflow.....9001-50-9	Degraded Mode Diagnostic Procedure.....9001-70-1

Engine Control Unit (ECU) Diagnostic Trouble Codes

The diagnostic trouble code (DTC) number is indicated by a Suspect Parameter Number (SPN) and a Failure Mode Indicator (FMI) number. In the example **000091.03**, 91 is the SPN and 03 is the FMI number.

Diagnostic trouble codes can be displayed using the advanced display unit (ADU) or by using Service ADVISOR™.

- See Display Unit—Main Menu—Codes. (Operator's Manual.)
- See Reading Diagnostic Trouble Codes with Service ADVISOR™ Diagnostic Application. (Group 9015-15.)

For in-depth diagnostics on machine specific ECU diagnostic trouble codes, see specific code diagnostic procedures in this group. Additional engine control unit DTC diagnostic procedures for John Deere 6.8 L Final Tier 4 OEM Diesel Engines are located in the component

Service ADVISOR is a trademark of Deere & Company



Engine Component Technical Manuals

technical manual, See PowerTech™ 6068 OEM Diesel Engines (Final Tier 4/Stage IV platform). (CTM120019.)

M44215 —UN—07SEP88

JK05397,000125B -19-21MAY15-1/1

000091.03 — Engine Throttle Short to Power

Alarm Level:

Engine control unit (ECU) measures more than 4.75 volts on analog throttle position sensor (B14) circuit.

- Warning Lamp

JZ81662,0001509 -19-21APR16-1/5

Engine Throttle Short to Power Diagnostic Procedure

JZ81662,0001509 -19-21APR16-2/5

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically “go away”?

YES: DTC is intermittent. See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-15.)
NO: Go to Short Circuit Check.

Continued on next page

JZ81662,0001509 -19-21APR16-3/5

Engine Control Unit (ECU) Diagnostic Trouble Codes

2 Short Circuit Check

Ignition OFF.

Disconnect analog throttle position sensor (B14) connector. [See Load Center Harness \(W3\) Component Location](#). (Group 9015-10.)

Ignition ON.

Check circuit E012 WHT for voltage between pin A on analog throttle position sensor (B14) connector and machine ground.

Is voltage more than approximately 5 volts?

YES: Circuit E012 WHT is short to power in load center harness. Repair or replace harness. [See Load Center Harness \(W3\) Wiring Diagram](#) and [see Engine Harness \(W6\) Wiring Diagram](#). (Group 9015-10.)

NO: Go to Harness Check.

JZ81662,0001509 -19-21APR16-4/5

3 Harness Check

Turn battery disconnect switch OFF.

Disconnect analog throttle position sensor (B14) connector. [See Load Center Harness \(W3\) Component Location](#). (Group 9015-10.)

Disconnect engine control unit (ECU) connector (X5503). [See Engine Harness \(W6\) Component Location](#). (Group 9015-10.)

Check circuit E012 WHT for continuity between pin 10 on ECU connector (X5503) and remaining pins on ECU connector (X5503).

Is continuity indicated?

YES: Circuit E012 WHT is short to circuit with continuity indicated. Repair or replace harness. [See Load Center Harness \(W3\) Wiring Diagram](#) and [see Engine Harness \(W6\) Wiring Diagram](#). (Group 9015-10.)

NO: Program controller.

JZ81662,0001509 -19-21APR16-5/5

000091.04 — Engine Throttle Open or Short

Alarm Level:

Engine control unit (ECU) measures less than 0.25 volts on analog throttle position sensor (B14) circuit.

- Warning Lamp

JZ81662,000150A -19-21APR16-1/7

Engine Throttle Open or Short Diagnostic Procedure

JZ81662,000150A -19-21APR16-2/7

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically “go away”?

YES: DTC is intermittent. [See Intermittent Diagnostic Trouble Code \(DTC\) Diagnostics](#). (Group 9015-15.)

NO: Go to Component Check.

Continued on next page

JZ81662,000150A -19-21APR16-3/7

Engine Control Unit (ECU) Diagnostic Trouble Codes

2 Component Check

Ignition OFF.

Disconnect analog throttle position sensor (B14) connector. [See Load Center Harness \(W3\) Component Location.](#) (Group 9015-10.)

Measure resistance between pins A and B on analog throttle position sensor (B14). [See Load Center Harness \(W3\) Wiring Diagram.](#) (Group 9015-10.)

Measure resistance between pins A and C on analog throttle position sensor (B14).

Compare resistance to specification. [See Electrical Component Specifications.](#) (Group 9015-25.)

Is resistance within specification?

YES: Go to Open Circuit Check.

NO: Analog throttle position sensor (B14) malfunction. Replace sensor.

JZ81662,000150A -19-21APR16-4/7

3 Open Circuit Check

Ignition OFF.

Disconnect analog throttle position sensor (B14) connector. [See Load Center Harness \(W3\) Component Location.](#) (Group 9015-10.)

Disconnect engine control unit (ECU) connector (X5503). [See Engine Harness \(W6\) Component Location.](#) (Group 9015-10.)

Check circuit E012 WHT for continuity between pin A on analog throttle position sensor (B14) connector and pin 10 on ECU connector (X5503). [See Load Center Harness \(W3\) Wiring Diagram](#) and [see Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

Is continuity indicated?

YES: Go to Short Circuit Check.

NO: Circuit E012 WHT is open. Repair or replace harness. [See Load Center Harness \(W3\) Wiring Diagram](#) and [see Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

JZ81662,000150A -19-21APR16-5/7

4 Short Circuit Check

Ignition OFF.

Disconnect analog throttle position sensor (B14). [See Load Center Harness \(W3\) Component Location.](#) (Group 9015-10.)

Ignition ON.

Check circuit E012 WHT for continuity between pin A on analog throttle position sensor (B14) connector and machine ground. [See Load Center Harness \(W3\) Wiring Diagram.](#) (Group 9015-10.)

Is continuity present?

YES: Circuit E012 WHT is short to ground. Repair or replace harness. [See Load Center Harness \(W3\) Wiring Diagram](#) and [see Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

NO: Go to Harness Check.

Continued on next page

JZ81662,000150A -19-21APR16-6/7

5 Harness Check

Turn battery disconnect switch OFF.

Disconnect analog throttle position sensor (B14) connector. [See Load Center Harness \(W3\) Component Location.](#) (Group 9015-10.)

Disconnect engine control unit (ECU) connector (X5503). [See Engine Harness \(W6\) Component Location.](#) (Group 9015-10.)

Check circuit E012 WHT for continuity between pin 10 on ECU connector (X5503) and remaining pins on ECU connector (X5503). [See Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

Is continuity indicated?

YES: Circuit E012 WHT is short to circuit with continuity indicated. Repair or replace harness. [See Load Center Harness \(W3\) Wiring Diagram](#) and [see Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

NO: Program controller.

JZ81662,000150A -19-21APR16-7/7

000091.14 — Engine Throttle Sensor Invalid

Analog throttle position sensor (B14) circuit voltage is above or below the specification.

This code is an informative code that tells that the primary analog throttle is either above or below the out of range specification.

To get the engine to change speed, either:

- Set the throttle to the minimum position, then increase it.
- Cycle the ignition key to OFF, then back to ON.

This is a safety feature used to keep the engine from running away after a throttle problem.

JZ81662,000150B -19-21APR16-1/1

000111.01 — Engine Coolant Level Extremely Low

Engine Coolant Level Alarm Switch (B5009) is open. Coolant level is below the alarm switch level while

coolant temperature is greater than 95°C (203°F). Low coolant, open circuit.

Alarm Level:

- Stop Lamp

JZ81662,000150C -19-21APR16-1/6

Engine Coolant Level Extremely Low Diagnostic Procedure

JZ81662,000150C -19-21APR16-2/6

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically “go away”?

YES: DTC is intermittent. [See Intermittent Diagnostic Trouble Code \(DTC\) Diagnostics.](#) (Group 9015-15.)

NO: Go to Engine Coolant Level Check.

JZ81662,000150C -19-21APR16-3/6

2 Engine Coolant Level Check

Is coolant level low? [See Check Coolant Level at Surge Tank.](#) (Operator's Manual.)

YES: Add engine coolant. [See Diesel Engine Coolant \(engine with wet sleeve cylinder liners\).](#) (Operator's Manual.)

NO: Go to Component Check.

Continued on next page

JZ81662,000150C -19-21APR16-4/6

Engine Control Unit (ECU) Diagnostic Trouble Codes

3 Component Check

Disconnect engine coolant level alarm switch (B5009) connector. [See Diesel Exhaust Fluid \(DEF\) Dosing Unit Harness \(W46\) Component Location](#). (Group 9015-10.)

Check for continuity on pins 1 and 2 of engine coolant level alarm switch (B5009). [See Diesel Exhaust Fluid \(DEF\) Dosing Unit Harness \(W46\) Wiring Diagram](#). (Group 9015-10.)

Is continuity indicated?

YES: Replace engine coolant level alarm switch (B5009).

NO: Go to Open Circuit Check.

JZ81662,000150C -19-21APR16-5/6

4 Open Circuit Check

Ignition OFF.

Disconnect engine coolant level alarm switch (B5009) connector. [See Diesel Exhaust Fluid \(DEF\) Dosing Unit Harness \(W46\) Component Location](#). (Group 9015-10.)

Disconnect engine control unit (ECU) connector (X5502). [See Engine Harness \(W6\) Component Location](#). (Group 9015-10.)

Check circuit 5125 GRN for continuity between pin 1 on engine coolant level alarm switch (B5009) and pin 17 on ECU connector (X5502). [See Engine Harness \(W6\) Wiring Diagram](#) and [see Diesel Exhaust Fluid \(DEF\) Dosing Unit Harness \(W46\) Wiring Diagram](#). (Group 9015-10.)

Check circuit 5628 GRY for continuity between pin 2 on engine coolant level alarm switch (B5009) and pin 14 on ECU connector (X5502).

Is continuity indicated?

YES: Program controller.

NO: Repair circuit without continuity indicated or replace harness.

JZ81662,000150C -19-21APR16-6/6

000111.18 — Engine Coolant Very Low Level

Alarm Level:

Engine coolant level alarm switch (B5009) is below low engine coolant level.

- Warning Lamp

JZ81662,000150D -19-21APR16-1/6

Engine Coolant Very Low Level Diagnostic Procedure

JZ81662,000150D -19-21APR16-2/6

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically “go away”?

YES: DTC is intermittent. [See Intermittent Diagnostic Trouble Code \(DTC\) Diagnostics](#). (Group 9015-15.)

NO: Go to Engine Coolant Level Check.

JZ81662,000150D -19-21APR16-3/6

2 Engine Coolant Level Check

Is engine coolant level low? [See Check Coolant Level at Surge Tank](#). (Operator's Manual.)

YES: Add engine coolant. [See Diesel Engine Coolant \(engine with wet sleeve cylinder liners\)](#). (Operator's Manual.)

NO: Go to Component Check.

Continued on next page

JZ81662,000150D -19-21APR16-4/6

Engine Control Unit (ECU) Diagnostic Trouble Codes

3 Component Check

Disconnect engine coolant level information switch (B5009) connector. [See Diesel Exhaust Fluid \(DEF\) Dosing Unit Harness \(W46\) Component Location](#). (Group 9015-10.)

Check for continuity on pins 1 and 2 of engine coolant level information switch (B5009). [See Diesel Exhaust Fluid \(DEF\) Dosing Unit Harness \(W46\) Wiring Diagram](#). (Group 9015-10.)

Is continuity indicated?

YES: Go to Open Circuit Check.

NO: Replace surge tank.

JZ81662,000150D -19-21APR16-5/6

4 Open Circuit Check

Ignition OFF.

Disconnect engine coolant level alarm switch (B5009) connector. [See Diesel Exhaust Fluid \(DEF\) Dosing Unit Harness \(W46\) Component Location](#). (Group 9015-10.)

Disconnect engine control unit (ECU) connector (X5502). [See Engine Harness \(W6\) Component Location](#). (Group 9015-10.)

Check circuit 5125 GRN for continuity between pin 1 on engine coolant level information switch (B5009) connector and pin 17 on ECU connector (X5502). [See Engine Harness \(W6\) Wiring Diagram](#). (Group 9015-10.)

Is continuity indicated?

YES: Program controller.

NO: Repair circuit without continuity indicated or replace harness. [See Diesel Exhaust Fluid \(DEF\) Dosing Unit Harness \(W46\) Component Location and see Engine Harness \(W6\) Wiring Diagram](#). (Group 9015-10.)

JZ81662,000150D -19-21APR16-6/6

000168.01 — Engine Control Unit (ECU) Battery Voltage Low

Alarm Level:

- Warning Lamp

ECU detects unswitched battery power below 10 volts.

JZ81662,0001510 -19-21APR16-1/6

Engine Control Unit (ECU) Battery Voltage Low Diagnostic Procedure

JZ81662,0001510 -19-21APR16-2/6

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically “go away”?

YES: DTC is intermittent. [See Intermittent Diagnostic Trouble Code \(DTC\) Diagnostics](#). (Group 9015-15.)

NO: Go to Fuse Check.

JZ81662,0001510 -19-21APR16-3/6

2 Fuse Check

Ignition OFF.

Remove fuse (F3). [See Fuse and Relay Specifications](#). (Group 9015-10.)

Check fuse (F3) for continuity.

Is continuity indicated?

YES: Go to Circuit Check.

NO: Replace fuse.

Continued on next page

JZ81662,0001510 -19-21APR16-4/6

Engine Control Unit (ECU) Diagnostic Trouble Codes

3 Circuit Check

Turn battery disconnect switch OFF.

Disconnect engine control unit (ECU) connector (X5503). [See Engine Harness \(W6\) Component Location](#). (Group 9015-10.)

Check circuit 5122 RED for ground at pins 13 and 14 on ECU connector (X5503). [See Engine Harness \(W6\) Wiring Diagram](#). (Group 9015-10.)

Is ground present?

YES: Repair circuit(s) with ground present or replace harness. [See Engine Harness \(W6\) Wiring Diagram](#). (Group 9015-10.)

NO: Go to Harness Check.

JZ81662,0001510 -19-21APR16-5/6

4 Harness Check

Ignition OFF.

Disconnect engine control unit (ECU) connectors (X5501, X5502, and X5503). [See Engine Harness \(W6\) Component Location](#). (Group 9015-10.)

Check continuity between pins 13 and 14 (circuit 5122 RED) on connector (X5503) and all remaining pins on connectors (X5501, X5502, and X5503).

Is continuity indicated?

YES: Circuit 5122 RED is short to circuit with continuity indicated. Repair circuit or replace harness. [See Engine Harness \(W6\) Wiring Diagram](#). (Group 9015-10.)

NO: Program controller.

JZ81662,0001510 -19-21APR16-6/6

000237.31 — Invalid Vehicle Identification Number (VIN)

Alarm Level:

- Warning Lamp

VIN sent by vehicle control unit (VCU) does not match the VIN stored in engine control unit (ECU).

JZ81662,0001511 -19-21APR16-1/4

Invalid Vehicle Identification Number (VIN) Diagnostic Procedure

JZ81662,0001511 -19-21APR16-2/4

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically “go away”?

YES: DTC is intermittent. [See Intermittent Diagnostic Trouble Code \(DTC\) Diagnostics](#). (Group 9015-15.)

NO: Go to Program Controller.

JZ81662,0001511 -19-21APR16-3/4

2 Program Controller

Program vehicle control unit (VCU).

Check for active codes.

Is ECU code 000237.31 present?

YES: Replace VCU.

NO: Check complete.

JZ81662,0001511 -19-21APR16-4/4

001321.05 — Starter Relay Open Circuit

Start relay (K3) control circuit is open.

Alarm Level:

- Protect Lamp

JZ81662,0001512 -19-21APR16-1/5

Starter Relay Open Circuit Diagnostic Procedure

JZ81662,0001512 -19-21APR16-2/5

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically "go away"?

YES: DTC is intermittent.
See [Intermittent Diagnostic Trouble Code \(DTC\) Diagnostics](#). (Group 9015-15.)

NO: Go to Start Relay Check.

JZ81662,0001512 -19-21APR16-3/5

2 Start Relay Check

Ignition OFF.

Disconnect start relay (K3). See [Load Center Harness \(W3\) Component Location](#). (Group 9015-10.)

Apply 24 volts and ground to coil of ignition relay (K4).

Check for continuity between remaining pins on ignition relay (K4).

Is continuity indicated?

YES: Go to Open Circuit Check.

NO: Replace start relay (K3).

JZ81662,0001512 -19-21APR16-4/5

3 Open Circuit Check

Ignition OFF.

Disconnect circuits E002 WHT and R093 BLK from start relay (K3). See [Load Center Harness \(W3\) Component Location](#). (Group 9015-10.)

Disconnect engine control unit (ECU) connector (X5503). See [Engine Harness \(W6\) Component Location](#). (Group 9015-10.)

Check circuit E002 WHT at pin 30 on ECU connector (X5503) and start relay (K3) for continuity. See [Engine Harness \(W6\) Wiring Diagram](#) and [Load Center Harness \(W3\) Wiring Diagram](#). (Group 9015-10.)

Check circuit R093 BLK at pin 26 on ECU connector (X5503) and start relay (K3) for continuity.

Is continuity indicated?

YES: Program controller.

NO: Open wire in harness. Repair or replace harness. See [Load Center Harness \(W3\) Wiring Diagram](#) and [Engine Harness \(W6\) Wiring Diagram](#). (Group 9015-10.)

JZ81662,0001512 -19-21APR16-5/5

001321.06 — Starter Relay High Current

Start relay (K3) control circuit is reading high current.

Alarm Level:

- Protect Lamp

Continued on next page

JZ81662,0001513 -19-21APR16-1/6

Starter Relay High Current Diagnostic Procedure

JZ81662,0001513 -19-21APR16-2/6

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically "go away"?

YES: DTC is intermittent.
See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-15.)

NO: Go to Start Relay Check.

JZ81662,0001513 -19-21APR16-3/6

2 Start Relay Check

Ignition OFF.

Disconnect start relay (K3). See Load Center Harness (W3) Component Location. (Group 9015-10.)

Apply 24 volts and ground to coil of ignition relay (K4).

Check for continuity between remaining pins on ignition relay (K4).

Is continuity indicated?

YES: Go to Short Circuit Check.

NO: Replace start relay (K3).

JZ81662,0001513 -19-21APR16-4/6

3 Short Circuit Check

Ignition OFF.

Disconnect circuits E002 WHT and R093 BLK from start relay (K3). See Load Center Harness (W3) Component Location. (Group 9015-10.)Disconnect engine control unit (ECU) connector (X5503). See Engine Harness (W6) Component Location. (Group 9015-10.)Check circuits E002 WHT and R093 BLK for ground on pins 26 and 30 of ECU connector (X5503). See Engine Harness (W6) Wiring Diagram. (Group 9015-10.)

Is ground present?

YES: Circuit is grounded.
Repair or replace harness.
See Load Center Harness (W3) Wiring Diagram and see Engine Harness (W6) Wiring Diagram. (Group 9015-10.)

NO: Go to Harness Check.

Continued on next page

JZ81662,0001513 -19-21APR16-5/6

4 Harness Check

Ignition OFF.

Disconnect circuits E002 WHT and R093 BLK from start relay (K3). [See Load Center Harness \(W3\) Component Location.](#) (Group 9015-10.)

Disconnect engine control unit (ECU) connectors (X5501, X5502, and X5503). [See Engine Harness \(W6\) Component Location.](#) (Group 9015-10.)

Check for continuity between pin 26 (circuit R093 BLK) and all other pins on ECU connectors (X5501, X5502, and X5503).

Check for continuity between pin 30 (circuit E002 WHT) and all other pins on ECU connectors (X5501, X5502, and X5503).

Is continuity indicated?

YES: Repair circuit with continuity or replace harness. [See Load Center Harness \(W3\) Wiring Diagram](#) and [see Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

NO: Program controller.

JZ81662,0001513 -19-21APR16-6/6

001321.09 — Starter Signal Invalid

Alarm Level:

Start relay (K3) circuit is receiving an invalid start signal from engine control unit (ECU).

- Warning Lamp

JZ81662,0001514 -19-21APR16-1/6

Starter Signal Invalid Diagnostic Procedure

JZ81662,0001514 -19-21APR16-2/6

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically “go away”?

YES: DTC is intermittent. [See Intermittent Diagnostic Trouble Code \(DTC\) Diagnostics.](#) (Group 9015-15.)

NO: Go to Start Relay Check.

JZ81662,0001514 -19-21APR16-3/6

2 Start Relay Check

Ignition OFF.

Disconnect start relay (K3). [See Load Center Harness \(W3\) Component Location.](#) (Group 9015-10.)

Apply 24 volts and ground to coil of ignition relay (K4).

Check for continuity between remaining pins on ignition relay (K4).

Is continuity indicated?

YES: Go to Short Circuit Check.

NO: Replace start relay (K3).

Continued on next page

JZ81662,0001514 -19-21APR16-4/6

Engine Control Unit (ECU) Diagnostic Trouble Codes

3 Short Circuit Check

Ignition OFF.

Disconnect circuits E002 WHT and R093 BLK from start relay (K3). [See Load Center Harness \(W3\) Component Location.](#) (Group 9015-10.)

Disconnect engine control unit (ECU) connector (X5503). [See Engine Harness \(W6\) Component Location.](#) (Group 9015-10.)

Check circuits E002 WHT at pin 30 and R093 BLK at pin 26 for ground on ECU connector (X5503). [See Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

Is ground present?

YES: Circuit is grounded.
Repair or replace harness.
[See Load Center Harness \(W3\) Wiring Diagram](#) and [see Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

NO: Go to Harness Check.

JZ81662,0001514 -19-21APR16-5/6

4 Harness Check

Ignition OFF.

Disconnect circuits E002 WHT and R093 BLK from start relay (K3). [See Load Center Harness \(W3\) Component Location.](#) (Group 9015-10.)

Disconnect engine control unit (ECU) connectors (X5501, X5502, and X5503). [See Engine Harness \(W6\) Component Location.](#) (Group 9015-10.)

Check for continuity between pin 26 (circuit R093 BLK) and all other pins on ECU connectors (X5501, X5502, and X5503). [See Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

Check for continuity between pin 30 (circuit E002 WHT) and all other pins on ECU connectors (X5501, X5502, and X5503).

Is continuity indicated?

YES: Repair or replace harness on circuit with continuity. [See Load Center Harness \(W3\) Wiring Diagram](#) and [see Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

NO: Program controller.

JZ81662,0001514 -19-21APR16-6/6

001321.16 — Too Long to Start

Alarm Level:

*Starter motor (M1) was engaged for 30 or more seconds.
Starter motor must be disengaged for 60 seconds to
reset engine control unit (ECU) timer.*

- Warning Lamp

JZ81662,0001515 -19-21APR16-1/4

Too Long to Start Diagnostic Procedure

JZ81662,0001515 -19-21APR16-2/4

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically “go away”?

YES: DTC is intermittent.
[See Intermittent Diagnostic Trouble Code \(DTC\) Diagnostics.](#) (Group 9015-15.)

NO: Go to Starter Motor Check.

Continued on next page

JZ81662,0001515 -19-21APR16-3/4

2 Starter Motor Check

Has starter motor been operated for 30 or more seconds?

YES: Do not attempt to start for 60 seconds. Starter motor must be disengaged for 60 seconds to reset engine control unit (ECU) timer.

NO: Program controller.

JZ81662,0001515 -19-21APR16-4/4

001321.31 — Starter Solenoid Open Circuit

Alarm Level:

Starter is commanded to start with no engine speed detected.

- Warning Lamp

JZ81662,0001516 -19-21APR16-1/4

Starter Solenoid Open Circuit Diagnostic Procedure

JZ81662,0001516 -19-21APR16-2/4

1 Intermittent Check

Does diagnostic trouble code (DTC) periodically “go away”?

YES: DTC is intermittent. [See Intermittent Diagnostic Trouble Code \(DTC\) Diagnostics.](#) (Group 9015-15.)

NO: Go to Start Relay Check.

JZ81662,0001516 -19-21APR16-3/4

2 Open Circuit Check

Ignition OFF.

Disconnect circuits E002 WHT and R093 BLK from start relay (K3). [See Load Center Harness \(W3\) Component Location.](#) (Group 9015-10.)

Disconnect engine control unit (ECU) connector (X5503). [See Engine Harness \(W6\) Component Location.](#) (Group 9015-10.)

Check circuit E002 WHT at pin 30 on ECU connector (X5503) and start relay (K3) for continuity. [See Engine Harness \(W6\) Wiring Diagram](#) and [see Load Center Harness \(W3\) Wiring Diagram.](#) (Group 9015-10.)

Check circuit R093 BLK at pin 26 on ECU connector (X5503) and start relay (K3) for continuity.

Is continuity indicated?

YES: Program controller.

NO: Open wire in harness. Repair or replace harness. [See Load Center Harness \(W3\) Wiring Diagram](#) and [see Engine Harness \(W6\) Wiring Diagram.](#) (Group 9015-10.)

JZ81662,0001516 -19-21APR16-4/4

001761.01 — Diesel Exhaust Fluid is Extremely Low

Diesel exhaust fluid (DEF) tank fluid level sensor is indicating the DEF tank is empty.

Alarm Level:

- Amber Warning Light

Machine Response:

- Engine power and speed derated.

Circuit Information:

- See Exhaust Aftertreatment Circuit Theory of Operation. (Group 9015-05.)
- See Controller Area Network (CAN) Circuit Theory of Operation. (Group 9015-05.)
- See CAN Circuit Test. (Group 9015-25.)

Component Location:

- See Engine Frame Harness (W5) Component Location. (Group 9015-10.)

Diagnostic Test Box Information:

- Not Applicable

Additional References:

- Intermittent DTCs: See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-15.)
- See Refilling Diesel Exhaust Fluid (DEF) Tank. (Operator's Manual.)

Possible Causes:

1. DEF tank is empty.
2. Problem with DEF header assembly.

PM10405,0001062 -19-25APR16-1/1

001761.18 — Diesel Exhaust Fluid is Very Low

Diesel exhaust fluid (DEF) tank fluid level sensor is indicating the DEF tank is almost empty.

Alarm Level:

- Amber Warning Light

Machine Response:

- Engine power derated.

Circuit Information:

- See Exhaust Aftertreatment Circuit Theory of Operation. (Group 9015-05.)
- See Controller Area Network (CAN) Circuit Theory of Operation. (Group 9015-05.)
- See CAN Circuit Test. (Group 9015-25.)

Component Location:

- See Engine Frame Harness (W5) Component Location. (Group 9015-10.)

Diagnostic Test Box Information:

- Not Applicable

Additional References:

- Intermittent DTCs: See Intermittent Diagnostic Trouble Code (DTC) Diagnostics. (Group 9015-15.)
- See Refilling Diesel Exhaust Fluid (DEF) Tank. (Operator's Manual.)

Possible Causes:

1. DEF tank fluid level is very low.
2. Problem with DEF header assembly.

PM10405,0001063 -19-25APR16-1/1

002003.09 — Controller Area Network (CAN) Communication Lost for Transmission Control Unit (TCU)

CAN communication error; engine control unit (ECU) has lost communication with TCU.

Alarm Level:

- Warning Lamp

JZ81662,0001517 -19-21APR16-1/10

Controller Area Network (CAN) Communication Lost for Transmission Control Unit (TCU) Diagnostic Procedure

Continued on next page

JZ81662,0001517 -19-21APR16-2/10

Engine Control Unit (ECU) Diagnostic Trouble Codes

1 Intermittent Check	Does DTC periodically “go away”?	YES: DTC is intermittent. See Intermittent Diagnostic Trouble Code (DTC) Diagnostics . (Group 9015-15.) NO: Go to Controller Sensors Check. JZ81662,0001517 -19-21APR16-3/10
2 Controller Sensors Check	View TCU monitored sensor outputs by accessing the DIAGNOSTICS/TRANSMISSION SENSORS submenu on the advanced display unit (ADU). See Display Unit—Main Menu—Diagnostics—Transmission/Axle . (Operator's Manual.) Are all transmission sensor values displayed on the ADU?	YES: Go to CAN Circuit Check. NO: Go to Fuse Check. JZ81662,0001517 -19-21APR16-4/10
3 Fuse Check	Ignition OFF. Remove fuses (F18) and (F28). See Fuse and Relay Specifications . (Group 9015-10.) Check fuses (F18) and (F28) for continuity. Is continuity indicated in both fuses?	YES: Go to Voltage Check. NO: Replace fuse(s) without continuity indicated. JZ81662,0001517 -19-21APR16-5/10
4 Voltage Check	Ignition OFF. Disconnect transmission control unit (TCU) connector (X23). See Load Center Harness (W3) Component Location . (Group 9015-10.) Ignition ON. Check for voltage at the following pins on TCU connector (X23): See Load Center Harness (W3) Wiring Diagram . (Group 9015-10.) <ul style="list-style-type: none">• 23 (circuit P018) RED• 45 (circuit P028) RED• 68 (circuit P018) RED Is voltage present at all pins?	YES: Go to Ground Circuit Check. NO: Circuit(s) without voltage is open. Repair circuit or replace harness. See Load Center Harness (W3) Wiring Diagram . (Group 9015-10.) Continued on next page JZ81662,0001517 -19-21APR16-6/10

This as a preview PDF file from **best-manuals.com**



Download full PDF manual at **best-manuals.com**