



Backhoe Loader

9803/3280	3CX, 4CX	930001 to 960000
	214e, 214, 215, 217	903000 Onwards



Publication No.
S2-eng



Copyright © 2004 JCB SERVICE. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any other means, electronic, mechanical, photocopying or otherwise, without prior permission from JCB SERVICE.

Issued by JCB Technical Publications, JCB Service, World Parts Centre, Beamhurst, Uttoxeter, Staffordshire, ST14 5PA, England. Tel +44 1889 590312 Fax +44 1889 593377

World Class
Customer Support



Service Manual

**3CX, 4CX,
214e, 214, 215, 217
& VARIANTS**

Backhoe Loader

**From M/c No. 930000 Onwards
From M/c No. 903000 Onwards (USA)**

PUBLISHED BY THE
TECHNICAL PUBLICATIONS DEPARTMENT
OF JCB SERVICE; © WORLD PARTS CENTRE,
WATERLOO PARK, UTTOXETER, ST14 5PA
ENGLAND

Tel. ROCESTER (01889) 590312
PRINTED IN ENGLAND

Publication No. 9803/3280 Issue 9

General Information	1
Care & Safety	2
Routine Maintenance	3
Attachments	A
Body & Framework	B
Electrics	C
Controls	D
Hydraulics	E
Transmission	F
Brakes	G
Steering	H
Engine	K
Servo Controls (Precision Controls)	L

Introduction

This publication is designed for the benefit of JCB Distributor Service Engineers who are receiving, or have received, training by JCB Technical Training Department.

These personnel should have a sound knowledge of workshop practice, safety procedures, and general techniques associated with the maintenance and repair of hydraulic earthmoving equipment.

Renewal of oil seals, gaskets, etc., and any component showing obvious signs of wear or damage is expected as a matter of course. It is expected that components will be cleaned and lubricated where appropriate, and that any opened hose or pipe connections will be blanked to prevent excessive loss of hydraulic fluid and ingress of dirt. Finally, please remember above all else **SAFETY MUST COME FIRST!**

The manual is compiled in sections, the first three are numbered and contain information as follows:

1	=	General Information - includes torque settings and service tools.
2	=	Care & Safety - includes warnings and cautions pertinent to aspects of workshop procedures etc.
3	=	Routine Maintenance - includes service schedules and recommended lubricants for all the machine.

The remaining sections are alphabetically coded and deal with Dismantling, Overhaul etc. of specific components, for example:

A	=	Attachments
B	=	Body & Framework ...etc.

The page numbering in each alphabetically coded section is not continuous. This allows for the insertion of new items in later issues of the manual.

Section contents, technical data, circuit descriptions, operation descriptions etc are inserted at the beginning of each alphabetically coded section.

All sections are listed on the front cover; tabbed divider cards align directly with individual sections on the front cover for rapid reference.

Where a torque setting is given as a single figure it may be varied by plus or minus 3%. Torque figures indicated are for dry threads, hence for lubricated threads may be reduced by one third.

With the exception of slewing operations 'Left Hand' and 'Right Hand' are as viewed from the rear of the machine facing forwards.

Machine Nomenclature

In this Service Manual, reference is made to machine models, e.g. 3CX, 4CX, these are European machine model names. North American machine models have different names, the table below shows the European and the equivalent North American nomenclature.

European		North American
3CX	=	214
4CX	=	214S, 215S, 217S

Colour Coding

The following colour coding, used on illustrations to denote various conditions of oil pressure and flow, is standardised throughout JCB Service publications.

-  **Red** — **Full Pressure**
Pressure generated from operation of a service. Depending on application this may be anything between neutral circuit pressure and M.R.V. operating pressure.
-  **Pink** — **Pressure**
Pressure that is above neutral circuit pressure but lower than that denoted by red.
-  **Orange** — **Servo**
Oil pressure used in controlling a device (servo).
-  **Blue** — **Neutral**
Neutral circuit pressure.
-  **Green** — **Exhaust**
-  **Light Green** — **Cavitation**
Oil subjected to a partial vacuum due to a drop in pressure (cavitation).
-  **Yellow** — **Lock Up**
Oil trapped within a chamber or line, preventing movement of components (lock up).

A390940


Contents	Page No.
Machine Identification Plate	1 - 1
Typical Vehicle Identification Number (VIN)	1 - 1
Typical Engine Identification Number	1 - 1
Serial Plates	1 - 2
Torque Settings	2 - 1
Service Tools Numerical List	3 - 1
Service Tools	
- Body & Framework	4 - 1
- Electrics	4 - 4
- Hydraulics	4 - 6
- Transmission	4 - 10
- Engine	4 - 19*
Sealing and Retaining Compounds	5 - 1

Machine Identification Plate


Your machine has an identification plate mounted on the loader tower. The serial numbers of the machine and its major units are stamped on the plate.

The serial number of each major unit is also stamped on the unit itself. If a major unit is replaced by a new one, the serial number on the identification plate will be wrong. Either stamp the new number of the unit on the identification plate, or simply stamp out the old number. This will prevent the wrong unit number being quoted when replacement parts are ordered.

The machine and engine serial numbers can help identify exactly the type of equipment you have.



U.K. and R.O.W.



North America

A246740

Typical Vehicle Identification Number (VIN)

SLP 3CX T S V E 930000
A B C D E F G

- A** World Manufacturer Identification
- B** Machine Model
- C** Steer Type (T= 2WS, F=4WS)
- D** Build Type (S=Sideshift, C=Centremount, L=Loader)
- E** Year of Manufacture:
 2 = 2002
 3 = 2003
 4 = 2004
 5 = 2005
 6 = 2006
 7 = 2007
 8 = 2008
- F** Manufacturer Location (E = England)
- G** Product Identification Number (PIN)








Typical Engine Identification Number

AB 50262 U 500405 P
A B C D E

- A** Engine Type
 AB = 4 cylinder turbo
- B** Build Number
- C** Country of Origin
- D** Engine Sequence Number
- E** Year of Manufacture

Serial Plates

- A** Front Axle (2WS machine)
- B** Front Axle (4WS machine)
- C** Rear Axle (2WS machine)
- D** Rear Axle (4WS machine)
- E** Synchro Shuttle Transmission
- F** Powershift Transmission
- G** Engine



Torque Settings

Use only where no torque setting is specified in the text. Values are for dry threads and may be within three per cent of the figures stated. For lubricated threads the values should be REDUCED by one third.

UNF Grade 'S' Bolts

Bolt Size in	(mm)	Hexagon (A/F) in	Torque Settings		
			Nm	kgf m	lbf ft
1/4	(6.3)	7/16	14	1.4	10
5/16	(7.9)	1/2	28	2.8	20
3/8	(9.5)	9/16	49	5.0	36
7/16	(11.1)	5/8	78	8.0	58
1/2	(12.7)	3/4	117	12.0	87
9/16	(14.3)	13/16	170	17.3	125
5/8	(15.9)	15/16	238	24.3	175
3/4	(19.0)	11/8	407	41.5	300
7/8	(22.2)	15/16	650	66.3	480
1	(25.4)	11/2	970	99.0	715
1 1/4	(31.7)	1 7/8	1940	198.0	1430
1 1/2	(38.1)	2 1/4	3390	345.0	2500

Metric Grade 8.8 Bolts

Bolt Size	(mm)	Hexagon (A/F) mm	Torque Settings		
			Nm	kgf m	lbf ft
M5	(5)	8	7	0.7	5
M6	(6)	10	12	1.2	9
M8	(8)	13	28	3.0	21
M10	(10)	17	56	5.7	42
M12	(12)	19	98	10	72
M16	(16)	24	244	25	180
M20	(20)	30	476	48	352
M24	(24)	36	822	84	607
M30	(30)	46	1633	166	1205
M36	(36)	55	2854	291	2105

Rivet Nut Bolts/Screws

Bolt Size	(mm)	Torque Settings (for steel rivet nuts)		
		Nm	kgf m	lbf ft
M3	(3)	1.2	0.12	0.9
M4	(4)	3.0	0.3	2.0
M5	(5)	6.0	0.6	4.5
M6	(6)	10.0	1.0	7.5
M8	(8)	24.0	2.5	18.0
M10	(10)	48.0	4.9	35.5
M12	(12)	82.0	8.4	60.5

Note: All bolts used on JCB machines are high tensile and must not be replaced by bolts of a lesser tensile specification.

Service Tools Numerical List

		Page No.			Page No.
460/15708	Flow Test Adapter	4 - 13	816/55040	Pressure Test 'T' Adapter	4 - 6
460/15707	Banjo Bolt	4 - 13	816/60096	Adapter	4 - 8
1406/0011	Bonded Washer	4 - 7	823/10420	Shim Kit - Powershift gearbox, layshaft clutch	4 - 17
1406/0014	Bonded Washer	4 - 7	825/00410	Crowfoot Wrench	4 - 4
1406/0018	Bonded Washer	4 - 7, 13	825/99833	Adapter for 825/00410	4 - 4
1406/0021	Bonded Washer	4 - 6, 4 - 7	826/01099	Rivet Nut	4 - 1
1406/0029	Bonded Washer	4 - 7	826/01101	Rivet Nut	4 - 1
1604/0003	Male Adapter	4 - 7	826/01102	Rivet Nut	4 - 1
1604/0004	Male Adapter	4 - 7, 13	826/01103	Rivet Nut	4 - 1
1604/0006	Male Adapter	4 - 6, 4 - 7	826/01104	Rivet Nut	4 - 1
1604/0008	Adapter	4 - 6	826/01105	Rivet Nut	4 - 1
1606/0003	Male Adapter	4 - 7	892/00011	Spool Clamp	4 - 8
1606/0004	Male Adapter	4 - 7	892/00041	De-glazing Tool	4 - 21
1606/0007	Male Adapter	4 - 7	892/00047	Adapter	4 - 8
1606/0008	Male Adapter	4 - 7	892/00048	Adapter	4 - 8
1606/0009	Male Adapter	4 - 7	892/00049	Adapter	4 - 8
1606/0012	Male Adapter	4 - 6, 4 - 7	892/00051	Adapter	4 - 8
1606/0014	Male Adapter	4 - 7	892/00055	Blanking Plug	4 - 8
1606/0015	Male Adapter	4 - 6, 4 - 7	892/00056	Blanking Plug	4 - 8
1606/0017	Male Adapter	4 - 7	892/00057	Blanking Plug	4 - 8
1612/0006	Adapter	4 - 6	892/00058	Blanking Plug	4 - 8
2401/0222	O-ring	4 - 13	892/00059	Blanking Plug	4 - 8
2403/0110	O-ring	4 - 13	892/00060	Blanking Plug	4 - 8
2403/0108	O-ring	4 - 13	892/00071	Male Adapter	4 - 7
4101/0651	Retainer (High Strength)	5 - 1	892/00074	Female Connector	4 - 8
4101/0250	Threadlocker and Sealer (10 ml)	5 - 1	892/00075	Female Connector	4 - 8
4101/0251	Threadlocker and Sealer (50 ml)	5 - 1	892/00076	Female Connector	4 - 8
4101/0451	Threadlocker	5 - 1	892/00077	Female Connector	4 - 8
4102/0502	High Strength Gasketing	5 - 1	892/00078	Connector	4 - 6
4102/0551	High Strength Threadlocker	5 - 1	* 892/01054	Adaptor for Compression Testing	4 - 21
4102/0933	Clear Silicone Sealant	5 - 1	892/00137	Micro-Bore Hose 1/4in. BSP, 3 Metres	4 - 7
4102/1212	Multi-Gasket	5 - 1	892/00167	Ram Seal Protection Sleeve 90 mm	4 - 9
4102/1951	Threadseal	5 - 1	892/00174	Measuring Cup	4 - 11
4102/2309	Black Polyurethane Sealant	5 - 1	892/00179	Bearing Press	4 - 10
4103/2109	Ultra Fast Adhesive (310ml)	5 - 1	892/00180	Seal Fitting Tool	4 - 20
4104/0251	Activator (Aersol)	5 - 1	892/00181	Replacement Plastic Boss	4 - 20
4104/0253	Activator (Bottle)	5 - 1	892/00182	Bearing Pad Driver	4 - 12
4104/1203	Active Wipe 205 (250g)	5 - 1	892/00223	Hand Pump	4 - 7
4104/1206	Active Wipe 205 (30 ml)	5 - 1	892/00224	Impulse Extractor	4 - 11
4104/1310	Hand Cleaner	4 - 1	892/00225	Adapter for Extractor	4 - 11
4104/1538	JCB Cleaner & Degreaser	5 - 1	892/00252	Test Block for Loader Valve A.R.V (214e Machines Only)	4 - 9
4104/1557	Cleaner/Degreaser (400 ml)	5 - 1	892/00253	Pressure Test Kit	4 - 6
4201/4906	Black Primer 206J (30ml)	5 - 1	892/00255	Pressure Test Adapter	4 - 6
* 721/10885	Interconnecting cable (G/box ECU to Data Link Adaptor)	4 - 18	892/00256	Pressure Test Adapter	4 - 6
816/00017	Adapter	4 - 8	892/00257	Pressure Test Adapter	4 - 6
816/00189	Blanking Cap	4 - 8	892/00258	Pressure Test Adapter	4 - 6
816/00190	Blanking Cap	4 - 8	892/00259	Pressure Test Adapter	4 - 6
816/00193	Blanking Cap	4 - 8	892/00260	Pressure Test Adapter	4 - 6
816/00196	Blanking Cap	4 - 8	892/00261	Pressure Test Adapter	4 - 6
816/00197	Blanking Cap	4 - 8	892/00262	Pressure Test 'T' Adapter	4 - 6, 4 - 7
816/00294	Blanking Cap	4 - 8	892/00263	Pressure Test 'T' Adapter	4 - 6
816/00439	Male Adapter	4 - 7	892/00264	Pressure Test 'T' Adapter	4 - 6
816/00440	Male Adapter	4 - 7	892/00265	Pressure Test 'T' Adapter	4 - 6
816/15007	Male Adapter	4 - 7	892/00268	Flow Monitoring Unit	4 - 6
816/15008	Male Adapter	4 - 7	892/00269	Sensor Head	4 - 6
816/15118	Pressure Test Adapter	4 - 6	892/00270	Load Valve	4 - 6
816/20008	Adapter	4 - 6	892/00271	Adapter	4 - 6
816/20013	Adapter	4 - 6	892/00272	Adapter	4 - 6
816/50005	Adapter	4 - 8	892/00273	Sensor Head	4 - 6
816/50043	Adapter	4 - 8	892/00274	Adapter	4 - 7
816/55038	Pressure Test 'T' Adapter	4 - 6			

Service Tools Numerical List

	Page No.		Page No.		
* 892/00275	Adapter	4 - 6	892/01079	Ring Socket Spanner	
* 892/00276	Adapter	4 - 6		Mainshaft setting ring	4 - 13
892/00277	Adapter	4 - 6	892/01080	Ring Socket Spanner	
892/00278	Gauge	4 - 7		Layshaft setting ring	4 - 13
892/00279	Gauge	4 - 7	892/01077	Synchro Shuttle Gearbox Selector	
892/00282	Shunt	4 - 4		Shaft Lock Screw	4 - 13
892/00283	Tool Kit Case	4 - 4	892/01078	Synchro Shuttle Gearbox	
892/00284	Tachometer	4 - 4		Mainshaft Adjuster	4 - 13
892/00285	Hydraulic Oil Temperature Probe	4 - 4	892/01076	Synchro Shuttle Support Plate	
892/00286	Surface Temperature Probe	4 - 4		Transfer gear end float setting	4 - 13
892/00293	Connector Pipe	4 - 6	892/01082	Powershift - Assembly Cradle	4 - 17
892/00294	Connector Pipe	4 - 6	892/01083	Powershift - Assembly tool,	
892/00298	Fluke Meter	4 - 4		transfer gear	4 - 17
892/00301	Flow Test Adapter	4 - 10	892/01084	Powershift - Transfer gear, bearing	
892/00302	Flow Test Adapter	4 - 10		assembly	4 - 17
892/00309	ARV Test Kit	4 - 7	892/01085	Powershift - Seal fitting tool	4 - 17
892/00333	Heavy Duty Socket	4 - 11	892/01092	Wheel Hub Service Kit	4 - 19
892/00334	Ram Seal Fitting Tool	4 - 9	892/01096	Speed Sensor Test Harness	4 - 17
892/00335	ARV Cartridge Removal Tool	4 - 7	892/01110	Torque Converter Alignment Tool	4 - 18
892/00347	Connector - Hose to gauge	4 - 6	926/15500	Rubber Spacer Blocks	4 - 3
892/00706	Test Probe	4 - 6, 4 - 7	992/04000	Torque Multiplier	4 - 12
892/00812	Drive Coupling Spanner	4 - 10	992/04800	Flange Spanner	4 - 12
892/00817	Heavy Duty Socket	4 - 11	992/07608	Bearing Adapter	4 - 10
892/00818	Heavy Duty Socket	4 - 11	992/07609	Bearing Adapter	4 - 10
892/00819	Heavy Duty Socket	4 - 11	992/07610	Bearing Adapter	4 - 10
892/00822	Splined Bolt Socket	4 - 11	992/07611	Bearing Adapter	4 - 10
892/00836	Lifting Wire Assembly	4 - 21	992/07612	Bearing Adapter	4 - 10
892/00842	Glass Lifter	4 - 2	992/07613	Bearing Adapter	4 - 10
892/00843	Folding Stand	4 - 1	992/09100	Spool Clamp	4 - 8
892/00844	Long Knife	4 - 3	992/09200	Charging Tool	4 - 1
892/00845	Cartridge Gun	4 - 1	992/09300	Ram Spanner	4 - 8
892/00846	Glass Extractor (Handles)	4 - 2	992/09400	Ram Spanner	4 - 8
892/00847	Nylon Spatula	4 - 3	992/09500	Ram Spanner	4 - 8
892/00848	Wire Starter	4 - 2	992/09600	Ram Spanner	4 - 8
892/00849	Braided Cutting Wire	4 - 3	992/09700	Ram Spanner	4 - 8
892/00881	Spool Seal Fitting Tool	4 - 7	992/09900	Ram Spanner	4 - 8
892/00882	Alternator Pulley Socket	4 - 5	992/10000	Ram Spanner	4 - 8
892/00891	Wheel Hub Seal - Fitting Tool	4 - 19	992/12300	12V Mobile Oven	4 - 1
892/00918	Setting Tool Kit	4 - 16	992/12400	Static Oven - 2 Cartridge	4 - 2
892/00920	Flow Test Adapter	4 - 10	992/12600	Static Oven - 6 Cartridge	4 - 2
892/00948	Charging Kit	4 - 9	992/12800	Cut-Out Knife	4 - 2
892/00949	Pressure Gauge	4 - 9	992/12801	"L" Blades	4 - 2
892/00956	Timing Pin	4 - 21	993/55700	Direct Glazing Kit	5 - 1
892/00964	Test Point (1/8BSP)	4 - 12	993/59500	Impulse Extractor Adapter	4 - 11
892/00965	Test Point (3/8BSP)	4 - 12	993/68100	Slide Hammer Kit	4 - 3
892/00966	Test Point (1/4BSP)	4 - 12	993/69800	Seal Kit	4 - 6
892/01016	Ram Seal Protection Sleeve 25 mm	4 - 9	993/70111	Breakback Torque Wrench	4 - 15
892/01017	Ram Seal Protection Sleeve 30 mm	4 - 9	993/85700	Battery Tester	4 - 4
892/01018	Ram Seal Protection Sleeve 40 mm	4 - 9	998/10650	Powershift Torque Converter	
892/01019	Ram Seal Protection Sleeve 50 mm	4 - 9		- Pressure Test Kit	4 - 12
892/01020	Ram Seal Protection Sleeve 50 mm (slew ram)	4 - 9	998/10738	Powershift Clutch - Adapter Spanner	4 - 13
892/01021	Ram Seal Protection Sleeve 60 mm	4 - 9	7210/0001	Dummy Plug	4 - 5
892/01022	Ram Seal Protection Sleeve 60 mm (slew ram)	4 - 9	7210/0002	Wire Seal (1.4 - 2.2 mm dia.)	4 - 5
892/01023	Ram Seal Protection Sleeve 65 mm	4 - 9	7210/0003	Wire Seal (2.2 - 2.9 mm dia.)	4 - 5
892/01024	Ram Seal Protection Sleeve 70 mm	4 - 9	7212/0001	2 Way Socket Connector	4 - 5
892/01025	Ram Seal Protection Sleeve 75 mm	4 - 9	7212/0002	2 Way Pin Housing	4 - 5
892/01026	Ram Seal Protection Sleeve 80 mm	4 - 9	7212/0003	2 Way Socket Retainer	4 - 5
892/01027	Piston Seal Assembly Tool	4 - 9	7212/0004	2 Way Pin Retainer	4 - 5
892/01033	Electronic Service Tool Kit	4 - 18	7213/0001	3 Way Socket Connector	4 - 5
			7213/0002	3 Way Pin Housing	4 - 5
			7213/0003	3 Way Socket Retainer	4 - 5
			7213/0004	3 Way Pin Retainer	4 - 5

Service Tools Numerical List


		Page No.			
* 7213/0005	3 Way Socket Connector (DT)	4 - 5	The following parts are replacement items for kits and would normally be included in the kit numbers quoted on pages 1/3-1 and 1/3-2.		
* 7213/0006	3 Way Pin Housing (DT)	4 - 5			
7213/0007	3 Way Socket Retainer (DT)	4 - 5			
7213/0008	3 Way Pin Retainer (DT)	4 - 5			
7214/0001	4 Way Socket Connector	4 - 5			
7214/0002	4 Way Pin Housing	4 - 5			
7214/0003	4 Way Socket Retainer	4 - 5			
7214/0004	4 Way Pin Retainer	4 - 5			
7216/0001	6 Way Socket Connector	4 - 5			
7216/0002	6 Way Pin Housing	4 - 5			
7216/0003	6 Way Socket Retainer	4 - 5			
7216/0004	6 Way Pin Retainer	4 - 5			
7218/0001	8 Way Socket Connector	4 - 5			
7218/0002	8 Way Pin Housing	4 - 5			
7218/0003	8 Way Socket Retainer	4 - 5			
7218/0004	8 Way Pin Retainer	4 - 5			
7219/0001	10 Way Socket Connector	4 - 5			
7219/0002	10 Way Pin Housing	4 - 5			
7219/0003	10 Way Socket Retainer	4 - 5			
7219/0004	10 Way Pin Retainer	4 - 5			
7219/0005	14 Way Socket Connector	4 - 5			
7219/0006	14 Way Pin Housing	4 - 5			
7219/0007	14 Way Socket Retainer	4 - 5			
7219/0008	14 Way Pin Retainer	4 - 5			
			Service Tools Numerical List		Page No.
			Replacement item for kit no. 892/00180		
			892/00181		4 - 9
			Replacement items for kit no. 892/00253		
			892/00201	Replacement Gauge	4 - 6
			892/00202	Replacement Gauge	4 - 6
			892/00203	Replacement Gauge	4 - 6
			892/00254	Replacement Hose	4 - 6
			Replacement items for kit no. 892/00309		
			892/00340	Test Block Body	4 - 7
			892/00341	Setting Body	4 - 7
			892/00343	Spanner	4 - 7
			892/00345	Anti-Cavitation Lock Out Bung	4 - 7
			993/68300	Adjusting Pin	4 - 7
			Replacement items for kit no. 993/68100		
			993/68101	Slide Hammer	4 - 3
			993/68102	End Stops	4 - 3
			993/68103	Adaptor - M20 x 5/8" UNF	4 - 3
			993/68104	Adaptor - M20 x 1" UNF	4 - 3
			993/68105	Adaptor - M20 x M20	4 - 3
			993/68106	Adaptor - M20 x M24	4 - 3
			993/68107	Bar - M20 x M20 X 800MM	4 - 3
			993/68108	Adaptor - M20 x 7/8" UNF	4 - 3
			993/68109	Adaptor - M20 x M12	4 - 3
			993/68110	Adaptor - M20 x 5/8" UNF (Shoulder)	4 - 3
			993/68111	Adaptor - M20 x 1/2" UNF	4 - 3

Service Tools (cont'd)


Section B - Body & Framework

- 826/01099 M6 x 16mm Rivet Nut
- 826/01101 M6 x 19mm Rivet Nut
- 826/01103 M8 x 18mm Rivet Nut
- 826/01102 M8 x 21mm Rivet Nut
- 826/01104 M10 x 23mm Rivet Nut
- 826/01105 M10 x 26mm Rivet Nut

Installation Tool Available from:
 Bollhoff Fastenings Ltd.
 Midacre
 The Willenhall Estate
 Rose Hill
 Willenhall
 West Midlands, WV13 2JW



S261210




Hand Cleaner - special blend for the removal of polyurethane adhesives.

JCB part number - 4104/1310
 (454g; 1 lb tub)


S186240

Cartridge Gun - hand operated - essential for the application of sealants, polyurethane materials etc.

JCB part number - 892/00845




S186270



12V Mobile Oven - 1 cartridge capacity - required to pre-heat adhesive prior to use. It is fitted with a male plug (703/23201) which fits into a female socket (715/04300).

JCB part number - 992/12300

S186250



Folding Stand for Holding Glass - essential for preparing new glass prior to installation.

JCB part number - 892/00843


S186280

Service Tools (cont'd)

Section B - Body & Framework

240V Static Oven - available with 2 or 6 cartridge capacity - required to pre-heat adhesive prior to use. No plug supplied. Note: 110V models available upon request - contact JCB Technical Service.


JCB part number:
 992/12400 - 2 Cartridge x 240V
 992/12600 - 6 Cartridge x 240V



S186260


Glass Lifter - minimum 2 off - essential for glass installation, 2 required to handle large panes of glass. Ensure suction cups are protected from damage during storage.

JCB part number - 892/00842



S186300

Wire Starter - used to access braided cutting wire (below) through original polyurethane seal.



JCB part number - 892/00848

S186310

Cut-Out Knife - used to remove broken glass.


JCB part number - 992/12800



S186340

Glass Extractor (Handles) - used with braided cutting wire (below) to cut out broken glass.


JCB part number - 892/00846



S186320

'L' Blades - 25 mm (1 in) cut - replacement blades for cut-out knife (above).

JCB part number - 992/12801 (unit quantity = 5 off)




S186350

Service Tools (cont'd)

Section B - Body & Framework

Braided Cutting Wire - consumable heavy duty cut-out wire used with the glass extraction tool (above).


JCB part number - 892/00849
(approx 25 m length)



S186330


Long Knife - used to give extended reach for normally inaccessible areas.

JCB part number - 892/00844



S186360

Nylon Spatula - general tool used for smoothing sealants - also used to re-install glass in rubber glazing because metal tools will chip the glass edge.




JCB part number - 892/00847

S186470

Rubber Spacer Blocks - used to provide the correct set clearance between glass edge and cab frame.


JCB part number - 926/15500
(unit quantity = 500 off)



S186550

Slide Hammer Kit - 993/68100


1 :993/68101	Slide Hammer	6 :993/68106	Adaptor - M20 x M24
2 :993/68102	End Stops	7 :993/68107	Bar - M20 x M20 X 800MM
3 :993/68103	Adaptor - M20 x 5/8" UNF	8 :993/68108	Adaptor - M20 x 7/8" UNF
4 :993/68104	Adaptor - M20 x 1" UNF	9 :993/68109	Adaptor - M20 x M12
5 :993/68105	Adaptor - M20 x M20	10 :993/68110	Adaptor - M20 x 5/8" UNF (Shoulder)
		11 :993/68111	Adaptor - M20 x 1/2" UNF



S196910

Service Tools (cont'd)

Section C - Electrics




AVO Test Kit

1	892/00283	Tool Kit Case
2	892/00298	Fluke Meter 85
3	892/00286	Surface Temperature Probe
4	892/00284	Venture Microtach Digital Tachometer
5	892/00282	100 amp Shunt - open type
6	892/00285	Hydraulic Temperature Probe


S188231

993/85700 Battery Tester




S239510

892/00882 Socket for Alternator Pulley Nut



S216770

825/00410 15 mm Crowfoot Wrench
825/99833 Adapter




S216200

Service Tools (cont'd)

Section C - Electrics


1	Electrical Repair Kit	6A :7216/0002	6 Way Pin Housing
2A :7212/0002	2 Way Pin Housing	6B :7216/0004	6 Way Pin Retainer
2B :7212/0004	2 Way Pin Retainer	6C :7216/0003	6 Way Socket Retainer
2C :7212/0003	2 Way Socket Retainer	6D :7216/0001	6 Way Socket Connector
2D :7212/0001	2 Way Socket Connector	7A :7218/0002	8 Way Pin Housing
3A :7213/0002	3 Way Pin Housing	7B :7218/0004	8 Way Pin Retainer
3B :7213/0004	3 Way Pin Retainer	7C :7218/0003	8 Way Socket Retainer
3C :7213/0003	3 Way Socket Retainer	7D :7218/0001	8 Way Socket Connector
3D :7213/0001	3 Way Socket Connector	8A :7219/0002	10 Way Pin Housing
4A :7213/0006	3 Way Pin Housing (DT)	8B :7219/0004	10 Way Pin Retainer
4B :7213/0008	3 Way Pin Retainer (DT)	8C :7219/0003	10 Way Socket Retainer
4C :7213/0007	3 Way Socket Retainer (DT)	8D :7219/0001	10 Way Socket Connector
4D :7213/0005	3 Way Socket Connector (DT)	9A :7219/0006	14 Way Pin Housing
5A :7214/0002	4 Way Pin Housing	9B :7219/0008	14 Way Pin Retainer
5B :7214/0004	4 Way Pin Retainer	9C :7219/0007	14 Way Socket Retainer
5C :7214/0003	4 Way Socket Retainer	9D :7219/0005	14 Way Socket Connector
5D :7214/0001	4 Way Socket Connector	10 :7210/0001	Dummy Plug
		11 :7210/0002	Wire Seal (1.4 - 2.2 mm dia.)
		12 :7210/0003	Wire Seal (2.2 - 2.9 mm dia.)



S188380

Service Tools (cont'd)

Section E - Hydraulics




Hydraulic Circuit Pressure Test Kit

892/00253	Pressure Test Kit
:892/00201	Replacement Gauge 0-20 bar (0-300 lbf/in ²)
:892/00202	Replacement Gauge 0-40 bar (0-600 lbf/in ²)
:892/00203	Replacement Gauge 0-400 bar (0-6000 lbf/in ²)
:892/00254	Replacement Hose
993/69800	Seal Kit for 892/00254 (can also be used with probe 892/00706)
892/00706	Test Probe
* 892/00347	Connector - Hose to gauge

S267300


S188121



Pressure Test 'T' Adapters

892/00262	1/4 in M BSP x 1/4 in F BSP x Test Point
816/55038	3/8 in M BSP x 3/8 in F BSP x Test Point
816/55040	1/2 in M BSP x 1/2 in F BSP x Test Point
892/00263	5/8 in M BSP x 5/8 in F BSP x Test Point
892/00264	3/4 in M BSP x 3/4 in F BSP x Test Point
892/00265	1 in M BSP x 1 in F BSP x Test Point

S188131




Pressure Test Adapters

892/00255	1/4 in BSP x Test Point
892/00256	3/8 in BSP x Test Point
892/00257	1/2 in BSP x Test Point
892/00258	5/8 in BSP x Test Point
816/15118	3/4 in BSP x Test Point
892/00259	1 in BSP x Test Point
892/00260	1.1/4 in BSP x Test Point
892/00261	5/8 in UNF x Test Point

S200141

Flow Test Equipment

892/00268	Flow Monitoring Unit
892/00269	Sensor Head 0 - 100 l/min (0 - 22 UK gal/min)
892/00293	Connector Pipe
892/00270	Load Valve
1406/0021	Bonded Washer
1604/0006	Adapter 3/4 in M x 3/4 in M BSP
1612/0006	Adapter 3/4 in F x 3/4 in M BSP
892/00271	Adapter 3/4 in F x 5/8 in M BSP
892/00272	Adapter 5/8 in F x 3/4 in M BSP
816/20008	Adapter 3/4 in F x 1/2 in M BSP
892/00275	Adapter 1/2 in F x 3/4 in M BSP
892/00276	Adapter 3/4 in F x 3/8 in M BSP
892/00277	Adapter 3/8 in F x 3/4 in M BSP
892/00273	Sensor Head 0 - 380 l/min
892/00294	Connector Pipe
1606/0015	Adapter 1.1/4 in M BSP x 1 in M BSP
892/00078	Connector 1 in F x 1 in F BSP
1604/0008	Adapter 1 in M x 1 in M BSP
1606/0012	Adapter 1 in M x 3/4 in M BSP
816/20013	Adapter 3/4 in F x 1 in M BSP



S188151

Service Tools (cont'd)

Section E - Hydraulics


892/00881 Valve Spool Seal Fitting Tool



S261220

Hand Pump Equipment

- 892/00223 Hand Pump
- 892/00137 Micro-bore Hose 1/4 in BSP x 3 metres
- 892/00274 Adapter 1/4 in M BSP x 3/8 in M BSP Taper
- 892/00262 1/4 in M BSP x 1/4 in F BSP x Test Point
- 892/00706 Test Probe
- 892/00278 Gauge 0 - 40 bar (0 - 600 lbf/in²)
- 892/00279 Gauge 0 - 400 bar (0 - 6000 lbf/in²)




S193850

Components for Valve Block A.R.V. Testing

For 4CX Variable Flow machines use 25/201103

- 892/00309 A.R.V. Pressure Test Kit
- 1 : 892/00340 Test Block Body
- 2 : 892/00341 Setting Body
- 3 : 993/68300 Adjusting Pin
- 4 : 892/00343 Spanner
- 5 : 892/00345 Anti-cavitation Lock Out Bung
- 6 : 892/00335 A.R.V. Cartridge Removal Tool



S196700

Bonded Washers


- 1406/0011 1/4 in. BSP
- 1406/0018 1/2 in. BSP
- 1406/0014 5/8 in. BSP
- 1406/0021 3/4 in. BSP
- 1406/0029 1.1/4 in. BSP



S188140

Male Adapters - BSP x NPT (USA only)

- 816/00439 3/8 in. x 1/4 in.
- 816/00440 1/2 in. x 1/4 in.
- 816/15007 3/8 in. x 3/8 in.
- 816/15008 1/2 in. x 3/8 in.



S193860


Male Adapters - BSP x BSP

- 1606/0003 3/8 in. x 1/4 in.
- 1604/0003 3/8 in. x 3/8 in.
- 892/00071 3/8 in. x 3/8 in. taper
- 1606/0004 1/2 in. x 1/4 in.
- 1606/0007 1/2 in. x 3/8 in.
- 1604/0004 1/2 in. x 1/2 in.
- 1606/0017 5/8 in. x 1/2 in.
- 1606/0008 3/4 in. x 3/8 in.
- 1606/0009 3/4 in. x 1/2 in.
- 1604/0006 3/4 in. x 3/4 in.
- 1606/0012 3/4 in. x 1 in.
- 1606/0014 3/4 in. x 1.1/4 in.
- 1606/0015 1 in. x 1.1/4 in.

Service Tools (cont'd)


Section E - Hydraulics

Female Cone Blanking Plug
 892/00055 1/4 in. BSP
 892/00056 3/8 in. BSP
 892/00057 1/2 in. BSP
 892/00058 5/8 in. BSP
 892/00059 3/4 in. BSP
 892/00060 1 in. BSP




S193870

Male Cone Blanking Cap
 816/00294 1/4 in. BSP
 816/00189 3/8 in. BSP
 816/00190 1/2 in. BSP
 816/00197 5/8 in. BSP
 816/00196 3/4 in. BSP
 816/00193 1 in. BSP




S193880



S193890

892/00047 3/8 in. BSP (A) x 1/4 in. BSP (B)
 892/00048 1/2 in. BSP (A) x 1/4 in. BSP (B)
 892/00049 5/8 in. BSP (A) x 1/4 in. BSP (B)
 816/50043 3/4 in. BSP (A) x 1/4 in. BSP (B)
 892/00051 1 in. BSP (A) x 1/4 in. BSP (B)
 816/50005 1/2 in. BSP (A) x 1/2 in. BSP (B)
 816/60096 3/4 in. BSP (A) x 3/4 in. BSP (B)
 816/00017 1 in. BSP (A) x 1 in. BSP (B)




S193900

Female Connectors

892/00074 3/8 in. BSP x 3/8 in. BSP
 892/00075 1/2 in. BSP x 1/2 in. BSP
 892/00076 5/8 in. BSP x 5/8 in. BSP
 892/00077 3/4 in. BSP x 3/4 in. BSP


992/09100 Excavator Spool Clamp
 892/00011 Spool Clamp



S216210

Hexagon Spanners for Ram Pistons and End Caps






992/09300 55mm A/F
 992/09400 65mm A/F
 992/09500 75mm A/F
 992/09600 85mm A/F
 992/09700 95mm A/F
 992/09900 115mm A/F
 992/10000 125mm A/F



S193930

Service Tools (cont'd)


Section E - Hydraulics



Service Tools (cont'd)


Section F - Transmission

892/00812 Drive Coupling Spanner for front axle and gearbox yoke couplings




S196720

A 892/00920 Flow Test Adapter
 B 892/00301 Flow Test Adapter
 C 892/00302 Flow Test Adapter




S266880

892/00179 Bearing Press (use with appropriate adapters)




S188200

992/07608 Bearing Adapter
 992/07609 Bearing Adapter
 992/07610 Bearing Adapter
 992/07611 Bearing Adapter
 992/07612 Bearing Adapter
 992/07613 Bearing Adapter



S188160



S261230

Torque Measuring Tool for Wheel Hub Seals

Manufacture locally, procedures in this manual show checking the wheel hub seal using a rolling force. However, the torque can be measured using above locally manufactured tool.

Bearing rolling torque is 12 to 22 Nm (9 to 16 lbf ft) excluding seal drag. Maximum permissible including seal drag is 40 Nm (29.5 lbf ft).

Service Tools (cont'd)


Section F - Transmission

892/00224

Impulse Extractor Set for Hub Bearing Seals



S197070



892/00225

Adapter - Impulse Extractor

Small 17mm to 25mm

Medium 25mm to 45mm

Large 45mm to 80mm

993/59500

Adapter - Impulse Extractor (syncro shuttle and powershift transmission)




S216290


- 892/00817 17 mm A/F x 3/4in. square drive
- 892/00818 22 mm A/F x 3/4in. square drive
- 892/00819 15 mm A/F x 1/2in. square drive
- 892/00333 19 mm A/F x 3/4in. square drive

892/00174

Measuring Cup - Pinion Head Bearing



S190770








892/00822

Splined Bolt Socket for driveshafts

S197060






Service Tools (cont'd)

Section F - Transmission




Service Tools (cont'd)

Section F - Transmission



Service Tools (cont'd)

Section F - Transmission



Hydraulic Circuit Pressure Test Kit (also used for main hydraulic system tests)


892/00253	Pressure Test Kit
:892/00201	Replacement Gauge 0-20 bar (0-300 lbf/in ²)
:892/00202	Replacement Gauge 0-40 bar (0-600 lbf/in ²)
:892/00203	Replacement Gauge 0-400 bar (0-6000 lbf/in ²)
:892/00254	Replacement Hose
993/69800	Seal Kit for 892/00254 (can also be used with probe 892/00706)
892/00706	Test Probe
* 892/00347	Connector - Hose to gauge

S267300

S188121

Flow Test Equipment (also used for main hydraulic system tests)


892/00268	Flow Monitoring Unit
892/00269	Sensor Head 0 - 100 l/min (0 - 22 UK gal/min)
892/00293	Connector Pipe
892/00270	Load Valve
1406/0021	Bonded Washer
1604/0006	Adapter 3/4 in M x 3/4 in M BSP
1612/0006	Adapter 3/4 in F x 3/4 in M BSP
892/00271	Adapter 3/4 in F x 5/8 in M BSP
892/00272	Adapter 5/8 in F x 3/4 in M BSP
816/20008	Adapter 3/4 in F x 1/2 in M BSP
892/00275	Adapter 1/2 in F x 3/4 in M BSP
892/00276	Adapter 3/4 in F x 3/8 in M BSP
892/00277	Adapter 3/8 in F x 3/4 in M BSP
892/00273	Sensor Head 0 - 380 l/min
892/00294	Connector Pipe
1606/0015	Adapter 1.1/4 in M BSP x 1 in M BSP
892/00078	Connector 1 in F x 1 in F BSP
1604/0008	Adapter 1 in M x 1 in M BSP
1606/0012	Adapter 1 in M x 3/4 in M BSP
816/20013	Adapter 3/4 in F x 1 in M BSP



S188151

Service Tools (cont'd)

Section F - Transmission



Service Tools (cont'd)

Section F - Transmission

**Solid Spacer Setting Kit
Synchro Shuttle Gearbox, SD70, SD80
Axles, Powershift 2004 Gearbox**

* 10 921/53400 Spacer Kit - Sychro Shuttle Gearbox,
SD70, SD80 Axles

Comprises of:

					Spacer thickness mm		Spacer thickness mm
1	892/00918	Setting Tool Kit					
*1a	892/01164	Adaptor (2004 Gearboxes)					
*1b	892/01165	Sleeve (2004 Gearboxes)					
*1c	892/01163	Support Bracket (2004 Gearboxes)					
2	921/52627	Spacer 14.20 Service use		921/52628	12.600	921/53425	13.300
3	993/70111	Breakback Torque Wrench		829/30405	12.625	921/53426	13.325
4	892/01076	Support Bracket - Synchro Shuttle Gearbox		921/52629	12.650	921/53427	13.350
				829/30406	12.675	921/53428	13.375
5	892/01075	Support Bracket PD70, SD80 Rear Axles		921/52630	12.700	921/53401	13.400
				829/30407	12.725	921/53402	13.425
6	997/11000	Support Bracket SD55, SD70 Front Axles		921/52601	12.750	921/53403	13.450
				829/30408	12.775	921/53404	13.475
7	998/10567	SD80 Pinion Shaft Adaptor		921/52602	12.800	921/53405	13.500
				829/30409	12.825	921/53406	13.525
*8	921/53300	Spacer Kit - SD55 Axles		921/52603	12.850	921/53407	13.550
				829/30410	12.875	921/53408	13.575
				921/52604	12.900	921/53409	13.600
				829/30411	12.925	921/53410	13.625
				921/52605	12.950	921/53411	13.650
				829/30412	12.975	921/53412	13.675
				921/52606	13.000	921/53413	13.700
				829/30413	13.025	921/53414	13.725
				921/52607	13.050	921/53415	13.750
				829/30414	13.075	921/53416	13.775
				921/52608	13.100	921/53417	13.800
				829/30415	13.125	921/53418	13.825
				921/52609	13.150	921/53419	13.850
				829/30416	13.175	921/53420	13.875
				921/52610	13.200	921/53421	13.900
				829/30417	13.225	921/53422	13.925
				921/52611	13.250	921/53423	13.950
				921/53424	13.275	921/52626	14.000

Note: After using a spacer, obtain a replacement to keep the set complete.

*9 823/10547 Spacer Kit - Powershift 2004 Gearbox

Comprises of:


	Spacer thickness mm		Spacer thickness mm
829/30946	13.850	829/30953	13.675
829/30947	13.825	829/30954	13.650
829/30948	13.800	829/30955	13.625
829/30949	13.775	829/30956	13.600
829/30950	13.750	829/30957	13.575
829/30951	13.725	829/30958	13.550
829/30952	13.700		

Service Tools (cont'd)

Section F - Transmission

892/01094 Transmission Jack

When removing the Powershift gearbox use of a special transmission jack is strongly recommended. This jack can also be used when removing Synchro Shuttle gearboxes.
 Note that the jack must be used with special support plates, see below.



Powershift - Support plates, for use with transmission jack, Manufacture locally, for details see **Section F, Service Tools.**

892/01082 - Powershift - Assembly Cradle, for details see **Section F, Service Tools.**

Powershift - Gearbox hydraulic pump removal tools, allow pump to be removed with torque converter housing fitted to gearbox. Manufacture locally, for details see **Section F, Service Tools.**

823/10420 Thrust Washer Kit - Powershift gearbox - Layshaft clutch

Comprises of:


	Washer thickness mm
823/10421	4.3
823/10422	4.4
823/10423	4.5
823/10424	4.6
823/10425	4.7
823/10426	4.8

892/01083 Powershift - Assembly tool, transfer gear.

892/01084 Powershift - Transfer gear, bearing assembly.

892/01085 Powershift - Seal fitting tool

892/01096 Speed Sensor Test Harness - Powershift Gearbox



Service Tools (cont'd)


Section F - Transmission

**Powershift Gearbox - 6 Speed (ShiftMaster)
Electronic Service Tool Kit**

* **1** 721/10885 - Interconnecting cable (Data Link Adaptor to machine ECU diagnostics socket). Note that this cable must be ordered separately in addition to the kit below.



892/01033 - Service Tool Kit comprises:

- 1A** Data Link Adaptor (DLA), enables data exchange between the machine ECU (Electronic Control Unit) and a laptop PC loaded with the applicable ShiftMaster diagnostics software.
- 2A** Interconnecting cable, DLA to laptop PC. Several cables are included to enable compatibility with different PC port types.
- 3A** Kit carrying case.



A406130

892/01110 Torque Converter Alignment Tool
(for 12" and W300 torque converters)



Ø 0.3 X
2 DOWELS
Ø 8 x 32 LONG
PRESS FIT

SECTION A-A

A436700

Service Tools (cont'd)

Section F - Transmission



Wheel Hub Service Tool -

- A Bearing Puller
- B Bearing Press
- C Hub Seal Dolly

Item	Description	Part No.	Qty
A, B & C	Hub Service Kit	892/01092	1

comprises of:


1	Puller Beam	998/10623	1
2	Inner Bearing Plate	998/10607	1
3	Bolt M16x220	1315/3731Z	2
4	Nut M16	1370/0601Z	2
5	Reaction Tube	998/10614	1
6	Modified Wheel Stud	998/10624	2
7	Wheel Bearing Carrier Puller	998/10615	2
8	Nut M20	1370/0701Z	4
9	Washer M20	1420/0012Z	2
10	Puller Rod	998/10610	2
11	Nut M12	1370/0401Z	2
12	Washer M12	1420/0009Z	2
13	Bearing Centre Puller	998/10608	1
14	Bolt M10x60	1315/3414Z	1
15	Nut M10	1370/0301Z	1
16	Bearing Fitting Tube	998/10606	1
17	Puller Handle Nut	998/10616	1
18	Bolt M20x300	1315/3835Z	2
19	Washer	445/12303	2
20	Bearing	917/02800	1
21	Seal Dolly	892/00891	1



A439160





Service Tools (cont'd)

Section H - Steering



Service Tools (cont'd)

Section K - Engine



* For details of other engine service tools refer to the Engine Service Manual (publication no. 9806/2140) for low emission engines.

Sealing and Retaining Compounds

JCB Multi-Gasket	A medium strength sealant suitable for all sizes of gasket flanges, and for hydraulic fittings of 25-65mm diameter.	4102/1212	50ml
JCB High Strength Threadlocker	A high strength locking fluid for use with threaded components. Gasketing for all sizes of flange where the strength of the joint is important.	4102/0551	50ml
JCB Retainer (High Strength)	For all retaining parts which are unlikely to be dismantled.	4101/0651	50ml
JCB Threadlocker and Sealer	A high strength locking fluid for sealing and retaining nuts, bolts, and screws up to 50mm diameter, and for hydraulic fittings up to 25mm diameter.	4101/0250 4101/0251	10ml 50ml
Threadseal	A medium strength thread sealing compound.	4102/1951	50ml
Threadlocker	A locking fluid for use on threads larger than 50mm dia.	4101/0451	50ml
Activator	A cleaning primer which speeds the curing rate of anaerobic products.	4104/0251 4104/0253	(1ltr) Bottle (200ml)
Cleaner / Degreaser	For degreasing components prior to use of anaerobic adhesives and sealants.	4104/1557	400ml
Direct Glazing Kit	For one pane of glass, comprises items marked † below plus applicator nozzle etc.	993/55700	
† Ultra Fast Adhesive	For direct glazing	4103/2109	310 ml
† Active Wipe 205	For direct glazing	4104/1206 4104/1203	30 ml 250 g
† Black Primer 206J	For direct glazing	4201/4906	30 ml
Clear Silicone Sealant	To seal butt jointed glass	4102/0933	
Black Polyurethane Sealant	To finish exposed edges of laminated glass	4102/2309	310 ml
JCB Cleaner & Degreaser	For degreasing components prior to use of anaerobic adhesives and sealants.	4104/1538	Aerosol

Contents	Page No.
Safety Notices	1 - 1
General Safety	2 - 1
Operating Safety	3 - 1
Maintenance Safety	4 - 1

Safety Notices

In this publication and on the machine, there are safety notices. Each notice starts with a signal word. The signal word meanings are given below.

DANGER

Denotes an extreme hazard exists. If proper precautions are not taken, it is highly probable that the operator (or others) could be killed or seriously injured.

INT-1-2-1

WARNING

Denotes a hazard exists. If proper precautions are not taken, the operator (or others) could be killed or seriously injured.

INT-1-2-2

CAUTION

Denotes a reminder of safety practices. Failure to follow these safety practices could result in injury to the operator (or others) and possible damage to the machine.

INT-1-2-3

All construction and agricultural equipment can be hazardous. When a JCB machine is correctly operated and properly maintained, it is a safe machine to work with. But when it is carelessly operated or poorly maintained it can become a danger to you (the operator) and others.

Do not work with the machine until you are sure that you can control it.

Do not start any job until you are sure that you and those around you will be safe.

If you are unsure of anything, about the machine or the job, ask someone who knows. Do not assume anything.

Remember

**BE CAREFUL
BE ALERT
BE SAFE**

GEN-1-6

General Safety

WARNING

Decals

You can be injured if you do not obey the decal safety instructions. Keep decals clean. Replace unreadable or missing decals with new ones before operating the machine. Make sure replacement parts include warning decals where necessary.

INT-1-3-4

WARNING

Lifting Equipment

You can be injured if you use faulty lifting equipment. Make sure that lifting equipment is in good condition. Make sure that lifting tackle complies with all local regulations and is suitable for the job. Make sure that lifting equipment is strong enough for the job.

INT-1-3-7

WARNING

Care and Alertness

All the time you are working with or on the machine, take care and stay alert. Always be careful. Always be alert for hazards.

INT-1-3-5

WARNING

Raised Attachments

Raised attachments can fall and injure you. Do not walk or work under raised attachments unless they are safely blocked.

INT-1-3-8

WARNING

Clothing

You can be injured if you do not wear the proper clothing. Loose clothing can get caught in the machinery. Wear protective clothing to suit the job. Examples of protective clothing are: a hard hat, safety shoes, safety glasses, a well fitting overall, ear-protectors and industrial gloves. Keep cuffs fastened. Do not wear a necktie or scarf. Keep long hair restrained.

INT-1-3-6

Operating Safety

WARNING

Machine Condition

A defective machine can injure you or others. Do not operate a machine which is defective or has missing parts. Make sure the maintenance procedures in this handbook are completed before using the machine.

INT-2-1-2

WARNING

Controls

You or others can be killed or seriously injured if you operate the control levers from outside the cab. Operate the control levers only when you are correctly seated inside the cab.

INT-2-1-3

WARNING

Machine Limits

Operating the machine beyond its design limits can damage the machine, it can also be dangerous. Do not operate the machine outside its limits. Do not try to upgrade the machine performance with unapproved modifications.

INT-2-1-4

WARNING

Engine/Steering Failure

If the engine or steering fails, stop the machine as quickly as possible. Do not operate the machine until the fault has been corrected.

INT-2-1-5

WARNING

Engine

The engine has exposed rotating parts. Do not open the engine cover while the engine is running. Do not use the machine with the cover open.

INT-2-1-6/1

WARNING

Entering/Leaving

Always face the machine when entering and leaving the cab. Use the step(s) and handrails. Make sure the step(s), handrails and your boot soles are clean and dry. Do not jump from the machine. Do not use the machine controls as handholds, use the handrails.

INT-2-1-7

WARNING

Exhaust Gases

Breathing the machine exhaust gases can harm and possibly kill you. Do not operate the machine in closed spaces without making sure there is good ventilation. If possible, fit an exhaust extension. If you begin to feel drowsy, stop the machine at once. Get out of the cab into fresh air.

INT-2-1-10

WARNING

ROPS/FOPS Structure

The machine is fitted with a Roll Over Protection Structure (ROPS) and a Falling Objects Protection Structure (FOPS). You could be killed or seriously injured if you operate the machine with a damaged or missing ROPS/FOPS. If the ROPS/FOPS has been in an accident, do not use the machine until the structure has been renewed. Modifications and repairs that are not approved by the manufacturer may be dangerous and will invalidate the ROPS/FOPS certification.

INT-2-1-9/3

WARNING

Communications

Bad communications can cause accidents. Keep people around you informed of what you will be doing. If you will be working with other people, make sure any hand signals that may be used are understood by everybody. Work sites can be noisy, do not rely on spoken commands.

INT-2-2-3

WARNING

Ramps and Trailers

Water, mud, ice, grease and oil on ramps or trailers can cause serious accidents. Make sure ramps and trailers are clean before driving onto them. Use extreme caution when driving onto ramps and trailers.

INT-2-2-6

DANGER

Sparks

Explosions and fire can be caused by sparks from the exhaust or the electrical system. Do not use the machine in closed areas where there is flammable material, vapour or dust.

INT-2-2-10

WARNING

Powershift Transmission

Do not change from a high gear to a low gear (for instance, 4th to 1st) in one sudden movement whilst the machine is moving. Otherwise the machine will rapidly decelerate, you or others could be killed or seriously injured. When selecting lower gears, allow the engine speed to drop before each gear change.

2-1-1-9/1

Maintenance Safety

WARNING

Repairs

Do not try to do repairs or any other type of maintenance work you do not understand. To avoid injury and/or damage get the work done by a specialist engineer.

GEN-1-5

WARNING

Modifications and Welding

Non-approved modifications can cause injury and damage. Parts of the machine are made from cast iron; welds on cast iron can weaken the structure and break. Do not weld cast iron. Contact your JCB distributor for advice before modifying the machine.

INT-3-1-2/1

WARNING

Metal Splinters

You can be injured by flying metal splinters when driving metal pins in or out. Use a soft faced hammer or drift to remove and fit metal pins. Always wear safety glasses.

INT-3-1-3

WARNING

Electrical Circuits

Understand the electrical circuit before connecting or disconnecting an electrical component. A wrong connection can cause injury and/or damage.

INT-3-1-4

WARNING

Communications

Bad communications can cause accidents. If two or more people are working on the machine, make sure each is aware of what the others are doing. Before starting the engine make sure the others are clear of the danger areas; examples of danger areas are: the rotating blades and belt on the engine, the attachments and linkages, and anywhere beneath or behind the machine. People can be killed or injured if these precautions are not taken.

INT-3-1-5

WARNING

Petrol

Do not use petrol in this machine. Do not mix petrol with the diesel fuel; in storage tanks the petrol will rise to the top and form flammable vapours.

INT-3-1-6

WARNING

Battery

A battery with frozen electrolyte can explode if it is used or charged. Do not use a machine with a frozen battery. To help prevent the battery from freezing, keep the battery fully charged.

INT-3-1-7

WARNING

Battery Gases

Batteries give off explosive gases. Keep flames and sparks away from the battery. Do not smoke close to the battery. Make sure there is good ventilation in closed areas where batteries are being used or charged. Do not check the battery charge by shorting the terminals with metal; use a hydrometer or voltmeter.

INT-3-1-8

WARNING

Battery Terminals

The machine is negatively earthed. Always connect the negative pole of the battery to earth.

When connecting the battery, connect the earth (-) lead last.

When disconnecting the battery, disconnect the earth (-) lead first.

INT-3-1-9

WARNING

Hydraulic Fluid

Fine jets of hydraulic fluid at high pressure can penetrate the skin. Do not use your fingers to check for hydraulic fluid leaks. Do not put your face close to suspected leaks. Hold a piece of cardboard close to suspected leaks and then inspect the cardboard for signs of hydraulic fluid. If hydraulic fluid penetrates your skin, get medical help immediately.

INT-3-1-10/1

DANGER

Hydraulic Pressure

Hydraulic fluid at system pressure can injure you. Before disconnecting or connecting hydraulic hoses, stop the engine and operate the controls to release pressure trapped in the hoses. Make sure the engine cannot be started while the hoses are open.

INT-3-1-11/1

Maintenance Safety (cont'd)**⚠ WARNING****Diesel Fuel**

Diesel fuel is flammable; keep naked flames away from the machine. Do not smoke while refuelling the machine or working on the engine. Do not refuel with the engine running. There could be a fire and injury if you do not follow these precautions.

INT-3-2-2

⚠ WARNING**Oil**

Oil is toxic. If you swallow any oil, do not induce vomiting, seek medical advice. Used engine oil contains harmful contaminants which can cause skin cancer. Do not handle used engine oil more than necessary. Always use barrier cream or wear gloves to prevent skin contact. Wash skin contaminated with oil thoroughly in warm soapy water. Do not use petrol, diesel fuel or paraffin to clean your skin.

INT-3-2-3

⚠ WARNING**Soft Ground**

A machine can sink into soft ground. Never work under a machine on soft ground.

INT-3-2-4

⚠ WARNING**Tyres and Rims**

Over-inflated or over-heated tyres can explode. Follow the instructions in this handbook for inflating the tyres. Do not weld or cut rims. Get a tyre/wheel specialist to do any repair work.

INT-3-2-6

⚠ WARNING**Hot Coolant**

The cooling system is pressurised when the engine is hot. Hot coolant can spray out when you remove the radiator cap. Let the system cool before removing the radiator cap. To remove the cap; turn it to the first notch and let the system pressure escape, then remove the cap.

INT-3-2-9

⚠ WARNING

Always wear safety glasses when dismantling assemblies containing components under pressure from springs. This will protect against eye injury from components accidentally flying out.

GEN 6-2

⚠ CAUTION**Rams**

The efficiency of the rams will be affected if they are not kept free of solidified dirt. Clean dirt from around the rams regularly. When leaving or parking the machine, close all rams if possible to reduce the risk of weather corrosion.

INT-3-2-10

⚠ CAUTION**Cleaning**

Cleaning metal parts with incorrect solvents can cause corrosion. Use only recommended cleaning agents and solvents.

INT-3-2-11

⚠ CAUTION**'O' rings, Seals and Gaskets**

Badly fitted, damaged or rotted 'O' rings, seals and gaskets can cause leakages and possible accidents. Renew whenever disturbed unless otherwise instructed. Do not use Trichloroethane or paint thinners near 'O' rings and seals.

INT-3-2-12

⚠ WARNING**Fires**

If your machine is equipped with a fire extinguisher, make sure it is checked regularly. Keep it in the operator's cab until you need to use it.

Do not use water to put out a machine fire, you could spread an oil fire or get a shock from an electrical fire. Use carbon dioxide, dry chemical or foam extinguishers. Contact your nearest fire department as quickly as possible. Firefighters should use self-contained breathing apparatus.

INT-3-2-7/1

⚠ WARNING**Jacking**

A machine can roll off jacks and crush you unless the wheels have been chocked. Always chock the wheels at the opposite end of the machine that is to be jacked. Do not work underneath a machine supported only by jacks. Always support a jacked-up machine on axle stands before working underneath it.

INT-3-2-8

Maintenance Safety (cont'd)

WARNING

Hydraulic Hoses

Damaged hoses can cause fatal accidents. Inspect the hoses regularly for:

- Damaged end fittings
- Chafed outer covers
- Ballooned outer covers
- Kinked or crushed hoses
- Embedded armouring in outer covers
- Displaced end fittings.

INT-3-3-2

WARNING

Safety Strut

Raised loader arms can drop suddenly and cause serious injury. Before working under raised loader arms, fit the loader arm safety strut.

2-1-1-6

WARNING

A raised and badly supported machine can fall on you. Position the machine on a firm, level surface before raising one end. Ensure the other end is securely chocked. Do not rely solely on the machine hydraulics or jacks to support the machine when working under it.

Disconnect the battery, to prevent the engine being started while you are beneath the machine.

GEN-1-1

WARNING

Waxoyl contains turpentine substitute, which is flammable. Keep flames away when applying Waxoyl. Waxoyl can take a few weeks to dry completely. Keep flames away during the drying period.

Do not weld near the affected area during the drying period. Take the same precautions as for oil to keep Waxoyl off your skin. Do not breathe the fumes. Apply in a well-ventilated area.

5-3-1-9

WARNING

Make the machine safe before working underneath it. Park the machine on level ground, lower the arms. Apply the parking brake, put the transmission in neutral and stop the engine. Chock both sides of all four wheels.

Disconnect the battery, to prevent the engine being started while you are beneath the machine.

GEN-1-2

WARNING

To avoid burning, wear protective gloves when handling hot components. To protect your eyes, wear goggles when using a wire brush to clean components.

HYD 1-3

WARNING

JCB Extradig Dipper Lubricant

JCB Extradig dipper lubricant contains 1.53% lead. The repeated swallowing of very small quantities can cause chronic lead poisoning. Do not smoke or touch food while handling this lubricant. Dispose of waste (rags etc.) in accordance with local regulations.

2-1-1-8

WARNING

Fluoroelastomeric Materials

Certain seals and gaskets (e.g. crankshaft oil seal) on JCB machines contain fluoroelastomeric materials such as Viton, Fluorel and Technoflon. Fluoroelastomeric materials subjected to high temperatures can produce highly corrosive hydrofluoric acid. THIS ACID CAN SEVERELY BURN.

New fluoroelastomeric components at ambient temperature require no special safety precautions.

Used fluoroelastomeric components whose temperatures have not exceeded 300°C require no special safety precautions. If evidence of decomposition (e.g. charring) is found, refer to the next paragraph for safety instructions DO NOT TOUCH COMPONENT OR SURROUNDING AREA.

Used fluoroelastomeric components subjected to temperatures greater than 300°C (e.g. engine fire) must be treated using the following safety procedure. Make sure that heavy duty gloves and special safety glasses are worn:

- 1 Ensure that components have cooled then remove and place material into plastic bags.
- 2 Thoroughly wash contaminated area with 10% calcium hydroxide or other suitable alkali solution, if necessary use wire wool to remove burnt remains.
- 3 Thoroughly wash contaminated area with detergent and water.
- 4 Contain all removed material, gloves etc. used in this operation in sealed plastic bags and dispose of in accordance with Local Authority Regulations.

DO NOT BURN FLUOROELASTOMERIC MATERIALS.

If contamination of skin or eyes occurs, wash the affected area with a continuous supply of clean water or with calcium hydroxide solution for 15-60 minutes. Get medical attention immediately.

INT-3-3-5/1

Contents	Page No.
Checking for Damage	1 - 1
Cleaning the Machine	1 - 2
Seat Belt	
Checking the Seat Belt Condition and Security	1 - 3
Fire Extinguisher (when fitted)	
Checking the Fire Extinguisher	1 - 3
ROPS/FOPS Structure	
Checking the ROPS/FOPS Structure	1 - 4
Tyres and Wheels	
Tyre Inflation	1 - 5
Checking the Wheel Nut Torques	1 - 5
Lubricants - Health and Safety	
Hygiene	1 - 6
Storage	1 - 6
Waste Disposal	1 - 6
Handling	1 - 6
First Aid - Oil	1 - 6
Spillage	1 - 6
Fires	1 - 6
Service Schedules	2 - 1
Loader Arm Safety Strut	
Installing and Removing	2 - 4
Engine Panels	
Opening and Closing the Bonnet	2 - 5
Removing and Fitting a Side Panel	2 - 6
Removing and Fitting the Front Grille	2 - 6
Greasing	
General	3 - 1
Loader Arms	3 - 1
Backhoe & Quickhitch	3 - 2
Front Axle (2 Wheel Drive Machines)	3 - 3
Front Axle (4 Wheel Drive Machines)	3 - 3
Front Axle (All Wheel Steer Machines)	3 - 4
Rear Axle (All Wheel Steer Machines)	3 - 4
Extending Dipper	3 - 5
Driveshafts	3 - 5
6 - in - 1 Clamshovel	3 - 6
Stabilisers (Centremount Machines)	3 - 6
Loader Quickhitch	3 - 6
Power Sideshift	3 - 7
Kingpost	3 - 7
Knuckle (if fitted)	3 - 8
Backhoe Quickhitch (Hydraulic)	3 - 8

Contents	Page No.
Engine Air Filter	
Cleaning the pre-cleaner (if fitted)	3 - 9
Changing the Elements	3 - 10
Engine Oil and Filter	
Checking the Oil Level	3 - 11
Changing the Oil and Filter	3 - 12
Engine Cooling System	
Checking the Coolant	3 - 13
Changing the Coolant	3 - 14
Adjusting the Fan Belt	3 - 16
Cleaning the Cab Heater Filter	3 - 16
Fuel System	
Types of Fuel	3 - 17
Fuel Standards	3 - 17
Low Temperature Fuels	3 - 17
Fatty Acid Methyl Ester Fuels	3 - 17
Petrol	3 - 17
Advice	3 - 17
Filling the Tank	3 - 18
Draining the Filter	3 - 19
Changing the Filter Element	3 - 20
Draining the Sediment Bowl	3 - 22
Cleaning the Fuel Lift Pump Strainer (AK and AR Build Engines Only)	3 - 24
Bleed the System	3 - 25
Fuel Pipes - Removal and Replacement (RE and RG Build Engines Only)	3 - 26
Synchro Shuttle Gearbox	
Checking the Oil Level	3 - 27
Changing the Oil and Filter	3 - 28
Powershift Gearbox	
Checking the Oil Level	3 - 29
Changing the Oil and Filter	3 - 30
Front and Rear Axle (All Wheel Steer Machines)	
Checking the Differential Oil Level	3 - 32
Changing the Differential Oil	3 - 32
Checking the Hub Oil Levels	3 - 33
Changing the Hub Oil	3 - 33
Front and Rear Axle (Two Wheel Steer Machines)	
Checking the Oil Level	3 - 34
Changing the Oil	3 - 34
Brakes	
Parking Brake Adjustment	3 - 35
Checking the Foot Brake Fluid Level	3 - 35

Contents	Page No.
Hydraulic System	
Checking the Fluid Level	3 - 37
Hydraulic Tank Cap	3 - 37
Changing the Filter Element	3 - 38
Changing the Suction Strainer	3 - 39
Hydraulic Oil Cooler	
Cleaning the Tubes/Fins	3 - 40
Windscreen Washer	3 - 41
Electrical System	
Fuses & Relays	4 - 1
Battery	
Warning Symbols	4 - 2
First Aid - Electrolyte	4 - 3
Checking the Electrolyte Level	4 - 3
Battery Isolator (if fitted)	4 - 4
Stabiliser Legs (Sideshift Machines Only)	
Wear Pads	5 - 1
Wear Pad Adjustment	5 - 1
Extending Dipper Wear Pads	
Inspecting the Top Wear Pads	5 - 2
Adjusting the Bottom Wear Pads	5 - 2
Air Conditioning (if fitted)	
Adjusting the Compressor Drive Belt	5 - 3
Hose Burst Protection Valve (if fitted)	
Checking Hose Burst Protection Valve	5 - 4
Lowering a Load - In a Failure Condition	5 - 4
Service Capacities and Lubricants	6 - 1
Coolant Mixtures	6 - 2

Inspect steelwork for damage. Note damaged paintwork for future repair.

Make sure all pivot pins are correctly in place and secured by their locking devices.

Ensure that the steps and handrails are undamaged and secure.

Check for broken or cracked window glass. Replace damaged items.

Check all bucket teeth for damage and security.

Check all lamp lenses for damage.

Inspect the tyres for damage and penetration by sharp objects.

Check that all safety decals are in place and undamaged. Fit new decals where necessary.

Park the machine on firm level ground, engage the parking brake and set the transmission to neutral. Lower the attachments to the ground and stop the engine.

Clean the machine using water and/or steam. Do not allow mud, debris etc to build upon the machine, pay particular attention to the following areas:

- 1 Backhoe hoses passing through mainframe.
- 2 Around twin slew rams.
- 3 Twin ram slew recess in chassis (centremount).
- 4 Kingpost slide rails (sideshift).
- 5 Kingpost hose tray and bottom 'shelf' (sideshift).
- 6 Recess between slew ram and kingpost casting (sideshift).

Stabiliser cavities can become clogged when operating in soft/wet ground conditions. Remove and clean away all debris that may have built up.

Do not allow mud to build up on the engine and transmission. Make sure the radiator grille is not clogged up.

WARNING

Airborne particles of light combustible material such as straw, grass, wood shavings, etc. must not be allowed to accumulate within the engine compartment or in the propshaft guards (when fitted). Please inspect these areas frequently and clean at the beginning of each work shift or more often if required. Before opening the engine cover, ensure that the top is clear of debris.

5-3-1-12/2


Avoid using neat detergent - always dilute detergents as per the manufacturer's recommendations, otherwise damage to the paint finish may occur.

It is important to note that excessive power washing can cause damage to the seals or bearings. Take care during routine machine washing not to direct high power water jets directly at oil seals or universal joints.


Note: The machine must always be greased after pressure washing or steam cleaning.

Always adhere to local regulations regarding the disposal of debris created from machine cleaning.


The illustrations show some of the areas that must be thoroughly cleaned as required.



S272900



S272880



S272890

Checking the Seat Belt Condition and Security

⚠ WARNING

When a seat belt is fitted to your machine replace it with a new one if it is damaged, if the fabric is worn, or if the machine has been in an accident. Fit a new seat belt every three years.

2-3-1-7/1

Inspect the seat belt for signs of fraying and stretching. Check that the stitching is not loose or damaged. Check that the buckle assembly is undamaged and works correctly.

Check that the belt mounting bolts are undamaged, correctly fitted and tightened.

Fire Extinguisher (when fitted)

Checking the Fire Extinguisher


Check the fire extinguisher for damage, security and signs of leaking.

Check that the gauge **B** indicates that the extinguisher is charged ie. the needle is in the GREEN segment.

Note: If the needle is in or very near the RED segment at either end of the gauge, the extinguisher must be serviced or replaced.

Make sure the safety pin is fitted and secure.

The extinguisher should be serviced every 12 months by a suitably qualified person.



S170520

Checking the ROPS/FOPS Structure

The procedure for checking the ROPS/FOPS structure is described in the Body & Framework section. Refer to **Section B Body & Framework, Service Procedures, Cab ROPS/FOPS Structure - Checks.**

Tyre Inflation

These instructions are for adding air to a tyre which is already inflated. If the tyre has lost all its air pressure, call in a qualified tyre mechanic. The tyre mechanic should use a tyre inflation cage and the correct equipment to do the job.

WARNING

An exploding tyre can kill, inflated tyres can explode if overheated. Do not cut or weld the rims. Use a tyre/wheel specialist for all repair work.

2-3-2-7

1 Prepare the Wheel

Before you add air to the tyre, make sure it is correctly fitted on the machine or installed in a tyre inflation cage.

2 Prepare the Equipment


Use only an air supply system which includes a pressure regulator. Set the regulator no higher than 1.38 bar (20 psi) above the recommended tyre pressure. See Section F, **Technical Data** for recommended tyres and pressures for your machine.

Use an air hose fitted with a self-locking air chuck and remote shut-off valve.

3 Add the Air

Make sure that the air hose is correctly connected to the tyre valve. Clear other people from the area. Stand behind the tread of the tyre while adding the air.

Inflate the tyre to the recommended pressure. Do not over-inflate.



S089571

Checking the Wheel Nut Torques

On new machines, and whenever a wheel has been removed, check the wheel nut torques every two hours until they stay correct.

Every day, before starting work, check that the wheel nuts are tight.

The correct torques are shown in the table below.

Front - Nm	lbf ft
680	500

Rear - Nm	lbf ft
680	500

WARNING

If, for whatever reason, a wheel stud is renewed, all the studs for that wheel must be changed as a set, since the remaining studs may have been damaged.

2-3-2-8

It is most important that you read and understand this information and the publications referred to. Make sure all your colleagues who are concerned with lubricants read it too.

Hygiene

JCB lubricants are not a health risk when used properly for their intended purposes.

However, excessive or prolonged skin contact can remove the natural fats from your skin, causing dryness and irritation.

Low viscosity oils are more likely to do this, so take special care when handling used oils, which might be diluted with fuel contamination.

Whenever you are handling oil products you should maintain good standards of care and personal and plant hygiene. For details of these precautions we advise you to read the relevant publications issued by your local health authority, plus the following.

Storage

Always keep lubricants out of the reach of children.

Never store lubricants in open or unlabelled containers.

Waste Disposal

All waste products should be disposed of in accordance with all the relevant regulations.

The collection and disposal of used oil should be in accordance with any local regulations. Never pour used engine oil into sewers, drains or on the ground.

Handling

New Oil.

There are no special precautions needed for the handling or use of new oil, beside the normal care and hygiene practices.

Used Oil.

Used engine crankcase lubricants contain harmful contaminants.

Here are precautions to protect your health when handling used engine oil:

- 1 Avoid prolonged, excessive or repeated skin contact with used oil.

- 2 Apply a barrier cream to the skin before handling used oil.

- 3 Note the following when removing engine oil from skin:
 - a Wash your skin thoroughly with soap and water.
 - b Using a nail brush will help.
 - c Use special hand cleansers to help clean dirty hands.
 - d Never use petrol, diesel fuel, or paraffin for washing.

- 4 Avoid skin contact with oil soaked clothing.

- 5 Don't keep oily rags in pockets.

- 6 Wash dirty clothing before re-use.

- 7 Throw away oil-soaked shoes.

First Aid - Oil

Eyes.

In the case of eye contact, flush with water for 15 minutes. If irritation persists, get medical attention.

Swallowing.

If oil is swallowed do not induce vomiting. Get medical advice.

Skin.

In the case of excessive skin contact, wash with soap and water.

Spillage

Absorb on sand or a locally approved brand of absorbent granules. Scrape up and remove to a chemical disposal area.

Fires

Extinguish with carbon dioxide, dry chemical or foam. Fire-fighters should use self-contained breathing apparatus.

A badly maintained machine is a danger to the operator and the people working around him. Make sure that the regular maintenance and lubrication jobs listed in the service schedules are done to keep the machine in a safe and efficient working condition.

WARNING

Maintenance

Maintenance must be done by suitably qualified personnel. Before attempting any maintenance work, make sure the machine is safe. Park on level ground. If it is necessary to work with the loader arms raised, then the loader arm safety strut must be fitted as shown in Loader Arm Safety Strut in MAINTENANCE section.

2-3-1-1

Apart from the daily jobs, the schedules are based on machine running hours. Keep a regular check on the hourmeter readings to correctly gauge service intervals. Do not use a machine which is due for a service. Make sure any defects found during the regular maintenance checks are rectified immediately.

Calendar equivalents:

10 Hours	=	Daily
50 Hours	=	Weekly
500 Hours	=	Six Months
1000 Hours	=	Yearly
2000 Hours	=	2 Years

Pre-start Cold Checks Service Points and Fluid Levels	Operation	10 Hr	50 Hr	†100 Hr	500 Hr	1000 Hr	2000 Hr
ENGINE							
Oil level	- Check	•	•				
Oil and Filter (AK and AR Build) ④	- Change			•	•	•	•
Oil and Filter (RE and RG Build) ④	- Change				•	•	•
Air Cleaner Outer Element ⑥	- Change					•	•
Air Cleaner Inner Element	- Change						•
Fuel Filter (AK and AR Build)	- Change			•	•	•	•
Fuel Filter (RE and RG Build)	- Change				•	•	•
Fuel Filter	- Drain		•				
Lift Pump Strainer (AK and AR Build Only)	- Clean			•	•	•	•
Coolant Quality/Level	- Check	•	•	•	•	•	•
Fuel Sedimenter	- Drain and Clean		•	•	•	•	•
Fan Belt Tension/Condition	- Check		•	•	•	•	•
Valve Clearances and Clean Breather Gauze (if fitted) ③	- Check and Adjust					•	•
Engine Mounting Bolts for Tightness ③	- Check			•	•	•	•
Radiator	- Clean				•	•	•
All Hoses - Condition	- Check			•	•	•	•
TRANSMISSION, AXLES AND STEERING							
Transmission Oil Level	- Check	•	•	•	•		
Transmission Oil ⑧	- Change					•	•
Transmission Filter	- Change			•	•	•	•
Axle Oil Level (incl. Hubs when applicable) ①	- Check			•	•		
Axle Oil (incl. Hubs when applicable) ⑨	- Change					•	•
Axle Oil - Limited Slip Differential	- Change				•	•	•
Tyre Pressures/Condition	- Check	•	•	•	•	•	•
Front Hub Bearings ③	- Check			•	•	•	•
Transmission Strainer	- Clean					•	•
Drive Shafts	- Security/Grease			•	•	•	•
Steer Axle Movement/Shimming ③	- Check			•	•	•	•
Steer Axle Pivots and Linkages ⑦	- Grease			•	•	•	•
Front Axle Main Pivot	- Grease	•	•	•	•	•	•
HYDRAULICS							
Oil Level ②	- Check	•	•	•	•	•	
Oil ③	- Sample/Change						•
Oil Filter	- Change			•	•	•	•
Rams - Chrome Condition	- Check			•	•	•	•

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com