

# HYDRAULIC EXCAVATOR

## SHOP MANUAL

# CASE CX25

## INDEX

1	SPECIFICATIONS
2	MAINTENANCE
3	SYSTEM
4	DISASSEMBLING
5	TROUBLESHOOTING
6	ENGINE
7	INSTALLATION PROCEDURES FOR OPTIONAL ATTACHMENTS

SPECIFICATIONS

MAINTENANCE

SYSTEM

DISASSEMBLING

TROUBLESHOOTING

E/G

OPT

# CASE

Book Code No. **S5PV001E** ①

**00-0-1** ①

**Shop Manual Model Number Cross Reference:  
SK25SR-2 is CASE Model CX25**



# INDEX

SK25SR-2



Book Code No. Issued Year-Month			Title	Index No.
S5PV0101E 2000-12		SPECIFICATIONS	PRELIMINARY REMARKS	PV01
S5PV0201E① 2001-10			SPECIFICATIONS	PV02
S5PV0301E① 2001-10			ATTACHMENT	PV03
S5PV1101E① 2001-10		MAINTENANCE	TOOLS	PV11
S5PV1201E① 2001-10			STANDARD MAINTENANCE TIME TABLE	PV12
S5PV1301E① 2001-10			MAINTENANCE STANDARDS AND TEST PROCEDURES	PV13
—		SYSTEM		
S5PV2201E① 2001-10			HYDRAULIC SYSTEM	PV22
S5PV2301E① 2001-10			ELECTRICAL SYSTEM	PV23
S5PV2401E① 2001-10			COMPONENTS SYSTEM	PV24
—				
—				
S5PV3101E 2000-12		DISASSEMBLING	WHOLE DISASSEMBLING & ASSEMBLING	PV31
S5PV3201E① 2001-10			ATTACHMENTS	PV32
S5PV3301E① 2001-10			UPPER SLEWING STRUCTURE	PV33
S5PV3401E 2000-12			TRAVEL SYSTEM	PV34
—		TROUBLESHOOTING		
S5PV4201E 2000-12			HYDRAULIC SYSTEM	PV42
S5PV4301E 2000-12			ELECTRICAL SYSTEM	PV43
S5PV4401E 2000-12			ENGINE	PV44
S5PV5101E 2000-12		E/G	ENGINE	PV51
		OPT		
PV08-20001~			APPLICABLE MACHINES	



# SAFETY PRECAUTIONS



## 1.1 GENERAL SAFETY INFORMATION



 <b>WARNING</b> 
<p>Do Not operate or perform any maintenance on this machine until all instructions found in the OPERATION &amp; MAINTENANCE MANUAL have been thoroughly read and understood.</p> <p>Improper operation or maintenance of this machine may cause accidents and could result in serious injury or death.</p> <p>Always keep the manual in the operator's seat pocket.</p> <p>If it is missing or damaged, place an order with an authorized CASE Distributor for a replacement.</p> <p>If you have any questions, please consult an authorized CASE Distributor.</p>

1. Most accidents, which occur during operation, are due to neglect of precautionary measures and safety rules. Sufficient care should be taken to avoid these accidents. Erroneous operation, lubrication or maintenance services are very dangerous and may cause injury or death of personnel. Therefore all precautionary measures, NOTES, DANGERS, WARNINGS and CAUTIONS contained in this manual and on the machine should be read and understood by all personnel before starting any work with or on the machine.
2. Operation, inspection, and maintenance should be carefully carried out, and safety must be given the first priority. Messages of safety are indicated with marks. The safety information contained in this manual is intended only to supplement safety codes, insurance requirements, local laws, rules and regulations.
3. Messages of safety appear in this manual and on the machine. All messages of safety are identified by the words "DANGER", "WARNING" and "CAUTION".
  - a. **DANGER** – Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury and is represented as follows:

 <b>DANGER</b> 
<ol style="list-style-type: none"><li>b. <b>WARNING</b> – Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury and is represented as follows:</li></ol>

 <b>WARNING</b> 
<ol style="list-style-type: none"><li>c. <b>CAUTION</b> – Indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injury. It may also be used to alert against possible damage to the machine and its components and is represented as follows:</li></ol>

 <b>CAUTION</b> 
<ol style="list-style-type: none"><li>4. It is very difficult to forecast every danger that may occur during operation. However, safety can be ensured by fully understanding proper operating procedures for this machine according to methods recommended by CASE.</li><li>5. While operating the machine, be sure to perform work with great care, so as not to damage the machine, or allow accidents to occur.</li><li>6. Continue studying this manual until all Safety, Operation and Maintenance procedures are completely understood by all persons working with the machine.</li></ol>

 <b>WARNING</b> 
<p>The proper and safe lubrication and maintenance for this machine, recommended by CASE, is outlined in the OPERATOR'S MANUAL for this machine.</p> <p>Improper performance of lubrication or maintenance procedures are dangerous and could result in injury or death. Read and understand the OPERATOR'S MANUAL before performing any lubrication or maintenance.</p>

# SAFETY PRECAUTIONS

## 1.2 SAFETY PRECAUTIONS

The serviceman or mechanic may be unfamiliar with many of the systems on this machine. This makes it important to use caution when performing service work. A knowledge of the system and or components is important before the removal or disassembly of any component.

Because of the size of some of the machine components, the serviceman or mechanic should check the weights noted in this manual. Use proper lifting procedures when removing any components. Weight of components table for CX25 is shown in page 02-1-4 of chapter SPECIFICATIONS in this manual

The following is a list of basic precautions that must always be observed.

1. Read and understand all Warning plates and decals on the machine before Operating, Maintaining or Repairing this machine.
2. Always wear protective glasses and protective shoes when working around machines. In particular, wear protective glasses when using hammers, punches or drifts on any part of the machine or attachments. Use welders gloves, hood/goggles, apron and the protective clothing appropriate to the welding job being performed. Do not wear loose fitting or torn clothing. Remove all rings from fingers, loose jewelry, confine long hair and loose clothing before working on this machinery.
3. Disconnect the battery and hang a "Do Not Operate" tag in the Operator's Compartment. Remove ignition keys
4. If possible, make all repairs with the machine parked on a level, hard surface. Block the machine so it does not roll while working on or under the machine. Hang a "Do Not Operate" tag in the Operator's Compartment.
5. Do not work on any machine that is supported only by lift, jacks or a hoist. Always use blocks or jack stands, capable of supporting the machine, before performing any disassembly.



## WARNING



**Do not operate this machine unless you have read and understand the instructions in the OPERATORS MANUAL. Improper machine operation is dangerous and could result in injury or death.**

6. Relieve all pressure in air, oil or water systems before any lines, fittings or related items are disconnected or removed. Always make sure all raised components are blocked correctly and be alert for possible pressure when disconnecting any device from a system that utilizes pressure
7. Lower the bucket, blade or other attachments to the ground before performing any work on the machine. If this cannot be done, make sure the bucket, blade or other attachment is blocked correctly to prevent it from dropping unexpectedly.
8. Use steps and grab handles when mounting or dismounting a machine. Clean any mud, grease, oil or debris from steps, walkways or work platforms before using. Always face the machine when using steps, ladders and walkways. When it is not possible to use the designed access system, provide ladders, scaffolds, or work platforms to perform safe repair operations.
9. To avoid back injury, use a hoist when lifting components which weigh 23 kg (50 lbs) or more. Make sure all chains, hooks, slings, etc., are in good condition and are the correct capacity. Be sure hooks are positioned correctly. Lifting eyes are not to be side loaded during a lifting operation.
10. To avoid burns, be alert for hot parts on machines which have just been stopped and hot fluids in lines, tubes and components.
11. Be careful when removing cover plates. Gradually back off the last two bolts or nuts located at opposite ends of the cover or device and carefully pry cover loose to relieve any spring or other pressure, before removing the last two bolts or nuts completely.
12. Be careful when removing filler caps, breathers and plugs on the machine. Hold a rag over the cap or plug to prevent being sprayed or splashed by liquids under pressure. The danger is even greater if the machine has just been stopped because fluids can be hot.

## **SAFETY PRECAUTIONS**

---

- 13.** Always use the proper tools that are in good condition and that are suited for the job at hand. Be sure you understand how to use them before performing any service work.
- 14.** Reinstall all fasteners with the same part number. Do not use a lesser quality fastener if replacements are necessary.
- 15.** Repairs which require welding should be performed only with the benefit of the appropriate reference information and by personnel adequately trained and knowledgeable in welding procedures. Determine type of metal being welded and select correct welding procedure and electrodes, rods or wire to provide a weld metal strength equivalent at least to that of the parent metal. Make sure to disconnect battery before any welding procedures are attempted.
- 16.** Do not damage wiring during removal operations. Reinstall the wiring so it is not damaged nor will be damaged in operation of the machine by contacting sharp corners, or by rubbing against some object or hot surface. Do not connect wiring to a line containing fluid.
- 17.** Be sure all protective devices including guards and shields are properly installed and functioning correctly before starting a repair. If a guard or shield must be removed to perform the repair work, use extra caution and replace the guard or shield after repair is complete.
- 18.** The maintenance and repair work while holding the bucket raised is dangerous due to the possibility of a falling attachment. Don't fail to lower the attachment and place the bucket to the ground before starting the work.
- 19.** Loose or damaged fuel, lubricant and hydraulic lines, tubes and hoses can cause fires. Do not bend or strike high pressure lines or install ones which have been bent or damaged. Inspect lines, tubes and hoses carefully. Do not check for leaks with your hands. Very small (pin hole) leaks can result in a high velocity oil stream that will be invisible close to the hose. This oil can penetrate the skin and cause personal injury. Use cardboard, wood or metal to locate pin hole leaks.
- 20.** Tighten connections to the correct torque. Make sure that all heat shields, clamps and guards are installed correctly to avoid excessive heat, vibration or rubbing against other parts during operation. Shields that protect against oil spray onto hot exhaust components in event of a line, tube or seal failure must be installed correctly.
- 21.** Do not operate a machine if any rotating part is damaged or contacts any other part during operation. Any high speed rotating component that has been damaged or altered should be checked for balance before reusing.
- 22.** Be careful when servicing or separating the tracks. Chips can fly when removing or installing a track pin. Wear safety glasses and long sleeve protective clothing. Tracks can unroll very quickly when separated. Keep away from front and rear of machine. The machine can move unexpectedly when both tracks are disengaged from the sprockets. Block the machine to prevent it from moving.

# CASE CX25

*See next page for model cross reference.*

## PRELIMINARY REMARKS

### TABLE OF CONTENTS

1. GENERAL PRECAUTIONS FOR REPAIRS .....	1-1
2. ESCAPING PROCEDURE IN CASE OF EMERGENCY .....	1-4
3. INTERNATIONAL UNIT CONVERSION SYSTEM .....	1-5

**Shop Manual Model Number Cross Reference:  
SK25SR-2 is CASE Model CX25**



# 1. GENERAL PRECAUTIONS FOR REPAIRS



## 1.1 PREPARATION BEFORE DISASSEMBLING

- (1) **Understanding operating procedure**  
Read OPERATION & MAINTENANCE MANUAL carefully to understand the operating procedure.
- (2) **Cleaning machines**  
Remove soil, mud, and dust from the machine before carrying it into the service shop to prevent loss of work efficiency, damage of parts, and difficulty in rust prevention and dust protection while reassembling.
- (3) **Inspecting machines**  
Identify the parts to be disassembled before starting work, determine the disassembling procedure by yourself considering the workshop situations etc., and request procurement of necessary parts in advance.
- (4) **Recording**  
Record the following items for communication and prevention of recurring malfunction.
  - 1) Inspection date and place
  - 2) Model name, applicable machine number, and hour meter read
  - 3) Trouble condition, location and cause.
  - 4) Visible Oil leakage, water leakage and damage
  - 5) Clogging of filters, oil level, oil quality, oil contamination and loosening of connections
  - 6) Result of consideration if any problem exists based on the operation rate per month calculated from hour meter indication after the last inspection date.
- (5) **Arrangement and cleaning in service shop**
  - 1) Tools required for repair work.
  - 2) Prepare space to place the disassembled parts.
  - 3) Prepare oil containers for spilling oil etc.




## 1.2 SAFETY IN DISASSEMBLING AND ASSEMBLING

- 1) Wear appropriate clothes with long sleeves, safety shoes, safety helmet and protective glasses.
- 2) Suspend warning tag "DO NOT OPERATE" from the doorknob or the operating lever, and have a preliminary meeting before starting work.
- 3) Stop the engine before starting inspection and maintenance to prevent the operator being

caught in machine.

- 4) Identify the location of a first-aid kit and a fire extinguisher, and also where to make contact in a state of emergency.
- 5) Choose a hard, level and safe place, and place the attachment on the ground securely.
- 6) Use a lifter such as a crane to remove heavy parts (20 kg [45 lbs] or more) from the machine.
- 7) Use proper tools, and replace or repair defective tools.
- 8) Support the machine and attachment with supports or blocks if the work is performed in the lifted condition.



## 1.3 DISASSEMBLING AND ASSEMBLING HYDRAULIC EQUIPMENT

- (1) **Removing hydraulic equipment**
  - 1) Before disconnecting pipes, release the hydraulic pressure of the system, or open the return side cover and take out the filter.
  - 2) Carefully drain oil of the removed pipes into a containers without spilling on the floor.
  - 3) Apply plugs or caps on the pipe ends to avoid oil spillage and dust intrusion.
  - 4) Clean off the external surface of the equipment before disassembling, and drain hydraulic and gear oil before placing it on the workbench.
- (2) **Disassembling hydraulic equipment**
  - 1) Do not disassemble, reassemble or modify the hydraulic equipment without the permission of the manufacturer, who is not responsible for the performance and function of the product after reassembling.
  - 2) When disassembling and reassembling for unavoidable reason, refer the work to qualified personnel who have the specific knowledge or completed the parts service training.
  - 3) Provide matching marks to facilitate reassembling work.
  - 4) Before starting the work, read the manual of disassembling procedure, if it is provided, and decide whether the work can be performed by yourself.
  - 5) Use the special jig and tools without fail if they are specified.
  - 6) If it is hard to remove a part according to the procedure, do not try it by force but investigate the cause.

- 7) Place the removed parts in order and attach tags to facilitate the reassembling.
- 8) Note the location and quantity of parts commonly applied to multiple locations.

**(3) Inspecting parts**

- 1) Ensure that the disassembled parts are free from seizure, interference and uneven contact.
- 2) Measure and record wear condition of parts and clearance.
- 3) If the problem is found in a part, repair or replace it with a new one.

**(4) Reassembling hydraulic equipment**

- 1) Turn ON the ventilation fan or open windows to maintain good ventilation prior to starting the cleaning of parts.
- 2) Perform rough and finish cleaning before assembling.
- 3) Remove washing oil by air and apply clean hydraulic or gear oil for assembling.
- 4) Always replace the removed O-rings, backup rings and oil seals with new ones by applying grease in advance.
- 5) Remove dirt and moisture from and perform degreasing on the surface where liquid gasket to be applied.
- 6) Remove rust preventive agent from the new parts before use.
- 7) Fit bearings, bushings and oil seals using special jigs.
- 8) Assemble the parts utilizing matching marks.
- 9) Ensure all the parts are completely assembled after the work.

**(5) Installing hydraulic equipment**

- 1) Ensure hydraulic oil and lubricant are properly supplied.
- 2) Perform air releasing when:
  - a. Hydraulic oil changed
  - b. Parts of suction side piping replaced
  - c. Hydraulic pump installed
  - d. Slewing motor installed
  - e. Travel motor installed
  - f. Hydraulic cylinder installed

**⚠** • Operation of the hydraulic equipment without filling hydraulic oil or lubricant or without performing air releasing will result in damage to the equipment.



- 3) Perform air releasing after loosening the upper drain plug, starting the engine and keep it in

low idle condition. Complete the air releasing when seeping of hydraulic oil is recognized, and tightly plug.

- 4) Perform air releasing of the travel motor and the hydraulic cylinders by running the engine for more than 5 minutes at low speed without load.

**⚠** • Do not allow the hydraulic cylinder to bottom on the stroke end just after the maintenance.

- 5) Perform air releasing of pilot line by performing a series of digging, slewing and travel.
- 6) Check hydraulic oil level after placing the attachment to the oil check position, and replenish oil if necessary.



**1.4 ELECTRICAL EQUIPMENT**

- (1) Do not disassemble electrical equipment.
- (2) Handle it carefully not to drop and give a shock.
- (3) Turn the key OFF prior to connecting and disconnecting work.
- (4) Disconnect the connector by holding it and pressing the lock. Do not pull the wire to apply force to the caulking portion.
- (5) Connect the connector and ensure it is completely locked.
- (6) Turn the key OFF prior to touching the terminal of starter or generator.
- (7) Remove the ground (earth) terminal of battery when handling tools around the battery or its relay.
- (8) Do not splash water on the electrical equipment and connectors during machine washing.
- (9) Check for moisture adhesion inside the waterproof connector after pulling it out, since it is hard to remove moisture from the connector. If moisture adhesion is found, dry it completely before the connection.



- Battery electrolyte is hazardous. Battery electrolyte is dilute sulfuric acid. Exposure of skin or eyes to this liquid will cause burning or loss of eyesight. If the exposure occurs, take the following emergency measures and seek the advice of a medical specialist.

- When skin exposed: Wash with water and soap sufficiently.
- When eyes exposed: Immediately wash away with city water continuously for more than 10 minutes.
- When a large amount of the liquid flows out: Neutralize with sodium bicarbonate or wash away with city water.
- When swallowed: Drink a large amount of milk or water.
- When clothes exposed: Immediately undress and wash.



### 1.5 HYDRAULIC PARTS

- 1) O-ring
  - Ensure O-rings have elasticity and are not damaged before use.
  - Use the appropriate O-rings. O-rings are made of various kinds of materials having different hardness to apply to a variety of parts, such as the part for moving or fixed portion, subjected to high pressure, and exposed to corrosive fluid, even if the size is same.
  - Fit the O-rings without distortion and bend.
  - Always handle floating seals as a pair.
- 2) Flexible hose (F hose)
  - Use the appropriate parts. Different parts are used depending on the working pressure even the size of fitting and the total length of the hose is same.
  - Tighten the fitting at the specified torque. Ensure no kink, tension, interference nor oil leakage is recognized.

### 1.6 WELDING REPAIR

- (1) Refer repair welding to qualified personnel according to the appropriate procedure.
- (2) Disconnect the ground (earth) cable of the battery before starting the repair. Failure to do so will cause damage to the electrical equipment.
- (3) Move away the articles in advance that may cause fire if exposed to sparks.

- (4) Before starting the repair of the attachment, do not fail to cover the plated surface of the piston rod with flameproof sheet to prevent it from being exposed to sparks.

### 1.7 ENVIRONMENTAL MEASURE

- (1) Run the engine at the place that is sufficiently ventilated.
- (2) Industrial waste disposal  
Dispose of the following parts according to the relevant regulations:  
Waste oil and waste container  
Battery
- (3) Precautions for handling hydraulic oil  
Exposure of eyes to hydraulic oil will cause inflammation. Wear protective glasses before handling to avoid an accident. If an eye is exposed to the oil, take the following emergency measures:
  - When an eye exposed: Immediately wash away with city water sufficiently till stimulative feeling vanishes.
  - When swallowed: Do not let vomit, and receive medical treatment immediately.
  - When skin exposed: Wash with water and soap sufficiently.
- (4) Others  
Use replacement parts and lubricants

## 2. ESCAPING PROCEDURE IN CASE OF EMERGENCY

### 2.1 WHEN CAB DOOR DOES NOT OPEN ;(CAB spec. only)

- (1) Escape from the front window.
- (2) Escape from skylight.
- (3) When front window and skylight do not open ;  
The life hammer is always reserved on the rear left side of cab. Break the glass on the rear side of cab, and escape from there.

- Break the window glass with care to protect eyes, and don't fail to break the window on which label "Emergency exit" is stuck.

- (4) In addition, the life hammer is equipped with a cutter on the lever side to cut the seat belt, etc.




FIG. 2-1 LIFE HAMMER AND "EMERGENCY EXIT" LABEL

### 2.2 WHEN MACHINE CAN NOT GO OUT FROM THE SOFT GROUND BY ITSELF ;

1. If the machine should become stuck in soft soil areas it may be necessary to tow the machine. Attach a wire rope or chain, with the capacity to pull the machine out, to the lower frame towing eyes.
2. Attach other end to the vehicle used to pull the machine. Operate the Machine's Travel Lever in the proper direction while pulling with the other vehicle.




FIG. 2-2 TOW MACHINE PROPERLY

<b>WARNING</b>	
<ul style="list-style-type: none"><li>• While towing, do not enter between the machine and towing vehicle.</li><li>• Do not apply a shock load onto the towing rope.</li><li>• Make sure to always use towing eyes (shackles) or the towing.</li><li>• Keep the wire rope horizontally, and perpendicularly to the crawler frame.</li><li>• Tow the machine slowly at low speed mode.</li><li>• For the towing of the machine body, provide pads to be applied to the corner of crawler frame to prevent the wire rope and crawler frame from any damages.</li></ul>	

### 3. INTERNATIONAL UNIT CONVERSION SYSTEM


(Based on MARKS' STANDARD HANDBOOK FOR MECHANICAL ENGINEERS)

#### Introduction

Although this manual uses the JIS unit system, if you need SI unit, refer to the following international system of units.

Given hereinafter is an excerpt of the units that are related to this manual :

1. Etymology of SI Units  
French:Le Système International d' Unités  
English:International System of Units
2. Construction of SI Unit System



#### (1)Base Units [ Table 3-1 ]

QUANTITY	UNIT	SYMBOL
Length	metre	m
Mass	kilogram	kg
Time	second	s
Electric current	ampere	A
Thermodynamic temperature	kelvin	K
Amount of substance	mol	mol
Luminous intensity	candela	cd

#### (2)Supplementary Units [ Table 3-2 ]

QUANTITY	UNIT	SYMBOL
Plane angle	radian	rad
Solid angle	steradian	sr

#### (3)Derived Units [ Table 3-3 ]

QUANTITY	UNIT	SYMBOL
Area	square metre	m <sup>2</sup>
Volume	cubic metre	m <sup>3</sup>
Velocity	metre per second	m/s
Acceleration	metre per second squared	m/s <sup>2</sup>
Density	kilogram per cubic metre	kg/m <sup>3</sup>

#### (4)Derived Units bearing Peculiar Designations [ Table 3-4 ]

QUANTITY	UNIT	SYMBOL	FORMULA
Frequency	Hertz	Hz	1/s
Force	Newton	N	kg·m/s <sup>2</sup>
Pressure and Stress	Pascal	Pa	N/m <sup>2</sup>
Energy, Work and Quantity of heat	Joule	J	N·m
Power	Watt	W	J/s
Quantity of electricity	Coulomb	C	A·s
Electric potential difference, Voltage, and Electromotive force	Volt	V	W/A
Quantity of static electricity and Electric capacitance	Farad	F	C / V
Electric resistance	Ohm	Ω	V / A
Celcius temperature	Celcius degree or degree	°C	(t+273.15)K
Illuminance	Lux	lx	lm/m <sup>2</sup>

#### (5)Prefixes of SI [ Table 3-5 ]




PREFIX	SYMBOL	MULTIPLICATION FACTORS
Giga	G	10 <sup>9</sup>
Mega	M	10 <sup>6</sup>
Kilo	k	10 <sup>3</sup>
Hecto	h	10 <sup>2</sup>
Deca	da	10
Deci	d	10 <sup>-1</sup>
Centi	c	10 <sup>-2</sup>
Milli	m	10 <sup>-3</sup>
Micro	μ	10 <sup>-6</sup>
Nano	n	10 <sup>-9</sup>
Pico	p	10 <sup>-12</sup>

#### (6)Unit Conversion [ Table 3-6 ]

QUANTITY	JIS	SI	CONVERSION FACTOR
Weight	kgf	—	
Mass	—	kg	
Force	kgf	N	1 kgf=9.807 N
Torque	kgf·m	N·m	1 kgf·m=9.807 N·m
Pressure	kgf/cm <sup>2</sup>	MPa	1 kgf/cm <sup>2</sup> =0.09807 MPa
Motive power	PS	kW	1 PS=0.7355 kW
Revolution	rpm	min <sup>-1</sup>	r/min *1

\*1 Units that are allowed to use

(7) Unit conversion logarithmic chart



# CASE CX25

PV02

*See next page for model cross reference.*

## SPECIFICATIONS


### TABLE OF CONTENTS

1. COMPONENTS NAME .....	1-1
2. MACHINE DIMENSIONS .....	1-2
3. SPECIFICATIONS AND PERFORMANCE .....	1-3
4. MACHINE & COMPONENTS WEIGHT (DRY) .....	1-4
5. TRANSPORTATION .....	1-5
6. TYPE OF CRAWLER SHOES .....	1-7
7. TYPE OF BUCKET .....	1-7
8. THE MACHINE LIFTING PROCEDURES .....	1-8
9. WORKING RANGES .....	1-9
10. LIFTING CAPACITIES .....	1-10
11. ENGINE SPECIFICATIONS .....	1-12

**Shop Manual Model Number Cross Reference:  
SK25SR-2 is CASE Model CX25**




# 1. COMPONENTS NAME




## 2. MACHINE DIMENSIONS

### ■ SK25SR-2 [EU] & [OCEANIA] Model

Unit : mm (ft-in)



### ■ SK25SR-2 [KAI] Model



### 3. SPECIFICATIONS AND PERFORMANCE

#### ■ SPEED AND GRADEABILITY

Model	SK25SR-2 (with Rubber Shoe)		
Serial No	PV08-20001~		
Item			
Slewing Speed	min <sup>-1</sup> {rpm}	9.4 {9.4}	
Travel Speed	km/h (mph)	Low (1st.)	High (2nd.)
		2.5 (1.6)	4.3 (2.7)
Gradeability	%(degree)	58(30)	

#### ■ ENGINE

Model (YANMAR)	3TNE74-NYBB		
Type	Vertical,4-cycle,water cooled diesel engine		
Number of cylinders-Bore X Stroke	3-ø74mm X 78mm		
Total Displacement	L	1.01	
Rated Output	kW/min <sup>-1</sup> {PS/rpm}	13.2/2,400 {18.0/2,400}	
Maximum Torque	N·m/min <sup>-1</sup> {kgf·m/rpm}	60.8/1,700 {6.2/1,700}	
Starter	V X kW	12 X 1.0	
Generator (Dynamo)	V X A	12 X 20	

#### ■ HYDRAULIC COMPONENTS

Hydraulic Pump	Variable displacement axial piston gearpump		
Slewing Motor	Axial piston		
Travel Motor	Axial piston 2 speed motor		
Control Valve	with 10 spools		
Cylinder	( Boom,Arm,Swing Bucket,Dozer )	Double acting cylinder	
Return filter	Paper filter with safety valve (30μ)		

#### ■ OFFSET DIGGING · DOZER

Mechanism	Boom swing operation by cylinder stroke		
Boom swing angle	degree	Right	58
		Left	82 (Cab spec : 65)
Strokes of dozer (Up / Down)	mm	320/330 (12.6 /13.0)	

Unit:kg (lb)

#### ■ WEIGHT

	EU & OCEANIA	KAI
Machine Weight	Rubber shoe	←
	2,410 (5310)	2,440 (5380)
Upper slewing body	1,160 (2560)	1,190 (2620)
Travel system	930 (2050)	←
Attachment (Boom+STD Arm+STD Bucket)	260 (570)	←
Oil & Water	60 (130)	←

Note : This figure is calculated with Japanese standard bucket.  
Bucket weight 47 kg (104 lb)

#### 4. MACHINE&COMPONENTS WEIGHT (DRY)

Unit : kg(lb)

Item	Model	EU & OCEANIA		KAI	
	Specification	Rubber shoe		Rubber Shoe	
		Canopy	Cab	Canopy	Cab
Complete Machine		2,410(5310)	2,520(5560)	2,440(5380)	2,560(5650)
1. Upper Structure (Assy of followings)		1,160(2560)	1,270(2800)	1,190(2620)	1,310(2890)
1.1 Upper frame		240(530)	←	←	←
1.2 Canopy/Cab		70(154)	180(400)	100(243)	220(530)
1.3 Engine		100(220)	←	←	←
1.4 Hydraulic pump		18(40)	←	←	←
1.5 Radiator		5(11)	←	←	←
1.6 Hydraulic tank		24(53)	←	←	←
1.7 Fuel tank		4(9)	←	←	←
1.8 Swing bracket		46(101)	←	←	←
1.9 Swing cylinder		23(51)	←	←	←
1.10 Slewing motor (with reduction)		32(71)	←	←	←
1.11 Control valve		25(55)	←	←	←
1.12 Counter weight		310(680)	←	←	←
1.13 Guard · Bonnet		73(160)	←	←	←
1.14 Boom cylinder		24(53)	←	←	←
2. Undercarriage (Assy of followings)		930(2050)	←	1,040(2290)	←
2.1 Lower frame		380(840)	←	←	←
2.2 Slewing bearing		37(82)	←	←	←
2.3 Travel motor (with reduction)		25X2(55X2)	←	←	←
2.4 Upper roller		—	—	—	—
2.5 Lower roller		6X8(13X8)	←	←	←
2.6 Front idler		17X2(37X2)	←	←	←
2.7 Idler adjuster		11X2(24X2)	←	←	←
2.8 Sprocket		5X2(11X2)	←	←	←
2.9 Rubber crawler (250mm width)		85X2(187X2)	←	←	←
2.10 Tracklink (250mm width iron shoe)		—	—	—	—
2.11 Swivel joint		11(24)	←	←	←
2.12 Dozer		112(250)	←	←	←
2.13 Dozer cylinder		18(40)	←	←	←
3. Attachment(Assy of followings)		260(570)	←	←	←
3.1 Boom assy		143(315)	←	←	←
3.1.1 Boom		82(180)	←	←	←
3.1.2 Arm cylinder		24(53)	←	←	←
3.2 Arm assy		70(150)	←	←	←
3.2.1 Arm		39(86)	←	←	←
3.2.2 Bucket cylinder		11(24)	←	←	←
3.2.3 Bucket Link		6(13)	←	←	←
3.2.4 Idler Link		4(9)	←	←	←
3.3 Bucket assy(0.08m <sup>3</sup> )		47(104)	←	←	←
4. Fluid,Water (Assy of followings)		60(132)	←	←	←
4.1 Hydraulic oil		36(79)	←	←	←
4.2 Fuel		21(46)	←	←	←
4.2 Water		3(7)	←	←	←

Note : (1) In case of iron crawlers, add 120kg (265 lb) to the weight of complete machine.

(2) Bucket weight is shown with Japanese standard bucket weight.

## 5. TRANSPORTATION

### ■ LOADING MACHINE ON A TRAILER

1. Keep trailer bed clean. Put chocks against truck wheels.
2. Use a ramp or loading dock. Ramps must be strong enough, have a low angle, and correct height. Load and unload machine on a level surface.
3. Travel machine onto ramps slowly. Center the machine over the trailer.
4. Lower all attachment.
5. Stop engine. Remove key from switch.

**⚠ Do not put chains over or against hydraulic lines or hoses.**

6. Fasten machine to trailer with chains or cables.


During transportation, the bucket or attachments may hit the canopy or the cab. Therefore, set the machine in the transporting position by observing following points:

1. Extend the bucket cylinder fully.
2. Extend the arm cylinder fully.
3. Lower the boom.
4. If machine cannot be transported with arm cylinder fully extended, remove bucket or attachment and extend arm cylinder.

### (2) Transportation Dimension and Weight of Attachment


#### (1) Boom

Length X Height X Width mm (ft-in)	2300X650X215 (7'7" X 2'2" X 8.5")
Weight kg (lb)	120 (265)




#### (2) 1,15m Arm and 0.08m<sup>3</sup> Bucket (Japanese standard bucket)

Length X Height X Width mm (ft-in)	2070X395X495 (6'10" X 1'4" X 1.7")
Weight kg (lb)	120 (265)




(3) Arm

Length X Height X Width mm (ft-in)	1470X320X210 (4'10" X 1'1" X 8.3")
Weight kg (lb)	70 (150)




(4) Bucket (Japanese standard bucket)

Bucket capacity m <sup>3</sup> (cu-yd) (SAE heaped)	0.08 (0.1)
Length X Height X Width mm (ft-in)	635X530X495 (2'1" X 1'9" X 1'7")
Weight kg (lb)	47 (104)





(5) Dozer

Length X Height X Width mm (ft-in)	1020X285X1500 (3'4" X 11.2" X 4'11")
Weight kg (lb)	112 (250)




## 6. TYPE OF CRAWLER SHOES

Type	Model	Shoe width mm (in)	Total Crawler width mm (ft·in)	Number of link	Ground pressure kgf/cm <sup>2</sup> (psi)
Rubber shoe 	SK25SR-2	250 (10)	1500 (4'11")	76	0.30 (4.3)
Iron shoe(option) 	SK25SR-2	250 (10)	1500(4'11")	39	0.31 (4.4)

## 7. TYPE OF BUCKET

(Japanese standard bucket)

Type	Model	Heaped capacity m <sup>3</sup> (cu.yd)	Outer width mm(in)		Number of tooth	Weight kg(lb)	Remarks
			with side cutter	without side cutter			
Back hoe bucket 	SK25SR-2	0.08(0.1)	500 (20)	—	3	47 (104)	Standard size

## 8. MACHINE LIFTING PROCEDURE

### ■ LIFTING PROCEDURES FOR THE MACHINE COMPLETE

! WARNING !

- The wire ropes to be used for lifting the machine should have sufficient strength against the machine weight.
- Improper lifting method and / or rope rigging manner might cause for a movement or slip of the machine while it is being lifted, resulting serious injury or damages to the machine.
- Do not impose a load suddenly on the wire ropes and slings.
- When the lifting work is carried out in cooperation with multiple persons, make sure to check every situation by exchanging signals with each other.
- During the lifting work, keep any persons away from the lifted machine, especially under the machine.


Carry out the lifting work on a level ground.

- [1] Manipulate each operating lever to take the machine to a position as shown in the figure.
- [2] Operate the boom swing pedal to face the boom directly in front, and raise the dozer blade.
- [3] Stop the engine, and set the safety lock lever to "LOCKED" position. Then get off the machine after ensuring for no abnormalities around the operator's seat.
- [4] Install shackles to both bores (C) provided at both ends to the dozer blade, and put the wire ropes on them.
- [5] Put the wire ropes on the (D) portion of the boom.
- [6] If any portions of the wire ropes directly touch the machine when the wire ropes are lifted, protect the machine from damage by means of applying a wooden piece or rag between them.
- [7] Slightly lift the machine to confirm the balance, then lift up the machine.

**EU** & **OCEANIA** Model

Weight : 2,410 kg  
(5,310 lb)


Unit : mm



**KAI** Model

Weight : 2,440 kg  
(5,380 lb)

Unit : mm




Note : This figure is calculated with Japanese standard bucket.

Bucket weight 47 kg (104 lb)



## 9. WORKING RANGES



Unit : mm (ft-in)

Code	Item	Model	SK25SR-2
	Arm length		1.15m (3'9")
	Bucket capacity		0.08m <sup>3</sup> (0.1 cu-yd)
A	Max. digging reach		4,640 (15'2.7")
A'	Max. digging reach at ground level		4540 (14'10.7")
B	Max. digging depth		2,560 (8'4.8")
C	Max. digging height		4,170 (13'8.2")
D	Max. dumping clearance		2,940 (9'7.8")
E	Min. dumping clearance		1,090 (3'6.9")
F	Max. vertical wall digging depth		2,420 (7'11.3")
G	Min. front slew radius		1,960 (6'5.2")
H	Height at min. slew radius		3,160 (10'4.4")
J	8-foot level digging depth		2,020 (6'7.5")
K	Horizontal digging stroke at ground level	Stroke	2,040 (6'8.3")
		Minimum	1520 (4'11.8")
X,Y	Dozer strokes	Up/ Down	320/330 (1'06"/1'1")

Note : Japanese domestic specification

## 10. LIFTING CAPACITIES

### (1) Conditions of calculation

- 1) The lifting load shows the lower value either 87% of lifting capacity by hydraulic pressure, or 75% of tipping load.
- 2) The load point is on the bucket lift point, and the bucket cylinder is extended (bucket IN).
- 3) Weight of hooks, slings, and all other lifting equipment shall be considered a part of the load.
- 4) The values in the upper rows show the lifting capacity at a machine facing sideways, and values in the lower rows show a machine facing longitudinally.
- 5) Unit : ton,  
Crawler : 250mm (10 in), Rubber crawler shoe.
- 6) Set hydraulic pressure 230 kgf / cm<sup>2</sup> (3270 psi)

### (2) Lifting conditions

Machine : SK25SR-2 EU


Arm length : 1.15m(3'9")

Dozer blade : Up position

With Japanese standard bucket.











Bucket weight 47 kg (104 lb)


Bucket capacity : 0.08m<sup>3</sup> (0.1cu-yd)



### SK25SR LIFTING CAPACITIES

Based on machine equipped with  
 Arm 1150mm (3'9" ) arm  
 Shoe 250mm (9.8" ) Rubber Shoe  
 Dozer blade down  
 With Japanese standard bucket  
 Bucket weight 47 kg (104 lb)

A	B	LOAD RADIUS									
											
	lb										
	kg										
10' (3.0m)	lb					* 960	* 960				
	kg					* 430	* 430				
7.5' (2.3m)	lb					* 990	* 990				
	kg					* 450	* 450				
5' (1.5m)	lb	* 3070	* 3070	* 1560	1530	* 1170	* 960	* 1010	660		
	kg	* 1390	* 1390	* 710	690	* 530	* 430	* 450	300		
2.5' (0.8m)	lb			* 2130	1410	* 1390	* 910	* 1080	640		
	kg			* 960	630	* 630	* 410	* 490	290		
GROUND LEVEL	lb	* 1950	* 1950	* 2340	1340	* 1510	* 870	* 1100	620		
	kg	* 880	* 880	* 1060	610	* 680	* 390	* 500	280		
-2.5' (-0.8m)	lb	* 3360	* 2740	* 2190	1340	* 1460	* 860				
	kg	* 1520	* 1240	* 990	600	* 660	* 390				
-5' (-1.5m)	lb	* 2760	* 2760	* 1720	1360						
	kg	* 1250	* 1250	* 780	610						



- Do not attempt to lift or hold any load that is greater than these rated values at their specified load radius and height. Weight of all accessories must be deducted from the above lifting capacities.
- Lifting capacities are based on machine standing on level, firm, and uniform ground. User must make allowance for job conditions such as soft or uneven ground out of level conditions, side loads, sudden stopping of loads, hazardous conditions, experience of personnel, etc.
- Ratings bucket lift hook.
- The above rated loads are in compliance with BS1757:1986. They do not exceed 87% of hydraulic lifting capacity or 75% of tipping load. Rated loads marked with an asterisk (\*) are limited by hydraulic capacity rather than tipping load.
- Operator should be fully acquainted with the operator's and Maintenance Instructions before operating this machine and rules for safe operation of equipment should be adhered to at all times.
- Capacities apply to only machine as originally manufactured and normally equipped by KOBELCO CONSTRUCTION MACHINERY CO.,LTD

Machine : SK25SR-2 **OCEANIA**


Arm length : 1.15 m (3'9")

Dozer blade : Up position

With Japanese standard bucket.

Bucket weight 47 kg (104 lb)

Bucket capacity : 0.08m<sup>3</sup> (0.1cu-yd)



## 11. ENGINE SPECIFICATIONS

### 11.1 SPECIFICATIONS


Model	SK25SR-2			
Applicable machine	PV08-20001~			
Engine Model	3TNE74-NYBB			
Type	Vertical, 4-cycle water-cooled diesel engine			
No. of cylinders - BoreXStroke	mmXmm	3- $\phi$ 74 X 78		
Total displacement	L	1.01		
Compression ratio	23.5			
Rated output	kW/min <sup>-1</sup> {PS/rpm}	13.2 <sup>+3%</sup> / 2400 {18 <sup>+3%</sup> /2400}		
Maximum torque	N·m/min <sup>-1</sup> {kgf·m/rpm}	60.8~65.7 / 1700 {6.2~6.7 / 1700}		
Low idling	min <sup>-1</sup> {rpm}	1350 <sup>+50</sup> {1350 <sup>+50</sup> }		
High idling	min <sup>-1</sup> {rpm}	2620 $\pm$ 25 {2620 $\pm$ 25}		
Fuel consumption rate	g/kW·h {g/ps·h}	279 {205} or less		
Allowable tilting angles	Back and forth, left and right 25° (momentary 30°)			
Rotating direction	Counterclockwise as seen from flywheel side			
Firing order	1-3-2			
Fuel injection timing (b.T.D.C.)	degree (°)	14 $\pm$ 1		
Fuel injection pressure	MPa {kgf/cm <sup>2</sup> }	11.8 <sup>+1</sup> {120 <sup>+10</sup> }		
Valve action	degree (°)		Open	Close
		Intake valve	b.T.D.C 12 $\pm$ 5	a.B.D.C 40 $\pm$ 5
		Exhaust valve	b.T.D.C 45 $\pm$ 5	a.B.D.C 13 $\pm$ 5
Valve clearance	Intake valve	0.2 mm (0.008 in) in cold condition		
	Exhaust valve	0.2 mm (0.008 in) in cold condition		
Thermostat action	Start/ Full open	°C		
Compression pressure	MPa {kgf/cm <sup>2</sup> }	at min <sup>-1</sup> {rpm}		
Lubrication oil pressure	MPa {kgf/cm <sup>2</sup> }	at min <sup>-1</sup> {rpm}		
Dimensions L X W X H	mm	507 X 480 X 574		
Dry weight	kg	100 <sup>+10</sup>		
Governor	Mechanical centrifugal governor (All speed type)			
Fuel filtration	Full flow,Paper filter			
Lubrication system	Forced lubrication with trochoid pump			
Engine oil filtration	Full flow,Paper filter cartridge			
Cooling system	Liquid cooling / Radiator, Plastic 5 bladed,OD : $\phi$ 310 (Discharge type) crank pully / Fan Pully : $\phi$ 110 / $\phi$ 85			
Starter capacity	V X kW	12 X 1.0		
Generator capacity (Dynamo)	V X A	12 X 20		
Starting aid	Glow plug (pre-heat:3sec)			
Cooling water capacity : Max / Engine	L	2.7 / 1.1		
Engine oil volume : Max / Effective	L	3.5 / 2.0		

## 11.2 ENGINE PERFORMANCE CURVE

### ■ SK25SR-2

Model : 3TNE74-NYBB

Rated Output : 13.2kW / 2400min<sup>-1</sup>{18.0PS/2400rpm}



$$\text{Fuel consumption volume} = \frac{F}{\rho \times 1000} \times P \times \alpha$$

$$= \frac{279}{0.835 \times 1000} \times 13.2 \times \alpha$$

$$= 4.41 \alpha$$

F : Fuel consumption rate(g/PS·h)

P : Shaft output (PS)

$\rho$  : Specific gravity

$\alpha$  : Standard load factor (0.60~0.70)

Fuel consumption in normal operation;  
2.65~3.09 ℓ/h (load factor : (0.60~0.70))

# CASE CX25

*See next page for model cross reference.*

**PV03**

## ATTACHMENT DIMENSIONS

### TABLE OF CONTENTS

1. BOOM	
1.1 Boom dimension .....	1-1
1.2 Boom maintenance standards .....	1-2
2. ARM	
2.1 Arm dimension .....	1-4
2.2 Arm maintenance standards .....	1-5
3. BUCKET	
3.1 Bucket dimension .....	1-7
3.2 Detail dimensional drawings of lug section .....	1-8
3.3 Detail dimensional drawings of boss section .....	1-9
4. DOZER	
4.1 Dozer dimension .....	1-10
4.2 Dozer maintenance standards .....	1-11
5. SWING	
5.1 Swing bracket dimension .....	1-12
5.2 Swing maintenance standards .....	1-13

**Shop Manual Model Number Cross Reference:  
SK25SR-2 is CASE Model CX25**



# 1. BOOM

## 1.1 BOOM DIMENSION




Fig. 1-1 Boom dimension

Table 1-1

Unit : mm (ft-in)

Code	Item	DIMENSIONS
A	Boom length	2.210 (7'3.01")
B	Distance between pins of boss	R1020 (3'4.16")
C	Distance between pins of bracket	R1064 (3'5.89")
D	Height of boom cylinder rod pin	230.5 (9'07")
E	Height of arm cylinder (head side) pin	563.5 (1'10.19")
F	Boom foot width	160 (6'30")
G	Bracket inner width for boom cylinder (rod side)	61 (2'40")
H	Boom end inner width	125 (4'92")
J	Boom end outer width	195 (7'68")
K	Bracket inner width for arm cylinder (head side)	56 (220")
d1	Boom foot pin dia.(O.D of bushing)	Ø40 (1'57") OD : Ø50 (1'9")
d2	Boom cylinder (rod side) pin dia.	Ø40 (1'57")
d3	Pin dia. of arm end	Ø40 (1'57")
d4	Arm cylinder (head side) pin dia.	Ø40 (1'57")

## 1.2 BOOM MAINTENANCE STANDARDS

### (1) Clearance of pin and bushing




Fig. 1-2 Clearance of pin and bushing

Table 1-2

Unit : mm (in)

Pos.	Item	Pin parts No.	Standard dimensions			Clearance			Remedy
			Pin dia.	Tolerance on pin dia.	Tolerance on bushing bore dia.	Standard value	Repairable level	Service limit	
A	Boom foot	PM02B01275P1	Ø40 (1.575)	-0.020	+0.062	+0.112	0.7 (0.028)	1.0 (0.039)	Replace bushing or pin
				-0.050	+0.010	+0.030			
				(-0.0008)	(+0.0024)	(+0.0044)			
				(-0.0020)	(+0.0004)	(+0.0012)			
B	Boom cylinder (Head side)	PV02B01230P2		-0.020	-0.180	+0.130			
C	Boom cylinder (Rod side)	PV02B01222P2		-0.080	+0.050	+0.020			
				(-0.0008)	(-0.0071)	(+0.0051)			
				(-0.0020)	(+0.0020)	(+0.0008)			
D	Arm cylinder (Head side)	PV02B01221P2							

(Note) • The tolerance for bushing inside diameter means the dimension after fitting of it into the place.

• The part number for pins may be changed owing to improvement, use them only for reference.

(2) Clearance in thrust direction on boom and cylinder installation section




Fig. 1-3 Clearance in thrust direction on boom

Table 1-3

Unit : mm (in)

Pos.	Item		Standard dimensions		Clearance X adjusted by shim (total of both sides)			Pin length		Remedy
			Code	Dimensions	Standard value	Repairable level	Service limit	Code	Dimensions	
A-A	Boom foot	Boom	L1	$160_{-0.4}^{-0.2}$ (6.30 $_{-0.016}^{-0.008}$ )	0.2~0.9 (0.008~0.035)	See "NOTE"	Ø1	263 (10.35)	Adjusted by shim	
		Swing bracket		$160_{+0.5}^{0}$ (6.30 $_{+0.020}^{+0.039}$ )						
B-B	Boom cylinder (Head side)	Head side	L2	$85_{-1.0}^0$ (3.35 $_{-0.039}^0$ )	0.1~0.5 (0.004~0.020)	1.0	1.5	Ø2		202 (7.95)
		Swing bracket		$86_{+1}^0$ (3.39 $_{+0.039}^{+0.039}$ )						
C-C	Boom cylinder (Rod side)	Rod side	L3	$60_{-0.5}^0$ (2.36 $_{-0.020}^0$ )	0.5~0.9 (0.020~0.035)	1.0	1.5	Ø3		151 (5.94)
		Boom		$61_{+1}^0$ (2.40 $_{+0.039}^{+0.039}$ )						
D-D	Arm cylinder (Head side)	Head side	L4	$55_{-0.5}^0$ (2.17 $_{-0.039}^0$ )	0.1~0.5 (0.004~0.020)	1.0	1.5	Ø4		143 (5.63)
		Boom		$56_{+1}^0$ (2.20 $_{+0.039}^{+0.039}$ )						

(Note) • Clearance "X" shall be adjusted with shims, if clearance exceeds the standard value.

## 2. ARM

### 2.1 ARM DIMENSION




Fig. 2-1 Arm dimension

Table 2-1

Unit : mm (ft-in)

Code	Item	Dimensions	Code	Item	Dimensions
A	Arm length	1150	M	Link dimension (Idler)	240 (9.45")
B	Distance between pins of boss and bracket	R276 (10.87")	N	Link dimension (Bucket link)	230 (9.06")
C	Distance between pins of boss and bracket	R854 (2'9.62")	D1	I.D. of boss	ø45 (1.77")
D	Distance between of boss and boss	R180 (7.09")	D2	I.D. of boss	ø45 (1.77")
E	Height between pins of boss and bracket	234 (9.21")	D3	I.D. of boss	ø50 (1.97")
F	Height between pins of boss and bracket	129.5 (5.10")	d1	Pin dia.	ø35 (1.38")
G	Height between pins of boss and center	8 (0.31")	d2	Pin dia.	ø35 (1.38")
H	Boss width	122 (4.80")	d3	Pin dia.	ø40 (1.57")
J	Boss width	125 (4.92")	d4	Pin dia.	ø35 (1.38")
K	Bracket inner width	46 (1.81")	d5	Pin dia.	ø40(1.57")
L	Bracket inner width	56(2.20")			

## 2.2 ARM MAINTENANCE STANDARDS

### (1) Clearance of pin and bushing




Fig. 2-2 Clearance of pin and bushing

Table 2-2

Unit : mm(in)

Pos	Item	Pin parts No.	Standard dimensions			Clearance			Remedy
			Pin dia.	Tolerance on pin dia.	Tolerance on bushing	Standard value	Repairable level	Service limit	
A	Arm point (Connected part of bucket)	PM12B01292P1	ø35 (1.378)	-0.020 -0.050 (-0.0008) (-0.0020)	+0.069 +0.020 (+0.0027) (+0.0008)	0.119 0.040 (0.0047) (0.0016)	0.7 (0.028)	1.0 (0.039)	Replace bushing or pin
B	Bucket link (Bucket side)								
C	Idler link (Connected part of arm)								
D	Bucket link (Idler link side)								
D'	Bucket cylinder (Rod side)								
E	Bucket cylinder (Head side)								
F	Arm foot (Connected part of boom)	PM12B01278P1							
G	Arm cylinder (Rod side)								

(Note) • The tolerance for bushing inside diameter means the dimension after fitting of it into the place.  
 • The part number for pins may be changed owing to improvement, use them only for reference.

(2) Clearance in thrust direction on arm and cylinder installation section




Fig. 2-3 Clearance in thrust direction

\* Total clearance of both sides to be 0.1 ~ 0.5 mm (0.004" ~ 0.020") or less after adjusting by shims.

Table 2-2

Unit : mm (in)

Pos.	Item		Standard dimensions		Clearance X adjusted by shim (total of both sides)			Pin length		Remedy
			Code	Dimensions	Standard value	Repairable level	Service limit	Code	Dimensions	
A-A	Arm point	Arm	L1	122 (4.803)	Less than 0.5 (0.020)			Q1	247 (9.72)	Adjusted by shim
		Bucket		$122^{+0.1}_{+0.5}$ ( $4.803^{+0.039}_{-0.020}$ )						
B-B	Bucket link	Link side	L2	$122^{+0.2}_{-0.4}$ ( $4.803^{+0.008}_{-0.016}$ )	Less than 2.5 (0.098)	1.5 (0.059)	2.0 (0.079)	Q2	247 (9.72)	
		Bucket		$123^{+0.9}_{-0.5}$ ( $4.843^{+0.035}_{-0.020}$ )						
C-C	Idler link (Connected part of arm)	Arm	L3	122 (4.803)	0.1~0.5 (0.004~0.020)	—		Q3	171 (6.73)	
		Link side		—						
D-D	Bucket link (Rod side)	Rod side	L4	$40^{+0}_{-0.5}$ ( $1.575^{+0}_{-0.020}$ )	0.6~1.0 (0.024~0.039)	1.5 (0.059)	2.0 (0.079)	Q5	171 (6.73)	
		Link side		42 (1.654)						
	Bucket link (Idler link side)	Bucket link	L5	$122^{+0.2}_{-0.4}$ ( $4.803^{+0.008}_{-0.016}$ )	0.1~0.5 (0.004~0.020)	—				
		Idler link		—						
E-E	Bucket/cylinder (Head side)	Head side	L6	$45^{+0}_{-0.5}$ ( $1.772^{+0}_{-0.020}$ )	0.5~0.9 (0.020~0.035)	1.0 (0.039)	1.5 (0.059)	Q6	134 (5.28)	
		Arm		$46^{+1}_{+0}$ ( $1.811^{+0.039}_{+0}$ )						
F-F	Arm foot	Arm	L7	125 (4.921)	Less than 0.5 (0.020)			Q7	195 (7.68)	
		Boom		$125^{+0.5}_{+0}$ ( $4.921^{+0.020}_{+0}$ )						
G-G	Arm cylinder (Rod side)	Rod side	L8	$55^{+0}_{-0.5}$ ( $2.165^{+0}_{-0.020}$ )	0.5~0.9 (0.020~0.035)	1.0 (0.039)	1.5 (0.059)	Q8	132 (5.20)	
		Arm		$56^{+1}_{+0}$ ( $2.165^{+0.039}_{+0}$ )						

(Note) • Clearance "X" shall be adjusted by shims, if clearance exceeds the standard value for repair.

### 3. BUCKET

#### 3.1 BUCKET DIMENSION




Fig. 3-1 Bucket dimension

Table 3-1

Unit : mm (ft-in)

Code	Name	Heaped Capacity m <sup>3</sup> (cu.yd)	0.064 (0.054) Standard capacity
A	Distance between pin and bracket		R180 (7.09')
B	Distance between bucket pin and tooth end		R626 (2'.0.65')
C	Inner width of bucket top end		438 (1'.5.24')
D	Inner width of lug		165 (6.50')
E	Inner width of bracket		123 (4.84')
F	Outer width of side cutter		494 (1'.7.45')
G	Outer width of bucket bottom		401 (1'.3.79')
H	Outer tooth distance		389 (1'.3.32')
I	Pitch between teeth		194.5 (7.66')
d1	Pin dia.		ø35 (1.38')
d2	Pin dia.		ø35 (1.38')

Note : Japanese standard bucket.

### 3.2 DETAIL DIMENSION OF LUG SECTION




Fig. 3-2 Dimension of lug section

Table 3-2

Unit : mm (in)

Portion	Pin bore dia.	Lug plate thickness	Bushing length.	Bore.	Spring pin dia.	Plate outer dia.	Thread size.	Plate thickness.	Boss outer dia.	Boss thickness.	Screw hole P.C.D.
Code	$\phi A$	B	C	$\phi D$	$\phi E$	$\phi F$	G	H	$\phi J$	$\phi A$	$\phi N$
Dimension	$35^{+0.10}_0$ (1.38 <sup>+0.004</sup> )	12 (0.472)	38 (1.496)	45 (1.772)	8 (0.315)	80 (3.150)	M10	9 (0.354)	77 (3.031)	21 (0.827)	65 (2.559)

Note : Japanese standard bucket.



This as a preview PDF file from [best-manuals.com](http://best-manuals.com)



Download full PDF manual at [best-manuals.com](http://best-manuals.com)