

Shop Manual

HYDRAULIC
EXCAVATOR

PC800 -8E0

PC800LC-8E0

PC800SE-8E0

PC850 -8E0

PC850SE-8E0

SERIAL NUMBERS

PC800- 65001

PC800LC- 65001

PC800SE- 65001

PC850- 65001

PC850SE- 65001

and up

ecot3

KOMATSU

Notice of revision

6th revision

2017/07

The affected pages are indicated by the use of the following marks. It is requested that necessary actions must be taken to these pages according to the list below.

Mark	Indication	Action required
○	Page to be newly added	Add
●	Page to be replaced	Replace
()	Page to be deleted	Discard

List of revised pages

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
●	1	(06)		00-34			01-21			10-34	
	2	(05)		00-35			01-22			10-35	
●	3	(06)		00-36			01-23			10-36	
	4	(01)		00-37			01-24			10-37	
	5	(01)		00-38			01-25			10-38	
●	6	(06)		00-39			01-26			10-39	
●	7	(06)		00-40			01-27			10-40	
	8	(01)		00-41			01-28			10-41	
	00-1			00-42			10-1			10-42	
	00-2	(01)		00-43			10-2			10-43	
	00-3			00-44			10-3			10-44	
	00-4			00-45			10-4			10-45	
	00-5			00-46			10-5			10-46	
	00-6			00-47			10-6			10-47	
	00-7			00-48			10-7			10-48	
	00-8			00-49			10-8			10-49	
	00-9			00-50			10-9			10-50	
	00-10			00-51			10-10			10-51	
	00-11			00-52			10-11	(05)		10-52	
	00-12	(03)		00-53			10-12			10-53	
	00-13	(03)		00-54			10-13			10-54	
	00-14	(03)		01-1			10-14			10-55	
	00-15	(03)		01-2			10-15			10-56	
	00-16	(03)		01-3			10-16			10-57	
	00-17			01-4			10-17			10-58	
	00-18			01-5			10-18			10-59	
	00-19			01-6			10-19			10-60	
	00-20			01-7			10-20			10-61	
	00-21			01-8			10-21			10-62	
	00-22			01-9			10-22			10-63	
	00-23			01-10			10-23			10-64	
	00-24			01-11			10-24			10-65	
	00-25			01-12			10-25			10-66	
	00-26			01-13			10-26			10-67	
	00-27			01-14			10-27			10-68	
	00-28			01-15			10-28			10-69	
	00-29			01-16			10-29			10-70	
	00-30			01-17			10-30			10-71	
	00-31			01-18			10-31			10-72	
	00-32			01-19			10-32			10-73	
	00-33			01-20			10-33			10-74	

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
	10-75			10-127			10-179			30-19	
	10-76	(01)		10-128			10-180			30-20	
	10-77			10-129			10-181			30-21	
	10-78			10-130			10-182			30-22	
	10-79			10-131			10-183			30-23	
	10-80			10-132			10-184			30-24	
	10-81			10-133			10-185			30-25	
	10-82			10-134			10-186			30-26	
	10-83			10-135			10-187			30-27	
	10-84			10-136			10-188			30-28	
	10-85			10-137			10-189			30-29	(04)
	10-86			10-138			10-190			30-30	
	10-87			10-139			10-191			30-31	
	10-88			10-140			10-192			30-32	
	10-89			10-141			10-193			30-33	
	10-90			10-142			10-194			30-34	
	10-91			10-143			10-195			30-35	
	10-92			10-144			10-196			30-36	
	10-93			10-145			20-1			30-37	
	10-94			10-146			20-2			30-38	
	10-95			10-147			20-3			30-39	
	10-96			10-148			20-4			30-40	
	10-97			10-149			20-5			30-41	
	10-98			10-150			20-6			30-42	
	10-99			10-151			20-7			30-43	
	10-100			10-152			20-8			30-44	
	10-101			10-153			20-9			30-45	
	10-102			10-154			20-10			30-46	
	10-103			10-155			20-11			30-47	
	10-104			10-156			20-12			30-48	
	10-105			10-157			20-13			30-49	
	10-106			10-158			20-14			30-50	
	10-107			10-159			20-15			30-51	
	10-108			10-160			20-16			30-52	
	10-109			10-161			30-1			30-53	
	10-110			10-162			30-2			30-54	
	10-111			10-163			30-3			30-55	
	10-112			10-164			30-4			30-56	
	10-113			10-165			30-5			30-57	
	10-114			10-166			30-6			30-58	
	10-115			10-167			30-7			30-59	
	10-116			10-168			30-8			30-60	
	10-117			10-169			30-9			30-61	
	10-118			10-170			30-10			30-62	
	10-119			10-171			30-11			30-63	
	10-120			10-172			30-12			30-64	
	10-121			10-173			30-13			30-65	
	10-122			10-174			30-14			30-66	
	10-123			10-175			30-15			30-67	
	10-124			10-176			30-16			30-68	
	10-125			10-177			30-17			30-69	
	10-126			10-178			30-18			30-70	

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
	30-71			30-123			40-45			40-97	
	30-72	(05)		30-124			40-46			40-98	
	30-73			30-125			40-47			40-99	
	30-74			30-126			40-48			40-100	
	30-75			30-127			40-49			40-101	
	30-76			30-128			40-50			40-102	
	30-77			30-129			40-51			40-103	
	30-78			30-130			40-52			40-104	
	30-79			40-1			40-53			40-105	
	30-80			40-2			40-54			40-106	
	30-81			40-3			40-55			40-107	
	30-82			40-4			40-56			40-108	
	30-83			40-5			40-57			40-109	
	30-84			40-6			40-58			40-110	
	30-85			40-7			40-59			40-111	
	30-86			40-8			40-60			40-112	
	30-87			40-9			40-61			40-113	
	30-88			40-10			40-62			40-114	
	30-89			40-11			40-63			40-115	
	30-90			40-12			40-64			40-116	
	30-91			40-13			40-65			40-117	
	30-92			40-14			40-66			40-118	
	30-93			40-15			40-67			40-119	
	30-94			40-16			40-68			40-120	
	30-95			40-17			40-69			40-121	
	30-96			40-18			40-70			40-122	
	30-97			40-19			40-71			40-123	
	30-98			40-20			40-72			40-124	
	30-99			40-21			40-73			40-125	
	30-100			40-22			40-74			40-126	
	30-101			40-23			40-75			40-127	
	30-102			40-24			40-76			40-128	
	30-103			40-25			40-77			40-129	
	30-104			40-26			40-78			40-130	
	30-105			40-27			40-79			40-131	
	30-106			40-28			40-80			40-132	
	30-107			40-29			40-81			40-133	
	30-108			40-30			40-82			40-134	
	30-109			40-31			40-83			40-135	
	30-110			40-32			40-84			40-136	
	30-111			40-33			40-85			40-137	
	30-112			40-34			40-86			40-138	
	30-113			40-35			40-87			40-139	
	30-114			40-36			40-88			40-140	
	30-115			40-37			40-89			40-141	
	30-116			40-38			40-90			40-142	
	30-117			40-39			40-91			40-143	
	30-118			40-40			40-92			40-144	
	30-119			40-41			40-93			40-145	
	30-120			40-42			40-94			40-146	
	30-121			40-43			40-95			40-147	
	30-122			40-44			40-96			40-148	

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
	40-149			40-201			40-253			40-305	
	40-150			40-202			40-254			40-306	
	40-151			40-203			40-255			40-307	
	40-152			40-204			40-256			40-308	
	40-153			40-205			40-257			40-309	
	40-154			40-206			40-258			40-310	
	40-155			40-207			40-259			40-311	
	40-156			40-208			40-260			40-312	
	40-157			40-209			40-261			40-313	
	40-158			40-210			40-262			40-314	
	40-159			40-211			40-263			40-315	
	40-160			40-212			40-264			40-316	
	40-161			40-213			40-265			40-317	
	40-162			40-214			40-266			40-318	
	40-163			40-215			40-267			40-319	
	40-164			40-216			40-268			40-320	
	40-165			40-217			40-269			40-321	
	40-166			40-218			40-270			40-322	
	40-167			40-219			40-271			40-323	
	40-168			40-220			40-272			40-324	
	40-169			40-221			40-273			40-325	
	40-170			40-222			40-274			40-326	
	40-171			40-223			40-275			40-327	
	40-172			40-224			40-276			40-328	
	40-173			40-225			40-277			40-329	
	40-174			40-226			40-278			40-330	
	40-175			40-227			40-279			40-331	
	40-176			40-228			40-280			40-332	
	40-177			40-229			40-281			40-333	
	40-178			40-230			40-282			40-334	
	40-179			40-231			40-283			40-335	
	40-180			40-232			40-284			40-336	
	40-181			40-233			40-285			40-337	
	40-182			40-234			40-286			40-338	
	40-183			40-235			40-287			40-339	
	40-184			40-236			40-288			40-340	
	40-185			40-237			40-289			40-341	
	40-186			40-238			40-290			40-342	
	40-187			40-239			40-291			40-343	
	40-188			40-240			40-292			40-344	
	40-189			40-241			40-293			40-345	
	40-190			40-242			40-294			40-346	
	40-191			40-243			40-295			40-347	
	40-192			40-244			40-296			40-348	
	40-193			40-245			40-297			40-349	
	40-194			40-246			40-298			40-350	
	40-195			40-247			40-299			40-351	
	40-196			40-248			40-300			40-352	
	40-197			40-249			40-301			40-353	
	40-198			40-250			40-302			40-354	
	40-199			40-251			40-303			40-355	
	40-200			40-252			40-304			40-356	

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
	40-357			40-409			40-461			50-35	
	40-358			40-410			40-462			50-36	
	40-359			40-411			40-463			50-37	
	40-360			40-412			40-464			50-38	
	40-361			40-413			40-465			50-39	
	40-362			40-414			40-466			50-40	
	40-363			40-415			40-467			50-41	
	40-364			40-416			40-468			50-42	
	40-365			40-417			40-469			50-43	
	40-366			40-418			40-470			50-44	
	40-367			40-419			40-471			50-45	
	40-368			40-420			40-472			50-46	
	40-369			40-421			40-473			50-47	
	40-370			40-422			40-474			50-48	
	40-371			40-423			40-475			50-49	
	40-372			40-424			40-476			50-50	
	40-373			40-425			40-477			50-51	
	40-374			40-426			40-478			50-52	
	40-375			40-427			50-1			50-53	
	40-376			40-428			50-2			50-54	
	40-377			40-429			50-3			50-55	
	40-378			40-430			50-4			50-56	
	40-379			40-431			50-5			50-57	
	40-380			40-432			50-6			50-58	
	40-381			40-433			50-7			50-59	
	40-382			40-434			50-8			50-60	
	40-383			40-435			50-9			50-61	
	40-384			40-436			50-10			50-62	
	40-385			40-437			50-11			50-63	
	40-386			40-438			50-12			50-64	
	40-387			40-439			50-13			50-65	
	40-388			40-440			50-14			50-66	
	40-389			40-441			50-15			50-67	
	40-390			40-442			50-16			50-68	
	40-391			40-443			50-17			50-69	
	40-392			40-444			50-18			50-70	
	40-393			40-445			50-19			50-71	
	40-394			40-446			50-20			50-72	
	40-395			40-447			50-21			50-73	
	40-396			40-448			50-22			50-74	
	40-397			40-449			50-23			50-75	
	40-398			40-450			50-24			50-76	
	40-399			40-451			50-25			50-77	
	40-400			40-452			50-26			50-78	
	40-401			40-453			50-27			50-79	
	40-402			40-454			50-28			50-80	
	40-403			40-455			50-29			50-81	
	40-404			40-456			50-30			50-82	
	40-405			40-457			50-31			50-83	
	40-406			40-458			50-32			50-84	
	40-407			40-459			50-33			50-85	
	40-408			40-460			50-34			50-86	

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
	50-87			50-137			50-189			60-3	
	50-88			50-138			50-190			60-4	(04)
	50-89	(05)		50-139			50-191			60-5	
	50-90	(05)		50-140			50-192			60-6	
	50-91			50-141			50-193			60-7	
	50-92			50-142			50-194			60-8	
	50-93			50-143			50-195			60-9	
	50-94	(05)		50-144			50-196			60-10	
	50-95	(05)		50-145			50-197			60-11	
●	50-96	(06)		50-146			50-198			60-12	
	50-97			50-147			50-199			60-13	
	50-98			50-148			50-200			60-14	
	50-99			50-149			50-201			60-15	
	50-100			50-150			50-202			60-16	
	50-101			50-151			50-203			60-17	
	50-102			50-152			50-204			60-18	
	50-103			50-153			50-205			60-19	
	50-104			50-154			50-206			60-20	
	50-105			50-155			50-207			60-21	
	50-106			50-156			50-208			60-22	
	50-107			50-157			50-209			60-23	
	50-108			50-158			50-210			60-24	
	50-109			50-159			50-211			60-25	
	50-110			50-160			50-212			60-26	
	50-111			50-161			50-213			60-27	
	50-112			50-162			50-214			60-28	
	50-113			50-163			50-215			60-29	
	50-114			50-164			50-216			60-30	
	50-115			50-165			50-217			60-31	
	50-116			50-166			50-218			60-32	
	50-117			50-167			50-219			60-33	
	50-118			50-168			50-220			60-34	
	50-119			50-169			50-221			60-35	
	50-120			50-170			50-222			60-36	
	50-121			50-171			50-223			60-37	
	50-122			50-172			50-224			60-38	
	50-123			50-173			50-225			60-39	
	50-124			50-174			50-226			60-40	
	50-125			50-175			50-227			60-41	
	50-126			50-176			50-228			60-42	
	50-127			50-177			50-229			60-43	
	50-128			50-178			50-230			60-44	
	50-129			50-179			50-231			60-45	
	50-130			50-180			50-232			60-46	
	50-131			50-181			50-233			60-47	
	50-132			50-182			50-234			60-48	
●	50-133	(06)		50-183			50-235			60-49	
	50-134			50-184			50-236			60-50	
	50-135			50-185			50-237			60-51	
	50-136			50-186			50-238			60-52	
	50-136-1	(02)		50-187			60-1			60-53	
	50-136-2	(02)		50-188			60-2			60-54	

Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number	Mark	Page	Revision number
	80-1			80-53			90-31				
	80-2			80-54			90-33				
	80-3			80-55			90-35				
	80-4			80-56			90-37				
	80-5			80-57			90-39				
	80-6			80-58			90-41				
	80-7			80-59			90-43				
	80-8			80-60			90-45				
	80-9			80-61			90-47				
	80-10			80-62			1				
	80-11			80-63			2				
	80-12			80-64			3				
	80-13			80-65			4				
	80-14			80-66			5				
	80-15			80-67			6				
	80-16			80-68		●	Colophon	(06)			
	80-17			80-69							
	80-18			80-70							
	80-19			80-71							
	80-20			80-72							
	80-21			80-73							
	80-22			80-74							
	80-23			80-75							
	80-24			80-76							
	80-25			80-77							
	80-26			80-78							
	80-27			80-79							
	80-28			80-80							
	80-29			80-81							
	80-30			80-82							
	80-31			80-83							
	80-32			80-84							
	80-33			90-1							
	80-34			90-2							
	80-35			90-3							
	80-36			90-4							
	80-37			90-5							
	80-38			90-6							
	80-39			90-7							
	80-40			90-9							
	80-41			90-11							
	80-42			90-12							
	80-43			90-13							
	80-44			90-14							
	80-45			90-15							
	80-46			90-17							
	80-47			90-19							
	80-48			90-21							
	80-49			90-23							
	80-50			90-25							
	80-51			90-27							
	80-52			90-29							

SHOP MANUAL

HYDRAULIC EXCAVATOR

PC800-8E0

PC850SE-8E0

PC800LC-8E0

PC800SE-8E0

PC850-8E0

Machine model	Serial number	Machine model	Serial number
PC800-8E0	65001 and up	PC850SE-8E0	65001 and up
PC800LC-8E0	65001 and up		
PC800SE-8E0	65001 and up		
PC850-8E0	65001 and up		

00 Index and foreword

Table of contents

Notice of revision.....	1
00 Index and foreword	
Table of contents	00 - 2
Table of contents	00 - 2
Foreword and general information	00- 12
Safety notice	00- 12
How to read the shop manual	00- 17
Explanation of terms for maintenance standard	00- 19
Handling of hydraulic components.....	00- 21
Method of disconnecting and connecting push-pull type coupler	00- 23
Handling of electric equipment.....	00- 26
How to read electric wire code.....	00- 36
Precautions when performing work.....	00- 39
Standard tightening torque table.....	00- 42
List of abbreviation.....	00- 46
Conversion table	00- 50
01 Specification	
Specifications.....	01- 4
Specifications drawing	01- 4
Specifications.....	01- 8
Table of weight.....	01- 18
Table of fuel, coolant and lubricants	01- 26
10 Structure and function	
Engine and cooling system	10- 3
Coupling.....	10- 3
Coupling lubrication system	10- 4
Cooling system	10- 6
Power train system	10- 8
Power train.....	10- 8
Swing circle.....	10- 10
Swing machinery.....	10- 11
Final drive	10- 13
Undercarriage and frame	10- 14
Track frame.....	10- 14
Idler cushion.....	10- 16
Hydraulic system.....	10- 18
Hydraulic component layout.....	10- 18
Hydraulic tank and filter	10- 20
Hydraulic pump	10- 22
Pump control system	10- 30
Servo valve	10- 32
Self-pressure reducing valve	10- 41
Cooling fan pump.....	10- 44
Cooling fan motor.....	10- 53
Electrical grease pump	10- 59
Control valve	10- 60
Straight-travel valve	10- 69
Swing motor	10- 72

PPC valve	10- 87
Solenoid valve	10- 95
Accumulator.....	10- 103
Quick return valve.....	10- 104
Return oil filter.....	10- 107
Line oil filter.....	10- 108
Pilot oil filter	10- 109
Drain oil filter.....	10- 110
Electrical system	10- 111
Engine control.....	10- 111
Electric control system.....	10- 121
Monitor system	10- 160
Sensors.....	10- 190
KOMTRAX system.....	10- 194
20 Standard value table	
Standard value table	20- 3
Standard value table for engine.....	20- 3
Standard value table for machine	20- 4
30 Testing and adjusting	
Tool for testing, adjusting and troubleshooting	30- 3
Tools for testing, adjusting, and troubleshooting	30- 3
Engine and cooling system.....	30- 7
Testing engine speed	30- 7
Testing intake air pressure (boost pressure)	30- 8
Testing exhaust gas temperature	30- 9
Testing exhaust gas color.....	30- 10
Adjusting valve clearance	30- 12
Testing compression pressure.....	30- 13
Testing blowby pressure.....	30- 15
Testing engine oil pressure.....	30- 16
Testing EGR valve and bypass valve drive pressure	30- 17
Handling fuel system parts	30- 18
Releasing remaining pressure from fuel system.....	30- 19
Testing fuel pressure	30- 20
Testing fuel return rate and leakage	30- 21
Bleeding air from fuel circuit	30- 24
Testing fuel circuit for leakage	30- 26
Testing and adjusting alternator belt tension	30- 27
Testing and adjusting air conditioner compressor belt tension.....	30- 28
Undercarriage and frame.....	30- 29
Testing swing circle bearing clearance	30- 29
Checking and adjusting track tension	30- 30
Hydraulic system	30- 31
Testing and adjusting oil pressure in work equipment, swing, and travel circuits.....	30- 31
Testing and adjusting control circuit oil pressure (output pressure of self-pressure reducing valve)	
.....	30- 37
Testing and adjusting control signal of main pump.....	30- 39
Testing PPC valve output pressure	30- 46
Measuring outlet pressure of solenoid valve, swing PPC shuttle valve, and swing priority selector valve	
.....	30- 50
Adjusting play of work equipment and swing PPC valves	30- 55
Testing and adjusting travel deviation	30- 56

Inspecting locations of hydraulic drift in work equipment.....	30- 58
Measuring fan speed	30- 59
Measuring fan circuit oil pressure	30- 60
Measuring fan pump EPC current.....	30- 61
Measuring fan pump EPC solenoid valve outlet pressure	30- 62
Measuring oil leakage	30- 63
Releasing remaining pressure from hydraulic circuit	30- 67
Bleeding air from various parts	30- 68
Inspection procedures for diode.....	30- 71
Adjusting mirrors	30- 72
Electrical system	30- 73
Special functions of machine monitor	30- 73
Handling voltage circuit of engine controller	30-117
Preparatory work for troubleshooting of electrical system	30-118
Pm Clinic.....	30-122
Pm clinic service	30-122
UNDERCARRIAGE INSPECTION REPORT	30-129
40 Troubleshooting	
General information on troubleshooting.....	40- 7
Points to remember when troubleshooting	40- 7
Sequence of events in troubleshooting.....	40- 8
Checks before troubleshooting	40- 9
Classification and procedures for troubleshooting	40- 35
Failure codes table.....	40- 38
Symptom and troubleshooting numbers	40- 43
Information in troubleshooting table.....	40- 46
Troubleshooting method for open circuit in wiring harness of pressure sensor system	40- 48
Connector list and layout	40- 50
Connection table for connector pin numbers	40- 61
T- branch box and T- branch adapter table	40- 97
Fuse locations.....	40-100
Troubleshooting by failure code.....	40-103
Failure code [989L00] Engine Controller Lock Caution 1	40-103
Failure code [989M00] Engine Controller Lock Caution 2	40-104
Failure code [989N00] Engine Controller Lock Caution 3.....	40-104
Failure code [AA10NX] Air Cleaner Clogging	40-105
Failure code [AB00KE] Charge Voltage Low	40-106
Failure code [B@BAZG] Eng Oil Press Low.....	40-108
Failure code [B@BAZK] Eng Oil Level Low.....	40-109
Failure code [B@BCNS] Eng Water Overheat	40-110
Failure code [B@BCZK] Eng Water Level Low	40-112
Failure code [B@HANS] Hyd Oil Overheat.....	40-114
Failure code [CA111] ECM Critical Internal Failure	40-116
Failure code [CA115] Eng Ne and Bkup Speed Sens Error	40-118
Failure code [CA122] Chg Air Press Sensor High Error	40-120
Failure code [CA123] Chg Air Press Sensor Low Error	40-122
Failure code [CA131] Throttle Sensor High Error	40-124
Failure code [CA132] Throttle Sensor Low Error	40-126
Failure code [CA135] Eng Oil Press Sensor High Error	40-128
Failure code [CA141] Eng Oil Press Sensor Low Error	40-130
Failure code [CA144] Coolant Temp Sens High Error	40-132
Failure code [CA145] Coolant Temp Sens Low Error.....	40-134
Failure code [CA153] Chg Air Temp Sensor High Error	40-136

Failure code [CA154] Chg Air Temp Sensor Low Error	40- 138
Failure code [CA187] Sens Supply 2 Volt Low Error	40- 140
Failure code [CA221] Ambient Press Sens High Error	40- 142
Failure code [CA222] Ambient Press Sens Low Error	40- 144
Failure code [CA227] Sens Supply 2 Volt High Error	40- 146
Failure code [CA234] Eng Overspeed	40- 147
Failure code [CA238] Ne Speed Sens Supply Volt Error.....	40- 148
Failure code [CA263] Fuel Temp Sensor High Error	40- 150
Failure code [CA265] Fuel Temp Sensor Low Error	40- 152
Failure code [CA271] IMV/PCV1 Short Error.....	40- 154
Failure code [CA272] IMV/PCV1 Open Error	40- 155
Failure code [CA273] PCV2 Short Error	40- 156
Failure code [CA274] PCV2 Open Error.....	40- 157
Failure code [CA322] Inj #1(L#1) Open/Short Error	40- 158
Failure code [CA323] Inj #5 (L#5) Open/Short Error	40- 160
Failure code [CA324] Inj #3(L#3) Open/Short Error	40- 162
Failure code [CA325] Inj #6 (L#6) Open/Short Error	40- 164
Failure code [CA331] Inj #2(L#2) Open/Short Error	40- 166
Failure code [CA332] Inj #4 (L#4) Open/Short Error	40- 168
Failure code [CA342] Calibration Code Incompatibility	40- 170
Failure code [CA351] Injectors Drive Circuit Error.....	40- 171
Failure code [CA352] Sens Supply 1 Volt Low Error.....	40- 172
Failure code [CA386] Sens Supply 1 Volt High Error	40- 174
Failure code [CA441] Battery Voltage Low Error.....	40- 174
Failure code [CA442] Battery Voltage High Error	40- 175
Failure code [CA449] Rail Press Very High Error.....	40- 175
Failure code [CA451] Rail Press Sensor High Error.....	40- 176
Failure code [CA452] Rail Press Sensor Low Error.....	40- 178
Failure code [CA553] Rail Press High Error	40- 180
Failure code [CA554] Rail Press Sensor In Range Error.....	40- 181
Failure code [CA559] Supply Pump Press Low Error 1	40- 182
Failure code [CA689] Eng Ne Speed Sensor Error	40- 186
Failure code [CA731] Eng Bkup Speed Sens Phase Error.....	40- 188
Failure code [CA757] All Continuous Data Lost Error	40- 189
Failure code [CA778] Eng Bkup Speed Sensor Error.....	40- 190
Failure code [CA1228] EGR Valve Servo Error 1	40- 192
Failure code [CA1625] EGR Valve Servo Error 2.....	40- 193
Failure code [CA1626] BP Valve Sol Current High Error.....	40- 194
Failure code [CA1627] BP Valve Sol Current Low Error	40- 196
Failure code [CA1628] Bypass Valve Servo Error 1	40- 198
Failure code [CA1629] Bypass Valve Servo Error 2.....	40- 199
Failure code [CA1631] BP Valve Pos Sens High Error	40- 200
Failure code [CA1632] BP Valve Pos Sens Low Error	40- 202
Failure code [CA1633] KOMNET Datalink Timeout Error.....	40- 204
Failure code [CA2185] Throt Sens Sup Volt High Error	40- 206
Failure code [CA2186] Throt Sens Sup Volt Low Error	40- 208
Failure code [CA2249] Rail Press Very Low Error.....	40- 209
Failure code [CA2271] EGR Valve Pos Sens High Error	40- 210
Failure code [CA2272] EGR Valve Pos Sens Low Error	40- 212
Failure code [CA2351] EGR Valve Sol Current High Error.....	40- 214
Failure code [CA2352] EGR Valve Sol Current Low Error	40- 216
Failure code [CA2555] Grid Htr Relay Open Circuit Error	40- 218
Failure code [CA2556] Grid Htr Relay Short Circuit Error	40- 220
Failure code [D110KB] Battery Relay Drive Short Circuit.....	40- 222

Failure code [D163KB] Flash Light Relay Short Circuit	40- 224
Failure code [D195KA] Step Light Relay Open Circuit	40- 226
Failure code [D195KB] Step Light Relay Short Circuit.....	40- 228
Failure code [D19JKZ] Personal Code Relay Abnormality	40- 230
Failure code [D862KA] GPS Antenna Open Circuit.....	40- 232
Failure code [DA22KK] Pump Solenoid Power Low Error	40- 234
Failure code [DA25KP] 5V Sensor1 Power Abnormality	40- 236
Failure code [DA29KQ] Model Selection Abnormality	40- 238
Failure code [DA2RMC] CAN Discon (Pump Con Detected).....	40- 240
Failure code [DA80MA] Auto. Lub. Abnormal.	40- 244
Failure code [DAF8KB] Camera Power Supply Short Circuit	40- 246
Failure code [DAFGMC] GPS Module Error	40- 248
Failure code [DAFRMC] CAN Discon (Monitor Detected)	40- 249
Failure code [DGE5KB] Ambi. Temp Sensor Short Circuit.....	40- 254
Failure code [DGH2KB] Hyd Oil Sensor Short.....	40- 256
Failure code [DH25KA] L Jet Sensor Open Circuit	40- 258
Failure code [DH25KB] L Jet Sensor Short Circuit	40- 260
Failure code [DH26KA] R Jet Sensor Open Circuit	40- 262
Failure code [DH26KB] R Jet Sensor Short Circuit.....	40- 264
Failure code [DHPEKA] F Pump P. Sensor Open Circuit.....	40- 266
Failure code [DHPEKB] F Pump P. Sensor Short Circuit	40- 268
Failure code [DHPFKA] R Pump P. Sensor Open Circuit.....	40- 270
Failure code [DHPFKB] R Pump P. Sensor Short Circuit.....	40- 272
Failure code [DV20KB] Travel alarm short circuit.....	40- 274
Failure code [DW41KA] Swing Priority Sol Open Circuit	40- 276
Failure code [DW41KB] Swing Priority Sol Short Circuit	40- 278
Failure code [DW43KA] Travel Speed Sol Open Circuit.....	40- 280
Failure code [DW43KB] Travel Speed Sol Short Circuit	40- 282
Failure code [DW45KA] Swing Brake Sol Open Circuit	40- 284
Failure code [DW45KB] Swing Brake Sol Short Circuit	40- 286
Failure code [DW7BKA] Fan Reverse Sol Open Circuit	40- 288
Failure code [DW7BKB] Fan Reverse Sol Short Circuit	40- 290
Failure code [DW7JKA] Bottom Dump Priority Sol Open Circuit	40- 292
Failure code [DW7JKB] Bottom Dump Priority Sol Short Circuit	40- 294
Failure code [DW91KA] Travel Junction Sol Open Circuit.....	40- 296
Failure code [DW91KB] Travel Junction Sol Short Circuit.....	40- 298
Failure code [DWK0KA] 2-stage Relief Sol Open Circuit.....	40- 300
Failure code [DWK0KB] 2-stage Relief Sol Short Circuit.....	40- 302
Failure code [DX16KA] Fan Pump EPC Sol Open Circuit	40- 304
Failure code [DX16KB] Fan Pump EPC Sol Short Circuit	40- 306
Failure code [DXAACA] F Pump EPC Sol Open Circuit	40- 308
Failure code [DXAACK] F Pump EPC Sol Short Circuit.....	40- 310
Failure code [DXABKA] R Pump EPC Sol Open Circuit	40- 312
Failure code [DXABKB] R Pump EPC Sol Short Circuit	40- 314
Failure code [DY20KA] Wiper Working Abnormality	40- 316
Failure code [DY20MA] Wiper Parking Abnormality	40- 320
Failure code [DY2CKA] Washer Drive Open Circuit	40- 322
Failure code [DY2CKB] Washer Drive Short Circuit	40- 324
Failure code [DY2DKB] Wiper Drive (Fwd) Short Circuit.....	40- 326
Failure code [DY2EKB] Wiper Drive (Rev) Short Circuit.....	40- 330
Failure code [DY2FMA] Upper Wiper Working Abnormality	40- 334
Failure code [DY2GKM] Wiper Select Abnormality.....	40- 336
Troubleshooting of electrical system (E-mode).....	40- 339
E-1 Engine does not start (Engine does not crank)	40- 339

E-2 Preheater does not operate	40- 344
E-3 When starting switch is turned to ON position, machine monitor displays nothing	40- 348
E-4 When starting switch is turned to ON position (before starting engine), basic check monitor lights up.	40- 351
E-5 Precaution item lights up while engine is running	40- 352
E-6 Emergency stop item lights up while engine is running	40- 354
E-7 Engine coolant temperature gauge does not indicate properly	40- 355
E-8 Fuel gauge does not indicate properly	40- 356
E-9 Hydraulic oil temperature gauge does not indicate properly	40- 358
E-10 Displays on machine monitor are different from those for actual machine	40- 360
E-11 Some areas of machine monitor screen are not displayed	40- 360
E-12 Function switch does not operate	40- 360
E-13 Automatic warm-up system does not operate (in cold season)	40- 361
E-14 Auto-decelerator does not operate properly	40- 362
E-15 Working mode does not change	40- 363
E-16 Travel speed does not change	40- 364
E-17 Alarm buzzer cannot be canceled	40- 365
E-18 When starting switch is turned OFF, service meter is not displayed.....	40- 365
E-19 Service mode cannot be selected	40- 365
E-20 Any of work equipment, swing and travel do not operate or cannot be locked	40- 366
E-21 Machine push-up function does not operate or cannot be canceled.....	40- 368
E-22 Boom shockless function does not operate properly	40- 370
E-23 Swing brake does not operate properly	40- 372
E-24 Windshield wiper and window washer do not operate	40- 374
E-25 Travel alarm does not sound or does not stop sounding	40- 378
E-26 Boom RAISE indicator is not displayed properly with monitoring function.....	40- 380
E-27 Boom LOWER indicator is not displayed properly with monitoring function	40- 382
E-28 Arm IN indicator is not displayed properly with monitoring function	40- 384
E-29 Arm OUT indicator is not displayed properly with monitoring function	40- 386
E-30 Bucket CURL indicator is not displayed properly with monitoring function	40- 388
E-31 Bucket DUMP indicator is not displayed properly with monitoring function	40- 390
E-32 Swing indicator is not displayed properly with monitoring function	40- 392
E-33 "L.H. travel" is not displayed properly with monitoring function.....	40- 394
E-34 "R.H. travel" is not displayed properly with monitoring function	40- 396
E-35 "Attachment" is not displayed properly with monitoring function	40- 398
E-36 Electric grease gun does not operate	40- 400
E-37 KOMTRAX system does not operate properly	40- 402
E-38 Horn does not sound or does not stop sounding	40- 403
E-39 Step light does not light up or go off.....	40- 406
Troubleshooting of hydraulic and mechanical system (H-mode).....	40- 410
Before starting troubleshooting for hydraulic and mechanical systems.....	40- 410
Information in troubleshooting table (H-mode)	40- 414
H-1 All of work equipment, swing and travel work slow or lack power	40- 416
H-2 Engine speed lowers significantly or engine stalls.....	40- 418
H-3 Any of work equipment, swing and travel does not work	40- 420
H-4 Unusual noise is heard from around hydraulic pump.....	40- 422
H-5 Boom operation lacks speed or power.....	40- 423
H-6 Arm operation lacks speed or power	40- 425
H-7 Bucket operation lacks speed or power	40- 426
H-8 Boom does not move	40- 427
H-9 Arm does not move.....	40- 427
H-10 Bucket does not move	40- 427
H-11 Hydraulic drift of work equipment is large	40- 428
H-12 Time lag of work equipment is large	40- 430

H-13 Heavy lift function does not work or is not released	40- 431
H-14 Machine push-up function does not work or is not released	40- 431
H-15 Boom shockless function does not work or is not canceled	40- 431
H-16 Machine deviates in one direction against operator's intention when travelling	40- 432
H-17 Machine deviates significantly at start	40- 435
H-18 Machine deviates significantly during combined operation	40- 436
H-19 Travel works slow or lack power	40- 437
H-20 One of tracks does not run	40- 438
H-21 Travel speed does not change	40- 439
H-22 Upper structure does not swing	40- 440
H-23 Swing speed is low or swing acceleration is poor	40- 441
H-24 In combined operation with work equipment, swing speed is low or swing acceleration is poor	40- 442
H-25 Upper structure overruns excessively when it stops swinging	40- 444
H-26 Shock is large when upper structure stops swinging	40- 445
H-27 Large unusual noise is heard when upper structure stops swinging	40- 446
H-28 Swing drift on a slope is large	40- 447
H-29 Fan revolution is abnormal (Fan sound/vibration is abnormally large or engine overheats)	40- 448
Troubleshooting of engine (S-mode)	40- 450
Method of using troubleshooting chart	40- 450
S-1 Startability is poor	40- 454
S-2 Engine does not start	40- 456
S-3 Engine does not pick up smoothly	40- 460
S-4 Engine stops during operation	40- 461
S-5 Engine runs rough or is unstable	40- 462
S-6 Engine lacks power	40- 464
S-7 Exhaust smoke is black (incomplete combustion)	40- 466
S-8 Oil consumption is excessive (or exhaust smoke is blue)	40- 468
S-9 Oil becomes contaminated early	40- 469
S-10 Fuel consumption is excessive	40- 470
S-11 Oil is in coolant (or coolant spurts or coolant level goes down)	40- 471
S-12 Oil pressure drops	40- 472
S-13 Oil level rises (coolant or fuel in oil)	40- 474
S-14 Coolant temperature rises too high (overheating)	40- 476
S-15 Unusual noise is made	40- 477
S-16 Vibration is excessive	40- 478
 50 Disassembly and assembly	
General information on disassembly and assembly	50- 4
How to read Disassembly and Assembly	50- 4
Coating materials list	50- 6
Special tools list	50- 9
Sketches of special tools	50- 16
Engine and cooling system	50- 21
Removal and installation of engine, PTO and hydraulic pump assembly	50- 21
Removal and installation of cooling assembly	50- 29
Removal and installation of aftercooler assembly	50- 35
Removal and installation of fuel cooler and air condenser assembly	50- 37
Removal and installation of fan motor assembly	50- 39
Removal and installation of fuel tank assembly	50- 44
Engine	50- 46
Removal and installation of fuel supply pump assembly	50- 46
Removal and installation of cylinder head assembly	50- 51

Removal and installation of fuel injector assembly	50- 67
Removal and installation of engine front seal	50- 70
Removal and installation of engine rear seal	50- 72
Power train	50- 77
Removal and installation of PTO assembly	50- 77
Disassembly and assembly of PTO assembly	50- 84
Removal and installation of swing motor and swing machinery assembly	50- 86
Disassembly and assembly of swing machinery assembly	50- 89
Removal and installation of swing circle assembly	50- 96
Disassembly and assembly of final drive assembly	50- 97
Undercarriage and frame	50-109
Separation and connection of track shoe assembly	50-109
Disassembly and assembly of one link in field	50-111
Removal and installation of idler assembly	50-115
Disassembly and assembly of idler assembly	50-116
Disassembly and assembly of idler adjustment cylinder assembly	50-119
Removal and installation of recoil spring assembly	50-120
Disassembly and assembly of recoil spring assembly	50-122
Removal and installation of carrier roller assembly	50-124
Disassembly and assembly of carrier roller assembly	50-125
Removal and installation of track roller assembly	50-128
Disassembly and assembly of track roller assembly	50-129
Removal and installation of revolving frame assembly	50-132
Removal and installation of counterweight assembly	50-134
Removal and installation of counterweight remover assembly	50-135
Hydraulic system	50-137
Removal and installation of hydraulic tank assembly	50-137
Removal and installation of main pump assembly	50-139
Removal and installation of main pump input shaft oil seal	50-146
Removal and installation of cooling fan pump assembly	50-147
Removal and installation of control valve assembly	50-150
Assembly of control valve assembly	50-153
Removal and installation of swing motor assembly	50-159
Removal and installation of center swivel joint assembly	50-160
Disassembly and assembly of center swivel joint assembly	50-162
Removal and installation of travel motor assembly	50-164
Removal and installation of solenoid valve assembly	50-165
Removal and installation of boom damping valve assembly	50-167
Disassembly and assembly of work equipment PPC valve assembly	50-168
Disassembly and assembly of travel PPC valve assembly	50-170
Disassembly and assembly of hydraulic cylinder assembly	50-173
Disassembly and assembly of grease gun assembly	50-180
Work equipment	50-181
Removal and installation of bucket cylinder assembly	50-181
Removal and installation of arm cylinder assembly	50-185
Removal and installation of boom cylinder assembly	50-189
Removal and installation of bottom dump cylinder assembly	50-193
Removal and installation of bucket assembly	50-195
Removal and installation of arm assembly	50-198
Removal and installation of boom assembly	50-202
Removal and installation of work equipment assembly	50-206
Cab and its attachments	50-210
Removal and installation of operator's cab assembly	50-210
Removal and installation of operator's cab glass (adhered window glass)	50-213

Removal and installation of front window assembly	50- 222
Electrical system	50- 229
Removal and installation of air conditioner unit assembly	50- 229
Removal and installation of engine controller assembly	50- 232
Removal and installation of monitor assembly.....	50- 234
Removal and installation of pump controller assembly.....	50- 236
Removal and installation of KOMTRAX terminal assembly	50- 238
60 Maintenance standard	
Engine and cooling system	60- 3
Coupling.....	60- 3
Power train.....	60- 4
Swing circle.....	60- 4
Swing machinery.....	60- 5
Final drive	60- 8
Sprocket.....	60- 10
Undercarriage and frame	60- 12
Track frame and idler cushion.....	60- 12
Idler	60- 14
Carrier roller	60- 16
Track roller	60- 18
Track shoe	60- 20
Hydraulic system.....	60- 24
Cooling fan motor.....	60- 24
Control valve	60- 26
Swing motor	60- 32
Center swivel joint.....	60- 34
PPC valve	60- 35
Work equipment.....	60- 38
Work equipment.....	60- 38
Work equipment dimension	60- 44
Hydraulic cylinder.....	60- 48
80 Appendix	
Air conditioner	80- 3
Precautions for refrigerant	80- 3
Air conditioner component	80- 4
Configuration and function of refrigeration cycle.....	80- 6
Outline of refrigeration cycle	80- 7
Air conditioner unit	80- 10
Air conditioner controller	80- 15
Compressor	80- 16
Condenser	80- 17
Receiver drier.....	80- 18
Procedure for testing and troubleshooting	80- 20
Circuit diagram and arrangement of connector pins	80- 22
System diagram	80- 24
Detail of air conditioner unit	80- 26
Parts and connectors layout	80- 28
Testing air leakage (duct)	80- 31
Testing with self-diagnosis function	80- 32
Testing temperature control	80- 35
Testing vent (mode) changeover	80- 37
Testing FRESH/RECIRC air changeover	80- 40

Testing inner sensor	80- 42
Testing evaporator temperature sensor	80- 43
Testing sunlight sensor	80- 45
Testing (dual) pressure switch for refrigerant	80- 46
Testing relays	80- 47
Troubleshooting chart 1	80- 48
Troubleshooting chart 2	80- 50
Information in troubleshooting table.....	80- 52
Troubleshooting for power supply and CAN communication system (Air conditioner does not operate)	80- 54
Troubleshooting for compressor and refrigerant system (Air is not cooled)	80- 59
Troubleshooting for blower motor system (No air comes out or air flow is abnormal)	80- 63
Troubleshooting for temperature control.....	80- 67
Troubleshooting for vent (mode) changeover	80- 70
Troubleshooting for FRESH/RECIRC air changeover	80- 72
Troubleshooting for temperature sensor system	80- 74
Troubleshooting with gauge pressure.....	80- 76
Connection of service tool	80- 78
Precautions for disconnecting and connecting air conditioner piping	80- 80
Handling of compressor oil	80- 82
90 Diagrams and drawings	
Hydraulic circuit diagram	90- 3
Symbols used in hydraulic circuit diagrams.....	90- 3
Hydraulic circuit diagram	90- 7
Electrical circuit diagram.....	90- 11
Symbols used in electric circuit diagrams.....	90- 11
Electrical circuit diagram.....	90- 15
Index	1

Foreword and general information

Safety notice

Important safety notice

Appropriate servicing and repair are extremely important to ensure safe operation of the machine. The shop manuals describe the effective and safe servicing and repair methods recommended by Komatsu. Some of the servicing and repair methods require use of special tools designed by Komatsu for special purposes.

The symbol mark "▲" is indicated for such matters that require special precautions. The work indicated with the warning mark should be performed according to the instructions with special attention to the precautions. Should a hazardous situation occur or be anticipated during such work, be sure to keep safe first and take every necessary measure.

1. General precautions

▲ Inappropriate handling creates an extreme danger. Read and understand what is described in the Operation and Maintenance Manual before operating the machine. Read and understand what is described in this manual before starting work.

- 1) Before performing any greasing or repairs, read all the safety labels stuck to the machine. For the locations of the safety labels and detailed explanation of precautions, see the Operation and Maintenance Manual.
- 2) Locate a place in the repair workshop to keep tools and removed parts. Always keep the tools and parts in their correct places. Always keep the work area clean and make sure that there is no dirt, water, or oil on the floor. Smoke only in the areas provided for smoking. Never smoke while working.
- 3) When performing any operation, always wear safety shoes and helmet. Do not wear loose work clothes, or clothes with buttons missing.
 - Always wear the safety glasses when hitting parts with a hammer.
 - Always wear the safety glasses when grinding parts with a grinder, etc.
- 4) When performing any operation with two or more workers, always agree on the operating procedure before starting. Always inform your fellow workers before starting any step of the operation. Before starting work, hang UNDER REPAIR warning tag in the operator's compartment.
- 5) Only qualified workers must perform the work and operation which require license or qualification.
- 6) Keep all tools in good condition, learn the correct way to use them, and use the proper ones. Before starting work, thoroughly check the tools, machine, forklift truck, service car, etc.

- 7) If welding repairs are needed, always have a trained and experienced welder perform the work. When performing welding work, always wear welding gloves, apron, shielding goggles, cap and other clothes suited for welding work.
- 8) Before starting work, warm up your body thoroughly to start work under good condition.
- 9) Avoid continuing work for long hours and take rests at proper intervals to keep your body in good condition and at the provided place.

Safety points


1	Good arrangement
2	Correct work clothes
3	Following work standard
4	Making and checking signals
5	Prohibition of operation and handling by unlicensed workers
6	Safety check before starting work
7	Wearing protective goggles (for cleaning or grinding work)
8	Wearing shielding goggles and protectors (for welding work)
9	Good physical condition and preparation
10	Precautions against work which you are not used to or you are used to too much

2. Preparation work

- 1) Before adding oil or making any repairs, park the machine on a hard and level ground, and apply the parking brake and chock the wheels or tracks to prevent the machine from moving.
- 2) Before starting work, lower the work equipment (blade, ripper, bucket, etc.) to the ground. If this is not possible, insert the lock pin or use blocks to prevent the work equipment from falling. In addition, be sure to lock all the control levers and hang warning tag on them.
- 3) When disassembling or assembling, support the machine with blocks, jacks, or stands before starting the work.
- 4) Remove all mud and oil from the steps or other places used to get on and off the machine. Always use the handrails, ladders or steps when getting on or off the machine. Never jump on or off the machine. If it is impossible to use the handrails, ladders or steps, use a stand to provide safe footing.

3. Precautions during work

- 1) Before disconnecting or removing components for the oil, water, or air circuits, first release the pressure completely from the circuit. When removing the oil filler cap, a drain plug, or an oil pressure pickup plug, loosen it slowly to prevent the oil from spurting out.
- 2) The coolant and oil in the circuits are hot when the engine is shut down, so be careful not to get scalded. Wait for the oil and coolant to cool before performing any work on the oil or water circuits.
- 3) Before starting work, shut down the engine. When working on or around a rotating part, in particular, shut down the engine. When checking the machine without shutting down the engine (measuring oil pressure, revolving speed, temperature, etc.), take extreme care not to get caught in rotating parts or moving parts.
- 4) **For the machine equipped with a battery disconnect switch, turn the battery disconnect switch to the OFF (O) position and pull the switch key out, before starting the work.** For machines without a battery disconnect switch, remove the cable from the battery, before starting the work. Always remove the cable from the negative (-) terminal first.



- 5) When raising a heavy component (heavier than 25 kg), use a hoist or crane. Before starting work, check that the slings (wire ropes, chains, and hooks) are free from damage. Always use slings which have ample capacity and install them to proper places. Operate the hoist or crane slowly to prevent the component from hitting any other part. Do not work with any part still raised by the hoist or crane.
- 6) When removing a cover which is under internal pressure or under pressure by a spring, always leave two bolts in diagonal positions. Loosen those bolts gradually and alternately to release the pressure, and then remove the cover.
- 7) When removing components, be careful not to break or damage the electrical wiring. Damaged wiring may cause electrical fires.
- 8) When removing piping, stop the fuel or oil from spilling out. If any fuel or oil drips onto the floor, wipe it off immediately. Fuel or oil on the floor can cause you to slip and can even cause fires.
- 9) As a general rule, do not use gasoline to wash parts. Do not use it to clean electrical parts, in particular.
- 10) Be sure to assemble all parts again in their original places. Replace any damaged parts and parts which must not be reused with new parts. When installing hoses and wires, be sure that they will not be damaged by contact with other parts when the machine is operated.
- 11) When installing high pressure hoses and tubes, make sure that they are not twisted. Damaged hoses and tubes are dangerous, so be extremely careful when installing hoses and tubes for high pressure circuits. In addition, check that connections of them are correct.

- 12) When assembling or installing parts, always tighten them to the specified torques. When installing protective parts such as guards, or parts which vibrate violently or rotate at high speeds, be particularly careful to check that they are installed correctly.
- 13) When aligning two holes, never insert your fingers or hand. Be careful not to get your fingers caught in a hole.
- 14) When measuring hydraulic pressure, check that the measuring tools are correctly installed.
- 15) Take care when removing or installing the tracks of track-type machines. When removing the track, the track separates suddenly, so never let anyone stand at either end of the track.
- 16) If the engine is operated for a long time in a place which is not ventilated well, you may suffer from gas poisoning. Accordingly, open the windows and doors to ventilate well.

4. Precautions for slinging work and making signals


- 1) Only one appointed worker must make signals and co-workers must communicate with each other frequently. The appointed signaler must make specified signals clearly at a place where he is well seen from the operator's seat and where he can see the working condition easily. The signaler must always stand in front of the load and guide the operator safely.
 - Do not stand under the load.
 - Do not step on the load.
- 2) Check the slings before starting sling work.
- 3) Keep putting on gloves during sling work. (Put on leather gloves, if available.)
- 4) Measure the weight of the load by the eye and check its center of gravity.
- 5) Use proper sling according to the weight of the load and method of slinging. If too thick wire ropes are used to sling a light load, the load may slip and fall.
- 6) Do not sling a load with one wire rope alone. If it is slung so, it may rotate and may slip out of the rope. Install two or more wire ropes symmetrically.

⚠ Slinging with one rope may cause turning of the load during hoisting, untwisting of the rope, or slipping of the rope from its original winding position on the load, which can result in a dangerous accident.


- 7) Limit the hanging angle to 60 degree, as a rule.

Do not sling a heavy load (25 kg or more) with ropes forming a wide hanging angle from the hook.

When hoisting a load with two or more ropes, the force subjected to each rope will increase with the hanging angle. The table below shows the variation of allowable load in kN {kg} when hoisting is made with two ropes, each of which is allowed to sling up to 9.8 kN {1,000 kg} vertically, at various hanging angles. When the two ropes sling a load vertically, up to 19.6 kN {2,000 kg} of total weight can be suspended. This weight is reduced to 9.8 kN {1,000 kg} when the two ropes make a hanging angle of 120 degree. If the two ropes sling a 19.6 kN {2,000 kg} load at a lifting angle of 150 degree, each of them is subjected to a force as large as 39.2 kN {4,000 kg}.



- 8) When installing wire ropes to an angular load, apply pads to protect the wire ropes. If the load is slippery, apply proper material to prevent the wire rope from slipping.
- 9) Use the specified eyebolts and fix wire ropes, chains, etc. to them with shackles, etc.
- 10) Apply wire ropes to the middle portion of the hook.
 - Slinging near the tip of the hook may cause the rope to slip off the hook during hoisting. The hook has the maximum strength at the middle portion.



- 11) Do not use twisted or kinked wire ropes.
- 12) When lifting up a load, observe the following.
 - Wind in the crane slowly until wire ropes are stretched. When settling the wire ropes with the hand, do not grasp them but press them from above. If you grasp them, your fingers may be caught.
 - After the wire ropes are stretched, stop the crane and check the condition of the slung load, wire ropes, and pads.
 - If the load is unstable or the wire rope or chains are twisted, lower the load and lift it up again.
 - Do not lift up the load at an angle.
- 13) When lowering a load, observe the following.
 - When lifting down a load, stop it temporarily at 30 cm above the floor, and then lower it slowly.
 - Check that the load is stable, and then remove the sling.
 - Remove kinks and dirt from the wire ropes and chains used for the sling work, and put them in the specified place.

5. Precautions for using mobile crane

- ★ Read the Operation and Maintenance Manual of the crane carefully in advance and operate the crane safely.

6. Precautions for using overhead traveling crane

⚠ A hoist crane or similar device must be used for lifting a heavy load (25 kg or more). The weight of a part that is 25 kg or more is indicated with the symbol "⚠" in "Disassembly and assembly".

- 1) Before starting work, inspect the wire ropes, brake, clutch, controller, rails, over wind stop device, ground fault circuit interrupter, crane collision prevention device, and power application warning lamp, and check safety.
- 2) Observe the signals for sling work.
- 3) Operate the hoist at a safe place.

- 4) Check the direction indicator plates (east, west, south, and north) and the directions of the control buttons without fail.
- 5) Do not sling a load at an angle. Do not move the crane while the slung load is swinging.
- 6) Do not raise or lower a load while the crane is moving longitudinally or laterally.
- 7) Do not drag a sling.
- 8) When lifting up a load, stop it just after it leaves the ground and check safety, and then lift it up.
- 9) Consider the travel route in advance and lift up a load to a safe height.
- 10) Place the control switch in a position where it will not be an obstacle to work and passage.
- 11) After operating the hoist, do not swing the control switch.
- 12) Remember the position of the main switch so that you can turn off the power immediately in an emergency.
- 13) If the hoist stops because of a power failure, turn the power switch OFF. When turning on a switch which was turned OFF by the ground fault circuit interrupter, check that the devices related to that switch are not in operating condition.
- 14) If you find an obstacle around the hoist, stop the operation.
- 15) After finishing the work, stop the hoist at the specified position and raise the hook to at least 2 m above the floor. Do not leave the sling installed to the hook.

7. Selecting wire ropes

- 1) Select adequate ropes depending on the weight of parts to be hoisted, referring to the table below

Wire ropes (Standard "Z" twist ropes without galvanizing) (JIS G3525, No. 6, Type 6X37-A)		
Nominal diameter of rope mm	Allowable load	
	kN	ton
10	8.8	0.9
12	12.7	1.3
14	17.3	1.7
16	22.6	2.3
18	28.6	2.9
20	35.3	3.6
25	55.3	5.6
30	79.6	8.1
40	141.6	14.4
50	221.6	22.6
60	318.3	32.4

- ★ The allowable load is one-sixth of the breaking strength of the rope to be used (Safety coefficient: 6).

8. Precautions for disconnecting and connecting hoses and tubes in an air conditioner circuit

1) Disconnection

⚠ Although the refrigerant (refrigerant gas: R134a) used on the machine's air conditioner is less destructive to the ozone layer for environmentally friendliness, it is not allowed to be released into the atmosphere as is. Whenever disconnecting the air conditioner gas circuit, be sure to recover the refrigerant gas to reuse it.

★ Ask a qualified person for collection and charge of the refrigerant (R134a).

★ Never release the refrigerant (R134a) to the atmosphere.

⚠ If the refrigerant gas gets in your eyes or contacts your skin, you may lose your sight or your skin may be frozen. Whenever recovering or adding refrigerant gas, you must put on safety glasses, safety gloves and long sleeved clothes.

The refrigerant gas must be recovered and added by a qualified person.

2) Connection


1] When installing the air conditioner circuit hoses and tubes, take care that dirt, dust, water, etc. will not enter them.

2] When connecting the air conditioner hoses and tubes, check that O-rings (1) are fitted to their joints.

3] Check that O-ring (1) is free from flaw and deterioration.

4] When connecting the refrigerant piping, apply compressor oil for refrigerant (R134a) (**DENSO: ND-OIL8, VALEO THERMAL SYSTEMS: ZXL100PG (equivalent to PAG46)**) to its O-rings.

★ Example of O-ring (Fitted to every joint of hoses and tubes)



★ For tightening torque, see the precautions for installation in each section of "Disassembly and assembly".

How to read the shop manual

(Rev. 2010/03)

- Some attachments and optional parts in this shop manual may not be delivered to certain areas. If one of them is required, consult KOMATSU distributors.
- Materials and specifications are subject to change without notice.
- Shop manuals are divided into the "Chassis volume" and "Engine volume". For the engine unit, see the engine volume of the engine model mounted on the machine.

1. Composition of shop manual

This shop manual contains the necessary technical information for services performed in a workshop. For ease of understanding, the manual is divided into the following sections.

00. Index and foreword

This section contains the index, foreword, safety and basic information. If any revision is made, the LIST OF REVISED PAGES will be added.

01. Specification

This section explains the specifications of the machine.

10. Structure and function

This section explains the structure and function of each component. It serves not only to give an understanding for the structure of each component, but also serves as reference material for troubleshooting.

20. Standard value table

This section explains the standard values for new machine and judgement criteria for testing, adjusting, and troubleshooting. This standard value table is used to check the standard values in testing and adjusting and to judge parts in troubleshooting.

30. Testing and adjusting

This section explains measuring tools and measuring methods for testing and adjusting, as well as the adjusting method of each part. The standard values and judgment criteria for "Testing and adjusting" are explained in "Standard value table".

40. Troubleshooting

This section explains how to find out failed parts and how to repair them. The troubleshooting is divided by failure modes. The "S mode" of the troubleshooting related to the engine may be also explained in the Chassis volume and Engine volume. In this case, see the Chassis volume.

50. Disassembly and assembly

This section explains the special tools and procedures for removing, installing, disassembling, and assembling each component, as well as precautions for them. In addition, tightening torque, and quantity and weight of coating material, oil, grease, and coolant necessary for the work are also explained.

60. Maintenance standard

This section gives maintenance standard values of each component. The maintenance standard sub-section explains the criteria and remedies for disassembly and service.

80. Appendix

This section explains the structure, function, testing, adjusting, and troubleshooting for the equipment not classifiable in other sections.

90. Diagrams and drawings (chassis volume) /Repair and replacement of parts (engine volume)

- Chassis volume
This section gives hydraulic circuit diagrams and electrical circuit diagrams.
- Engine volume
This section explains the method of remanufacturing and repairing engine and replacing parts.

2. Revision and distribution

Any additions, revisions, or other change of notices will be sent to KOMATSU distributors. Get the most up-to-date information before you start any work.

3. Filing method

File the revised or added pages in the correct order of the page numbers printed in the LIST OF REVISED PAGES.

- **Revision number**








When a manual is revised, revision number of each page is increased by 1.
(Example: (01), (02), (03)...))

- **Revisions**

The revised pages are shown in the LIST OF REVISED PAGES.

4. Symbol

Important safety and quality portions are marked with the following symbols so that the shop manual will be used practically.

Symbol	Item	Description
	Safety	Special safety precautions which are necessary when performing work are described.
	Caution	Special technical precautions or other precautions for preserving standards which are necessary when performing work are described.
	Weight	Weight of parts of component or parts are indicated. Caution necessary when selecting hoisting wire, or when working posture is important, etc. are described.
	Tightening torque	Places that require special attention for tightening torque during assembly are indicated.
	Coat	Places to be coated with adhesives, etc. during assembly are indicated.
	Oil, coolant	Places where oil, etc. must be added, and capacity are indicated.
	Drain	Places where oil, etc. must be drained, and quantity to be drained are indicated.

5. Unit

In this shop manual, the units are indicated with International System of units (SI).

For reference, conventionally used Gravitational System of units is indicated in parentheses { }.

Explanation of terms for maintenance standard

(Rev. 2010/03)

The maintenance standard chapter explains the criteria for replacing or reusing products and parts in the machine maintenance work. The following terms are used to explain the criteria.

1. Standard dimension and tolerance

- To be accurate, the finished dimension of parts is slightly different from one to another.
- To specify the finished dimension of a part, a certain dimension is set for the part and an allowable difference from that dimension is indicated.
- The above dimension set is called the "standard dimension" and the range of difference from the standard dimension is called the "tolerance".
- The tolerance with the symbols of + or – is indicated on the right side of the standard dimension.

Example:

Standard dimension	Tolerance
120	-0.022 -0.126

- ★ The tolerance may be indicated in the text and a table as [standard dimension (upper limit of tolerance/lower limit of tolerance)]. Example) 120 (-0.022/-0.126)
- Usually, the dimension of a hole and the dimension of the shaft to be inserted into that hole are indicated by the same standard dimension and different tolerances of the hole and shaft. The tightness of fit is decided by the tolerance.
- Indication of dimension of rotating shaft and hole and their related drawing.


Example:

Standard dimension	Tolerance	
	Shaft	Hole
60	-0.030 -0.076	+0.046 0

2. Standard clearance and standard value

- The clearance made when new parts are assembled is called the "standard clearance", which is indicated by the range from the minimum clearance to the maximum clearance.
- When some parts are repaired, the clearance is generally adjusted to the standard clearance.
- The values indicating performance and function of new products or equivalent are called the "standard value", which is indicated by a range or a target value.

- When some parts are repaired, the value of performance/function is set to the standard value.



3. Standard interference

- When the diameter of a hole of a part shown in the given standard dimension and tolerance table is smaller than that of the shaft to be inserted, the difference between those diameters is called the "interference".
- The range (between A and B) from the difference (A) between the minimum dimension of the shaft and the maximum dimension of the hole to the difference (B) between the maximum dimension of the shaft and the minimum dimension of the hole is the "standard interference".
- After repairing or replacing some parts, measure the dimension of their hole and shaft and check that the interference is in the standard range.

4. **Repair limit and allowable value or allowable dimension**

- The dimension of a part changes because of wear and deformation while it is used. The limit of changed dimension is called the "repair limit".
- If a part is worn to the repair limit, it must be replaced or repaired.
- The performance and function of a product lowers while it is used. A value with which the product can be used without causing a problem is called the "allowable value" or "allowable dimension".
- If a product deviates from the allowable value, it must be checked or repaired. However, since most of the allowable values are estimated from various tests or experiences in most cases, it must be judged after considering the operating condition and customer's requirement.

5. **Allowable clearance**

- Parts can be used until the clearance between them is increased to a certain limit. The limit at which those parts cannot be used is called the "allowable clearance".
- If the clearance between the parts exceeds the allowable clearance, they must be replaced or repaired.

6. **Allowable interference**

- The allowable maximum interference between the hole of a part and the shaft of another part to be assembled is called the "allowable interference".
- The allowable interference shows the repair limit of the part of smaller tolerance.
- If the interference between the parts exceeds the allowable interference, they must be replaced or repaired.

Handling of hydraulic components

(Rev. 2010/03)


With the increase in pressure and precision of hydraulic equipment, the most common cause of failure is dirt (foreign material) in the hydraulic circuit. Therefore, special precaution is required when adding hydraulic oil, or when disassembling or assembling hydraulic components.

1. Be careful of the operating environment

Avoid adding hydraulic oil, replacing filters, or repairing the machine in rain or high winds, or at places where there is a lot of dust.


2. Disassembly and maintenance work in the field

If disassembly or maintenance work is performed on hydraulic components in the field, there is danger of dust entering the components. It is also difficult to check the performance after repairs, so it is desirable to use unit exchange. Disassembly and maintenance of hydraulic components should be performed in a specially prepared dustproof workshop, and the performance should be checked with special test equipment.




3. Sealing openings

After any piping or equipment is removed, the openings should be sealed with caps, tapes, or vinyl bags to prevent any dirt or dust from entering. If the opening is left open or is blocked with a rag, there is danger of dirt entering or of the surrounding area being made dirty by leaking oil so never do this. Do not simply drain oil out onto the ground, but collect it and ask the customer to dispose of it, or take it back with you for disposal.



4. Preventing intrusion of foreign materials during refilling operations.

Be careful not to let any dirt or dust get in when refilling with hydraulic oil. Always keep the oil filler and the area around it clean, and also use clean pumps and oil containers. If an oil cleaning device is used, it is possible to filter out the dirt that has been collected during storage, so this is an even more effective method.




5. Replacing hydraulic oil while its temperature is high

When hydraulic oil or other oil is warm, it flows easily. In addition, the sludge can also be drained out easily from the circuit together with the oil, so it is best to change the oil when it is still warm. When changing the oil, as much as possible of the old hydraulic oil must be drained out. (Drain the oil from the hydraulic tank; also drain the oil from the filter and from the drain plug hole in the circuit.) If any old oil is left, the contaminants and sludge in it will mix with the new oil and will shorten the life of the hydraulic oil.


6. Flushing operations

After disassembling and assembling the equipment, or changing the oil, use flushing oil to remove the contaminants, sludge, and old oil from the hydraulic circuit. Normally, flushing is performed twice. Primary flushing is performed by use of flushing oil and secondary flushing is performed by use of the specified hydraulic oil.



7. Cleaning operations

After repairing the hydraulic equipment (pump, control valve, etc.) or when running the machine, perform oil cleaning to remove the sludge or contaminants in the hydraulic oil circuit. The oil cleaning equipment can remove the ultra fine (about 3 μ) particles that the filter built in the hydraulic equipment cannot remove, so it is an extremely effective device.



Method of disconnecting and connecting push-pull type coupler


(Rev. 2010/03)

- ⚠ Before performing the following work, loosen the oil filler cap of the hydraulic tank gradually to release the remaining pressure in the hydraulic tank.
- ⚠ Even if the remaining pressure is released from the hydraulic tank, some hydraulic oil flows out when the hose is disconnected. Accordingly, prepare an oil container.

Type 1


1. Disconnection

- 1) Hold adapter (1) and push hose joint (2) into mating adapter (3). (Fig. 1)
 - ★ The adapter can be pushed in about 3.5 mm.
 - ★ Do not hold rubber cap portion (4).
- 2) With hose joint (2) pushed into adapter (3), press rubber cap portion (4) against adapter (3) until it clicks. (Fig. 2)
- 3) Hold hose adapter (1) or hose (5) and pull it out. (Fig. 3)
 - ★ Since some hydraulic oil flows out, prepare an oil container.



2. Connection


- 1) Hold hose adapter (1) or hose (5) and insert it in mating adapter (3), aligning them with each other. (Fig. 4)
 - ★ Do not hold rubber cap portion (4).
- 2) After inserting the hose fitting in the adapter on the other side perfectly, pull it back to check the connecting condition (Fig. 5)
 - ★ When the hose is pulled back, the rubber cap portion moves toward the hose about 3.5 mm. This does not indicate abnormality, however.



Type 2


1. Disconnection

- 1) Hold the tightening portion and push body (7) straight until sliding prevention ring (6) contacts contact surface (a) of the hexagonal portion at the male end. (Fig. 6)
- 2) While holding the condition of Step 1), turn lever (8) to the right (clockwise). (Fig. 7)
- 3) While holding the condition of Steps 1) and 2), pull out whole body (7) to disconnect it. (Fig. 8)



2. Connection


- Hold the tightening portion and push body (7) straight until sliding prevention ring (6) contacts contact surface (a) of the hexagonal portion at the male end. (Fig. 9)



Type 3


1. Disconnection

- 1) Hold the tightening portion and push body (9) straight until sliding prevention ring (8) contacts contact surface (b) of the hexagonal portion at the male end. (Fig. 10)
- 2) While holding the condition of Step 1), push cover (10) straight until it contacts contact surface (b) of the hexagonal portion at the male end. (Fig. 11)
- 3) While holding the condition of Steps 1) and 2), pull out whole body (9) to disconnect it. (Fig. 12)



2. Connection

- Hold the tightening portion and push body (9) straight until sliding prevention ring (8) contacts contact surface (b) of the hexagonal portion at the male end. (Fig. 13)



Handling of electric equipment

(Rev. 2010/03)


To maintain the performance of the machine over a long period, and to prevent failures or other troubles before they occur, correct "operation", "maintenance and inspection", "troubleshooting", and "repairs" must be performed. This section deals particularly with correct repair procedures for mechatronics and is aimed at improving the quality of repairs. For this purpose, it gives sections on "Handling electric equipment".

Points to remember when handling electric equipment

1. Handling wiring harnesses and connectors

Wiring harnesses consist of wires connecting one component to another component, connectors used for connecting and disconnecting one wire from another wire, and protectors or tubes used for protecting the wires.


Compared with other electrical components fitted in boxes or cases, wiring harnesses are more likely to be affected by the direct effects of rain water, heat, or vibration. Furthermore, during inspection and repair operations, they are frequently removed and installed again, so they are likely to suffer deformation or damage. For this reason, it is necessary to be extremely careful when handling wiring harnesses.



2. Main failures occurring in wiring harnesses


1) Defective contact of connectors (defective contact between male and female connectors)

Problems with defective contact are likely to occur because the male connector is not properly fitted into the female connector, or because one or both of the connectors is deformed or the position is not correctly aligned, or because there is corrosion or oxidization of the contact surfaces. The corroded or oxidized contact surfaces may become shiny again (and contact may become normal) by connecting and disconnecting the connector about ten times.




2) Defective crimping or soldering of connectors

The pins of the male and female connectors are attached to wires by crimping or soldering. If excessive force is applied to the wire, the joint is separated and causes a defective contact or the wire is broken.



3) Disconnections in wiring

If the harness is pulled to disconnect the connector, or components are lifted with a crane with the harness still connected, or a heavy object hits the harness, the crimping of the connector may separate, or the soldering may be damaged, or the harness may be broken.




4) High-pressure water entering connector

The connector is designed to make it difficult for water to enter (drip-proof structure), but if high-pressure water is sprayed directly on the connector, water may enter the connector, depending on the direction of the water jet.

Accordingly, take care not to spray water over the connector.

The connector is designed to prevent water from entering, but at the same time, if water does enter, it is difficult for it to be drained. Therefore, if water should get into the connector, the pins will be short-circuited by the water, so if any water gets in, immediately dry the connector or take other appropriate action before passing electricity through it.




5) Oil or dirt stuck to connector

If oil or grease are stuck to the connector and an oil film is formed on the mating surface of the male and female pins, the oil will not let the electricity pass, so there will be defective contact. If there is oil or grease stuck to the connector, wipe it off with a dry cloth or blow it to dry with compressed air and spray it with electric contact cleaner.

★ When wiping the joint portion of the connector, be careful not to apply excessive force or deform the pins.

★ If there is oil or water in the compressed air, the contacts will become even dirtier, so remove the oil and water from the compressed air completely before cleaning with compressed air.




3. Removing, installing, and drying connectors and wiring harnesses

1) Disconnecting connectors


- 1] Hold the connectors when disconnecting. When disconnecting the connectors, hold the connectors. For connectors held by a screw, loosen the screw fully, then hold the male and female connectors in each hand and pull apart. For connectors which have a lock stopper, press down the stopper with your thumb and pull the connectors apart.

★ Never pull with one hand.




2] When removing from clips

- Both of the connector and clip have stoppers, which are engaged with each other when the connector is installed.



- When removing a connector from a clip, pull the connector in a parallel direction to the clip for removing stoppers.


★ If the connector is pried up and down or to the left or right, the housing may break.



3] Action to take after removing connectors

After removing a connector, cover it with a vinyl bag to prevent the entry of dust, dirt, oil, or water to the contact portion.

★ If the machine is left disassembled for a long time, it is particularly easy for improper contact to occur, so always cover the connector.



2) Connecting connectors

1] Check the connector visually.

Check that no oil, dirt, or water is stuck to connector pins (joint portion).

Check that connector pins are free from deformation, defective contact, corrosion, or damage.

Check that external surfaces of the connectors are free from damage or breakage.

- ★ If there is any oil, water, or dirt stuck to the connector, wipe it off with a dry cloth. If any water has got inside the connector, warm the inside of the connector and harness with a dryer, but be careful not to make them too hot as this will cause short circuits.

2] Fix the connector securely.




Position the connectors correctly, and then fit them securely. For connectors with the lock stopper, push in the connector until the stopper clicks into position.

3] Correcting protrusion of the boot and misalignment of the wiring harness

For connectors fitted with the boot, correct any extrusion of the boot. In addition, if the wiring harness is moved in laying, or the clamp is out of position, correct it to its right position.

- ★ If the connector cannot be corrected easily, remove the clamp and adjust the position.
- If the connector clamp is removed, be sure to return it to its original position. Check also that there are no loose clamps.

- ★ If there is any damage or breakage, replace the connector.



3) Deutsch connector (DT 8-pin, 12-pin)

Disconnection (Left of figure)

While pressing locks (a) and (b), pull out the female connector (2).

Connection (Right of figure)

1] Push in female connector (2) horizontally until the lock clicks.

Arrow: 1)

2] Since locks (a) and (b) may not be set completely, push in female connector (2) while moving it up and down until the locks are set normally.

Arrow: 1), 2), 3)

★ Right of figure: Lock (a) is pulled down (not set completely) and lock (b) is set completely.


(1): Male connector

(2): Female connector

(a), (b): Locks

● Disconnection

● Connection (Example of incomplete setting of (a))




4) Drying wiring harness

If there is any oil or dirt on the wiring harness, wipe it off with a dry cloth. Avoid washing it in water or using steam. If the connector must be washed in water, do not use high-pressure water or steam directly on the wiring harness. If water gets directly on the connector, do as follows.

1] Disconnect the connector and wipe off the water with a dry cloth.


- ★ If the connector is to be blown with dry compressed air, there is the risk that oil in the air may cause defective contact, remove oil and water in the air before starting air blow.



2] Dry the inside of the connector with a dryer.

If water gets inside the connector, use a dryer to dry the connector.


- ★ Hot air from the dryer can be used, but regulate the time that the hot air is used in order not to make the connector or related parts too hot, as this will cause deformation or damage to the connector.



3] Perform a continuity test on the connector.

After drying, leave the wiring harness disconnected and perform a continuity test to check for any short circuits between pins caused by water.

- ★ After completely drying the connector, blow it with electric contact cleaner and reassemble.



4. Handling of connectors used on engine

★ Mainly, following engines are object for following connectors.

- 95E-5
- 107E-1
- 114E-3
- 125E-5
- 140E-5
- 170E-5
- 12V140E-3


1) Slide, lock type (FRAMATOME-3, FRAMATOME-2)

- 95/107/114/125/140/170/12V140 Series
 - Various pressure sensors and NE speed sensor
Examples)
Intake air pressure sensor in intake manifold: PIM (125/170/12V140 series)
Oil pressure sensor: POIL (125/170/12V140 series)
Oil pressure switch (95/107/114 series)
Ne speed sensor on flywheel housing: NE (95/107/114/125/140/170/12V140 series)
Ambient pressure sensor: PAMB (125/170/12V140 series)

Disconnection

- 1] Slide lock L1 to the right.
- 2] While pressing lock L2, pull out connector (1) toward you.

★ Even if lock L2 is pressed, connector (1) cannot be pulled out toward you, if part (A) does not float. In this case, float part (A) with a small screwdriver while pressing lock L2, and then pull out connector (1) toward you.



Connection


Insert the connector straight until it "clicks".

2) Pull lock type (PACKARD-2)

- 95/107/114/125/140/170/12V140 Series
 - Various temperature sensors
Examples)
Intake air temperature sensor in intake manifold: TIM
Fuel temperature sensor: TFUEL
Oil temperature sensor: TOIL
Coolant temperature sensor: TWTR, etc.

Disconnection

Disconnect the connector by pulling lock (B) (on the wiring harness side) of connector (2) outward.



Connection

Insert the connector straight until it "clicks".

3) Push lock type (1)


- 95/107/114 series

Example) Fuel pressure sensor in common rail (**BOSCH-03**)


Disconnection

While pressing lock (C), pull out connector (3) in the direction of the arrow.

- 114 series




- 107 series



- ★ If the lock is located on the underside, use flat-head screwdriver [1] since you cannot insert your fingers.

While pressing up lock (C) of the connector with flat-head screwdriver [1], pull out connector (3) in the direction of the arrow.



Connection

Insert the connector straight until it "clicks".


4) Push lock type (2)

- 107/114 series

Example) Intake air pressure/temperature sensor in intake manifold (**SUMI-TOMO-04**)

Disconnection

While pressing lock (D), pull out connector (4) in the direction of the arrow.



Connection


Insert the connector straight until it "clicks".

5) **Push lock type (3)**


- 95/125/140/170/12V140 series

Disconnection

While pressing lock (E) of the connector, pull out connector (5) in the direction of the arrow.
 Example) Fuel pressure sensor in common rail: PFUEL etc. **(AMP-3)**




Example) Injection pressure control valve of fuel supply pump: PCV **(SUMITOMO-2)**



Examples) Speed sensor of fuel supply pump: G **(SUMITOMO-3)**

- ★ Pull the connector straight up.



Connection

Insert the connector straight until it "clicks".

6) **Turn-housing type (Round green connector)**

- 140 series

Example) Intake air pressure sensor in intake manifold.

(CANNON-04): PIM, etc.


Disconnection

1] Turn housing (H1) in the direction of the arrow.

- ★ When connector is unlocked, housing (H1) becomes heavy to turn.

2] Pull out housing (H1) in the direction of the arrow.


- ★ Housing (H1) is left on the wiring harness side.



Connection


1] Insert the connector to the end, while setting its groove.

2] Turn housing (H1) in the direction of the arrow until it "clicks".




5. Handling controller

- 1) The controller contains a microcomputer and electronic control circuits. These control all of the electronic circuits on the machine, so be extremely careful when handling the controller.
- 2) Do not place objects on top of the controller.
- 3) Cover the control connectors with tape or a vinyl bag. Never touch the connector contacts with your hand.
- 4) During rainy weather, do not leave the controller in a place where it is exposed to rain.
- 5) Do not place the controller on oil, water, or soil, or in a place that can be heated to a high temperature even for a short time. (Place it on a suitable dry stand.)
- 6) Precautions when performing arc welding
When performing arc welding on the machine body, disconnect all of the wiring harness connectors connected to the controller. Fit an arc welding ground to the place close to the welding point.



6. Points to remember when troubleshooting electric circuits


- 1) Be sure to turn the power OFF before disconnecting or connecting connectors.
- 2) Before performing troubleshooting, check all the related connectors for loose connection.
 - ★ Disconnect and connect the related connectors several times to check.
- 3) Be sure to connect any disconnected connectors before going on to the next step.
 - ★ If the power is turned ON with the connectors still disconnected, unnecessary warning will be displayed.
- 4) When performing troubleshooting of circuits (measuring the voltage, resistance, continuity, or current), wiggle the related wiring harnesses and connectors several times and check that there is no change in the reading of the tester.
 - ★ If there is any change, there may be defective contact in the circuit.



How to read electric wire code

(Rev. 2010/03)

In the electric circuit diagram, the material, thickness, and color of each electric wire are indicated by symbols. The electric wire code is helpful in understanding the electric circuit diagram.



1. Type, symbol, and material

AV and AVS are different only in thickness and outside diameter of the cover. CAVS has a circular compressed conductor. It differs from AV and AVS in the outside diameter and thickness of the cover. And AEX is similar to AV in thickness and outside diameter of the cover but different from AV and AVS in material of the cover.

(Table 1)

Type	Symbol	Material		Temperature range for use (°C)	Example of use
Low-voltage wire for automobiles	AV	Conductor	Annealed copper for electric appliance	-30 – +60	General wiring (nominal No. 5 and above)
		Insulator	Soft polyvinyl chloride		
Thin low-voltage wire for automobile (type 1)	AVS	Conductor	Annealed copper for electric appliance		
		Insulator	Soft polyvinyl chloride		
Thin low-voltage wire for automobile (type 2)	CAVS	Conductor	Annealed copper for electric appliance		For mid- to small-size excavators (nominal No. 1.25 and below)
		Insulator	Soft polyvinyl chloride		
Heat resistant low-voltage wire for automobiles	AEX	Conductor	Annealed copper for electric appliance	-50 – +110	General wiring in extremely cold weather district, wiring at high ambient temperature place
		Insulator	Heat-resistant crosslinked polyethylene		

2. Dimensions


(Table 2)

Nominal No.		0.5f	(0.5)	0.75f	(0.85)	1.25f	(1.25)	2f	2	3f	3	5	
Conductor	Number of strands/Diameter of strand	20/0.18	7/0.32	30/0.18	11/0.32	50/0.18	16/0.32	37/0.26	26/0.32	58/0.26	41/0.32	65/0.32	
	Sectional area (mm ²)	0.51	0.56	0.76	0.88	1.27	1.29	1.96	2.09	3.08	3.30	5.23	
	d (approx.)	1.0		1.2		1.5		1.9	1.9	2.3	2.4	3.0	
Cover D	AVS	Standard	2.0		2.2		2.5		2.9	2.9	3.5	3.6	–
	AV	Standard	–		–		–		–	–	–	–	4.6
	AEX	Standard	2.0		2.2		2.7		3.0	3.1	–	3.8	4.6

Nominal No.		8	15	20	30	40	50	60	85	100	
Conductor	Number of strands/Diameter of strand	50/0.45	84/0.45	41/0.80	70/0.80	85/0.80	108/0.80	127/0.80	169/0.80	217/0.80	
	Sectional area (mm ²)	7.95	13.36	20.61	35.19	42.73	54.29	63.84	84.96	109.1	
	d (approx.)	3.7	4.8	6.0	8.0	8.6	9.8	10.4	12.0	13.6	
Cover D	AVS	–	–	–	–	–	–	–	–	–	
	AV	Standard	5.5	7.0	8.2	10.8	11.4	13.0	13.6	16.0	17.6
	AEX	Standard	5.3	7.0	8.2	10.8	11.4	13.0	13.6	16.0	17.6

Nominal No.		0.5f	0.5	0.75f	0.85	1.25f	1.25	
Conductor	Number of strands/Diameter of strand	–	7/Circular compressed	–	11/Circular compressed	–	16/Circular compressed	
	Sectional area (mm ²)	–	0.56	–	0.88	–	1.29	
	d (approx.)	–	0.9	–	1.1	–	1.4	
Cover D	CAVS	Standard	–	1.6	–	1.8	–	2.1

"f" of nominal No. denotes "flexible".



9JS02064

3. Color codes table

(Table 3)

Color Code	Color of wire	Color Code	Color of wire
B	Black	LgW	Light green & White
Br	Brown	LgY	Light green & Yellow
BrB	Brown & Black	LR	Blue & Red
BrR	Brown & Red	LW	Blue & White
BrW	Brown & White	LY	Blue & Yellow
BrY	Brown & Yellow	O	Orange
Ch	Charcoal	P	Pink
Dg	Dark green	R	Red
G	Green	RB	Red & Black
GB	Green & Black	RG	Red & Green
GL	Green & Blue	RL	Red & Blue
Gr	Gray	RW	Red & White
GR	Green & Red	RY	Red & Yellow
GW	Green & White	Sb	Sky Blue
GY	Green & Yellow	Y	Yellow
L	Blue	YB	Yellow & Black
LB	Blue & Black	YG	Yellow & Green
Lg	Light green	YL	Yellow & Blue
LgB	Light green & Black	YR	Yellow & Red
LgR	Light green & Red	YW	Yellow & White

Remarks: In a color code consisting of 2 colors, the first color is the color of the background and the second color is the color of the marking.

Example: "GW" means that the background is "Green" and marking is "White".

4. Types of circuits and color codes

(Table 4)

Type of wire		AVS, AV, CAVS						AEX	
Type of circuit	Charge	R	WG	-	-	-	-	R	-
	Ground	B	-	-	-	-	-	B	-
	Start	R	-	-	-	-	-	R	-
	Light	RW	RB	RY	RG	RL	-	D	-
	Instrument	Y	YR	YB	YG	YL	YW	Y	Gr
	Signal	G	GW	GR	GY	GB	GL	G	Br
	Others	L	LW	LR	LY	LB	-	L	-
		Br	BrW	BrR	BrY	BrB	-	-	-
		Lg	LgR	LgY	LgB	LgW	-	-	-
		O	-	-	-	-	-	-	-
		Gr	-	-	-	-	-	-	-
		P	-	-	-	-	-	-	-
		Sb	-	-	-	-	-	-	-
Dg	-	-	-	-	-	-	-		
Ch	-	-	-	-	-	-	-		

Precautions when performing work

(Rev. 2010/03)

When removing, installing, disassembling or assembling a unit, be sure to follow the general precautions given below.

1. Precautions for removal work

- If the coolant contains antifreeze, dispose of it correctly as chemicals.
- After disconnecting hoses or tubes, cover them or fit plugs to prevent dirt or dust from entering.
- When draining oil, prepare a container of adequate size to catch the oil.
- Check the match marks showing the installation position, and put match marks in the necessary places before removal to prevent any mistake when assembling.
- To prevent any excessive force from being applied to the wiring, always hold the connectors when disconnecting the connectors. Do not pull the wires.
- Attach the tags to wires and hoses to show their installation position to prevent any mistake when installing.
- Check the number and thickness of the shims, and keep them in a safe place.
- When slinging component, be sure to use lifting equipment of ample strength.
- When using forcing screws to remove any component, tighten the forcing screws uniformly and alternately.
- Before removing any unit, clean the surrounding area and fit a cover to prevent any dust or dirt from entering after removal.

★ Precautions when handling piping during disassembly

Put the following plugs into the piping after disconnecting it during disassembly operations.

1) Face seal type hoses and tubes


Nominal number	Plug (nut end)	Sleeve nut (elbow end)
02	07376 - 70210	02789 - 20210
03	07376 - 70315	02789 - 20315
04	07376 - 70422	02789 - 20422
05	07376 - 70522	02789 - 20522
06	07376 - 70628	02789 - 20628
10	07376 - 71034	07221 - 21034
12	07376 - 71234	07221 - 21234

2) Split flange type hoses and tubes

Nominal number	Flange (hose end)	Sleeve head (tube end)	Split flange
04	07379 - 00400	07378 - 10400	07371 - 30400
05	07379 - 00500	07378 - 10500	07371 - 30500

3) If the part is not under hydraulic pressure, the following corks can be used.

Nominal number	Part No.	Dimensions		
		D	d	L
06	07049 - 00608	6	5	8
08	07049 - 00811	8	6.5	11
10	07049 - 01012	10	8.5	12
12	07049 - 01215	12	10	15
14	07049 - 01418	14	11.5	18
16	07049 - 01620	16	13.5	20
18	07049 - 01822	18	15	22
20	07049 - 02025	20	17	25
22	07049 - 02228	22	18.5	28
24	07049 - 02430	24	20	30
27	07049 - 02734	27	22.5	34



2. Precautions for installation work

- Tighten all of the bolts and nuts (sleeve nuts) to the specified torque (KES).
- Install the hoses without twisting or interference and fix them with intermediate clamps, if available.
- Replace all of the gaskets, O-rings, cotter pins, and lock plates with new parts.
- Bend the cotter pins and lock plates securely.
- When coating with adhesive, clean and degrease the part, and coat the threaded portion with two to three drops of adhesive.
- When coating with liquid gasket, clean and degrease the surface, and apply it uniformly after making sure that the surface is free from dirt or damage.
- Clean all of the parts, and correct any damage, dents, burrs, or rust found on them.
- Coat the rotating parts and sliding parts with engine oil.
- When press-fitting parts, coat the surface with molybdenum disulfide lubricant (LM-P).
- After installing the snap rings, check that the snap ring is settled in the ring groove completely.
- When connecting wiring connectors, clean the connector to remove all oil, dirt, or water, then connect them securely.
- When using eyebolts, check that there is no deformation or deterioration, screw them in fully, and align the direction of the hook.
- When installing split flanges, fasten them uniformly and alternately to prevent excessive tightening on one side.
- ★ When operating the hydraulic cylinders for the first time after reassembling the cylinders, hydraulic pumps and other hydraulic component removed for repair, be sure to bleed the air as follows:
 - 1] Start and run the engine at low idle.
 - 2] Operate the work equipment control lever to operate the hydraulic cylinder four to five times, stopping the piston at 100 mm off the end of its stroke.
 - 3] Next, operate the hydraulic cylinder three to four times to the end of its stroke.
- ★ When using the machine for the first time after repair or long storage, follow the same procedure.

3. Precautions for completing work

- 1) Refilling of coolant, oil and grease
 - If the coolant is drained, close the drain valve, and add coolant to the specified level. Run the engine to circulate the coolant through the system. Then add the coolant again if necessary.
 - If the hydraulic component is removed and installed again, add engine oil to the specified level. Run the engine to circulate the oil through the system. Then add the oil again if necessary.
 - If the hydraulic piping or hydraulic equipment are removed, be sure to bleed air from the system after reassembling the parts, by referring to "Testing and adjusting".
 - Supply the specified amount of grease (molybdenum disulfide grease) to the work equipment parts.
- 2) Check of installed condition of cylinder head and manifolds

Check the cylinder head and intake and exhaust manifold mountings for looseness.
If any part is loosened, retighten it.

 - For the tightening torques, see the "Disassembly and assembly".
- 3) Checking engine piping for damage and looseness
 - Intake and exhaust system

Check the piping for damage, the mounting bolts and nuts for looseness, and the joints for air suction and exhaust gas leakage.
If any part is loosened or damaged, retighten or repair it.
 - Cooling system

Check the piping for damage, the mounting bolts and nuts for looseness, and the joints for coolant leakage.
If any part is loosened or damaged, retighten or repair it.
 - Fuel system

Check the piping for damage, the mounting bolts and nuts for looseness, and the joints for fuel leakage.
If any part is loosened or damaged, retighten or repair it.

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com