

XUV560E and XUV560E S4 Gator™ Utility Vehicles

(Serial No. 040001 -)

**TECHNICAL MANUAL
XUV560E and XUV560E S4
Gator™ Utility Vehicles
(Serial No. 040001-)
TM159819 30NOV20 (ENGLISH)**

John Deere Horicon Works
PRINTED IN U.S.A.




Introduction

Foreword

This manual is written for an experienced technician. Essential tools required in performing certain service work are identified in this manual and are recommended for use.

Live with safety: Read the safety messages in the introduction of this manual and the cautions presented throughout the text of the manual.

 This is the safety-alert symbol. When you see this symbol on the machine or in this manual, be alert to the potential for personal injury.

Technical manuals are divided in two parts: repair and operation and tests. Repair sections tell how to repair the components. Operation and tests sections help you identify the majority of routine failures quickly.

Information is organized in groups for the various components requiring service instruction. At the beginning of each group are summary listings of all applicable essential tools, service equipment and tools, other materials needed to do the job, service parts kits, specifications, wear tolerances, and torque values.

Technical Manuals are concise guides for specific machines. They are on-the-job guides containing only the vital information needed for diagnosis, analysis, testing, and repair.

Fundamental service information is available from other sources covering basic theory of operation, fundamentals of troubleshooting, general maintenance, and basic type of failures and their causes.

DX, TMIFC -19-15APR14-1/1

Contents

Section 10—General Information—Repair

- Group 10—Safety
- Group 20—General Specifications
- Group 30—Fuel and Lubricants
- Group 40—Machine Specifications

Section 20—Engine Repair

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble
- Group 30—Inspect

Section 30—Fuel, Air Intake, and Cooling System Repair

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble
- Group 30—Inspect

Section 40—Electrical Repair

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble

Section 50—Drivetrain Repair

- Group 05—General Information
- Group 10—Remove and Install
- Group 20—Disassemble and Assemble
- Group 30—Inspect

Section 60—Steering and Brake Repair

- Group 05—General Information
- Group 10—Remove and Install

Section 80—Attachments and Machine—Specific Repair

- Group 05—General Information
- Group 10—Remove and Install

Section 90—Operator Station Repair

- Group 05—General Information
- Group 10—Remove and Install Operator Station Components

Section 210—General Information — Diagnostics

- Group 05—General Information

Section 211—Diagnostic Trouble Codes

- Group 1—Control Unit ICC

Section 212—System Diagnostics Access

- Group 220—Engine
- Group 230—Fuel, Air Intake, and Cooling System
- Group 240—Electrical System
- Group 245—Electrical Control Units
- Group 250—Drivetrain
- Group 260—Steering and Brakes
- Group 280—Attachments

Section 220—Engine System Diagnostics

- Group 05—General Information
- Group 10—Operational and Preliminary Checks
- Group 20—Theory of Operation
- Group 50—Tests and Adjustments
- Group 50A—Diagnostics

Section 230—Fuel, Air Intake, and Cooling System Diagnostics

- Group 05—General Information
- Group 20—Theory of Operation
- Group 30—Schematics
- Group 50—Tests and Adjustments
- Group 50A—Diagnostics

Section 240—Electrical System Diagnostics

- Group 05—General Information
- Group 20A—Theory of Operation - Starting, Charging, and Power Distribution
- Group 20B—Theory of Operation - Steering and Brakes
- Group 20C—Theory of Operation - Operator Station
- Group 20D—Theory of Operation - CAN Bus
- Group 20E—Theory of Operation - Engine
- Group 20F—Theory of Operation - Lighting
- Group 20G—Theory of Operation - Drivetrain
- Group 30A—Schematics - Starting, Charging, and Power Distribution
- Group 30B—Schematics - Steering and Brakes
- Group 30C—Schematics - Operator Station
- Group 30D—Schematics - CAN Bus
- Group 30E—Schematics - Engine
- Group 30F—Schematics - Lighting
- Group 30G—Schematics - Drivetrain
- Group 50—Tests and Adjustments

Continued on next page

Original Instructions. All information, illustrations and specifications in this manual are based on the latest information available at the time of publication. The right is reserved to make changes at any time without notice.

COPYRIGHT © 2020
DEERE & COMPANY
Moline, Illinois
All rights reserved.
A John Deere ILLUSTRATION™ Manual

- Group 50A—Diagnostics - Starting, Charging, and Power Distribution
- Group 50B—Diagnostics - Steering and Brakes
- Group 50C—Diagnostics - Operator Station
- Group 50D—Diagnostics - CAN Bus
- Group 50E—Diagnostics - Engine Systems
- Group 50F—Diagnostics - Lighting
- Group 50G—Diagnostics - Drivetrain

**Section 245—Electrical Control Unit
Diagnostics**

- Group 05—General Information
- Group 20—Theory of Operation
- Group 30—Schematics
- Group 50A—Diagnostics

**Section 249—Electrical Systems—Con-
nectors**

- Group 05—General Information
- Group 40A—XA—Electrical Assembly Connectors
- Group 40B—XB—Sensor Connectors
- Group 40E—XE—Light Connectors
- Group 40F—XF—Fuse Connectors
- Group 40G—XG—Charging Connectors
- Group 40H—XH—Alarm Connectors
- Group 40K—XK—Relay Connectors
- Group 40L—XL—Inductor Connectors
- Group 40M—XM—Motor Connectors
- Group 40N—XN— Regulator Connectors
- Group 40R—XR—Resistor Connectors
- Group 40S—XS—Switch Connectors
- Group 40X—XX—Inline Connectors
- Group 40Y—XY—Solenoid Connectors

Section 250—Drivetrain System Diagnostics

- Group 20—Theory of Operation
- Group 50—Tests and Adjustments
- Group 50A—Diagnostics

**Section 260—Steering and Brake System
Diagnostics**

- Group 20—Theory of Operation
- Group 30—Schematics
- Group 50—Tests and Adjustments
- Group 50A—Diagnosis

**Section 280—Attachments and
Machine—Specific System
Diagnostics**

- Group 20—Theory of Operation
- Group 50A—Diagnostics

Section 300—Special Tools

- Group 10—Service Tools

Section 10 General Information—Repair


Contents

	Page		Page
Group 10—Safety			
Recognize Safety Information	10-10-1	Lubricant Storage	10-30-3
Understand Signal Words	10-10-1	Group 40—Machine Specifications	
Follow Safety Instructions	10-10-1	Machine Specifications XUV560, and XUV560 S4	10-40-1
Practice Safe Maintenance	10-10-2	Product Identification Number Location	10-40-2
Use Proper Tools	10-10-2		
Handle Fluids Safely—Avoid Fires	10-10-3		
Drain Gasoline When Storing Machine	10-10-3		
Handling Batteries Safely	10-10-4		
Prepare for Emergencies	10-10-4		
Parking Safely	10-10-5		
Support Machine Properly	10-10-5		
Wear Protective Clothing	10-10-5		
Work in Clean Area	10-10-5		
Service Machines Safely	10-10-6		
Work In Ventilated Area	10-10-6		
Illuminate Work Area Safely	10-10-6		
Replace Safety Signs	10-10-7		
Use Proper Lifting Equipment	10-10-7		
Keep ROPS Installed Properly	10-10-7		
Follow Tire Recommendations	10-10-8		
Decommissioning — Proper Recycling and Disposal of Fluids and Components	10-10-8		
Protect Against High Pressure Spray	10-10-9		
Live With Safety	10-10-9		
Group 20—General Specifications			
Service Recommendations for O-Ring Boss Fittings	10-20-1		
Service Recommendations For Flat Face O-Ring Seal Fittings	10-20-2		
Metric Cap Screw Torque Values—Grade 7	10-20-3		
Metric Bolt and Screw Torque Values	10-20-4		
Unified Inch Bolt and Screw Torque Values	10-20-5		
Group 30—Fuel and Lubricants			
Gasoline Engine Oil	10-30-1		
Oil Filters	10-30-1		
Gasoline Fuel for 4-Cycle Engines	10-30-1		
Transmission and 4WD Front Differential Oil	10-30-2		
Multipurpose Extreme Pressure (EP) Grease	10-30-2		
Mixing of Lubricants	10-30-2		
Alternative and Synthetic Lubricants	10-30-3		

Recognize Safety Information

This is a safety-alert symbol. When you see this symbol on your machine or in this manual, be alert to the potential for personal injury.

Follow recommended precautions and safe operating practices.



T81388 —UN—28JUN13

DX,ALERT -19-29SEP98-1/1

Understand Signal Words

DANGER; The signal word DANGER indicates a hazardous situation which, if not avoided, will result in death or serious injury.

WARNING; The signal word WARNING indicates a hazardous situation which, if not avoided, could result in death or serious injury.

CAUTION; The signal word CAUTION indicates a hazardous situation which, if not avoided, could result in minor or moderate injury. CAUTION may also be used to alert against unsafe practices associated with events which could lead to personal injury.

A signal word—DANGER, WARNING, or CAUTION—is used with the safety-alert symbol. DANGER identifies the most serious hazards. DANGER or WARNING safety signs are located near specific hazards. General



precautions are listed on CAUTION safety signs. CAUTION also calls attention to safety messages in this manual.

TS187 —19—30SEP88

DX,SIGNAL -19-05OCT16-1/1

Follow Safety Instructions

Carefully read all safety messages in this manual and on your machine safety signs. Keep safety signs in good condition. Replace missing or damaged safety signs. Be sure new equipment components and repair parts include the current safety signs. Replacement safety signs are available from your John Deere dealer.

There can be additional safety information contained on parts and components sourced from suppliers that is not reproduced in this operator's manual.

Learn how to operate the machine and how to use controls properly. Do not let anyone operate without instruction.

Keep your machine in proper working condition. Unauthorized modifications to the machine may impair the function and/or safety and affect machine life.



If you do not understand any part of this manual and need assistance, contact your John Deere dealer.

TS201 —UN—15APR13

DX,READ -19-16JUN09-1/1

Practice Safe Maintenance

Understand service procedure before doing work. Keep area clean and dry.

Never lubricate, service, or adjust machine while it is moving. Keep hands, feet, and clothing away from power-driven parts. Disengage all power and operate controls to relieve pressure. Lower equipment to the ground. Stop the engine. Remove the key. Allow machine to cool.

Securely support any machine elements that must be raised for service work.

Keep all parts in good condition and properly installed. Fix damage immediately. Replace worn or broken parts. Remove any buildup of grease, oil, or debris.

On self-propelled equipment, disconnect battery ground cable (-) before making adjustments on electrical systems or welding on machine.

On towed implements, disconnect wiring harnesses from tractor before servicing electrical system components or welding on machine.

Falling while cleaning or working at height can cause serious injury. Use a ladder or platform to easily reach each location. Use sturdy and secure footholds and handholds.



TS218 —UN—23AUG88

DX,SERV -19-28FEB17-1/1

Use Proper Tools

Use tools appropriate to the work. Makeshift tools and procedures can create safety hazards.

Use power tools only to loosen threaded parts and fasteners.

For loosening and tightening hardware, use the correct size tools. DO NOT use U.S. measurement tools on metric fasteners. Avoid bodily injury caused by slipping wrenches.

Use only service parts meeting John Deere specifications.



TS779 —UN—08NOV89

DX,REPAIR -19-17FEB99-1/1

Handle Fluids Safely—Avoid Fires

When you work around fuel, do not smoke or work near heaters or other fire hazards.

Store flammable fluids away from fire hazards. Do not incinerate or puncture pressurized containers.

Make sure machine is clean of trash, grease, and debris.

Do not store oily rags; they can ignite and burn spontaneously.



TS227—UN—15APR13

DX,FLAME -19-29SEP98-1/1

Drain Gasoline When Storing Machine

Gasoline stored in fuel tank can explode.

Never store equipment with gasoline in the tank inside a building where fumes may reach an open flame or spark.

Always drain gasoline from fuel tank and carburetor bowl when storing machine. Allow engine to cool before storing.



TS227—UN—15APR13

DX,STORE2 -19-26JAN90-1/1

Handling Batteries Safely

Battery gas can explode. Keep sparks and flames away from batteries. Use a flashlight to check battery electrolyte level.

Never check battery charge by placing a metal object across the posts. Use a voltmeter or hydrometer.

Always remove grounded (-) battery clamp first and replace grounded clamp last.

Sulfuric acid in battery electrolyte is poisonous and strong enough to burn skin, eat holes in clothing, and cause blindness if splashed into eyes.

Avoid hazards by:

- Filling batteries in a well-ventilated area
- Wearing eye protection and rubber gloves
- Avoiding use of air pressure to clean batteries
- Avoiding breathing fumes when electrolyte is added
- Avoiding spilling or dripping electrolyte
- Using correct battery booster or charger procedure.


If acid is spilled on skin or in eyes:

1. Flush skin with water.
2. Apply baking soda or lime to help neutralize the acid.
3. Flush eyes with water for 15—30 minutes. Get medical attention immediately.

If acid is swallowed:

1. Do not induce vomiting.
2. Drink large amounts of water or milk, but do not exceed 2 L (2 qt.).
3. Get medical attention immediately.

WARNING: Battery posts, terminals, and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and reproductive harm. **Wash hands after handling.**



TS204—UN—15APR13

TS203—UN—23AUG88


DX,WW,BATTERIES -19-02DEC10-1/1

Prepare for Emergencies

Be prepared if a fire starts.

Keep a first aid kit and fire extinguisher handy.

Keep emergency numbers for doctors, ambulance service, hospital, and fire department near your telephone.



TS291—UN—15APR13

DX,FIRE2 -19-03MAR93-1/1

Safety

Parking Safely

1. Stop vehicle on a level surface, not on a slope.
2. Fully lower the cargo box and any attachments on the machine that can be lowered.
3. Fully engage park brake and ensure vehicle is not moving.
4. Stop engine.
5. Remove key.
6. Before you leave the operator's seat, wait for engine and all moving parts to stop.
7. Disconnect the negative battery cable before servicing the machine.
8. Hang a "DO NOT OPERATE" tag in operator station.


MK71445,00000EF -19-05FEB19-1/1

Support Machine Properly

Always lower the attachment or implement to the ground before you work on the machine. If the work requires that the machine or attachment be lifted, provide secure support for them. If left in a raised position, hydraulically supported devices can settle or leak down.

Do not support the machine on cinder blocks, hollow tiles, or props that may crumble under continuous load. Do not work under a machine that is supported solely by a jack. Follow recommended procedures in this manual.

When implements or attachments are used with a machine, always follow safety precautions listed in the implement or attachment operator's manual.



TSS229 —UN—23AUG88

DX,LOWER -19-24FEB00-1/1


Wear Protective Clothing

Wear close fitting clothing and safety equipment appropriate to the job.

Prolonged exposure to loud noise can cause impairment or loss of hearing.

Wear a suitable hearing protective device such as earmuffs or earplugs to protect against objectionable or uncomfortable loud noises.

Operating equipment safely requires the full attention of the operator. Do not wear radio or music headphones while operating machine.




TSS206 —UN—15APR13

DX,WEAR -19-10SEP90-1/1

Work in Clean Area

Before starting a job:

- Clean work area and machine.
- Make sure you have all necessary tools to do your job.
- Have the right parts on hand.
- Read all instructions thoroughly; do not attempt shortcuts.




T6642EJ —UN—18OCT88

DX,CLEAN -19-04JUN90-1/1

Service Machines Safely

Tie long hair behind your head. Do not wear a necktie, scarf, loose clothing, or necklace when you work near machine tools or moving parts. If these items were to get caught, severe injury could result.

Remove rings and other jewelry to prevent electrical shorts and entanglement in moving parts.




TS228 —UN—23AUG88

DX,LOOSE -19-04JUN90-1/1

Work In Ventilated Area

Engine exhaust fumes can cause sickness or death. If it is necessary to run an engine in an enclosed area, remove the exhaust fumes from the area with an exhaust pipe extension.

If you do not have an exhaust pipe extension, open the doors and get outside air into the area.




TS220 —UN—15APR13

DX,AIR -19-17FEB99-1/1

Illuminate Work Area Safely

Illuminate your work area adequately but safely. Use a portable safety light for working inside or under the machine. Make sure the bulb is enclosed by a wire cage. The hot filament of an accidentally broken bulb can ignite spilled fuel or oil.




TS223 —UN—23AUG88

DX,LIGHT -19-04JUN90-1/1

Replace Safety Signs

Replace missing or damaged safety signs. See the machine operator's manual for correct safety sign placement.




TS201 —UN—15APR13

DX,SIGNS1 -19-04JUN90-1/1

Use Proper Lifting Equipment

Lifting heavy components incorrectly can cause severe injury or machine damage.

Follow recommended procedure for removal and installation of components in the manual.



TS226 —UN—23AUG88

DX,LIFT -19-04JUN90-1/1


Keep ROPS Installed Properly

Make certain all parts are reinstalled correctly if the roll-over protective structure (ROPS) is loosened or removed for any reason. Tighten mounting bolts to proper torque.

The protection offered by ROPS will be impaired if ROPS is subjected to structural damage, is involved in an overturn incident, or is in any way altered by welding, bending, drilling, or cutting. A damaged ROPS should be replaced, not reused.

The seat is part of the ROPS safety zone. Replace only with John Deere seat approved for your tractor.

Any alteration of the ROPS must be approved by the manufacturer.



TS212 —UN—23AUG88


DX,ROPS3 -19-12OCT11-1/1

Follow Tire Recommendations

Keep your machine in proper working order.

Use only prescribed tire sizes with correct ratings and inflate to the pressure specified in this manual.

Use of other than prescribed tires may decrease stability, affect steering, result in premature tire failure, or cause other durability or safety issues.




H111235—UN—13MAY14

DX,TIRE,INFO -19-19MAY14-1/1

Decommissioning — Proper Recycling and Disposal of Fluids and Components

Safety and environmental stewardship measures must be taken into account when decommissioning a machine and/or component. These measures include the following:

- Use appropriate tools and personal protective equipment such as clothing, gloves, face shields or glasses, during the removal or handling of objects and materials.
- Follow instructions for specialized components.
- Release stored energy by lowering suspended machine elements, relaxing springs, disconnecting the battery or other electrical power, and releasing pressure in hydraulic components, accumulators, and other similar systems.
- Minimize exposure to components which may have residue from agricultural chemicals, such as fertilizers and pesticides. Handle and dispose of these components appropriately.
- Carefully drain engines, fuel tanks, radiators, hydraulic cylinders, reservoirs, and lines before recycling components. Use leak-proof containers when draining fluids. Do not use food or beverage containers.
- Do not pour waste fluids onto the ground, down a drain, or into any water source.
- Observe all national, state, and local laws, regulations, or ordinances governing the handling or disposal of waste fluids (example: oil, fuel, coolant, brake fluid);



TS1133—UN—15APR13


- filters; batteries; and, other substances or parts. Burning of flammable fluids or components in other than specially designed incinerators may be prohibited by law and could result in exposure to harmful fumes or ashes.
- Service and dispose of air conditioning systems appropriately. Government regulations may require a certified service center to recover and recycle air conditioning refrigerants which could damage the atmosphere if allowed to escape.
 - Evaluate recycling options for tires, metal, plastic, glass, rubber, and electronic components which may be recyclable, in part or completely.
 - Contact your local environmental or recycling center, or your John Deere dealer for information on the proper way to recycle or dispose of waste.

DX,DRAIN -19-01JUN15-1/1

Protect Against High Pressure Spray

Spray from high pressure nozzles can penetrate the skin and cause serious injury. Keep spray from contacting hands or body.

If an accident occurs, see a doctor immediately. Any high pressure spray injected into the skin must be surgically removed within a few hours or gangrene may result. Doctors unfamiliar with this type of injury should reference a knowledgeable medical source. Such information is available from Deere & Company Medical Department in Moline, Illinois, U.S.A.



TS1343 —UN—18MAR92

DX,SPRAY -19-16APR92-1/1

Live With Safety

Before returning machine to customer, make sure machine is functioning properly, especially the safety systems. Install all guards and shields.



TS231 —19—07OCT88


DX,LIVE -19-25SEP92-1/1

Group 20 General Specifications

Service Recommendations for O-Ring Boss Fittings

Straight Fitting

1. Inspect O-ring boss seat for dirt or defects.
2. Lubricate O-ring with petroleum jelly. Place electrical tape over threads to protect O-ring. Slide O-ring over tape and into O-ring groove of fitting. Remove tape.
3. Tighten fitting to torque value shown on chart.



Straight Fitting

T6243AE — UN — 15APR13


04T,90,K66 -19-29SEP99-1/2

Angle Fitting

1. Back off lock nut (A) and backup washer (B) completely to head end (C) of fitting.
2. Turn fitting into threaded boss until backup washer contacts face of boss.
3. Turn fitting head end counterclockwise to proper index (maximum of one turn).

NOTE: Do not allow hoses to twist when tightening fittings.

4. Hold fitting head end with a wrench and tighten locknut and backup washer to proper torque value.



Angle Fitting

A—Lock Nut
B—Backup Washer
C—Head End

T6520AB — UN — 15APR13

STRAIGHT FITTING OR SPECIAL NUT TORQUE CHART		
Thread Size	N·m	lb·ft
3/8-24 UNF	8	6
7/16-20 UNF	12	9
1/2-20 UNF	16	12
9/16-18 UNF	24	18
3/4-16 UNF	46	34
7/8-14 UNF	62	46
1-1/16-12 UN	102	75
1-3/16-12 UN	122	90
1-5/16-12 UN	142	105
1-5/8-12 UN	190	140
1-7/8-12 UN	217	160

NOTE: Torque tolerance is ± 10%.

04T,90,K66 -19-29SEP99-2/2

General Specifications

Service Recommendations For Flat Face O-Ring Seal Fittings

1. Inspect the fitting sealing surfaces and O-ring. They must be free of dirt or defects.
2. Lubricate O-rings and install into groove using petroleum jelly to hold in place.
3. Index angle fittings and tighten by hand pressing joint together to insure O-ring remains in place.

4. Tighten fitting or nut to torque value shown on the chart. Do not allow hoses to twist when tightening fittings, use backup wrench on straight hose couplings.

IMPORTANT: Tighten fittings to 150% of listed torque value if indexing is necessary or if fitting is attached to an actuating device.

Tighten fittings to 50% of listed torque value if used in aluminum housing.

FLAT FACE O-RING SEAL FITTING TORQUE*						
Nomial Tube O.D.		Thread Size	Swivel Nut		Bulkhead Nut	
mm	in.	in.	N·m	lb·ft	N·m	lb·ft
6.35	0.250	9/16-18	16	12	12	9
9.52	0.375	11/16-16	24	18	24	18
12.70	0.500	13/16-16	50	37	46	34
15.88	0.625	1-14	69	51	62	46
19.05	0.750	1 3/16-12	102	75	102	75
22.22	0.875	1 3/16-12	102	75	102	75
25.40	1.000	1 7/16-12	142	105	142	105
31.75	1.250	1 11/16-12	190	140	190	140
38.10	1.500	2-12	217	160	217	160

*Torque tolerance is +15 -20% unless otherwise specified.

Stud End O-ring Seal Torque for Straight and Adjustable Fittings*				
Thread Size	Straight Hex Size	Locknut Hex Size	Straight Fitting or Locknut Toque	
Inch	Inch	Inch	N·m	lb·ft
3/8-24	5/8	9/16	12	9
7/16-20	5/8	5/8	21	15
1/2-20	3/4	11/16	26	19
9/16-18	3/4	3/4	34	25
3/4-16	7/8	15/16	73	55
7/8-14	1 1/16	1 1/16	104	76
1 1/16-12	1 1/4	1 3/8	176	130
1 3/16-12	1 3/8	1 1/2	230	170
1 5/16-12	1 1/2	1 5/8	285	210

*Torque tolerance is +15 -20% unless otherwise specified.

OUO6092,00010A4 -19-31MAY11-1/1

General Specifications

Metric Cap Screw Torque Values—Grade 7

NOTE: When bolting aluminum parts, tighten to 80% of torque specified in table.


Size	N·m	(lb-ft)
M6	9.5—12.2	(7—9)
M8	20.3—27.1	(15—20)
M10	47.5—54.2	(35—40)
M12	81.4—94.9	(60—70)
M14	128.8—146.4	(95—108)
M16	210.2—240	(155—177)

CED,OUO1085,12 -19-31JUL00-1/1

General Specifications

Metric Bolt and Screw Torque Values

TS1742 —UN—31MAY18




Bolt or Screw Size	Class 4.8				Class 8.8 or 9.8				Class 10.9				Class 12.9			
	Hex Head ^a		Flange Head ^b		Hex Head ^a		Flange Head ^b		Hex Head ^a		Flange Head ^b		Hex Head ^a		Flange Head ^b	
	N·m	lb·in	N·m	lb·in	N·m	lb·in	N·m	lb·in	N·m	lb·in	N·m	lb·in	N·m	lb·in	N·m	lb·in
M6	3.6	31.9	3.9	34.5	6.7	59.3	7.3	64.6	9.8	86.7	10.8	95.6	11.5	102	12.6	112
									N·m	lb·ft	N·m	lb·ft	N·m	lb·ft	N·m	lb·ft
M8	8.6	76.1	9.4	83.2	16.2	143	17.6	156	23.8	17.6	25.9	19.1	27.8	20.5	30.3	22.3
			N·m	lb·ft	N·m	lb·ft	N·m	lb·ft								
M10	16.9	150	18.4	13.6	31.9	23.5	34.7	25.6	46.8	34.5	51	37.6	55	40.6	60	44.3
	N·m	lb·ft														
M12	—	—	—	—	55	40.6	61	45	81	59.7	89	65.6	95	70.1	105	77.4
M14	—	—	—	—	87	64.2	96	70.8	128	94.4	141	104	150	111	165	122
M16	—	—	—	—	135	99.6	149	110	198	146	219	162	232	171	257	190
M18	—	—	—	—	193	142	214	158	275	203	304	224	322	245	356	263
M20	—	—	—	—	272	201	301	222	387	285	428	316	453	334	501	370
M22	—	—	—	—	365	263	405	299	520	384	576	425	608	448	674	497
M24	—	—	—	—	468	345	518	382	666	491	738	544	780	575	864	637
M27	—	—	—	—	683	504	758	559	973	718	1080	797	1139	840	1263	932
M30	—	—	—	—	932	687	1029	759	1327	979	1466	1081	1553	1145	1715	1265
M33	—	—	—	—	1258	928	1398	1031	1788	1319	1986	1465	2092	1543	2324	1714
M36	—	—	—	—	1617	1193	1789	1319	2303	1699	2548	1879	2695	1988	2982	2199

The nominal torque values listed are for general use only with the assumed wrenching accuracy of 20%, such as a manual torque wrench. DO NOT use these values if a different torque value or tightening procedure is given for a specific application. For lock nuts, for stainless steel fasteners, or for nuts on U-bolts, see the tightening instructions for the specific application.

Replace fasteners with the same or higher property class. If higher property class fasteners are used, tighten these to the strength of the original.

- Make sure that fastener threads are clean.
- Apply a thin coat of Hy-Gard™ or equivalent oil under the head and on the threads of the fastener, as shown in the following image.
- Be conservative with the amount of oil to reduce the potential for hydraulic lockup in blind holes due to excessive oil.
- Properly start thread engagement.

TS1741 —UN—22MAY18



^aHex head column values are valid for ISO 4014 and ISO 4017 hex head, ISO 4162 hex socket head, and ISO 4032 hex nuts.


^bHex flange column values are valid for ASME B18.2.3.9M, ISO 4161, or EN 1665 hex flange products.

DX,TORQ2 -19-30MAY18-1/1

General Specifications

Unified Inch Bolt and Screw Torque Values

TS1671 —UN—01MAY03




Bolt or Screw Size	SAE Grade 1 ^a				SAE Grade 2 ^b				SAE Grade 5, 5.1 or 5.2				SAE Grade 8 or 8.2			
	Hex Head ^c		Flange Head ^d		Hex Head ^c		Flange Head ^d		Hex Head ^c		Flange Head ^d		Hex Head ^c		Flange Head ^d	
	N·m	lb·in	N·m	lb·in	N·m	lb·in	N·m	lb·in	N·m	lb·in	N·m	lb·in	N·m	lb·in	N·m	lb·in
1/4	3.1	27.3	3.2	28.4	5.1	45.5	5.3	47.3	7.9	70.2	8.3	73.1	11.2	99.2	11.6	103
													N·m	lb·ft	N·m	lb·ft
5/16	6.1	54.1	6.5	57.7	10.2	90.2	10.9	96.2	15.7	139	16.8	149	22.2	16.4	23.7	17.5
									N·m	lb·ft	N·m	lb·ft				
3/8	10.5	93.6	11.5	102	17.6	156	19.2	170	27.3	20.1	29.7	21.9	38.5	28.4	41.9	30.9
					N·m	lb·ft	N·m	lb·ft								
7/16	16.7	148	18.4	163	27.8	20.5	30.6	22.6	43	31.7	47.3	34.9	60.6	44.7	66.8	49.3
	N·m	lb·ft	N·m	lb·ft												
1/2	25.9	19.1	28.2	20.8	43.1	31.8	47	34.7	66.6	49.1	72.8	53.7	94	69.3	103	75.8
9/16	36.7	27.1	40.5	29.9	61.1	45.1	67.5	49.8	94.6	69.8	104	77	134	98.5	148	109
5/8	51	37.6	55.9	41.2	85	62.7	93.1	68.7	131	96.9	144	106	186	137	203	150
3/4	89.5	66	98	72.3	149	110	164	121	230	170	252	186	325	240	357	263
7/8	144	106	157	116	144	106	157	116	370	273	405	299	522	385	572	422
1	216	159	236	174	216	159	236	174	556	410	609	449	785	579	860	634
1-1/8	305	225	335	247	305	225	335	247	685	505	751	554	1110	819	1218	898
1-1/4	427	315	469	346	427	315	469	346	957	706	1051	775	1552	1145	1703	1256
1-3/8	564	416	618	456	564	416	618	456	1264	932	1386	1022	2050	1512	2248	1658
1-1/2	743	548	815	601	743	548	815	601	1665	1228	1826	1347	2699	1991	2962	2185

The nominal torque values listed are for general use only with the assumed wrenching accuracy of 20%, such as a manual torque wrench. DO NOT use these values if a different torque value or tightening procedure is given for a specific application. For lock nuts, for stainless steel fasteners, or for nuts on U-bolts, see the tightening instructions for the specific application.

Replace fasteners with the same or higher property class. If higher property class fasteners are used, tighten these to the strength of the original.

- Make sure that fastener threads are clean.
- Apply a thin coat of Hy-Gard™ or equivalent oil under the head and on the threads of the fastener, as shown in the following image.
- Be conservative with the amount of oil to reduce the potential for hydraulic lockup in blind holes due to excessive oil.
- Properly start thread engagement.

TS1741 —UN—22MAY18



^aGrade 1 applies for hex cap screws over 6 in (152 mm) long, and for all other types of bolts and screws of any length.

^bGrade 2 applies for hex cap screws (not hex bolts) up to 6 in (152 mm) long.

^cHex head column values are valid for ISO 4014 and ISO 4017 hex head, ISO 4162 hex socket head, and ISO 4032 hex nuts.

^dHex flange column values are valid for ASME B18.2.3.9M, ISO 4161, or EN 1665 hex flange products.

DX,TORQ1 -19-30MAY18-1/1

General Specifications

Gasoline Engine Oil

Use oil viscosity based on the expected air temperature range during the period between oil changes.

Using single viscosity grade oils such as SAE 30 or SAE 40 can reduce oil consumption in air cooled engines.


The following oils are approved:

- John Deere Plus-50™ II
- John Deere Turf-Gard™

Other oils may be used if they meet one or more of the following:

- ILSAC GF-6A
- API Service Category SP
- API Service Category SN
- API Service Category SM
- API Service Category SL
- API Service Category SJ
- ACEA Oil Sequence A3/B3
- ACEA Oil Sequence A3/B4
- ACEA Oil Sequence A5/B5
- ACEA Oil Sequence C5
- ACEA Oil Sequence C4
- ACEA Oil Sequence C3
- ACEA Oil Sequence C2

*Plus-50 is a trademark of Deere & Company
Turf-Gard is a trademark of Deere & Company*



Oil Viscosities for Air Temperature Ranges

- ACEA Oil Sequence C1

TS1744 —UN—25AUG20

DX,ENOil2 -19-15JUL20-1/1

Oil Filters

Filtration of oils is critical to proper operation and lubrication.

Always change filters regularly as specified in this manual.

Use filters meeting John Deere performance specifications.

DX,FILT -19-18MAR96-1/1

Gasoline Fuel for 4-Cycle Engines

Use unleaded gasoline with a minimum octane rating of 87 AKI (anti-knock index) or 90 RON (research octane number). Gasoline fuels specified to EN 228 or ASTM D4814 are recommended.

Fuel blends of unleaded gasoline with a maximum 10% ethanol or 15% MTBE (methyl tertiary-butyl ether) are also acceptable.

⚠ CAUTION: Reduce the risk of fire. Handle fuel carefully. DO NOT fill the fuel tank when the engine is running or hot. Stop engine and allow it to cool for several minutes before filling fuel tank. Fill fuel tank only to the bottom of the filler neck.

Refuel outdoors. DO NOT smoke while you fill the fuel tank or service the fuel system.

Store fuel in properly identified polyethylene containers.

When storing fuel, add John Deere Gasoline Conditioner and Stabilizer (or equivalent) at the specified concentration.

IMPORTANT: DO NOT use methanol or fuel blends that contain methanol.

Avoid spilling fuel. Gasoline can damage plastic and painted surfaces.

DO NOT mix oil with gasoline.

DX,FUEL2 -19-15MAY13-1/1

Transmission and 4WD Front Differential Oil

IMPORTANT: Avoid damage! DO NOT mix any other oils in this transmission. DO NOT use engine oil or "Type F" (Red) Automatic Transmission Fluid in this transmission.

John Deere J20D Low Viscosity Hy-Gard™ transmission and hydraulic oil is recommended.

Hy-Gard is a trademark of Deere & Company

Other oils can be used if recommended John Deere oils are not available, provided they meet the following specifications:

- John Deere Standard JDM J20D

MX52301,0002CA3 -19-20NOV20-1/1

Multipurpose Extreme Pressure (EP) Grease

IMPORTANT: For automated lubrication systems different ambient air temperatures need to be considered.

Use grease based on NLGI consistency numbers and the expected air temperature range during the service interval.

John Deere SD Polyurea Grease is preferred.

The following greases are also recommended:


- John Deere HD Lithium Complex Grease
- John Deere Grease-Gard™ Premium Plus

Other greases may be used if they meet the following:

- NLGI Performance Classification GC-LB
- ISO-L-X-BDHB 2 or DIN KP 2 N-10 Lithium Complex, Non-Synthetic Base Oil (100 to 220 mm²/s @ 40°C)

IMPORTANT: Some types of thickeners, base oils, and additives used in greases are not compatible with others. Mixing greases should be avoided. Consult your grease supplier before mixing different types of grease.

Grease-Gard is a trademark of Deere & Company



Greases for Air Temperature Ranges

RG30199—UN—08MAR18

DX,GREA1 -19-13JAN18-1/1

Mixing of Lubricants

In general, avoid mixing different brands or types of oil. Oil manufacturers blend additives in their oils to meet certain specifications and performance requirements.

Mixing different oils can interfere with the proper functioning of these additives and degrade lubricant performance.

Consult your John Deere dealer to obtain specific information and recommendations.

DX,LUBMIX -19-18MAR96-1/1

Alternative and Synthetic Lubricants

Conditions in certain geographical areas may require lubricant recommendations different from those printed in this manual.

Some John Deere brand coolants and lubricants may not be available in your location.

Consult your John Deere dealer to obtain information and recommendations.

Synthetic lubricants may be used if they meet the performance requirements as shown in this manual.

The temperature limits and service intervals shown in this manual apply to John Deere branded fluids or fluids that have been tested and/or approved for use in John Deere equipment.

Re-refined base stock products may be used if the finished lubricant meets the performance requirements.

DX,ALTER -19-13JAN18-1/1

Lubricant Storage

Your equipment can operate at top efficiency only when clean lubricants are used.

Use clean containers to handle all lubricants.

Store lubricants and containers in an area protected from dust, moisture, and other contamination. Store containers on their side to avoid water and dirt accumulation.

Make certain that all containers are properly marked to identify their contents.

Properly dispose of all old containers and any residual lubricant they may contain.

DX,LUBST -19-11APR11-1/1

Machine Specifications XUV560, and XUV560 S4

NOTE: Specifications and design subject to change without notice.

	XUV560	XUV560 S4	XUV560 Export
Ground Speed:			
Forward - Range LO	0—34 km/h (0—21 mph)		
Forward - Range HI	45 km/h (28 mph)		
Reverse	0—26 km/h (0—16 mph)		
Engine:			
Make	Briggs & Stratton		
Engine Power Information	http://www.briggsandstratton.com		
Type	Gas		
Model	355447		
Slow Idle Speed	650—800 rpm		
Slow Idle Speed (Governed)	1150 ± 100 rpm		
Fast Idle Speed	4100 ± 100 rpm		
Cylinders	V-twin		
Displacement	0.570 L (34.7 in. ³)		
Bore	72 mm (2.83 in)		
Stroke	70 mm (2.76 in)		
Lubrication	Pressurized		
Cooling	Air Cooled		
Air Cleaner	Dry-Type Element		
Engine Shut Off	Key Switch		
Fuel System:			
Type	Mechanical Vacuum Pump		
Electrical System:			
Type	12 Volt Negative Ground		
Alternator	16 A		50 A
Battery	12 volt		
Cold Cranking Amps	340		
Voltage Rectifier and Regulator Module Output at 1150 rpm (idle)	7 amps		
Voltage Rectifier and Regulator Module Output at 4100 rpm (full throttle)	16 amps		
Voltage Rectifier and Regulator Module Output at 1300 rpm			20 amps
Voltage Rectifier and Regulator Module Output at 3600 rpm			50 amps
Spark Plug Gap	0.76 mm (0.030 in)		

Continued on next page

SR99263,00000E1 -19-30JUL19-1/2

Machine Specifications

Ignition Coil Air Gap	0.20—0.30 mm (0.008—0.012 in)		
Steering:			
Type	Rack and Pinion		
Brakes:			
Type	All Wheel Hydraulic Disc		
Capacities:			
Fuel Tank	18.5 L (4.9 gal)		
Crankcase (with Filter)	1.4 L (1.5 qt)		
Transmission	2.4—2.8 L (2.54—2.96 qt)		
MFWD Front Differential	0.4—0.6 L (13.5—20.3 oz)		
Dimensions:			
Overall Length with Bumper	2.92 m (115 in)	3.71 m (146 in)	2.92 m (115 in)
Overall Width	1.45 m (57 in)	1.45 m (57 in)	1.45 m (57 in)
Ground Clearance	26.2 cm (10.3 in)	23.6 cm (9.3 in)	26.2 cm (10.3 in)

SR99263,00000E1 -19-30JUL19-2/2

Product Identification Number Location

Product identification number (A), also called serial number or chassis number, is located on the rear of the frame.




MXT001072—UN—06SEP11

Continued on next page

OUMX258,00001BE -19-06SEP11-1/2

Machine Specifications

Engine identification number (B), is located on the engine or valve cover.



MXT001073—UN—06SEP11

OUMX258,00001BE -19-06SEP11-2/2

Machine Specifications

Section 20 Engine Repair

Contents

	Page
Group 05—General Information	
Summary of References.....	20-05-1
Essential or Recommended Tools.....	20-05-1
Group 10—Remove and Install	
Specifications	20-10-1
Remove and Inspect Crankshaft and Camshaft	20-10-2
Install Crankshaft and Camshaft	20-10-4
Remove Cylinder Head	20-10-5
Install Cylinder Head	20-10-7
Remove Engine	20-10-10
Install Engine	20-10-13
Remove Flywheel.....	20-10-14
Install Flywheel.....	20-10-17
Remove Flywheel (High Capacity)	20-10-17
Install Flywheel (High Capacity)	20-10-21
Remove and Install Intake Manifold	20-10-22
Remove Oil Pump	20-10-24
Remove Piston, Rings and Rod	20-10-28
Install Piston and Rod.....	20-10-29
Remove Valve	20-10-31
Install Valve	20-10-32
Group 20—Disassemble and Assemble	
Assemble Piston and Rod	20-20-1
Group 30—Inspect	
Specifications	20-30-1
Repair Breather Valve	20-30-2
Clean Cylinder Bore	20-30-4
Hone Cylinder Bore	20-30-5
Inspect Cylinder Bore	20-30-5
Resize Cylinder Bore.....	20-30-6
Inspect and Repair Cylinder Head.....	20-30-7
Inspect Magneto Bearing.....	20-30-7
Check Piston Ring End Gap.....	20-30-9
Inspect Piston and Rod	20-30-9
Inspect PTO and Cam Bearing.....	20-30-11
Inspect and Repair Valves and Guides	20-30-11
Ream Valve Guide.....	20-30-13

Summary of References

Remove and Install

- [Remove and Inspect Crankshaft and Camshaft](#)
- [Install Crankshaft and Camshaft](#)
- [Remove Cylinder Head](#)
- [Install Cylinder Head](#)
- [Remove Engine](#)
- [Install Engine](#)
- [Remove Flywheel](#)
- [Install Flywheel](#)
- [Remove Flywheel \(High Capacity\)](#)
- [Install Flywheel \(High Capacity\)](#)
- [Remove and Install Intake Manifold](#)
- [Remove Oil Pump](#)
- [Remove Piston, Rings and Rod](#)
- [Install Piston and Rod](#)
- [Remove Valve](#)
- [Install Valve](#)

Disassemble and Assemble

- [Assemble Piston and Rod](#)

Inspect

- [Repair Breather Valve](#)
- [Clean Cylinder Bore](#)
- [Hone Cylinder Bore](#)
- [Inspect Cylinder Bore](#)
- [Resize Cylinder Bore](#)
- [Inspect and Repair Cylinder Head](#)
- [Inspect Magneto Bearing](#)
- [Check Piston Ring End Gap](#)
- [Inspect Piston and Rod](#)
- [Inspect PTO and Cam Bearing](#)
- [Inspect and Repair Valves and Guides](#)
- [Ream Valve Guide](#)

MX52301,0002A97 -19-19OCT20-1/1

Essential or Recommended Tools

NOTE: Order tools from the SERVICEGARD™ Catalog.

ESSENTIAL TOOLS listed are required to perform the job correctly and are obtainable only from the SERVICEGARD™ Catalog.

SERVICEGARD is a trademark of Deere & Company

RECOMMENDED TOOLS, as noted, are suggested to perform the job correctly. Some tools may be available from local suppliers or may be fabricated.

MX52301,000297C -19-02OCT20-1/2

JDG1640 Flywheel Removal Tool JDG1640 Remove high capacity flywheel.

MX52301,000297C -19-02OCT20-2/2

General Information

Specifications

Item	Measurement	Specification
Crankshaft Wear Limits		
PTO Journal	Wear Limit	34.92 mm (1.375 in)
Magneto Journal	Wear Limit	34.95 mm (1.376 in)
Crankshaft Crank Pin	Wear Limit	36.95 mm (1.455 in)
Camshaft Wear Limits		
PTO Journal	Wear Limit	19.92 mm (0.784 in)
Magneto Journal	Wear Limit	15.93 mm (0.627 in)
Cam Lobe	Wear Limit	30.25 mm (1.191 in)
Cylinder Head Bolts	Torque	19 N·m (165 lb·in)
Rocker Stud	Torque	16 N·m (140 lb·in)
Valve Cover Screws	Torque	3.4 N·m (30 lb·in)
Spark Plug	Gap	0.76 mm (0.030 in)
Spark Plug	Torque	20 N·m (180 lb·in)
Clutch Enclosure-to-Transmission	Torque	32 N·m (24 lb·ft)
Engine Mounting Bolts	Torque	32 N·m (24 lb·ft)
Exhaust Pipe Flange Bolts	Torque	17 N·m (150 lb·ft)
Flywheel Nut	Torque	170 N·m (125 lb·ft)
Ignition Coil	Gap	0.20—0.30 mm (0.008—0.012 in)
Intake Manifold Screws	Torque	16 N·m (140 lb·in)
Crankcase Cover Bolts	Torque	17 N·m (150 lb·in)
Connecting Rod Bolts	Torque	13 N·m (115 lb·in)
Voltage Regulator to Engine	Torque	3.4 N·m (30 lb·in)
Voltage Regulator to Engine	Torque	17 N·m (150 lb·in)

MX52301,0002985 -19-02OCT20-1/1


Remove and Inspect Crankshaft and Camshaft

NOTE: Before crankcase cover (A) is removed, it is recommended that any rust, paint, or burrs be removed from power take off end of crankshaft. This eliminates or reduces chances of damaging the crankcase cover bearing.

1. Remove governor lever and disconnect governor link and springs. Remove governor control bracket. Remove oil fill tube and dipstick assembly.
2. Remove exhaust manifold, intake manifold, and cylinder heads.

IMPORTANT: Avoid Damage! DO NOT remove dowel pins.

3. Remove crankcase cover. If crankcase cover sticks, tap lightly with soft hammer on alternate sides near dowel pin locations.
4. Tip engine onto the flywheel side of crankcase.
5. Support engine to prevent end of crankshaft from resting on workbench.



A—Crankcase Cover

MXT001715—UN—10OCT11


OUMX068.00000E0 -19-30JUL19-1/4

6. Rotate crankshaft until timing marks (B) are aligned. With cam gear in this position, the valve tappets remain clear of cam lobes.

IMPORTANT: Avoid Damage! If engine is rotated from this position, tappets will fall out. Tappets must not be mixed.

7. Lift out cam gear and governor assembly.
8. Mark the connecting rods and caps to prevent interchanging when reassembling.
9. Remove piston and connecting rod assemblies.

B—Timing Marks



MXT001716—UN—10OCT11

Continued on next page

OUMX068.00000E0 -19-30JUL19-2/4


10. Remove crankshaft from crankcase.

IMPORTANT: Avoid Damage! All wear points on the crankshaft must be measured.

11. Inspect and measure the crankshaft. Replace crankshaft if worn or if journals are scored. Keyways should be checked to be sure that they are not worn or spread. To prevent damaging the bearing or oil seal, remove burrs from keyway edges. Check oil galleries for blockage or obstructions.

Crankshaft Wear Limits—Specification

PTO Journal—Wear	
Limit.....	34.92 mm (1.375 in)
Magneto Journal—Wear	
Limit.....	34.95 mm (1.376 in)
Crankshaft Crank	
Pin—Wear Limit.....	36.95 mm (1.455 in)



C—Magneto Journal
D—Oil Galleries
E—Crankpin
F—Timing Gear Teeth
G—PTO Journal
H—Keyway
I—Oil Galleries
J—Threads and Keyway

OUMX068,00000E0 -19-30JUL19-3/4

MXT001717 —UN—10OCT11


12. Check camshaft timing gear for chipped or cracked teeth. Replace if needed.

13. The compression release balls must be clean and free to move when the centrifugal weight is rotated counterclockwise. When the centrifugal weight is released, the balls should move up into the locked position.

14. Inspect cam gear teeth, lobes, and journals for wear and nicks. Replace cam gear if worn or damaged.

Camshaft Wear Limits—Specification

PTO Journal—Wear	
Limit.....	19.92 mm (0.784 in)
Magneto Journal—Wear	
Limit.....	15.93 mm (0.627 in)
Cam Lobe—Wear Limit.....	
	30.25 mm (1.191 in)



K—Magneto Journal
L—Cam Lobes
M—Gear Teeth
N—Spring
O—PTO Journal
P—Compression Release Balls
Q—Flywheel Pivot
R—Exhaust Lobe
S—Intake Lobe

OUMX068,00000E0 -19-30JUL19-4/4


MXT001718 —UN—13OCT11

Install Crankshaft and Camshaft

1. Governor slider (A) must move freely on PTO journal of cam gear. Flywheel must pivot freely. Make sure flyweight spring is not stretched. Governor weights must move freely on hinge pins. Make sure hinge pins are not loose.
2. Assemble governor slider onto PTO journal on cam gear making sure that slot on slider fits over locating pin (B) on cam gear. Be sure the weights are in the proper location so that they will be able to move freely without binding.
3. Install crankshaft and camshaft, aligning timing marks (C) accordingly. Install thrust washer (D), if required. Tip engine to position crankshaft horizontally.

A—Governor Slider
B—Locating Pin

C—Timing Marks
D—Thrust Washer




MXT001763—UN—13OCT11

OUMX068,00000E2 -19-13OCT11-1/4

NOTE: Be sure O-ring (E) is installed in crankcase.

4. Place new crankcase cover gasket on crankcase.

E—O-ring




MXT001720—UN—13OCT11

OUMX068,00000E2 -19-13OCT11-2/4

5. Rotate governor shaft (F) against boss (G).
6. Take care to protect the oil seal while assembling crankcase cover. No force should be used.

F—Governor Shaft

G—Boss




MXT001721—UN—13OCT11

Continued on next page

OUMX068,00000E2 -19-13OCT11-3/4

Remove and Install

7. Tighten cover bolts to specification in the sequence shown.
8. Install cylinder heads. (See [Install Cylinder Head](#).)
9. Install flywheel. (See [Install Flywheel](#), or [Install Flywheel \(High Capacity\)](#).)
10. Install intake manifold and carburetor assembly. (See [Install Carburetor](#).)
11. Install governor lever and governor springs.
12. Install oil fill tube and dipstick assembly. Perform static governor adjustment. (See [Adjust Governor](#).)
13. Install engine shrouding.



MXT001722 —UN—10OCT11

OUMX068,00000E2 -19-13OCT11-4/4


Remove Cylinder Head

IMPORTANT: Avoid Damage! Mark all parts when disassembling cylinder heads to prevent interchanging.

1. Disconnect spark plug leads and remove spark plugs.
2. Remove intake manifold. (See [Remove and Install Intake Manifold](#).)
3. Remove cylinder air guides.
4. Remove bolts (A), and valve cover (B).

A—Bolts

B—Cover




MXT001596 —UN—06OCT11

OUMX068,00000C8 -19-30JUL19-1/5

5. Release valve spring pressure from rocker arms (C) by rocking the arm against spring pressure and allowing push rod (D) to drop out of the rocker arm socket. Push rod will move out of position, releasing valve spring (E) pressure.

C—Rocker Arms
D—Push Rod

E—Valve Spring



MXT001597 —UN—06OCT11

Continued on next page

OUMX068,00000C8 -19-30JUL19-2/5


Remove and Install

IMPORTANT: Avoid Damage! Exhaust valve and intake valve push rods are different. Mark push rods for correct reinstallation.

6. Remove rocker studs (F).
7. Remove rocker arm assemblies (G) and push rods (H).

F—Rocker Studs
G—Rocker Arms

H—Push Rods




MXT001598—JUN—06OCT11

OUMX068,00000C8 -19-30JUL19-3/5

8. Remove cylinder head bolts (I).

I—Bolts



MXT001599—JUN—11OCT11

Continued on next page

OUMX068,00000C8 -19-30JUL19-4/5

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com