

SERVICE MANUAL

TD3.50 Tractor


Part number 47840677

English
March 2015





NEW HOLLAND



TD 3.50

MODEL TRACTOR REPAIR MANUAL

SECTION

| | |
|---|-----------|
| GENERAL | 00 |
| ENGINE | 10 |
| CLUTCH | 18 |
| TRANSMISSION | 21 |
| DRIVELINES | 23 |
| FRONT AXLE MECHANICAL TRANSMISSION | 25 |
| REAR AXLE AND TRANSMISSION | 27 |
| PTO | 31 |
| BRAKES | 33 |
| HYDRAULIC SYSTEMS | 35 |
| STEERING | 41 |
| ELECTRICAL SYSTEM | 55 |

S E R V I C E

INTRODUCTION

- (*This manual is divided into sections identified by two-figure numbers. Each section has independent page numbering.
For ease of reference, these sections have the same numbers and names as the Repairs Rate Book sections.*
- (*The different sections can easily be found by consulting the table of contents on the following pages.*
- (*The document number of the manual and the edition/update dates are given at the bottom of each page.*
- (*The information contained in this manual was current on the date printed on each section. As NEW HOLLAND constantly improves its product range, some information may be out of date subsequent to modifications implemented for technical or commercial reasons or to meet legal requirements in different countries.
In the event of conflicting information, consult the NEW HOLLAND Sales and Service Departments.*

IMPORTANT WARNINGS

- (*All maintenance and repair work described in this manual must be performed exclusively by NEW HOLLAND AGRICULTURE service technicians, in strict accordance with the instructions given and using any specific tools necessary.*
- (*Anyone who performs the operations described herein without strictly following the instructions is personally responsible for resulting injury or damage to property.*
- (*The Manufacturer and all organisations belonging to the Manufacturer's distribution network, including but not restricted to national, regional or local distributors, will accept no responsibility for personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer, including those used for maintenance and/or repair of the product manufactured or marketed by the Manufacturer.
In any case, the product manufactured or marketed by the Manufacturer is covered by no guarantee of any kind against personal injury or damage to property caused by abnormal function of parts and/or components not approved by the Manufacturer.*

TEXT AND ILLUSTRATIONS ARE THE PROPERTY
OF NEW HOLLAND.



No part of the text or illustrations
may be reproduced.

PRINTED IN TURKEY

NEW HOLLAND

SERVICE - Technical Publications & Special Tools

Part No:47840677

NEW HOLLAND

Service Manual - TD3.50 Tractor

TABLE OF CONTENTS

GENERAL

SECTION 00

General Instructions and Health and Safety

Chapter 1

| Section | Description | Page |
|---------|-----------------------------|------|
| 00 000 | General Instructions | 1 |
| | Notes for spare parts | 2 |
| | Notes for equipment | 2 |
| | Safety Rules | 3 |
| | Consumables | 6 |

ENGINE

SECTION 10

Engine System

Chapter 1

| Bölüm | Tanım | Sayfa |
|--------|---|-------|
| 10 000 | Specifications | 2 |
| | Tightening Torques | 14 |
| | Special Tools | 15 |
| | Cross Sectional Views | 17 |
| | Engine Cooling System | 20 |
| | Troubleshooting | 21 |
| | Engine - Remove and Install | 25 |
| | Engine Removal and Overhaul | 37 |
| | Engine Timing Gear Cover, Timing Gears, and Cam Shaft | 44 |
| | Cylinder Head | 46 |
| | Valves | 47 |
| | Cylinder Block | 50 |
| | Pistons | 70 |
| | Crankshaft - Main Bearing and Thrust Washer | 65 |
| | Camshaft | 73 |
| | Hydraulic Oil Pump | 83 |
| | Description of operation - Engine Lubrication System | 84 |
| | Description of operation - Cooling System | 86 |

Clutches

Section 18

| Section | Description | Page |
|--------------------------|---------------------------------------|-------|
| 18 000 | Specifications | 1 |
| | TIGHTENING TORQUES | 2 |
| | Special Tools | 3 |
| | Cross Sectional Views | 3 |
| | Troubleshooting | 4 |
| | Remove - Assembly | 5-13 |
| | Control, Measurement and Repair | 15-18 |
| | General Maintenance - Overhaul | 18-19 |
| Clutch Adjustments | 20-22 | |

TRANSMISSION

SECTION 21

Mechanical Transmission

Chapter 1

| Section | Description | Page |
|---------|---------------------------------|------|
| 21 000 | Specifications | 2 |
| | Tightening Torques | 2 |
| 2 | Liquid Sealants | 4 |
| | Special Tools | 5 |
| | Cross Sectional Views | 6 |
| | Troubleshooting | 8 |
| | Description and Operation | 8 |

Reverser

Chapter 2

| Section | Description | Page |
|---------|---|------|
| | General Recommendations For Overhauling Operations | 2 |
| | Transmission Assembly, Removal - Installation | 3 |
| | Transmission - Mechanical - Disassemble 8x8 Shuttle Transmission | 18 |
| | Gear and Synchroniser - Remove Transmission Synchroniser Kit and Cluster Gear Assembly | 24 |
| | Gear and Synchroniser - Inspect Transmission Synchroniser Kit and Cluster Gear Assembly | 28 |
| | Gear and Synchroniser - Install Transmission Synchroniser Kit and Cluster Gear Assembly | 29 |

DRIVE LINES

SECTION 23

Drive Lines

Chapter 1

| Section | Description | Page |
|---------|--|------|
| 23 000 | Specifications | 1 |
| | Torque Settings and Tools | 2 |
| | Cross-Sectional Views | 3 |
| | Transmission shafts and guard (Disassembly - Assembly) | 4 |
| | Drive gear housing (Removal - Installation) | 5 |
| | Drive gear housing removed (Disassembly - Assembly) | 6 |

FRONT AXLE MECHANICAL TRANSMISSION

SECTION 25

Front Axle Mechanical Transmission

Chapter 1

| Section | Description | Page |
|--------------|---|------|
| 25 000 | Specifications | 2 |
| | TIGHTENING TORQUES | 3 |
| | Tools | 6 |
| | Cross Sectional Views | 7 |
| | Description and Operation | 9 |
| 25 100 30 | Complete front axle. Remove - Install | 10 |
| 25 100 38 | Front axle. Remove - Install | 15 |
| 25 108 46-47 | Steering knuckle bearing pins. Replace | 22 |
| | Stub axle adjustment | 23 |
| | Wheel hub bearing adjustment | 25 |
| | Bevel drive adjustment | 26 |
| 25 102 24 | Front Axle Differential. Overhaul | 32 |
| 25 100 27 | Front axle differential with LIM-SLIP. Overhaul | 33 |
| 44 511 80 | Leading drive wheels toe-in check | 35 |

REAR AXLE AND TRANSMISSION

SECTION 27

Rear Axle And Transmission

Chapter 1

| Section | Description | Page |
|---------|---|------|
| 21 000 | Specifications | 2 |
| | Tightening Torques | 3 |
| | Liquid Sealants | 6 |
| | Special Tools | 7 |
| | Cross Sectional Views | 7 |
| | Troubleshooting | 10 |
| | Description and Operation | 10 |
| | Low Gear Drive Line Schema | 13 |
| | Reverse Gear Drive Shaft | 13 |
| | High Gear Drive Shaft | 14 |
| | Transmission Assembly, Removal - Installation | 16 |
| | Internal Components, Disassembly - Assembly | 33 |

Diferential

Chapter 2

| Section | Description | Page |
|---------|---|------|
| 27 000 | Differential Assembly | 2 |
| | Differential pinion and side gear backlash | 4 |
| | Repair and Inspection | 5 |
| | Adjustment of bevel wheel bearings and crown pinion backlash adjustment | 6 |
| | Final drive housing | 8 |

POWER TAKE-OFF

SECTION 31

Mechanical Power Take - Off

Chapter 1

| Section | Description | Page |
|---------|--------------------------------------|------|
| 31 000 | Specifications | 1 |
| | Tightening Torques | 2 |
| | Liquid Sealants | 3 |
| | Cross Sectional Views | 4 |
| | Description and Operation | 5 |
| | RemovalInstallation - Overhaul | 7 |

BRAKING SYSTEM

SECTION 33

Braking System

Chapter 1

| Section | Description | Page |
|---------|--|------|
| 33 000 | Specifications | 2 |
| | Tightening Torques | 3 |
| | Special Tools | 4 |
| | Liquid Sealants | 4 |
| | Cross Sectional Views | 5 |
| | Troubleshooting | 6 |
| | Description and Operation | 7 |
| | Brake Control, Removal - Installation | 8 |
| | Brake Assembly, Removal - Installation | 10 |
| | Brake Pedal Free Play Setting | 13 |

HYDRAULIC SYSTEM

SECTION 35

Hydraulic System

Chapter 1

| | | |
|---------------|---|---|
| 35 000 | Introduction and Circuit Identification | 1 |
| | Open Centre High Pressure Hydraulic Circuit | 3 |
| | Hydraulic Circuit Diagram | 4 |
| | Sectional view | 5 |

Hydraulic Pump

Chapter 1

| | | |
|--|---------------------------------|---|
| | Specifications | 1 |
| | Tightening Torques | 2 |
| | Special Tools | 2 |
| | Description and Operation | 3 |
| | Remove and Install | 4 |
| | Disassembly - Assembly | 5 |

Hydraulic Pump

Chapter 2

| | | |
|---------------|---|----|
| 35 000 | Specifications | 2 |
| | Tightening Torques | 3 |
| | Liquid Sealants | 4 |
| | Special Tools | 4 |
| | Cross Sectional Views | 5 |
| | Troubleshooting | 7 |
| | Description and Operation | 8 |
| | Operation of Distributor | 12 |
| | Internal Three-Point Hitch | 15 |
| | Operation of Internal Lift-O-Matic Levers | 21 |
| | Remove and Install | 23 |
| | Disassembly - Assembly | 25 |
| | Adjustment and Settings | 38 |

STEERING

SECTION 41

Steering

Chapter 1

| Section | Description | Page |
|----------------|--------------------------|-------------|
| Section | Description | Page |
| 41 000 | Specifications | 1 |
| | Tightening Torques | 3 |
| | Special Tools | 3 |

| | |
|---------------------------------------|----|
| Troubleshooting | 3 |
| Description and Operation | 8 |
| Removal Installation - Overhaul | 12 |

ELECTRICAL SYSTEM

SECTION 55

Instruments

Section 1

| Section | Description | Page |
|---------|---------------------------------------|------|
| | Semi-digital instruments Introduction | 1 |
| | Transmitters, sensors and switches | 3 |

Components

Chapter 2

| Section | Description | Page |
|---------|------------------------------|------|
| 55 500 | Introduction | 1 |
| | Description of the Component | 2 |

Starting System

Chapter 3

| Section | Description | Page |
|---------|--|------|
| 55 000 | Technical Information | 1 |
| | TIGHTENING TORQUES | 1 |
| | Description and Operation | 2 |
| | Starter System Circuit | 3 |
| | Operation Description | 5 |
| | Removal and re-installation of starter motor | 7 |
| | Electrical Test | 8 |
| | Bench tests | 10 |

Charging System

Chapter 4

| Section | Description | Page |
|---------|---|------|
| 55 000 | Technical Information | 1 |
| | TIGHTENING TORQUES | 1 |
| | Description and Operation | 2 |
| | Alternator - Removal and Reassembly | 4 |
| | Alternator component testing and inspection | 10 |

Battery

Chapter 5

| Section | Description | Page |
|---------|------------------------------------|------|
| 55 000 | Technical Information | 1 |
| | Description and Operation | 1 |
| | Removal and Re-installation | 2 |
| | Battery Checking and Maintenance | 3 |
| | Battery Charging | 4 |
| | Battery Problems - Frequent Causes | 7 |

Electrical Circuits

Chapter 6

| Section | Description | Page |
|----------------|--|-------------|
| 55 100 | Contents | 1 |
| | Fuses (all versions) | 2 |
| | Symbols used in electrical circuits | 3 |
| | Electrical wire colour coding | 4 |
| | Ground location points | 5 |
| | -General electrical diagram | 7 |
| | Start-up circuit | 9 |
| | Direction indicator & hazard warning light circuit | 10 |
| | Worklamp | 16 |
| | Side Lights, main and dipped headlights, parking light circuit | 18 |

GENERAL INSTRUCTIONS

IMPORTANT NOTICE

All maintenance and repair operations described in this manual should be carried out exclusively by the NEW HOLLAND authorised workshops. All instructions detailed should be carefully observed and special equipment indicated should be used if necessary.

Everyone who carries out service operations described without carefully observing these prescriptions will be directly responsible of deriving damages.

SHIMS

At each adjustment, select adjusting shims, measure them individually using a micrometer and then sum up recorded values. Do not rely on measuring the entire shimming set, which may be incorrect, or the rated value indicated on each shim.

ROTATING SHAFT SEALS

To correctly install rotating shaft seals, observe the following instructions:

- Let the seal soak into the same oil as it will seal for at least half an hour before mounting
- Thoroughly clean the shaft and ensure that the shaft working surface is not damaged.
- Place the sealing lip towards the fluid. In case of a hydrodynamic lip, consider the shaft rotation direction and orient grooves in order that they deviate the fluid towards the inner side of the seal.
- coat the sealing lip with a thin layer of lubricant (use oil rather than grease) and fill the gap between the sealing lip and the dust lip on double lip seals with grease;
- Insert the seal into its seat and press it down using a flat punch. Do not tap the seal with a hammer or a drift;
- Take care to insert the seal perpendicularly to its seat while you are pressing it. Once the seal is settled, ensure that it contacts the thrust element if required;

To prevent damaging the sealing lip against the shaft, place a suitable protection during installation.

O RINGS

Lubricate the O rings before inserting them into their seats. This will prevent the O rings from rolling over and twine during mounting which will jeopardise sealing.

SEALANTS

Apply one of the following sealers: RTV SILMATE, RHODORSIL CAF 1, or LOCTITE PLASTIC GASKET over the mating surfaces marked with an X.

Before applying the sealer, prepare the surface as follows:

- remove possible scales using a metal brush;
- thoroughly de-grease the surfaces using one of the following cleaning agents: trichlorethylene, petrol or a water and soda solution.

BEARINGS

It is advisable to heat the bearings to 80 to 90 C before mounting them on their shafts and cool them down before inserting them into their seats with external tapping.

ROLL PINS

When fitting straight roll pins, ensure that the pin notch is oriented in the direction of the effort to stress the pin. Coil roll pins can be installed in any position.

NOTES FOR SPARE PARTS

Use exclusively genuine **NEW HOLLAND** spare parts, the only ones bearing this logo.



Only genuine parts guarantee same quality, life, safety as original components as they are the same as mounted in production.

Only NEW HOLLAND genuine spare parts can offer this guarantee.

All spare parts orders should be complete with the following data:

- tractor model (commercial name) and frame number;
- engine type and number;
- part number of the ordered part, which can be found in the "Microfiches" or the "Spare Parts Catalogue", used for order processing.

NOTES FOR EQUIPMENT

Equipment which NEW HOLLAND proposes and shows in this manual are as follows:

- studied and designed expressly for use on NEW HOLLAND tractors;
- necessary to make reliable repair;
- accurately built and strictly tested to offer efficient and long-lasting working means.

We also remind the Repair Personnel that having these equipment means:

- operating in optimal technical conditions;
- obtaining the best results;
- saving time and effort;
- work more safely.

NOTICES

Wear limits indicated for some details should be intended as advised, but not binding values. The words "front", "rear", "right hand", and "left hand" referred to the different parts should be intended as seen from the operator's seat oriented to the normal sense of movement of the tractor.

HOW TO MOVE THE TRACTOR WITH THE BATTERY REMOVED

Cables from the external power supply should be connected exclusively to the respective terminals of the tractor positive and negative cables using pliers in good condition which allow proper and steady contact.

Disconnect all services (lights, wind-shield wipers, etc.) before starting the tractor.

If it is necessary to check the tractor electrical system, check it only with the power supply connected. At check end, disconnect all services and switch the power supply off before disconnecting the cables.

SAFETY RULES

PAY ATTENTION TO THIS SYMBOL



This warning symbol points out important messages involving personal safety. Carefully read the safety rules contained herein and follow advised precautions to avoid potential hazards and safeguard your safety and personal integrity.

In this manual you will find this symbol together with the following key-words:



WARNING -it gives warning about improper repair operations and potential consequences affecting the service technician's personal safety.

DANGER - it gives specific warning about potential dangers for personal safety of the operator or other persons directly or indirectly involved in the operation.

TO PREVENT ACCIDENTS

Most accidents and personal injuries taking place in workshops are due from non-observance of some simple and essential prudential rule and safety precautions. For this reason, IN MOST CASES THEY CAN BE AVOIDED. It suffices to foresee possible causes and act consequently with necessary caution and care.

The possibility that an accident might occur with any type of machines should not be disregarded, no matter how well the machine in question was designed and built.

A wise and careful service technician is the best precautions against accidents.

Careful observance of this only basic precaution would be enough to avoid many severe accidents.

DANGER Never carry out any cleaning, lubrication or maintenance operations when the engine is running.

SAFETY RULES

GENERAL

- (Carefully follow specified repair and maintenance procedures.
- (Do not wear rings, wrist watches, jewelry, unbuttoned or loose articles of clothing such as: ties, torn clothing, scarves, open jackets or shirts with open zips which may remain entangled in moving parts. We advise to use approved safety clothing such as anti-slipping footwear, gloves, safety goggles, helmets, etc.
- (Never carry out any repair on the machine if someone is sitting on the operator's seat, except if they are certified operators to assist in the operation to be carried out.
- (Never operate the machine or use attachments from a place other than sitting at the operator's seat.
- (Never carry out any operation on the machine when the engine is running, except when specifically indicated.
- (Stop the engine and ensure that all pressure is relieved from hydraulic circuits before removing caps, covers, valves, etc.
- (All repair and maintenance operations must be carried out using extreme care and attention.
- (Service steps and platforms used in a workshop or in the field should be built in compliance with the safety rules in force.
- (Disconnect the batteries and label all controls to indicate that the vehicle is being serviced. Block the machine and all equipment which should be raised.
- (Never check or fill fuel tanks or batteries, nor use starting liquid if you are smoking or near open flames as such fluids are flammable.
- (Brakes are inoperative when they are manually released for maintenance purposes. In such cases, the machine should be kept constantly under control using blocks or similar devices.
- (The fuel filling gun should always remain in contact with the filler neck. Maintain this contact until the fuel stops flowing into the tank to avoid possible sparks due to static electricity build-up.

- (Use exclusively specified towing points for towing the tractor. Connect parts carefully. Ensure that foreseen pins and/or locks are steadily fixed before applying traction. Do not stop near towing bars, cables or chains working under load.
- (To transfer a failed tractor, use a trailer or a low loading platform trolley if available.
- (To load and unload the machine from the transportation means, select a flat area providing a firm support to the trailer or truck wheels. Firmly tie the machine to the truck or trailer platform and block wheels as required by the forwarder.
- (For electrical heaters, battery-chargers and similar equipment use exclusive auxiliary power supplies with a efficient ground to avoid electrical shock hazard.
- (Always use lifting equipment of appropriate capacity to lift or move heavy components.
- (Pay special attention to bystanders.
- (Never pour gasoline or diesel oil into open, wide and low containers.
- (Never use petrol, diesel oil or other inflammable liquids as cleaning agents. Use non-flammable non-toxic proprietary solvents.
- (Wear safety glasses with side guards when cleaning parts using compressed air.
- (Do not exceed a pressure of 2.1 bar, in accordance with local regulations.
- (Do not run the engine in a closed building without proper ventilation.
- (Do not smoke, use naked flames, or cause sparks in the area when fuel filling or handling highly inflammable liquids.
- (Do not use flames as light sources when working on a machine or checking for leaks.
- (Move with caution when working under a tractor, and also on or near a tractor. Wear proper safety accessories: helmets, goggles and special footwear.
- (During checks which should be carried out with the engine running, ask an assistant to seat at the operator's seat and keep the service technician under visual control at any moment.
- (In case of operations outside the workshop, drive the tractor to a flat area and block it. If working on an incline cannot be avoided, first block the tractor carefully. Move it to a flat area as soon as possible with a certain extent of safety.
- (Ruined or plied cables and chains are unreliable. Do not use them for lifting or trailing. Always handle them wearing gloves of proper thickness.
- (Chains should always be safely fastened. Ensure that fastening device is strong enough to hold the load foreseen. No persons should stop near the fastening point, trailing chains or cables.
- (The working area should be always kept CLEAN and DRY. Immediately clean any spillage of water or oil.
- (Do not pile up grease or oil soaked rags, as they constitute a great fire hazard. Always place them into a metal container.
Before starting the tractor or its attachments, check, adjust and block the operator's seat. Also ensure that there are no persons within the tractor or attachment operating range.
- (Do not keep in your pockets any object which might fall unobserved into the tractor's inner compartments.
- (Whenever there is the possibility of being reached by ejected metal parts or similar, use protection eye mask or goggles with side guards, helmets, special footwear and heavy gloves.
- (Wear suitable protection such as tinted eye protection, helmets, special clothing, gloves and footwear whenever it is necessary to carry out welding procedures. All persons standing in the vicinity of the welding process should wear tinted eye protection. NEVER LOOK AT THE WELDING ARC IF YOUR EYES ARE NOT SUITABLY PROTECTED.
- (Metal cables with the use get frayed. Always wear adequate protections (heavy gloves, eye protection, etc.)
- (Handle all parts with the greatest caution. Keep your hands and fingers far from gaps, moving gears and similar. Always use approved protective equipment, such as eye protection, heavy gloves and protective footwear.

STARTUP

- (Never run the engine in confined spaces that are not equipped with adequate ventilation for exhaust gas extraction.
- (Never place the head, body, limbs, feet, hands or fingers near fans or rotating belts.

ENGINE

- (Always loosen the radiator cap very slowly before removing it to allow pressure in the system to dissipate. Coolant should be topped up only when the engine is stopped or idle if hot.
- (Do not fill up fuel tank when the engine is running, mainly if it is hot, to avoid ignition of fires in case of fuel spilling.
- (Never check or adjust fan belt tension when the engine is running.
Never adjust the fuel injection pump when the tractor is moving.
- (Never lubricate the tractor when the engine is running.

ELECTRICAL SYSTEMS

- (If it is necessary to use auxiliary batteries, cables must be connected at both sides as follows: (+) with (+) and (-) with (-). Avoid short-circuiting the terminals. GAS RELEASED FROM BATTERIES IS HIGHLY FLAMMABLE. During charging, leave the battery compartment uncovered to improve ventilation. Avoid checking the battery charge by means of "jumpers" made by placing metallic objects across the terminals. Avoid sparks or flames near the battery zone. Do not smoke to prevent explosion hazards.
- (Before servicing operations, check for fuel or current leaks. Remove these leaks before going on with the work.
- (Do not charge batteries in confined spaces. Ensure that ventilation is appropriate to prevent accidental explosion hazard due to build-up of gases released during charging.
- (Always disconnect the batteries before performing any type of service on the electrical system.

HYDRAULIC SYSTEMS

- (Some fluid slowly coming out from a very small port can be almost invisible and be strong enough to penetrate the skin. Therefore, NEVER USE HANDS TO CHECK FOR LEAKS but use a piece of cardboard or wood for this purpose. If any fluid is injected into the skin, seek medical aid immediately. Lack of immediate medical attention, serious infections or dermatosis may result.
- (Always take system pressure readings using the appropriate gauges.

WHEELS AND TYRES

- (Check that the tyres are correctly inflated at the pressure specified by the manufacturer. Periodically check possible damages to the rims and tyres.
- (Keep off and stay at the tyre side when correcting the inflation pressure.
- (Check the pressure only when the tractor is unloaded and tyres are cold to avoid wrong readings due to over-pressure. Do not reuse parts of recovered wheels as improper welding, brazing or heating may weaken the wheel and make it fail.
- (Never cut, nor weld a rim with the inflated tyre assembled.
- (To remove the wheels, block both front and rear tractor wheels. Raise the tractor and install safe and stable supports under the tractor in accordance with regulations in force.
- (Deflate the tyre before removing any object caught into the tyre tread.
- (Never inflate tires using flammable gases, as this may result in explosions and injury to bystanders.

REMOVAL AND INSTALLATION

- (Lift and handle all heavy components using lifting equipment with adequate capacity. Ensure that parts are supported by appropriate slings and hooks. Use lifting eyes provided to this purpose. Take care of the persons near the loads to be lifted.
- (Handle all parts with care. Do not place your hands or fingers between two parts. Wear approved protective clothing such as safety goggles, gloves and footwear.
- (Do not twine chains or metal cables. Always wear safety gloves when handling cables or chains.

LUBRICANT CAPACITIES AND SPECIFICATIONS

| COMPONENT TO BE FILLED OR TOPPED UP | QUANTITY | | RECOMMENDED PRODUCTS | INTERNATIONAL SPECIFICATIONS |
|--|-----------------------|--------------|---|---------------------------------------|
| | liter/dm ³ | US gallon | | |
| Cooling System: | 10 | 2.6 | Water & liquid NEW HOLLAND AMBRA AGRIFLU 50% + 50% (NH 900 A) | - |
| Fuel tank..... | 52 | 13.75 | Decanted and filtered diesel fuel | - |
| Engine sump: without filter with filter | 5.8 6.0 | 1.5 1.6 | NEWHOLLAND AMBRA MASTERGOLD HSP ENGINE OIL SAE 15W - 40 or 10W-30 (NH 330-324 H) | API CI-4/CH-4 or CI-4 |
| Hydrostatic steering | 2.0 | 0.53 | Oil AMBRA MULTI 20W-30 (NH 410B) | API GL4 ISO VG 32/46 SAE 10W-30 |
| Front axle -axle housing -final drives (each): | 4.5 0.8 | 1.2 0.2 | | |
| Rear transmission (bevel drive and brakes), gearbox, hydraulic lift and PTO | 23 25 | 6,01 6.6 | | |
| Front wheel hubs | - | - | | |
| Grease fittings | - | - | Grease NEW HOLLAND AMBRA GR-9 MULTI-PURPOSE (NH 710A) | NLHI 2 |

CHAPTER 1 - ENGINE**TABLE OF CONTENTS**

| Section | Description | Page |
|----------------|--|-------------|
| 10 000 | Technical Information | 2 |
| | Fuel system technical data | 5 |
| | Angular tightening torque values | 14 |
| | Special tools | 15 |
| | Longitudinal and cross sectional views of the engine | 17 |
| | Cross sectional view of the lubrication system | 19 |
| | Troubleshooting | 21 |
| 10 001 | Removal - Installation - Overhaul | 25 |
| | Checking, dimensions and overhaul | 65 |

| TECHNICAL INFORMATION | 3 cylinders |
|--|----------------------|
| Engine type: | - |
| - TD 3.50Turbocharged -- (BOSCH pump) | TTF8035.25F313T |
| Type | |
| Injection method | Diesel, 4 stroke |
| Number of cylinders | Direct |
| Piston diameter | 3 |
| - TD 3.50model | |
| | 104 mm |
| Stroke | 115 mm |
| Cylinder displacement: | |
| - TD 3.50model | 2930 cm ³ |
| | |
| Compression rate | 18:1 |
| Maximum power: | |
| - TD 3.50model | 35.3 kW (48 HP) |
| | |
| Torque Values: | |
| Max.tork (Nm) at 1400 d/dak: TD 3.50 model | 180 |
| | |
| Number of bearings | 4 |
| Oil sump | Cast iron |

(continued)

| TECHNICAL INFORMATION | |
|---|--|
| Lubrication | Forced feeding, gear pump |
| Pump drive | Through camshaft |
| Engine speed/pump speed ratio | 2:1 |
| Oil filter | Strainer at the intake and full output cartridge |
| Normal oil pressure at engine running at full throttle: | 2.9 - 3.9 bar (3 - 4 kg/cm ²) |
| All models | |
| Pressure safety valve | In pump body |
| Opening pressure | 3.5 bar (3.6 kg/cm ²) |
| For detailed information about lubrication | see page 13 |
| Cooling system | Water cooled |
| Radiator in TD 3.50models | 3 rows of vertical pipes, aluminum channels |
| Fan installed on water pump pulley In TD 3.50model | Air sucking type with 10 blades |
| Water pump | Centrifugal type |
| Engine speed/water pump speed ratio | 1.03/1 |
| Temperature control | Via thermostat |
| Temperature gauge | with colored scale divided into three sectors |
| Temperature values corresponding to each sectors: | |
| - First, white sector | 30° - 65° C |
| - Middle, green sector | 65° - 105° C |
| - Last, red sector | 105° - 115° C |
| For detailed information about cooling system | see page 13 |
| Tractor meter | Instrument panel (from alternator) |

(continued)

| TECHNICAL INFORMATION | |
|--|---|
| <p>Timing gears</p> <p>Inlet:</p> <ul style="list-style-type: none"> - Opening: Before TDC - Closing: After BDC <p>Exhaust:</p> <ul style="list-style-type: none"> - Opening: Before BDC - Closing: After TDC <p>Valve Clearance (engine cold):</p> <ul style="list-style-type: none"> - Inlet - Exhaust <p>For more information</p> | <p>Top valves operated through push rods on camshaft Camshaft is driven by crankshaft.</p> <p style="text-align: right;">12°</p> <p style="text-align: right;">31°</p> <p style="text-align: right;">50°</p> <p style="text-align: right;">16°</p> <p style="text-align: right;">0.30 ± 0.05 mm</p> <p style="text-align: right;">0.30 ± 0.05 mm</p> <p style="text-align: right;">see page 10</p> |
| <p>Fuel System</p> <p>Air filter</p> <p>Supply pump</p> <p>Fuel Filtering</p> <p>Minimum fuel flow rate with pump shaft rotating at 1600 rpm .</p> <p>Operated by camshaft</p> <p>BOSCH injection pump</p> <p>Governor for all speeds, installed within the pump: BOSCH</p> <p>For more information about fuel system</p> <p>Fixed advance (pump setting for start of delivery before TDC) - Pressure setting - Injection order, and other information regarding the BOSCH pump</p> | <p>Dry type, with centrifugal prefilter and automatic dust extractor and filter clogged indicator with double diaphragm</p> <p>through wire filter in supply pump, and replaceable cartridge on delivery line to injection pump.</p> <p style="text-align: right;">100 liter/hour</p> <p style="text-align: right;">Through camshaft</p> <p style="text-align: right;">distributor type</p> <p style="text-align: right;">Centrifugal, with counterweights</p> <p style="text-align: right;">see Section 10 page 99</p> |

TECHNICAL INFORMATION

| | |
|--|---|
| Turbocharger -Holset | HX25 |
| Injection pump BOSCH pump: -TD 3.50model | distributor type with speed governor and automatic advance L 1135 |
| Rotation direction | counter clockwise |
| Firing order | 1-2-3 |
| Injectors: BOSCH | 84300592 84404382 |
| - Injector nipple holder type | KBAL 86P163 |
| - Injector type | 0432291494 |
| Number of holes | 6 |
| Nipple orifice diameter | 0.19 mm |
| Pressure setting | 260-272 bar |
| High pressure pipes - BOSCH pump - Type | 4797506 |
| - Pipe sizes | 6 x 1,6 x 530mm |

| FUEL LIFT PUMP DATA | mm |
|--|-----------------|
| Shaft eccentricity | 3 |
| Shaft diameter | 31.975 - 32.000 |
| Bushing inner diameter (after reaming) | 32.050 - 32.075 |
| Bushing seat snug fit size | 0.063 - 0.140 |
| Bushing shaft gap | 0.050 - 0.100 |
| Internal thrust washer thickness | 1.45 - 1.50 |
| External thrust washer thickness | 2.93 - 3.00 |

| ENGINE OIL SUMP AND CRANKCASE DATA | mm |
|---|--|
| Cylinder block | Cast monoblock houses crankshaft, camshaft, valve push rod cups. |
| Inner diameter | 104.000 - 104.024 (1) |
| Outer diameter | 107.020 - 107.050 |
| Block snug fit size | 106.850 - 106.900 |
| Inner diameter upper range | 0.120 - 0.200 |
| Outer diameter upper range | 0.4 - 0.8 |
| Ovality and taper | 0.2 |
| Main bearing race diameter | 0.12 |
| Main bearing race diameter | 84.200 - 84.230 |
| Camshaft bushings race diameter: | |
| - Front | 54.780 - 54.805 |
| - Middle | 54.280 - 54.305 |
| - Rear | 53.780 - 53.805 |
| Valve push rod cup seat diameter | 15.000 - 15.018 |
| Valve push rod cup upper range | 0.1 - 0.2 - 0.3 |

(1) After honing.

(2) Take measures parallel and perpendicular to the axis of the engine, where snap rings are operating.

| CRANKSHAFT BEARINGS | mm |
|--|-------------------------------|
| Crankshaft | balanced with counterweights |
| Main journal and crank pin diameter | 79.791 - 79.810 (1) |
| Main journal and crank pin undersize range | 0.254 - 0.508 - 0.762 - 1.016 |
| Main journal wall thickness | 2.168 - 2.178 |
| Main journal undersize range | 0.254 - 0.508 - 0.762 - 1.016 |
| Main journal and crank pin end float | 0.034 - 0.103 |
| Maximum end float after wear out | 0.180 |
| Crank pin diameter ... | 63.725 - 63.744 (1) |
| Crank pin undersize range | 0.254 - 0.508 - 0.762 - 1.016 |
| Connecting rod wall thickness | 1.805 - 1.815 |
| Connecting rod undersize range | 0.254 - 0.508 - 0.762 - 1.016 |
| Connecting rod oversize bearing end float | 0.033 - 0.087 |
| Maximum end float after wear out | 0,180 |
| Crankshaft thrust bearing thickness | 3.378 - 3.429 |
| Thrust bearing upper range | 0.127 - 0.254 - 0.381 - 0.508 |
| Main bearing width of the thrust bearings | 31.766 - 31.918 |
| Main journal and crank pin length | 32.000 - 32.100 |
| Axial play of crankshaft | 0.082 - 0.334 |
| Maximum axial play | 0.40 |
| Maximum ovality and taper of main journal and crank pins after grinding | 0.01 |
| Maximum ovality and taper of main journal and crank pins after wear .. | 0.05 |
| Eccentricity of crankshaft main journal and crank pins, housed between front and rear crank pins (maximum) | 0.10 |
| Eccentricity and parallelism of error crank pin pairs in relation to the main journal | 0.25 |
| Distance tolerance of the external surfaces of the crank pins in relation to main journal axis (maximum) | ± 0.10 |

(continued)

(1) During manufacturing 0,1 mm undersized main journals and crank pins are installed together with correspondingly oversized bearings.

(continued)

| CRANKSHAFT BEARINGS | mm |
|--|-----------|
| The crankshaft is measured with a 1/100 sensitivity micrometer, with comparator tip being on point A. | 0,025 |
| Wobbling of flywheel seat surfaces in relation to main journal axis | 0.04 |

| CONNECTING ROD (TD 3.50) | mm |
|---|-----------------------|
| Connecting rod | Cast iron oil passage |
| Connecting rod bushing seat diameter | 41.846 - 41.884 |
| Connecting rod bushing seat outer diameter | 41.979 - 42.017 |
| Connecting rod bushing snug fit size | 0.095 - 0.171 |
| Connecting rod bush inner diameter (pressed in) | 38.004 - 38.014 |
| Connecting rod seat diameter | 67.407 - 67.422 |
| Connecting rod axes twist (over 125 mm distance) maximum | ± 0,07 |
| Weight difference of the connecting rods in the same engine (maximum) ... | 25 gram |

| PISTON DATA | mm |
|---|--|
| | TD 3.50 |
| Piston | Light alloy, with compression, double compression and oil wiper piston rings |
| Piston diameter (measured at the axis of piston pin at 57 mm above the skirt) | 103.852 - 103.870 |
| End float after wear out | 0.30 |
| Piston diameter upper range | 0.6 |
| Protrusion of the piston from the surface of the head at TDC ... | 0.355 - 0.761 |
| Piston Pin diameter | 37.983 - 37.990 |
| Pin housing diameter on piston | 37.994 - 38.000 |
| Piston Pin - pin housing gap | 0.004 - 0.017 |
| Connecting rod bushing - piston pin gap | 0.014 - 0.031 |
| Gap after wear out (maximum) | 0.06 |
| Weight difference of the pistons used in the same engine (maximum) . | 20 gram |
| Piston ring - ring groove clearance : | |
| - Top | 0.090 - 0.122 |
| - Second | 0.060 - 0.092 |
| - Bottom | 0.040 - 0.075 |
| Maximum end float after wear out: | |
| - Top | 0.50 |
| - Second and bottom | 0.20 |
| Piston ring opening gap (on the piston): | |
| - Top | 0.40 - 0.65 |
| - Second | 0.30 - 0.55 |
| - Bottom | 0.30 - 0.55 |
| Maximum opening after wear out | 1.20 |

| TIMING GEARS AND CAMSHAFT | mm |
|--|-----------------|
| Gap between timing gear teeth | 0.160 |
| Idle gear bushing inner diameter (after pressing and reaming) .. | 37.050 - 37.075 |
| Idle gear shaft diameter | 36.975 - 37.000 |
| Idle gear shaft bushing gap | 0.050 - 0.100 |
| Maximum gap after wear out | 0.15 |
| Idle gear bushing snug fit size | 0.063 - 0.140 |
| Camshaft bushing outer diameter: | |
| - Front | 54.875 - 54.930 |
| - Middle | 54.375 - 54.430 |
| - Rear | 53.875 - 53.930 |
| Bushing-housing snug fit size | 0.070 - 0.150 |
| Camshaft bushing inner diameter (after pressing and reaming): | |
| - Front | 51.080 - 51.130 |
| - Middle | 50.580 - 50.630 |
| - Rear | 50.080 - 50.130 |
| Camshaft diameter: | |
| - Front | 50.970 - 51.000 |
| - Middle | 50.470 - 50.500 |
| - Rear | 49.970 - 50.000 |
| Camshaft-bushing gap | 0.080 - 0.160 |
| Maximum gap after wear out | 0.20 |
| Backlash of the camshaft (with thrust plate installed) | 0.070 - 0.220 |
| For more information .. | see page 4 |

| VALVE PUSH ROD CUPS | mm |
|---|-----------------|
| Valve push rod cup seat diameter | 15.000 - 15.018 |
| Valve push rod cup outer diameter | 14.950 - 14.970 |
| Valve push rod cup seat gap in the cylinder block | 0.030 - 0.068 |
| Maximum gap after wear out | 0.15 |
| Valve push rod cup upper range | 0.1 - 0.2 - 0.3 |

| ROCKER ARM SHAFT - VALVES | mm |
|---|-----------------|
| Rocker arm shaft support hole diameter | 18.016 - 18.034 |
| Rocker arm shaft diameter | 17.982 - 18.000 |
| :Rocker arm support clearance | 0.016 - 0.052 |
| Maximum gap after wear out | 0.15 |
| Rocker arm intermediate spring length: | |
| - Free | 59.5 |
| - Under load (46 - 52 N (4.7 - 5.3 kg)) | 44 |
| Valve clearance (during timing check) | 0.45 |
| Valve clearance for normal running (engine cold): | |
| -inlet | 5.97 |
| -exhaust | 6.25 |

| CYLINDER HEAD | mm |
|--|------------------------------|
| Cylinder head | Valve guides press installed |
| Original height of the cylinder head | 92 |
| Cylinder head chipping depth | 0.5 |
| Valve guide seat diameter on cylinder head | 13.950 - 13.983 |
| Standard valve guide seat outer diameter | 13.993 - 14.016 |
| Valve guide seat snug fit size | 0.010 - 0.066 |
| Valve guide inner diameter (after pressed and reaming) | 8.023 - 8.043 |
| Valve stem diameter | 7.985 - 8.000 |
| Clearance between valve guide and its stem | 0.023 - 0.058 |
| Maximum gap after wear out | 0.13 |
| Maximum eccentricity of working surface in relation to valve stem (measured while turning the stem once with the tip of the comparator being on the working surface) | 0.03 |
| Valve guide upper range | 0.2 |
| Valve seat angle on the cylinder head: | |
| -Inlet | 60° ± 5' |
| -Exhaust | 45° ± 5' |
| Valve working surface tapering angles: | |
| -Inlet | 60° 30' ± 7' |
| -Exhaust | 45° 30' ± 7' |
| Valve head diameter: | |
| -Inlet | 45.300 - 45.500 |
| -Exhaust | 37.500 - 37.750 |
| Valve indent .. | 0.7 - 1.0 |
| Maximum valve indent | 1.3 |
| Inlet and exhaust valve springs: | |
| - Free | 44.6 |
| - 256 - 284 N with the valve closed (26.1-28.9 kg) under load | 34 |
| - 502 - 544 N with the valve open (51.2 - 56.6 kg) under load | 23.8 |
| Injector protrusion relative to head face: | |
| BOSCH injector | 0.3 - 1.1 |

| LUBRICATION SYSTEM INFORMATION | mm | |
|---|-----------------|--------|
| | TD 3.50 | |
| Long shaft - bush clearance | 0.016 - 0.055 | - |
| Driven gear - short shaft clearance | 0.033 - 0.066 | - |
| Clearance between the gears | 0,100 | - |
| Gear pump body clearance | 0.060 - 0.170 | - |
| Driving and driven gears width | 40.961 - 41.000 | - |
| Pump body gear housing depth | 41.025 - 41.087 | - |
| Driving and driven gears backlash | 0.025 - 0.126 | - |
| Bypass valve spring length: | | - |
| - Free | 45 | - |
| - Under load of 45 - 49 N (4.6 - 5 kg) | 37.5 | - |
| - Under load of 88 - 94 N (9 - 9.6 kg) | 30.5 | - |
| - Under the load of 127.8 - 141.2 N (130 - 144 kg) (2, Figure 130) | - | - |
| - Under load of 233.4 - 258 N (238 - 263 kg130) | - | - |
| For more information about lubrication system | | page 3 |

| COOLING SYSTEM INFORMATION | mm |
|--|---------------|
| Shaft - propeller snug fit size | 0.017 - 0.059 |
| Shaft - fan hub snug fit size | 0.024 - 0.058 |
| Propeller - sealant bush snug fit size | 0.012 - 0.058 |
| For information about cooling system | see page 3 |

ANGULAR TIGHTENING TORQUE VALUES

| DESCRIPTION | Thread size | Pre-torque | | Angle |
|---------------------------------|-------------|------------|-----|-------------|
| | | Nm | kgm | |
| Cylinder head bolts | M 12 x 1.25 | 40 | 4 | 120° + 120° |
| Main journal cap screws | M 14 x 1.5 | 80 | 8.2 | 90° |
| Connecting rod cap screws | M 12 x 1.5 | 40 | 4.1 | 60° |
| Flywheel bolts | M 12 x 1.25 | 40 | 4.1 | 60° |

TIGHTENING TORQUES

| DESCRIPTION | Thread size | Tightening torque | |
|---|-------------|-------------------|---------|
| | | Nm | kgm |
| Rocker arm shaft support clearance | M 8 | 25 | 2.5 |
| Crank pulley hub bolt | M 30 x 1.5 | 294 | 30 |
| Fan and alternator pulley bolts | M 10 x 1.25 | 55 | 5.6 |
| Intake manifold retaining bolts | M 8 | 25 | 2.6 |
| Alternator and belt tensioner adjuster nut | M 10 x 1.25 | 55 | 5.6 |
| Water pump fixing bolts | M 10 x 1.25 | 55 | 5.6 |
| Rocker cover bolts | M 8 | 25 (*) | 2.6 (*) |
| Rocker arm shaft support clearance | M 8 | 25 | 2.6 |
| Oil pump and pump cover fixing bolts | M 8 | 25 | 2.6 |
| Timing gear housing and cover bolts | M 8 | 25 | 2.6 |
| Idle gear flange bolts | M 10 x 1.25 | 55 | 5.6 |
| Camshaft clearance adjustment plate fixing bolt | M 8 | 35 | 3.6 |
| Crankshaft back cover bolts | M 8 | 25 | 2.6 |
| Rocker shaft adjustment nut | M 8 | 22 | 2.2 |
| Exhaust manifold retaining bolts | M 8 | 25 | 2.6 |
| Injection pump fixing bolts | M 8 | 25 | 2.6 |
| Bolts fixing, - Oil sump cover to back cover | M 10 X 1.25 | 39 - 49 | 4 - 5 |
| - Cylinder block and flywheel ...All models | M 10 X 1.25 | 49 - 59 | 5 - 6 |

(*)


SPECIAL TOOLS

The tools listed below must be manufactured and used in order to work safely and efficiently and obtain the best results.

List of special tools necessary to carry out the different operations described in this Section.


| | | | |
|------------------|---|------------------|---|
| 380000226 | Engine front pulley puller. | | |
| 380000322 | Fuel pump gear puller | 380000277 | Exhaust Valve Guide Reamer Set. |
| 296044 | Valve adjustment wrench. | 380000302 | Valve Spring Compressor |
| 380000223 | Water pump propeller puller | 380000301 | Graduated protractor for angular tightening measurements. |
| 999900015 | Advance adjustment apparatus (suitable for 8-10 mm connection) | 380000247 | Water Pump Propeller Seal Installation Punch |
| 380000219 | Valve guide removal/installation punch. | 380000303 | Cylinder Compression Test Set |
| 380000242 | Valve guide installation bush (used together with Tool 380000219) | 380000246 | Injector Seat Refurbishment Set |
| 380000222 | Reamer Bit for Valve Guide | 380000308 | Injector Detachment Support |
| 380000276 | Drill Bit for Valve Guide (7.9 mm) | 380000309 | Injector Detachment Wrench Set |

Measurements necessary for manufacturing crankshaft front seat installation apparatus, are given in mm.
Material UNI C40.




1


Measurements necessary for manufacturing crankshaft front seat installation apparatus, are given in mm.
Material UNI C40.




2



LONGITUDINAL SECTION OF 3 CYLINDER ENGINE




CROSS SECTION OF 3 CYLINDER ENGINE



5

LUBRICATION SYSTEM OF 3 CYLINDER ENGINE

F. Filter G. Oil pressure gage L. Oil dipstick P. Pump S. Suction screen T. Oil fill cover V. Pressure bypass valve V1. Filter bypass valve



6

ENGINE COOLING SYSTEM

- a. Thermostat open
- b. Thermostat closed
- c. 3-cylinder models
- 1. Thermostat

- 2. Pump
- 3. Water temperature gage
- 4. Engine coolant temperature sender
- 5. Fan
- 6. Radiator

TROUBLESHOOTING

| Problem | Possible Causes | Suggested solutions |
|---|--|---|
| Engine does not start. | <ol style="list-style-type: none"> 1. Battery is partially flat. 2. Battery poles have been corroded or loose connections. 3. Injection pump timing is incorrect. 4. Impurities or water in fuel lines. 5. Fuel tank is empty. 6. Fuel delivery pump is not running. 7. Air in fuel system. 8. Starter motor is faulty. 9. Thermostarter is faulty. | <p>Check and charge the battery. If necessary, re place the battery.</p> <p>Clean, check and tighten the battery pole nuts. If necessary replace them.</p> <p>Readjust pump timing.</p> <p>Disconnect fuel lines from injection pump and clean thoroughly. If necessary clean and dry the fuel tank.</p> <p>Fill the tank.</p> <p>Check and replace pump if necessary.</p> <p>Check if there is air in the fuel lines, connectors, filters and injection pump and if necessary bleed the system.</p> <p>Repair or replace.</p> <p>Check and if necessary replace.</p> |
| Engine speed decreases and engine stops. | <ol style="list-style-type: none"> 10. Idle speed is low. 11. Irregular fuel distribution from injection pump. 12. Impurities or water in fuel lines. 13. Oil filter is clogged. 14. Valve setting is incorrect. 15. Valves are charred or cracked. 16. Air in fuel system. 17. Injection pump drive mechanism is faulty. | <p>Adjust the idle speed.</p> <p>Check the quantity of fuel distributed by the injection pump on test instrument.</p> <p>Disconnect fuel lines from injection pump and clean thoroughly. If necessary, clean and dry the fuel tank.</p> <p>Replace the filter elements.</p> <p>Adjust the Valve setting.</p> <p>Replace the valves.</p> <p>Check if there is air in the fuel lines, connectors, filters and injection pump. Bleed fuel system.</p> <p>Replace the defective parts.</p> |

(continued in the next page)

TROUBLESHOOTING

(continued)

| Problem | Possible Causes | Suggested solutions |
|---|--|---|
| Water pump is not running. | 18. Pump is defective. 19. Thermostat is defective. 20. Radiator is not running effectively. 21. There are deposits in the water passages within the cylinder head and engine block. 22. Pump and fan drive belt is loose. 23. Water level is low. 24. Incorrect timing. 25. Incorrect calibration of the injection pump (it pumps excessive fuel). 26. Air filter is clogged. | Repair or replace. Replace thermostat. Wash the channels of the radiator core. Check for leaks. Repair if there is any punctures. Clean the cooling system. Check and adjust. Add and adequate quantity of coolant to the radiator. Check and adjust. Calibrate the pump to the values stated on calibration charts, by means of test instrument. Clean the filter. If necessary replace the filter element. |
| Engine does not build up power and runs irregularly. | 27. Incorrect timing of the injection pump. 28. Automatic advance governor within the pump is damaged. 29. Distributor shaft is worn. 30. Irregular distribution by the injection pump. 31. Governor is defective for all speeds. 32. Injectors are partially clogged or damaged. 33. Impurities or water in fuel lines. | Adjust the pump timing. Calibrate the pump to the values stated on calibration charts, by means of test instrument. Calibrate the pump to the values stated on calibration charts, by means of test instrument. Calibrate the pump to the values stated on calibration charts, by means of test instrument. Calibrate the pump to the values stated on calibration charts, by means of test instrument. Clean, repair and calibrate the injectors. Disconnect fuel lines from injection pump and clean thoroughly. If necessary, clean and dry the fuel tank. |

(continued in the next page)

TROUBLESHOOTING

(continued)

| Problem | Possible Causes | Suggested solutions |
|---|--|--|
| Abnormal knocking noises from the engine. | 34. Fuel delivery pump is damaged. | Replace pump. |
| | 35. Valve setting is incorrect. | Adjust the Valve setting. |
| | 36. Cylinder pressure is low. | Test compression and if necessary, rectify the engine. |
| | 37. Air filter is clogged. | Clean the air filter and if necessary, replace the filter element. |
| | 38. The link between the accelerator pedal and injection pump is incorrectly adjusted. | Adjust to the correct length. |
| | 39. Maximum speed adjusting screw on the pump is incorrectly adjusted. | Adjust to the correct value. |
| | 40. Injectors are partially clogged or damaged. | Clean, repair and calibrate the injectors. |
| | 41. Impurities in fuel lines. | Clean and if necessary, replace the fuel lines. If necessary, clean the injection pump too. |
| | 42. Incorrect timing of the injection pump. | Adjust the pump timing. |
| | 43. Excessive gap or backlash in one or more of the crankshaft main journal or crank pin bearings. | Rectify the crankshaft and bushes. Install a suitable set of oversized bearings and washers. |
| | 44. Crankshaft is not balanced. | Check balance of crankshaft. If necessary, replace crankshaft. |
| | 45. Flywheel bolts are loose. | Tighten all loose bolts to the prescribed angular torque values. |
| | 46. Axes of the connecting rods are not parallel. | Straighten the connecting rods and check their axes. If necessary, re place them. |
| | 47. Piston knocks due to excessive wear-out. | Grind the cylinder surfaces and install an oversized piston. |
| 48. Noise stems from excessive clearance of the piston pins or lose bush. | Install an oversized gudgeon pin. Grind the bush seats. Replace the bushes. | |
| 49. Valve push rod cup/valve noise. | Check if there is excessive gap or pieces of broken spring between valve stems, valve guides and valve push rod roller and cylinders. Adjust the valve settings. | |

(continued in the next page)

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com