

Motoniveladora 670G/670GP



JOHN DEERE

CATÁLOGO DE PIEZAS

Motoniveladora 670G/670GP

PC10100 (Jun-10) Español

Worldwide Construction and Forestry Division

Litho in U.S.A. (Revised)
COPYRIGHT © 2010
DEERE & COMPANY
Moline, Illinois
All rights reserved

670G/670GP Motor Grader

TX1069859A A.1



670G/670GP Motor Grader

(Manufactured 2009–)

(Specifications and design subject to change without notice)

Al cliente

Los números de pieza en este catálogo de piezas eran correctos al momento de la publicación del catálogo. Es nuestra política mejorar continuamente nuestras máquinas y, por lo tanto, los números de pieza están sujetos a cambios. Al pedir las piezas, consultar al concesionario para verificar los números de pieza.

Unidades de medida SI

Siempre que sea aplicable, en todo este catálogo de piezas las dimensiones se indican en el sistema métrico.

Identificación de resistencia de pernos y tornillos

En este catálogo, los pernos y tornillos que deben tener características de resistencia alta equivalentes al grado 8 de SAE se identifican con la descripción HS SAE 8 (valor de sistema métrico 10.9). Todos los pernos y tornillos estándar son de grado 5 SAE (valor de sistema métrico 8.8) o inferior.

Información de lista de número de serie

La información de número de serie se lista para indicar la máquina en la cual se puede usar la pieza; por ejemplo:

- **La pieza puede usarse en todos los productos.**
- 000000** - **La pieza puede usarse en los productos a partir del número de serie listado.**
- **000000** **La pieza puede usarse en los productos hasta e inclusive el número de serie listado.**
- 000000** - **000000** **La pieza puede usarse en los productos entre e inclusive el número de serie listado.**

Cuando aparece XXXXXX en vez de un número de serie, se modificó el número de serie, pero el número de serie preciso no se tenía disponible en el momento de producción del catálogo.

Si se requieren números de identificación de producto o números de serie para reclamaciones de garantía o la correspondencia acerca de este producto, es muy importante suministrar todos los caracteres. No es posible sobreenfatizar este punto.

Flecha de sentido

Las flechas se emplean en las ilustraciones para indicar la parte delantera de la unidad. Los lados derecho e izquierdo se determinan mirando en el sentido de avance de la máquina.

Ilustraciones encerradas en cuadros

Al cuadro que encierra todas las piezas vendidas como un conjunto, se asigna un número de referencia que se emplea en la lista de piezas. Un cuadro sin número de referencia incluye piezas no actuales.

Conjuntos completos

Los conjuntos completos se listan en negritas. Pedir por separado. No incluir en el pedido de piezas de repuesto.

Orientación del motor

Los lados derecho e izquierdo se determinan al pararse junto al volante del motor y mirar hacia el motor.

Componentes John Deere Reman

Las piezas de repuesto listadas en este catálogo son para la reparación del equipo original. A pesar de que la mayoría de las piezas de repuesto puedan servir para reparar los componentes reconstruidos, en el proceso de reconstrucción se puede modificar los componentes de modo que las piezas de repuesto no sean adecuadas para usar.

Serial Number Location

Each 670G motor grader may have five serial number plates: one for the product identification number, one for the engine, one for the transmission, one for the hydraulic pump and one for the differential.

The product identification number plate is located below the operator's platform on the left-hand side of the main frame. This is the serial number used in this catalog unless otherwise noted in the serial number column.

The engine serial number plate is located on the left-hand side of the cylinder block above the starting motor for 9.0 L tier 3 engines.

The engine serial number plate is located on the side of the engine near the fuel transfer pump for 6.8 L stage II engines.

The transmission serial number plate is located on the lower left of the transmission housing.

The hydraulic pump serial number plate is located on the bottom of the pump.

The differential serial number plate is located on the cover, right lower, below the driveshaft input.

Note: In the transmission section, transmission serial number information is provided as follows: (1) When asterisks (*****) are listed in place of a serial number, a serial number change was made and "it" can be found in the remarks column in the publication. (2) When x's (xxxxxx) are listed in place of a serial number, a serial number change was not available at time of publication.

Product Identification Number

TX1069866 A.1



TX1069866

| First Line | Designates |
|---|---|
| DW | Manufacturer — John Deere Davenport Works |
| 670G | Model |
| X — Standard Controls P — Grade Pro Controls | Configuration |
| 123456 | Serial Number (Example) |
| Second Line | Designates |
| MOTOR GRADER | Unit Type |

Engine Emissions Level Identification

| Engine Model Number | Emissions Level |
|---------------------|----------------------|
| 6090HDW01 | Tier 3 / Stage III A |
| 6068HDW75 | Stage II |

Chapa de número de serie del motor

RGP11387 A.1



RGP11387

| El número de serie del motor consta de 13 caracteres | |
|--|--|
| Primer renglón | Designa |
| 1 — Dos letras para la designación de la fábrica del motor | RG: Waterloo, EE.UU. |
| 2 — Un dígito para la cantidad de cilindros | 6 cilindros |
| 3 — Tres dígitos para la cilindrada en litros | 090: nueve litros |
| 4 — Una letra para el tipo de aspiración o el nivel de emisiones | D= Motor atmosférico T= Turboalimentado H= Turboalimentado con posenfriador de aire-aire A= Turboalimentado con posenfriador de aire-aire B= Sin certificación C= Nivel de emisiones Tier1/Fase I G= Nivel de emisiones Tier 2/Fase II L= Nivel de emisiones Tier 3/Fase IIIA R= Nivel de emisiones provisional Tier 4/Fase IIIB |
| 5 — Seis dígitos | 123456= Número secuencial de fabricación del motor. Los números secuenciales empiezan en 001 |
| El tipo de motor se define con 9 caracteres alfanuméricos | |
| 6 — Cuatro dígitos | Igual a los puntos 2 y 3 de arriba |
| 7 — Una letra para el tipo de aspiración | Igual al punto 4 de arriba |
| 8 — Una o dos letras para el usuario | F= OEM, FM=marino |
| 9 — Dos o tres dígitos para la versión | 485 |

Engine Emissions Level Identification


| Engine Model Number | Emissions Level |
|----------------------------|------------------------|
| 6090HDW01 | Tier 3 / Stage III A |
| 6068HDW75 | Stage II |

Transmission Serial Number Plate



YZTAGS2 A.1

YZ XXXX X 123456



Marcas comerciales

En este catálogo de piezas pueden aparecer las siguientes marcas comerciales de Deere and Company:

| | | |
|------------------|---|--|
| Best Bid™ | CounterParts™ | DEERE™ (Deere™) |
| Dura-Trax™ | Fanggs™ | Guardian™ |
| HTH™ | Jagz™ | JDLink™ |
| MARKS™ | MIC™ [Centro de información de máquina] | MTH™ |
| Power Curve™ | PowerIel™ | PowerShift Plus™ |
| Powerwize™ | POWR SAVR™ | PowrShift™ |
| ProPath™ | Quad-Cool™ | Quik-Tatch™ |
| SC-2™ | Side-Tracker™ | Stinger™ |
| StructureALL™ | Swamper™ | TMC™ [Control total de la máquina] |
| ValueSelect™ | Waratah™ | Worksite Pro™ |
| FlexBox™ | Funk™ | iTorque™ |
| Phoenix™ | Phoenix International™ | PowerTech |
| PowerTech™ E | PowerTech™ M | PowerTech™ Plus |
| Precision Joint™ | SHIFT-O-MATIC™ | SWEDA™ (eje doble extremo súper ancho) |
| TeamMate™ | TeamMate™ II | TeamMate™ IV |
| TMII™ | TMIII™ | |

Comentarios y abreviaturas

Los comentarios y abreviaturas siguientes pueden aparecer en este catálogo de piezas. Consultar la tabla siguiente para las traducciones.

| Frase | Significado | Frase | Significado |
|------------------------------|---|------------------------|--|
| ALSO ORDER, ORD W/ | Pedir también | MFWD | Tracción delantera mecánica |
| AMP | Amperio | NA, NOT USED THIS APPL | No se usa para esta aplicación |
| APPL, APPL ONLY | Sólo esta aplicación | NLA | Ya no se encuentra disponible |
| AR | Según se requiera | NSEP | No disponible por separado |
| ASSY | Conjunto completo | OD | Diámetro exterior |
| BOAC | Borde cortante empernado | OPTIONAL | Opcional |
| CCW | En sentido contrahorario | OR | O |
| COMPLETE | Completo | ORD, ORDER | Pedir |
| COMPLETE GOODS | Mercancía completa | OS | Sobretamaño |
| CONVENIENCE ASSY, CA | Conjunto de comodidad | OUTER | Exterior |
| CTL, CUT TO LENGTH | Cortar según se requiera | PKG, PACKG | Paquete, paquete de |
| CW | Sentido horario | PTO | Toma de fuerza |
| ENGINE | Motor | RATIO | Relación |
| FOR | Para | REAR | Trasero |
| FRONT | Delantero | REMAN | Reconstruido |
| GAS | Gasolina | REPL | Sustituye |
| HFWD | Tracción delantera hidráulica | RH | Lado derecho |
| HP | Caballos de fuerza | SN | Número de serie |
| HS, HEAD MARKED | Resistencia alta, cabeza marcada | STD | Estándar |
| ID | Diámetro interior | SUB | Sustituido por |
| INCH | in. | SUB COMPONENTS | Sustituir componentes (del juego o conjunto) |
| INCL KEYS | Incluye los elementos… | SUB FOR | Sustitución para |
| INCL, INCLUDES | Incluye… | TEETH, Z | Número de dientes de engranaje |
| INCLUDES PARTS/ ITEMS MARKED | Incluye las piezas/elementos marcados… | TK | Espesor |
| INNER | Interior | UP, UPPER | Superior |
| KIT | Juego | US | Subtamaño |
| L | Número de eslabones | USE UNTIL EXHAUSTED | Usar hasta que se acabe |
| LF, LINE FILL | Llenado de línea | USE WITH | Usar con |
| LGP | Baja presión sobre suelo | VEC | Controlador electrónico de vehículo |
| LGTH | Largo | VLC | Centro eléctrico del vehículo |
| LH | Lado izquierdo | W/ | Con |
| LOW, LOWER | Inferior | W/O | Sin |
| LT | Cadena de oruga larga | WHOLE GOODS | Mercancía completa |
| MAKE FROM, MF | Fabricar de | WT | Cadena de oruga ancha |
| MARKED | Marcado | XLT | Cadena de oruga extra larga |
| MATCHED SET | Conjunto apareado | | |

670G/670GP Motor Grader

TX1069859A A.1



670G/670GP Motor Grader

(Manufactured 2009–)

(Specifications and design subject to change without notice)

To the Customer

The part numbers in this parts catalog were correct at the time your catalog was published. It is our policy to constantly improve our machines, and therefore, part numbers may change. When ordering parts, verify part numbers through your dealer.

SI Units of Measure

Metric dimensions are given, where applicable, throughout this parts catalog.

Bolt and Cap Screw Strength Identification

Bolts and cap screws required to have high-strength qualities equivalent to SAE grade 8 are identified throughout this catalog by the description HS SAE 8 (10.9 for metric). All standard bolts and cap screws are SAE grade 5 (metric 8.8) or lower.

Serial Number Listing Information

Serial number information is listed to show on which machines each part can be used; for example:

- **The part can be used on all products.**
- 000000** - **The part can be used on products beginning with the serial number listed.**
- **000000** **The part can be used on products up to and including the serial number listed.**
- 000000** - **000000** **The part can be used on products between and including the serial number listed.**

When XXXXXX's are listed in place of a serial number, a serial number change was made, but the exact serial number was not available when the catalog was produced.

If product identification numbers or serial numbers are required for warranty claims or correspondence pertaining to this product, it is extremely important that all characters be furnished. This point cannot be overemphasized.

Direction Arrow

Arrows are used with illustrations to indicate the front of the unit. "Right-Hand" and "Left-Hand" sides are determined by facing in direction of machine forward travel.

Box-enclosed Illustrations

A key number, shown in the parts list, is assigned to a box enclosing all parts sold as a service assembly. A box not keyed includes non-current parts.

Complete Goods Listings

Complete Goods are listed in bold face type. Order separately. Do not include on replacement part order.

Orientation of Engine

"Right Hand" and "Left Hand" sides are determined by standing at the flywheel and facing the engine.

John Deere Reman Components

The service parts listed in this catalog are intended for the repair of original equipment components. Although most service parts may be used to repair remanufactured components, the remanufacturing process may change parts sufficiently so that service parts are inadequate or not usable.

Serial Number Location

Each 670G motor grader may have five serial number plates: one for the product identification number, one for the engine, one for the transmission, one for the hydraulic pump and one for the differential.

The product identification number plate is located below the operator's platform on the left-hand side of the main frame. This is the serial number used in this catalog unless otherwise noted in the serial number column.

The engine serial number plate is located on the left-hand side of the cylinder block above the starting motor for 9.0 L tier 3 engines.

The engine serial number plate is located on the side of the engine near the fuel transfer pump for 6.8 L stage II engines.

The transmission serial number plate is located on the lower left of the transmission housing.

The hydraulic pump serial number plate is located on the bottom of the pump.

The differential serial number plate is located on the cover, right lower, below the driveshaft input.

Note: In the transmission section, transmission serial number information is provided as follows: (1) When asterisks (*****) are listed in place of a serial number, a serial number change was made and "it" can be found in the remarks column in the publication. (2) When x's (xxxxxx) are listed in place of a serial number, a serial number change was not available at time of publication.

Product Identification Number

TX1069866 A.1



TX1069866

| First Line | Designates |
|---|---|
| DW | Manufacturer — John Deere Davenport Works |
| 670G | Model |
| X — Standard Controls P — Grade Pro Controls | Configuration |
| 123456 | Serial Number (Example) |
| Second Line | Designates |
| MOTOR GRADER | Unit Type |

Engine Emissions Level Identification

| Engine Model Number | Emissions Level |
|---------------------|----------------------|
| 6090HDW01 | Tier 3 / Stage III A |
| 6068HDW75 | Stage II |

Engine Serial Number Plate

RGP11387 A.1



RGP11387

| Engine Serial Number is Defined by 13 Characters | |
|---|---|
| First Line | Designates |
| 1 — Two letters for engine factory designation | RG: Waterloo, USA |
| 2 — One digit for number of cylinders. | 6 Cylinder |
| 3 — Three digits for displacement in liters | 090: nine liter |
| 4 — One letter for aspiration type or emission level | D= Naturally Aspirated T= Turbocharged H= Turbocharged with air-to-air aftercooler A= Turbocharged with air-to-air aftercooler B= Non-Certified C= Tier1/Stage I emission level G= Tier 2/Stage II emission level L= Tier 3/Stage IIIA emission level R= Interim Tier 4/Stage IIIB emission level |
| 5 — Six digits | 123456= Engine build sequence number. Sequence numbers start at 000001 |
| Engine Type is Defined by 9 Alpha-Numerical Characters | |
| 6 — Four digits | Same as items 2 and 3 above |
| 7 — One letter for aspiration type | Same as item 4 above |
| 8 — One or two letters for user | F= OEM, FM=Marine |
| 9 — Two or three digits for version | 485 |

Engine Emissions Level Identification

| Engine Model Number | Emissions Level |
|----------------------------|------------------------|
| 6090HDW01 | Tier 3 / Stage III A |
| 6068HDW75 | Stage II |

Transmission Serial Number Plate



YZTAGS2 A.1

YZ XXXX X 123456

Product Identifier
T = Transmission

Model Identifier
F15 = DF150

Factory Identifier
C = Coffeyville
P = Piqua

Numeric Sequence
1 Sequence for each factory

TF15
TF25

T = Transmission

F/G = ECT
F15 = DF150
F25 = DF250

Trademarks

Throughout this parts catalog, you may find the following Deere and Company trademarks:

| | | |
|------------------|-----------------------------------|---------------------------------------|
| Best Bid™ | CounterParts™ | DEERE™ (Deere™) |
| Dura-Trax™ | Fanggs™ | Guardian™ |
| HTH™ | Jagz™ | JDLINK™ |
| MARKS™ | MIC™ [Machine Information Center] | MTH™ |
| Power Curve™ | PowerIel™ | PowerShift Plus™ |
| Powerwise™ | POWR SAVR™ | PowrShift™ |
| ProPath™ | Quad-Cool™ | Quik-Tatch™ |
| SC-2™ | Side-Tracker™ | Stinger™ |
| StructureALL™ | Swamper™ | TMC™ [Total Machine Control] |
| ValueSelect™ | Waratah™ | Worksite Pro™ |
| FlexBox™ | Funk™ | iTorque™ |
| Phoenix™ | Phoenix International™ | PowerTech™ |
| PowerTech™ E | PowerTech™ M | PowerTech™ Plus |
| Precision Joint™ | SHIFT-O-MATIC™ | SWEDA™ (Super Wide Extreme Dual Axle) |
| TeamMate™ | TeamMate™ II | TeamMate™ IV |
| TMII™ | TMIII™ | |

Remarks and Abbreviations

The following remarks and abbreviations may appear throughout this parts catalog. Refer to the following table for translations.

| Phrase | Meaning | Phrase | Meaning |
|---------------------------------|--------------------------------|------------------------|--|
| ALSO ORDER, ORD W/ | Also Order | MFWD | Mechanical Front Wheel Drive |
| AMP | Ampere | NA, NOT USED THIS APPL | Not used in this application |
| APPL, APPL ONLY | This application only | NLA | No longer available |
| AR | As required | NSEP | Not available separately |
| ASSY | Complete assembly | OD | Outside diameter |
| BOAC | Bolt-on cutting edge | OPTIONAL | Optional |
| CCW | Counterclockwise | OR | Or |
| COMPLETE | Complete | ORD, ORDER | Order |
| COMPLETE GOODS | Complete goods | OS | Oversize |
| CONVENIENCE ASSY, CA | Convenience assembly | OUTER | Outer |
| CTL, CUT TO LENGTH | Cut to length | PKG, PACKG | Package, Packet of |
| CW | Clockwise | PTO | Power Take Off |
| ENGINE | Engine | RATIO | Ratio |
| FOR | For | REAR | Rear |
| FRONT | Front | REMAN | Remanufactured |
| GAS | Gasoline | REPL | Replaces |
| HFWD | Hydraulic Front-Wheel Drive | RH | Right-hand |
| HP | Horsepower | SN | Serial number |
| HS, HEAD MARKED | High Strength, head marked | STD | Standard |
| ID | Inside diameter | SUB | Replaced by |
| INCH | Inch | SUB COMPONENTS | Substitute components (of the kit or assy) |
| INCL KEYS | Includes keys... | SUB FOR | Substitutes for |
| INCL, INCLUDES | Includes... | TEETH, Z | Number of gear teeth |
| INCLUDES PARTS/ ITEMS MARKED | Includes parts/items marked... | TK | Thickness |
| INNER | Inner | UP, UPPER | Upper |
| KIT | Kit | US | Undersize |
| L | Number of links | USE UNTIL EXHAUSTED | Use until exhausted |
| LF, LINE FILL | Line Fill | USE WITH | Use with |
| LGP | Low Ground Pressure | VEC | Vehicle Electronic Controller |
| LGTH | Length | VLC | Vehicle Load Center |
| LH | Left-hand | W/ | With |
| LOW, LOWER | Lower | W/O | Without |
| LT | Long Track | WHOLE GOODS | Whole Goods |
| MAKE FROM, MF | Make from | WT | Wide Track |
| MARKED | Marked | XLT | Extra Long Track |
| MATCHED SET | Matched set | | |

Índice

| | |
|---|-----|
| 01 Ruedas, neumáticos y orugas | |
| 0111 Ruedas motrices, aros | 52 |
| 02 Ejes, diferenciales y sistemas de suspensión hidr. | |
| 0201 Caja de puente motriz y soporte (incluye mandos finales) | 60 |
| 0225 Ejes impulsores de entrada y juntas universales..... | 72 |
| 0240 Puente (incluye tracción delantera) | 74 |
| 0261 Bomba de difer..... | 84 |
| 0263 Líneas, mangueras y adaptadores | 86 |
| 02A Axle | |
| 0200A Axle yz18885..... | 92 |
| 03 Transmisión | |
| 0315 Controles | 112 |
| 0325 Ejes impulsores de entrada y juntas universales..... | 118 |
| 0341 Caja y cubiertas | 120 |
| 0342 Piezas de montaje de transmisión..... | 122 |
| 0363 Líneas de aceite de transmisión | 124 |
| 0364 Filtro de transmisión, enfriador y deposito auxiliar | 132 |
| 03A Transmisión | |
| 0300A Transmisión yz19237, yz19238..... | 134 |
| 04A Motor | |
| 0400A Motor 6090HDW01..... | 178 |
| 04B Motor | |
| 0400B Motor 6068HDW75..... | 294 |
| 05 Sistema auxiliar del motor | |
| 0505 Auxiliares de arranque para tiempo frío..... | 390 |
| 0510 Sistemas de enfriamiento del motor | 402 |
| 0512 Ventilador..... | 424 |
| 0515 Controles de velocidad del motor | 434 |
| 0521 Filtro de aire y tubería..... | 440 |
| 0531 Silenciador y tubo de escape..... | 448 |
| 0540 Montaje del motor..... | 452 |
| 0563 Líneas y adaptadores de combustible | 456 |
| 0564 Tanque de combustible..... | 468 |
| 0575 Circuitos de control automáticos..... | 472 |
| 07 Embragues de tracción (motor) y desembrague | |
| 0715 Controles del embrague | 476 |
| 09 Sistema de dirección | |
| 0930 Dirección de emergencia | 480 |
| 0962 Válvula de dirección y control..... | 486 |
| 0963 Líneas de dirección, mangueras y adaptadores..... | 492 |
| 0965 Cilindros de la dirección..... | 508 |
| 10 Frenos de servicio | |
| 1062 Válvula de frenos de servicio..... | 520 |
| 1063 Varillaje, mangueras y adaptadores de frenos de servicio | 522 |
| 1064 Depósito y acumulador | 524 |
| 11 Frenos de estacionamiento | |
| 1100 Frenos de estacionamiento..... | 526 |
| 13 Varios – vehículo | |
| 1314 Escuadra para matrícula..... | 528 |
| 1322 Etiquetas y marcas comerciales | 530 |
| 1369 Grasas, aceites, combustibles y refrigerantes..... | 542 |
| 1370 Sistemas de lubricación..... | 550 |

Índice, continuación

| | |
|--|------|
| 15 Fijación del equipo | |
| 16 Sistemas eléctricos del vehículo | |
| 1671 Baterías, soporte y cables | 554 |
| 1672 Alambrado del alternador, regulador y sistema de carga | 562 |
| 1673 Sistema de alumbrado del vehículo..... | 574 |
| 1674 Grupo de cables e interruptores | 594 |
| 1675 Controles de sistemas | 664 |
| 1676 Instrumentos e indicadores..... | 676 |
| 17 Bastidor, chasis o estructura de apoyo | |
| 1741 Bastidor de motor o principal..... | 686 |
| 1746 Protectores inferiores del chasis..... | 690 |
| 1747 Parachoques del vehículo | 692 |
| 1749 Pesos del chasis..... | 694 |
| 18 Puesto del operador | |
| 1811 Rops, fops, ops o marco de carrocería..... | 698 |
| 1812 Plataforma | 710 |
| 1813 Costados, puertas, escudos y vidriado de carrocería..... | 728 |
| 1814 Parabrisas y limpiaparabrisas..... | 742 |
| 1816 Estructura de montaje de instrumentos y controles..... | 754 |
| 1821 Asiento y cinturón de seguridad | 790 |
| 1822 Peldaños y asideros | 804 |
| 1831 Calefactor, mangueras y controles | 806 |
| 1832 Compresor y mando de sistema de acond. de aire..... | 818 |
| 19 Chapa metálica y styling | |
| 1911 Capó y soportes..... | 828 |
| 1912 Escudos laterales del motor | 832 |
| 1913 Varios escudos | 834 |
| 1927 Guardabarros..... | 848 |
| 20 Seguridad, comodidad y varios | |
| 2001 Radio | 854 |
| 2002 Espejo..... | 856 |
| 2003 Extinguidor de incendios..... | 862 |
| 2004 Dispositivos de aviso incl. Bocina y alarma de retroceso..... | 864 |
| 2005 Caja de herramientas | 870 |
| 2007 Visera..... | 872 |
| 2008 Reflectores y emblema de VML..... | 876 |
| 21 Sistema hidráulico principal | |
| 2161 Bomba hidráulica y mando (si corresponde) | 878 |
| 2162 Válvulas de control selectivo y retención hidráulicas..... | 880 |
| 2163 Líneas y mangueras hidráulicas | 998 |
| 2164 Depósito hidráulicos, filtro y enfriador..... | 1012 |
| 26 Comunicación global de vehículo | |
| 2601 Controlador de comunicaciones | 1016 |
| 34 Dispositivo de explanación | |
| 3401 Hoja | 1020 |
| 3402 Extensión de hoja | 1054 |
| 3441 Bastidor principal (bastidor de tiro)..... | 1058 |
| 3442 Subbastidor (caballete)..... | 1060 |
| 3443 Bastidor móvil (círculo) | 1062 |
| 3450 Mecanismo de círculo..... | 1074 |
| 3460 Sistema hidráulico | 1078 |
| 3463 Líneas, mangueras y adaptadores | 1092 |

Índice, continuación

| | |
|--|------|
| 3465 Cilindros hidráulicos..... | 1116 |
| 3467 Motor hidráulico | 1126 |
| 42 Herramienta de preparación de tierra | |
| 4243 Bastidor móvil | 1128 |
| 4263 Líneas, mangueras y adaptadores | 1146 |
| 4265 Cilindro hidráulico | 1172 |

Índice alfabético

| Página | Página |
|---|----------|
| A | |
| ACCUMULATOR LABEL (FRENCH) | 536 |
| ACCUMULATOR LABEL (RUSSIAN) | 540 |
| ACCUMULATOR LABEL (SPANISH) | 538 |
| ACCUMULATOR, A/C (6068HDW75) | 824 |
| ACCUMULATOR, A/C (6090HDW01 / 6090HDW04) | 822 |
| ACCUMULATOR, BLADE IMPACT | 1112 |
| ACCUMULATOR, BRAKE | 524 |
| ACCUMULATOR, SECONDARY STEERING | 484 |
| ACCUMULATOR, SECONDARY STEERING (FIELD KIT) | 482 |
| ACCUMULATOR, SECONDARY STEERING (GRADE PRO) | 480 |
| ACTUATOR 6511 | 234 |
| ACTUATOR, BLADE SIDE SHIFT VALVE SECTION (EH) (GRADE PRO) | 984 |
| ACTUATOR, BLADE SIDE SHIFT VALVE SECTION (STD) | 910 |
| ACTUATOR, BLADE TILT VALVE SECTION (STD) | 914 |
| ACTUATOR, CIRCLE ROTATE VALVE SECTION (STD) | 912 |
| ACTUATOR, CIRCLE SIDE SHIFT VALVE SECTION (EH) (GRADE PRO) | 988 |
| ACTUATOR, CIRCLE SIDE SHIFT VALVE SECTION (STD) | 908 |
| ACTUATOR, LEFT AUXILIARY VALVE SECTION (WITHOUT FLOAT) (STD) | 932 |
| ACTUATOR, LEFT AUX VALVE WITH FLOAT (STD) | 928 |
| ACTUATOR, LEFT BLADE LIFT VALVE SECTION (STD) | 902 |
| ACTUATOR, MID MOUNTED SCARIFIER VALVE SECTION (STD) | 922 |
| ACTUATOR, REAR STEERING VALVE SECTION (STD) | 904 |
| ACTUATOR, RIGHT AUXILIARY VALVE SECTION (WITHOUT FLOAT) (STD) | 930 |
| ACTUATOR, RIGHT AUX VALVE WITH FLOAT (STD) | 926 |
| ACTUATOR, RIGHT BLADE LIFT VALVE SECTION (STD) (BREAKDOWN) | 900 |
| ACTUATOR, RIPPER VALVE SECTION (STD) | 924 |
| ACTUATOR, SCARIFIER VALVE SECTION (STD) | 920 |
| ACTUATOR, WHEEL LEAN VALVE SECTION (EH) (GRADE PRO) | 986 |
| ACTUATOR, WHEEL LEAN VALVE SECTION (STD) | 906 |
| Additional Fuel and Water Separator Kit (- 627690) | 464 |
| Additional Fuel and Water Separator Kit (627691 -) | 466 |
| Additional Fuel And Water Separator (Engines 6090HDW01 / 6090HDW04) | 460 |
| Additional Fuel And Water Separator (6068HDW75) | 462 |
| ADU (GRADE PRO) | 672 |
| ADU (STD CONTROLS) | 670 |
| AIR BAG KIT (GRADE PRO SEAT) | 800 |
| AIR BAG KIT (PREMIUM SEAT) | 796 |
| AIR BAG KIT (STANDARD SEAT) | 792 |
| AIR CLEANER LABEL (ENGLISH) | 530 |
| AIR CLEANER LABEL (FRENCH) | 536 |
| AIR CLEANER LABEL (RUSSIAN) | 540 |
| AIR CLEANER LABEL (SPANISH) | 538 |
| Air Cleaner (Engines 6090HDW01 / 6090HDW04) | 440 |
| Air Cleaner (Engine 6068HDW75) | 442 |
| Air Compressor Mounting - Plug | 238 |
| AIR COMPRESSOR (GRADE PRO SEAT) | 800 |
| AIR COMPRESSOR (PREMIUM SEAT) | 796 |
| AIR COMPRESSOR (STANDARD SEAT) | 792 |
| AIR COMPRESSOR (9901) | 269 |
| AIR COMPRESSOR, MIDLAND AUX DRIVE (9901) | 378 |
| AIR CONDITIONER AND HEATER COVER | 814 |
| AIR CONDITIONER AND HEATER DUCTS | 812 |
| Air Conditioning Compressor, Pulley and Service Kits | 826 |
| Air Conditioning Hoses (Engine 6068HDW75) | 824 |
| Air Conditioning Hoses (6090HDW01 / 6090HDW04) | 822 |
| AIR COOLER HOSES (6068HDW75) (SERIAL NUMBER 626426-) | 422 |
| AIR COOLER HOSES (6068HDW75) (SERIAL NUMBER-626425) | 420 |
| AIR COOLER HOSES (6090HDW01 / 6090HDW04) | 412, 414 |
| AIR FILTER, CAB FRESH | 814 |
| AIR HEATER, ENGINE | 390 |
| AIR INLET (1701) | 186 |
| AIR INLET, TURBO (5497) | 342 |
| Air Intake | 210 |
| AIR INTAKE (1701) | 186 |
| AIR PRESSURE SENSOR (6744) | 350 |
| Air Seat Suspension Components (Grade Pro) | 800 |
| Air Seat Suspension Components (Premium) | 796 |
| Air Seat Suspension Components (Standard) | 792 |
| Air Temperature Sensor | 210 |
| AIR TEMPERATURE SENSOR (1797) | 302 |
| AIR TEMPERATURE SENSOR (6744) | 350 |
| Alarm, Backup | 866 |
| Alternator (100 Amp) (Engine 6068HDW75) | 566 |
| Alternator (100 Amp) (6090HDW01 / 6090HDW04) | 562 |
| Alternator (130 Amp) (Engine 6068HDW75) | 568 |
| Alternator (130 Amp) (6090HDW01 / 6090HDW04) | 564 |
| ANTENNA, JD LINK™ | 1016 |
| ANTENNA, RADIO | 854 |
| Armrests (Grade Pro) | 802 |
| ARMRESTS, SEAT (GRADE PRO) | 802 |
| ARMREST WIRING HARNESSSES (GRADE PRO) | 636 |
| ARMREST WIRING HARNESSSES, LEFT (GRADE PRO) (CONNECTORS) | 644 |
| ARMREST WIRING HARNESSSES, RIGHT (GRADE PRO) (CONNECTORS) | 642 |
| ARM REST (DELUXE) | 794 |
| ARM REST (STD) | 790 |
| Articulation Cylinder | 514 |
| ARTICULATION CYLINDER COMPONENTS | 514 |
| ARTICULATION CYLINDER HOSES (STANDARD CONTROLS) | 496 |
| ARTICULATION CYLINDER PIN | 686 |
| Articulation Cylinder Pins | 512 |
| ARTICULATION LOCK LABEL | 530 |
| ARTICULATION PIN | 686 |
| ARTICULATION SENSOR (GRADE PRO) | 682 |
| ARTICULATION SENSOR (STD CONTROLS) | 680 |
| ARTICULATION VALVE SECTION (EH) (GRADE PRO) (BREAKDOWN) | 974 |
| ARTICULATION VALVE SECTION (STD) (BREAKDOWN) | 904 |
| ARTICULATION WARNING LABEL (ENGLISH) | 530 |
| ARTICULATION WARNING LABEL (FRENCH) | 536 |
| ASSEMBLY, BRAKE- W/O FINAL DRIVE | 100 |
| ASSEMBLY, FIFTH STAGE SHAFT DF180 | 144 |
| ASSEMBLY, FIRST STAGE SHAFT DF180 | 136 |
| ASSEMBLY, FOURTH STAGE SHAFT DF180 | 142 |
| ASSEMBLY, OUTPUT GROUP DF180 | 148 |
| ASSEMBLY, SECOND STAGE SHAFT DF180 | 138 |
| ASSEMBLY, SIXTH STAGE SHAFT DF180 | 146 |
| ASSEMBLY, SPIRAL BEVEL 4.364 | 92 |
| ASSEMBLY, THIRD STAGE SHAFT DF180 | 140 |
| ASSEMBLY, VALVE DF180 | 158 |
| ASSEMBLY, VLV BODY | 110 |
| AUXILIARY CONTROLS, EH (GRADE PRO) | 788 |
| AUXILIARY CONTROL VALVE KIT, EH (GRADE PRO) | 996 |
| AUXILIARY DRIVE COVER 5299 | 228 |
| AUXILIARY DRIVE, MAIN HYDRAULIC PUMP | 878 |
| AUXILIARY HOSES, REAR (SIXTH FUNCTION) (STANDARD CONTROLS) | 1168 |
| AUXILIARY PLUMBING, REAR (GRADE PRO) (FIFTH FUNCTION) | 1166 |
| AUXILIARY PLUMBING, REAR (SIXTH FUNCTION) (GRADE PRO) | 1170 |
| AUXILIARY REAR HOSES (STANDARD) | 1164 |
| AUXILIARY VALVE CONTROLLER, EH (GRADE PRO) | 668 |
| Auxiliary Valve Section (Grade Pro) | 994 |
| AUXILIARY VALVE SECTION, LEFT (WITHOUT FLOAT) (STD) (BREAKDOWN) | 932 |
| AUXILIARY VALVE SECTION, RIGHT (WITHOUT FLOAT) (STD) (BREAKDOWN) | 930 |
| AUX CONTROL VALVE KIT W/O FLOAT (SEVENTH FUNCTION LH) | 944 |
| AUX CONTROL VALVE KIT W/O FLOAT (SEVENTH FUNCTION RH) | 942 |
| AUX CONTROL VALVE KIT W/ FLOAT (SIXTH FUNCTION LH) | 940 |
| AUX W/O FLOAT CONTROL LINKAGE (SEVENTH FUNCTION LEFT) | 774 |
| AUX W/ FLOAT CONTROL LINKAGE (SEVENTH FUNCTION RIGHT) | 772 |
| AUX W/ FLOAT CONTROL LINKAGE (SIXTH FUNCTION LEFT) | 770 |
| AUX W/ FLOAT CONTROL LINKAGE (SIXTH FUNCTION RIGHT) | 768 |
| Axle and Drive Chain | 68 |
| AXLE BEARING | 68 |
| AXLE COOLER HOSES | 402 |
| AXLE DRIVESHAFT | 72 |
| AXLE DRIVE SHAFT | 64 |
| AXLE DRIVE SPROCKET | 68 |
| Axle Grease Fittings | 70 |
| Axle Grease Hoses | 70 |
| Axle Grease Lines Kit | 86 |
| Axle Hoses and Fittings | 70 |
| AXLE HOUSING | 68 |
| AXLE HOUSING AND SHAFT (RE44158) | 96 |
| AXLE HOUSING OIL SEAL | 68 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> |
|--|---------------|
| AXLE/GEARBOX OIL LABEL..... | 530 |
| AXLE, FRONT..... | 74 |
| AXLE, FRONT, TIE ROD..... | 78 |
| A/C AND HEATER CONTROL CABLE..... | 818 |
| A/C AND HEATER CONTROL KNOB..... | 818 |
| A/C AND HEATER THERMOSTAT SWITCH..... | 820 |
| A/C AND HEATER WIRING HARNESS..... | 818 |
| A/C AND HEAT TEMPERATURE CONTROL SWITCH..... | 818 |
| A/C BLOWER MOTOR AND SWITCH..... | 820 |
| A/C COMPRESSOR (COMPLETE) (6068HDW75)..... | 824 |
| A/C COMPRESSOR (COMPLETE) (6090HDW01 / 6090HDW04)..... | 822 |
| A/C COMPRESSOR (COMPONENTS)..... | 826 |
| A/C CONDENSER (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| A/C CONDENSER (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| A/C CONDENSER (6090HDW01 / 6090HDW04) (SN 626426-)..... | 410 |
| A/C CONDENSER (6090HDW01 / 6090HDW04) (SN-626425)..... | 408 |
| A/C CONTROL SWITCH..... | 818 |
| A/C HOSES (6068HDW75)..... | 824 |
| A/C HOSES (6090HDW01 / 6090HDW04)..... | 822 |
| A/C MANIFOLD..... | 826 |
| A/C PRESSURE SWITCH..... | 818 |
| A/C PULLEY KIT..... | 826 |
| B | |
| BACKREST CUSHION (DELUXE)..... | 794 |
| BACKREST CUSHION (GRADE PRO)..... | 798 |
| BACKREST CUSHION (STD)..... | 790 |
| Backup Alarm..... | 866 |
| BAFFLE, RADIATOR (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| BAFFLE, RADIATOR (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| BAFFLE, RADIATOR (6090HDW01 / 6090HDW04) (SN 626426-)..... | 410 |
| BAFFLE, RADIATOR (6090HDW01 / 6090HDW04) (SN-626425)..... | 408 |
| BAG, OPERATORS MANUAL (GRADE PRO)..... | 714, 716 |
| BALL RETAINER, DRAFT FRAME..... | 1058 |
| Batteries and Battery Cables (1000 CCA) (Engine 6068HDW75)..... | 558 |
| Batteries and Battery Cables (1000 CCA) (6090HDW01 / 6090HDW04)..... | 554 |
| Batteries and Battery Cables (1400 CCA) (Engine 6068HDW75)..... | 560 |
| Batteries and Battery Cables (1400 CCA) (6090HDW01 / 6090HDW04)..... | 556 |
| BATTERY BOX..... | 1014 |
| BATTERY COVERS..... | 832 |
| BATTERY DISCONNECT LABEL (FRENCH)..... | 536 |
| BATTERY DISCONNECT LABEL (SPANISH)..... | 538 |
| BATTERY DISCONNECT SWITCH BRACKET..... | 1014 |
| BATTERY DISCONNECT LABEL (RUSSIAN)..... | 540 |
| Beacon Light Bracket..... | 588 |
| BEACON, WARNING (STROBE)..... | 592 |
| BEARINGS AND CRANKSHAFT (4712)..... | 332 |
| BEARINGS, CONNECTING ROD (4801)..... | 220 |
| BEARINGS, CONNECTING ROD (4834)..... | 334 |
| BEARING CONNECTING ROD (9901)..... | 366 |
| BEARING KIT (9901)..... | 361, 362, 363 |
| BEARING KIT, CONNECTING ROD (9901)..... | 250 |
| BEARING KIT, MAIN (9901)..... | 249 |
| BEARING KIT, THRUST (9901)..... | 251 |
| BEARING, THRUST (9901)..... | 365 |
| BEARING, AXLE..... | 68 |
| BEARING, CIRCLE DRIVE GEARBOX..... | 1074 |
| BEARING, CIRCLE DRIVE GEARBOX WITH SLIP CLUTCH..... | 1076 |
| BEARING, MANUAL CONTROL LEVER SHAFT..... | 760 |
| BELT, ENGINE W/ 100A ALTERNATOR (6068HDW75)..... | 566 |
| BELT, ENGINE W/ 100A ALTERNATOR (6090HDW01 / 6090HDW04)..... | 562 |
| BELT, ENGINE W/ 130A ALTERNATOR (6068HDW75)..... | 568 |
| BELT, ENGINE W/ 130A ALTERNATOR (6090HDW01 / 6090HDW04)..... | 564 |
| BINARY PRESSURE SWITCH, A/C..... | 818 |
| Bit, End (12 ft. X 24 in. X 7/8 in. Moldboard With 5/8 in. X 6 in. Cutting Edge)..... | 1020 |
| Bit, End (12 ft. X 24 in. X 7/8 in. Moldboard With 5/8 in. X 8 in. Cutting Edge)..... | 1022 |
| Bit, End (12 ft. X 27 in. X 1 in. Moldboard With 5/8 in. X 8 in. Cutting Edge)..... | 1024 |
| Bit, End (13 ft. X 27 in. X 1 in. Moldboard With 5/8 in. X 8 in. Cutting Edge)..... | 1026 |
| Bit, End (14 ft. X 24 in. X 7/8 in. Moldboard With 5/8 in. X 6 in. Cutting Edge)..... | 1028 |
| Bit, End (14 ft. X 24 in. X 7/8 in. Moldboard With 5/8 in. X 8 in. Cutting Edge)..... | 1030 |
| Bit, End (14 ft. X 27 in. X 1 in. Moldboard With 5/8 in. X 8 in. Cutting Edge)..... | 1032 |
| Bit, End (14 ft. X 27 in. X 1 in. Moldboard With 5/8 in. X 8 in. Cutting Edge) (3/4 in. Hardware)..... | 1034 |
| Blade Impact Switch (Grade Pro)..... | 1090 |
| Blade Impact Switch (Standard Controls)..... | 1088 |
| Blade Impact System Accumulator..... | 1112 |
| Blade Impact System Field Kit (Grade Pro)..... | 1084 |
| Blade Impact System Field Kit (Standard Controls)..... | 1082 |
| Blade Impact System Hoses (Grade Pro)..... | 1110 |
| Blade Impact System Hoses (Standard Controls)..... | 1108 |
| Blade Impact Valve..... | 1086 |
| Blade Impact Valve Wiring Harness..... | 658 |
| BLADE INSERTS (STANDARD)..... | 1072 |
| BLADE LIFT ARM AND BUSHINGS..... | 1060 |
| Blade Lift Cylinder..... | 1116 |
| Blade Lift Cylinder Hydraulic Hoses (Grade Pro)..... | 1094 |
| Blade Lift Cylinder Hydraulic Hoses (Standard Controls)..... | 1092 |
| BLADE LIFT VALVE RELIEF VALVE, RIGHT (STD) (BREAKDOWN)..... | 900 |
| Blade Lift Valve Section (Grade Pro)..... | 978 |
| BLADE LIFT VALVE SECTION, LEFT (STD) (BREAKDOWN)..... | 902 |
| BLADE LIFT VALVE SECTION, RIGHT (STD) (BREAKDOWN)..... | 900 |
| BLADE ROTATION SENSOR..... | 684 |
| BLADE SIDE SHIFT CONTROL LINKAGE..... | 762 |
| BLADE SIDE SHIFT CONTROL, LEFT 4 FUNCTION (EH) (GRADE PRO)..... | 782 |
| BLADE SIDE SHIFT CONTROL, LEFT 5 FUNCTION (EH) (GRADE PRO)..... | 786 |
| BLADE SIDE SHIFT CYLINDER HOSES (GRADE PRO)..... | 1098 |
| BLADE SIDE SHIFT CYLINDER HOSES (STANDARD CONTROLS)..... | 1096 |
| Blade Side Shift Valve Section (Grade Pro)..... | 984 |
| Blade Side Shift Valve Section (Standard Controls)..... | 910 |
| Blade Slide Cylinder..... | 1118 |
| Blade Tilt and Side Shift Hydraulic Hoses (Grade Pro)..... | 1098 |
| Blade Tilt and Side Shift Hydraulic Hoses (Standard Controls)..... | 1096 |
| BLADE TILT CONTROL LINKAGE..... | 762 |
| BLADE TILT CONTROL, LEFT 4 FUNCTION (EH) (GRADE PRO)..... | 782 |
| BLADE TILT CONTROL, LEFT 5 FUNCTION (EH) (GRADE PRO)..... | 786 |
| Blade Tilt Cylinder..... | 1120 |
| Blade Tilt Frame..... | 1062 |
| Blade Tilt Valve Section (Grade Pro)..... | 980 |
| Blade Tilt Valve Section (Standard Controls)..... | 914 |
| BLADE, FRONT MOUNTED DOZER..... | 1144 |
| BLADE, FRONT WINDSHIELD WIPER (FULL HEIGHT CAB)..... | 744 |
| BLADE, FRONT WINDSHIELD WIPER (LOW PROFILE CAB)..... | 742 |
| BLADE, REAR WINDSHIELD WIPER (FULL HEIGHT CAB)..... | 748 |
| BLADE, REAR WINDSHIELD WIPER (LOW PROFILE CAB)..... | 746 |
| BLOCK ASSEMBLY SHORT (9901)..... | 376 |
| BLOCK ASSEMBLY, COMPLETE (9901)..... | 256 |
| BLOCK, CAMSHAFT(4633)..... | 330 |
| BLOCK, CYLINDER (4601)..... | 214 |
| BLOCK, CYLINDER (4606)..... | 216 |
| BLOCK, PUSH..... | 694 |
| BLOCK, SHORT (9901)..... | 254, 258 |
| BLOWER MOTOR AND SWITCH, HEATER AND A/C..... | 820 |
| BOLT KIT, CYLINDER HEAD (9901)..... | 262 |
| BOLT, HOOK (1000 CCA BATTERIES) (6068HDW75)..... | 558 |
| BOLT, HOOK (1000 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 554 |
| BOLT, HOOK (1400 CCA BATTERIES) (6068HDW75)..... | 560 |
| BOLT, HOOK (1400 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 556 |
| BOOM SCARIFIER, LIFT (FIELD KIT)..... | 1138 |
| BOTTOM GUARD KIT..... | 690 |
| BOTTOM GUARD (FUEL TANK)..... | 690 |
| BOX, BATTERY..... | 1014 |
| BRACKETS, ENGINE MOUNTING (6068HDW75)..... | 454 |
| BRACKETS, ENGINE MOUNTING (6090HDW01 / 6090HDW04)..... | 452 |
| BRACKETS, SEAT (DELUXE)..... | 794 |
| BRACKETS, SEAT (GRADE PRO)..... | 798 |
| BRACKETS, SEAT (STD)..... | 790 |
| BRACKETS, SNOW LIGHTS..... | 586 |
| Brackets, Wiring Harness..... | 244 |
| BRACKET, AIR CLEANER (6068HDW75)..... | 442 |
| BRACKET, AIR CLEANER (6090HDW01 / 6090HDW04)..... | 440 |
| BRACKET, ALTERNATOR, 100AMP (6068HDW75)..... | 566 |
| BRACKET, ALTERNATOR, 100AMP (6090HDW01 / 6090HDW04)..... | 562 |
| BRACKET, ALTERNATOR, 130AMP (6068HDW75)..... | 568 |
| BRACKET, ALTERNATOR, 130AMP (6090HDW01 / 6090HDW04)..... | 564 |
| BRACKET, BATTERY DISCONNECT SWITCH..... | 1014 |
| BRACKET, BATTERY (1000 CCA) (6068HDW75)..... | 558 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> |
|---|---------------|
| BRACKET, BATTERY (1000 CCA) (6090HDW01 / 6090HDW04) | 554 |
| BRACKET, BATTERY (1400 CCA) (6068HDW75)..... | 560 |
| BRACKET, BATTERY (1400 CCA) (6090HDW01 / 6090HDW04) | 556 |
| BRACKET, BEACON LIGHT | 588 |
| BRACKET, BLADE IMPACT ACCUMULATOR | 1112 |
| BRACKET, BOTTOM GUARD..... | 690 |
| BRACKET, BRAKE VALVE/PEDAL MOUNTING | 520 |
| BRACKET, CAB STEP | 804 |
| BRACKET, COOLANT HEATER (120V) (6068HDW75) | 396 |
| BRACKET, COOLANT HEATER (120V) (6090HDW01 / 6090HDW04) | 394 |
| BRACKET, COOLANT HEATER, DIESEL FIRED (6090HDW01 / 6090HDW04) | 400 |
| BRACKET, DISPLAY MONITOR (GRADE PRO)..... | 672 |
| BRACKET, DISPLAY MONITOR (STD CONTROLS) | 670 |
| BRACKET, DISPLAY MONITOR, ALTERNATE MOUN MOUNTING (IGC) | 674 |
| BRACKET, EH CONTROLLER MOUNTING (GRADE PRO)..... | 668 |
| BRACKET, EH VALVE HARNESS BULKHEAD (GRADE PRO)..... | 646 |
| BRACKET, ENGINE COMPARTMENT WORK LIGHTS | 584 |
| BRACKET, ETHER START AID | 392 |
| BRACKET, EXTERIOR MIRROR | 858 |
| BRACKET, EXTERIOR MIRROR (HEATED) | 860 |
| BRACKET, FIRE EXTINGUISHER | 862 |
| BRACKET, FLC MOUNTING (GRADE PRO)..... | 758 |
| BRACKET, FLC MOUNTING (STD CONTROLS)..... | 756 |
| BRACKET, FRONT EH VALVE MOUNT (GRADE PRO) | 954 |
| BRACKET, FRONT FENDERS | 848 |
| BRACKET, FRONT MOUNTED SCARIFIER | 1128 |
| BRACKET, HVAC MODE ACTUATOR..... | 812 |
| Bracket, IGC Mast Mounts (3/4 in. Hardware) | 1056 |
| Bracket, IGC Mast Mounts (5/8 in. Hardware)..... | 1054 |
| Bracket, Left Moldboard Extension (24 in. With 5/8 in. Hardware)..... | 1044 |
| Bracket, Left Moldboard Extension (27 in. With 3/4 in. Hardware)..... | 1052 |
| Bracket, Left Moldboard Extension (27 in. With 5/8 in. Hardware)..... | 1048 |
| BRACKET, LICENSE PLATE | 528 |
| BRACKET, MACHINE INFORMATION GATEWAY (MIG)..... | 1018 |
| BRACKET, MAIN CONTROL VALVE MOUNTING..... | 880 |
| BRACKET, MAIN MANIFOLD VALVE (W/O SEC. STEERING)..... | 950 |
| BRACKET, MAIN MANIFOLD VALVE (W/ SEC. STEERING)..... | 948 |
| BRACKET, MID MOUNTED SCARIFIER..... | 1140 |
| BRACKET, POWER CONVERTER (15 AMP)..... | 570 |
| BRACKET, POWER CONVERTER (25 AMP)..... | 572 |
| BRACKET, RADIO..... | 854 |
| BRACKET, REAR EH VALVE MOUNT (GRADE PRO)..... | 956 |
| BRACKET, REAR WORK LIGHTS..... | 578 |
| Bracket, Right Moldboard Extension (24 in. With 5/8 in. Hardware) | 1042 |
| Bracket, Right Moldboard Extension (27 in. With 3/4 in. Hardware) | 1050 |
| Bracket, Right Moldboard Extension (27 in. With 5/8 in. Hardware) | 1046 |
| BRACKET, SADDLE LOCK PIN..... | 1060 |
| BRACKET, STEERING TILT (GRADE PRO) | 778 |
| BRACKET, STEERING TILT (STD CONTROLS)..... | 760 |
| BRACKET, TRANSMISSION CONTROL UNIT MOUNTING..... | 116 |
| BRACKET, TRANSMISSION GEAR SELECTOR (GRADE PRO)..... | 114 |
| BRACKET, TRANSMISSION GEAR SELECTOR (STANDARD CONTROLS)..... | 112 |
| BRACKET, TRANSMISSION WIRING HARNESS..... | 618 |
| BRACKET, FRONT MOUNTED DOZER BLADE | 1144 |
| BRAKES, SERVICE | 66 |
| Brake Accumulator | 524 |
| BRAKE ACCUMULATOR HOSES | 522 |
| BRAKE ACCUMULATOR PRESSURE SWITCH..... | 520 |
| BRAKE ASSEMBLY WITHOUT FINAL DRIVE (RE65559)..... | 100 |
| BRAKE COVER LABEL (ENGLISH) | 530 |
| BRAKE COVER LABEL (FRENCH)..... | 536 |
| BRAKE COVER LABEL (RUSSIAN)..... | 540 |
| BRAKE COVER (SPANISH)..... | 538 |
| BRAKE DISK | 66 |
| BRAKE LIGHTS, LED | 576 |
| BRAKE LIGHT SWITCH..... | 520 |
| BRAKE PEDAL..... | 520 |
| BRAKE VALVE HOSES..... | 522 |
| BRAKE VALVE/PEDAL MOUNTING BRACKET | 520 |
| BRAKE VALVE, SERVICE..... | 520 |
| BREAKER, CIRCUIT, ENGINE AIR HEATER (120A) | 390 |
| BREAKER, CIRCUIT, GLOW PLUG (120A)..... | 398 |
| BREATHER FILTER, HYDRAULIC RESERVOIR | 1014 |
| BREATHER, FAST FILL FUEL SYSTEM | 470 |
| BREATHER, FUEL TANK..... | 468 |
| BREATHER, TANDEM HOUSING | 60 |
| BULB, FRONT AND REAR CAB WORK LIGHTS..... | 580 |
| BULB, FRONT AND REAR WORK LIGHT | 578 |
| BULB, FRONT DRIVING LIGHTS | 574 |
| BULB, FRONT SIGNAL LIGHT | 574 |
| BULB, INTERIOR DOME | 590 |
| BULB, LICENSE PLATE LIGHT | 528 |
| BULB, SIDE CAB WORK LIGHTS | 582 |
| BULB, STROBE WARNING BEACON..... | 592 |
| BUMPER, DOOR, SERVICE | 832 |
| BUSHING, BLADE LIFT CYLINDER..... | 1060 |
| BUSHING, BLADE TILT FRAME..... | 1062 |
| BUSHING, CIRCLE FRAME | 1064 |
| BUSHING, FRONT MOUNTED DOZER BLADE | 1144 |
| BUSHING, MID MOUNTED SCARIFIER HYDRAULIC CYLINDER..... | 1176 |
| BUSHING, RIPPER CYLINDER..... | 1174 |
| BUSHING, SADDLE FRAME | 1060 |
| BUTTON, HORN | 676 |
| BUTTON, HORN (GRADE PRO) | 636 |
| BUZZER, PRIMARY WARNING..... | 676 |
| BUZZER, PRIMARY WARNING (GRADE PRO)..... | 678 |
| B-POST CAB DISPLAY MOUNTING BRACKET | 674 |
| C | |
| CABLE, A/C AND HEATER CONTROL | 818 |
| CABLE, BATTERY GROUND (1000 CCA) (6068HDW75) | 558 |
| CABLE, BATTERY GROUND (1000 CCA) (6090HDW01 / 6090HDW04) | 554 |
| CABLE, BATTERY GROUND (1400 CCA) (6068HDW75) | 560 |
| CABLE, BATTERY GROUND (1400 CCA) (6090HDW01 / 6090HDW04) | 556 |
| CABLE, BATTERY TO BATTERY (1000 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 554 |
| CABLE, BATTERY TO BATTERY (1000 CCA) (6068HDW75) | 558 |
| CABLE, BATTERY TO BATTERY (1400 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 556 |
| CABLE, BATTERY TO BATTERY (1400 CCA) (6068HDW75) | 560 |
| CABLE, BATTERY TO DISCONNECT (1000 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 554 |
| CABLE, BATTERY TO DISCONNECT (1000 CCA) (6068HDW75) | 558 |
| CABLE, BATTERY TO DISCONNECT (1400 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 556 |
| CABLE, BATTERY TO DISCONNECT (1400 CCA) (6068HDW75) | 560 |
| CABLE, BATTERY TO STARTER (1000 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 554 |
| CABLE, BATTERY TO STARTER (1000 CCA) (6068HDW75) | 558 |
| CABLE, BATTERY TO STARTER (1400 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 556 |
| CABLE, BATTERY TO STARTER (1400 CCA) (6068HDW75) | 560 |
| CABLE, BATTERY (1000 CCA) (6068HDW75) | 558 |
| CABLE, BATTERY (1000 CCA) (6090HDW01 / 6090HDW04)..... | 554 |
| CABLE, BATTERY (1400 CCA) (6068HDW75) | 560 |
| CABLE, BATTERY (1400 CCA) (6090HDW01 / 6090HDW04)..... | 556 |
| CABLE, DISCONNECT TO GROUND (1000 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 554 |
| CABLE, DISCONNECT TO GROUND (1400 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 556 |
| CABLE, DISCONNECT TO STARTER (1000 CCA) (6068HDW75) | 558 |
| CABLE, DISCONNECT TO STARTER (1400 CCA) (6068HDW75) | 560 |
| CABLE, GROUND, FRAME TO FRAME (1000 CCA BATTERIES) (6068HDW75) | 558 |
| CABLE, GROUND, FRAME TO FRAME (1000 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 554 |
| CABLE, GROUND, FRAME TO FRAME (1400 CCA BATTERIES) (6068HDW75) | 560 |
| CABLE, GROUND, FRAME TO FRAME (1400 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 556 |
| CABLE, RADIO ANTENNA | 854 |
| CABLE, STARTER TO GROUND (1000 CCA) (6068HDW75) | 558 |
| CABLE, STARTER TO GROUND (1400 CCA) (6068HDW75) | 560 |
| Cab Decals and Labels | 532 |
| Cab Decals and Labels (Grade Pro) | 534 |
| Cab Display Monitor Alternate Mounting Bracket..... | 674 |
| Cab Display Monitor (Grade Pro) | 672 |
| Cab Display Monitor (Standard Controls)..... | 670 |
| Cab Doors (Full Height Cab) | 732 |
| Cab Doors (Low Profile Cab)..... | 730 |
| CAB ENCLOSURE, GRADE PRO W/ AND OPENING WINDOWS (COMPLETE)..... | 704 |
| CAB ENCLOSURE, LOW PROFILE W/ DOORS AND FIXED WINDOWS (COMPLETE)..... | 698 |

Índice alfabético, continuación

| Página | Página | | |
|--|---------------|--|----------|
| CAB ENCLOSURE, LOW PROFILE W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 700 | CHECK VALVE (REVERSING FAN)..... | 432 |
| Cab Floormat (Grade Pro)..... | 724 | CHECK VALVE, AUX/RIPPER/SCAFIER VALVE SECTION (EH) (GRADE PRO)..... | 994 |
| Cab Floormat (Standard Controls)..... | 722 | CHECK VALVE, A/C EVAPORATION (6068HDW75)..... | 824 |
| CAB FRESH AIR FILTER..... | 814 | CHECK VALVE, A/C EVAPORATION (6090HDW01 / 6090HDW04)..... | 822 |
| CAB FRESH AIR FILTER HOUSING..... | 814 | CHECK VALVE, BLADE SIDE SHIFT VALVE SECTION (EH) (GRADE PRO)..... | 984 |
| CAB FRONT CONSOLE (GRADE PRO)..... | 778 | CHECK VALVE, BLADE SIDE SHIFT VALVE SECTION (STD)..... | 910 |
| CAB FRONT CONSOLE (STD CONTROLS)..... | 760 | CHECK VALVE, BLADE TILT VALVE SECTION (EH) (GRADE PRO)..... | 980 |
| Cab Heater Hoses (Engine 6068HDW75)..... | 810 | CHECK VALVE, BLADE TILT VALVE SECTION (STD)..... | 914 |
| Cab Heater Hoses (6090HDW01 / 6090HDW04) (Without Coolant Heater)..... | 806 | CHECK VALVE, BRAKE ACCUMULATOR..... | 524 |
| Cab Heater Hoses (6090HDW01 / 6090HDW04)(With Coolant Heater)..... | 808 | CHECK VALVE, CIRCLE SIDE SHIFT VALVE SECTION (EH) (GRADE PRO)..... | 988 |
| Cab Interior Wiring Harness..... | 622 | CHECK VALVE, CIRCLE SIDE SHIFT VALVE SECTION (STD)..... | 908 |
| Cab Interior Wiring Harness (Connectors)..... | 624, 626, 628 | CHECK VALVE, HYDRAULIC OIL COOLER BYPASS..... | 952 |
| Cab Isolators..... | 708 | CHECK VALVE, LEFT AUX VALVE WITH FLOAT (STD)..... | 928 |
| CAB LABELS, ENGLISH (STD CAB)..... | 532 | CHECK VALVE, MAIN MANIFOLD VALVE (W/O SEC. STEERING)..... | 950 |
| CAB LIGHTS, FRONT AND REAR..... | 580 | CHECK VALVE, MAIN MANIFOLD VALVE (W/ SEC. STEERING)..... | 948 |
| CAB POWER WIRING HARNESS (FLC)..... | 622 | CHECK VALVE, MID MOUNTED SCARIFIER VALVE SECTION (STD)..... | 922 |
| CAB POWER WIRING HARNESS (FLC) (CONNECTORS)..... | 632 | CHECK VALVE, REAR STEERING VALVE SECTION (EH) (GRADE PRO) (BREAKDOWN)..... | 974 |
| Cab Rear Interior Panels..... | 726 | CHECK VALVE, REAR STEERING VALVE SECTION (STD)..... | 904 |
| CAB REAR WIRING HARNESS CONNECTOR COVER..... | 594 | CHECK VALVE, RIGHT AUX VALVE WITH FLOAT (STD)..... | 926 |
| Cab Roof..... | 728 | CHECK VALVE, SCARIFIER VALVE SECTION (STD)..... | 920 |
| Cab Roof Wiring Harness..... | 652 | CHECK VALVE, STEERING VALVE SECTION (EH) (GRADE PRO) (BREAKDOWN)..... | 976 |
| Cab Side Console (Grade Pro)..... | 758 | CHECK VALVE, WHEEL LEAN VALVE SECTION (EH) (GRADE PRO)..... | 986 |
| Cab Side Console (Standard Console)..... | 756 | CHECK VALVE, WHEEL LEAN VALVE SECTION (STD)..... | 906 |
| Cab Side Work Lights..... | 582 | Circle Drive Gearbox..... | 1074 |
| Cab Stationary Front Console..... | 754 | Circle Drive Gearbox (w/ Slip Clutch)..... | 1076 |
| Cab Steps..... | 804 | Circle Frame..... | 1064 |
| Cab Tilt Console Wiring Harness (Grade Pro)..... | 656 | CIRCLE INSERTS (EXTENDED LIFE)..... | 1070 |
| Cab Tilt Console Wiring Harness (Standard Controls)..... | 654 | CIRCLE INSERTS (STANDARD) (WITHOUT SLIP CLUTCH)..... | 1066 |
| CAB TRAY..... | 814 | CIRCLE INSERTS, (STANDARD) (WITH SLIP CLUTCH)..... | 1068 |
| Cab Trim Panels and Headliner (Full Height Cab) (XXXXXX -)..... | 720 | CIRCLE ROTATE CONTROLS, LEFT 4 FUNCTION (EH) (GRADE PRO)..... | 782 |
| Cab Trim Panels and Headliner (Full Height Cab) (- XXXXXX)..... | 718 | CIRCLE ROTATE CONTROLS, LEFT 5 FUNCTION (EH) (GRADE PRO)..... | 786 |
| Cab Trim Panels and Headliner (Grade Pro) (XXXXXX -)..... | 716 | CIRCLE ROTATE CONTROL LINKAGE..... | 762 |
| Cab Trim Panels and Headliner (Grade Pro) (- XXXXXX)..... | 714 | Circle Rotate Motor..... | 1126 |
| Cab Trim Panels and Headliner (Low Profile) (Standard Controls) (XXXXXX -)..... | 712 | Circle Rotate Motor and Rotary Manifold Hoses (Grade Pro)..... | 1102 |
| Cab Trim Panels and Headliner (Low Profile) (Standard Controls) (- XXXXXX)..... | 710 | Circle Rotate Motor Hoses (Standard Controls)..... | 1100 |
| Cab Wiring Harness (Grade Pro)..... | 636, 638 | Circle Rotate Valve Section (Grade Pro)..... | 982 |
| CAB WORK LIGHTS, LOWER..... | 578 | Circle Rotate Valve Section (Standard Controls)..... | 912 |
| CAB, FULL HEIGHT W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 706 | CIRCLE SIDE SHIFT CONTROLS, RIGHT 4 FUNCTION (EH) (GRADE PRO)..... | 780 |
| CAB, LOW PROFILE W/ DOORS AND OPENING SIDE/FIXED FRONT WINDOWS (COMPLETE)..... | 702 | CIRCLE SIDE SHIFT CONTROLS, RIGHT 5 FUNCTION (EH) (GRADE PRO)..... | 784 |
| CAMERA..... | 868 | CIRCLE SIDE SHIFT CONTROL LINKAGE..... | 762 |
| CAMSHAFT KIT (9901)..... | 264 | Circle Side Shift Cylinder..... | 1122 |
| CAM FOLLOWER (4606)..... | 216 | Circle Side Shift Cylinder Hoses (Grade Pro)..... | 1106 |
| CAN TERMINATOR (ENGINE FRAME HARNESS)..... | 616 | Circle Side Shift Cylinder Hoses (Standard Controls)..... | 1104 |
| CAP, FUEL TANK..... | 468 | Circle Side Shift Valve Section (Grade Pro)..... | 988 |
| CAP, HYDRAULIC RESERVOIR..... | 1014 | Circle Side Shift Valve Section (Standard Controls)..... | 908 |
| CAP, TRANSMISSION DIAGNOSTIC FITTINGS..... | 130 | CIRCUIT BREAKER LABEL (ENGLISH)..... | 530 |
| CARGO NET (FULL HEIGHT CAB)..... | 718, 720 | CIRCUIT BREAKER LABEL (FRENCH)..... | 536 |
| CARGO NET (GRADE PRO)..... | 714, 716 | CIRCUIT BREAKER LABEL (RUSSIAN)..... | 540 |
| CARGO NET (LOW PROFILE CAB - STD)..... | 710, 712 | CIRCUIT BREAKER LABEL (SPANISH)..... | 538 |
| CARRIER, PLANET PINION..... | 62 | CIRCUIT BREAKER, ENGINE AIR HEATER (120A)..... | 390 |
| CARTRIDGE, PRESSURE REDUCING MAIN MANIFOLD VALVE (W/O SEC. STEERING)..... | 950 | CIRCUIT BREAKER, GLOW PLUG (120A)..... | 398 |
| CARTRIDGE, PRESSURE REDUCING MAIN MANIFOLD VALVE (W/ SEC. STEERING)..... | 948 | CLAMP, FRONT FENDERS..... | 848 |
| CASE, DIFFERENTIAL..... | 102 | CLAMP, REAR FENDER..... | 852 |
| CD PLAYER..... | 854 | CLEANER, AIR (6068HDW75)..... | 442 |
| CENTER COVER, STEERING WHEEL..... | 486 | CLEANER, AIR (6090HDW01 / 6090HDW04)..... | 440 |
| CENTER COVER, STEERING WHEEL (GRADE PRO)..... | 488 | CLEANOUT COVER LABEL (ENGLISH)..... | 530 |
| CENTRAL LUBRICATION, FRAME HINGE..... | 550 | CLEANOUT COVER LABEL (FRENCH)..... | 536 |
| CHAIN CASE DEBRIS MAGNET..... | 68 | CLEANOUT COVER LABEL (RUSSIAN)..... | 540 |
| CHAIN, TANDEM DRIVE..... | 68 | CLEANOUT COVER LABEL (SPANISH)..... | 538 |
| CHARGE AIR COOLER HOSES (6068HDW75) (SERIAL NUMBER 626426-)..... | 422 | CLUTCH PEDAL COVER (FULL HEIGHT CAB)..... | 718, 720 |
| CHARGE AIR COOLER HOSES (6068HDW75) (SERIAL NUMBER-626425)..... | 420 | CLUTCH PEDAL COVER (GRADE PRO)..... | 714, 716 |
| CHARGE AIR COOLER HOSES (6090HDW01 / 6090HDW04)(SN 626426-)..... | 414 | CLUTCH PEDAL COVER (LOW PROFILE CAB - STD)..... | 710, 712 |
| CHARGE AIR COOLER HOSES (6090HDW01 / 6090HDW04)(SN-626425)..... | 412 | CLUTCH, SLIP, CIRCLE DRIVE GEARBOX..... | 1076 |
| CHARGE AIR COOLER (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 | COAT HOOK (FULL HEIGHT CAB)..... | 718, 720 |
| CHARGE AIR COOLER (6068HDW75) (SERIAL NUMBER-626425)..... | 416 | COAT HOOK (GRADE PRO)..... | 714, 716 |
| CHARGE AIR COOLER (6090HDW01 / 6090HDW04)..... | 410 | COAT HOOK (LOW PROFILE CAB - STD)..... | 710, 712 |
| CHARGE AIR COOLER (6090HDW01 / 6090HDW04)(SN-626425)..... | 408 | CODE COOLANT HEATER (2694)..... | 309 |
| | | CODE 1102 ROCKER ARM COVER..... | 178 |
| | | CODE 1144 ROCKER ARM COVER..... | 294 |
| | | CODE 1230 OIL FILLER NECK..... | 296 |
| | | CODE 1320 CRANKSHAFT PULLEY..... | 297 |

Índice alfabético, continuación

| Página | Página |
|---|---------------|
| CODE 1346 CRANKSHAFT PULLEY | 180 |
| CODE 1412 FLYWHEEL HOUSING | 181 |
| CODE 1423 FLYWHEEL HOUSING | 298 |
| CODE 1520 FLYWHEEL | 182 |
| CODE 1530 FLYWHEEL | 299 |
| CODE 169Z FUEL INJECTION PUMP | 300 |
| CODE 1701 AIR INTAKE | 186 |
| CODE 1797 INTAKE MANIFOLD | 302 |
| CODE 19BR OIL PAN | 304 |
| CODE 1909 OIL PAN | 188 |
| CODE 2001 WATER PUMP PULLEY | 306 |
| CODE 2107 THERMOSTAT COVER | 191 |
| CODE 2154 THERMOSTAT COVER | 307 |
| CODE 2201 - THERMOSTAT (HDW01) | 192 |
| CODE 2255 THERMOSTAT | 308 |
| CODE 2310 FAN DRIVE | 193 |
| CODE 2697 ENGINE HEATER | 194 |
| CODE 2699 COOLANT HEATER PLUG | 195 |
| CODE 28AY EXHAUST MANIFOLD | 311 |
| CODE 2802 EXHAUST MANIFOLD | 196 |
| CODE 2870 EXHAUST MANIFOLD | 310 |
| CODE 2901 VENTILATING SYSTEM | 198 |
| CODE 2943 VENTILATING SYSTEM | 312 |
| CODE 3005 STARTER, 24V | 200 |
| CODE 3008 STARTER MOTOR | 201 |
| CODE 3059 STARTER MOTOR | 314 |
| CODE 35DZ FUEL FILTER, FINAL | 316 |
| CODE 3508 FUEL FILTER | 204 |
| CODE 3612 FRONT PLATE AND IDLE GEARS | 318 |
| CODE 3713 FUEL TRANSFER PUMP | 320 |
| CODE 3903 THERMOSTAT HOUSING | 206 |
| CODE 3926 THERMOSTAT HOUSING | 322 |
| CODE 4018 ENGINE OIL DIPSTICK | 208 |
| CODE 4048 OIL DIPSTICK | 324 |
| CODE 4330 STARTING AID (4330) | 326 |
| CODE 4397 STARTING AID | 212 |
| CODE 4436, TIMING GEAR COVER, WATER PUMP | 328 |
| CODE 4601 CYLINDER BLOCK | 214 |
| CODE 4606 CYLINDER BLOCK | 216 |
| CODE 4633 CYLINDER BLOCK | 330 |
| CODE 4712 CRANKSHAFT AND BEARINGS | 332 |
| CODE 4801 CONNECTING ROD, PISTON | 220 |
| CODE 4834 CONNECTING RODS AND PISTONS | 334 |
| CODE 4901 ROCKER ARMS (HDW01) | 222 |
| CODE 4905 ROCKER ARM, SHAFT, TAPPET, PUSH RODS | 336 |
| CODE 5001 OIL PUMP | 224 |
| CODE 5024 OIL PUMP | 338 |
| CODE 5101 CYLINDER HEAD | 226 |
| CODE 5128 CYLINDER HEAD | 340 |
| CODE 5299 AUXILIARY DRIVE COVER | 228 |
| CODE 5497 TURBO AIR INLET | 342 |
| Code 5701 Water Pump Inlet | 229 |
| CODE 5722 WATER PUMP INLET | 343 |
| CODE 5912 OIL COOLER | 230 |
| CODE 5951 OIL COOLER | 344 |
| CODE 6401 EXHAUST ELBOW | 345 |
| CODE 6401, EXHAUST ELBOW | 232 |
| CODE 65VS TURBOCHARGER | 346 |
| CODE 6511 TURBOCHARGER | 234 |
| CODE 6698 TEMPERATURE SWITCH PLUG | 348 |
| CODE 6744 ENGINE SENSORS | 350 |
| CODE 7701 TIMING GEAR COVER | 236 |
| CODE 81AL WATER SEPARATOR | 352 |
| CODE 8485 WITHOUT ENGINE WIRING HARNESS | 354 |
| CODE 8497 WIRING HARNESS, ECU | 240 |
| CODE 8724 FAN DRIVE TENSIONER | 356 |
| CODE 8860 OIL FILTER AND HEAD | 358 |
| CODE 8902 EXHAUST GAS RECIRCULATION | 242 |
| CODE 9801 LIFT STRAPS | 245, 360 |
| CODE 9807 LIFT STRAPS | 246 |
| CODE 9901 AIR COMPRESSOR | 269 |
| CODE 9901 AIR COMPRESSOR, MIDLAND AUX DR | 378 |
| CODE 9901 BEARING KIT | 361, 362, 363 |
| CODE 9901 CAMSHAFT KIT | 264 |
| CODE 9901 COMPLETE BLOCK ASSEMBLY | 256 |
| CODE 9901 CONNECTING ROD BEARINGS | 366 |
| CODE 9901 CONNECTING ROD BEARINGS | 250 |
| CODE 9901 CONTROL VALVE | 367 |
| CODE 9901 CYLINDER HEAD BOLT KIT (HDW01) | 262 |
| CODE 9901 CYLINDER HEAD KIT | 266 |
| CODE 9901 CYLINDER HEAD REMOVAL GASKET KIT | 276 |
| CODE 9901 CYLINDER LINER KIT | 372 |
| CODE 9901 CYLINDER LINER PACKING KIT | 263 |
| CODE 9901 EGR SERVICE KIT | 274 |
| CODE 9901 EGR VALVE GASKET KIT | 272, 370 |
| CODE 9901 ENGINE GASKET KIT | 368 |
| CODE 9901 ENGINE GASKET KIT, LONG BLOCK | 284 |
| CODE 9901 ENGINE REBUILD GASKET KIT | 278 |
| CODE 9901 ENGINE SHORT BLOCK | 254 |
| CODE 9901 EXHAUST MANIFOLD REMOVAL KIT | 271 |
| CODE 9901 FILTER O-RING KIT | 379 |
| CODE 9901 FUEL FILTER ELEMENT | 253 |
| CODE 9901 FUEL FILTER ELEMENT KIT | 268 |
| CODE 9901 FUEL INJECTION NOZZLE SERVICE KIT | 374 |
| CODE 9901 MAIN BEARING KIT | 249 |
| CODE 9901 MAIN THRUST BEARING | 365 |
| CODE 9901 PISTON RING KIT | 270, 380 |
| CODE 9901 PISTON-LINER KIT (HDW01) | 260 |
| CODE 9901 PRIMARY FUEL FILTER | 247 |
| CODE 9901 REAR OIL SEAL | 382 |
| CODE 9901 REPLACEMENT ENGINE (HDW75) | 388 |
| CODE 9901 REPLACEMENT ENGINE (TN054) | 286 |
| CODE 9901 SEAL KIT, FUEL INJ CONNECTOR (HDW01) | 261 |
| CODE 9901 SERVICE KIT, WATER PUMP INSERT | 383 |
| CODE 9901 SHORT BLOCK | 258 |
| CODE 9901 SHORT BLOCK ASSEMBLY | 376 |
| CODE 9901 STARTER MOTOR KIT | 282 |
| CODE 9901 STARTER RELAY | 381 |
| CODE 9901 SUCTION CONTROL VALVE | 252 |
| CODE 9901 THRUST BEARING KIT | 251, 364 |
| CODE 9902 ENGINE OVERHAUL KIT | 280, 386 |
| CODE-9901 STARTER RELAY-12V (HT067) | 375 |
| CODE-9901 WATER PUMP KIT | 248 |
| COIL, SOLENOID VALVE, MAIN MANIFOLD VALVE (W/O SEC. STEERING) | 950 |
| COIL, SOLENOID VALVE, MAIN MANIFOLD VALVE (W/ SEC. STEERING) | 948 |
| COIL, SOLENOID, BLADE IMPACT VALVE | 1086 |
| COIL, SOLENOID, HYDRAULIC PUMP DISCONNECT, COLD START (BREAKDOWN) | 1004 |
| COIL, SOLENOID, REVERSING FAN VALVE | 432 |
| Cold Start Disconnect Hoses and Fittings | 1002 |
| Cold Start Disconnect Solenoid Valve | 1004 |
| COLD WEATHER STARTING AID (4330) | 326 |
| COLD WEATHER STARTING AID (4397) | 212 |
| COLD WEATHER START AID, ETHER | 392 |
| COLUMN, STEERING | 486 |
| COLUMN, STEERING (GRADE PRO) | 488 |
| COMMON RAIL SYSTEM, HIGH PRESSURE (169Z) | 300 |
| Communication Controller | 1016 |
| COMPARTMENT LIGHTS, ENGINE | 584 |
| COMPLETE BLOCK ASSEMBLY (9901) | 256 |
| COMPONENTS, HVAC MODULE | 820 |
| COMPRESSOR AIR (9901) | 269 |
| COMPRESSOR, AIR (GRADE PRO SEAT) | 800 |
| COMPRESSOR, AIR (PREMIUM SEAT) | 796 |
| COMPRESSOR, AIR (STANDARD SEAT) | 792 |
| COMPRESSOR, A/C (COMPLETE) (6068HDW75) | 824 |
| COMPRESSOR, A/C (COMPLETE) (6090HDW01 / 6090HDW04) | 822 |
| COMPRESSOR, A/C (COMPONENTS) | 826 |
| CONDENSER HOSES, A/C (6068HDW75) | 824 |
| CONDENSER HOSES, A/C (6090HDW01 / 6090HDW04) | 822 |
| CONDENSER, A/C (6068HDW75) (SERIAL NUMBER 626426-) | 418 |
| CONDENSER, A/C (6068HDW75) (SERIAL NUMBER-626425) | 416 |
| CONDENSER, A/C (6090HDW01 / 6090HDW04) (SN 626426-) | 410 |
| CONDENSER, A/C (6090HDW01 / 6090HDW04) (SN-626425) | 408 |
| CONNECTING RODS AND PISTONS (4834) | 334 |
| CONNECTING ROD BEARING KIT (9901) | 250 |
| CONNECTING ROD BEARING (9901) | 366 |
| CONNECTING ROD, BEARINGS (4801) | 220 |
| CONNECTOR, ACCELERATOR PEDAL | 624 |
| CONNECTOR, ADU | 624 |
| CONNECTOR, AIR FILTER RESTRICTION SWITCH (6068HDW75) | 614 |
| CONNECTOR, AIR FILTER RESTRICTION SWITCH (6090HDW01) | 608 |
| CONNECTOR, AIR HEATER COILS | 616 |
| CONNECTOR, ALTERNATOR EXCITATION (6068HDW75) | 614 |
| CONNECTOR, ALTERNATOR EXCITATION (6090HDW01) | 610 |
| CONNECTOR, ALTERNATOR GROUND AND OUTPUT (6068HDW75) | 614 |
| CONNECTOR, ALTERNATOR GROUND (6090HDW01) | 608 |
| CONNECTOR, ARTICULATION ANGLE SENSOR | 596 |
| CONNECTOR, AUXILIARY GRADE PRO CONTROLS | 642 |
| CONNECTOR, A/C COMPRESSOR CLUTCH SOLENOID (6068HDW75) | 614 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> | | |
|--|---------------|--|------|
| CONNECTOR, BATTERY DISCONNECT | 598 | CONNECTOR, ELECTROHYDRAULIC VALVE CONTROLLERS (GRADE PRO) | 648 |
| CONNECTOR, BEACON LIGHTS | 652 | CONNECTOR, ELECTROHYDRAULIC VALVE, FRONT (GRADE PRO) | 650 |
| CONNECTOR, BLADE IMPACT SOLENOID | 658 | CONNECTOR, ELECTROHYDRAULIC VALVE, REAR (GRADE PRO) | 648 |
| CONNECTOR, BLADE IMPACT SWITCH (GRADE PRO) | 656 | CONNECTOR, ENGINE COMPARTMENT WORK LIGHTS | 584 |
| CONNECTOR, BLADE IMPACT SWITCH (STANDARD CONTROLS) | 654 | CONNECTOR, ENGINE COMPARTMENT WORK LIGHTS SWITCH | 584 |
| CONNECTOR, BLADE IMPACT VALVE HARNESS (FRONT PLATFORM HARNESS) | 596 | CONNECTOR, ENGINE CONTROLLER (BROWN) | 616 |
| CONNECTOR, BLADE ROTATION SENSOR | 650 | CONNECTOR, ENGINE CONTROLLER (ECU) (BLUE AND BLACK) (6068HDW75) | 614 |
| CONNECTOR, BRAKE ACCUMULATOR PRESSURE SWITCH | 596 | CONNECTOR, ENGINE CONTROLLER (ECU) (BLUE AND BLACK) (6090HDW01) | 610 |
| CONNECTOR, BRAKE LIGHT SWITCH | 596 | CONNECTOR, ENGINE FRAME GROUND | 616 |
| CONNECTOR, BRAKE/TAILO LIGHT | 576 | CONNECTOR, ENGINE FRAME HARNESS (CAB INTERIOR HARNESS) | 628 |
| CONNECTOR, BUS FAN MOTOR | 626 | CONNECTOR, ENGINE FRAME HARNESS (ENGINE HARNESS 6068HDW75) | 614 |
| CONNECTOR, CAB DIAGNOSTIC | 626 | CONNECTOR, ENGINE FRAME HARNESS (ENGINE HARNESS 6090HDW01) | 610 |
| CONNECTOR, CAB DISPLAY MONITOR | 624 | CONNECTOR, ENGINE HARNESS (ENGINE FRAME HARNESS) | 616 |
| CONNECTOR, CAB FUSES | 624 | CONNECTOR, ENGINE OIL PRESSURE SENSOR (6068HDW75) | 614 |
| CONNECTOR, CAB GRADE PRO HARNESS (REAR GRADE PRO VALVE HARNESS) | 648 | CONNECTOR, ENGINE OIL PRESSURE SENSOR (6090HDW01) | 608 |
| CONNECTOR, CAB HARNESS (CAB ROOF HARNESS) | 652 | CONNECTOR, ENGINE SPEED CONTROL MODE SWITCH | 628 |
| CONNECTOR, CAB HARNESS (FRONT TILT CONSOLE HARNESS) (GRADE PRO) | 656 | CONNECTOR, ENGINE SPEED CONTROL SET SWITCH | 626 |
| CONNECTOR, CAB HARNESS (FRONT TILT CONSOLE HARNESS) (STANDARD CONTROLS) | 654 | CONNECTOR, ENGINE WORK LIGHT HARNESS (MIDSTRUCTURE HARNESS) | 600 |
| CONNECTOR, CAB HARNESS, GRADE PRO (CAB INTERIOR HARNESS) | 626 | CONNECTOR, ETHERNET | 1018 |
| CONNECTOR, CAB INTERIOR HARNESS (ENGINE FRAME HARNESS) | 616 | CONNECTOR, ETHER START AID SOLENOID (6090HDW01) | 608 |
| CONNECTOR, CAB INTERIOR HARNESS (FRONT PLATFORM HARNESS) | 596 | CONNECTOR, EXHAUST AIR TEMP SENSOR (6090HDW01) | 608 |
| CONNECTOR, CAB INTERIOR HARNESS (RADIO HARNESS) | 634 | CONNECTOR, FAN DIRECTION SOLENOID | 600 |
| CONNECTOR, CAB INTERIOR HARNESS (REAR PLATFORM HARNESS) | 598 | CONNECTOR, FAN DOOR HARNESS (REAR PLATFORM HARNESS) | 598 |
| CONNECTOR, CAB ROOF HARNESS (CAB INTERIOR HARNESS) | 628 | CONNECTOR, FAN DOOR HARNESS (TAIL LIGHT HARNESS) | 576 |
| CONNECTOR, CAB ROOF LIGHTS | 652 | CONNECTOR, FAN MOTOR, BUS | 626 |
| CONNECTOR, CAB WORK LIGHTS, LOWER | 596 | CONNECTOR, FAN PRESSURE SENSOR | 600 |
| CONNECTOR, CAMSHAFT SPEED SENSOR (6068HDW75) | 614 | CONNECTOR, FAN SPEED SOLENOID | 600 |
| CONNECTOR, CAMSHAFT SPEED SENSOR (6090HDW01) | 608 | CONNECTOR, FLEX LOAD CONTROLLER | 626 |
| CONNECTOR, CAN BUS (LEFT GRADE PRO ARMREST HARNESS) | 644 | CONNECTOR, FLEX LOAD CONTROLLER POWER | 632 |
| CONNECTOR, CAN BUS (RIGHT GRADE PRO ARMREST HARNESS) | 642 | CONNECTOR, FLOAT SWITCH | 644 |
| CONNECTOR, CAN TERMINATOR (CAB INTERIOR HARNESS) | 626 | CONNECTOR, FORWARD/REVERSE MODULE | 624 |
| CONNECTOR, CAN TERMINATOR (ENGINE FRAME HARNESS) | 616 | CONNECTOR, FRESH AIR TEMP SENSOR (6090HDW01) | 608 |
| CONNECTOR, CAN TERMINATOR (GRADE PRO IGC HARNESS) | 640 | CONNECTOR, FRONT AND REAR CAB WORK LIGHTS | 580 |
| CONNECTOR, CAN TO JDLINK™ SYSTEM (MIG HARNESS) | 1018 | CONNECTOR, FRONT DRIVE LIGHTS | 596 |
| CONNECTOR, CIRCUIT BREAKER, CAB POWER | 616 | CONNECTOR, FRONT DRIVING LIGHTS | 574 |
| CONNECTOR, CIRCUIT BREAKER, CAB POWER | 598 | CONNECTOR, FRONT GRADE PRO VALVE | 650 |
| CONNECTOR, COMPRESSOR CLUTCH SOLENOID (6068HDW75) | 614 | CONNECTOR, FRONT GRADE PRO VALVE HARNESS (REAR GRADE PRO VALVE HARNESS) | 648 |
| CONNECTOR, COMPRESSOR CLUTCH SOLENOID (6090HDW01) | 608 | CONNECTOR, FRONT LOWER WIPER | 596 |
| CONNECTOR, COMPRESSOR INLET TEMP SENSOR (6068HDW75) | 614 | CONNECTOR, FRONT PLATFORM HARNESS (CAB INTERIOR HARNESS) | 628 |
| CONNECTOR, COMPRESSOR INLET TEMP SENSOR (6090HDW01) | 608 | CONNECTOR, FRONT PLATFORM HARNESS (FRONT LIGHT HARNESS) | 604 |
| CONNECTOR, CONTROLLERS, GRADE PRO VALVE | 648 | CONNECTOR, FRONT PLATFORM HARNESS (WHEEL LEAN SENSOR HARNESS) | 602 |
| CONNECTOR, CONVERTER, 12V/15A | 628 | CONNECTOR, FRONT PLATFORM (BLADE IMPACT HARNESS) | 658 |
| CONNECTOR, COOLANT TEMPERATURE SENSOR (6068HDW75) | 614 | CONNECTOR, FRONT SIGNAL LIGHTS | 574 |
| CONNECTOR, COOLANT TEMPERATURE SENSOR (6090HDW01) | 608 | CONNECTOR, FRONT TILT CONSOLE (CAB INTERIOR HARNESS) | 626 |
| CONNECTOR, CRANKSHAFT SPEED SENSOR (6068HDW75) | 614 | CONNECTOR, FRONT WIPER MOTOR | 634 |
| CONNECTOR, CRANKSHAFT SPEED SENSOR (6090HDW01) | 608 | CONNECTOR, FUEL INJECTORS (6068HDW75) | 614 |
| CONNECTOR, CYLINDER SHAFT SPEED SENSOR | 598 | CONNECTOR, FUEL INJECTORS (6090HDW01) | 608 |
| CONNECTOR, DECELERATOR PEDAL | 624 | CONNECTOR, FUEL LEVEL SENSOR | 598 |
| CONNECTOR, DIAGNOSTIC, CAB | 626 | CONNECTOR, FUEL PRESSURE SENSOR (6068HDW75) | 614 |
| CONNECTOR, DIFFERENTIAL FILTER RESTRICTION SWITCH | 600 | CONNECTOR, FUEL PRESSURE SENSOR (6090HDW01) | 608 |
| CONNECTOR, DIFFERENTIAL LOCK SOLENOID | 598 | CONNECTOR, FUEL RAIL PRESSURE SENSOR (6068HDW75) | 614 |
| CONNECTOR, DIFFERENTIAL LOCK SWITCH | 642, 654 | CONNECTOR, FUEL RAIL PRESSURE SENSOR (6090HDW01) | 608 |
| CONNECTOR, DIODE, SOFT START | 600 | CONNECTOR, FUEL TEMPERATURE SENSOR (6068HDW75) | 614 |
| CONNECTOR, DOME LIGHT | 634 | CONNECTOR, FUEL TEMPERATURE SENSOR (6090HDW01) | 608 |
| CONNECTOR, DRAFT FRAME PITCH/ROLL INCLINOMETER | 650 | CONNECTOR, FUEL TRANSFER PUMP (6090HDW01) | 610 |
| CONNECTOR, DRIVE LIGHTS | 652 | CONNECTOR, FUSES, CAB | 624 |
| CONNECTOR, DRIVING LIGHTS | 604 | CONNECTOR, GEAR POSITION MODULE | 624 |
| CONNECTOR, ECU FUSE | 616 | CONNECTOR, GLOW PLUGS AND GLOW PLUG RELAY (6068HDW75) | 614 |
| CONNECTOR, EGR MANIFOLD AIR TEMP SENSOR (6068HDW75) | 614 | CONNECTOR, GLOW PLUG COILS | 616 |
| CONNECTOR, EGR MANIFOLD AIR TEMP SENSOR (6090HDW01) | 608 | CONNECTOR, GRADE PRO CAB HARNESS (CAB INTERIOR HARNESS) | 626 |
| CONNECTOR, EGR VALVE (6090HDW01) | 610 | CONNECTOR, GRADE PRO CAB HARNESS (GRADE PRO IGC HARNESS) | 640 |

Índice alfabético, continuación

| Página | Página | | |
|---|----------|--|----------|
| CONNECTOR, GRADE PRO CAB HARNESS (LEFT GRADE PRO ARMREST HARNESS)..... | 644 | CONNECTOR, REAR PLATFORM HARNESS (MIDSTRUCTURE HARNESS)..... | 600 |
| CONNECTOR, GRADE PRO CAB HARNESS (RIGHT GRADE PRO ARMREST HARNESS)..... | 642 | CONNECTOR, REAR WIPER MOTOR..... | 628 |
| CONNECTOR, GRADE PRO JOYSTICKS, LEFT..... | 644 | CONNECTOR, REAR WORK LIGHTS..... | 576 |
| CONNECTOR, GRADE PRO JOYSTICKS, RIGHT..... | 642 | CONNECTOR, RETURN TO STRAIGHT SWITCH..... | 648 |
| CONNECTOR, GRADE PRO VALVE CONTROLLERS..... | 648 | CONNECTOR, REVERSE WARNING ALARM..... | 576 |
| CONNECTOR, GRADE PRO VALVE, FRONT..... | 650 | CONNECTOR, RIGHT BLADE IMPACT SOLENOID..... | 658 |
| CONNECTOR, GRADE PRO VALVE, REAR..... | 648 | CONNECTOR, RIGHT JOYSTICKS (GRADE PRO)..... | 642 |
| CONNECTOR, GROUND, FRONT PLATFORM WIRING HARNESS..... | 596 | CONNECTOR, ROTARY MANIFOLD SENSOR..... | 650 |
| CONNECTOR, GROUND, REAR PLATFORM HARNESS..... | 598 | CONNECTOR, RS232..... | 1016 |
| CONNECTOR, GTT DIAGNOSTIC (RS232)..... | 1016 | CONNECTOR, SADDLE LOCK PIN SOLENOID..... | 596 |
| CONNECTOR, HEATED MIRRORS..... | 652 | CONNECTOR, SADDLE LOCK PIN SWITCH..... | 596 |
| CONNECTOR, HEATED SEAT..... | 626 | CONNECTOR, SEALED SWITCH MODULE..... | 628 |
| CONNECTOR, HEATED SEAT SWITCH..... | 628 | CONNECTOR, SEAT AIR COMPRESSOR..... | 624 |
| CONNECTOR, HFWD FRONT HARNESS (REAR PLATFORM HARNESS)..... | 598 | CONNECTOR, SEAT HEATER..... | 626 |
| CONNECTOR, HI/LOW BEAM SWITCH (GRADE PRO)..... | 656 | CONNECTOR, SENSOR, ROTARY MANIFOLD..... | 650 |
| CONNECTOR, HI/LOW BEAM SWITCH (STANDARD CONTROLS)..... | 654 | CONNECTOR, SIDE CAB WORK LIGHTS..... | 582 |
| CONNECTOR, HORN..... | 596, 654 | CONNECTOR, SLEEVE FRONT GRADE PRO VALVE..... | 650 |
| CONNECTOR, HORN SWITCH (GRADE PRO)..... | 644 | CONNECTOR, SNOW LIGHT..... | 586 |
| CONNECTOR, HVAC HARNESS (CAB INTERIOR HARNESS)..... | 624 | CONNECTOR, SOFT START SOLENOID AND DIODE..... | 600 |
| CONNECTOR, HVAC POWERED PRECLEANER..... | 652 | CONNECTOR, SOLENOID, BLADE IMPACT..... | 658 |
| CONNECTOR, HYDRAULIC FILTER RESTRICTION SWITCH..... | 600 | CONNECTOR, SOLENOID, TRANSMISSION..... | 620 |
| CONNECTOR, HYDRAULIC OIL TEMPERATURE SENSOR..... | 600 | CONNECTOR, SPEAKER..... | 634 |
| CONNECTOR, HYDRAULIC PUMP PRESSURE SENSOR JUMPER..... | 596 | CONNECTOR, SSM..... | 628 |
| CONNECTOR, IGC HARNESS (CAB INTERIOR HARNESS)..... | 626 | CONNECTOR, STARTER GROUND (6068HDW75)..... | 614 |
| CONNECTOR, INCHING PEDAL..... | 624 | CONNECTOR, STARTER GROUND (6090HDW01)..... | 608 |
| CONNECTOR, INCLINOMETER, DRAFT FRAME PITCH/ROLL..... | 650 | CONNECTOR, STARTER RELAY..... | 616 |
| CONNECTOR, INCLINOMETER, MAINFALL ANGLE..... | 648 | CONNECTOR, STARTER SOLENOID..... | 616 |
| CONNECTOR, INPUT SHAFT SPEED SENSOR..... | 620 | CONNECTOR, STROBE WARNING BEACON..... | 592 |
| CONNECTOR, JOYSTICKS, LEFT (GRADE PRO)..... | 644 | CONNECTOR, SWITCH, ENGINE SPEED CONTROL MODE..... | 628 |
| CONNECTOR, JOYSTICKS, RIGHT (GRADE PRO)..... | 642 | CONNECTOR, SWITCH, ENGINE SPEED CONTROL SET..... | 626 |
| CONNECTOR, LEFT BLADE IMPACT SOLENOID..... | 658 | CONNECTOR, SWITCH, HEATED SEAT..... | 628 |
| CONNECTOR, LEFT JOYSTICKS (GRADE PRO)..... | 644 | CONNECTOR, SWITCH, RETURN TO STRAIGHT..... | 648 |
| CONNECTOR, LICENSE PLATE HARNESS (TAIL LIGHT HARNESS)..... | 576 | CONNECTOR, TAIL LIGHT HARNESS (FAN DOOR HARNESS)..... | 576 |
| CONNECTOR, LICENSE PLATE LIGHT..... | 528 | CONNECTOR, TAIL LIGHT HARNESS (LICENSE PLATE LIGHT)..... | 528 |
| CONNECTOR, LIGHTS, FRONT DRIVE..... | 596 | CONNECTOR, TO GTT HARNESS (MIG HARNESS)..... | 1018 |
| CONNECTOR, LIGHTS, FRONT DRIVING..... | 604 | CONNECTOR, TRANSMISSION RUN/CAL..... | 626 |
| CONNECTOR, LIGHT, DOME..... | 634 | CONNECTOR, TRANSMISSION AND SOLENOIDS..... | 620 |
| CONNECTOR, LOWER WIPER DISABLE SWITCH..... | 596 | CONNECTOR, TRANSMISSION CAL MODE..... | 628 |
| CONNECTOR, MACHINE INFORMATION GATEWAY (MIG)..... | 1018 | CONNECTOR, TRANSMISSION CONTROLLER..... | 624 |
| CONNECTOR, MAINFALL ANGLE INCLINOMETER..... | 648 | CONNECTOR, TRANSMISSION FILTER RESTRICTION SWITCH..... | 600 |
| CONNECTOR, MAIN HARNESS (ENGINE WORK LIGHT HARNESS)..... | 584 | CONNECTOR, TRANSMISSION HARNESS (REAR PLATFORM HARNESS)..... | 598 |
| CONNECTOR, MAIN HARNESS (FAN DOOR HARNESS)..... | 576 | CONNECTOR, TRANSMISSION OIL SENSOR..... | 620 |
| CONNECTOR, MANIFOLD AIR PRESSURE SENSOR (6090HDW01)..... | 608 | CONNECTOR, TRANSMISSION RUN MODE..... | 628 |
| CONNECTOR, MIDFRAME WORK LIGHTS..... | 596 | CONNECTOR, TURBO INLET TEMP SENSOR (6068HDW75)..... | 614 |
| CONNECTOR, MIDSTRUCTURE HARNESS (REAR PLATFORM HARNESS)..... | 598 | CONNECTOR, TURBO INLET TEMP SENSOR (6090HDW01)..... | 608 |
| CONNECTOR, MIG HARNESS (CAB INTERIOR HARNESS)..... | 628 | CONNECTOR, TURN SIGNAL..... | 604 |
| CONNECTOR, MIG HARNESS (GTT HARNESS)..... | 1016 | CONNECTOR, TURN SIGNAL LIGHT..... | 576 |
| CONNECTOR, MIG POWER..... | 1018 | CONNECTOR, TURN SIGNAL SWITCH (GRADE PRO)..... | 656 |
| CONNECTOR, MONITOR, CAB DISPLAY..... | 624 | CONNECTOR, TURN SIGNAL SWITCH (STANDARD CONTROLS)..... | 654 |
| CONNECTOR, MOTOR, REAR WIPER..... | 628 | CONNECTOR, VTG SPEED SENSOR AND ACTUATOR (6090HDW01)..... | 610 |
| CONNECTOR, OUTPUT SHAFT SPEED SENSOR..... | 620 | CONNECTOR, WARNING BUZZER (GRADE PRO)..... | 656 |
| CONNECTOR, PARK BRAKE PRESSURE SWITCH..... | 620 | CONNECTOR, WARNING BUZZER (STANDARD CONTROLS)..... | 654 |
| CONNECTOR, PARK BRAKE SOLENOID..... | 620 | CONNECTOR, WATER IN FUEL SENSOR (6068HDW75)..... | 614 |
| CONNECTOR, PARK/NEUTRAL MODULE..... | 624 | CONNECTOR, WATER IN FUEL SENSOR (6090HDW01)..... | 608 |
| CONNECTOR, POWER PORT..... | 626 | CONNECTOR, WATER IN FUEL SEPARATOR (6068HDW75)..... | 462 |
| CONNECTOR, POWER TO GTT HARNESS (MIG HARNESS)..... | 1018 | CONNECTOR, WATER IN FUEL SEPARATOR (6090HDW01 / 6090HDW04)..... | 460 |
| CONNECTOR, POWER, FLEX LOAD CONTROLLER..... | 632 | CONNECTOR, WHEEL ANGLE SENSOR..... | 602 |
| CONNECTOR, POWER, GTT..... | 1016 | CONNECTOR, WHEEL LEAN SENSOR HARNESS..... | 596 |
| CONNECTOR, POWER, 12V SWITCHED..... | 624 | CONNECTOR, WINDSHIELD WASHER PUMP..... | 626 |
| CONNECTOR, POWER, 24 VOLT (SWITCHED AND UNSWITCHED)..... | 626 | CONNECTOR, WIPER DISABLE SENSOR..... | 752 |
| CONNECTOR, PUMP, WINDSHIELD WASHER FLUID..... | 626 | CONNECTOR, WIPER MOTOR, FRONT..... | 634 |
| CONNECTOR, RADIO..... | 634 | CONNECTOR, WIPER, FRONT LOWER..... | 596 |
| CONNECTOR, RADIO HARNESS (CAB INTERIOR HARNESS)..... | 626 | CONNECTOR, WORK LIGHTS, CAB..... | 652 |
| CONNECTOR, REAR CAMERA HARNESS (REAR PLATFORM HARNESS)..... | 598 | CONNECTOR, WORK LIGHTS, CAB, LOWER..... | 596 |
| CONNECTOR, REAR DEFROST..... | 626 | CONNECTOR, WORK LIGHTS, MIDFRAME..... | 596 |
| CONNECTOR, REAR GRADE PRO VALVE..... | 648 | CONNECTOR, WORK LIGHT, ENGINE COMPARTMENT..... | 584 |
| CONNECTOR, REAR GRADE PRO VALVE HARNESS (FRONT GRADE PRO VALVE HARNESS)..... | 650 | CONNECTOR, 12V SWITCHED POWER..... | 624 |
| CONNECTOR, REAR PLATFORM HARNESS (CAB INTERIOR HARNESS)..... | 628 | CONNECTOR, 24 VOLT POWER (SWITCHED AND UNSWITCHED)..... | 626 |
| | | CONSOLE COVER, FRONT (FULL HEIGHT CAB)..... | 718, 720 |
| | | CONSOLE COVER, FRONT (GRADE PRO)..... | 714, 716 |
| | | CONSOLE COVER, FRONT (LOW PROFILE CAB - STD)..... | 710, 712 |
| | | CONSOLE WIRING HARNESS, FRONT TILT (GRADE PRO)..... | 656 |
| | | CONSOLE WIRING HARNESS, FRONT TILT (STANDARD CONTROLS)..... | 654 |
| | | CONSOLE, CAB FRONT (STATIONARY)..... | 754 |
| | | CONSOLE, CAB FRONT (TILT) (GRADE PRO)..... | 778 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> | | |
|---|---------------|--|---------------|
| CONSOLE, CAB FRONT (TILT) (STD CONTROLS)..... | 760 | COOLANT HEATER (120V) (6068HDW75)..... | 396 |
| CONSOLE, CAB SIDE (GRADE PRO)..... | 758 | COOLANT HEATER (120V) (6090HDW01 / 6090HDW04)..... | 394 |
| CONSOLE, CAB SIDE (STD CONTROLS)..... | 756 | COOLANT HEATER, DIESEL FIRED (6090HDW01 / 6090HDW04)..... | 400 |
| CONTROLLER MOUNTING BRACKET, FLEX LOAD (GRADE PRO)..... | 758 | COOLANT OVERFLOW TANK (6068HDW75) (SERIAL NUMBER 626426-)..... | 422 |
| CONTROLLER MOUNTING BRACKET, FLEX LOAD (STD CONTROLS)..... | 756 | COOLANT OVERFLOW TANK (6068HDW75) (SERIAL NUMBER-626425)..... | 420 |
| CONTROLLER, COMMUNICATION (GLOBALTRACS™ TERMINAL (GTT))..... | 1016 | COOLANT OVERFLOW TANK (6090HDW01 / 6090HDW04)(SN 626426-)..... | 414 |
| CONTROLLER, ELECTROHYDRAULIC VALVE (GRADE PRO)..... | 668 | COOLANT OVERFLOW TANK (6090HDW01 / 6090HDW04)(SN-626425)..... | 412 |
| CONTROLLER, ENGINE (6090HDW01)..... | 472 | COOLER HOSES, DIFFERENTIAL..... | 402 |
| CONTROLLER, ENGINE (8497)..... | 240 | COOLER HOSES, HYDRAULIC OIL..... | 404 |
| CONTROLLER, FLEX LOAD (WITHOUT AUTOSHIFT)..... | 664 | COOLER HOSES, TRANSMISSION..... | 406 |
| CONTROLLER, FLEX LOAD (WITH AUTOSHIFT)..... | 666 | COOLER, AIR (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| CONTROLLER, MIG..... | 1018 | COOLER, AIR (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| CONTROLLER, TRANSMISSION..... | 116 | COOLER, AIR (6090HDW01 / 6090HDW04) (SN 626426-)..... | 410 |
| CONTROLS, EH AUXILIARY (GRADE PRO)..... | 788 | COOLER, AIR (6090HDW01 / 6090HDW04) (SN-626425)..... | 408 |
| CONTROLS, LEFT FIVE FUNCTION (EH) (GRADE PRO)..... | 786 | COOLER, DIFFERENTIAL OIL (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| CONTROLS, LEFT FOUR FUNCTION (EH) (GRADE PRO)..... | 782 | COOLER, DIFFERENTIAL OIL (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| CONTROLS, RIGHT FIVE FUNCTION (EH) (GRADE PRO)..... | 784 | COOLER, DIFFERENTIAL OIL (6090HDW01 / 6090HDW04)(SN 626426-)..... | 410 |
| CONTROLS, RIGHT FOUR FUNCTION (EH) (GRADE PRO)..... | 780 | COOLER, DIFFERENTIAL OIL (6090HDW01 / 6090HDW04)(SN-626425)..... | 408 |
| CONTROL KIT, ONE HAND BLADE LIFT..... | 776 | COOLER, ENGINE OIL (5951)..... | 344 |
| CONTROL LINKAGES, STANDARD..... | 762 | COOLER, FUEL (6090HDW01 / 6090HDW04) (SN 626426-)..... | 410 |
| CONTROL LINKAGE, AUX W/O FLOAT (SEVENTH FUNCTION LH)..... | 774 | COOLER, FUEL (6090HDW01 / 6090HDW04) (SN-626425)..... | 408 |
| CONTROL LINKAGE, AUX W/O FLOAT (SEVENTH FUNCTION RH)..... | 772 | COOLER, OIL (5912)..... | 230 |
| CONTROL LINKAGE, AUX W/ FLOAT (SIXTH FUNCTION LH)..... | 770 | COOLER, TRANSMISSION OIL (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| CONTROL LINKAGE, AUX W/ FLOAT (SIXTH FUNCTION RH)..... | 768 | COOLER, TRANSMISSION OIL (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| CONTROL LINKAGE, RIPPER (FIFTH FUNCTION LH)..... | 766 | COOLER, TRANSMISSION OIL (6090HDW01 / 6090HDW04)(SN 626426-)..... | 410 |
| CONTROL LINKAGE, SCARIFIER (FIFTH FUNCTION RH)..... | 764 | COOLER, TRANSMISSION OIL (6090HDW01 / 6090HDW04)(SN-626425)..... | 408 |
| CONTROL UNIT, ENGINE (6068HDW75)..... | 474 | Cooling System Hoses and Fittings (6068HDW75) (- 626425)..... | 420 |
| CONTROL UNIT, ENGINE (6090HDW01)..... | 472 | Cooling System Hoses and Fittings (6068HDW75) (626426 -)..... | 422 |
| CONTROL UNIT, FLEX LOAD (WITHOUT AUTOSHIFT)..... | 664 | Cooling System Hoses and Fittings (6090HDW01 / 6090HDW04) (- 626425)..... | 412 |
| CONTROL UNIT, FLEX LOAD (WITH AUTOSHIFT)..... | 666 | Cooling System Hoses and Fittings (6090HDW01 / 6090HDW04) (626426 -)..... | 414 |
| CONTROL VALVE..... | 486 | Cooling System (6068HDW75) (- 626425)..... | 416 |
| Control Valve Covers (Standard Controls)..... | 838 | Cooling System (6068HDW75) (626426 -)..... | 418 |
| Control Valve Cover (Front) (Grade Pro)..... | 842 | Cooling System (6090HDW01 / 6090HDW04) (- 626425)..... | 408 |
| Control Valve Cover (Rear) (Grade Pro)..... | 840 | Cooling System (6090HDW01 / 6090HDW04) (626426 -)..... | 410 |
| CONTROL VALVE COVER, REAR (GRADE PRO)..... | 840 | Cooling System (6090HDW01 / 6090HDW04) (626426 -)..... | 410 |
| CONTROL VALVE KIT, AUX W/O FLOAT (SEVENTH FUNCTION LEFT)..... | 944 | CORE, RADIATOR (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| CONTROL VALVE KIT, AUX W/O FLOAT (SEVENTH FUNCTION RIGHT)..... | 942 | CORE, RADIATOR (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| CONTROL VALVE KIT, AUX W/ FLOAT (SIXTH FUNCTION LH)..... | 940 | CORE, RADIATOR (6090HDW01 / 6090HDW04) (SN 626426-)..... | 410 |
| CONTROL VALVE KIT, AUX W/ FLOAT (SIXTH FUNCTION RH)..... | 938 | CORE, RADIATOR (6090HDW01 / 6090HDW04) (SN-626425)..... | 408 |
| CONTROL VALVE KIT, ELECTROHYDRAULIC AUXILIARY (GRADE PRO)..... | 996 | COUNTERWEIGHT (FIELD KIT), REAR..... | 696 |
| CONTROL VALVE KIT, ONE HAND BLADE LIFT..... | 946 | COUPLING, DIFF LOCK PUMP TO TRANS..... | 84 |
| CONTROL VALVE KIT, RIPPER (FIFTH FUNCTION LH)..... | 936 | COVERS, BATTERY..... | 832 |
| CONTROL VALVE KIT, SCARIFIER (FIFTH FUNCTION RH)..... | 934 | COVERS, CONTROL VALVE (STANDARD)..... | 838 |
| CONTROL VALVE MOUNTING BRACKETS..... | 880 | COVERS, FRONT CONTROL VALVE (GRADE PRO)..... | 842 |
| CONTROL VALVE (GRADE PRO)..... | 488 | COVERS, FRONT FRAME..... | 834 |
| CONTROL VALVE (9901)..... | 367 | COVERS, REAR CONTROL VALVE (GRADE PRO)..... | 840 |
| CONTROL VALVE, EH FRONT (5 FUNCTION) (GRADE PRO)..... | 960 | COVERS, TANDEM HOUSING..... | 60 |
| CONTROL VALVE, EH FRONT (6 FUNCTION MMS) (GRADE PRO)..... | 966 | COVER, AIR CONDITIONER AND HEATER..... | 814 |
| CONTROL VALVE, EH FRONT (6 FUNCTION) (GRADE PRO)..... | 964 | COVER, AUXILIARY DRIVE (5299)..... | 228 |
| CONTROL VALVE, EH FRONT (8 FUNCTION) (GRADE PRO)..... | 972 | COVER, BATTERY TERMINAL (1000 CCA) (6068HDW75)..... | 558 |
| CONTROL VALVE, EH REAR (4 FUNCTION) (GRADE PRO)..... | 958 | COVER, BATTERY TERMINAL (1000 CCA) (6090HDW01 / 6090HDW04)..... | 554 |
| CONTROL VALVE, EH REAR (5 FUNCTION) (GRADE PRO)..... | 962 | COVER, BATTERY TERMINAL (1400 CCA) (6068HDW75)..... | 560 |
| CONTROL VALVE, EH REAR (6 FUNCTION) (GRADE PRO)..... | 968 | COVER, BATTERY TERMINAL (1400 CCA) (6090HDW01 / 6090HDW04)..... | 556 |
| CONTROL VALVE, EH REAR (7 FUNCTION) (GRADE PRO)..... | 970 | COVER, CAB REAR..... | 726 |
| CONTROL VALVE, HEATER..... | 820 | COVER, CAB REAR WIRING HARNESS CONNECTOR..... | 594 |
| CONTROL VALVE, LEFT (4 FUNCTION)..... | 884 | COVER, CIRCLE DRIVE GEARBOX..... | 1074 |
| CONTROL VALVE, LEFT (5 FUNCTION)..... | 890 | COVER, CIRCLE DRIVE GEARBOX WITH SLIP CLUTCH..... | 1076 |
| CONTROL VALVE, LEFT (6 FUNCTION)..... | 894 | COVER, CLUTCH PEDAL (FULL HEIGHT CAB)..... | 718, 720 |
| CONTROL VALVE, LEFT (7 FUNCTION)..... | 898 | COVER, CLUTCH PEDAL (GRADE PRO)..... | 714, 716 |
| CONTROL VALVE, RIGHT (4 FUNCTION)..... | 882 | COVER, CLUTCH PEDAL (LOW PROFILE CAB - STD)..... | 710, 712 |
| CONTROL VALVE, RIGHT (5 FUNCTION)..... | 886 | COVER, FRONT CONSOLE (FULL HEIGHT CAB)..... | 718, 720 |
| CONTROL VALVE, RIGHT (5 FUNCTION) (MID MOUNTED SCARIFIER)..... | 888 | COVER, FRONT CONSOLE (GRADE PRO)..... | 714, 716, 778 |
| CONTROL VALVE, RIGHT (6 FUNCTION)..... | 892 | COVER, FRONT CONSOLE (LOW PROFILE CAB - STD)..... | 710, 712 |
| CONTROL VALVE, RIGHT (7 FUNCTION)..... | 896 | COVER, FRONT WIPER (FULL HEIGHT CAB)..... | 718, 720 |
| CONTROL VALVE, SUCTION (9901)..... | 252 | COVER, FRONT WIPER (GRADE PRO)..... | 714, 716 |
| CONTROL, MAIN HYDRAULIC PUMP..... | 878 | COVER, FRONT WIPER (LOW PROFILE CAB - STD)..... | 710, 712 |
| CONVERTER, 15 AMP POWER..... | 570 | COVER, HEATER AND AIR CONDITIONER..... | 814 |
| CONVERTER, 25 AMP POWER..... | 572 | | |
| COOLANT DIAGNOSTIC FITTING, ENGINE (6068HDW75)..... | 548 | | |
| COOLANT DIAGNOSTIC FITTING, ENGINE (6090HDW01 / 6090HDW04)..... | 546 | | |
| COOLANT HEATER ENGINE..... | 309 | | |
| COOLANT HEATER PLUG (2699)..... | 195 | | |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> |
|---|---------------|
| COVER, HYDRAULIC RESERVOIR CLEAN OUT | 1014 |
| COVER, INCHING PEDAL | 476, 478 |
| COVER, INTEGRATED GRADE CONTROL (IGC) (FULL HEIGHT CAB) | 718, 720 |
| COVER, INTEGRATED GRADE CONTROL (IGC) (GRADE PRO) .. | 714, 716 |
| COVER, INTEGRATED GRADE CONTROL (IGC) (LOW PROFILE CAB - STD) | 710, 712 |
| COVER, LOWER FRONT WINDSHIELD WIPER | 750 |
| COVER, MAIN FRAME SIDE | 836 |
| COVER, REAR WIPER (FULL HEIGHT CAB) | 718, 720 |
| COVER, REAR WIPER (GRADE PRO) | 714, 716 |
| COVER, REAR WIPER (LOW PROFILE CAB - STD) | 710, 712 |
| COVER, ROCKER ARM | 178 |
| COVER, ROCKER ARM (1144) | 294 |
| COVER, STEERING WHEEL CENTER (GRADE PRO) | 488 |
| COVER, STROBE WARNING BEACON | 592 |
| COVER, THERMOSTAT (2154) | 307 |
| COVER, THERMOSTAT 2107 | 191 |
| COVER, TIMING GEAR AND WATER PUMP (4436) | 328 |
| COVER, TIMING GEAR (7701) | 236 |
| COVER, TRANSMISSION DIAGNOSTIC FITTINGS | 130 |
| COVER, VALVE (1102) | 178 |
| COVER, W/O RADIO (FULL HEIGHT CAB) | 718, 720 |
| COVER, W/O RADIO (GRADE PRO) | 714, 716 |
| COVER, W/O RADIO (LOW PROFILE CAB - STD) | 710, 712 |
| Crankshaft | 218 |
| CRANKSHAFT AND BEARINGS (4712) | 332 |
| CRANKSHAFT DAMPER (1346) | 180 |
| CRANKSHAFT POSITION SENSOR (4601) | 214 |
| CRANKSHAFT PULLEY (1320) | 297 |
| CRANKSHAFT PULLEY (1346) | 180 |
| Crankshaft Thrust Bearing | 218 |
| Crankshaft / Bearings | 218 |
| CROSS OVER TUBE, OIL (5912) | 230 |
| CUSHION, SEAT (DELUXE) | 794 |
| CUSHION, SEAT (GRADE PRO) | 798 |
| CUSHION, SEAT (STD) | 790 |
| CUTTING EDGE, FRONT MOUNTED DOZER BLADE | 1144 |
| Cutting Edge, 5/8 in. X 6 in. (Use With 12 ft. X 24 in. X 7/8 in. Moldboard) | 1020 |
| Cutting Edge, 5/8 in. X 6 in. (Use With 14 ft. X 24 in. X 7/8 in. Moldboard) | 1028 |
| Cutting Edge, 5/8 in. X 8 in. (Use With 12 ft. X 24 in. X 7/8 in. Moldboard) | 1022 |
| Cutting Edge, 5/8 in. X 8 in. (Use With 12 ft. X 27 in. X 1 in. Moldboard) | 1024 |
| Cutting Edge, 5/8 in. X 8 in. (Use With 13 ft. X 27 in. X 1 in. Moldboard) | 1026 |
| Cutting Edge, 5/8 in. X 8 in. (Use With 14 ft. X 24 in. X 7/8 in. Moldboard) | 1030 |
| Cutting Edge, 5/8 in. X 8 in. (Use With 14 ft. X 27 in. X 1 in. Moldboard) | 1032 |
| Cutting Edge, 5/8 in. X 8 in. (Use With 14 ft. X 27 in. X 1 in. Moldboard) (3/4 in. Hardware) | 1034 |
| CYLINDER BLOCK WITH CAMSHAFT (4633) | 330 |
| CYLINDER BLOCK WITH LINERS (4633) | 330 |
| CYLINDER BLOCK (4606) | 216 |
| CYLINDER HEAD GASKET (5101) | 226 |
| CYLINDER HEAD KIT (9901) | 266 |
| CYLINDER HEAD REMOVAL KIT (9901) | 276 |
| CYLINDER HEAD (5101) | 226 |
| CYLINDER HEAD (5128) | 340 |
| CYLINDER HOSES, ARTICULATION (STANDARD CONTROLS) .. | 496 |
| CYLINDER HOSES, BLADE LIFT (GRADE PRO) | 1094 |
| CYLINDER HOSES, BLADE LIFT (STANDARD CONTROLS) .. | 1092 |
| CYLINDER HOSES, BLADE SIDE SHIFT (GRADE PRO) | 1098 |
| CYLINDER HOSES, BLADE SIDE SHIFT (STANDARD CONTROLS) | 1096 |
| CYLINDER HOSES, BLADE TILT (GRADE PRO) | 1098 |
| CYLINDER HOSES, BLADE TILT (STANDARD CONTROLS) .. | 1096 |
| CYLINDER HOSES, CIRCLE SIDE SHIFT (GRADE PRO) | 1106 |
| CYLINDER HOSES, CIRCLE SIDE SHIFT (STANDARD CONTROLS) | 1104 |
| CYLINDER HOSE, WHEEL LEAN (GRADE PRO) | 506 |
| CYLINDER HOSE, WHEEL LEAN (STANDARD CONTROLS) .. | 504 |
| CYLINDER LINER AND PISTON KIT (9901) | 260 |
| CYLINDER LINER KIT | 372 |
| CYLINDER LINER PACKING KIT (9901) | 263 |
| CYLINDER LINER PACKING (9901) | 372 |
| CYLINDER LINER (4601) | 214 |
| CYLINDER LINER (4834) | 334 |
| CYLINDER, ARTICULATION COMPONENTS | 514 |
| CYLINDER, ARTICULATION PINS | 512 |
| CYLINDER, BLADE LIFT | 1116 |
| CYLINDER, BLADE SLIDE | 1118 |
| CYLINDER, BLADE TILT | 1120 |
| CYLINDER, CIRCLE SIDE SHIFT | 1122 |
| CYLINDER, ETHER | 392 |
| CYLINDER, FRONT MOUNTED DOZER BLADE (BREAKDOWN) | 1172 |
| CYLINDER, FRONT MOUNTED DOZER BLADE (COMPLETE) .. | 1144 |
| CYLINDER, FRONT STEERING | 508 |
| CYLINDER, FRONT STEERING, COMPONENTS | 510 |
| CYLINDER, MID MOUNTED SCARIFIER | 1176 |
| CYLINDER, PARALLEL LIFT GROUP(BREAKDOWN) | 1172 |
| CYLINDER, REAR RIPPER/SCARIFIER | 1174 |
| CYLINDER, REAR STEERING COMPONENTS | 514 |
| CYLINDER, REAR STEERING PINS | 512 |
| CYLINDER, SCARIFIER (BREAKDOWN) | 1172 |
| CYLINDER, WHEEL LEAN | 516 |
| CYLINDER, WHEEL LEAN COMPONENTS | 518 |
| D | |
| DAMPENER, TORSIONAL | 118 |
| DAMPER (1346) | 180 |
| DEBRIS MAGNET, CHAIN CASE | 68 |
| DECALS (RUSSIAN) | 540 |
| DECALS, ENGLISH | 530 |
| DECALS, ENGLISH (GRADE PRO CAB) | 534 |
| DECALS, ENGLISH (STANDARD CAB) | 532 |
| DECALS, FRENCH | 536 |
| DECALS, SPANISH | 538 |
| DECAL, BATTERY DISCONNECT (1000 CCA) (6068HDW75) .. | 558 |
| DECAL, BATTERY DISCONNECT (1000 CCA) (6090HDW01 / 6090HDW04) | 554 |
| DECAL, BATTERY DISCONNECT (1400 CCA) (6068HDW75) .. | 560 |
| DECAL, BATTERY DISCONNECT (1400 CCA) (6090HDW01 / 6090HDW04) | 556 |
| DECAL, BRAKE ACCUMULATOR | 524 |
| DECAL, DIFFERENTIAL LOCK SWITCH | 676 |
| DECAL, ENGINE COMPARTMENT WORK LIGHTS SWITCH | 584 |
| DECAL, FUSE PANEL | 622 |
| DECAL, GRAY CIRCLE (FULL HEIGHT CAB) | 718, 720 |
| DECAL, GRAY CIRCLE (LOW PROFILE CAB - STD) | 710, 712 |
| DECELERATOR PEDAL | 438 |
| DEFLECTOR (1102) | 178 |
| DEFROST DUCT, CENTER CAB | 754 |
| DIAGNOSTIC FITTINGS, TRANSMISSION | 130 |
| DIAGNOSTIC FITTING, DIFFERENTIAL | 70 |
| DIAGNOSTIC FITTING, FLUIDS (6068HDW75) | 548 |
| DIAGNOSTIC FITTING, FLUIDS (6090HDW01 / 6090HDW04) .. | 546 |
| Diesel Fired Engine Coolant Heater Kit (6090HDW01 / 6090HDW04) | 400 |
| DIFFERENTIAL CASE- 1400 SERIES (YZ120521) | 102 |
| Differential Cooler Hoses | 402 |
| DIFFERENTIAL FILTER LABEL (ENGLISH) | 530 |
| DIFFERENTIAL FILTER LABEL (FRENCH) | 536 |
| DIFFERENTIAL FILTER LABEL (RUSSIAN) | 540 |
| DIFFERENTIAL FILTER LABEL (SPANISH) | 538 |
| Differential Lock Filter | 90 |
| Differential Lock Hydraulic Lines | 88 |
| DIFFERENTIAL LOCK LABEL (ENGLISH, GRADE PRO) | 534 |
| Differential Lock Pump, Hydraulic Fittings and Mounting .. | 84 |
| DIFFERENTIAL LOCK SWITCH AND LABEL | 676 |
| DIFFERENTIAL LOCK SWITCH (GRADE PRO) | 636 |
| DIFFERENTIAL LOCK W. VALVE(YZ120521) | 106 |
| DIFFERENTIAL OIL COOLER HOSES (6068HDW75)(SERIAL NUMBER 626426-) | 422 |
| DIFFERENTIAL OIL COOLER HOSES (6068HDW75)(SERIAL NUMBER-626425) | 420 |
| DIFFERENTIAL OIL COOLER HOSES (6090HDW01 / 6090HDW04) (SN-626425) | 412 |
| DIFFERENTIAL OIL COOLER HOSES (6090HDW01 / 6090HDW04)(SN 626426-) | 414 |
| DIFFERENTIAL OIL COOLER (6068HDW75) (SERIAL NUMBER 626426-) | 418 |
| DIFFERENTIAL OIL COOLER (6068HDW75) (SERIAL NUMBER-626425) | 416 |
| DIFFERENTIAL OIL COOLER (6090HDW01 / 6090HDW04)(SN 626426-) | 410 |
| DIFFERENTIAL OIL COOLER (6090HDW01 / 6090HDW04)(SN-626425) | 408 |
| DIFFERENTIAL - LOW PRESSURE | 104 |

Índice alfabético, continuación

| | Página | | Página |
|---|----------|--|----------|
| DIFF CASE, MULT DISK BRAKE..... | 108 | EGR SERVICE KIT (9901)..... | 274 |
| DIFF LOCK PUMP..... | 84 | EGR VALVE GASKET KIT (9901)..... | 272, 370 |
| Diodes, Fuse Panel..... | 630 | EGR (8902)..... | 242 |
| DIODE, A/C COMPRESSOR CLUTCH SOLENOID (6068HDW75)..... | 614 | EH STEERING HYDRAULIC HOSES (GRADE PRO)..... | 494 |
| DIODE, A/C COMPRESSOR CLUTCH SOLENOID (6090HDW01)..... | 610 | EH STEERING PLUMBING (GRADE PRO)..... | 494 |
| DIODE, ENGINE AIR HEATER..... | 616 | EH VALVE COVER, FRONT (GRADE PRO)..... | 842 |
| DIODE, GLOW PLUGS..... | 616 | EH VALVE COVER, REAR (GRADE PRO)..... | 840 |
| DIODE, PARK BRAKE SOLENOID..... | 620 | EH VALVE COVER, (GRADE PRO)..... | 840 |
| DIODE, SOFT START..... | 600 | EIGHT FUNCTION CONTROL VALVE, FRONT (EH) (GRADE PRO)..... | 972 |
| DIODE, STARTER RELAY AND MOTOR..... | 616 | ELBOW, EXHAUST (6401)..... | 345 |
| DIPSTICK, OIL (4048)..... | 324 | ELBOW, EXHAUST(6401)..... | 232 |
| DIPSTICK, OIL, ENGINE 4018..... | 208 | ELECTROHYDRAULIC ARMREST WIRING HARNESS (GRADE PRO)..... | 636 |
| DIPSTICK, TRANSMISSION OIL..... | 122 | ELECTROHYDRAULIC ARMREST WIRING HARNESS, LEFT (GRADE PRO) (CONNECTORS)..... | 644 |
| DIRECTIONAL VALVE (REVERSING FAN)..... | 432 | ELECTROHYDRAULIC ARMREST WIRING HARNESS, RIGHT (GRADE PRO) (CONNECTORS)..... | 642 |
| DISCONNECT SWITCH, BATTERY (1000 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 554 | Electrohydraulic Auxiliary Control Valve Kit (Grade Pro)..... | 996 |
| DISCONNECT SWITCH, BATTERY (1000 CCA) (6068HDW75)..... | 558 | ELECTROHYDRAULIC AUX/RIPPER/SCAFIER VALVE SECTION (GRADE PRO) (BREAKDOWN)..... | 994 |
| DISCONNECT SWITCH, BATTERY (1400 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 556 | ELECTROHYDRAULIC BLADE LIFT VALVE SECTION (GRADE PRO) (BREAKDOWN)..... | 978 |
| DISCONNECT SWITCH, BATTERY (1400 CCA) (6068HDW75)..... | 560 | ELECTROHYDRAULIC BLADE SIDE SHIFT VALVE SECTION (GRADE PRO) (BREAKDOWN)..... | 984 |
| DISCONNECT, MAIN HYD PUMP COLD START..... | 1002 | ELECTROHYDRAULIC BLADE TILT VALVE SECTION (BREAKDOWN) (GRADE PRO)..... | 980 |
| DISK, BRAKE..... | 66 | ELECTROHYDRAULIC CAB WIRING HARNESS (GRADE PRO)..... | 636 |
| DISPLAY MONITOR, CAB (GRADE PRO)..... | 672 | ELECTROHYDRAULIC CAB WIRING HARNESS (GRADE PRO) (CONNECTORS)..... | 638 |
| DISPLAY MONITOR, CAB (STD CONTROLS)..... | 670 | ELECTROHYDRAULIC CIRCLE ROTATE VALVE SECTION (GRADE PRO) (BREAKDOWN)..... | 982 |
| DISPLAY MONITOR, CAB, ALTERNATE MOUNTING BRACKET (ICG)..... | 674 | ELECTROHYDRAULIC CIRCLE SIDE SHIFT VALVE SECTION (GRADE PRO) (BREAKDOWN)..... | 988 |
| DOMELIGHT HOUSING (FULL HEIGHT CAB)..... | 718, 720 | ELECTROHYDRAULIC IGC WIRING HARNESS (GRADE PRO)..... | 636 |
| DOMELIGHT HOUSING (GRADE PRO)..... | 714, 716 | ELECTROHYDRAULIC IGC WIRING HARNESS (GRADE PRO) (CONNECTORS)..... | 640 |
| DOMELIGHT HOUSING (LOW PROFILE CAB - STD)..... | 710, 712 | Electrohydraulic Inlet Valve Section (Front) (Grade Pro)..... | 992 |
| Dome Light..... | 590 | Electrohydraulic Inlet Valve Section (Rear) (Grade Pro)..... | 990 |
| DOORS, ENGINE..... | 832 | ELECTROHYDRAULIC REAR STEERING VALVE SECTION (GRADE PRO) (BREAKDOWN)..... | 974 |
| DOORS, FULL HEIGHT CAB..... | 732 | ELECTROHYDRAULIC STEERING VALVE SECTION (GRADE PRO) (BREAKDOWN)..... | 976 |
| DOORS, LOW PROFILE CAB..... | 730 | Electrohydraulic Valve Controllers (Grade Pro)..... | 668 |
| DOORS, SERVICE..... | 832 | Electrohydraulic Valve Mount (Front) (Grade Pro)..... | 954 |
| DOOR BUMPER, SERVICE..... | 832 | Electrohydraulic Valve Mount (Rear) (Grade Pro)..... | 956 |
| DOOR HINGE, SERVICE..... | 832 | Electrohydraulic Valve Wiring Harnesses (Grade Pro)..... | 646 |
| DOOR LATCH (FULL HEIGHT CAB)..... | 732 | ELECTROHYDRAULIC VALVE WIRING HARNESSES, FRONT (GRADE PRO) (CONNECTORS)..... | 650 |
| DOOR LATCH (LOW PROFILE CAB)..... | 730 | ELECTROHYDRAULIC VALVE WIRING HARNESSES, REAR (GRADE PRO) (CONNECTORS)..... | 648 |
| DOOR, FAN..... | 424 | ELECTROHYDRAULIC WHEEL LEAN VALVE SECTION (GRADE PRO) (BREAKDOWN)..... | 986 |
| DOOR, HVAC MODE..... | 812 | ELECTROHYDRAULIC 4 FUNCTION CONTROLS (LH) (GRADE PRO)..... | 782 |
| DOZER BLADE, FRONT MOUNTED..... | 1144 | ELECTROHYDRAULIC 4 FUNCTION CONTROLS (RH) (GRADE PRO)..... | 780 |
| Draft Frame..... | 1058 | Electrohydraulic 4 Function Valve (Rear) (Grade Pro)..... | 958 |
| Draft Frame Sensors..... | 684 | ELECTROHYDRAULIC 5 FUNCTION CONTROLS (LH) (GRADE PRO)..... | 786 |
| DRAFT FRAME WORK LIGHTS..... | 578 | ELECTROHYDRAULIC 5 FUNCTION CONTROLS (RH) (GRADE PRO)..... | 784 |
| DRAIN VALVE, ENGINE OIL PAN (19BR)..... | 304 | Electrohydraulic 5 Function Valve (Front) (Grade Pro)..... | 960 |
| DRAIN, FLYWHEEL HOUSING (6068HDW75)..... | 128 | Electrohydraulic 5 Function Valve (Rear) (Grade Pro)..... | 962 |
| DRAIN, FLYWHEEL HOUSING (6090HDW01 / 6090HDW04)..... | 126 | Electrohydraulic 6 Function Valve (Front) (Grade Pro)..... | 964 |
| Driveshaft..... | 72 | Electrohydraulic 6 Function Valve (Front) (Mid Mounted Scarifier) (Grade Pro)..... | 966 |
| DRIVE CHAIN, TANDEM..... | 68 | Electrohydraulic 6 Function Valve (Rear) (Grade Pro)..... | 968 |
| DRIVE COVER, AUXILIARY..... | 228 | Electrohydraulic 7 Function Valve (Rear) (Grade Pro)..... | 970 |
| DRIVE LIGHTS WIRING HARNESS, FRONT..... | 594 | Electrohydraulic 8 Function Valve (Front) (Grade Pro)..... | 972 |
| DRIVE LIGHTS WIRING HARNESS, FRONT (CONNECTORS)..... | 604 | Element, Filter..... | 202 |
| DRIVE MOTOR, FAN..... | 428 | ELEMENT, FUEL FILTER/HEATER, ADDITIONAL (6068HDW75)..... | 462 |
| DRIVE SHAFT, FINAL DRIVE AND TANDEM PIVOT..... | 64 | ELEMENT, FUEL FILTER/HEATER, ADDITIONAL (6090HDW01 / 6090HDW04)..... | 460 |
| DRIVE SPROCKET..... | 64 | ELEMENT, TRANSMISSION FILTER..... | 132 |
| DRIVE, AUXILIARY, MAIN HYDRAULIC PUMP..... | 878 | ELEMENT, WATER SEPARATOR (81AL)..... | 352 |
| DRIVE, FAN (2310)..... | 193 | ENCLOSURE, FULL HEIGHT W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 706 |
| DRIVE, TANDEM..... | 62 | ENCLOSURE, GRADE PRO CAB W/ DOORS AND OPENING FIXED WINDOWS (COMPLETE)..... | 704 |
| DRIVING LIGHTS, FRONT..... | 574 | ENCLOSURE, LOW PROFILE CAB W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 698 |
| DUCT, DEFROST, CENTER CAB..... | 754 | | |
| E | | | |
| ECU (6068HDW75)..... | 474 | | |
| ECU (6090HDW01)..... | 472 | | |
| ECU (8497)..... | 240 | | |
| Edge, Cutting, 5/8 in. X 6 in. (Use With 12 ft. X 24 in. X 7/8 in. Moldboard)..... | 1020 | | |
| Edge, Cutting, 5/8 in. X 6 in. (Use With 14 ft. X 24 in. X 7/8 in. Moldboard)..... | 1028 | | |
| Edge, Cutting, 5/8 in. X 8 in. (Use With 12 ft. X 24 in. X 7/8 in. Moldboard)..... | 1022 | | |
| Edge, Cutting, 5/8 in. X 8 in. (Use With 12 ft. X 27 in. X 1 in. Moldboard)..... | 1024 | | |
| Edge, Cutting, 5/8 in. X 8 in. (Use With 13 ft. X 27 in. X 1 in. Moldboard)..... | 1026 | | |
| Edge, Cutting, 5/8 in. X 8 in. (Use With 14 ft. X 24 in. X 7/8 in. Moldboard)..... | 1030 | | |
| Edge, Cutting, 5/8 in. X 8 in. (Use With 14 ft. X 27 in. X 1 in. Moldboard)..... | 1032 | | |
| Edge, Cutting, 5/8 in. X 8 in. (Use With 14 ft. X 27 in. X 1 in. Moldboard) (3/4 in. Hardware)..... | 1034 | | |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> |
|--|---------------|
| ENCLOSURE, LOW PROFILE CAB W/ DOORS AND OPENING FIXED WINDOWS (COMPLETE)..... | 700 |
| ENCLOSURE, LOW PROFILE W/ DOORS AND OPEN SIDE/FIXED FRONT WINDOWS (COMPLETE)..... | 702 |
| End Bit Overlays For 6 in. Cutting Edge (5/8 in. Hardware)..... | 1036 |
| End Bit Overlays For 8 in. Cutting Edge (3/4 in. Hardware)..... | 1040 |
| End Bit Overlays For 8 in. Cutting Edge (5/8 in. Hardware)..... | 1038 |
| End Bit (12 ft. X 24 in. X 7/8 in. Moldboard With 5/8 in. X 6 in. Cutting Edges)..... | 1020 |
| End Bit (12 ft. X 24 in. X 7/8 in. Moldboard With 5/8 in. X 8 in. Cutting Edges)..... | 1022 |
| End Bit (12 ft. X 27 in. X 1 in. Moldboard With 5/8 in. X 8 in. Cutting Edges)..... | 1024 |
| End Bit (13 ft. X 27 in. X 1 in. Moldboard With 5/8 in. X 8 in. Cutting Edges)..... | 1026 |
| End Bit (14 ft. X 24 in. X 7/8 in. Moldboard With 5/8 in. X 6 in. Cutting Edges)..... | 1028 |
| End Bit (14 ft. X 24 in. X 7/8 in. Moldboard With 5/8 in. X 8 in. Cutting Edges)..... | 1030 |
| End Bit (14 ft. X 27 in. X 1 in. Moldboard With 5/8 in. X 8 in. Cutting Edges)..... | 1032 |
| End Bit (14 ft. X 27 in. X 1 in. Moldboard With 5/8 in. X 8 in. Cutting Edges) (3/4 in. Hardware)..... | 1034 |
| END, TIE ROD, FRONT AXLE..... | 78 |
| ENGINE AIR CLEANER AND FILTERS (6068HDW75)..... | 442 |
| ENGINE AIR CLEANER AND FILTERS (6090HDW01 / 6090HDW04)..... | 440 |
| Engine Air Heater..... | 390 |
| ENGINE AIR HEATER WIRING HARNESS..... | 390 |
| ENGINE BELT, W/ 100A ALTERNATOR (6068HDW75)..... | 566 |
| ENGINE BELT, W/ 100A ALTERNATOR (6090HDW01 / 6090HDW04)..... | 562 |
| ENGINE BELT, W/ 130A ALTERNATOR (6068HDW75)..... | 568 |
| ENGINE BELT, W/ 130A ALTERNATOR (6090HDW01 / 6090HDW04)..... | 564 |
| Engine Compartment Work Lights..... | 584 |
| Engine Control Unit (ECU) (Engine 6068HDW75)..... | 474 |
| Engine Control Unit (ECU) (Engine 6090HDW01)..... | 472 |
| ENGINE CONTROL UNIT (8497)..... | 240 |
| ENGINE COOLANT DIAGNOSTIC FITTING (6068HDW75)..... | 548 |
| ENGINE COOLANT DIAGNOSTIC FITTING (6090HDW01 / 6090HDW04)..... | 546 |
| Engine Coolant Heater (120V) (Engines 6068HDW75)..... | 396 |
| Engine Coolant Heater (120V) (Engines 6090HDW01 / 6090HDW04)..... | 394 |
| ENGINE COOLANT HEATER, DIESEL FIRED (6090HDW01 / 6090HDW04)..... | 400 |
| ENGINE COOLANT LABEL (6068HDW75) (SERIAL NUMBER 626426-)..... | 422 |
| ENGINE COOLANT LABEL (6068HDW75) (SERIAL NUMBER-626425)..... | 420 |
| ENGINE COOLANT LABEL (6090HDW01 / 6090HDW04)(SN 626426-)..... | 414 |
| ENGINE COOLANT LABEL (6090HDW01 / 6090HDW04)(SN-626425)..... | 412 |
| ENGINE DOORS..... | 832 |
| Engine Frame..... | 688 |
| Engine Frame Harness..... | 616 |
| ENGINE GASKET KIT 9901..... | 368 |
| ENGINE GASKET KIT, CYLINDER HEAD REMOVAL (9901)..... | 276 |
| ENGINE GASKET KIT, LONG BLOCK (9901)..... | 284 |
| ENGINE HEATER (2697)..... | 194 |
| Engine Mounting Brackets and Isolators (Engines 6090HDW01 / 6090HDW04)..... | 452 |
| Engine Mounting Brackets and Isolators (Engine 6068HDW75)..... | 454 |
| ENGINE OIL BY-PASS VALVE (4606)..... | 216 |
| ENGINE OIL DIAGNOSTIC FITTING (6068HDW75)..... | 548 |
| ENGINE OIL DIAGNOSTIC FITTING (6090HDW01 / 6090HDW04)..... | 546 |
| ENGINE OIL DIPSTICK..... | 208 |
| Engine Oil Drain Line (Engines 6090HDW01 / 6090HDW04)..... | 542 |
| Engine Oil Drain Line (Engine 6068HDW75)..... | 544 |
| ENGINE OIL FILLER NECK(1230)..... | 296 |
| ENGINE OVERHAUL KIT..... | 386 |
| ENGINE OVERHAUL KIT (9902)..... | 280 |
| ENGINE REBUILD GASKET KIT (9901)..... | 278 |
| ENGINE SENSORS..... | 350 |
| Engine Sound Absorption..... | 844 |
| ENGINE SPEED CONTROL ON/OFF SWITCH (GRADE PRO)..... | 436 |
| ENGINE SPEED CONTROL ON/OFF SWITCH (STANDARD)..... | 434 |
| Engine Speed Control Pedal and Switches (Grade Pro)..... | 436 |
| Engine Speed Control Pedal and Switches (Standard Controls)..... | 434 |
| Engine Speed Decelerator Pedal..... | 438 |
| ENGINE SPEED, SENSOR (6744)..... | 350 |
| Engine Wiring Harnesses (6068HDW75)..... | 612, 614 |
| Engine Wiring Harnesses (6090HDW01)..... | 606, 608, 610 |
| ENGINE WIRING HARNESS (CONNECTORS) (6090HDW01)..... | 610 |
| ENGLISH LABELS AND TRADEMARKS (STD CAB)..... | 532 |
| ENGLISH TRADEMARKS AND LABELS (GRADE PRO CAB)..... | 534 |
| Ether Starting Aid..... | 392 |
| EVAPORATION CHECK VALVE, A/C (6068HDW75)..... | 824 |
| EVAPORATION CHECK VALVE, A/C (6090HDW01 / 6090HDW04)..... | 822 |
| EXHAUST ELBOW (6401)..... | 232, 345 |
| EXHAUST GAS RECIRCULATION (8902)..... | 242 |
| EXHAUST MANIFOLD REMOVAL KIT (9901)..... | 271 |
| EXHAUST MANIFOLD (28AY)..... | 311 |
| EXHAUST MANIFOLD 2802..... | 196 |
| EXHAUST MANIFOLD 2870..... | 310 |
| EXHAUST MUFFLER AND CLAMPS (6068HDW75)..... | 450 |
| EXHAUST MUFFLER AND CLAMPS (6090HDW01 / 6090HDW04)..... | 448 |
| EXHAUST VALVE (5101)..... | 226 |
| EXHAUST VALVE (5128)..... | 340 |
| EXPANSION VALVE WITH TEMP SWITCH..... | 820 |
| Extended Life Circle Inserts..... | 1070 |
| EXTENSIONS, SNOW LIGHT..... | 586 |
| EXTENSION, CAB FLOOR MAT (GRADE PRO)..... | 724 |
| Extension, Left Moldboard (24 in. WITH 5/8 in. Hardware)..... | 1044 |
| Extension, Left Moldboard (27 in. With 3/4 in. Hardware)..... | 1052 |
| Extension, Left Moldboard (27 in. WITH 5/8 in. Hardware)..... | 1048 |
| Extension, Right Moldboard (24 in. WITH 5/8 in. Hardware)..... | 1042 |
| Extension, Right Moldboard (27 in. With 3/4 in. Hardware)..... | 1050 |
| Extension, Right Moldboard (27 in. WITH 5/8 in. Hardware)..... | 1046 |
| Exterior Mirror..... | 858 |
| EXTERIOR MIRROR (HEATED)..... | 860 |
| EXTINGUISHER, FIRE..... | 862 |
| F | |
| FACTORY, REAR RIPPER/SCARIFIER..... | 1130 |
| FAN DOOR WIRING HARNESS..... | 576 |
| FAN DRIVE HOSES..... | 430 |
| Fan Drive Motor Hoses..... | 430 |
| FAN DRIVE PULLEY (8724)..... | 356 |
| Fan Drive Pump..... | 426 |
| FAN DRIVE TENSIONER..... | 356 |
| FAN DRIVE VALVE, REVERSING..... | 432 |
| FAN DRIVE 2310..... | 193 |
| FAN SHROUD (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| FAN SHROUD (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| FAN SHROUD (6090HDW01 / 6090HDW04) (SN 626426-)..... | 410 |
| FAN SHROUD (6090HDW01 / 6090HDW04) (SN-626425)..... | 408 |
| Fan, Fan Door and Fan Guard..... | 424 |
| Fast Fill Fuel System..... | 470 |
| FENDERS, FRONT..... | 848 |
| FENDERS, FRONT FIELD KIT..... | 850 |
| FENDERS, REAR..... | 852 |
| FIELD KIT, BEACON BRACKET..... | 588 |
| FIELD KIT, BLADE IMPACT SYSTEM (GRADE PRO)..... | 1084 |
| FIELD KIT, BLADE IMPACT SYSTEM (STANDARD CONTROLS)..... | 1082 |
| FIELD KIT, DIESEL FIRED COOLANT HEATER (6090HDW01 / 6090HDW04)..... | 400 |
| FIELD KIT, FAST FILL FUEL SYSTEM..... | 470 |
| FIELD KIT, FRONT FENDERS..... | 850 |
| FIELD KIT, FRONT MOUNTED DOZER BLADE..... | 1144 |
| FIELD KIT, HYDRAULIC WARMUP CIRCUIT..... | 1010 |
| FIELD KIT, PUSH BLOCK..... | 694 |
| FIELD KIT, REAR FENDERS..... | 852 |
| FIELD KIT, REAR HITCH..... | 552 |
| FIELD KIT, REAR RIPPER/SCARIFIER..... | 1132 |
| FIFTH FUNCTION CONTROL LINKAGE (LEFT) (SCARIFIER)..... | 766 |
| FIFTH FUNCTION CONTROL LINKAGE (RIGHT) (SCARIFIER)..... | 764 |
| FIFTH FUNCTION CONTROL VALVE KIT (LEFT) (RIPPER)..... | 936 |
| FIFTH FUNCTION CONTROL VALVE KIT (RIGHT) (SCARIFIER)..... | 934 |
| FIFTH FUNCTION HYDRAULICS (GRADE PRO)..... | 1158 |
| FIFTH FUNCTION HYDRAULICS (STANDARD)..... | 1156, 1164 |
| FIFTH FUNCTION PLUMBING (GRADE PRO)..... | 1158 |
| FIFTH FUNCTION PLUMBING (STANDARD)..... | 1156, 1164 |
| FIFTH FUNCTION REAR AUXILIARY HOSES (GRADE PRO) (FIFTH FUNCTION)..... | 1166 |
| FIFTH FUNCTION REAR AUXILIARY PLUMBING (GRADE PRO) (FIFTH FUNCTION)..... | 1166 |
| FIFTH STAGE SHAFT ASSEMBLY (YZ106564)..... | 144 |
| FILTER ELEMENT SERVICE KIT, FUEL (9901)..... | 268 |
| FILTER ELEMENT, FUEL (9901)..... | 253 |
| FILTER O-RING KIT(9901)..... | 379 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> | | |
|--|---------------|---|----------|
| FILTER RESTRICTION SWITCH, MAIN HYDRAULIC FILTER..... | 1012 | FRAME, REAR RIPPER/SCARIFIER..... | 1130 |
| FILTER, CAB FRESH AIR..... | 814 | FRAME, SADDLE..... | 1060 |
| FILTER, DIFFERENTIAL LOCK..... | 90 | FRAME, TILT, BLADE..... | 1062 |
| FILTER, ENGINE AIR (6068HDW75)..... | 442 | FRENCH LABELS AND TRADEMARKS..... | 536 |
| FILTER, ENGINE AIR (6090HDW01 / 6090HDW04)..... | 440 | FRESH AIR FILTER, CAB..... | 814 |
| Filter, Fuel..... | 202 | FRESH AIR INTAKE PLATE (CAB ROOF)..... | 728 |
| FILTER, FUEL FINAL (35DZ)..... | 316 | Front and Rear Cab Lights..... | 580 |
| FILTER, FUEL (3508)..... | 204 | FRONT ASSEMBLY HOUSING..... | 166 |
| FILTER, FUEL, INLINE (6068HDW75)..... | 458 | Front Attachment Cylinder..... | 1172 |
| FILTER, FUEL, INLINE (6090HDW01 / 6090HDW04)..... | 456 | Front Auxiliary Hoses (Fifth Function) (Grade Pro)..... | 1158 |
| FILTER, HYDRAULIC..... | 1012 | Front Auxiliary Hoses (Fifth Function) (Standard Controls)..... | 1156 |
| FILTER, OIL AND HEAD (8860)..... | 358 | Front Auxiliary Hoses (Sixth Function) (Grade Pro)..... | 1162 |
| FILTER, OIL (5912)..... | 230 | Front Auxiliary Hoses (Sixth Function) (Standard Controls)..... | 1160 |
| FILTER, PRIMARY FUEL (9901)..... | 247 | Front Axle and Mounting Pin..... | 74 |
| FILTER, TRANSMISSION..... | 132 | FRONT AXLE GUARD..... | 74 |
| Final Drive and Tandem Pivot..... | 64 | FRONT AXLE PIVOT PIN..... | 74 |
| FINAL DRIVE HOUSING..... | 64 | Front Axle Tie Rod..... | 78 |
| Fire Extinguisher and Bracket..... | 862 | FRONT CONSOLE COVER (FULL HEIGHT CAB)..... | 718, 720 |
| FIRST STAGE SHAFT ASSEMBLY (YZ106678)..... | 136 | FRONT CONSOLE COVER (GRADE PRO)..... | 714, 716 |
| FITTINGS, ARTICULATION CYLINDER HOSE (STANDARD CONTROLS)..... | 496 | FRONT CONSOLE COVER (LOW PROFILE CAB - STD)..... | 710, 712 |
| FITTINGS, PARK BRAKE VALVE..... | 526 | Front Console Switches (Grade Pro)..... | 678 |
| FITTINGS, RIPPER CYLINDER..... | 1150, 1152 | Front Console Switches (Standard Controls)..... | 676 |
| FITTINGS, SCARIFIER CYLINDER (REAR)..... | 1150, 1152 | Front Console (Grade Pro)..... | 778 |
| FITTINGS, TRANSMISSION DIAGNOSTIC..... | 130 | Front Console (Standard Controls)..... | 760 |
| FITTING, DIFFERENTIAL BREATHER..... | 70 | FRONT DRIVE/TURN LIGHTS WIRING HARNESS..... | 594 |
| FITTING, DIFFERENTIAL DIAGNOSTIC..... | 70 | FRONT DRIVE/TURN LIGHTS WIRING HARNESS (CONNECTORS)..... | 604 |
| FIVE FUNCTION CONTROLS, LEFT (EH) (GRADE PRO)..... | 786 | Front Driving and Signal Lights..... | 574 |
| FIVE FUNCTION CONTROLS, RIGHT (EH) (GRADE PRO)..... | 784 | FRONT EH VALVE HARNESS (GRADE PRO)..... | 646 |
| FIVE FUNCTION CONTROL VALVE, FRONT (EH) (GRADE PRO)..... | 960 | FRONT EH VALVE MOUNT (GRADE PRO)..... | 954 |
| FIVE FUNCTION CONTROL VALVE, LEFT..... | 890 | FRONT EIGHT FUNCTION CONTROL VALVE (EH) (GRADE PRO)..... | 972 |
| FIVE FUNCTION CONTROL VALVE, REAR (EH) (GRADE PRO)..... | 962 | FRONT ELECTROHYDRAULIC CONTROL VALVE INLET SECTION (GRADE PRO) (BREAKDOWN)..... | 992 |
| FIVE FUNCTION CONTROL VALVE, RIGHT..... | 886 | Front Fenders..... | 848 |
| FIVE FUNCTION CONTROL VALVE, RIGHT (MID MOUNTED SCARIFIER)..... | 888 | Front Fenders Kit..... | 850 |
| Fixed Windows (Low Profile Cab)..... | 734 | FRONT FIVE FUNCTION CONTROL VALVE (EH) (GRADE PRO)..... | 960 |
| FLC MOUNTING BRACKET (GRADE PRO)..... | 758 | Front Frame Covers and Shields..... | 834 |
| FLC MOUNTING BRACKET (STD CONTROLS)..... | 756 | Front Grade Pro Valve Harness..... | 650 |
| FLC (WITHOUT AUTOSHIFT)..... | 664 | Front Light Harness..... | 604 |
| FLC (WITH AUTOSHIFT)..... | 666 | Front Mounted Dozer Blade..... | 1144 |
| FLEX LOAD CONTROLLER MOUNTING BRACKET (GRADE PRO)..... | 758 | FRONT MOUNTED DOZER BLADE CYLINDER (BREAKDOWN)..... | 1172 |
| FLEX LOAD CONTROLLER MOUNTING BRACKET (STD CONTROLS)..... | 756 | FRONT MOUNTED DOZER BLADE CYLINDER (COMPLETE)..... | 1144 |
| Flex Load Controller Power Cable..... | 632 | Front Mounted Scarifier Field Kit..... | 1128 |
| FLEX LOAD CONTROLLER POWER CABLE..... | 622 | FRONT MOUNTED SCARIFIER KIT..... | 1128 |
| Flex Load Controller (FLC) (Without Autoshift)..... | 664 | FRONT MOUNTED SCARIFIER MOUNTING BRACKET..... | 1128 |
| Flex Load Controller (FLC) (With Autoshift)..... | 666 | FRONT PLATE (3612)..... | 318 |
| FLOAT SWITCH (GRADE PRO)..... | 636 | Front Platform Harness..... | 596 |
| FLOORMAT, CAB (GRADE PRO)..... | 724 | FRONT PLATFORM WIRING HARNESS..... | 594 |
| FLOORMAT, CAB (STD CONTROLS)..... | 722 | FRONT SCARIFIER FIELD KIT..... | 1146 |
| Flywheel Housing Drain (Engines 6090HDW01 / 6090HDW04)..... | 126 | Front Scarifier Hydraulic Hoses..... | 1146 |
| Flywheel Housing Drain (6068HDW75)..... | 128 | Front Scarifier Hydraulic Hoses (Field Kit)..... | 1148 |
| FLYWHEEL HOUSING (1412)..... | 181 | FRONT SIX FUNCTION CONTROL VALVE W/MID MOUNTED SCARIFIER (GRADE PRO)..... | 966 |
| FLYWHEEL HOUSING (1423)..... | 298 | FRONT SIX FUNCTION CONTROL VALVE (EH) (GRADE PRO)..... | 964 |
| FLYWHEEL 1520..... | 182 | Front Steering Cylinder..... | 510 |
| FLYWHEEL 1530..... | 299 | Front Steering Cylinder Pins..... | 508 |
| FOURTH STAGE SHAFT ASSEMBLY (YZ106665)..... | 142 | Front Steering Plumbing (Grade Pro)..... | 494 |
| FOUR FUNCTION CONTROLS, LEFT (EH) (GRADE PRO)..... | 782 | Front Steering Plumbing (Standard Controls)..... | 492 |
| FOUR FUNCTION CONTROLS, RIGHT (EH) (GRADE PRO)..... | 780 | FRONT TILT CONSOLE WIRING HARNESS (GRADE PRO)..... | 656 |
| FOUR FUNCTION CONTROL VALVE, LEFT..... | 884 | FRONT TILT CONSOLE WIRING HARNESS (STANDARD CONTROLS)..... | 654 |
| FOUR FUNCTION CONTROL VALVE, REAR (EH) (GRADE PRO)..... | 958 | FRONT VALVE COVER (GRADE PRO)..... | 842 |
| FOUR FUNCTION CONTROL VALVE, RIGHT..... | 882 | FRONT WHEEL BEARING (LEFT)..... | 82 |
| FOUR WHEEL DRIVE INSTRUMENT PANEL LABEL (ENGLISH, GRADE PRO)..... | 534 | FRONT WHEEL BEARING (RIGHT)..... | 80 |
| FOUR WHEEL DRIVE INSTRUMENT PANEL LABEL (FRENCH)..... | 536 | FRONT WHEEL DRIVE HOSES (GRADE PRO)..... | 506 |
| FOUR WHEEL DRIVE INSTRUMENT PANEL LABEL (SPANISH)..... | 538 | FRONT WHEEL HUB (LEFT)..... | 82 |
| FRAME ARTICULATION SENSOR (GRADE PRO)..... | 682 | FRONT WINDOWS, LOWER FIXED W/ OPENING (LOW PROFILE CAB)..... | 738 |
| FRAME ARTICULATION SENSOR (STD CONTROLS)..... | 680 | FRONT WINDOWS, LOWER FIXED (LOW PROFILE CAB)..... | 734 |
| FRAME BRIDGE, GROUND CABLE (1000 CCA BATTERIES) (6068HDW75)..... | 558 | FRONT WINDOWS, LOWER OPENING (FULL HEIGHT CAB) (S.N. -627324)..... | 740 |
| FRAME BRIDGE, GROUND CABLE (1000 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 554 | FRONT WINDOWS, LOWER OPENING (LOW PROFILE CAB)..... | 736 |
| FRAME BRIDGE, GROUND CABLE (1400 CCA BATTERIES) (6068HDW75)..... | 560 | Front Window Sun Visor..... | 872 |
| FRAME BRIDGE, GROUND CABLE (1400 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 556 | Front Windshield Wiper (Full Height Cab)..... | 744 |
| Frame Hinge Central Lubrication Lines and Fittings..... | 550 | Front Windshield Wiper (Low Profile Cab)..... | 742 |
| FRAME SHIELDS..... | 834 | FRONT WIPER HOUSING (FULL HEIGHT CAB)..... | 718, 720 |
| FRAME, CIRCLE..... | 1064 | FRONT WIPER HOUSING (GRADE PRO)..... | 714, 716 |
| FRAME, DRAFT..... | 1058 | FRONT WIPER HOUSING (LOW PROFILE CAB - STD)..... | 710, 712 |
| FRAME, ENGINE..... | 688 | FRONT WORK LIGHTS..... | 578 |
| FRAME, MAIN..... | 686 | Fuel And Water Separator (S.N. 627691-)..... | 466 |
| | | FUEL AND WATER SEPARATOR (3508)..... | 204 |
| | | Fuel And Water Separator, Additional (Field Kit S.N. -627690)..... | 464 |

Índice alfabético, continuación

| Página | Página | | |
|---|----------|--|---------------|
| FUEL AND WATER SEPARATOR, ADDITIONAL (6068HDW75)..... | 462 | GRADE CONTROL (IGC) COVER (LOW PROFILE CAB - STD)..... | 710, 712 |
| FUEL AND WATER SEPARATOR, ADDITIONAL (6090HDW01 / 6090HDW04)..... | 460 | Grade Pro Auxiliary Controls..... | 788 |
| FUEL COOLER (6090HDW01 / 6090HDW04) (SN 626426-)..... | 410 | GRADE PRO CAB ENCLOSURE W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 704 |
| FUEL COOLER (6090HDW01 / 6090HDW04) (SN-626425)..... | 408 | Grade Pro Controls (Left 4 Function)..... | 782 |
| Fuel Filter..... | 202 | Grade Pro Controls (Left 5 Function)..... | 786 |
| Fuel Filter Element Service Kit..... | 202 | Grade Pro Controls (Right 4 Function)..... | 780 |
| FUEL FILTER ELEMENT SERVICE KIT (9901)..... | 268 | Grade Pro Controls (Right 5 Function)..... | 784 |
| FUEL FILTER ELEMENT (9901)..... | 253 | GRAY CIRCLE DECAL (FULL HEIGHT CAB)..... | 718, 720 |
| FUEL FILTER GASKET KIT (35DZ)..... | 316 | GRAY CIRCLE DECAL (LOW PROFILE CAB - STD)..... | 710, 712 |
| FUEL FILTER (3508)..... | 204 | Grease Bank..... | 86 |
| Fuel Filter, Additional (Field Kit S.N. -627690)..... | 464 | Grease Bank Kit..... | 86 |
| FUEL FILTER, ADDITIONAL (6068HDW75)..... | 462 | GREASE FITTINGS, FRAME HINGE CENTRAL LUBRICATION..... | 550 |
| FUEL FILTER, ADDITIONAL (6090HDW01 / 6090HDW04)..... | 460 | Grille Housing..... | 692 |
| FUEL FILTER, FINAL (35DZ)..... | 316 | GRILLE, FAN..... | 424 |
| FUEL FILTER, IN-LINE (6068HDW75)..... | 458 | GRILLE, SPEAKER (FULL HEIGHT CAB)..... | 718, 720 |
| FUEL FILTER, IN-LINE (6090HDW01 / 6090HDW04)..... | 456 | GRILLE, SPEAKER (GRADE PRO)..... | 714, 716 |
| FUEL FILTER, PRIMARY (9901)..... | 247 | GRILLE, SPEAKER (LOW PROFILE CAB - STD)..... | 710, 712 |
| Fuel Hoses and Fittings (Engines 6090HDW01 / 6090HDW04)..... | 456 | GROMMET, TAIL AND SIGNAL LAMPS..... | 576 |
| Fuel Hoses and Fittings (Engine 6068HDW75)..... | 458 | GROUND CABLE, BATTERY (1000 CCA) (6068HDW75)..... | 558 |
| Fuel Injection Lines..... | 184 | GROUND CABLE, BATTERY (1000 CCA) (6090HDW01 / 6090HDW04)..... | 554 |
| Fuel Injection Nozzle..... | 184 | GROUND CABLE, BATTERY (1400 CCA) (6068HDW75)..... | 560 |
| FUEL INJECTION NOZZLE SERVICE KIT (9901)..... | 374 | GROUND CABLE, BATTERY (1400 CCA) (6090HDW01 / 6090HDW04)..... | 556 |
| Fuel Injection Pump..... | 184 | GROUND CABLE, FRAME TO FRAME (1000 CCA BATTERIES) (6068HDW75)..... | 558 |
| FUEL INJECTION PUMP, COMMON RAIL (169Z)..... | 300 | GROUND CABLE, FRAME TO FRAME (1000 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 554 |
| FUEL INJECTOR CONNECTOR SEAL KIT (9901) (HDW01)..... | 261 | GROUND CABLE, FRAME TO FRAME (1400 CCA BATTERIES) (6068HDW75)..... | 560 |
| FUEL LINES, HIGH PRESSURE (169Z)..... | 300 | GROUND CABLE, FRAME TO FRAME (1400 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 556 |
| FUEL PUMP, DIESEL FIRED COOLANT HEATER (6090HDW01 / 6090HDW04)..... | 400 | GROUND TERMINAL, FRONT PLATFORM WIRING HARNESS..... | 596 |
| Fuel Tank..... | 468 | GROUND TERMINAL, REAR PLATFORM HARNESS..... | 598 |
| Fuel Tank Bottom Guard..... | 690 | GROUND, CAB..... | 624 |
| FUEL TRANSFER PUMP (3713)..... | 320 | GROUP, CHARGE PUMP DF180..... | 162 |
| FUEL, FAST FILL SYSTEM..... | 470 | GROUP, HOSE AND FITTING -DF180..... | 164 |
| FULL HEIGHT CAB DOORS..... | 732 | GROUP, INPUT -DF180..... | 134 |
| Full Height Cab With Doors And Opening Windows..... | 706 | GROUP, MAIN CASE DF180..... | 152, 154 |
| Fuses, Fuse Panel..... | 630 | GROUP, VALVE CONTROL DF180..... | 156 |
| Fuse Panel..... | 630 | GROUP, WET BRAKE DF180..... | 150 |
| FUSE PANEL DECAL..... | 622 | GROUP, YOKE 7C DF180..... | 160 |
| FUSE PANEL LABEL (ENGLISH, GRADE PRO)..... | 534 | GUARD, AUXILIARY CONTROLS (GRADE PRO)..... | 788 |
| FUSE PANEL LABEL (ENGLISH, STD CAB)..... | 532 | GUARD, BOTTOM..... | 690 |
| FUSE PANEL LABEL (FRENCH)..... | 536 | GUARD, FAN..... | 424 |
| FUSE PANEL LABEL (RUSSIAN)..... | 540 | GUARD, FRONT AXLE..... | 74 |
| FUSE PANEL LABEL (SPANISH)..... | 538 | GUARD, VALVE, TRANSMISSION..... | 846 |
| FUSE, ECU..... | 616 | | |
| G | | H | |
| GASKET KIT, CYLINDER HEAD REMOVAL (9901)..... | 276 | HARNESS, A/C AND HEATER WIRING..... | 818 |
| GASKET KIT, EGR VALVE (9901)..... | 272, 370 | HARNESS, BLADE IMPACT..... | 658 |
| GASKET KIT, ENGINE LONG BLOCK (9901)..... | 284 | HARNESS, CAB INTERIOR WIRING..... | 622 |
| GASKET KIT, REBUILD ENGINE (9901)..... | 278 | HARNESS, CAB INTERIOR WIRING (CONNECTORS)..... | 624, 626, 628 |
| GASKET, CYLINDER HEAD (5101)..... | 226 | HARNESS, CAB ROOF WIRING..... | 652 |
| GASKET, DOOR LATCH (FULL HEIGHT CAB)..... | 732 | HARNESS, DIESEL FIRED COOLANT HEATER (6090HDW01 / 6090HDW04)..... | 400 |
| GASKET, DOOR LATCH (LOW PROFILE CAB)..... | 730 | HARNESS, EH VALVE FRONT (GRADE PRO) (CONNECTORS)..... | 650 |
| GASKET, ENGINE AIR HEATER..... | 390 | HARNESS, EH VALVE REAR AND FRONT (GRADE PRO)..... | 646 |
| GASKET, HYDRAULIC RESERVOIR CLEAN OUT GASKET..... | 1014 | HARNESS, EH VALVE REAR (GRADE PRO) (CONNECTORS)..... | 648 |
| GASKET, ROCKER ARM COVER (1144)..... | 294 | HARNESS, ENGINE COMPARTMENT WORK LIGHTS..... | 584 |
| GASKET, ROTARY EJECTOR PRECLEANER (6068HDW75)..... | 446 | HARNESS, ENGINE FRAME (CONNECTORS)..... | 616 |
| GASKET, ROTARY EJECTOR PRECLEANER (6090HDW01 / 6090HDW04)..... | 444 | HARNESS, ENGINE WIRING (CONNECTORS) (6068HDW75)..... | 614 |
| GASKET, THERMOSTAT HOUSING (3926)..... | 322 | HARNESS, ENGINE WIRING (CONNECTORS) (6090HDW01)..... | 608, 610 |
| GAS VALVE, BLADE IMPACT ACCUMULATOR..... | 1112 | HARNESS, ENGINE WIRING (6068HDW75)..... | 612 |
| GAUGE, SIGHT, HYDRAULIC RESERVOIR..... | 1014 | HARNESS, ENGINE WIRING (6090HDW01)..... | 606 |
| GEARBOX, CIRCLE DRIVE..... | 1074 | HARNESS, FAN DOOR WIRING..... | 576 |
| GEARBOX, CIRCLE DRIVE WITH SLIP CLUTCH..... | 1076 | HARNESS, FLEX LOAD CONTROLLER POWER..... | 622 |
| GEARS, IDLE (UPPER AND LOWER) (3612)..... | 318 | HARNESS, FLEX LOAD CONTROLLER POWER (CONNECTORS)..... | 632 |
| GEAR SELECTOR, TRANSMISSION (GRADE PRO)..... | 114 | HARNESS, FRONT DRIVE/TURN LIGHTS WIRING..... | 594 |
| GEAR SELECTOR, TRANSMISSION (STANDARD CONTROLS)..... | 112 | HARNESS, FRONT DRIVE/TURN LIGHTS WIRING (CONNECTORS)..... | 604 |
| GEAR, FLYWHEEL RING 1530..... | 299 | HARNESS, FRONT PLATFORM..... | 594 |
| GEAR, OIL PUMP (5001)..... | 224 | HARNESS, FRONT PLATFORM (CONNECTORS)..... | 596 |
| GEAR, OIL PUMP (5024)..... | 338 | HARNESS, FRONT TILT CONSOLE WIRING (GRADE PRO)..... | 656 |
| GLASS, DOOR (FULL HEIGHT CAB)..... | 732 | HARNESS, FRONT TILT CONSOLE WIRING (STANDARD CONTROLS)..... | 654 |
| GLASS, DOOR (LOW PROFILE CAB)..... | 730 | HARNESS, GLOW PLUGS, WIRING (4330)..... | 326 |
| GLOBALTRACS™ TERMINAL (GTT)..... | 1016 | | |
| GLOW PLUGS (4330)..... | 326 | | |
| Glow Plug Wiring Harness..... | 398 | | |
| GRADE CONTROL WIRING HARNESS (GRADE PRO)..... | 636 | | |
| GRADE CONTROL WIRING HARNESS (GRADE PRO) (CONNECTORS)..... | 640 | | |
| GRADE CONTROL (IGC) COVER (FULL HEIGHT CAB)..... | 718, 720 | | |
| GRADE CONTROL (IGC) COVER (GRADE PRO)..... | 714, 716 | | |

Índice alfabético, continuación

| | Página | | Página |
|--|----------|---|------------|
| HARNESS, GRADE PRO ARMREST WIRING..... | 636 | HOSES, AIR COOLER (6068HDW75) (SERIAL NUMBER 626426-) | 422 |
| HARNESS, GRADE PRO ARMREST WIRING, LEFT (CONNECTORS)..... | 644 | HOSES, AIR COOLER (6068HDW75) (SERIAL NUMBER-626425)..... | 420 |
| HARNESS, GRADE PRO ARMREST WIRING, RIGHT (CONNECTORS)..... | 642 | HOSES, AIR COOLER (6090HDW01 / 6090HDW04)(SN 626426-).. | 414 |
| HARNESS, GRADE PRO CAB WIRING..... | 636 | HOSES, AIR COOLER (6090HDW01 / 6090HDW04)(SN-626425) .. | 412 |
| HARNESS, GRADE PRO CAB WIRING (CONNECTORS)..... | 638 | HOSES, ARTICULATION CYLINDER (STANDARD CONTROLS)... | 496 |
| HARNESS, HYDRAULIC WARMUP CIRCUIT..... | 1010 | HOSES, BLADE IMPACT (GRADE PRO)..... | 1110 |
| HARNESS, HYDRAULIC PUMP PRESSURE SENSOR JUMPER .. | 484 | HOSES, BLADE IMPACT (STANDARD CONTROLS)..... | 1108 |
| HARNESS, IGC (GRADE PRO)..... | 636 | HOSES, BLADE LIFT CYLINDER (GRADE PRO)..... | 1094 |
| HARNESS, IGC (GRADE PRO) (CONNECTORS)..... | 640 | HOSES, BLADE LIFT CYLINDER (STANDARD CONTROLS)..... | 1092 |
| HARNESS, JD LINK™ COMMUNICATION CONTROLLER..... | 1016 | HOSES, BLADE SIDE SHIFT CYLINDER (GRADE PRO)..... | 1098 |
| HARNESS, MACHINE INFORMATION GATEWAY (MIG)..... | 1018 | HOSES, BLADE SIDE SHIFT CYLINDER (STANDARD CONTROLS)..... | 1096 |
| HARNESS, MIDSTRUCTURE..... | 594 | HOSES, BLADE TILT CYLINDER (GRADE PRO)..... | 1098 |
| HARNESS, MIDSTRUCTURE (CONNECTORS)..... | 600 | HOSES, BLADE TILT CYLINDER (STANDARD CONTROLS)..... | 1096 |
| HARNESS, REAR PLATFORM..... | 594 | HOSES, BRAKE ACCUMULATOR | 522 |
| HARNESS, REAR PLATFORM (CONNECTORS)..... | 598 | HOSES, BRAKE VALVE..... | 522 |
| HARNESS, SNOW LIGHT WIRING..... | 586 | HOSES, CAB HEATER (6068HDW75)..... | 810 |
| HARNESS, STARTER JUMPER (6068HDW75)..... | 612 | HOSES, CAB HEATER (6090HDW01/6090HDW04) (W COOLANT HEATER)..... | 808 |
| HARNESS, STARTER JUMPER (6090HDW01)..... | 606 | HOSES, CAB HEATER (6090HDW01/6090HDW04) (W/O COOLANT HEATER)..... | 806 |
| HARNESS, TAIL LIGHT WIRING..... | 576 | HOSES, CIRCLE SIDE SHIFT CYLINDER (GRADE PRO)..... | 1106 |
| HARNESS, TRANSMISSION WIRING..... | 618 | HOSES, CIRCLE SIDE SHIFT CYLINDER (STANDARD CONTROLS)..... | 1104 |
| HARNESS, TRANSMISSION WIRING (CONNECTORS)..... | 620 | HOSES, DIFFERENTIAL COOLER..... | 402 |
| HARNESS, WHEEL LEAN SENSOR..... | 594 | HOSES, DIFFERENTIAL LOCK PUMP..... | 88 |
| HARNESS, WHEEL LEAN SENSOR (CONNECTORS)..... | 602 | HOSES, DIFFERENTIAL OIL COOLER (6068HDW75)(SERIAL NUMBER 626426-) | 422 |
| HARNESS, WIRING - ECU (8497)..... | 240 | HOSES, DIFFERENTIAL OIL COOLER (6068HDW75)(SERIAL NUMBER-626425)..... | 420 |
| HARNESS, WIRING, LICENSE PLATE LIGHT..... | 528 | HOSES, DIFFERENTIAL OIL COOLER (6090HDW01 / 6090HDW04)(SN 626426-)..... | 414 |
| HARNESS, WIRING, STROBE WARNING BEACON | 592 | HOSES, DIFFERENTIAL OIL COOLER (6090HDW01 / 6090HDW04)(SN-626425)..... | 412 |
| HEADLINER (FULL HEIGHT CAB)..... | 718, 720 | HOSES, ENGINE OIL DRAIN (6068HDW75)..... | 544 |
| HEADLINER (GRADE PRO)..... | 714, 716 | HOSES, ENGINE OIL DRAIN (6090HDW01 / 6090HDW04)..... | 542 |
| HEADLINER (LOW PROFILE CAB - STD)..... | 710, 712 | HOSES, FAN DRIVE..... | 430 |
| HEADREST (DELUXE)..... | 794 | HOSES, FRONT SCARIFIER..... | 1146, 1148 |
| HEADREST (GRADE PRO)..... | 798 | HOSES, FUEL (6068HDW75)..... | 458 |
| HEADREST (STD)..... | 790 | HOSES, FUEL (6090HDW01 / 6090HDW04)..... | 456 |
| HEAD BOLT KIT, CYLINDER (9901)..... | 262 | HOSES, HYDRAULIC OIL COOLER..... | 404 |
| HEAD KIT, CYLINDER (9901)..... | 266 | HOSES, MID-SCARIFIER..... | 1154 |
| HEAD REMOVAL GASKET KIT, CYLINDER (9901)..... | 276 | HOSES, PARK BRAKE..... | 526 |
| HEAD, HYDRAULIC FILTER..... | 1012 | HOSES, RADIATOR (6068HDW75) (SERIAL NUMBER 626426-)..... | 422 |
| HEAD, TRANSMISSION FILTER..... | 132 | HOSES, RADIATOR (6068HDW75) (SERIAL NUMBER-626425)..... | 420 |
| Heated Mirror..... | 860 | HOSES, RADIATOR (6090HDW01 / 6090HDW04) (SN 626426-) .. | 414 |
| HEATED SEAT SWITCH (DELUXE)..... | 794 | HOSES, RADIATOR (6090HDW01 / 6090HDW04) (SN-626425) | 412 |
| HEATED SEAT SWITCH (GRADE PRO)..... | 798 | HOSES, RADIATOR (6090HDW01 / 6090HDW04) (SN-626425) | 412 |
| Heater and Air Conditioner Filter, Filter Housing, and Cover | 814 | HOSES, RADIATOR (6090HDW01 / 6090HDW04) (SN-626425) | 412 |
| Heater and Air Conditioning Ducting..... | 812 | HOSES, SCARIFIER (FRONT)..... | 1146, 1148 |
| HEATER BLOWER MOTOR AND SWITCH..... | 820 | HOSES, SCARIFIER (MIDDLE)..... | 1154 |
| HEATER CONTROL CABLE..... | 818 | HOSES, SERVICE BRAKE..... | 522 |
| HEATER CONTROL VALVE..... | 820 | HOSES, STEERING VALVE (GRADE PRO)..... | 502 |
| HEATER HOSES, CAB (6068HDW75)..... | 810 | HOSES, STEERING VALVE (STANDARD CONTROLS)..... | 500 |
| HEATER HOSES, CAB (6090HDW01/6090HDW04) W/O COOLANT HEATER)..... | 806 | HOSES, TRANSMISSION..... | 124 |
| HEATER HOSES, CAB (6090HDW01/6090HDW04) (W COOLANT HEATER)..... | 808 | HOSES, TRANSMISSION COOLING..... | 406 |
| HEATER PLUG (2699)..... | 195 | HOSES, TRANSMISSION OIL COOLER (6068HDW75)(SERIAL NUMBER 626426-) | 422 |
| HEATER, COOLANT (120V) (6068HDW75)..... | 396 | HOSES, TRANSMISSION OIL COOLER (6068HDW75)(SERIAL NUMBER-626425)..... | 420 |
| HEATER, COOLANT (120V) (6090HDW01 / 6090HDW04) | 394 | HOSES, TRANSMISSION OIL COOLER (6090HDW01 / 6090HDW04)(SN 626426-)..... | 414 |
| HEATER, COOLANT (2694)..... | 309 | HOSES, TRANSMISSION OIL COOLER (6090HDW01 / 6090HDW04)(SN-626425)..... | 412 |
| HEATER, COOLANT, DIESEL FIRED (6090HDW01 / 6090HDW04)..... | 400 | HOSES, TRANSMISSION OIL COOLER (6090HDW01 / 6090HDW04) (SN-626425)..... | 412 |
| HEATER, ENGINE AIR..... | 390 | HOSES, WHEEL LEAN CYLINDER (GRADE PRO)..... | 506 |
| HEATER, ENGINE (2697)..... | 194 | HOSES, WHEEL LEAN CYLINDER (STANDARD CONTROLS)..... | 504 |
| Heating and Air Conditioning Lines and Controls..... | 818 | HOSE, CIRCLE ROTATE MOTOR (GRADE PRO)..... | 1102 |
| HIGH PRESSURE, COMMON RAIL SYSTEM (169Z)..... | 300 | HOSE, CIRCLE ROTATE MOTOR (STANDARD CONTROLS)..... | 1100 |
| HINGE, DOOR, SERVICE..... | 832 | HOSE, DIFFERENTIAL LOCK FILTER TO DIFFERENTIAL LOCK VALVE..... | 88 |
| HITCH COUPLING..... | 1136 | HOSE, DIFFERENTIAL LOCK PUMP TO DIFFERENTIAL LOCK VALVE..... | 88 |
| HITCH, REAR..... | 552 | HOSE, FAST FILL FUEL TANK BREATHER..... | 470 |
| HI-LOW BEAM SWITCH..... | 676 | HOSE, FUEL TANK BREATHER..... | 468 |
| HI-LOW BEAM SWITCH (GRADE PRO)..... | 678 | HOSE, HYDRAULIC LOAD SENSE (GRADE PRO)..... | 1008 |
| HOLDER, OPERATORS MANUAL (GRADE PRO)..... | 714, 716 | HOSE, HYDRAULIC LOAD SENSE (STD CONTROLS)..... | 1006 |
| HOLD OPEN ROD, FAN DOOR..... | 424 | HOSE, HYDRAULIC, MAIN HYD COLD START DISCONNECT | 1002 |
| Hood and Hood Supports (Engine 6068HDW75)..... | 830 | HOSE, MAIN HYDRAULIC PUMP LOAD SENSE (GRADE PRO).. | 1008 |
| Hood and Hood Supports (6090HDW01 / 6090HDW04) | 828 | HOSE, MAIN HYDRAULIC PUMP LOAD SENSE (STD CONTROLS)..... | 1006 |
| HOOK BOLT, BATTERY (1000 CCA (6068HDW75)..... | 558 | HOSE, PARK BRAKE VALVE TO TRANSMISSION..... | 526 |
| HOOK BOLT, BATTERY (1000 CCA) (6090HDW01 / 6090HDW04) | 554 | HOSE, REAR SCARIFIER..... | 1150, 1152 |
| HOOK BOLT, BATTERY (1400 CCA (6068HDW75)..... | 560 | HOSE, RIPPER..... | 1150, 1152 |
| HOOK BOLT, BATTERY (1400 CCA) (6090HDW01 / 6090HDW04) | 556 | | |
| HOOK, COAT (FULL HEIGHT CAB)..... | 718, 720 | | |
| HOOK, COAT (GRADE PRO)..... | 714, 716 | | |
| HOOK, COAT (LOW PROFILE CAB - STD)..... | 710, 712 | | |
| Horn..... | 864 | | |
| HORN SWITCH..... | 676 | | |
| HORN SWITCH (GRADE PRO)..... | 636 | | |
| HOSES, AIR CONDITIONING (6068HDW75)..... | 824 | | |
| HOSES, AIR CONDITIONING (6090HDW01 / 6090HDW04)..... | 822 | | |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> |
|---|---------------|
| HOSE, ROTARY MANIFOLD (GRADE PRO)..... | 1102 |
| HOSE, SADDLE LOCK PIN..... | 1114 |
| HOSE, SECONDARY STEERING..... | 484 |
| HOSE, VENTILATING (2943)..... | 312 |
| HOSE, VENT (2901)..... | 198 |
| HOUSING COVER, FRONT (FULL HEIGHT CAB)..... | 718, 720 |
| HOUSING COVER, FRONT (GRADE PRO)..... | 714, 716 |
| HOUSING COVER, FRONT (LOW PROFILE CAB - STD)..... | 710, 712 |
| HOUSING COVER, REAR (FULL HEIGHT CAB)..... | 718, 720 |
| HOUSING COVER, REAR (GRADE PRO)..... | 714, 716 |
| HOUSING COVER, REAR (LOW PROFILE CAB - STD)..... | 710, 712 |
| HOUSING, AXLE..... | 68 |
| HOUSING, CAB FRESH AIR FILTER..... | 814 |
| HOUSING, CIRCLE DRIVE MOTOR..... | 1126 |
| HOUSING, FINAL DRIVE..... | 64 |
| HOUSING, FLYWHEEL (1412)..... | 181 |
| HOUSING, FLYWHEEL (1423)..... | 298 |
| HOUSING, FRONT ASSEMBLY..... | 166 |
| HOUSING, GRILLE..... | 692 |
| HOUSING, HVAC..... | 820 |
| HOUSING, INPUT..... | 98 |
| HOUSING, OIL FILTER (5912)..... | 230 |
| HOUSING, OIL PUMP (5001)..... | 224 |
| HOUSING, OIL PUMP (5024)..... | 338 |
| HOUSING, PIVOT..... | 64 |
| HOUSING, RADIO/DOMELIGHT (FULL HEIGHT CAB)..... | 718, 720 |
| HOUSING, RADIO/DOMELIGHT (GRADE PRO)..... | 714, 716 |
| HOUSING, RADIO/DOMELIGHT (LOW PROFILE CAB - STD)..... | 710, 712 |
| HOUSING, REAR ASSEMBLY..... | 168 |
| HOUSING, REAR GRILLE..... | 692 |
| HOUSING, SIDE CONSOLE (GRADE PRO)..... | 758 |
| HOUSING, SIDE CONSOLE (STD CONTROLS)..... | 756 |
| HOUSING, TANDEM..... | 60 |
| HOUSING, THERMOSTAT (3903)..... | 206 |
| HOUSING, THERMOSTAT (3926)..... | 322 |
| HUB, FRONT WHEEL (LEFT)..... | 82 |
| HUB, FRONT WHEEL (RIGHT)..... | 80 |
| HVAC DUCTS..... | 812 |
| HVAC Module Components..... | 820 |
| HVAC Powered Precleaner..... | 816 |
| HYDRAULICS, REAR STEERING (GRADE PRO)..... | 498 |
| HYDRAULICS, STEERING (STANDARD CONTROLS)..... | 492 |
| HYDRAULIC CYLINDER, ARTICULATION COMPONENTS..... | 514 |
| HYDRAULIC CYLINDER, ARTICULATION PINS..... | 512 |
| HYDRAULIC CYLINDER, BLADE LIFT..... | 1116 |
| HYDRAULIC CYLINDER, BLADE SLIDE..... | 1118 |
| HYDRAULIC CYLINDER, BLADE TILT..... | 1120 |
| HYDRAULIC CYLINDER, CIRCLE SIDE SHIFT..... | 1122 |
| HYDRAULIC CYLINDER, MID MOUNTED SCARIFIER..... | 1176 |
| HYDRAULIC CYLINDER, REAR RIPPER/ SCARIFIER..... | 1174 |
| HYDRAULIC CYLINDER, SCARIFIER (BREAKDOWN)..... | 1172 |
| HYDRAULIC CYLINDER, STEERING..... | 508 |
| HYDRAULIC CYLINDER, STEERING, COMPONENTS..... | 510 |
| HYDRAULIC CYLINDER, WHEEL LEAN..... | 516 |
| HYDRAULIC CYLINDER, WHEEL LEAN COMPONENTS..... | 518 |
| Hydraulic Fan Drive Motor..... | 428 |
| HYDRAULIC FILTER LABEL (ENGLISH)..... | 530 |
| HYDRAULIC FILTER LABEL (FRENCH)..... | 536 |
| HYDRAULIC FILTER LABEL (RUSSIAN)..... | 540 |
| HYDRAULIC FILTER LABEL (SPANISH)..... | 538 |
| HYDRAULIC HOSES, AUX FIFTH FUNCTION, (GRADE PRO)..... | 1158 |
| HYDRAULIC HOSES, AUX FIFTH FUNCTION, (STANDARD)..... | 1156 |
| HYDRAULIC HOSES, AUX SIXTH FUNCTION, (GRADE PRO)..... | 1162 |
| HYDRAULIC HOSES, AUX SIXTH FUNCTION, (STANDARD)..... | 1160 |
| HYDRAULIC HOSES, FIFTH FUNCTION AUX, (GRADE PRO)..... | 1158 |
| HYDRAULIC HOSES, FIFTH FUNCTION AUX, (STANDARD)..... | 1156 |
| HYDRAULIC HOSES, REAR AUX (SIXTH FUNCTION) (GRADE PRO)..... | 1170 |
| HYDRAULIC HOSES, REAR AUX (SIXTH FUNCTION) (STANDARD CONTROLS)..... | 1168 |
| HYDRAULIC HOSES, SIXTH FUNCTION AUX, (GRADE PRO)..... | 1162 |
| HYDRAULIC HOSES, SIXTH FUNCTION AUX, (STANDARD)..... | 1160 |
| Hydraulic Load Sense Hoses (Grade Pro)..... | 1008 |
| Hydraulic Load Sense Hoses (Standard Controls)..... | 1006 |
| Hydraulic Oil Cooler Bypass Valve..... | 952 |
| Hydraulic Oil Cooler Hoses..... | 404 |
| HYDRAULIC OIL DIAGNOSTIC FITTING (6068HDW75)..... | 548 |
| HYDRAULIC OIL DIAGNOSTIC FITTING (6090HDW01 / 6090HDW04)..... | 546 |
| HYDRAULIC OIL LABEL..... | 530 |
| HYDRAULIC OIL LEVEL LABEL (ENGLISH)..... | 530 |
| HYDRAULIC OIL LEVEL LABEL (FRENCH)..... | 536 |
| HYDRAULIC OIL LEVEL LABEL (RUSSIAN)..... | 540 |
| HYDRAULIC OIL LEVEL LABEL (SPANISH)..... | 538 |
| HYDRAULIC PLUMBING, MAIN (GRADE PRO)..... | 1000 |
| HYDRAULIC PLUMBING, MAIN (STD CONTROLS)..... | 998 |
| HYDRAULIC PUMP DISCONNECT, COLD START..... | 1002 |
| HYDRAULIC PUMP, MAIN..... | 878 |
| Hydraulic Reservoir..... | 1014 |
| HYDRAULIC WARMUP CIRCUIT..... | 1010 |
| HYDRUALIC PUMP PRESSURE SENSOR..... | 484 |
| HYDRUALIC PUMP PRESSURE SENSOR JUMPER HARNESS..... | 484 |
| I | |
| IDLER, ALTERNATOR, 100AMP (6068HDW75)..... | 566 |
| IDLER, ALTERNATOR, 130AMP (6068HDW75)..... | 568 |
| IDLE GEARS (UPPER AND LOWER) (3612)..... | 318 |
| IGC ALTERNATE MOUNTING BRACKET FOR CAB DISPLAY MONITOR..... | 674 |
| IGC CONTROLS, LEFT 4 FUNCTION (EH) (GRADE PRO)..... | 782 |
| IGC CONTROLS, LEFT 5 FUNCTION (EH) (GRADE PRO)..... | 786 |
| IGC CONTROLS, RIGHT 4 FUNCTION (EH) (GRADE PRO)..... | 780 |
| IGC CONTROLS, RIGHT 5 FUNCTION (EH) (GRADE PRO)..... | 784 |
| IGNITION RELAY..... | 622 |
| Inching Pedal (XXXXXX -)..... | 478 |
| Inching Pedal (- XXXXXX)..... | 476 |
| INDICATOR SWITCH, SADDLE LOCKING PIN..... | 1124 |
| INJECTION NOZZLE & WIRING HARNESS (169Z)..... | 300 |
| Injection Pump, Fuel..... | 184 |
| Injector, Fuel..... | 184 |
| INLET SECTION, FRONT ELECTROHYDRAULIC CONTROL VALVE (GRADE PRO)..... | 992 |
| INLET SECTION, LEFT MAIN HYDRAULIC CONTROL VALVE (STD)..... | 918 |
| INLET SECTION, REAR ELECTROHYDRAULIC CONTROL VALVE (GRADE PRO) (BREAKDOWN)..... | 990 |
| INLET SECTION, RIGHT MAIN HYDRAULIC CONTROL VALVE (STD)..... | 916 |
| Inlet, Water Pump..... | 229 |
| INLET, WATER PUMP (5722)..... | 343 |
| INPUT GROUP (YZ103439)..... | 134 |
| INPUT HOUSING WITH PARK BRAKE COVER (RE46977)..... | 98 |
| INPUT YOKE 7C (RE35714)..... | 94 |
| INSERTS, BLADE (STANDARD)..... | 1072 |
| INSERTS, CIRCLE (EXTENDED LIFE)..... | 1070 |
| INSERTS, CIRCLE (STANDARD) (WITHOUT SLIP CLUTCH)..... | 1066 |
| INSERTS, CIRCLE (STANDARD) (WITH SLIP CLUTCH)..... | 1068 |
| INSTRUMENT PANEL, SIDE CONSOLE 4WD (STD CONTROLS)..... | 756 |
| INTAKE MANIFOLD AND GASKET (1797)..... | 302 |
| INTAKE VALVE (5101)..... | 226 |
| INTAKE VALVE (5128)..... | 340 |
| Intake, Air..... | 210 |
| INTAKE, AIR (1701)..... | 186 |
| INTAKE, OIL PUMP (1909)..... | 188 |
| Integrated Grade Control Cab Harness..... | 640 |
| Integrated Grade Control Mast Mounts (3/4 in. Hardware)..... | 1056 |
| Integrated Grade Control Mast Mounts (5/8 in. Hardware)..... | 1054 |
| INTEGRATED GRADE CONTROL WIRING HARNESS (GRADE PRO)..... | 636 |
| INTEGRATED GRADE CONTROL (IGC) COVER (FULL HEIGHT CAB)..... | 718, 720 |
| INTEGRATED GRADE CONTROL (IGC) COVER (GRADE PRO)..... | 714, 716 |
| INTEGRATED GRADE CONTROL (IGC) COVER (LOW PROFILE CAB - STD)..... | 710, 712 |
| Interior Dome Light..... | 590 |
| Interior Rear View Mirror..... | 856 |
| IN-LINE FUEL FILTER (6068HDW75)..... | 458 |
| IN-LINE FUEL FILTER (6090HDW01 / 6090HDW04)..... | 456 |
| ISOLATORS, CAB..... | 708 |
| ISOLATORS, ENGINE MOUNTING (6068HDW75)..... | 454 |
| ISOLATORS, ENGINE MOUNTING (6090HDW01 / 6090HDW04)..... | 452 |
| ISOLATOR, TORSIONAL..... | 118 |
| ISO 9001 LABEL..... | 530 |
| J | |
| JD LINK™ COMMUNICATION CONTROLLER..... | 1016 |
| JOINT, DRIVESHAFT..... | 72 |
| JOYSTICKS, LEFT 4 FUNCTION (EH) (GRADE PRO)..... | 782 |
| JOYSTICKS, LEFT 5 FUNCTION (EH) (GRADE PRO)..... | 786 |
| JOYSTICKS, RIGHT 4 FUNCTION (EH) (GRADE PRO)..... | 780 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> | | |
|--|---------------|---|------|
| JOYSTICKS, RIGHT 5 FUNCTION (EH) (GRADE PRO) | 784 | Kit, Right Moldboard Extension (27 in. With 3/4 in. Hardware)..... | 1050 |
| JOYSTICK ARMREST ADJUSTMENT LABEL (ENGLISH, GRADE PRO) | 534 | Kit, Right Moldboard Extension (27 in. With 5/8 in. Hardware)..... | 1046 |
| JOYSTICK ARMREST ADJUSTMENT LABEL (FRENCH)..... | 536 | KIT, RIPPER CONTROL VALVE KIT (FIFTH FUNCTION LH)..... | 936 |
| JOYSTICK ARMREST ADJUSTMENT LABEL (SPANISH)..... | 538 | KIT, RIPPER/REAR SCARIFIER HYDRAULIC HOSES | 1152 |
| JOYSTICK FUNCTIONS LABEL (ENGLISH, GRADE PRO)..... | 534 | KIT, SCARIFIER CONTROL VALVE KIT (FIFTH FUNCTION RH) | 934 |
| JOYSTICK STEERING LABEL (ENGLISH, GRADE PRO)..... | 534 | KIT, SCARIFIER CYLINDER SEAL..... | 1172 |
| JUMPER HARNESS, STARTER (6068HDW75)..... | 612 | KIT, SCARIFIER HYDRAULIC HOSE (FRONT)..... | 1148 |
| JUMPER HARNESS, STARTER (6090HDW01)..... | 606 | KIT, SEAL - FUEL INJECTOR CONNECTOR 9901 (HDW01)..... | 261 |
| JUMPER, HYDRUALIC PUMP PRESSURE SENSOR..... | 484 | KIT, SEAL, ARTICULATION CYLINDER..... | 514 |
| JUMPER, SNOW LIGHT WIRING HARNESS | 586 | KIT, SEAL, MAIN HYDRAULIC PUMP..... | 878 |
| | | KIT, SECONDARY STEERING..... | 482 |
| K | | KIT, SERVICE BRAKE VALVE SEAL..... | 520 |
| KEY (ENGLISH, GRADE PRO)..... | 534 | KIT, STARTER MOTOR (9901)..... | 282 |
| KEY (STD CAB)..... | 532 | KIT, STEERING VALVE SEAL (STANDARD CONTROLS)..... | 500 |
| KEY, DOOR (ENGLISH, GRADE PRO)..... | 534 | KIT, THRUST BEARING (9901)..... | 364 |
| KEY, DOOR (STD CAB)..... | 532 | KNOB, AUX W/O FLOAT CONTROL LINKAGE (SEVENTH FUNCTION LEFT)..... | 774 |
| KEY, FAN DRIVE MOTOR..... | 428 | KNOB, AUX W/ FLOAT CONTROL LINKAGE (SIXTH FUNCTION LEFT)..... | 770 |
| KIT SEAL, REVERSING FAN VALVE..... | 432 | KNOB, AUX W/ FLOAT CONTROL LINKAGE (SIXTH FUNCTION RH)..... | 768 |
| KIT, AUX CONTROL VALVE KIT W/O FLOAT (SEVENTH FUNCTION LH)..... | 944 | KNOB, RIPPER CONTROL LINKAGE (FIFTH FUNCTION LH)..... | 766 |
| KIT, AUX CONTROL VALVE KIT W/O FLOAT (SEVENTH FUNCTION RH)..... | 942 | KNOB, SCARIFIER CONTROL LINKAGE (FIFTH FUNCTION RIGHT)..... | 764 |
| KIT, AUX CONTROL VALVE KIT W/ FLOAT (SIXTH FUNCTION LH)..... | 940 | KNOB, SEVENTH FUNCTION CONTROL LINKAGE (RIGHT) (AUX W/O FLOAT)..... | 772 |
| KIT, AUX CONTROL VALVE KIT W/ FLOAT (SIXTH FUNCTION RH)..... | 938 | KNOB, STANDARD CONTROL LINKAGES..... | 762 |
| KIT, A/C PULLEY..... | 826 | KNOB, TRANSMISSION GEAR SELECTOR (GRADE PRO)..... | 114 |
| KIT, A/C SERVICE..... | 826 | KNOB, TRANSMISSION GEAR SELECTOR (STANDARD CONTROLS)..... | 112 |
| KIT, A/C SHAFT SEAL..... | 826 | | |
| KIT, BEACON BRACKET..... | 588 | L | |
| KIT, BEARING (9901)..... | 361, 362, 363 | LABELS AND TRADEMARKS, ENGLISH..... | 530 |
| KIT, BLADE IMPACT SYSTEM (GRADE PRO)..... | 1084 | LABELS AND TRADEMARKS, ENGLISH (GRADE PRO CAB)..... | 534 |
| KIT, BLADE IMPACT SYSTEM (STANDARD CONTROLS)..... | 1082 | LABELS AND TRADEMARKS, ENGLISH (STANDARD CAB)..... | 532 |
| KIT, BLADE LIFT CYLINDER SEAL..... | 1116 | LABELS AND TRADEMARKS, FRENCH..... | 536 |
| KIT, BLADE SLIDE CYLINDER SEAL..... | 1118 | LABELS AND TRADEMARKS, SPANISH..... | 538 |
| KIT, BLADE TILT CYLINDER SEAL..... | 1120 | LABELS (RUSSIAN)..... | 540 |
| KIT, BOTTOM GUARD..... | 690 | LABEL, ACCUMULATOR (FRENCH)..... | 536 |
| KIT, CAMSHAFT (9901)..... | 264 | LABEL, ACCUMULATOR (RUSSIAN)..... | 540 |
| KIT, CIRCLE DRIVE MOTOR SEAL..... | 1126 | LABEL, ACCUMULATOR (SPANISH)..... | 538 |
| KIT, CIRCLE SIDE SHIFT CYLINDER SEAL..... | 1122 | LABEL, AIR CLEANER (ENGLISH)..... | 530 |
| KIT, CONNECTING ROD BEARING (9901)..... | 250 | LABEL, AIR CLEANER (FRENCH)..... | 536 |
| KIT, CYLINDER HEAD BOLT (9901)..... | 262 | LABEL, AIR CLEANER (RUSSIAN)..... | 540 |
| KIT, CYLINDER HEAD (9901)..... | 266 | LABEL, AIR CLEANER (SPANISH)..... | 538 |
| KIT, CYLINDER LINER PACKING (9901)..... | 263 | LABEL, ARTICULATION LOCK..... | 530 |
| KIT, CYLINDER LINER (9901)..... | 372 | LABEL, AXLE/GEARBOX OIL..... | 530 |
| KIT, DIESEL FIRED COOLANT HEATER (6090HDW01 / 6090HDW04)..... | 400 | LABEL, BATTERY DISCONNECT (FRENCH)..... | 536 |
| KIT, EGR SERVICE (9901)..... | 274 | LABEL, BATTERY DISCONNECT (SPANISH)..... | 538 |
| KIT, EGR VALVE GASKET (9901)..... | 272 | LABEL, BATTERY DISCONNECT (1000 CCA) (6068HDW75)..... | 558 |
| KIT, ELECTROHYDRAULIC AUXILIARY CONTROL VALVE (GRADE PRO)..... | 996 | LABEL, BATTERY DISCONNECT (1000 CCA) (6090HDW01 / 6090HDW04)..... | 554 |
| KIT, ENGINE GASKET 9901..... | 368 | LABEL, BATTERY DISCONNECT (1400 CCA) (6068HDW75)..... | 560 |
| KIT, ENGINE LONG BLOCK GASKET (9901)..... | 284 | LABEL, BATTERY DISCONNECT (1400 CCA) (6090HDW01 / 6090HDW04)..... | 556 |
| KIT, ENGINE OVERHAUL..... | 386 | LABEL, BATTERY DISCONNECT (RUSSIAN)..... | 540 |
| KIT, ENGINE OVERHAUL (9902)..... | 280 | LABEL, BLADE IMPACT ACCUMULATOR..... | 1112 |
| KIT, EXHAUST MANIFOLD REMOVAL (9901)..... | 271 | LABEL, BLADE IMPACT ACCUMULATOR (GRADE PRO FIELD KIT)..... | 1084 |
| KIT, FAST FILL FUEL SYSTEM..... | 470 | LABEL, BLADE IMPACT ACCUMULATOR (STANDARD CONTROLS FIELD KIT)..... | 1082 |
| KIT, FILTER O-RING (9901)..... | 379 | LABEL, BRAKE ACCUMULATOR..... | 524 |
| KIT, FRONT FENDERS FIELD..... | 850 | LABEL, BRAKE COVER (ENGLISH)..... | 530 |
| KIT, FRONT MOUNTED DOZER BLADE..... | 1144 | LABEL, BRAKE COVER (FRENCH)..... | 536 |
| KIT, FRONT MOUNTED SCARIFIER..... | 1128 | LABEL, BRAKE COVER (RUSSIAN)..... | 540 |
| KIT, FRONT STEERING CYLINDER SEAL..... | 510 | LABEL, BRAKE COVER (SPANISH)..... | 538 |
| KIT, FUEL FILTER ELEMENT SERVICE (9901)..... | 268 | LABEL, CAUTION SHUTDOWN (ENGLISH, GRADE PRO)..... | 534 |
| KIT, FUEL INJECTION NOZZLE SERVICE (9901)..... | 374 | LABEL, CAUTION SHUTDOWN (ENGLISH, STD CAB)..... | 532 |
| KIT, HYDRAULIC WARMUP CIRCUIT..... | 1010 | LABEL, CAUTION SHUTDOWN (FRENCH)..... | 536 |
| KIT, INJECTION NOZZLE (9901)..... | 374 | LABEL, CAUTION SHUTDOWN (RUSSIAN)..... | 540 |
| Kit, Left Moldboard Extension (24 in. With 5/8 in. Hardware)..... | 1044 | LABEL, CAUTION SHUTDOWN (SPANISH)..... | 538 |
| Kit, Left Moldboard Extension (27 in. With 3/4 in. Hardware)..... | 1052 | LABEL, CIRCUIT BREAKER (ENGLISH)..... | 530 |
| Kit, Left Moldboard Extension (27 in. With 5/8 in. Hardware)..... | 1048 | LABEL, CIRCUIT BREAKER (FRENCH)..... | 536 |
| KIT, MAIN BEARING (9901)..... | 249 | LABEL, CIRCUIT BREAKER (RUSSIAN)..... | 540 |
| KIT, MID MOUNTED SCARIFIER CYLINDER SEAL..... | 1176 | LABEL, CIRCUIT BREAKER (SPANISH)..... | 538 |
| KIT, ONE HAND BLADE LIFT CONTROL..... | 776 | LABEL, CLEANOUT COVER (ENGLISH)..... | 530 |
| KIT, ONE HAND BLADE LIFT CONTROL AND VALVE..... | 946 | LABEL, CLEANOUT COVER (FRENCH)..... | 536 |
| KIT, PISTON RING (9901)..... | 270, 380 | LABEL, CLEANOUT COVER (RUSSIAN)..... | 540 |
| KIT, PISTON-LINER (9901)..... | 260 | LABEL, CLEANOUT COVER (SPANISH)..... | 538 |
| KIT, REAR FENDERS..... | 852 | LABEL, DIFFERENTIAL FILTER (ENGLISH)..... | 530 |
| KIT, REAR HITCH..... | 552 | LABEL, DIFFERENTIAL FILTER (FRENCH)..... | 536 |
| KIT, REAR RIPPER/SCARIFIER..... | 1132 | | |
| KIT, REAR RIPPER/SCARIFIER CYLINDER SEAL..... | 1174 | | |
| Kit, Right Moldboard Extension (24 in. With 5/8 in. Hardware)..... | 1042 | | |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> | | |
|--|---------------|--|------|
| LABEL, DIFFERENTIAL FILTER (RUSSIAN)..... | 540 | LABEL, START AND STOP PROCEDURE (ENGLISH, GRADE PRO)..... | 534 |
| LABEL, DIFFERENTIAL FILTER (SPANISH)..... | 538 | LABEL, START AND STOP PROCEDURE (ENGLISH, STD CAB)..... | 532 |
| LABEL, DIFFERENTIAL LOCK SWITCH..... | 676 | LABEL, START/STOP PROCEDURE (FRENCH)..... | 536 |
| LABEL, DIFFERENTIAL LOCK (ENGLISH, GRADE PRO)..... | 534 | LABEL, START/STOP PROCEDURE (RUSSIAN)..... | 540 |
| LABEL, ENGINE COMPARTMENT WORK LIGHTS SWITCH..... | 584 | LABEL, START/STOP PROCEDURE (SPANISH)..... | 538 |
| LABEL, ENGINE COOLANT (6068HDW75) (SERIAL NUMBER 626426-)..... | 422 | LABEL, TIE DOWN..... | 530 |
| LABEL, ENGINE COOLANT (6068HDW75) (SERIAL NUMBER-626425)..... | 420 | LABEL, TRANSMISSION FILTER (ENGLISH)..... | 530 |
| LABEL, ENGINE COOLANT (6090HDW01 / 6090HDW04)(SN 626426-)..... | 414 | LABEL, TRANSMISSION FILTER (FRENCH)..... | 536 |
| LABEL, ENGINE COOLANT (6090HDW01 / 6090HDW04)(SN-626425)..... | 412 | LABEL, TRANSMISSION FILTER (RUSSIAN)..... | 540 |
| LABEL, FUSE PANEL..... | 622 | LABEL, TRANSMISSION FILTER (SPANISH)..... | 538 |
| LABEL, FUSE PANEL (ENGLISH, GRADE PRO)..... | 534 | LABEL, TRANSMISSION OIL..... | 530 |
| LABEL, FUSE PANEL (ENGLISH, STD CAB)..... | 532 | LABEL, TRANSMISSION OIL LEVEL (ENGLISH)..... | 530 |
| LABEL, FUSE PANEL (FRENCH)..... | 536 | LABEL, TRANSMISSION OIL LEVEL (FRENCH)..... | 536 |
| LABEL, FUSE PANEL (RUSSIAN)..... | 540 | LABEL, TRANSMISSION OIL LEVEL (RUSSIAN)..... | 540 |
| LABEL, FUSE PANEL (SPANISH)..... | 538 | LABEL, TRANSMISSION OIL LEVEL (SPANISH)..... | 538 |
| LABEL, GRAY CIRCLE (FULL HEIGHT CAB)..... | 718, 720 | LABEL, WARNING ARTICULATION (ENGLISH)..... | 530 |
| LABEL, HVAC CONTROLS..... | 818 | LABEL, WARNING ARTICULATION (FRENCH)..... | 536 |
| LABEL, HYDRAULIC FILTER (ENGLISH)..... | 530 | LABEL, WARNING ARTICULATION (RUSSIAN)..... | 540 |
| LABEL, HYDRAULIC FILTER (FRENCH)..... | 536 | LABEL, WARNING ARTICULATION (SPANISH)..... | 538 |
| LABEL, HYDRAULIC FILTER (RUSSIAN)..... | 540 | LABEL, WARNING SEAT BELT (ENGLISH, GRADE PRO)..... | 534 |
| LABEL, HYDRAULIC FILTER (SPANISH)..... | 538 | LABEL, WARNING SEAT BELT (ENGLISH, STD CAB)..... | 532 |
| LABEL, HYDRAULIC OIL..... | 530 | LABEL, WARNING SEAT BELT (FRENCH)..... | 536 |
| LABEL, HYDRAULIC OIL LEVEL (ENGLISH)..... | 530 | LABEL, WARNING SEAT BELT (RUSSIAN)..... | 540 |
| LABEL, HYDRAULIC OIL LEVEL (FRENCH)..... | 536 | LABEL, WARNING SEAT BELT (SPANISH)..... | 538 |
| LABEL, HYDRAULIC OIL LEVEL (RUSSIAN)..... | 540 | LABEL, 4WD INSTRUMENT PANEL (ENGLISH, GRADE PRO)..... | 534 |
| LABEL, HYDRAULIC OIL LEVEL (SPANISH)..... | 538 | LABEL, 4WD INSTRUMENT PANEL (FRENCH)..... | 536 |
| LABEL, ISO 9001 REGISTERED..... | 530 | LABEL, 4WD INSTRUMENT PANEL (RUSSIAN)..... | 540 |
| LABEL, JOYSTICK ARMREST ADJUSTMENT (ENGLISH, GRADE PRO)..... | 534 | LABEL, 4WD INSTRUMENT PANEL (SPANISH)..... | 538 |
| LABEL, JOYSTICK ARMREST ADJUSTMENT (FRENCH)..... | 536 | LABEL, 4WD INSTRUMENT PANEL, SIDE CONSOLE (STD CONTROLS)..... | 756 |
| LABEL, JOYSTICK ARMREST ADJUSTMENT (SPANISH)..... | 538 | LABEL, 6WD INSTRUMENT PANEL (FRENCH)..... | 536 |
| LABEL, JOYSTICK FUNCTIONS (ENGLISH, GRADE PRO)..... | 534 | LABEL, 6WD INSTRUMENT PANEL (RUSSIAN)..... | 540 |
| LABEL, JOYSTICK STEERING (ENGLISH, GRADE PRO)..... | 534 | LABEL, 6WD INSTRUMENT PANEL (SPANISH)..... | 538 |
| LABEL, JOYSTICK STEERING (GRADE PRO)..... | 782 | LAMPS, LED TAIL AND SIGNAL..... | 576 |
| LABEL, JOYSTICK STEERING 5 FUNCTION (GRADE PRO)..... | 786 | LATCH, DOOR (FULL HEIGHT CAB)..... | 732 |
| LABEL, LEAPING DEER..... | 530 | LATCH, DOOR (LOW PROFILE CAB)..... | 730 |
| LABEL, LIFT AND TIE DOWN (RUSSIAN)..... | 540 | LATCH, ENGINE DOOR..... | 832 |
| LABEL, MODEL DESIGNATION..... | 530 | LATCH, REAR CAB PANEL DOOR..... | 726 |
| LABEL, OIL DESCRIPTION (ENGLISH)..... | 530 | LATCH, SERVICE DOORS..... | 832 |
| LABEL, OIL DESCRIPTION (FRENCH)..... | 536 | LATCH, TOOLBOX SPRING HOOK..... | 870 |
| LABEL, OIL DESCRIPTION (RUSSIAN)..... | 540 | LEAN BAR LINK..... | 76 |
| LABEL, OIL DESCRIPTION (SPANISH)..... | 538 | LEAN CYLINDER PINS..... | 516 |
| LABEL, PARK BRAKE RELEASE (ENGLISH)..... | 530 | LEAN CYLINDER, WHEEL..... | 516 |
| LABEL, PARK BRAKE RELEASE (FRENCH)..... | 536 | LEAN CYLINDER, WHEEL COMPONENTS..... | 518 |
| LABEL, PARK BRAKE RELEASE (RUSSIAN)..... | 540 | LEAN SENSOR WIRING HARNESS, WHEEL..... | 594 |
| LABEL, PARK BRAKE RELEASE (SPANISH)..... | 538 | LEAN SENSOR WIRING HARNESS, WHEEL (CONNECTORS)..... | 602 |
| LABEL, PERIODIC MAINTENANCE (ENGLISH)..... | 530 | LEAPING DEERE LABEL..... | 530 |
| LABEL, PERIODIC MAINTENANCE (FRENCH)..... | 536 | LED FRONT SIGNAL LIGHT..... | 574 |
| LABEL, PERIODIC MAINTENANCE (RUSSIAN)..... | 540 | LED TAIL AND SIGNAL LAMPS..... | 576 |
| LABEL, PERIODIC MAINTENANCE (SPANISH)..... | 538 | Left Armrest Harness..... | 644 |
| LABEL, QUICK SERVICE (6068HDW75)..... | 548 | Left Auxiliary Valve Section Without Float (Standard Controls)..... | 932 |
| LABEL, QUICK SERVICE (6090HDW01 / 6090HDW04)..... | 546 | Left Auxiliary Valve Section With Float (Standard Controls)..... | 928 |
| LABEL, RECEIVER/DRIER (6068HDW75)..... | 824 | LEFT BLADE LIFT CONTROL LINKAGE..... | 762 |
| LABEL, RECEIVER/DRIER (6090HDW01 / 6090HDW04)..... | 822 | LEFT BLADE LIFT CONTROL, 4 FUNCTION (EH) (GRADE PRO)..... | 782 |
| LABEL, RECEIVER/DRYER (FRENCH)..... | 536 | LEFT BLADE LIFT CONTROL, 5 FUNCTION (EH) (GRADE PRO)..... | 786 |
| LABEL, RECEIVER/DRYER (RUSSIAN)..... | 540 | Left Blade Lift Valve Section (Standard Controls)..... | 902 |
| LABEL, RECEIVER/DRYER (SPANISH)..... | 538 | LEFT CAB DOOR (FULL HEIGHT CAB)..... | 732 |
| LABEL, REFLECTIVE RED..... | 530 | LEFT CAB DOOR (LOW PROFILE CAB)..... | 730 |
| LABEL, REFLECTIVE YELLOW..... | 530 | LEFT FIVE FUNCTION CONTROLS (EH) (GRADE PRO)..... | 786 |
| LABEL, ROPS (ENGLISH, GRADE PRO)..... | 534 | LEFT FOUR FUNCTION CONTROLS (EH) (GRADE PRO)..... | 782 |
| LABEL, ROPS (ENGLISH, STD CAB)..... | 532 | Left Front Wheel Hub..... | 82 |
| LABEL, ROPS (FRENCH)..... | 536 | LEFT GRADE PRO ARMREST WIRING HARNESS..... | 636 |
| LABEL, ROPS (RUSSIAN)..... | 540 | Left Main Hydraulic Control Valve Inlet and Outlet Sections (Standard Controls)..... | 918 |
| LABEL, ROPS (SPANISH)..... | 538 | Left Moldboard Extension (24 in. With 5/8 in. Hardware)..... | 1044 |
| LABEL, SECONDARY STEERING ACCUMULATOR WARNING (FIELD KIT)..... | 482 | Left Moldboard Extension (27 in. With 3/4 in. Hardware)..... | 1052 |
| LABEL, SECONDARY STEERING ACCUMULATOR WARNING (GRADE PRO)..... | 480 | Left Moldboard Extension (27 in. With 5/8 in. Hardware)..... | 1048 |
| LABEL, SHIFTER (ENGLISH, GRADE PRO)..... | 534 | LEFT STANDARD CONTROL LINKAGES..... | 762 |
| LABEL, SHIFTER (ENGLISH, STD CAB)..... | 532 | Left 4 Function Control Valve..... | 884 |
| LABEL, SSM ICON DESCRIPTION (ENGLISH, GRADE PRO)..... | 534 | Left 5 Function Control Linkage..... | 766 |
| LABEL, SSM ICON DESCRIPTION (ENGLISH, STD CAB)..... | 532 | Left 5 Function Control Valve..... | 890 |
| LABEL, SSM ICON DESCRIPTION (FRENCH)..... | 536 | Left 5 Function Control Valve Kit..... | 936 |
| LABEL, SSM ICON DESCRIPTION (RUSSIAN)..... | 540 | Left 6 Function Control Linkage..... | 770 |
| LABEL, SSM ICON DESCRIPTION (SPANISH)..... | 538 | Left 6 Function Control Valve..... | 894 |
| LABEL, STARTER BYPASS (RUSSIAN)..... | 540 | Left 6 Function Control Valve Kit..... | 940 |
| LABEL, STARTER BY-PASS (FRENCH)..... | 536 | Left 7 Function Control Linkage..... | 774 |
| LABEL, STARTER BY-PASS (SPANISH)..... | 538 | Left 7 Function Control Valve..... | 898 |
| LABEL, STARTER (3005)..... | 200 | Left 7 Function Control Valve Kit..... | 944 |
| | | LENS, STROBE WARNING BEACON..... | 592 |
| | | LEVER, DOOR LATCH (FULL HEIGHT CAB)..... | 732 |
| | | LEVER, DOOR LATCH (LOW PROFILE CAB)..... | 730 |
| | | LEVER, SEAT ARMRESTS (GRADE PRO)..... | 802 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> |
|---|---------------|
| LEVER, STEERING TILT (GRADE PRO)..... | 778 |
| LEVER, STEERING TILT (STD CONTROLS)..... | 760 |
| LEVER, TRANSMISSION GEAR SELECTOR (GRADE PRO)..... | 114 |
| LEVER, TRANSMISSION GEAR SELECTOR (STANDARD CONTROLS)..... | 112 |
| License Plate Bracket and Light..... | 528 |
| LIFT AND TIE DOWN LABEL (RUSSIAN)..... | 540 |
| LIFT ARM, BLADE..... | 1060 |
| LIFT CYLINDER HOSES, BLADE (GRADE PRO)..... | 1094 |
| LIFT CYLINDER HOSES, BLADE (STANDARD CONTROLS)..... | 1092 |
| LIFT CYLINDER, BLADE..... | 1116 |
| LIFT GROUP..... | 1136 |
| LIFT GROUP (FIELD KIT)..... | 1138 |
| LIFT STRAPS (9801)..... | 245, 360 |
| LIFT STRAPS (9807)..... | 246 |
| LIGHTS, CAB, FRONT AND REAR..... | 580 |
| LIGHTS, CAB, SIDE..... | 582 |
| LIGHTS, DRAFT FRAME WORK..... | 578 |
| LIGHTS, ENGINE COMPARTMENT..... | 584 |
| LIGHTS, FRONT AND REAR WORK..... | 578 |
| LIGHTS, FRONT DRIVING..... | 574 |
| LIGHTS, FRONT SIGNAL..... | 574 |
| LIGHTS, HI-LOW BEAM SWITCH..... | 676 |
| LIGHTS, HI-LOW BEAM SWITCH (GRADE PRO)..... | 678 |
| LIGHTS, LED TAIL AND SIGNAL..... | 576 |
| LIGHT BRACKET, BEACON..... | 588 |
| LIGHT PANEL, REAR..... | 692 |
| LIGHT WIRING HARNESS, FRONT DRIVE/TURN..... | 594 |
| LIGHT WIRING HARNESS, FRONT DRIVE/TURN (CONNECTORS)..... | 604 |
| LIGHT, INTERIOR DOME..... | 590 |
| LIGHT, LICENSE PLATE..... | 528 |
| LINERS, BLOCK (4633)..... | 330 |
| LINER KIT, PISTON AND CYLINDER (9901)..... | 260 |
| LINER PACKING KIT, CYLINDER (9901)..... | 263 |
| LINER, CYLINDER (4601)..... | 214 |
| LINER, CYLINDER (4834)..... | 334 |
| LINES AND FITTINGS, FRAME HINGE CENTRAL LUBRICATION..... | 550 |
| Lines, Fuel Injection..... | 184 |
| LINES, TURBOCHARGER OIL 6511..... | 234 |
| LINES, TURBOCHARGER (65VS)..... | 346 |
| LINE, HVAC..... | 818 |
| LINKAGE 6511..... | 234 |
| LINKAGE, AUX W/O FLOAT CONTROL (SEVENTH FUNCTION LEFT)..... | 774 |
| LINKAGE, AUX W/O FLOAT CONTROL (SEVENTH FUNCTION RIGHT)..... | 772 |
| LINKAGE, AUX W/ FLOAT CONTROL (SIXTH FUNCTION LEFT)..... | 770 |
| LINKAGE, AUX W/ FLOAT CONTROL (SIXTH FUNCTION RIGHT)..... | 768 |
| LINKAGE, FRONT MOUNTED DOZER BLADE..... | 1144 |
| LINKAGE, LEFT AND RIGHT STANDARD CONTROL VALVES..... | 762 |
| LINKAGE, REAR STEERING SENSOR (GRADE PRO)..... | 682 |
| LINKAGE, REAR STEERING SENSOR (STD CONTROLS)..... | 680 |
| LINKAGE, RIPPER CONTROL (FIFTH FUNCTION LH)..... | 766 |
| LINKAGE, SCARIFIER CONTROL (FIFTH FUNCTION RH)..... | 764 |
| LINK SCARIFIER, LIFT (FIELD KIT)..... | 1138 |
| LINK, LEAN BAR..... | 76 |
| LINK, WHEEL LEAN BAR..... | 76 |
| LOAD CENTER (WITHOUT AUTOSHIFT)..... | 664 |
| LOAD CENTER (WITH AUTOSHIFT)..... | 666 |
| LOAD SENSE HOSES, HYDRAULIC (GRADE PRO)..... | 1008 |
| LOAD SENSE HOSES, HYDRAULIC (STD CONTROLS)..... | 1006 |
| LOCKOUT VALVE, BLADE LIFT VALVE SECTION (EH) (GRADE PRO) (BREAKDOWN)..... | 978 |
| LOCKOUT VALVE, BLADE TILT VALVE SECTION (EH) (GRADE PRO)..... | 980 |
| LOCKOUT VALVE, BLADE TILT VALVE SECTION (STD)..... | 914 |
| LOCKOUT VALVE, CIRCLE SIDE SHIFT VALVE SECTION (EH) (GRADE PRO)..... | 988 |
| LOCKOUT VALVE, CIRCLE SIDE SHIFT VALVE SECTION (STD)..... | 908 |
| LOCKOUT VALVE, LEFT AUXILIARY VALVE SECTION (WITHOUT FLOAT) (STD)..... | 932 |
| LOCKOUT VALVE, LEFT AUX VALVE WITH FLOAT (STD)..... | 928 |
| LOCKOUT VALVE, LEFT BLADE LIFT VALVE SECTION (STD)..... | 902 |
| LOCKOUT VALVE, MID MOUNTED SCARIFIER VALVE SECTION (STD)..... | 922 |
| LOCKOUT VALVE, REAR STEER VALVE SECTION (EH) (GRADE PRO) (BREAKDOWN)..... | 974 |
| LOCKOUT VALVE, REAR STEER VALVE SECTION (STD)..... | 904 |
| LOCKOUT VALVE, RIGHT AUXILIARY VALVE SECTION (WITHOUT FLOAT) (STD)..... | 930 |
| LOCKOUT VALVE, RIGHT AUX VALVE WITH FLOAT (STD)..... | 926 |
| LOCKOUT VALVE, RIGHT BLADE LIFT VALVE SECTION (STD) (BREAKDOWN)..... | 900 |
| LOCKOUT VALVE, RIPPER VALVE SECTION (STD)..... | 924 |
| LOCKOUT VALVE, SCARIFIER VALVE SECTION (STD)..... | 920 |
| LOCKOUT VALVE, STEERING VALVE SECTION (EH) (GRADE PRO) (BREAKDOWN)..... | 976 |
| LOCKOUT VALVE, WHEEL LEAN VALVE SECTION (EH) (GRADE PRO)..... | 986 |
| LOCKOUT VALVE, WHEEL LEAN VALVE SECTION (STD)..... | 906 |
| LOCK PIN, SADDLE..... | 1124 |
| LOCK W/VALE, DIFF..... | 106 |
| LOCK, SERVICE DOORS..... | 832 |
| LONG BLOCK GASKET KIT (9901)..... | 284 |
| LOUVERS, HVAC..... | 812 |
| Lower Front Windshield Wiper..... | 750 |
| Lower Wiper Disable Sensor..... | 752 |
| LOW PROFILE CAB DOORS..... | 730 |
| Low Profile Cab With Doors And Fixed Windows..... | 698 |
| Low Profile Cab With Doors And Opening Windows..... | 700 |
| Low Profile Cab With Doors And Opening Windows (Grade Pro)..... | 704 |
| Low Profile Cab With Doors, Opening Side And Fixed Front Windows..... | 702 |
| LUBRICATION LINES, FRAME HINGE..... | 550 |
| LUBRICATION, CENTRAL, FRAME HINGE..... | 550 |
| Lug Bolt, Front Wheel (10 in. X 24 in.) (For 14X24 or 14R24 Tires) (Split Rim)..... | 54 |
| Lug Bolt, Front Wheel (9 in. X 24 in.) (For 14X24 or 14R24 Tires) (One Piece)..... | 52 |
| Lug Bolt, Wheel (13 in. X 25 in.) (For 17.5X25 or 17.5R25 Tires)..... | 56 |
| Lug Bolt, Wheel (14 in. X 25 in.) (For 17.5X25 or 17.5R25 Tires) (Split Rim)..... | 58 |
| LUMBAR KIT (DELUXE SEAT)..... | 794 |
| LUMBAR KIT (GRADE PRO SEAT)..... | 798 |
| LUMBAR KIT (STANDARD SEAT)..... | 790 |
| M | |
| Machine Information Gateway..... | 1018 |
| MAGNETIC PICK-UP SENSOR (6744)..... | 350 |
| MAGNET, A/C COMPRESSOR..... | 826 |
| MAGNET, CHAIN CASE DEBRIS..... | 68 |
| MAINFALL ANGLE SENSOR..... | 684 |
| MAIN BEARING CAP (4606)..... | 216 |
| MAIN BEARING KIT (9901)..... | 249 |
| Main Bearing, Crankshaft..... | 218 |
| MAIN CASE GROUP - YZ106537..... | 152 |
| MAIN CASE GROUP - YZ106540..... | 154 |
| Main Control Valve Mounting Brackets..... | 880 |
| MAIN DRIVE AXLE HOUSING..... | 64 |
| Main Frame..... | 686 |
| Main Frame Front Side Covers..... | 836 |
| MAIN FRAME, SHIELDS..... | 834 |
| MAIN HYDRAULIC CONTROL VALVE INLET SECTION (FRONT EH) (GRADE PRO) (BREAKDOWN)..... | 992 |
| MAIN HYDRAULIC CONTROL VALVE INLET SECTION (REAR EH) (GRADE PRO) (BREAKDOWN)..... | 990 |
| MAIN HYDRAULIC CONTROL VALVE OUTLET AND INLET SECTION (LEFT) (STD)..... | 916, 918 |
| Main Hydraulic Filter..... | 1012 |
| Main Hydraulic Manifold Valve (Without Secondary Steering)..... | 950 |
| Main Hydraulic Manifold Valve (With Secondary Steering)..... | 948 |
| Main Hydraulic Plumbing (Grade Pro)..... | 1000 |
| Main Hydraulic Plumbing (Standard Controls)..... | 998 |
| Main Hydraulic Pump..... | 878 |
| MAIN HYDRAULIC PUMP LOAD SENSE HOSE (GRADE PRO)..... | 1008 |
| MAIN HYDRAULIC PUMP LOAD SENSE HOSE (STD CONTROLS)..... | 1006 |
| Main Manifold Valve..... | 490 |
| Main Wiring Harnesses..... | 594 |
| MAIN WIRING HARNESS, FRONT..... | 594 |
| MAIN WIRING HARNESS, FRONT (CONNECTORS)..... | 596 |
| MAIN WIRING HARNESS, REAR (CONNECTORS)..... | 598 |
| MANIFOLD REMOVAL KIT, EXHAUST (9901)..... | 271 |
| MANIFOLD VALVE, HYDRAULIC WARMUP CIRCUIT..... | 1010 |
| Manifold Valve, Main..... | 490 |
| MANIFOLD VALVE, MAIN (W/O SEC. STEERING)..... | 950 |
| MANIFOLD VALVE, MAIN (W/ SEC. STEERING)..... | 948 |
| MANIFOLD, A/C..... | 826 |
| MANIFOLD, EXHAUST (28AY)..... | 311 |
| MANIFOLD, EXHAUST (2802)..... | 196 |
| MANIFOLD, EXHAUST 2870..... | 310 |
| MANIFOLD, HYDRAULIC OIL COOLER BYPASS..... | 952 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> |
|--|---------------|
| MANIFOLD, INTAKE (1797)..... | 302 |
| MANIFOLD, ROTARY (GRADE PRO)..... | 1080 |
| MANIFOLD, ROTARY (STD CONTROLS)..... | 1078 |
| MAP SENSOR (1701)..... | 186 |
| MAT, FLOOR (GRADE PRO)..... | 724 |
| MAT, FLOOR (STD CONTROLS)..... | 722 |
| MIDLAND AUX DRIVE AIR COMPRESSOR (9901)..... | 378 |
| Midstructure Harness..... | 600 |
| MIDSTRUCTURE WIRING HARNESS..... | 594 |
| Mid Mounted Scarifier..... | 1140 |
| Mid Mounted Scarifier Hydraulic Hoses..... | 1154 |
| Mid Mounted Scarifier Valve Section (Standard Controls)..... | 922 |
| Mid Mounted Scarifier (Field Kit)..... | 1142 |
| Mid Mounted Scarifier (Hydraulic Cylinder)..... | 1176 |
| Mid Mounted Scarifier 6 Function Control Valve (Grade Pro)..... | 966 |
| MID-SCARIFIER HOSE KIT..... | 1154 |
| MID-SCARIFIER HYDRAULIC HOSES..... | 1154 |
| MID-SCARIFIER PLUMBING KIT..... | 1154 |
| MIRROR BRACKET, EXTERIOR..... | 858 |
| MIRROR BRACKET, EXTERIOR (HEATED)..... | 860 |
| MIRROR, EXTERIOR..... | 858 |
| MIRROR, EXTERIOR HEATED..... | 860 |
| MIRROR, EXTERIOR (HEATED)..... | 860 |
| MIRROR, INTERIOR REARVIEW..... | 856 |
| MODEL DESIGNATION LABEL..... | 530 |
| MODULE, HVAC..... | 820 |
| MODULE, SSM (GRADE PRO)..... | 662 |
| MODULE, SSM (STD CONTROLS)..... | 660 |
| Moisture Sensor..... | 202 |
| Moldboard Extension, Left (24 in. With 5/8 in. Hardware)..... | 1044 |
| Moldboard Extension, Left (27 in. With 3/4 in. Hardware)..... | 1052 |
| Moldboard Extension, Left (27 in. With 5/8 in. Hardware)..... | 1048 |
| Moldboard Extension, Right (24 in. With 5/8 in. Hardware)..... | 1042 |
| Moldboard Extension, Right (27 in. With 3/4 in. Hardware)..... | 1050 |
| Moldboard Extension, Right (27 in. With 5/8 in. Hardware)..... | 1046 |
| Moldboard Overlays (6 in. Cutting Edge) (5/8 in. Hardware)..... | 1036 |
| Moldboard Overlays (8 in. Cutting Edge) (3/4 in. Hardware)..... | 1040 |
| Moldboard Overlays (8 in. Cutting Edge) (5/8 in. Hardware)..... | 1038 |
| Moldboard (12 ft. X 24 in. X 7/8 in. With 5/8 in. X 6 in. Cutting Edges)..... | 1020 |
| Moldboard (12 ft. X 24 in. X 7/8 in. With 5/8 in. X 8 in. Cutting Edges)..... | 1022 |
| Moldboard (12 ft. X 27 in. X 1 in. With 5/8 in. X 8 in. Cutting Edges)..... | 1024 |
| Moldboard (13 ft. X 27 in. X 1 in. With 5/8 in. X 8 in. Cutting Edges)..... | 1026 |
| Moldboard (14 ft. X 24 in. X 7/8 in. With 5/8 in. X 6 in. Cutting Edges)..... | 1028 |
| Moldboard (14 ft. X 24 in. X 7/8 in. With 5/8 in. X 8 in. Cutting Edges)..... | 1030 |
| Moldboard (14 ft. X 27 in. X 1 in. With 5/8 in. X 8 in. Cutting Edges)..... | 1032 |
| Moldboard (14 ft. X 27 in. X 1 in. With 5/8 in. X 8 in. Cutting Edges) (3/4 in. Hardware)..... | 1034 |
| MONITOR, CAB DISPLAY (GRADE PRO)..... | 672 |
| MONITOR, CAB DISPLAY (STD CONTROLS)..... | 670 |
| MONITOR, CAB DISPLAY, ALTERNATE MOUNTING BRACKET (IGC)..... | 674 |
| MOTOR AND SWITCH, HEATER AND A/C BLOWER..... | 820 |
| MOTOR KIT, STARTER (9901)..... | 282 |
| MOTOR STARTER (3059)..... | 314 |
| MOTOR, CIRCLE DRIVE..... | 1126 |
| MOTOR, FAN DRIVE..... | 428 |
| MOTOR, FRONT WINDSHIELD WIPER (FULL HEIGHT CAB)..... | 744 |
| MOTOR, FRONT WINDSHIELD WIPER (LOW PROFILE CAB)..... | 742 |
| MOTOR, LOWER FRONT WINDSHIELD WIPER..... | 750 |
| MOTOR, REAR WINDSHIELD WIPER (FULL HEIGHT CAB)..... | 748 |
| MOTOR, REAR WINDSHIELD WIPER (LOW PROFILE CAB)..... | 746 |
| MOTOR, STARTER (3008)..... | 201 |
| MOTOR, STARTING (3005)..... | 200 |
| MOUNTING BOLTS, TRANSMISSION..... | 122 |
| MOUNTING BRACKETS, MAIN CONTROL VALVE..... | 880 |
| Mounting Brackets, Wiring Harness..... | 244 |
| MOUNTING BRACKET, TCU..... | 116 |
| MOUNTING, DIFF LOCK PUMP..... | 84 |
| MOUNTING, ENGINE (6068HDW75)..... | 454 |
| MOUNTING, ENGINE (6090HDW01 / 6090HDW04)..... | 452 |
| Mounts, IGC Mast (3/4 in. Hardware)..... | 1056 |
| Mounts, IGC Mast (5/8 in. Hardware)..... | 1054 |
| MOUNT ISOLATORS, CAB..... | 708 |
| MOUNT, COOLING SYSTEM (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| MOUNT, COOLING SYSTEM (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| MOUNT, COOLING SYSTEM (6090HDW01 / 6090HDW04)(SN 626426-)..... | 410 |
| MOUNT, COOLING SYSTEM (6090HDW01 / 6090HDW04)(SN-626425)..... | 408 |
| MOUNT, FRONT EH VALVE (GRADE PRO)..... | 954 |
| MOUNT, FRONT FENDERS..... | 848 |
| MOUNT, JD LINK™ COMMUNICATION CONTROLLER..... | 1016 |
| MOUNT, REAR EH VALVE (GRADE PRO)..... | 956 |
| MOUNT, REAR FENDER..... | 852 |
| Muffler (Engines 6090HDW01 / 6090HDW04)..... | 448 |
| Muffler (Engine 6068HDW75)..... | 450 |
| MULTIPLE DISK BRAKE DIFFERENTIAL CASE (RE65558)..... | 108 |
| N | |
| NECK, ENGINE OIL FILLER(1230)..... | 296 |
| NET, CARGO (FULL HEIGHT CAB)..... | 718, 720 |
| NET, CARGO (GRADE PRO)..... | 714, 716 |
| NET, CARGO (LOW PROFILE CAB - STD)..... | 710, 712 |
| Nozzle, Fuel Injection..... | 184 |
| O | |
| OIL COOLER BYPASS VALVE, HYDRAULIC..... | 952 |
| OIL COOLER HOSES, HYDRAULIC..... | 404 |
| OIL COOLER (5912)..... | 230 |
| OIL COOLER, DIFFERENTIAL (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| OIL COOLER, DIFFERENTIAL (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| OIL COOLER, DIFFERENTIAL (6090HDW01 / 6090HDW04)(SN 626426-)..... | 410 |
| OIL COOLER, DIFFERENTIAL (6090HDW01 / 6090HDW04)(SN-626425)..... | 408 |
| OIL COOLER, TRANSMISSION (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| OIL COOLER, TRANSMISSION (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| OIL COOLER, TRANSMISSION (6090HDW01 / 6090HDW04)(SN 626426-)..... | 410 |
| OIL COOLER, TRANSMISSION (6090HDW01 / 6090HDW04)(SN-626425)..... | 408 |
| OIL COOLER, TRANSMISSION (6090HDW01 / 6090HDW04)(SN 626426-)..... | 410 |
| OIL COOLER, TRANSMISSION (6090HDW01 / 6090HDW04)(SN-626425)..... | 408 |
| OIL DESCRIPTION LABEL (ENGLISH)..... | 530 |
| OIL DESCRIPTION LABEL (FRENCH)..... | 536 |
| OIL DESCRIPTION LABEL (RUSSIAN)..... | 540 |
| OIL DESCRIPTION LABEL (SPANISH)..... | 538 |
| OIL DIAGNOSTIC FITTING, ENGINE (6068HDW75)..... | 548 |
| OIL DIAGNOSTIC FITTING, ENGINE (6090HDW01 / 6090HDW04)..... | 546 |
| OIL DIAGNOSTIC FITTING, HYDRAULIC (6068HDW75)..... | 548 |
| OIL DIAGNOSTIC FITTING, HYDRAULIC (6090HDW01 / 6090HDW04)..... | 546 |
| OIL DIAGNOSTIC FITTING, TRANSMISSION (6068HDW75)..... | 548 |
| OIL DIAGNOSTIC FITTING, TRANSMISSION (6090HDW01 / 6090HDW04)..... | 546 |
| OIL DIPSTICK (4048)..... | 324 |
| OIL DIPSTICK, ENGINE 4018..... | 208 |
| OIL FILLER NECK COVER(1230)..... | 296 |
| OIL FILTER AND HEAD (8860)..... | 358 |
| OIL FILTER HOUSING..... | 230 |
| OIL GASKET, TURBOCHARGER (65VS)..... | 346 |
| OIL LINES, TURBOCHARGER 6511..... | 234 |
| OIL PAN (1909)..... | 188 |
| OIL PAN, ENGINE (19BR)..... | 304 |
| OIL PUMP INTAKE (1909)..... | 188 |
| OIL PUMP (5001)..... | 224 |
| OIL PUMP (5024)..... | 338 |
| OIL SEAL, AXLE HOUSING..... | 68 |
| OIL SEAL, REAR (1423)..... | 298 |
| OIL SEAL, REAR (9901)..... | 382 |
| One Hand Blade Lift Control Lever and Valve Kit..... | 946 |
| One Hand Blade Lift Control Lever Kit..... | 776 |
| Opening Side And Fixed Front Windows (Low Profile Cab)..... | 738 |
| Opening Windows (Full Height Cab) (- 627324)..... | 740 |
| Opening Windows (Low Profile Cab)..... | 736 |
| OPERATORS STATION, FULL HEIGHT W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 706 |
| OPERATORS STATION, GRADE PRO W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 704 |

Índice alfabético, continuación

| | <i>Página</i> | | <i>Página</i> |
|--|---------------|---|---------------|
| OPERATORS STATION, LOW PROFILE W/ DOORS AND FIXED WINDOWS (COMPLETE)..... | 698 | PIVOT PIN..... | 64 |
| OPERATORS STATION, LOW PROFILE W/ DOORS AND OPENING SIDE WINDOWS (COMPLETE)..... | 702 | PIVOT PIN, MAIN FRAME..... | 686 |
| OPERATORS STATION, LOW PROFILE W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 700 | PIVOT, DRAFT FRAME BALL..... | 1058 |
| OPTION CODE -9901 SERVICE PARTS ASSEMBLY (HDW75)..... | 384 | PIVOT, TANDEM..... | 64 |
| OUTLET SECTION, LEFT MAIN HYDRAULIC CONTROL VALVE (STD)..... | 918 | PLANETARY, TANDEM DRIVE..... | 62 |
| OUTLET SECTION, RIGHT MAIN HYDRAULIC CONTROL VALVE (STD)..... | 916 | PLANET PINION CARRIER..... | 62 |
| OUTLET, 12V POWER..... | 622 | PLATE, CAB ROOF..... | 728 |
| OVERFLOW TANK, COOLANT (6068HDW75) (SERIAL NUMBER 626426-)..... | 422 | PLATE, FRESH AIR INTAKE (CAB ROOF)..... | 728 |
| OVERFLOW TANK, COOLANT (6068HDW75) (SERIAL NUMBER-626425)..... | 420 | PLATE, FRONT SWITCHES (GRADE PRO)..... | 778 |
| OVERFLOW TANK, COOLANT (6090HDW01 / 6090HDW04)(SN 626426-)..... | 414 | PLATE, FRONT SWITCHES (STD CONTROLS)..... | 760 |
| OVERFLOW TANK, COOLANT (6090HDW01 / 6090HDW04)(SN-626425)..... | 412 | PLATE, FRONT (3612)..... | 318 |
| OVERHAUL KIT, ENGINE (9902)..... | 280 | PLATE, INTERIOR DOME LIGHT..... | 590 |
| Overlays, Moldboard (6 in. Cutting Edge) (5/8 in. Hardware)..... | 1036 | PLATE, REAR MOUNTED WEIGHT..... | 696 |
| Overlays, Moldboard (8 in. Cutting Edge) (3/4 in. Hardware)..... | 1040 | PLATE, SEPARATOR, BRAKE..... | 66 |
| Overlays, Moldboard (8 in. Cutting Edge) (5/8 in. Hardware)..... | 1038 | PLATE, TRANSMISSION COOLING HOSE BULKHEAD..... | 406 |
| OVERLOAD PROTECTION DEVICE (GRADE PRO)..... | 636 | PLATFORM, TANDEM HOUSING..... | 60 |
| | | PLUGS, GLOW (4330)..... | 326 |
| | | PLUG, COOLANT HEATER (2699)..... | 195 |
| | | PLUG, MAIN MANIFOLD VALVE (W/O SEC. STEERING)..... | 950 |
| | | PLUG, MAIN MANIFOLD VALVE (W/ SEC. STEERING)..... | 948 |
| | | PLUG, TEMPERATURE SWITCH (6698)..... | 348 |
| | | PLUMBING, BLADE IMPACT SYSTEM (GRADE PRO)..... | 1110 |
| | | PLUMBING, BLADE IMPACT SYSTEM (STANDARD CONTROLS)..... | 1108 |
| | | PLUMBING, BLADE LIFT CYLINDER (GRADE PRO)..... | 1094 |
| | | PLUMBING, BLADE LIFT CYLINDER (STANDARD CONTROLS)..... | 1092 |
| | | PLUMBING, BLADE SIDE SHIFT CYLINDER (GRADE PRO)..... | 1098 |
| | | PLUMBING, BLADE SIDE SHIFT CYLINDER (STANDARD CONTROLS)..... | 1096 |
| | | PLUMBING, BLADE TILT CYLINDER (GRADE PRO)..... | 1098 |
| | | PLUMBING, BLADE TILT CYLINDER (STANDARD CONTROLS)..... | 1096 |
| | | PLUMBING, CIRCLE ROTATE MOTOR (GRADE PRO)..... | 1102 |
| | | PLUMBING, CIRCLE ROTATE MOTOR (STANDARD CONTROLS)..... | 1100 |
| | | PLUMBING, CIRCLE SIDE SHIFT CYLINDER (GRADE PRO)..... | 1106 |
| | | PLUMBING, CIRCLE SIDE SHIFT CYLINDER (STANDARD CONTROLS)..... | 1104 |
| | | PLUMBING, DIFFERENTIAL COOLER..... | 402 |
| | | PLUMBING, FAN..... | 430 |
| | | PLUMBING, HYDRAULIC OIL COOLER..... | 404 |
| | | PLUMBING, MAIN HYDRAULIC (GRADE PRO)..... | 1000 |
| | | PLUMBING, MAIN HYDRAULIC (STD CONTROLS)..... | 998 |
| | | PLUMBING, ROTARY MANIFOLD (GRADE PRO)..... | 1102 |
| | | PLUMBING, SADDLE LOCK PIN..... | 1114 |
| | | PLUMBING, STEERING (STANDARD CONTROLS)..... | 492 |
| | | PLUMBING, TRANSMISSION..... | 124 |
| | | POWERED PRECLEANER, HVAC..... | 816 |
| | | POWER CONNECTOR, GTT..... | 1016 |
| | | POWER CONVERTER, 15 AMP..... | 570 |
| | | POWER CONVERTER, 25 AMP..... | 572 |
| | | POWER OUTLET (12V)..... | 622 |
| | | PRECLEANER, HVAC POWERED..... | 816 |
| | | PRECLEANER, ROTARY EJECTOR (6068HDW75)..... | 446 |
| | | PRECLEANER, ROTARY EJECTOR (6090HDW01 / 6090HDW04)..... | 444 |
| | | PRESSURE REDUCING CARTRIDGE, MAIN MANIFOLD VALVE (W/O SEC. STEERING)..... | 950 |
| | | PRESSURE REDUCING CARTRIDGE, MAIN MANIFOLD VALVE (W/ SEC. STEERING)..... | 948 |
| | | PRESSURE RELIEF VALVE (MID MOUNTED SCARIFIER VALVE SECTION)..... | 888 |
| | | PRESSURE RELIEF VALVE, MID MOUNTED SCARIFIER VALVE SECTION (STD)..... | 922 |
| | | PRESSURE SENSOR, FAN PRESSURE..... | 432 |
| | | PRESSURE SENSOR, HYDRAULIC PUMP..... | 484 |
| | | PRESSURE SWITCH, BRAKE ACCUMULATOR..... | 520 |
| | | PRESSURE SWITCH, DIFFERENTIAL LOCK FILTER..... | 90 |
| | | PRESSURE SWITCH, MAIN HYDRAULIC..... | 1012 |
| | | PRESSURE SWITCH, TRANSMISSION FILTER..... | 132 |
| | | Primary Fuel Filter..... | 202 |
| | | PRIMARY FUEL FILTER (9901)..... | 247 |
| | | PRIMARY WARNING ALARM..... | 676 |
| | | PRIMARY WARNING ALARM (GRADE PRO)..... | 678 |
| | | Priority Valve, Steering..... | 490 |
| | | PROP ROD, FAN DOOR..... | 424 |
| | | PULLEY, ALTERNATOR, 100AMP (6068HDW75)..... | 566 |
| | | PULLEY, ALTERNATOR, 100AMP (6090HDW01 / 6090HDW04)..... | 562 |
| | | PULLEY, ALTERNATOR, 130AMP (6068HDW75)..... | 568 |
| | | PULLEY, ALTERNATOR, 130AMP (6090HDW01 / 6090HDW04)..... | 564 |
| | | PULLEY, CRANKSHAFT (1320)..... | 297 |
| | | PULLEY, CRANKSHAFT (1346)..... | 180 |
| | | PULLEY, FAN DRIVE (8724)..... | 356 |
| | | PULLEY, TENSIONER (8724)..... | 356 |
| | | PULLEY, WATERPUMP (2001)..... | 306 |

P

| | |
|---|------------|
| PAD, SEAT ARMRESTS (GRADE PRO)..... | 802 |
| PANELS, CAB REAR INTERIOR..... | 726 |
| Panel, Fuse..... | 630 |
| PANEL, REAR LIGHT..... | 692 |
| PANEL, SIDE (FULL HEIGHT CAB)..... | 718, 720 |
| PANEL, SIDE (GRADE PRO)..... | 714, 716 |
| PANEL, SIDE (LOW PROFILE CAB - STD)..... | 710, 712 |
| PANEL, 4WD INSTRUMENT (STD CONTROLS)..... | 756 |
| PAN, ENGINE OIL (19BR)..... | 304 |
| PAN, OIL (1909)..... | 188 |
| Parallel Lift Group..... | 1136, 1138 |
| PARALLEL LIFT GROUP CYLINDER (BREAKDOWN)..... | 1172 |
| PARALLEL LIFT GROUP (FIELD KIT)..... | 1138 |
| Park Brake Hydraulic Hoses..... | 526 |
| PARK BRAKE RELEASE LABEL (ENGLISH)..... | 530 |
| PARK BRAKE RELEASE LABEL (FRENCH)..... | 536 |
| PARK BRAKE RELEASE LABEL (RUSSIAN)..... | 540 |
| PARK BRAKE RELEASE LABEL (SPANISH)..... | 538 |
| PARK BRAKE VALVE FITTINGS..... | 526 |
| PEDAL, BRAKE..... | 520 |
| PEDAL, DECELERATOR..... | 438 |
| PEDAL, ENGINE SPEED CONTROL (GRADE PRO)..... | 436 |
| PEDAL, ENGINE SPEED CONTROL (STANDARD)..... | 434 |
| PEDAL, INCHING..... | 476, 478 |
| PEDAL, SERVICE BRAKE..... | 520 |
| PEDAL, STEERING TILT (GRADE PRO)..... | 778 |
| PEDAL, STEERING TILT (STD CONTROLS)..... | 760 |
| PERIODIC MAINTENANCE LABEL (ENGLISH)..... | 530 |
| PERIODIC MAINTENANCE LABEL (FRENCH)..... | 536 |
| PERIODIC MAINTENANCE LABEL (RUSSIAN)..... | 540 |
| PERIODIC MAINTENANCE LABEL (SPANISH)..... | 538 |
| PINS, HYDRAULIC CYLINDER..... | 516 |
| PINS, STEERING CYLINDER..... | 508, 510 |
| PINS, WHEEL LEAN CYLINDER..... | 516 |
| PIN, ARTICULATION CYLINDER..... | 686 |
| PIN, BLADE SLIDE CYLINDER..... | 1118 |
| PIN, BLADE TILT CYLINDER..... | 1120 |
| PIN, CIRCLE FRAME TILT/PIVOT..... | 1064 |
| PIN, FRONT AXLE PIVOT..... | 74 |
| PIN, FRONT MOUNTED DOZER BLADE..... | 1144 |
| PIN, HITCH..... | 552 |
| PIN, PIVOT..... | 64 |
| PIN, PIVOT, MAIN FRAME..... | 686 |
| PIN, SADDLE..... | 1060 |
| PIN, WHEEL LEAN BAR LINK..... | 76 |
| PISTON COOLING ORIFICE (4606)..... | 216 |
| PISTON LINER KIT (9901)..... | 372 |
| PISTON RING KIT (9901)..... | 270, 380 |
| PISTON (4801)..... | 220 |
| PISTON (4834)..... | 334 |
| PISTON-LINER KIT (9901)..... | 260 |
| PISTON, TILT STEERING (GRADE PRO)..... | 778 |
| PISTON, TILT STEERING (STD CONTROLS)..... | 760 |
| PIVOT HOUSING..... | 64 |

Índice alfabético, continuación

| Página | Página |
|--|----------|
| Pump Inlet, Water..... | 229 |
| PUMP INLET, WATER (5722)..... | 343 |
| PUMP PLUMBING, HYDRAULIC (GRADE PRO)..... | 1000 |
| PUMP PLUMBING, HYDRAULIC (STD CONTROLS)..... | 998 |
| PUMP WATER KIT (9901)..... | 248 |
| PUMP, DIFFERENTIAL LOCK..... | 84 |
| PUMP, DIFF LOCK..... | 84 |
| PUMP, FAN..... | 426 |
| PUMP, FRONT WINDSHIELD WASHER (FULL HEIGHT CAB)..... | 744 |
| PUMP, FRONT WINDSHIELD WASHER (LOW PROFILE CAB)..... | 742 |
| Pump, Fuel Injection..... | 184 |
| PUMP, FUEL, DIESEL FIRED COOLANT HEATER (6090HDW01 / 6090HDW04)..... | 400 |
| PUMP, INTAKE OIL (1909)..... | 188 |
| PUMP, LOWER FRONT WINDSHIELD WIPER..... | 750 |
| PUMP, MAIN HYDRAULIC..... | 878 |
| PUMP, OIL (5001)..... | 224 |
| PUMP, OIL (5024)..... | 338 |
| PUMP, REAR WINDSHIELD WASHER (FULL HEIGHT CAB)..... | 748 |
| PUMP, REAR WINDSHIELD WASHER (LOW PROFILE CAB)..... | 746 |
| PUMP, TRANSFER FUEL (3713)..... | 320 |
| Pump, Water..... | 190 |
| PUMP, WATER (4436)..... | 328 |
| Push Block..... | 694 |
| PUSH ROD (4901) (HDW01)..... | 222 |
| PUSH ROD, ROCKER ARM, SHAFT, TAPPET..... | 336 |
| Q | |
| Quick Service (Engines 6090HDW01 / 6090HDW04)..... | 546 |
| Quick Service (Engine 6068HDW75)..... | 548 |
| QUICK SERVICE, LABEL (6090HDW01 / 6090HDW04)..... | 546 |
| R | |
| RADIATOR HOSES (6068HDW75) (SERIAL NUMBER 626426-)..... | 422 |
| RADIATOR HOSES (6068HDW75) (SERIAL NUMBER-626425)..... | 420 |
| RADIATOR HOSES (6090HDW01 / 6090HDW04)..... | 414 |
| RADIATOR HOSES (6090HDW01 / 6090HDW04) (SN-626425)..... | 412 |
| RADIATOR (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| RADIATOR (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| RADIATOR (6090HDW01 / 6090HDW04) (SN 626426-)..... | 410 |
| RADIATOR (6090HDW01 / 6090HDW04) (SN-626425)..... | 408 |
| Radio and Speakers Field Kit..... | 854 |
| RADIO HOUSING (FULL HEIGHT CAB)..... | 718, 720 |
| RADIO HOUSING (GRADE PRO)..... | 714, 716 |
| RADIO HOUSING (LOW PROFILE CAB - STD)..... | 710, 712 |
| RADIO SPEAKER WIRING HARNESS..... | 622 |
| Radio Wiring Harness..... | 634 |
| REARVIEW MIRROR, INTERIOR..... | 856 |
| REAR ASSEMBLY HOUSING..... | 168 |
| Rear Auxiliary Hoses (Fifth Function) (Grade Pro)..... | 1166 |
| Rear Auxiliary Hoses (Fifth Function) (Standard Controls)..... | 1164 |
| Rear Auxiliary Hoses (Sixth Function) (Grade Pro)..... | 1170 |
| Rear Auxiliary Hoses (Sixth Function) (Standard Controls)..... | 1168 |
| Rear Camera..... | 868 |
| Rear Counterweight..... | 696 |
| REAR CRANKSHAFT SEAL (1412)..... | 181 |
| REAR EH VALVE HARNESS (GRADE PRO)..... | 646 |
| REAR EH VALVE MOUNT (GRADE PRO)..... | 956 |
| REAR ELECTROHYDRAULIC CONTROL VALVE INLET SECTION (GRADE PRO) (BREAKDOWN)..... | 990 |
| Rear Fenders..... | 852 |
| REAR FIVE FUNCTION CONTROL VALVE (EH) (GRADE PRO)..... | 962 |
| REAR FOUR FUNCTION CONTROL VALVE (EH) (GRADE PRO)..... | 958 |
| Rear Grade Pro Valve Harness..... | 648 |
| REAR GRILLE..... | 692 |
| REAR GRILLE HOUSING..... | 692 |
| Rear Hitch..... | 552 |
| REAR LIGHT PANEL..... | 692 |
| REAR OIL SEAL (1423)..... | 298 |
| REAR OIL SEAL (9901)..... | 382 |
| Rear Platform Harness..... | 598 |
| REAR PLATFORM WIRING HARNESS..... | 594 |
| REAR PTO (1412)..... | 181 |
| REAR RIPPER SHANK..... | 1130 |
| Rear Ripper /Scarifier (Factory)..... | 1130 |
| Rear Ripper /Scarifier (Field Kit)..... | 1132 |
| Rear Ripper / Rear Scarifier Hydraulic Hoses..... | 1150 |
| Rear Ripper / Rear Scarifier Hydraulic Hoses (Field Kit)..... | 1152 |
| Rear Ripper / Scarifier Cylinder..... | 1174 |
| REAR RIPPER/SCARIFIER FACTORY..... | 1130 |
| REAR RIPPER, FIELD KIT..... | 1130 |
| REAR SCARIFIER FIELD KIT..... | 1130 |
| REAR SCARIFIER SHANK..... | 1134 |
| Rear Scarifier Shanks and Teeth..... | 1134 |
| REAR SEVEN FUNCTION CONTROL VALVE (EH) (GRADE PRO)..... | 970 |
| REAR SIX FUNCTION CONTROL VALVE (EH) (GRADE PRO)..... | 968 |
| REAR STEERING CYLINDER COMPONENTS..... | 514 |
| REAR STEERING CYLINDER PINS..... | 512 |
| REAR STEERING HYDRAULICS (GRADE PRO)..... | 498 |
| Rear Steering Plumbing (Grade Pro)..... | 498 |
| Rear Steering Plumbing (Standard Controls)..... | 496 |
| Rear Steering Sensor (Grade Pro)..... | 682 |
| Rear Steering Sensor (Standard Controls)..... | 680 |
| Rear Steering Valve Section (Grade Pro)..... | 974 |
| Rear Steering Valve Section (Standard Controls)..... | 904 |
| REAR STEER CONTROL LINKAGE..... | 762 |
| REAR STEER CONTROL, RIGHT 4 FUNCTION (EH) (GRADE PRO)..... | 780 |
| REAR STEER CONTROL, RIGHT 5 FUNCTION (EH) (GRADE PRO)..... | 784 |
| REAR VALVE COVER (GRADE PRO)..... | 840 |
| Rear Window Sun Visor..... | 874 |
| REAR WINDOW (FULL HEIGHT CAB W/ OPENING WINDOWS) (S.N. -627324)..... | 740 |
| REAR WINDOW (LOW PROFILE CAB W/ FIXED WINDOWS)..... | 734 |
| REAR WINDOW (LOW PROFILE CAB W/ OPENING SIDE AND FIXED FRONT WINDOWS)..... | 738 |
| REAR WINDOW (LOW PROFILE CAB W/ OPENING WINDOWS)..... | 736 |
| Rear Windshield Wiper (Full Height Cab)..... | 748 |
| Rear Windshield Wiper (Low Profile Cab)..... | 746 |
| REAR WIPER HOUSING (FULL HEIGHT CAB)..... | 718, 720 |
| REAR WIPER HOUSING (GRADE PRO)..... | 714, 716 |
| REAR WIPER HOUSING (LOW PROFILE CAB - STD)..... | 710, 712 |
| Rear, Mid-Frame, and Under Cab Work Lights..... | 578 |
| REBUILD ENGINE GASKET KIT (9901)..... | 278 |
| RECEIVER/DRIER, A/C (6068HDW75)..... | 824 |
| RECEIVER/DRIER, A/C (6090HDW01 / 6090HDW04)..... | 822 |
| RECEIVER/DRYER LABEL (FRENCH)..... | 536 |
| RECEIVER/DRYER LABEL (RUSSIAN)..... | 540 |
| RECEIVER/DRYER LABEL (SPANISH)..... | 538 |
| REFLECTIVE LABELS, RED AND YELLOW..... | 530 |
| REFRIGERANT LINES, A/C (6068HDW75)..... | 824 |
| REFRIGERANT LINES, A/C (6090HDW01 / 6090HDW04)..... | 822 |
| Relays, Fuse Panel..... | 630 |
| RELAY STARTER-12V (9901) (HT067)..... | 375 |
| RELAY STARTER(9901)..... | 381 |
| RELAY, ENGINE AIR HEATER START..... | 390 |
| RELAY, GLOW PLUG START..... | 398 |
| RELAY, IGNITION..... | 622 |
| RELAY, STARTER (24V/100A) (6068HDW75)..... | 612 |
| RELAY, STARTER (24V/100A) (6090HDW01)..... | 606 |
| RELIEF VALVE (MID MOUNTED SCARIFIER VALVE SECTION)..... | 888 |
| RELIEF VALVE (REVERSING FAN)..... | 432 |
| RELIEF VALVE, BLADE LIFT VALVE SECTION (EH) (GRADE PRO) (BREAKDOWN)..... | 978 |
| RELIEF VALVE, HYDRAULIC WARMUP CIRCUIT..... | 1010 |
| RELIEF VALVE, LEFT BLADE LIFT VALVE SECTION (STD)..... | 902 |
| RELIEF VALVE, MAIN MANIFOLD VALVE (W/O SEC. STEERING)..... | 950 |
| RELIEF VALVE, MAIN MANIFOLD VALVE (W/ SEC. STEERING)..... | 948 |
| RELIEF VALVE, MID MOUNTED SCARIFIER VALVE SECTION (STD)..... | 922 |
| RELIEF VALVE, RIGHT BLADE LIFT VALVE SECTION (STD) (BREAKDOWN)..... | 900 |
| REMANUFACTURED TRANSMISSION..... | 120 |
| Reman Fuel Injection Nozzle..... | 300, 374 |
| Reman Fuel Injection Pump..... | 184, 300 |
| Reman Injection Nozzle..... | 184 |
| Reman Turbocharger..... | 234 |
| Reman Water Pump..... | 190 |
| RESERVOIR, HYDRAULIC..... | 1014 |
| RESERVOIR, WINDSHIELD WASHER (FULL HEIGHT CAB)..... | 744 |
| RESERVOIR, WINDSHIELD WASHER (LOW PROFILE CAB)..... | 742 |
| RESTRICTION SWITCH, DIFFERENTIAL LOCK FILTER..... | 90 |
| RESTRICTION SWITCH, TRANSMISSION FILTER..... | 132 |
| RETAINER, CIRCLE FRAME SUPPORT..... | 1064 |
| RETAINER, DRAFT FRAME BALL..... | 1058 |
| Reverse Fan Drive Solenoid Valve..... | 432 |
| RE35708 SPIRAL BEVEL ASSEMBLY 4.364..... | 92 |
| RE35714 INPUT YOKE 7C..... | 94 |
| RE44158 AXLE HOUSING AND SHAFT..... | 96 |
| RE46977 INPUT HOUSING WITH PARK BRAKE COVER..... | 98 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> |
|---|---------------|
| RE65558 MULTIPLE DISK BRAKE DIFF CASE..... | 108 |
| RE65559 BRAKE ASSEMBLY WITHOUT FINAL DRIVE..... | 100 |
| Right Armrest Harness..... | 642 |
| Right Auxiliary Valve Section Without Float (Standard Controls)..... | 930 |
| Right Auxiliary Valve Section With Float (Standard Controls)..... | 926 |
| RIGHT BLADE LIFT CONTROL LINKAGE..... | 762 |
| RIGHT BLADE LIFT CONTROL, 4 FUNCTION (EH) (GRADE PRO)..... | 780 |
| RIGHT BLADE LIFT CONTROL, 5 FUNCTION (EH) (GRADE PRO)..... | 784 |
| Right Blade Lift Valve Section (Standard Controls)..... | 900 |
| RIGHT CAB DOOR (FULL HEIGHT CAB)..... | 732 |
| RIGHT CAB DOOR (LOW PROFILE CAB)..... | 730 |
| RIGHT FIVE FUNCTION CONTROLS (EH) (GRADE PRO)..... | 784 |
| RIGHT FOUR FUNCTION CONTROLS (EH) (GRADE PRO)..... | 780 |
| Right Front Wheel Hub..... | 80 |
| RIGHT GRADE PRO ARMREST WIRING HARNESS..... | 636 |
| Right Main Hydraulic Control Valve Inlet and Outlet Sections (Standard Controls)..... | 916 |
| Right Moldboard Extension (24 in. With 5/8 in. Hardware)..... | 1042 |
| Right Moldboard Extension (27 in. With 3/4 in. Hardware)..... | 1050 |
| Right Moldboard Extension (27 in. With 5/8 in. Hardware)..... | 1046 |
| RIGHT STANDARD CONTROL LINKAGES..... | 762 |
| Right 4 Function Control Valve..... | 882 |
| Right 5 Function Control Linkage..... | 764 |
| Right 5 Function Control Valve..... | 886 |
| Right 5 Function Control Valve Kit..... | 934 |
| Right 5 Function Control Valve (Mid Mounted Scarifier)..... | 888 |
| Right 6 Function Control Linkage..... | 768 |
| Right 6 Function Control Valve..... | 892 |
| Right 6 Function Control Valve Kit..... | 938 |
| Right 7 Function Control Linkage..... | 772 |
| Right 7 Function Control Valve..... | 896 |
| Right 7 Function Control Valve Kit..... | 942 |
| Rim, Wheel (10 in. X 24 in.) (For 14X24 or 14R24 Tires) (Split Rim)..... | 54 |
| Rim, Wheel (13 in. X 25 in.) (For 17.5X25 or 17.5R25 Tires)..... | 56 |
| Rim, Wheel (14 in. X 25 in.) (For 17.5 X 25 or 17.5R25 Tires) (Split Rim)..... | 58 |
| Rim, Wheel (9 in. X 24 in.) (For 14X24 or 14R24 Tires) (One Piece)..... | 52 |
| RING GEAR, FLYWHEEL 1520..... | 182 |
| RING GEAR, FLYWHEEL 1530..... | 299 |
| RING KIT, PISTON (4801)..... | 220 |
| RING KIT, PISTON (4834)..... | 334 |
| RING KIT, PISTON (9901)..... | 270 |
| RIPPER CONTROLS, LEFT 5 FUNCTION (EH) (GRADE PRO)..... | 786 |
| RIPPER CONTROL LINKAGE (FIFTH FUNCTION LH)..... | 766 |
| RIPPER CONTROL VALVE KIT..... | 936 |
| RIPPER FIELD KIT, REAR..... | 1130 |
| RIPPER HYDRAULIC HOSES..... | 1150, 1152 |
| RIPPER PLUMBING FIELD KIT..... | 1150 |
| RIPPER TEETH..... | 1130 |
| RIPPER VALVE SECTION (EH) (BREAKDOWN) (GRADE PRO)..... | 994 |
| Ripper Valve Section (Standard Controls)..... | 924 |
| RIPPER/REAR SCARIFIER HYDRAULIC HOSE KIT..... | 1152 |
| RIPPER/SCARIFIER CYLINDER, REAR..... | 1174 |
| RIPPER, REAR..... | 1130 |
| ROCKER ARM COVER (1102)..... | 178 |
| ROCKER ARM COVER (1144)..... | 294 |
| ROCKER ARM (4901) (HDW01)..... | 222 |
| ROCKER ARM, SHAFT, TAPPET, PUSH ROD (4905)..... | 336 |
| ROD BEARINGS, CONNECTING (4801)..... | 220 |
| ROD BEARING KIT, CONNECTING (9901)..... | 250 |
| ROD, DOOR LATCH (FULL HEIGHT CAB)..... | 732 |
| ROD, DOOR LATCH (LOW PROFILE CAB)..... | 730 |
| ROD, FAN DOOR HOLD OPEN..... | 424 |
| ROD, PUSH (4901) HDW01..... | 222 |
| ROD, TIE, FRONT EH EIGHT FUNCTION CONTROL VALVE (GRADE PRO)..... | 972 |
| ROD, TIE, FRONT EH FIVE FUNCTION CONTROL VALVE (GRADE PRO)..... | 960 |
| ROD, TIE, FRONT EH SIX FUNCTION CONTROL VALVE (GRADE PRO)..... | 964 |
| ROD, TIE, LEFT FIVE FUNCTION CONTROL VALVE..... | 890 |
| ROD, TIE, LEFT FOUR FUNCTION CONTROL VALVE..... | 884 |
| ROD, TIE, LEFT SEVEN FUNCTION CONTROL VALVE..... | 898 |
| ROD, TIE, LEFT SIX FUNCTION CONTROL VALVE..... | 894 |
| ROD, TIE, REAR EH FIVE FUNCTION CONTROL VALVE (GRADE PRO)..... | 962 |
| ROD, TIE, REAR EH FOUR FUNCTION CONTROL VALVE (GRADE PRO)..... | 958 |
| ROD, TIE, REAR EH SEVEN FUNCTION CONTROL VALVE (GRADE PRO)..... | 970 |
| ROD, TIE, REAR EH SIX FUNCTION CONTROL VALVE (GRADE MOUNTED SCARIFIER)..... | 888 |
| ROD, TIE, RIGHT FIVE FUNCTION CONTROL VALVE..... | 886 |
| ROD, TIE, RIGHT FIVE FUNCTION CONTROL VALVE (MID MOUNTED SCARIFIER)..... | 888 |
| ROD, TIE, RIGHT FOUR FUNCTION CONTROL VALVE..... | 882 |
| ROD, TIE, RIGHT SEVEN FUNCTION CONTROL VALVE..... | 896 |
| ROD, TIE, RIGHT SIX FUNCTION CONTROL VALVE..... | 892 |
| ROOF WIRING HARNESS..... | 652 |
| ROOF WORK LIGHTS, FRONT AND REAR..... | 580 |
| ROOF WORK LIGHTS, SIDE..... | 582 |
| ROOF, CAB..... | 728 |
| ROPS LABEL (ENGLISH, GRADE PRO)..... | 534 |
| ROPS LABEL (ENGLISH, STD CAB)..... | 532 |
| ROPS LABEL (FRENCH)..... | 536 |
| ROPS LABEL (RUSSIAN)..... | 540 |
| ROPS LABEL (SPANISH)..... | 538 |
| ROPS, FULL HEIGHT W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 706 |
| ROPS, GRADE PRO ENCLOSURE W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 704 |
| ROPS, LOW PROFILE ENCLOSURE W/ DOORS AND FIXED WINDOWS (COMPLETE)..... | 698 |
| ROPS, LOW PROFILE ENCLOSURE W/ DOORS AND OPENING WINDOWS (COMPLETE)..... | 700 |
| ROPS, LOW PROFILE W/ DOORS AND OPENING SIDE/FIXED FRONT WINDOWS (COMPLETE)..... | 702 |
| ROTARY ACTUATOR, BLADE SIDE SHIFT VALVE SECTION (EH) (GRADE PRO)..... | 984 |
| ROTARY ACTUATOR, BLADE SIDE SHIFT VALVE SECTION (STD)..... | 910 |
| ROTARY ACTUATOR, BLADE TILT VALVE SECTION (STD)..... | 914 |
| ROTARY ACTUATOR, CIRCLE ROTATE VALVE SECTION (STD)..... | 912 |
| ROTARY ACTUATOR, CIRCLE SIDE SHIFT VALVE SECTION (EH) (GRADE PRO)..... | 988 |
| ROTARY ACTUATOR, CIRCLE SIDE SHIFT VALVE SECTION (STD)..... | 908 |
| ROTARY ACTUATOR, LEFT AUXILIARY VALVE SECTION (WITHOUT FLOAT) (STD)..... | 932 |
| ROTARY ACTUATOR, LEFT AUX VALVE WITH FLOAT (STD)..... | 928 |
| ROTARY ACTUATOR, LEFT BLADE LIFT VALVE SECTION (STD)..... | 902 |
| ROTARY ACTUATOR, MID MOUNTED SCARIFIER VALVE SECTION (STD)..... | 922 |
| ROTARY ACTUATOR, REAR STEER VALVE SECTION (STD)..... | 904 |
| ROTARY ACTUATOR, RIGHT AUXILIARY VALVE SECTION (WITHOUT FLOAT) (STD)..... | 930 |
| ROTARY ACTUATOR, RIGHT AUX VALVE WITH FLOAT (STD)..... | 926 |
| ROTARY ACTUATOR, RIGHT BLADE LIFT VALVE SECTION (STD) (BREAKDOWN)..... | 900 |
| ROTARY ACTUATOR, RIPPER VALVE SECTION (STD)..... | 924 |
| ROTARY ACTUATOR, SCARIFIER VALVE SECTION (STD)..... | 920 |
| ROTARY ACTUATOR, WHEEL LEAN VALVE SECTION (EH) (GRADE PRO)..... | 986 |
| ROTARY ACTUATOR, WHEEL LEAN VALVE SECTION (STD)..... | 906 |
| Rotary Ejector Precleaner (Engines 6090HDW01 / 6090HDW04)..... | 444 |
| Rotary Ejector Precleaner (Engine 6068HDW75)..... | 446 |
| ROTARY MANIFOLD HYDRAULIC HOSES (GRADE PRO)..... | 1102 |
| ROTARY MANIFOLD SENSOR..... | 684 |
| Rotary Manifold (Grade Pro)..... | 1080 |
| Rotary Manifold (Standard Controls)..... | 1078 |
| RUSSIAN TRADEMARKS AND LABELS..... | 540 |

S

| | |
|---|------------|
| Saddle Frame..... | 1060 |
| Saddle Lock Pin..... | 1124 |
| Saddle Lock Pin Hoses..... | 1114 |
| SCARIFIER BOOM..... | 1136 |
| SCARIFIER CONTROL LINKAGE (FIFTH FUNCTION RIGHT)..... | 764 |
| SCARIFIER CONTROL VALVE KIT..... | 934 |
| SCARIFIER CONTROL, RIGHT 5 FUNCTION (EH) (GRADE PRO)..... | 784 |
| SCARIFIER CYLINDER (BREAKDOWN)..... | 1172 |
| SCARIFIER FIELD KIT, REAR..... | 1130 |
| SCARIFIER HOSES, FRONT..... | 1146, 1148 |
| SCARIFIER HOSES, MIDDLE..... | 1154 |
| SCARIFIER HYDRAULIC HOSES (REAR)..... | 1150, 1152 |
| SCARIFIER HYDRAULIC HOSE KIT (FRONT)..... | 1148 |
| SCARIFIER PLUMBING KIT..... | 1150 |
| SCARIFIER TEETH, REAR..... | 1134 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> |
|--|---------------|
| SCARIFIER VALVE SECTION (EH) (BREAKDOWN) (GRADE PRO)..... | 994 |
| Scarifier Valve Section (Standard Controls)..... | 920 |
| SCARIFIER, FRONT MOUNTED..... | 1128 |
| SCARIFIER, MID MOUNTED..... | 1140 |
| SCARIFIER, MID MOUNTED HYDRAULIC CYLINDER..... | 1176 |
| SCARIFIER, MID MOUNTED (FIELD KIT)..... | 1142 |
| SCARIFIER, REAR..... | 1130 |
| Sealed Switch Module (Grade Pro)..... | 662 |
| Sealed Switch Module (Standard Controls)..... | 660 |
| SEAL KIT, ARTICULATION CYLINDER..... | 514 |
| SEAL KIT, BLADE IMPACT VALVE..... | 1086 |
| SEAL KIT, BLADE LIFT CYLINDER..... | 1116 |
| SEAL KIT, BLADE SLIDE CYLINDER..... | 1118 |
| SEAL KIT, BLADE TILT CYLINDER..... | 1120 |
| SEAL KIT, CHECK VALVE MAIN MANIFOLD VALVE (W/O SEC. STEERING)..... | 950 |
| SEAL KIT, CHECK VALVE MAIN MANIFOLD VALVE (W/ SEC. STEERING)..... | 948 |
| SEAL KIT, CIRCLE DRIVE MOTOR..... | 1126 |
| SEAL KIT, CIRCLE SIDE SHIFT CYLINDER..... | 1122 |
| SEAL KIT, FRONT STEERING CYLINDER..... | 510 |
| SEAL KIT, FUEL INJECTOR CONNECTOR (9901) (HDW01)..... | 261 |
| SEAL KIT, HYDRAULIC OIL COOLER BYPASS VALVE..... | 952 |
| SEAL KIT, HYDRAULIC PUMP DISCONNECT VALVE, COLD START (BREAKDOWN)..... | 1004 |
| SEAL KIT, MAIN HYDRAULIC PUMP..... | 878 |
| SEAL KIT, MID MOUNTED SCARIFIER CYLINDER..... | 1176 |
| SEAL KIT, REAR RIPPER/SCARIFIER CYLINDER..... | 1174 |
| SEAL KIT, RELIEF VALVE MAIN MANIFOLD VALVE (W/O SEC. STEERING)..... | 950 |
| SEAL KIT, RELIEF VALVE MAIN MANIFOLD VALVE (W/ SEC. STEERING)..... | 948 |
| SEAL KIT, REVERSING FAN VALVE..... | 432 |
| SEAL KIT, SCARIFIER CYLINDER..... | 1172 |
| SEAL KIT, SERVICE BRAKE VALVE..... | 520 |
| SEAL KIT, SOLENOID VALVE, MAIN MANIFOLD VALVE (W/O SEC. STEERING)..... | 950 |
| SEAL KIT, SOLENOID VALVE, MAIN MANIFOLD VALVE (W/ SEC. STEERING)..... | 948 |
| SEAL KIT, STEERING VALVE (STANDARD CONTROLS)..... | 500 |
| SEAL KIT, WATER SEPARATOR (81AL)..... | 352 |
| SEAL, AXLE HOUSING OIL..... | 68 |
| SEAL, DOOR (FULL HEIGHT CAB)..... | 732 |
| SEAL, DOOR (LOW PROFILE CAB)..... | 730 |
| SEAL, HVAC DUCTING..... | 812 |
| SEAL, REAR OIL (9901)..... | 382 |
| SEAT ARMRESTS (GRADE PRO)..... | 802 |
| SEAT BELT WARNING LABEL (ENGLISH, GRADE PRO)..... | 534 |
| SEAT BELT WARNING LABEL (ENGLISH, STD CAB)..... | 532 |
| SEAT BELT WARNING LABEL (FRENCH)..... | 536 |
| SEAT BELT WARNING LABEL (RUSSIAN)..... | 540 |
| SEAT BELT WARNING LABEL (SPANISH)..... | 538 |
| SEAT SUSPENSION (GRADE PRO)..... | 800 |
| SEAT SUSPENSION (PREMIUM)..... | 796 |
| SEAT SUSPENSION (STANDARD)..... | 792 |
| Seat (Grade Pro)..... | 798 |
| Seat (Premium)..... | 794 |
| Seat (Standard)..... | 790 |
| Secondary Steering..... | 484 |
| SECONDARY STEERING ACCUMULATOR..... | 484 |
| SECONDARY STEERING ACCUMULATOR (GRADE PRO)..... | 480 |
| SECONDARY STEERING HOSE..... | 484 |
| Secondary Steering (Field Kit)..... | 482 |
| Secondary Steering (Grade Pro)..... | 480 |
| SELECTOR, TRANSMISSION GEAR (GRADE PRO)..... | 114 |
| SELECTOR, TRANSMISSION GEAR (STANDARD CONTROLS)..... | 112 |
| SENDING UNIT, FUEL TANK..... | 468 |
| SENSOR, AIR FILTER RESTRICTION (6068HDW75)..... | 442 |
| SENSOR, AIR FILTER RESTRICTION (6090HDW01 / 6090HDW04)..... | 440 |
| SENSOR, AIR PRESSURE (6744)..... | 350 |
| Sensor, Air Temperature..... | 210 |
| SENSOR, AIR TEMPERATURE (6744)..... | 350 |
| SENSOR, CRANKSHAFT POSITION (4601)..... | 214 |
| SENSOR, CRANKSHAFT POSITION (4606)..... | 216 |
| SENSOR, DRAFT FRAME PITCH AND ROLL..... | 684 |
| SENSOR, ENGINE SPEED (6744)..... | 350 |
| SENSOR, FAN PRESSURE..... | 432 |
| SENSOR, HYDRAULIC PUMP PRESSURE..... | 484 |
| SENSOR, MAGNETIC PICK-UP (6744)..... | 350 |
| SENSOR, MAINFALL ANGLE..... | 684 |
| SENSOR, MAP (1701)..... | 186 |
| SENSOR, REAR STEERING (GRADE PRO)..... | 682 |
| SENSOR, REAR STEERING (STD CONTROLS)..... | 680 |
| SENSOR, ROTARY MANIFOLD..... | 684 |
| SENSOR, TEMPERATURE (1701)..... | 186 |
| SENSOR, TRANSMISSION..... | 120 |
| SENSOR, WATER IN FUEL, ADDITIONAL (6068HDW75)..... | 462 |
| SENSOR, WATER IN FUEL, ADDITIONAL (6090HDW01 / 6090HDW04)..... | 460 |
| SENSOR, WHEEL LEAN..... | 80 |
| SEPARATOR PLATE, BRAKE..... | 66 |
| Service Brakes..... | 66 |
| Service Brake Accumulator and Hoses..... | 522 |
| Service Brake Pedal and Valve..... | 520 |
| Service Doors..... | 832 |
| SERVICE ENGINE (9901) (HDW75)..... | 388 |
| SERVICE ENGINE (9901) (TN054)..... | 286 |
| SERVICE KIT, WATER PUMP INSERT..... | 383 |
| SERVICE PARTS ASSEMBLY (9901) (HDW75)..... | 384 |
| SEVENTH FUNCTION CONTROL LINKAGE (LEFT) (AUX W/O FLOAT)..... | 774 |
| SEVENTH FUNCTION CONTROL LINKAGE (RIGHT) (AUX W/O FLOAT)..... | 772 |
| SEVENTH FUNCTION CONTROL VALVE KIT (LEFT) (AUX W/O FLOAT)..... | 944 |
| SEVENTH FUNCTION CONTROL VALVE KIT (RIGHT) (AUX W/O FLOAT)..... | 942 |
| SEVEN FUNCTION CONTROL VALVE, LEFT..... | 898 |
| SEVEN FUNCTION CONTROL VALVE, REAR (EH) (GRADE PRO)..... | 970 |
| SEVEN FUNCTION CONTROL VALVE, RIGHT..... | 896 |
| SHAFT, AND AXLE HOUSING..... | 96 |
| SHAFT, DRIVE, FINAL DRIVE AND TANDEM PIVOT..... | 64 |
| SHAFT, ROCKER ARM (4901) (HDW01)..... | 222 |
| SHANK, FRONT MOUNTED SCARIFIER..... | 1128 |
| SHANK, MID MOUNTED SCARIFIER..... | 1140 |
| SHANK, REAR RIPPER..... | 1130 |
| SHANK, REAR SCARIFIER..... | 1134 |
| SHIELDS, FRONT FRAME..... | 834 |
| SHIFTER LABEL (ENGLISH, GRADE PRO)..... | 534 |
| SHIFTER LABEL (ENGLISH, STD CAB)..... | 532 |
| SHIFTER, TRANSMISSION GEAR (GRADE PRO)..... | 114 |
| SHIFTER, TRANSMISSION GEAR (STANDARD CONTROLS)..... | 112 |
| SHIFT CYLINDER HOSES, BLADE (GRADE PRO)..... | 1098 |
| SHIFT CYLINDER HOSES, BLADE (STANDARD CONTROLS)..... | 1096 |
| SHIM, BLADE LIFT CYLINDER..... | 1116 |
| SHIM, CIRCLE FRAME..... | 1064 |
| SHIM, CIRCLE SIDE SHIFT CYLINDER..... | 1122 |
| SHIM, DRAFT FRAME..... | 1064 |
| SHOCK ABSORBER KIT (GRADE PRO SEAT)..... | 800 |
| SHOCK ABSORBER KIT (PREMIUM SEAT)..... | 796 |
| SHOCK ABSORBER KIT (STANDARD SEAT)..... | 792 |
| SHORT BLOCK ASSEMBLY (9901)..... | 376 |
| SHORT BLOCK (9901)..... | 254, 258 |
| SHROUD, FAN..... | 424 |
| SHROUD, FAN (6068HDW75) (SERIAL NUMBER 626426-)..... | 418 |
| SHROUD, FAN (6068HDW75) (SERIAL NUMBER-626425)..... | 416 |
| SHROUD, FAN (6090HDW01 / 6090HDW04) (SN 626426-)..... | 410 |
| SHROUD, FAN (6090HDW01 / 6090HDW04) (SN-626425)..... | 408 |
| SHUTDOWN CAUTION LABEL (ENGLISH, GRADE PRO)..... | 534 |
| SHUTDOWN CAUTION LABEL (ENGLISH, STD CAB)..... | 532 |
| SHUTDOWN CAUTION LABEL (FRENCH)..... | 536 |
| SHUTDOWN CAUTION LABEL (RUSSIAN)..... | 540 |
| SHUTDOWN CAUTION LABEL (SPANISH)..... | 538 |
| SIDE CAB WORK LIGHTS..... | 582 |
| SIDE COVERS, MAIN FRAME..... | 836 |
| SIDE PANEL (FULL HEIGHT CAB)..... | 718, 720 |
| SIDE PANEL (GRADE PRO)..... | 714, 716 |
| SIDE PANEL (LOW PROFILE CAB - STD)..... | 710, 712 |
| SIDE SHIFT CYLINDER HOSES, CIRCLE (GRADE PRO)..... | 1106 |
| SIDE SHIFT CYLINDER HOSES, CIRCLE (STANDARD CONTROLS)..... | 1104 |
| SIDE SHIFT CYLINDER, CIRCLE..... | 1122 |
| SIGHT GAUGE, HYDRAULIC RESERVOIR..... | 1014 |
| SIGNAL LIGHTS, FRONT..... | 574 |
| SIXTH FUNCTION CONTROL LINKAGE (LEFT) (AUX W/ FLOAT)..... | 770 |
| SIXTH FUNCTION CONTROL LINKAGE (RIGHT) (AUX W/ FLOAT)..... | 768 |
| SIXTH FUNCTION CONTROL VALVE KIT (LEFT) (AUX W/ FLOAT)..... | 940 |
| SIXTH FUNCTION CONTROL VALVE KIT (RIGHT) (AUX W/ FLOAT)..... | 938 |
| SIXTH FUNCTION HYDRAULICS (GRADE PRO)..... | 1162 |
| SIXTH FUNCTION HYDRAULICS (STANDARD)..... | 1160 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> | | |
|---|---------------|--|------|
| SIXTH FUNCTION PLUMBING (GRADE PRO)..... | 1162 | STARTER JUMPER WIRING HARNESS (6090HDW01) | 606 |
| SIXTH FUNCTION PLUMBING (STANDARD)..... | 1160 | STARTER MOTOR KIT 9901 | 282 |
| SIXTH FUNCTION REAR AUXILIARY HOSES (SIXTH FUNCTION) | | STARTER MOTOR (3008) | 201 |
| (GRADE PRO)..... | 1170 | STARTER MOTOR (3059) | 314 |
| SIXTH FUNCTION REAR AUX HOSES (STANDARD | | STARTER RELAY (24V/100A) (6068HDW75) | 612 |
| CONTROLS)..... | 1168 | STARTER RELAY (24V/100A) (6090HDW01) | 606 |
| SIXTH FUNCTION (GRADE PRO)..... | 1162 | STARTER RELAY (9901)..... | 381 |
| SIXTH FUNCTION (STANDARD CONTROLS)..... | 1160 | STARTER RELAY-12V (9901) (HT067)..... | 375 |
| SIXTH FUNCTION, REAR AUXILIARY HOSES (SIXTH FUNCTION) | | STARTER (3005) 24V | 200 |
| (GRADE PRO)..... | 1170 | STARTER (3008)..... | 201 |
| SIXTH FUNCTION, REAR AUXILIARY HOSES (STANDARD | | STARTING AID | 326 |
| CONTROLS)..... | 1168 | STARTING AID (4397) | 212 |
| SIXTH STAGE SHAFT ASSEMBLY (YZ106680)..... | 146 | STARTING MOTOR (3005)..... | 200 |
| SIX FUNCTION CONTROL VALVE, FRONT W/ MID MOUNTED | | START AID, EITHER..... | 392 |
| SCARIFIER (GRADE PRO)..... | 966 | START AND STOP PROCEDURE LABEL (ENGLISH, GRADE | |
| SIX FUNCTION CONTROL VALVE, FRONT (EH) (GRADE PRO)... | 964 | PRO)..... | 534 |
| SIX FUNCTION CONTROL VALVE, LEFT..... | 894 | START AND STOP PROCEDURE LABEL (ENGLISH, STD CAB)... | 532 |
| SIX FUNCTION CONTROL VALVE, REAR (EH) (GRADE PRO)... | 968 | START/STOP PROCEDURE LABEL (FRENCH)..... | 536 |
| SIX FUNCTION CONTROL VALVE, RIGHT..... | 892 | START/STOP PROCEDURE LABEL (RUSSIAN)..... | 540 |
| SIX WHEEL DRIVE INSTRUMENT PANEL LABEL (FRENCH)..... | 536 | START/STOP PROCEDURE LABEL (SPANISH)..... | 538 |
| SLEEVE, FRONT GRADE PRO VALVE CONNECTORS..... | 650 | STATIONARY CONSOLE, CAB FRONT..... | 754 |
| SLEEVE, FUEL HOSE (6068HDW75)..... | 458 | STATIONARY WINDOWS (LOW PROFILE CAB)..... | 734 |
| SLEEVE, FUEL HOSE (6090HDW01 / 6090HDW04)..... | 456 | STEERING COLUMN STANDARD..... | 486 |
| SLEEVE, SHIFTER LOCK (GRADE PRO)..... | 114 | STEERING COLUMN (GRADE PRO)..... | 488 |
| SLEEVE, SHIFTER LOCK (STANDARD CONTROLS)..... | 112 | STEERING CYLINDER, FRONT..... | 508 |
| SLIDE CONTROL KIT (DELUXE SEAT)..... | 794 | STEERING CYLINDER, FRONT, COMPONENTS | 510 |
| SLIDE CONTROL KIT (GRADE PRO SEAT)..... | 798 | STEERING CYLINDER, REAR COMPONENTS | 514 |
| SLIDE CONTROL KIT (STANDARD SEAT)..... | 790 | STEERING CYLINDER, REAR PINS..... | 512 |
| SLIDE CYLINDER, BLADE..... | 1118 | Steering Hoses (Grade Pro)..... | 502 |
| SLIDE PUCK KIT (DELUXE SEAT)..... | 794 | Steering Hoses (Standard Controls)..... | 500 |
| SLIDE PUCK KIT (GRADE PRO SEAT)..... | 798 | STEERING JOYSTICK, LEFT 4 FUNCTION (EH) (GRADE PRO)... | 782 |
| SLIDE PUCK KIT (STANDARD SEAT)..... | 790 | STEERING JOYSTICK, LEFT 5 FUNCTION (EH) (GRADE PRO)... | 786 |
| SLIDE SPRING KIT (DELUXE SEAT)..... | 794 | Steering Priority Valve | 490 |
| SLIDE SPRING KIT (GRADE PRO SEAT)..... | 798 | STEERING SENSOR, REAR (GRADE PRO)..... | 682 |
| SLIDE SPRING KIT (STANDARD SEAT)..... | 790 | STEERING SENSOR, REAR (STD CONTROLS) | 680 |
| SLIP CLUTCH, CIRCLE DRIVE GEARBOX..... | 1076 | STEERING SPINDLE (LEFT)..... | 82 |
| Slow Moving Vehicle Sign | 876 | STEERING SPINDLE (RIGHT)..... | 80 |
| SMV SIGN..... | 876 | Steering System (Grade Pro)..... | 488 |
| Snow Light Brackets..... | 586 | Steering System (Standard)..... | 486 |
| SNOW LIGHT BRACKET WIRING HARNESS..... | 586 | STEERING VALVE..... | 486 |
| SOLENOID VALVE (REVERSING FAN)..... | 432 | STEERING VALVE HOSES (STANDARD CONTROLS)..... | 500 |
| SOLENOID VALVE 24V..... | 170 | STEERING VALVE SEAL KIT (STANDARD CONTROLS) | 500 |
| SOLENOID VALVE, ETHER START AID..... | 392 | Steering Valve Section (Grade Pro)..... | 976 |
| SOLENOID VALVE, HYDRAULIC PUMP DISCONNECT, COLD START | | STEERING VALVE (STANDARD CONTROLS)..... | 500 |
| (BREAKDOWN)..... | 1004 | STEERING WHEEL..... | 486 |
| SOLENOID VALVE, HYDRAULIC PUMP DISCONNECT, COLD START | | STEERING WHEEL CENTER COVER..... | 486 |
| (COMPLETE)..... | 1002 | STEERING WHEEL CENTER COVER (GRADE PRO)..... | 488 |
| SOLENOID VALVE, HYDRAULIC WARMUP CIRCUIT..... | 1010 | STEERING WHEEL (GRADE PRO)..... | 488 |
| SOLENOID VALVE, MAIN MANIFOLD VALVE (W/O SEC. | | Stem, Valve, Wheel (10 in. X 24 in.) (For 14X24 or 14R24 Tires) (Split | |
| STEERING)..... | 950 | Rim)..... | 54 |
| SOLENOID VALVE, MAIN MANIFOLD VALVE (W/ SEC. | | Stem, Valve, Wheel (13 in. X 25 in.) (For 17.5X25 or 17.5R25 Tires) .. | 56 |
| STEERING)..... | 948 | Stem, Valve, Wheel (14 in. X 25 in.) (For 17.5X25 or 17.5R25 Tires) | |
| SOLENOID, A/C COMPRESSOR..... | 826 | (Split Rim)..... | 58 |
| SOLENOID, BLADE IMPACT VALVE..... | 1086 | Stem, Valve, Wheel (9 in. X 24 in.) (FOR 14X24 OR 14R24 TIRES) | |
| Sound Absorption (Engine)..... | 844 | (One Piece)..... | 52 |
| SPACER, FAN..... | 424 | STEPS, CAB..... | 804 |
| SPANISH LABELS AND TRADEMARKS..... | 538 | STEP, BOTTOM GUARD..... | 690 |
| SPEAKERS..... | 854 | STEP, TANDEM HOUSING..... | 60 |
| SPEAKER GRILLE (FULL HEIGHT CAB)..... | 718, 720 | STRAINER, HYDRAULIC RESERVOIR | 1014 |
| SPEAKER GRILLE (GRADE PRO)..... | 714, 716 | STRAPS (9801)..... | 360 |
| SPEAKER GRILLE (LOW PROFILE CAB - STD)..... | 710, 712 | STRAPS, LIFT (9801) | 245 |
| SPEED CONTROL PEDAL, ENGINE (GRADE PRO)..... | 436 | STRAPS, LIFT (9807) | 246 |
| SPEED CONTROL PEDAL, ENGINE (STANDARD)..... | 434 | STRAP, ALTERNATOR, 100AMP (6068HDW75)..... | 566 |
| SPINDLE, STEERING (LEFT)..... | 82 | STRAP, ALTERNATOR, 100AMP (6090HDW01 / 6090HDW04) | 562 |
| SPINDLE, STEERING (RIGHT)..... | 80 | STRAP, ALTERNATOR, 130AMP (6068HDW75)..... | 568 |
| SPIRAL BEVEL ASSEMBLY 4.364 (RE35708)..... | 92 | STRAP, ALTERNATOR, 130AMP (6090HDW01 / 6090HDW04)..... | 564 |
| SPRING, DOOR LATCH (FULL HEIGHT CAB)..... | 732 | STRAP, CAB STEPS..... | 804 |
| SPRING, DOOR LATCH (LOW PROFILE CAB)..... | 730 | STRIKER, DOOR (FULL HEIGHT CAB)..... | 732 |
| SPROCKET, AXLE DRIVE..... | 68 | STRIKER, DOOR (LOW PROFILE CAB)..... | 730 |
| SPROCKET, DRIVE..... | 64 | Strobe Beacon..... | 592 |
| SSM ICON DESCRIPTION LABEL (ENGLISH, GRADE PRO)..... | 534 | STUD, FRONT EH EIGHT FUNCTION CONTROL VALVE (GRADE | |
| SSM ICON DESCRIPTION LABEL (ENGLISH, STD CAB)..... | 532 | PRO)..... | 972 |
| SSM ICON DESCRIPTION LABEL (FRENCH)..... | 536 | STUD, FRONT EH FIVE FUNCTION CONTROL VALVE (GRADE | |
| SSM ICON DESCRIPTION LABEL (RUSSIAN)..... | 540 | PRO)..... | 960 |
| SSM ICON DESCRIPTION LABEL (SPANISH)..... | 538 | STUD, FRONT EH SIX FUNCTION CONTROL VALVE W/ MMS | |
| Standard Blade Inserts..... | 1072 | (GRADE PRO)..... | 966 |
| Standard Circle Inserts (Without Slip Clutch)..... | 1066 | STUD, FRONT EH SIX FUNCTION CONTROL VALVE (GRADE | |
| Standard Circle Inserts (With Slip Clutch)..... | 1068 | PRO)..... | 964 |
| Standard Control Linkages..... | 762 | STUD, LEFT FIVE FUNCTION CONTROL VALVE..... | 890 |
| STARTER BYPASS LABEL (RUSSIAN)..... | 540 | STUD, LEFT FOUR FUNCTION CONTROL VALVE | 884 |
| STARTER BY-PASS LABEL (FRENCH)..... | 536 | STUD, LEFT SEVEN FUNCTION CONTROL VALVE | 898 |
| STARTER BY-PASS LABEL (SPANISH)..... | 538 | STUD, LEFT SIX FUNCTION CONTROL VALVE..... | 894 |
| STARTER JUMPER WIRING HARNESS (6068HDW75)..... | 612 | | |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> |
|--|---------------|
| STUD, REAR EH FIVE FUNCTION CONTROL VALVE (GRADE PRO)..... | 962 |
| STUD, REAR EH FOUR FUNCTION CONTROL VALVE (GRADE PRO)..... | 958 |
| STUD, REAR EH SEVEN FUNCTION CONTROL VALVE (GRADE PRO)..... | 970 |
| STUD, REAR EH SIX FUNCTION CONTROL VALVE (GRADE PRO)..... | 968 |
| STUD, RIGHT FIVE FUNCTION CONTROL VALVE..... | 886 |
| STUD, RIGHT FIVE FUNCTION CONTROL VALVE (MID MOUNTED SCARIFIER)..... | 888 |
| STUD, RIGHT FOUR FUNCTION CONTROL VALVE..... | 882 |
| STUD, RIGHT SEVEN FUNCTION CONTROL VALVE..... | 896 |
| STUD, RIGHT SIX FUNCTION CONTROL VALVE..... | 892 |
| SUCTION CONTROL VALVE (169Z)..... | 300 |
| SUCTION CONTROL VALVE (9901)..... | 252 |
| SUNSCREEN (FULL HEIGHT CAB)..... | 718, 720 |
| SUNSCREEN (GRADE PRO)..... | 714, 716 |
| SUNSCREEN (LOW PROFILE CAB - STD)..... | 710, 712 |
| SUNSHADE, FRONT WINDOW..... | 872 |
| SUNSHADE, REAR WINDOW..... | 874 |
| SUNVISOR, FRONT WINDOW..... | 872 |
| SUNVISOR, REAR WINDOW..... | 874 |
| SUPPORTS, ENGINE MOUNTING (6068HDW75)..... | 454 |
| SUPPORTS, ENGINE MOUNTING (6090HDW01 / 6090HDW04)..... | 452 |
| SUPPORT, CIRCLE FRAME..... | 1064 |
| SUPPORT, DEFROST HOSES..... | 812 |
| SUPPORT, HOOD (6068HDW75)..... | 830 |
| SUPPORT, HOOD (6090HDW01 / 6090HDW04)..... | 828 |
| SURGE TANK (6068HDW75) (SERIAL NUMBER 626426-)..... | 422 |
| SURGE TANK (6068HDW75) (SERIAL NUMBER-626425)..... | 420 |
| SURGE TANK (6090HDW01 / 6090HDW04)..... | 414 |
| SURGE TANK (6090HDW01 / 6090HDW04) (SN-626425)..... | 412 |
| SUSPENSION SEAT (GRADE PRO)..... | 800 |
| SUSPENSION SEAT (PREMIUM)..... | 796 |
| SUSPENSION SEAT (STANDARD)..... | 792 |
| SUSPENSION, SEAT (DELUXE)..... | 794 |
| SUSPENSION, SEAT (GRADE PRO)..... | 798 |
| SUSPENSION, SEAT (STD)..... | 790 |
| SWASHPLATE, MAIN HYDRAULIC PUMP..... | 878 |
| SWITCH MODULE, SEALED (GRADE PRO)..... | 662 |
| SWITCH MODULE, SEALED (STD CONTROLS)..... | 660 |
| SWITCH, A/C AND HEATER FAN SPEED..... | 818 |
| SWITCH, A/C AND HEATER ON/OFF..... | 818 |
| SWITCH, A/C AND HEATER THERMOSTAT..... | 820 |
| SWITCH, A/C AND HEAT TEMPERATURE CONTROL..... | 818 |
| SWITCH, BATTERY DISCONNECT (1000 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 554 |
| SWITCH, BATTERY DISCONNECT (1000 CCA) (6068HDW75)..... | 558 |
| SWITCH, BATTERY DISCONNECT (1400 CCA BATTERIES) (6090HDW01 / 6090HDW04)..... | 556 |
| SWITCH, BATTERY DISCONNECT (1400 CCA) (6068HDW75)..... | 560 |
| SWITCH, BLADE IMPACT (GRADE PRO)..... | 1090 |
| SWITCH, BLADE IMPACT (STD CONTROLS)..... | 1088 |
| SWITCH, BRAKE ACCUMULATOR PRESSURE..... | 520 |
| SWITCH, BRAKE LIGHT..... | 520 |
| SWITCH, DIFFERENTIAL LOCK..... | 676 |
| SWITCH, DIFFERENTIAL LOCK (GRADE PRO)..... | 636 |
| SWITCH, EH AUXILIARY CONTROLS (GRADE PRO)..... | 788 |
| SWITCH, ENGINE COMPARTMENT WORK LIGHTS..... | 584 |
| SWITCH, ENGINE SPEED CONTROL ON/OFF (GRADE PRO)..... | 436 |
| SWITCH, ENGINE SPEED CONTROL ON/OFF (STANDARD)..... | 434 |
| SWITCH, ENGINE SPEED CONTROL SET (GRADE PRO)..... | 436 |
| SWITCH, ENGINE SPEED CONTROL SET (STANDARD)..... | 434 |
| SWITCH, FILTER RESTRICTION, MAIN HYDRAULIC FILTER..... | 1012 |
| SWITCH, FLOAT (GRADE PRO)..... | 636 |
| SWITCH, HEATED SEAT (DELUXE)..... | 794 |
| SWITCH, HEATED SEAT (GRADE PRO)..... | 798 |
| SWITCH, HEATER AND A/C BLOWER MOTOR..... | 820 |
| SWITCH, HI-LOW BEAM..... | 676 |
| SWITCH, HI-LOW BEAM (GRADE PRO)..... | 678 |
| SWITCH, HORN..... | 676 |
| SWITCH, HORN (GRADE PRO)..... | 636 |
| SWITCH, HYDRAULIC WARMUP CIRCUIT..... | 1010 |
| SWITCH, MAIN HYD FILTER PRESSURE..... | 1012 |
| SWITCH, RESTRICTION, DIFFERENTIAL LOCK FILTER..... | 90 |
| SWITCH, RESTRICTION, TRANSMISSION FILTER..... | 132 |
| SWITCH, SADDLE LOCKING PIN INDICATOR..... | 1124 |
| SWITCH, SEALED (GRADE PRO)..... | 662 |
| SWITCH, SEALED (STD CONTROLS)..... | 660 |
| SWITCH, TURN SIGNAL..... | 676 |
| SWITCH, TURN SIGNAL (GRADE PRO)..... | 678 |
| SWIVEL (GRADE PRO)..... | 1080 |
| SWIVEL (STD CONTROLS)..... | 1078 |
| T | |
| Tail Lights..... | 576 |
| TAIL LIGHT WIRING HARNESS..... | 576 |
| Tandem Drive and Planetary..... | 62 |
| TANDEM DRIVE CHAIN..... | 68 |
| Tandem Housing..... | 60 |
| TANDEM PIVOT..... | 64 |
| Tandem Pivots Grease Lines Kit..... | 86 |
| TANK, COOLANT HEATER (120V) (6068HDW75)..... | 396 |
| TANK, COOLANT HEATER (120V) (6090HDW01 / 6090HDW04)..... | 394 |
| TANK, COOLANT HEATER, DIESEL FIRED (6090HDW01 / 6090HDW04)..... | 400 |
| TANK, FUEL..... | 468 |
| TANK, SURGE (6068HDW75) (SERIAL NUMBER 626426-)..... | 422 |
| TANK, SURGE (6068HDW75) (SERIAL NUMBER-626425)..... | 420 |
| TANK, SURGE (6090HDW01 / 6090HDW04) (SN 626426-)..... | 414 |
| TANK, SURGE (6090HDW01 / 6090HDW04) (SN-626425)..... | 412 |
| TANK, WINDSHIELD WASHER (FULL HEIGHT CAB)..... | 744 |
| TANK, WINDSHIELD WASHER (LOW PROFILE CAB)..... | 742 |
| TAPPET (4901) (HDW01)..... | 222 |
| TAPPET, PUSH ROD, ROCKER ARM, SHAFT (4905)..... | 336 |
| TCU..... | 116 |
| TEETH, FRONT MOUNTED SCARIFIER..... | 1128 |
| TEETH, MID MOUNTED SCARIFIER..... | 1140 |
| TEETH, REAR SCARIFIER..... | 1134 |
| TEETH, RIPPER..... | 1130 |
| TEMPERATURE SENSOR (1701)..... | 186 |
| TEMPERATURE SENSOR, AIR (1797)..... | 302 |
| TEMPERATURE SWITCH PLUG (6698)..... | 348 |
| TENSIONER (8724)..... | 356 |
| TERMINAL, CAB GROUND..... | 624 |
| TERMINAL, REAR DEFROST..... | 626 |
| TERMINATOR, CAN (GRADE PRO IGC HARNESS)..... | 640 |
| THERMOCOUPLE (6744)..... | 350 |
| THERMOSTAT COVER (2107)..... | 191 |
| THERMOSTAT COVER (2154)..... | 307 |
| THERMOSTAT HOUSING (3903)..... | 206 |
| THERMOSTAT HOUSING (3926)..... | 322 |
| THERMOSTAT (2201) (HDW01)..... | 192 |
| THERMOSTAT (2255)..... | 308 |
| THERMOSTAT, A/C AND HEATER SWITCH..... | 820 |
| THIRD STAGE SHAFT ASSEMBLY (YZ106563)..... | 140 |
| THRUST BEARING KIT (9901)..... | 251, 364 |
| THRUST BEARING (9901)..... | 364 |
| Thrust Bearing, Crankshaft..... | 218 |
| THRUST BEARING, MAIN (9901)..... | 365 |
| TIE DOWN, LABEL..... | 530 |
| TIE ROD END, FRONT AXLE..... | 78 |
| TIE ROD, FRONT AXLE..... | 78 |
| TIE ROD, FRONT EH EIGHT FUNCTION CONTROL VALVE (GRADE PRO)..... | 972 |
| TIE ROD, FRONT EH FIVE FUNCTION CONTROL VALVE (GRADE PRO)..... | 960 |
| TIE ROD, FRONT EH SIX FUNCTION CONTROL VALVE W/ MMS (GRADE PRO)..... | 966 |
| TIE ROD, FRONT EH SIX FUNCTION CONTROL VALVE (GRADE PRO)..... | 964 |
| TIE ROD, LEFT FIVE FUNCTION CONTROL VALVE..... | 890 |
| TIE ROD, LEFT FOUR FUNCTION CONTROL VALVE..... | 884 |
| TIE ROD, LEFT SEVEN FUNCTION CONTROL VALVE..... | 898 |
| TIE ROD, LEFT SIX FUNCTION CONTROL VALVE..... | 894 |
| TIE ROD, REAR EH FIVE FUNCTION CONTROL VALVE (GRADE PRO)..... | 962 |
| TIE ROD, REAR EH FOUR FUNCTION CONTROL VALVE (GRADE PRO)..... | 958 |
| TIE ROD, REAR EH SEVEN FUNCTION CONTROL VALVE (GRADE PRO)..... | 970 |
| TIE ROD, REAR EH SIX FUNCTION CONTROL VALVE (GRADE PRO)..... | 968 |
| TIE ROD, RIGHT FIVE FUNCTION CONTROL VALVE..... | 886 |
| TIE ROD, RIGHT FIVE FUNCTION CONTROL VALVE (MID MOUNTED SCARIFIER)..... | 888 |
| TIE ROD, RIGHT FOUR FUNCTION CONTROL VALVE..... | 882 |
| TIE ROD, RIGHT SEVEN FUNCTION CONTROL VALVE..... | 896 |
| TIE ROD, RIGHT SIX FUNCTION CONTROL VALVE..... | 892 |
| TILT CONSOLE WIRING HARNESS, FRONT (GRADE PRO)..... | 656 |
| TILT CONSOLE WIRING HARNESS, FRONT (STANDARD CONTROLS)..... | 654 |
| TILT CYLINDER HOSES, BLADE (GRADE PRO)..... | 1098 |

Índice alfabético, continuación

| <i>Página</i> | <i>Página</i> | | |
|--|---------------|--|-----|
| TILT CYLINDER HOSES, BLADE (STANDARD CONTROLS)..... | 1096 | TURN LIGHT WIRING HARNESS, FRONT..... | 594 |
| TILT CYLINDER, BLADE..... | 1120 | TURN LIGHT WIRING HARNESS, FRONT (CONNECTORS)..... | 604 |
| TILT FRAME, BLADE..... | 1062 | TURN SIGNAL LIGHTS, LED..... | 576 |
| TILT STEERING CONSOLE (GRADE PRO)..... | 778 | TURN SIGNAL SWITCH..... | 676 |
| TILT STEERING CONSOLE (STD CONTROLS)..... | 760 | TURN SIGNAL SWITCH (GRADE PRO)..... | 678 |
| TIMER, DIESEL FIRED COOLANT HEATER (6090HDW01 / | | | |
| 6090HDW04)..... | 400 | | |
| TIMING GEAR COVER AND WATER PUMP (4436)..... | 328 | U | |
| TIMING GEAR COVER (7701)..... | 236 | | |
| Tool Box..... | 870 | UNIVERSAL JOINT, DRIVESHAFT..... | 72 |
| Torsional Isolator..... | 118 | | |
| Trademarks and Labels (English)..... | 530 | V | |
| Trademarks and Labels (French)..... | 536 | | |
| Trademarks and Labels (Russian)..... | 540 | VALVE ASSEMBLY (YZ106602)..... | 158 |
| Trademarks and Labels (Spanish)..... | 538 | VALVE BODY ASSEMBLY (YZ120442)..... | 110 |
| TRADEMARKS AND LABELS, ENGLISH..... | 530 | VALVE CONTROL GROUP (YZ106603)..... | 156 |
| TRADEMARKS AND LABELS, ENGLISH (GRADE PRO CAB)..... | 534 | VALVE COVER (1102)..... | 178 |
| TRADEMARKS AND LABELS, ENGLISH (STANDARD CAB)..... | 532 | VALVE COVER, FRONT (GRADE PRO) (EH)..... | 842 |
| TRANSFER FUEL, PUMP (3713)..... | 320 | VALVE EGR, GASKET KIT (9901)..... | 370 |
| Transmission..... | 120 | VALVE GUARD, TRANSMISSION..... | 846 |
| TRANSMISSION CHARGE PUMP GROUP (YZ106549)..... | 162 | VALVE HOSES, FAN..... | 430 |
| Transmission Control Unit..... | 116 | VALVE KIT, AUX W/O FLOAT (SEVENTH FUNCTION LEFT)..... | 944 |
| Transmission Cooler Hoses..... | 406 | VALVE KIT, AUX W/O FLOAT (SEVENTH FUNCTION RIGHT)..... | 942 |
| Transmission Diagnostic Fittings..... | 130 | VALVE KIT, AUX W/ FLOAT (SIXTH FUNCTION LH)..... | 940 |
| TRANSMISSION DIPSTICK AND TUBE..... | 122 | VALVE KIT, AUX W/ FLOAT (SIXTH FUNCTION RH)..... | 938 |
| Transmission Filter..... | 132 | VALVE KIT, ELECTROHYDRAULIC AUXILIARY (GRADE PRO)..... | 996 |
| TRANSMISSION FILTER LABEL (ENGLISH)..... | 530 | VALVE KIT, ONE HAND BLADE LIFT KIT..... | 946 |
| TRANSMISSION FILTER LABEL (FRENCH)..... | 536 | VALVE KIT, RIPPER (FIFTH FUNCTION LH)..... | 936 |
| TRANSMISSION FILTER LABEL (RUSSIAN)..... | 540 | VALVE KIT, SCARIFIER (FIFTH FUNCTION RH)..... | 934 |
| TRANSMISSION FILTER LABEL (SPANISH)..... | 538 | VALVE MOUNTING BRACKETS, MAIN CONTROL..... | 880 |
| TRANSMISSION FRONT HSG..... | 166 | VALVE MOUNT, FRONT EH (GRADE PRO)..... | 954 |
| Transmission Gear Selector (Grade Pro)..... | 114 | VALVE MOUNT, REAR EH (GRADE PRO)..... | 956 |
| Transmission Gear Selector (Standard Controls)..... | 112 | VALVE RELIEF, MID MOUNTED SCARIFIER VALVE SECTION | |
| TRANSMISSION HOSE FITTING (YZ106766)..... | 164 | (STD)..... | 922 |
| Transmission Lines and Fittings..... | 124 | VALVE SECTION, AUXILIARY (EH) (GRADE PRO) | |
| Transmission Mounting Parts..... | 122 | (BREAKDOWN)..... | 994 |
| TRANSMISSION OIL COOLER HOSES (6068HDW75)(SERIAL | | VALVE SECTION, BLADE LIFT (EH) (GRADE PRO) | |
| NUMBER 626426-)..... | 422 | (BREAKDOWN)..... | 978 |
| TRANSMISSION OIL COOLER HOSES (6068HDW75)(SERIAL | | VALVE SECTION, BLADE SIDE SHIFT (EH) (GRADE PRO) | |
| NUMBER-626425)..... | 420 | (BREAKDOWN)..... | 984 |
| TRANSMISSION OIL COOLER HOSES (6090HDW01 / | | VALVE SECTION, BLADE SIDE SHIFT (STD) (BREAKDOWN)..... | 910 |
| 6090HDW04)(SN 626426-)..... | 414 | VALVE SECTION, BLADE TILT (EH) (BREAKDOWN) (GRADE | |
| TRANSMISSION OIL COOLER HOSES (6090HDW01 / | | PRO)..... | 980 |
| 6090HDW04)(SN-626425)..... | 412 | VALVE SECTION, BLADE TILT (STD) (BREAKDOWN)..... | 914 |
| TRANSMISSION OIL COOLER (6068HDW75) (SERIAL NUMBER | | VALVE SECTION, CIRCLE ROTATE (EH) (GRADE PRO) | |
| 626426-)..... | 418 | (BREAKDOWN)..... | 982 |
| TRANSMISSION OIL COOLER (6068HDW75) (SERIAL | | VALVE SECTION, CIRCLE ROTATE (STD) (BREAKDOWN)..... | 912 |
| NUMBER-626425)..... | 416 | VALVE SECTION, CIRCLE SIDE SHIFT (EH) (BREAKDOWN) (GRADE | |
| TRANSMISSION OIL COOLER (6090HDW01 / 6090HDW04)(SN | | PRO)..... | 988 |
| 626426-)..... | 410 | VALVE SECTION, CIRCLE SIDE SHIFT (STD) (BREAKDOWN)..... | 908 |
| TRANSMISSION OIL COOLER (6090HDW01 / | | VALVE SECTION, INLET AND OUTLET (LEFT) (STD)..... | 918 |
| 6090HDW04)(SN-626425)..... | 408 | VALVE SECTION, INLET AND OUTLET (RIGHT) (STD)..... | 916 |
| TRANSMISSION OIL DIAGNOSTIC FITTING (6068HDW75)..... | 548 | VALVE SECTION, INLET (FRONT EH) (GRADE PRO) | |
| TRANSMISSION OIL DIAGNOSTIC FITTING (6090HDW01 / | | (BREAKDOWN)..... | 992 |
| 6090HDW04)..... | 546 | VALVE SECTION, INLET (REAR EH) (GRADE PRO) | |
| TRANSMISSION OIL LABEL..... | 530 | (BREAKDOWN)..... | 990 |
| TRANSMISSION OIL LEVEL LABEL (ENGLISH)..... | 530 | VALVE SECTION, LEFT AUXILIARY (WITHOUT FLOAT) (STD) | |
| TRANSMISSION OIL LEVEL LABEL (FRENCH)..... | 536 | (BREAKDOWN)..... | 932 |
| TRANSMISSION OIL LEVEL LABEL (RUSSIAN)..... | 540 | VALVE SECTION, LEFT AUX VALVE WITH FLOAT (STD) | |
| TRANSMISSION OIL LEVEL (SPANISH)..... | 538 | (BREAKDOWN)..... | 928 |
| TRANSMISSION OUTPUT GROUP(YZ106448)..... | 148 | VALVE SECTION, LEFT BLADE LIFT (STD) (BREAKDOWN)..... | 902 |
| TRANSMISSION REAR HSG..... | 168 | VALVE SECTION, MID MOUNTED SCARIFIER (STD) | |
| TRANSMISSION SECOND STAGE ASSEMBLY (YZ106765)..... | 138 | (BREAKDOWN)..... | 922 |
| TRANSMISSION SENSOR..... | 120 | VALVE SECTION, REAR STEER (EH) (GRADE PRO) | |
| Transmission Valve Guards..... | 846 | (BREAKDOWN)..... | 974 |
| Transmission Wiring Harness..... | 618, 620 | VALVE SECTION, REAR STEER (STD) (BREAKDOWN)..... | 904 |
| TRAVEL ALARM..... | 866 | VALVE SECTION, RIGHT AUXILIARY (WITHOUT FLOAT) (STD) | |
| TRAY, CAB..... | 814 | (BREAKDOWN)..... | 930 |
| TRAY, TOOLBOX..... | 870 | VALVE SECTION, RIGHT AUX VALVE WITH FLOAT (STD) | |
| TRIM, CAB (FULL HEIGHT CAB)..... | 718, 720 | (BREAKDOWN)..... | 926 |
| TRIM, CAB (GRADE PRO)..... | 714, 716 | VALVE SECTION, RIGHT BLADE LIFT (STD) (BREAKDOWN)..... | 900 |
| TRIM, CAB (LOW PROFILE - STD)..... | 710, 712 | VALVE SECTION, RIPPER (EH) (BREAKDOWN) (GRADE PRO)..... | 994 |
| TUBE, OIL PUMP INTAKE (5024)..... | 338 | VALVE SECTION, RIPPER (STD) (BREAKDOWN)..... | 924 |
| TUBE, ROTARY EJECTOR PRECLEANER (6068HDW75)..... | 446 | VALVE SECTION, SCARIFIER (EH) (GRADE PRO) | |
| TUBE, ROTARY EJECTOR PRECLEANER (6090HDW01 / | | (BREAKDOWN)..... | 994 |
| 6090HDW04)..... | 444 | VALVE SECTION, SCARIFIER (STD) (BREAKDOWN)..... | 920 |
| TUBE, THERMOSTAT HOUSING (3926)..... | 322 | VALVE SECTION, STEERING (EH) (GRADE PRO) | |
| TUBE, TRANSMISSION OIL DIPSTICK..... | 122 | (BREAKDOWN)..... | 976 |
| TUBE, WATER PUMP BYPASS 2107..... | 191 | VALVE SECTION, WHEEL LEAN (EH) (GRADE PRO) | |
| TURBOCHARGER (65VS)..... | 346 | (BREAKDOWN)..... | 986 |
| TURBOCHARGER 6511..... | 234 | VALVE SECTION, WHEEL LEAN (STD) (BREAKDOWN)..... | 906 |
| TURBO AIR INLET (5497)..... | 342 | | |
| TURBO OIL SUPPLY LINE (5912)..... | 230 | | |

Índice alfabético, continuación

| Página | W | Página |
|--|---|----------|
| Valve Stem, Wheel (10 in. X 24 in.) (For 14X24 or 14R24 Tires) (Split Rim)..... | | 54 |
| Valve Stem, Wheel (13 in. X 25 in.) (For 17.5X25 or 17.5R25 Tires) .. | | 56 |
| Valve Stem, Wheel (14 in. X 25 in.) (For 17.5X25 or 17.5R25 Tires) (Split Rim) | | 58 |
| Valve Stem, Wheel (9 in. X 24 in.) (FOR 14X24 OR 14R24 TIRES) (One Piece)..... | | 52 |
| VALVE , CONTROL (9901) | | 367 |
| VALVE, BLADE IMPACT | | 1086 |
| VALVE, BLADE LIFT (EH) (BREAKDOWN) (GRADE PRO)..... | | 978 |
| VALVE, BRAKE | | 520 |
| VALVE, CHECK (REVERSING FAN) | | 432 |
| VALVE, CHECK, A/C EVAPORATION (6068HDW75) | | 824 |
| VALVE, CHECK, A/C EVAPORATION (6090HDW01 / 6090HDW04) | | 822 |
| VALVE, CONTROL COVERS (STANDARD)..... | | 838 |
| VALVE, DIRECTIONAL (REVERSING FAN)..... | | 432 |
| VALVE, EH FRONT CONTROL (6 FUNCTION MMS) (GRADE PRO)..... | | 966 |
| VALVE, EH FRONT, CONTROL (5 FUNCTION) (GRADE PRO)..... | | 960 |
| VALVE, EH FRONT, CONTROL (6 FUNCTION) (GRADE PRO)..... | | 964 |
| VALVE, EH FRONT, CONTROL (8 FUNCTION) (GRADE PRO)..... | | 972 |
| VALVE, EH REAR, CONTROL (4 FUNCTION) (GRADE PRO)..... | | 958 |
| VALVE, EH REAR, CONTROL (5 FUNCTION) (GRADE PRO)..... | | 962 |
| VALVE, EH REAR, CONTROL (6 FUNCTION) (GRADE PRO)..... | | 968 |
| VALVE, EH REAR, CONTROL (7 FUNCTION) (GRADE PRO)..... | | 970 |
| VALVE, ENGINE OIL BY-PASS (4601) | | 214 |
| VALVE, ENGINE OIL BY-PASS (4606) | | 216 |
| VALVE, EXHAUST (5101) | | 226 |
| VALVE, EXHAUST (5128)..... | | 340 |
| VALVE, EXPANSION, WITH TEMP SWITCH | | 820 |
| VALVE, FAST FILL INLET..... | | 470 |
| VALVE, HEATER CONTROL..... | | 820 |
| VALVE, HYDRAULIC OIL COOLER BYPASS..... | | 952 |
| VALVE, HYDRAULIC PUMP DISCONNECT, COLD START (BREAKDOWN)..... | | 1004 |
| VALVE, HYDRAULIC PUMP DISCONNECT, COLD START (COMPLETE)..... | | 1002 |
| VALVE, HYDRAULIC WARMUP CIRCUIT | | 1010 |
| VALVE, INTAKE (5101) | | 226 |
| VALVE, INTAKE (5128) | | 340 |
| VALVE, LEFT BLADE LIFT (STD) (BREAKDOWN)..... | | 902 |
| VALVE, LEFT CONTROL (4 FUNCTION) | | 884 |
| VALVE, LEFT CONTROL (5 FUNCTION) | | 890 |
| VALVE, LEFT CONTROL (6 FUNCTION) | | 894 |
| VALVE, LEFT CONTROL (7 FUNCTION) | | 898 |
| VALVE, LOCKOUT, BLADE LIFT VALVE SECTION (EH) (GRADE PRO) (BREAKDOWN)..... | | 978 |
| VALVE, LOCKOUT, LEFT BLADE LIFT VALVE SECTION (STD)..... | | 902 |
| VALVE, LOCKOUT, RIGHT BLADE LIFT VALVE SECTION (STD) (BREAKDOWN)..... | | 900 |
| VALVE, MAIN MANIFOLD (W/O SEC. STEERING) | | 950 |
| VALVE, MAIN MANIFOLD (W/ SEC. STEERING) | | 948 |
| Valve, Manifold | | 490 |
| VALVE, RELIEF (REVERSING FAN) | | 432 |
| VALVE, RELIEF, BLADE LIFT VALVE SECTION (EH) (GRADE PRO) (BREAKDOWN)..... | | 978 |
| VALVE, RELIEF, LEFT BLADE LIFT VALVE SECTION (STD)..... | | 902 |
| VALVE, RELIEF, RIGHT BLADE LIFT VALVE SECTION (STD) (BREAKDOWN)..... | | 900 |
| VALVE, REVERSING FAN DRIVE | | 432 |
| VALVE, RIGHT BLADE LIFT (STD)(BREAKDOWN) | | 900 |
| VALVE, RIGHT CONTROL (4 FUNCTION)..... | | 882 |
| VALVE, RIGHT CONTROL (5 FUNCTION)..... | | 886 |
| VALVE, RIGHT CONTROL (5 FUNCTION) (MID MOUNTED SCARIFIER)..... | | 888 |
| VALVE, RIGHT CONTROL (6 FUNCTION)..... | | 892 |
| VALVE, RIGHT CONTROL (7 FUNCTION)..... | | 896 |
| VALVE, SERVICE BRAKE..... | | 520 |
| VALVE, SOLENOID (REVERSING FAN) | | 432 |
| Valve, Steering Priority | | 490 |
| VALVE, STEERING (STANDARD CONTROLS) | | 500 |
| VALVE, SUCTION CONTROL (169Z) | | 300 |
| VALVE, SUCTION CONTROL (9901) | | 252 |
| VALVE, WATER..... | | 820 |
| VENTILATING HOSE (2901)..... | | 198 |
| VENTILATING HOSE (2943)..... | | 312 |
| VENTILATING SYSTEM | | 198 |
| VGT 6511 | | 234 |
| VIBRATION DAMPER (1346)..... | | 180 |
| VLV, SOLENOID | | 170 |
| | Warm-Up Circuit | 1010 |
| | WARNING ALARM..... | 676 |
| | WARNING ALARM (GRADE PRO)..... | 678 |
| | WARNING ARTICULATION LABEL (RUSSIAN)..... | 540 |
| | WARNING ARTICULATION LABEL (SPANISH)..... | 538 |
| | WARNING BEACON, STROBE | 592 |
| | Water in Fuel Sensor..... | 202 |
| | WATER IN FUEL SENSOR, ADDITIONAL (6068HDW75) | 462 |
| | WATER IN FUEL SENSOR, ADDITIONAL (6090HDW01 / 6090HDW04) | 460 |
| | Water in Fuel Separator, Additional (Field Kit S.N. -627690) | 464 |
| | Water Pump..... | 190 |
| | WATER PUMP BYPASS TUBE 2107 | 191 |
| | Water Pump Inlet..... | 229 |
| | WATER PUMP INLET (5722)..... | 343 |
| | WATER PUMP INSERT SERVICE KIT | 383 |
| | WATER PUMP KIT (9901)..... | 248 |
| | WATER PUMP PULLEY (2001) | 306 |
| | WATER PUMP (4436)..... | 328 |
| | WATER SEPARATOR (81AL)..... | 352 |
| | WATER VALVE..... | 820 |
| | WEIGHT, REAR MOUNTED | 696 |
| | WET BRAKE GROUP (YZ104053)..... | 150 |
| | Wheels (Front 10 in. X 24 in.) (Rear 9 in. X 24 in.) (Split Rim) | 54 |
| | WHEEL BEARING, FRONT (LEFT) | 82 |
| | WHEEL BEARING, FRONT (RIGHT)..... | 80 |
| | WHEEL HUB, FRONT (LEFT)..... | 82 |
| | WHEEL HUB, FRONT (RIGHT)..... | 80 |
| | Wheel Lean Bar..... | 76 |
| | WHEEL LEAN CONTROL LINKAGE..... | 762 |
| | WHEEL LEAN CONTROL, RIGHT 4 FUNCTION (EH) (GRADE PRO)..... | 780 |
| | WHEEL LEAN CONTROL, RIGHT 5 FUNCTION (EH) (GRADE PRO)..... | 784 |
| | Wheel Lean Cylinder | 518 |
| | WHEEL LEAN CYLINDER COMPONENTS | 518 |
| | Wheel Lean Cylinder Hoses (Grade Pro) | 506 |
| | Wheel Lean Cylinder Hoses (Standard Controls)..... | 504 |
| | Wheel Lean Cylinder Pins | 516 |
| | WHEEL LEAN SENSOR | 80 |
| | WHEEL LEAN SENSOR HARNESS..... | 602 |
| | WHEEL LEAN SENSOR WIRING HARNESS | 594 |
| | Wheel Lean Valve Section (Grade Pro)..... | 986 |
| | Wheel Lean Valve Section (Standard Controls) | 906 |
| | Wheel (10 in. X 24 in.) (For 14X24 or 14R24 Tires) (Split Rim)..... | 54 |
| | Wheel (13 in. X 25 in.)..... | 56 |
| | Wheel (13 in. X 25 in.) (For 17.5X25 or 17.5R25 Tires) | 56 |
| | Wheel (14 in. X 25 in. Split Rim) | 58 |
| | Wheel (14 in. X 25 in.) (For 17.5X25 or 17.5R25 Tires) (Split Rim)..... | 58 |
| | Wheel (9 in. X 24 in. One Piece) | 52 |
| | Wheel (9 in. X 24 in.) (For 14X24 or 14R24 Tires) (One Piece) | 52 |
| | WHEEL, STEERING | 486 |
| | WHEEL, STEERING (GRADE PRO)..... | 488 |
| | WINDOWS, OPENING SIDE AND FIXED FRONT (LOW PROFILE CAB)..... | 738 |
| | WINDOWS, OPENING (FULL HEIGHT CAB) (S.N. -627324)..... | 740 |
| | WINDOWS, OPENING (LOW PROFILE CAB) | 736 |
| | WINDOWS, STATIONARY (LOW PROFILE CAB)..... | 734 |
| | WINDOW SHADE, REAR | 874 |
| | WINDOW, DOOR (FULL HEIGHT CAB)..... | 732 |
| | WINDOW, DOOR (LOW PROFILE CAB)..... | 730 |
| | WINDSHIELD WASHER RESERVOIR (FULL HEIGHT CAB) | 744 |
| | WINDSHIELD WASHER RESERVOIR (LOW PROFILE CAB)..... | 742 |
| | WINDSHIELD WIPER DISABLE SENSOR, LOWER..... | 752 |
| | WINDSHIELD WIPER, FRONT (FULL HEIGHT CAB)..... | 744 |
| | WINDSHIELD WIPER, FRONT (LOW PROFILE CAB) | 742 |
| | WINDSHIELD WIPER, LOWER FRONT..... | 750 |
| | WINDSHIELD WIPER, REAR (FULL HEIGHT CAB) | 748 |
| | WINDSHIELD WIPER, REAR (LOW PROFILE CAB)..... | 746 |
| | WIPER BLADE, FRONT WINDSHIELD (FULL HEIGHT CAB)..... | 744 |
| | WIPER BLADE, FRONT WINDSHIELD (LOW PROFILE CAB)..... | 742 |
| | WIPER BLADE, REAR WINDSHIELD (FULL HEIGHT CAB)..... | 748 |
| | WIPER BLADE, REAR WINDSHIELD (LOW PROFILE CAB)..... | 746 |
| | WIPER COVER, FRONT (FULL HEIGHT CAB) | 718, 720 |
| | WIPER COVER, FRONT (GRADE PRO)..... | 714, 716 |
| | WIPER COVER, FRONT (LOW PROFILE CAB - STD)..... | 710, 712 |
| | WIPER DISABLE SENSOR, LOWER WINDSHIELD..... | 752 |
| | WIPER HOUSING, REAR (FULL HEIGHT CAB)..... | 718, 720 |
| | WIPER HOUSING, REAR (GRADE PRO)..... | 714, 716 |
| | WIPER HOUSING, REAR (LOW PROFILE CAB - STD)..... | 710, 712 |
| | WIPER, LOWER FRONT WINDSHIELD..... | 750 |

Índice alfabético, continuación

| Página | Página | | |
|---|---------------|--|------|
| WIRING HARNESES, ENGINE (6068HDW75) | 612 | YZ106539 TRANSMISSION FRONT HOUSING | 166 |
| WIRING HARNESES, ENGINE (6090HDW01) | 606 | YZ106540 MAIN CASE GROUP | 154 |
| WIRING HARNESS BRACKET (8485) | 354 | YZ106549 TRANSMISSION CHARGE PUMP GROUP | 162 |
| Wiring Harness Mounting - Brackets | 244 | YZ106563 THIRD STAGE SHAFT ASSEMBLY | 140 |
| WIRING HARNESS & INJECTION NOZZLE (169Z) | 300 | YZ106564 FIFTH STAGE SHAFT ASSEMBLY | 144 |
| WIRING HARNESS, A/C AND HEATER | 818 | YZ106602 VALVE ASSEMBLY | 158 |
| WIRING HARNESS, BLADE IMPACT | 658 | YZ106603 VALVE CONTROL GROUP | 156 |
| WIRING HARNESS, CAB INTERIOR | 622 | YZ106665 FOURTH STAGE SHAFT ASSEMBLY | 142 |
| WIRING HARNESS, CAB INTERIOR (CONNECTORS) .. | 624, 626, 628 | YZ106678 FIRST STAGE SHAFT ASSEMBLY | 136 |
| WIRING HARNESS, CAB ROOF | 652 | YZ106680 SIXTH STAGE SHAFT ASSEMBLY | 146 |
| WIRING HARNESS, DIESEL FIRED COOLANT HEATER (6090HDW01 / 6090HDW04) | 400 | YZ106765 TRANSMISSION SECOND STAGE ASSEMBLY | 138 |
| WIRING HARNESS, ECU (8497) | 240 | YZ106766 TRANSMISSION HOSE FITTING | 164 |
| WIRING HARNESS, ENGINE AIR HEATER | 390 | YZ120442 VALVE ASSEMBLY | 110 |
| WIRING HARNESS, ENGINE COMPARTMENT WORK LIGHTS .. | 584 | YZ120521 DIFFERENTIAL CASE- 1400 SERIES AXLE | 102 |
| WIRING HARNESS, ENGINE FRAME (CONNECTORS) | 616 | YZ120521 DIFFERENTIAL LOCK W. VALVE | 106 |
| WIRING HARNESS, ENGINE (CONNECTORS) (6068HDW75) .. | 614 | YZ120521 DIFFERENTIAL - LOW PRESSURE (S.N.XXXX-) | 104 |
| WIRING HARNESS, ENGINE (CONNECTORS) (6090HDW01) .. | 608, 610 | YZ501988 24V SOLENOID VALVE | 170 |
| WIRING HARNESS, FAN DOOR | 576 | | |
| WIRING HARNESS, FLEX LOAD CONTROLLER POWER | 622 | # | |
| WIRING HARNESS, FLEX LOAD CONTROLLER POWER (CONNECTORS) | 632 | 1102 (ROCKER ARM COVER) | 178 |
| WIRING HARNESS, FRONT DRIVE/TURN LIGHTS | 594 | 1144 (ROCKER ARM COVER) | 294 |
| WIRING HARNESS, FRONT DRIVE/TURN LIGHTS (CONNECTORS) | 604 | 12 ft. X 24 in. X 7/8 in. Moldboard (5/8 in. X 6 in. Cutting Edges) .. | 1020 |
| WIRING HARNESS, FRONT EH VALVE (GRADE PRO) | 646 | 12 ft. X 24 in. X 7/8 in. Moldboard (5/8 in. X 8 in. Cutting Edges) .. | 1022 |
| WIRING HARNESS, FRONT EH VALVE (GRADE PRO) (CONNECTORS) | 650 | 12 ft. X 27 in. X 1 in. Moldboard (5/8 in. X 8 in. Cutting Edges) .. | 1024 |
| WIRING HARNESS, FRONT PLATFORM | 594 | 1230 (OIL FILLER NECK) | 296 |
| WIRING HARNESS, FRONT PLATFORM (CONNECTORS) | 596 | 13 ft. X 27 in. X 1 in. Moldboard (5/8 in. X 8 in. Cutting Edges) .. | 1026 |
| WIRING HARNESS, FRONT TILT CONSOLE (GRADE PRO) .. | 656 | 1320 (CRANKSHAFT PULLEY) | 297 |
| WIRING HARNESS, FRONT TILT CONSOLE (STANDARD CONTROLS) | 654 | 1346 (CRANKSHAFT PULLEY) | 180 |
| WIRING HARNESS, GLOW PLUG | 398 | 14 ft. X 24 in. X 7/8 in. Moldboard (5/8 in. X 6 in. Cutting Edges) .. | 1028 |
| WIRING HARNESS, GLOW PLUGS (4330) | 326 | 14 ft. X 24 in. X 7/8 in. Moldboard (5/8 in. X 8 in. Cutting Edges) .. | 1030 |
| WIRING HARNESS, GRADE PRO ARMREST | 636 | 14 ft. X 27 in. X 1 in. Moldboard (3/4 in. X 8 in. Cutting Edges) (3/4 in. HARDWARE) | 1034 |
| WIRING HARNESS, GRADE PRO ARMREST, LEFT (CONNECTORS) | 644 | 14 ft. X 27 in. X 1 in. Moldboard (5/8 in. X 8 in. Cutting Edges) .. | 1032 |
| WIRING HARNESS, GRADE PRO ARMREST, RIGHT (CONNECTORS) | 642 | 1412 (FLYWHEEL HOUSING) | 181 |
| WIRING HARNESS, GRADE PRO CAB | 636 | 1423 (FLYWHEEL HOUSING) | 298 |
| WIRING HARNESS, GRADE PRO CAB (CONNECTORS) | 638 | 15 Amp Power Converter (24 Volt to 12 Volt) | 570 |
| WIRING HARNESS, HYDRAULIC WARMUP CIRCUIT | 1010 | 1520 (FLYWHEEL) | 182 |
| WIRING HARNESS, IGC (GRADE PRO) | 636 | 1530 (FLYWHEEL) | 299 |
| WIRING HARNESS, IGC (GRADE PRO) (CONNECTORS) | 640 | 169Z (FUEL INJECTION PUMP) | 300 |
| WIRING HARNESS, JD LINK™ COMMUNICATION CONTROLLER | 1016 | 1701 (AIR INTAKE) | 186 |
| WIRING HARNESS, LICENSE PLATE LIGHT | 528 | 1797 (INTAKE MANIFOLD) | 302 |
| WIRING HARNESS, MACHINE INFORMATION GATEWAY (MIG) | 1018 | 19BR (OIL PAN) | 304 |
| WIRING HARNESS, MIDSTRUCTURE | 594 | 1909 (OIL PAN) | 188 |
| WIRING HARNESS, MIDSTRUCTURE (CONNECTORS) | 600 | 2001 (WATER PUMP PULLEY) | 306 |
| WIRING HARNESS, RADIO SPEAKER | 622 | 2107 (THERMOSTAT COVER) | 191 |
| WIRING HARNESS, RADIO SPEAKER (CONNECTORS) | 634 | 2154 (THERMOSTAT COVER) | 307 |
| WIRING HARNESS, REAR EH VALVE (GRADE PRO) | 646 | 2201 (THERMOSTAT) | 192 |
| WIRING HARNESS, REAR EH VALVE (GRADE PRO) (CONNECTORS) | 648 | 2255 (THERMOSTAT) | 308 |
| WIRING HARNESS, REAR PLATFORM | 594 | 2310 (FAN DRIVE) | 193 |
| WIRING HARNESS, REAR PLATFORM (CONNECTORS) | 598 | 25 Amp Power Converter (24 Volt to 12 Volt) | 572 |
| WIRING HARNESS, SNOW LIGHT | 586 | 2694 (ENGINE COOLANT HEATER) | 309 |
| WIRING HARNESS, STARTER JUMPER (6068HDW75) | 612 | 2697 (ENGINE HEATER) | 194 |
| WIRING HARNESS, STARTER JUMPER (6090HDW01) | 606 | 2699 (NO ENGINE HEATER) | 195 |
| WIRING HARNESS, STROBE WARNING BEACON | 592 | 28AY (EXHAUST MANIFOLD) | 311 |
| WIRING HARNESS, TAIL LIGHT | 576 | 2802 (EXHAUST MANIFOLD) | 196 |
| WIRING HARNESS, TRANSMISSION | 618 | 2870 (EXHAUST MANIFOLD) | 310 |
| WIRING HARNESS, TRANSMISSION (CONNECTORS) | 620 | 2901 (VENTILATING SYSTEM) | 198 |
| WIRING HARNESS, WHEEL LEAN SENSOR | 594 | 2943 (VENTILATING SYSTEM) | 312 |
| WIRING HARNESS, WHEEL LEAN SENSOR (CONNECTORS) .. | 602 | 3005 (STARTING MOTOR) | 200 |
| WITHOUT ENGINE WIRING HARNESS | 354 | 3008 (STARTER MOTOR) | 201 |
| | | 3059 (STARTER MOTOR) | 314 |
| | | 35DZ (FUEL FILTER) | 316 |
| | | 3508 (FUEL FILTER) | 204 |
| | | 3612 (FRONT PLATE AND IDLE GEARS (UPPER AND LOWER) .. | 318 |
| | | 3713 (FUEL TRANSFER PUMP) | 320 |
| | | 3903 (THERMOSTAT HOUSING / BY PASS TUBE TO WATER PUMP) | 206 |
| | | 3926 (THERMOSTAT HOUSING, BY PASS TUBE TO WATER PUMP) | 322 |
| | | 4018 (ENGINE OIL DIPSTICK) | 208 |
| | | 4048 (ENGINE OIL DIPSTICK) | 324 |
| | | 4330 (STARTING AID) | 326 |
| | | 4397 (STARTING AID) | 212 |
| | | 4436 (TIMING GEAR COVER) | 328 |
| | | 4601 (CYLINDER BLOCK) | 214 |
| | | 4606 (CYLINDER BLOCK) | 216 |
| | | 4633 (CYLINDER BLOCK) | 330 |
| | | 4712 (CRANKSHAFT AND BEARINGS) | 332 |
| | | 4801 (CONNECTING RODS AND PISTONS) | 220 |
| | | 4834 (CONNECTING RODS AND PISTONS) | 334 |
| | | 4901 (ROCKER ARM, SHAFT, TAPPET, PUSH ROD) | 222 |
| | | 4905 (ROCKER ARM, SHAFT, TAPPET, PUSH ROD) | 336 |
| | | 5001 (OIL PUMP) | 224 |

Y

| | |
|--|-----|
| YOKE GROUP 7C (YZ106449) | 160 |
| YOKE, DRIVESHAFT | 72 |
| YOKE, INPUT | 94 |
| YZ103439 INPUT GROUP | 134 |
| YZ104053 WET BRAKE GROUP | 150 |
| YZ106448 TRANSMISSION OUTPUT GROUP | 148 |
| YZ106449 YOKE GROUP 7C | 160 |
| YZ106536 TRANSMISSION REAR HOUSING | 168 |
| YZ106537 MAIN CASE GROUP | 152 |

This as a preview PDF file from best-manuals.com



Download full PDF manual at best-manuals.com