

Quality Changes The World



Wheel loader SYL956H5



Parts Books

Table of Contents

Group 1 SYL956H5 wheel loader body	1-1
13539579 SYL956H5 wheel loader body	1-2
Group 2 carriage assembly.....	2-1
13543568 carriage assembly	2-2
13543532 lubrication system	2-4
13054732 hinge	2-6
13046191 upper hinged	2-8
13340262 lower articulation	2-10
Group 3 work device.....	3-1
13543594 work device	3-2
Group 4 cover asm.	4-1
13702095 cover asm.	4-2
13695518 engine hood	4-4
Group 5 cab assembly.....	5-1
13711330 cab assembly	5-2
13686031 China Tier 3 cab	5-4
Group 6 platform staircase and dashboard assembly	6-1
13510092 platform staircase and dashboard assembly	6-2
Group 7 Power system.....	7-1
13530785 Power system	7-2
60272742 engine	7-6
13530246 Cooling system	7-12
13529746 Fuel System	7-16
60289942 AIR FILTER	7-18
Group 8 transmission system.....	8-1
13518600 transmission system	8-2
60233623 Front Driving Bridge	8-8
60271953 Planetary assembly	8-10
60271951 Housing assembly.....	8-12
60271929 Carrier assembly	8-14
60271917 Diff. assembly	8-16
60271957 Brake assembly	8-18


60270125 front transmission shaft assy	8-20
60270127 middle transmission shaft assembly	8-22
60271289 gearbox.....	8-24
60272154 Wtring harness	8-26
60273706 GROUP-REAR COVER.....	8-28
60273707 GROUP-TRANSMISSION CASE	8-30
60273708 GROUP-CONVERTER HOUSING	8-32
60273709 GROUP-TORQUE CONVERTER	8-34
60273710 GROUP-FORWARD AND FIRST SHAFT.....	8-36
60273711 Group-reverse and 2nd shaft.....	8-38
60273712 GROUP-2ND CLUTCH	8-40
60273713 GROUP-FWD/HI AND 3RD SHAFT	8-42
60273714 GROUP-3RD CLUTCH	8-44
60273715 GROUP-IDLER SHAFT	8-46
60273716 GROUP-INPUT SHAFT	8-48
60273717 GROUP-PUMP DRIVE SHAFT	8-50
60273718 GROUP-TURBINE SHAFT	8-52
60273719 GROUP-OUTPUT SHAFT.....	8-54
60273720 GROUP-CONTROL VALVE.....	8-56
60273721 GROUP-MODULATOR AND SELECTOR VALVE.....	8-58
60273722 GROUP-SHIPPIING COVER SAE C	8-60
60273723 GROUP-FLANGE 7C AND BRAKE DISC	8-62
60273724 SAHR HYDRAULIC BRAKE	8-64
60273724 GROUP-7C FLANGE	8-64
60273725 GROUP-DIPSTICK TUBE	8-66
60273726 GROUP-FLYWHEEL ADAPTOR.....	8-68
60233624 Rear Driving Bridge	8-70
60271957 Brake assembly	8-72
60271948 Back occilating rack assembly	8-74
60271953 Planetary assembly	8-76
60271950 Housing assembly.....	8-78
60271930 Carrier assembly	8-80
60271917 Diff. assembly	8-82
60271945 Front occilating rack assembly.....	8-84
60232602 Rear Transmission Shaft	8-86
Group 9 hydraulic system	9-1
13530117 hydraulic system	9-2
13056536 main valve pipeline	9-4
13055767 right moveable boom oil cylinder assembly	9-8
13056510 bucket cylinder assembly.....	9-12
60232814 Multi-way Valve.....	9-16
13056400 left derrick oil cylinder assembly	9-18
13671096 pilot pipeline	9-22
60232815 Pilot-control Valve	9-24
60211330 Filter.....	9-26

13524381 hydraulic oil tank piping diagram	9-28
60129702 Valve, Breather Assembly	9-32
SSW005554447 Hydraulic Fuel Tank Assy	9-34
13524379 working pump pipeline.....	9-36
60286578 gear pump	9-40
SSW005018170 Oil filling pipeline of main oil pump	9-42
150101040021B Plunger Pump	9-44
13760201 Brake pipeline	9-48
60243096 Brake Valve	9-52
60242150 Pressure Oil Filter	9-54
13524367 steering pipeline	9-56
60232381 Steering Cylinder.....	9-58
Group 10 ELECTRICAL SYSTEM.....	10-1
13511968 ELECTRICAL SYSTEM	10-2
13090270 Front frame harness	10-4
13511967 CHASIS ELECTRICAL COMPONENT ASSEMBLY	10-6
13090275 Electrical assembly	10-10
13511793 CABIN ELECTRICAL COMPONENT ASSEMBLY	10-12
Group 11 AIR CONDICTION SYSTEM.....	11-1
13511972 AIR CONDICTION SYSTEM	11-2
Group 12 painting	12-1
13711359 painting	12-2


BLANK PAGE

Group 1

SYL956H5 wheel loader body




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	13543568	carriage assembly	1	2-2
2	13543594	work device	1	3-2
3	13702095	cover asm.	1	4-2
4	13711330	cab assembly	1	5-2
5	13510092	platform staircase and dashboard assembly	1	6-2
6	13530785	Power system	1	7-2
7	13518600	transmission system	1	8-2
8	13530117	hydraulic system	1	9-2
9	13511968	ELECTRICAL SYSTEM	1	10-2
10	13511972	AIR CONDICTION SYSTEM	1	11-2
12	13711359	painting	1	12-2




Group 2



carriage assembly




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	A210111000203	Bolt	26	
2	13042665	Cover Plate	1	
3	13512154	Front	1	
4	13543532	lubrication system	1	2-4
5	13047166	pin	2	
6	A210111000202	Bolt	2	
7	24000639	Washer	2	
8	B229900000686	Grease Joint	4	
9	14180329	Adjusting spacer	4	
10	13054732	hinge	1	2-6
11	A210111000053	Bolt	2	
12	A210491000118	Washer	2	
13	13047163	pin	2	
14	13203265	retainer ring	4	
15	13515937	rear frame frame body	1	
16	13601264	counterweight	1	
17	A210110000354	Bolt	4	
18	A210444000003	Washer	4	
19	A210204000166	Screw	2	
20	24000642	Washer	2	
21	13389685	Rubber Buffer Pad	2	
22	13049026	maintenance window cover plate	2	
23	13042668	Bumper	1	
24	13042603	Inserted pin	2	
25	13042602	Lock Pin	2	
26	13052409	inserted pin	1	
27	13052410	traction pin	1	
28	13527032	sealing board	2	
29	13936604	Joint bearing	2	
30	13185322	pull	1	
31	13198884	hood pedal assembly	2	
32	A210111000037	Bolt	4	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	13043586	right boom lubricating pipeline	1	
2	13527036	lubricating pipeline	1	
3	13527034	steering cylinder lubricating pipeline	2	
4	13043588	left boom lubricating pipeline	1	
5	B229900000686	Grease Joint	5	
6	11102368	Fitting	5	
7	12325478	Joint	5	
8	10668937	Washer	10	
9	A210111000012	Bolt	1	
10	24000637	Washer	1	
11	A820101211947	Clamp, Pipe	1	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	13046191	upper hinged	1	
2	SSW004836924	lower articulation	1	



INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	A210111000053	Bolt	2	
2	24000642	Washer	2	
3	13046194	pin	1	
4	A210110000323	Bolt	6	
5	24000639	Washer	6	
6	13046187	upper bearing seat	1	
7	13046190	adjusting spacer	4	
8	13046189	adjusting spacer	4	
9	24002096	oil seal	2	
10	A210604000009	Rolling Bearing	2	
11	13046188	lower bearing seat	1	




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	24000639	Washer	12	
2	A210491000118	Washer	4	
3	24002816	oil seal	2	
4	29006091	Bearing	2	
5	A210110000384	Bolt	6	
6	A210111000118	Bolt	6	
7	A210110000281	Bolt	4	
8	13340252	adjusting spacer	4	
9	13340253	adjusting spacer	4	
10	13340254	upper bearing seat	1	
11	13340255	lower bearing seat	1	
12	13340256	taper sleeve	1	
13	13340257	bush	1	
14	13340258	flange plate	1	
15	13340259	Lock pin	1	
16	13340260	adjusting spacer	7	
17	13340261	adjusting spacer	5	




Group 3

work device




INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	B229900000686	Grease Joint	11	
2	60060553	Washer	13	
3	A210111000366	Bolt	11	
4	A210111000053	Bolt	6	
5	A210609000324	O-ring	6	
6	13203266	spacer sleeve	2	
7	B230101000623	O-ring	8	
8	B230101000534	Dust Ring	2	
9	60055872	O-ring	8	
10	A820102010744	Spacer	10	
11	A820102010387	Spacer	32	
12	A820102010381	Gasket	16	
13	24000642	Washer	4	
14	13046908	PIN	3	
15	13046859	Shaft sleeve	2	
16	13046886	pin	2	
17	13046642	Shaft sleeve	2	
18	13046903	pin	1	
19	13046858	Shaft sleeve	2	
20	13046883	pin	2	
21	13046643	Shaft sleeve	2	
22	13046874	PIN	2	
23	13046906	PIN	1	
24	13046877	pin	2	
25	13046641	Shaft sleeve	2	
26	13511541	Loader boom assembly	1	
27	13511274	rocker arm	1	
28	13039980	Limit block	1	
29	13511191	linkage	1	
30	13627589	bucket assembly	1	




Group 4

cover asm.



INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	A210111000011	Bolt	1	
2	60060546	Washer	1	
3	24000646	Washer	1	
4	24000637	Washer	4	
5	A210111000197	Bolt	4	
6	A210508000100	Pin Shaft	2	
7	A210491000011	Pin	4	
8	60233857	gas spring	2	
9	A210508000001	Pin	2	
10	A210111000089	Bolt	4	
11	24000633	Washer	4	
12	13695518	engine hood	1	4-4
13	A210111000202	Bolt	6	
14	60060548	Washer	6	



4-4 cover asm.

INDEX	PART NO.	DESCRIPTION	QTY	SEE PAGE
1	13694414	safety supporting lever	1	
2	A222200000065	Machine Shed Lock Assembly	2	
3	13694149	engine cover assem.	1	
4	13417650	limit plate	2	
5	13381684	hinge bearer	1	
6	A210414000025	Retainer Ring	2	
7	13381658	hinge bearer	1	
8	A210405000008	Washer	4	
9	13428358	PIN	2	

This as a preview PDF file from **best-manuals.com**



Download full PDF manual at **best-manuals.com**