# 580N, 580SN, 580SN WT, 590SN Tractor Loader Backhoe Tier III

Parts Catalog

Print No. 47371403 Replaces: 843001691 Issued 3/2012



# 580N, 580SN, 580SN WT, 590SN Tractor Loader Backhoe Tier III

Parts Catalog

Print No. 47371403 Replaces: 843001691 Issued 3/2012



### **GENERAL INFORMATION**

1. Whenever the terms left and right are used, it should be understood to mean from a position facing in direction of travel.


2. Throughout this manual you may find common hardware not illustrated, but listed in the description column. The service part immediately preceding a hardware listing is the part using these particular items for mounting purposes. This hardware is not included with the service part or assembly when ordered as a replacement.

3. The illustrations show typical assemblies plus individual parts but in all cases may not show the exact shape or detail of parts required. However, the purpose for the illustrations is to identify parts performing like functions. Whenever possible illustrations are located at the beginning of each section or immediately adjacent to the applicable text.

4. CNH America LLC is continually striving to improve its products. We must, therefore, reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

CNH America LLC, Racine, WI 53404 U.S.A.

### How to Use Your Parts Catalog



#### How to Use Your Parts Catalog

- 1. Figure Number
- 2. Sequence code within the Figure Number
- 3. Page number within the Sequence Code
- 4. Date of Printing (month / year)
- 5. Figure Description
- 6. General information regarding the figure
- 7. Parts supplied in repair kits per symbol reference
- 8. Figure call-out of the part number (REF)
- 9. Technical Specifications relating to the part indicated
- 10. Figure call-out includes bracketed items, the included items may also be listed in the additional description area
- 11. Orientation Arrow indicates front of the machine
- 12. Footnote Additional information relating to the part number. In this example, 08-20 equals another figure that this part is shown on.
- Part Number NSS = Non-serviced parts Bracketed numbers = not available as service parts in this market
- 14. Not Available as service part in this market
- 15. YR/SN

Year Before 01/85 = Part valid for production January 1985 and before From 01/85 = Part valid for production from January 1985 and after BTW 01/85 & 02/02 = Part valid for machines produced between January 1985 and February 2002.

Serial Number (P.I.N.)

BSN JJC0268800 = Part valid for serial number JJC0268800 and below ASN JJC0268800 = Part valid for serial number JJC0268800 and above BTW JJC0178000 & JJC0179000 = Part valid for serial numbers between JJC0178000 & JJC0179000

- Total Quantity of the Part referred to in the page. The quantity can be replaced by the following indications:
  AR = quantity as required
  X = as required
- 17. Part Description
- 18. Additional description of the part to help confirm identification
- 19. Figure Notes
- 20. Model Number(s)

# Explanation of Abbreviations

Abbreviation	Meaning
adj	adjustable
amp	ampere
AR	As required
ASN	Serial number and after / P.I.N. and after
barb	barb
blkhd	bulkhead
boss	boss
BSN	before serial number / before P.I.N
BTW	between
сс	cubic centimetre
chain	chain
cl	class
cp pt	cup point
CRS	Chrome Alloy Steel
CST	Carbon Steel
cu yd	cubic yard
deg	degree
dia	diameter
dr type	drive type
dry	dry
fc	face
fc sl	face seal
fem	female
fem PT	female pipe thread
fl	flare
ft	feet (or foot)
gal	gallon(s)
gr	grade
hd	head
hp	horsepower
ID	inside diameter

Abbreviation	Meaning
in	inch(es)
Inc.	includes
inv fl	inverted flare
К	kilo
kg	kilogram
L	litre
lb	pound(s)
lg	long
LH	left hand
LH thd	left hand thread
links	links
М	(prefix) metric thread size
m	metre
male	male
mm	millimetre
NF	National Fine
No.	number
NS	National Super Fine
OD	outside diameter
ohm	electrical unit of resis- tance
Or	O-ring
orifice	orifice
Р	pitch
piece	piece
psi	pounds per square inch
РТ	pipe thread
rd	round
rd holes	round holes
RH	right hand
RH thd	right hand thread
rpm	revolutions per minute

### **Explanation of Abbreviations**

Abbreviation	Meaning
sl	self locking
slat	slat
spool	spool
sq	square
SST	Stainless Steel
st	self tapping
stem	stem
strk	stroke
sw	swivel
Т	teeth
Teflon	Teflon
thin	thin
thk	thick
tpr	taper

Abbreviation	Meaning
tube	tube
type	type
V	volt(s)
W	watt(s)
way	way
wide	wide
Х	as required
yd	yard

#### Dimensions

Metric and U.S. hardware dimensions do not show the numeric designations of standard coarse threads. A number following a semi colon (;) is the class or grade of hardware. A comma (,) represents the decimal point (.) used in U.S. dimensions.

00.000.00		PICTORIAL INDEX - MAINTENANCE
00.000.10		PICTORIAL INDEX - ENGINE
00.000.21		PICTORIAL INDEX - TRANSMISSION
00.000.25		PICTORIAL INDEX - FRONT MECHANICAL DRIVE
00.000.27		PICTORIAL INDEX - REAR DRIVE AXLE
00.000.33		PICTORIAL INDEX - BRAKE & CONTROLS
00.000.35		PICTORIAL INDEX - HYDRAULIC SYSTEMS
00.000.37		PICTORIAL INDEX - TOWING HOOKS & BALLISTING
00.000.39		PICTORIAL INDEX - FRAME COMPONENTS
00.000.41		PICTORIAL INDEX - STEERING
00.000.44		PICTORIAL INDEX - AXLE & WHEELS
00.000.50		PICTORIAL INDEX - CAB CLIMATE CONTROL
00.000.55		PICTORIAL INDEX - ELECTRICAL SYSTEM
00.000.82		PICTORIAL INDEX - FRONT LOADER
00.000.84		PICTORIAL INDEX - BACKHOE
00.000.90		PICTORIAL INDEX - PLATFORM, CAB, BODYWORK AND DECALS
05.001.01		BUCKET RETROFIT KIT
05.100.01		FILTERS AND CAPACITIES
05.500.00	01	INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY
05.500.01	01	INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY
05.500.01	02	INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY
05.500.01	03	INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY
10.000.00		PICTORIAL INDEX - ENGINE
10.001.01		ENGINE
10.001.01		ENGINE (580N)
10.001.02	01	CYLINDER BLOCK (580SN, 580SN WT, 590SN)
10.001.02	01	CYLINDER BLOCK (580N)
10.001.02	02	CYLINDER BLOCK (580SN, 580SN WT, 590SN)
10.001.02	02	CYLINDER BLOCK (580N)
10.012.03		ENGINE - MOUNTING
10.012.03		ENGINE - MOUNTING (580N)
10.012.05		ENGINE - LIFT HOOK
10.101.01		CYLINDER HEAD (580SN, 580SN WT, 590SN)
10.101.01		CYLINDER HEAD (580N)
10.101.02		CYLINDER HEAD COVERS (580SN, 580SN WT, 590SN)
10.101.02		CYLINDER HEAD - COVERS (580N)
10.101.04		BREATHER - ENGINE (580SN, 580SN WT, 590SN)
10.101.04		BREATHER - ENGINE (580N)
10.102.01		OIL PUMP, PAN (580SN, 580SN WT, 590SN)
10.102.03	01	CRANKCASE COVERS (580SN, 580SN WT, 590SN)
10.102.03	01	CRANKCASE COVERS (580N)
10.102.03	02	CRANKCASE COVERS (580SN, 580SN WT, 590SN)
10.102.03	02	CRANKCASE COVERS (580N)
10.102.04	-	CYLINDER BLOCK - COVERS (580SN, 580SN WT, 590SN)
10.102.04		CYLINDER BLOCK - COVERS (580N)
10.102.06		ACCESSORY DRIVE COVER (580SN, 580SN WT, 590SN)
10.103.01		CRANKSHAFT (580SN, 580SN WT, 590SN)
10.103.01		CRANKSHAFT (580N)
10.103.03		FLYWHEEL - ENGINE (580SN, 580SN WT, 590SN)
10.103.03		FLYWHEEL - ENGINE (580N)
10.103.06		PULLEY - CRANKSHAFT (580SN, 580SN WT, 590SN)
10.100.00		102221 010 WILLOID # 1 (000014, 000014 WIL, 000014)

10.103.06		PULLEY - CRANKSHAFT (580N)
10.105.01		PISTON - ENGINE (580SN, 580SN WT, 590SN)
10.105.01		PISTON - ENGINE (580N)
10.105.02		PISTONS - CONNECTING ROD (580SN, 580SN WT, 590SN)
10.105.02		CONNECTING ROD (580N)
10.106.04		ROCKER SHAFT (580SN, 580SN WT, 590SN)
10.106.04		ROCKER SHAFT (580N)
10.106.07		CAMSHAFT - TIMING CONTROL (580SN, 580SN WT, 590SN)
10.106.07		CAMSHAFT (580N)
10.110.02		DYNAMIC BALANCER, GEARS & SHAFTS (580SN, 580SN WT, 590SN)
10.110.02		DYNAMIC BALANCER, GEARS & SHAFTS (580N)
10.110.03		DYNAMIC BALANCER, HOUSING (580SN, 580SN WT, 590SN)
10.202.01		AIR CLEANER - AIR INTAKE PARTS
10.202.03		AIR CLEANER
10.206.01	01	FUEL FILTER (580N)
10.206.01	02	FUEL FILTER (580SN, 580SN WT, 590SN)
10.206.04	01	OIL FILTERS - ENGINE (580N)
10.206.04	02	OIL FILTERS - ENGINE (580SN, 580SN WT, 590SN)
10.210.01		FUEL PUMP (580N)
10.214.01	01	FUEL LINES, RESÉRVOIR (580N)
10.214.01	02	FUEL LINES, RESERVOIR (580SN, 580SN WT, 590SN)
10.216.01		LOCKABLE FUEL CAP
10.218.03		INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN)
10.218.03		FUEL INJECTION SYSTEM - INJECTOR (580N)
10.218.04		PIPING - FUEL (580SN, 580SN WT, 590SN)
10.218.04		PIPING - FUEL (580N)
10.218.05		INJECTION EQUIPMENT - PIPING (580N)
10.218.05	01	INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)
10.218.05	02	INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)
10.218.05	03	FUEL INJECTION SYSTEM (580N)
10.220.01		CONTROLS - THROTTLE, FOOT
10.220.02		CONTROLS - THROTTLE, HAND
10.220.03		THROTTLE, HAND - THROTTLE, FOOT
10.246.01		INJECTION PUMP (580SN, 580SN WT, 590SN)
10.246.01	01	FUEL INJECTION PUMP (580N)
10.246.01	02	FUEL INJECTION SYSTEM (580N)
10.250.05		TURBOCHARGER (580SN, 580SN WT, 590SN)
10.250.05		TURBOCHARGER (580N)
10.250.06		TURBOCHARGER SYSTEM (580SN, 580SN WT, 590SN)
10.250.06		TURBOCHARGER SYSTEM (580N)
10.254.03		ENGINE - BLOCK HEATER (580SN, 580SN WT, 590SN)
10.254.03		ENGINE - BLOCK HEATER (580N)
10.254.06		MANIFOLD - INTAKE (580SN, 580SN WT, 590SN)
10.254.06		MANIFOLD - INTAKE (580N)
10.254.10		EXHAUST MANIFOLD (580SN, 580SN WT, 590SN)
10.254.10		EXHAUST MANIFOLD (580N)
10.254.11		MUFFLER - EXHAUST SYSTEM
10.254.12		COLD START / GRID HEATER (580SN, 580SN WT, 590SN)
10.304.01		OIL PUMP - ENGINE (580SN, 580SN WT, 590SN)
10.304.01		OIL PUMP, PAN (580N)
10.304.01		OIL PUMP - ENGINE (580N)

10.304.10		ENGINE OIL DIPSTICK (580SN, 580SN WT, 590SN)
10.304.10		ENGINE OIL DIPSTICK (580N)
10.400.03		COOLING SYSTEM - ENGINE (580SN, 580SN WT, 590SN)
10.400.03		COOLING SYSTEM - ENGINE (580N)
10.402.01		WATER PUMP (580SN, 580SN WT, 590SN)
10.402.01		WATER PUMP (580N)
10.402.05		WATER PUMP - CONTROL (580SN, 580SN WT, 590SN)
10.402.05		WATER PUMP - CONTROL (580N)
10.402.09		THERMOSTAT - ENGINE COOLING SYSTEM (580SN, 580SN WT, 590SN)
10.402.09		THERMOSTAT - ENGINE COOLING SYSTEM (580N)
10.406.01	01	DEAERATION SYSTEM - MOUNTING
10.406.04	01	RADIATOR - MOUNTING (580N)
10.406.04	02	RADIATOR - MOUNTING (580SN, 580SN WT, 590SN)
10.406.06		RADIATOR WRAPPER
10.406.10		PIPING - ENGINE COOLING SYSTEM (580SN, 580SN WT, 590SN)
10.408.01		OIL FILTER AND COOLER (580SN, 580SN WT, 590SN)
10.408.01		HEAT EXCHANGER - ENGINE (580N)
10.408.07		COOLER, CHARGE AIR AND HOSES (580SN, 580SN WT, 590SN)
10.414.01	01	ENGINE FAN - 9 BLADE (VISCOUS)
10.414.01	02	ENGINE FAN - 7BLADE (NON VISCOUS)
10.414.02		FAN DRIVE (580SN, 580SN WT, 590SN)
10.414.02		FAN DRIVE (580N)
21.000.00		PICTORIAL INDEX - TRANSMISSION
21.100.01		TRANSMISSION ASSEMBLY
21.104.02		TRANSMISSION- 2WD / 4WD POWERSHIFT S TYPE, SPS - FILTER, OIL
21.104.03	01	TRANSMISSION - 2WD - FILTER, OIL
21.104.03	02	TRANSMISSION - 4WD - FILTER, OIL
21.109.02		TRANSMISSION- COOLING SYSTEM
21.112.01	01	TRANSMISSION - 4WD - HOUSING
21.112.01	02	TRANSMISSION - 2WD - HOUSING
21.112.04	01	TRANSMISSION - MOUNTING (MODELS WITHOUT POWERSHIFT) (580N)
21.112.04	02	TRANSMISSION - MOUNTING (MODELS WITHOUT POWERSHIFT) (580SN, 580SN
		WT AND 590SN)
21.113.01	01	TRANSMISSION - 4WD POWERSHIFT H TYPE - HOUSING & FILTER, OIL
21.113.01	02	TRANSMISSION - 4WD POWERSHIFT H TYPE - HOUSING, REAR & THERMOSTAT
21.113.01	03	TRANSMISSION - MOUNTING (MODELS WITH POWERSHIFT)
21.113.01	04	TRANSMISSION - 4WD POWERSHIFT S TYPE- HOUSING
21.133.01		TRANSMISSION - 2WD / 4WD POWERSHIFT S TYPE - SHIFTER MECHANISM
21.133.02	01	TRANSMISSION - 2WD - SHIFTER MECHANISM
21.133.02	02	TRANSMISSION - 4WD - SHIFTER MECHANISM
21.134.01		TRANSMISSION - 2WD / 4WD POWERSHIFT S TYPE- VALVE, CONTROL
21.134.01	01	TRANSMISSION - 2WD - VALVE, CONTROL
21.134.01	02	TRANSMISSION - 4WD - VALVE, CONTROL
21.134.05		TRANSMISSION - 4WD - VALVE, SOLENOID
21.140.01	01	TRANSMISSION - 2WD - SHAFT, INPUT & PTO
21.140.01	02	TRANSMISSION - 4WD - SHAFT, INPUT & PTO
21.154.01	01	TRANSMISSION - 2WD - PUMP, OIL
21.154.01	02	TRANSMISSION - 4WD - PUMP, OIL
21.154.02		TRANSMISSION - 2WD - SHAFT, REVERSE & PRIMARY
21.154.03		TRANSMISSION - 4WD POWERSHIFT S TYPE- SHAFT, OUTPUT POWERSHIFT
21.154.03		TRANSMISSION - 4WD - SHAFT, OUTPUT

21.154.08		TRANSMISSION - 4WD - SHAFT, REVERSE & PRIMARY
21.154.09		TRANSMISSION - 2WD / 4WD POWERSHIFT S TYPE- SHAFT, SECONDARY
21.154.09		TRANSMISSION - 4WD - SHAFT, SECONDARY
21.155.01		TRANSMISSION - 2WD / 4WD, POWERSHIFT H TYPE / SPS - PUMP, OIL
21.155.03		TRANSMISSION - 2WD / 4WD POWERSHIFT H TYPE, SPS - SHAFT, REVERSE &
		PRIMARY
21.155.07		TRANSMISSION - 2WD - SHAFT, SECONDARY
21.155.08		TRANSMISSION - 4WD POWERSHIFT H TYPE - SHAFT, SECONDARY
21.155.14		TRANSMISSION - 2WD / 4WD POWERSHIFT H TYPE, SPS - SHAFT, INPUT & PTO
21.155.15		TRANSMISSION - 4WD POWERSHIFT H TYPE - SHAFT, OUTPUT
21.155.16		TRANSMISSION - 4WD POWERSHIFT H TYPE - VALVE, CONTROL
21.300.00		DRIVESHAFT - REAR AXLE (580SN WT, 590SN)
21.300.00		DRIVESHAFT - REAR AXLE (580N, 580SN)
25.000.00		PICTORIAL INDEX - FRONT MECHANICAL DRIVE
25.100.02	01	AXLE, FRONT DRIVE - MOUNTING (580N, 580SN)
25.100.02	02	AXLE, FRONT DRIVE - MOUNTING (580SN WT)
25.100.02	03	AXLE, FRONT DRIVE - MOUNTING (590SN)
25.100.08	01	AXLE, FRONT DRIVE - HOUSING (580N, 580SN)
25.100.08	02	AXLE, FRONT DRIVE - HOUSING HD ACP (580SN WT, 590SN)
25.100.16	01	AXLE, FRONT DRIVE - SHAFT
25.100.16	02	AXLE, FRONT DRIVE - SHAFT HD ACP (580SN WT, 590SN)
25.102.01	01	AXLE, FRONT DRIVE - RING AND PINION (580N,580SN)
25.102.01	02	AXLE, FRONT DRIVE - RING AND PINION HD ACP LS (580SN WT)
25.102.01	03	AXLE, FRONT DRIVE - RING AND PINION (590SN)
25.102.03		AXLE, FRONT DRIVE - DIFFERENTIAL
25.102.04	01	AXLE, FRONT DRIVE - DIFFERENTIAL HD ACP LS (580SN WT)
25.102.04	02	AXLE, FRONT DRIVE - DIFFERENTIAL HD ACP LS (580SN WT)
25.108.01	01	AXLE, FRONT DRIVE - HOUSING, SWIVEL (580N, 580SN)
25.108.01	02	AXLE, FRONT DRIVE - HOUSING, SWIVEL HD ACP (580SN WT, 590SN)
25.300.02		AXLE, FRONT DRIVE - SHAFTS, AXLE (580N, 580SN)
25.300.02		AXLE, FRONT DRIVE - SHAFTS, AXLE (580SN WT, 590SN)
25.310.01	01	AXLE, FRONT DRIVE - PLANETARY (580N, 580SN)
25.310.01	02	AXLE, FRONT DRIVE - PLANETARY HD ACP (580SN WT, 590SN)
44.100.17	02	AXLE, FRONT - HOUSING, SWIVEL (590SN)
27.000.00		PICTORIAL INDEX - REAR DRIVE AXLE
27.100.08	01	AXLE, REAR DRIVE - MOUNTING (580N, 580SN)
27.100.08	02	AXLE, REAR DRIVE - MOUNTING (580SN WT, 590SN)
27.100.09		AXLE, REAR DRIVE - HOUSING (580N, 580SN)
27.100.10		AXLE, REAR DRIVE - HOUSING (580SN WT, 590SN)
27.100.11		AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL
27.106.01	01	AXLE, REAR DRIVE - DIFFERENTIAL (580N, 580SN)
27.106.01	02	AXLE, REAR DRIVE - DIFFERENTIAL (580SN WT, 590SN)
27.106.02	01	AXLE, REAR DRIVE - RING AND PINION (580N, 580SN)
27.106.02	02	AXLE, REAR DRIVE - RING AND PINION (580SN WT, 590SN)
27.110.02	01	AXLE, REAR DRIVE - DIFFERENTIAL LOCK
27.110.02	02	AXLE, REAR DRIVE - DIFFERENTIAL LOCK (580N, 580SN)
27.110.02	03	AXLE, REAR DRIVE - DIFFERENTIAL LOCK (580SN WT, 590SN)
27.120.02	01	AXLE, REAR DRIVE - PLANETARY (580N, 580SN)
27.120.02	02	AXLE, REAR DRIVE - PLANETARY (580SN WT, 590SN)
33.000.00		PICTORIAL INDEX - BRAKE & CONTROLS
33.110.04		TRANSMISSION - 2WD / 4WD - BRAKE, PARKING
		·

33.110.05		TRANSMISSION - 4WD - BRAKE, PARKING
33.110.06		TRANSMISSION - 4WD POWERSHIFT H TYPE, SPS - BRAKE, PARKING
33.202.03		BRAKE - PEDALS
33.202.09		CYLINDER ASSY - BRAKE MASTER
33.202.11		BRAKE LINES TO TRANSMISSION - 2WD
33.202.12		BRAKE LINES TO TRANSMISSION - 4WD
33.202.13		BRAKE LINES TO TRANSMISSION - 4WD POWERSHIFT
33.202.14		HYDRAULICS - BRAKE MASTER CYLINDER
35.000.00		PICTORIAL INDEX - HYDRAULIC SYSTEMS
35.106.01	01	HYDRAULICS - PUMP INSTALL (580SN, 580SN WT, 590SN)
35.106.01	02	HYDRAULICS - PUMP INSTALL (590SN)
35.106.01	03	HYDRAULICS - PUMP, EQUIPMENT (590SN)
35.106.01	04	HYDRAULICS - PUMP INSTALL (580N)
35.106.01	05	PUMP, EQUIPMENT HYDRAULIC
35.106.02	01	HYDRAULICS - PUMP, EQUIPMENT (WITH POWER LIFT) (580SN, 580SN WT)
35.106.02	02	HYDRAULICS - PUMP, EQUIPMENT (WITHOUT POWER LIFT) (580SN)
35.114.02		VALVE - LOADER CONTROL, 3 SPOOL (PILOT CONTROLS) (580SN, 580SN WT,
		590SN)
35.150.01	01	VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N)
35.150.01	02	VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT,
		590SN)
35.150.02		VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS)
35.150.03		VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS)
35.150.04		VALVE SECTION - BACKHOE, BI-DIRECTIONAL
35.150.05		VALVE SECTION - BACKHOE, OUTLET
35.150.06	02	VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS)
35.150.08	01	VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS)
35.150.09		VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS)
35.150.11		VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS)
35.150.14	01	HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT CONTROLS)
35.150.14	02	HYDRAULICS - VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT CONTROLS)
35.150.14	03	HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT CONTROLS)
35.150.15	01	HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (LEFT-HAND) WITH HORN &
		UNI-DIRECTIONAL BUTTONS
35.150.15	02	HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (LEFT-HAND) WITH HORN &
		BI-DIRECTIONAL BUTTONS
35.150.15	03	HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (LEFT-HAND) WITH HORN
35.150.16	01	VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND) WITHOUT EXTENDABLE
		DIPPER
35.150.16	02	HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND) WITHOUT
		EXTENDABLE DIPPER, 7 SPOOL
35.150.16	03	HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND) WITH
		EXTENDABLE DIPPER, 8 SPOOL
35.350.02		HYDRAULICS - RIDE CONTROL
35.701.01	01	HYDRAULICS - LOADER 4 IN 1
35.701.01	02	HYDRAULICS - LOADER 4 IN 1
35.701.02	01	HYDRAULICS - CYLINDER, LOADER BUCKET 4-IN-1
35.701.02	02	HYDRAULICS - CYLINDER, LOADER BUCKET 4-IN-1
35.701.03	-	CYLINDER - LOADER 4-IN-1
35.701.04	01	HYDRAULICS - LOADER, 2 SPOOL (PILOT CONTROLS) (580SN, 580SN WT, 590SN)
35.701.05	01	HYDRAULICS - LOADER, 3 SPOOL (PILOT CONTROLS) (580SN, 580SN WT, 590SN)
	-	,, <u></u> ,,,,

35.701.06	01	HYDRAULICS - LOADER, 2 SPOOL (580N WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN WITHOUT PILOT CONTROLS)
35.701.06	02	HYDRAULICS - LOADER, 3 SPOOL (580N WITH PILOT CONTROLS) (580SN, 580SN
55.701.00	02	WT, 590SN WITHOUT PILOT CONTROLS)
35.701.07		HYDRAULICS - VALVE, LOADER CONTROL (2 SPOOL) (580SN, 580SN WT, 590SN)
35.701.08		HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, MECHANICAL CONTROLS)
		(580SN, 580SN WT, 590SN)
35.701.09	01	HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT CONTROLS (580SN, 580SN WT, 590SN)
35.701.09	02	HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT CONTROLS (580SN,
00.701.00	02	580SN WT, 590SN)
35.701.11		HYDRAULICS - LOADER LIFT CYLINDER (580SN)
35.701.12		HYDRAULICS - LOADER LIFT CYLINDER (580SN WT, 590SN)
35.701.13		HYDRAULICS - LOADER LIFT (580SN, 580SN WT, 590SN)
35.701.14		HYDRAULICS - LOADER
35.701.16		HYDRAULICS - COUPLER, LOADER TOOL QUICK
35.724.03	01	CONTROLS - LOADER LIFT AND BUCKET
35.724.04		HANDLE, LOADER CONTROL - TRANSMISSION ASSY, 2WD, 4WD
35.724.05		HANDLE, LOADER CONTROL - POWER SHIFT TRANSMISSION
35.724.06		CONTROLS - LOADER CLAM
35.724.07	01	CONTROLS - LOADER LIFT AND BUCKET
35.724.07	02	CONTROL - LOADER LIFT AND BUCKET
35.724.08		VALVE - LOADER CONTROL, GUARD
35.724.09		VALVE - LOADER CONTROL, TWO SPOOL (580SN, 580SN WT, 590SN)
35.724.09	01	VALVE - LOADER CONTROL, TWO SPOOL (580N)
35.724.09	03	SEAL KIT - LOADER CONTROL VALVE
35.724.10	01	VALVE - LOADER CONTROL, THREE SPOOL (580N)
35.724.10	02	VALVE - LOADER CONTROL, THREE SPOOL (MANUAL CONTROLS) (580SN, 580SN WT, 590SN)
35.724.11		VALVE - LOADER CONTROL, THREE SPOOL (PILOT CONTROLS) (580SN, 580SN WT, 590SN)
35.724.12		VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN)
35.724.15		VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN)
35.724.16		VALVE SECTION - 4 IN 1, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN)
35.724.17		VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN)
35.726.02		VALVE - PILOT CONTROL AND JOYSTICKS (6 SPOOL, W/O EXT DIPPER, W/ AUX HYDS)
35.726.03	02	VALVE - PILOT CONTROL AND JOYSTICKS (6 SPOOL, W/O EXT DIPPER, W/O AUX HYDS)
35.726.04	01	VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/ EXT DIPPER, W/ AUX HYDS) (580N)
35.726.04	02	VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/ EXT DIPPER, W/O AUX HYDS) (580N)
35.726.04	03	VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/ EXT DIPPER, W/ AUX HYDS)
35.726.04	04	VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/ EXT DIPPER, W/O AUX HYDS)
35.726.05		VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/O EXT DIPPER W/ AUX HYDS) (580N)

35.726.06		VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/O EXT DIPPER W/ AUX
		HYDS) (580SN, 580SN WT, 590SN)
35.726.07		VALVE - PILOT CONTROL AND JOYSTICKS (8 SPOOL, W/ EHOE, W/ AUX HYDS)
35.726.08	01	HYDRAULICS - PILOT CONTROLS
35.726.08	02	HYDRAULICS - PILOT CONTROLS
35.726.08	03	HYDRAULICS - PILOT CONTROLS, DUAL AUX. (7 SPOOL)
35.726.08	04	HYDRAULICS - PILOT CONTROLS, DUAL AUX. (8 SPOOL)
35.726.09	01	CONTROL, TOWER STRUCTURE
35.726.09	02	CONTROL, TOWER STRUCTURE
35.726.09	03	CONTROL, TOWER STRUCTURE
35.726.09	04	HYDRAULICS - PILOT CONTROL JOYSTICKS
35.726.09	05	VALVE ASSY - AUXILIARY UNI-DIRECTIONAL (WITH PILOT CONTROLS)
35.726.10	01	HYDRAULICS - BACKHOE AUXILIARY
35.726.10	02	HYDRAULICS - BACKHOE AUXILIARY, EXTENDABLE DIPPER (580N, 580SN, 580SN WT)
35.726.11	01	HYDRAULICS - BACKHOE AUXILIARY (590SN)
35.726.11	02	HYDRAULICS - BACKHOE AUXILIARY, EXTENDABLE DIPPER (590SN)
35.726.12	01	VALVE, SINGLE COUPLER - LOADER TOOL OR BACKHOE
35.726.12	02	HYDRAULICS - COUPLER VALVE TO BULKHEAD
35.726.12	03	VALVE INSTALL - SINGLE COUPLER
35.726.12	04	VALVE, DUAL COUPLER - LOADER TOOL AND BACKHOE (580SN, 580SN WT,
00.120.12	•	590SN)
35.726.12	06	VALVE INSTALL - DUAL COUPLER (580SN, 580SN WT, 590SN)
35.726.13	01	HYDRAULICS - COUPLER, BACKHOE BUCKET (STANDARD DIPPER)
35.726.13	02	HYDRAULICS - COUPLER, BACKHOE BUCKET (EXTENDABLE DIPPER)
35.726.14		HYDRAULICS - COUPLER, BACKHOE BUCKET (EXTENDABLE DIPPER)(590SN)
35.726.15		CYLINDER - COUPLER, BACKHOE BUCKET
35.726.16	01	VALVE - BACKHOE CONTROL, 6 SPOOL (W/O EXT DIPPER, W/O AUX HYDS, W/O
35.726.16	02	PILOT CONTROLS) VALVE - BACKHOE CONTROL, 6 SPOOL (W/O EXT DIPPER, W/O AUX HYDS, W/
55.720.10	02	PILOT CONTROLS)
35.726.17	01	VALVE - BACKHOE CONTROL, 7 SPOOL (W/O EXT DIPPER,W/ AUX HYDS, W/O
		PILOT CONTROLS)
35.726.17	02	VALVE - BACKHOE CONTROL, 7 SPOOL (W/ EXT DIPPER, W/O AUX, W/O PILOT
35.726.17	03	CONTROLS) VALVE - BACKHOE CONTROL, 7 SPOOL (W/O EXT DIPPER, W/ AUX HYDS, W/
55.720.17	03	PILOT CONTROLS)
25 706 17	04	VALVE - BACKHOE CONTROL, 7 SPOOL (W/ EXT DIPPER, W/O AUX, W/ PILOT
35.726.17	04	CONTROLS)
35.726.18	01	VALVE - BACKHOE CONTROL, 8 SPOOL (W/O EXT DIPPER, W/O AUX HYDS, W/O
55.720.10	01	PILOT CONTROLS)
35.726.18	02	VALVE - BACKHOE CONTROL, 8 SPOOL (W/O EXT DIPPER, W/ AUX HYDS, W/
00.720.10	02	PILOT CONTROLS)
35.726.19	01	VALVE INSTALL - BACKHOE CONTROL, 8 SPOOL (FOOT SWING)
35.726.19	02	VALVE INSTALL - BACKHOE CONTROL, 8 SPOOL (HAND SWING)
35.726.19	03	VALVE INSTALL - BACKHOE CONTROL, 7 SPOOL (FOOT SWING)
35.726.19	04	VALVE INSTALL - BACKHOE CONTROL, 7 SPOOL (HAND SWING)
35.726.20	01	VALVE INSTALL - BACKHOE CONTROL, UNI AUX PILOT, GEAR PUMP ONLY (580N)
35.726.20	02	VALVE INSTALL - BACKHOE CONTROL, SINGLE AUX (MECHANICAL CONTROLS)
35.726.21	01	VALVE INSTALL - BACKHOE CONTROL, SINGLE AUX (PILOT CONTROLS)
		VARIABLE VALVE PUMP (580SN, 580SN WT, 590SN)

35.726.21	02	BRACKET - VARIABLE VALVE PUMP PRESSURE HOSES (580SN)
35.726.21	03	BRACKET - VARIABLE VALVE PUMP PRESSURE HOSES (580SN WT, 590SN)
35.726.22	01	VALVE INSTALL - BACKHOE CONTROL, BI-AUXILIARY (MECHANICAL CONTROLS)
35.726.22	02	VALVE INSTALL - HAMMER (PILOT CONTROLS) (580SN, 580SN WT, 590SN)
35.726.23		VALVE INSTALL - BACKHOE CONTROL, DUAL AUXILIARY (PILOT CONTROLS)
		VARIABLE VALVE PUMP (580SN, 580SN WT, 590SN)
35.726.24		VALVE INSTALL - BACKHOE CONTROL, DUAL AUXILIARY (MECHANICAL CONTROLS)
35.726.25		VALVE INSTALL - BACKHOE CONTROL, DUAL AUX (PILOT CONTROLS) GEAR PUMP ONLY (580N)
35.726.26		VALVE - BACKHOE CONTROL - SEAL KIT
35.726.27	01	HYDRAULICS - HEAVY LIFT (PILOT CONTROL) (580SN,580SN WT, 590SN)
35.726.27	02	VALVE - HEAVY LIFT (PILOT CONTROL) (580SN, 580SN WT, 590SN)
35.726.28	01	HYDRAULICS - HEAVY LIFT (MECHANICAL CONTROL) (580SN, 580SN WT, 590SN)
35.726.28	02	VALVE - HEAVY LIFT (MECHANICAL CONTROL) (580SN, 580SN WT, 590SN)
35.726.30	01	CONTROL - BACKHOE, WITH FOOT SWING (WITH EXTENDABLE DIPPER)
35.726.30	02	CONTROL - BACKHOE, WITH FOOT SWING (WITH EXTENDABLE DIPPER)
35.726.31	01	CONTROL - BACKHOE, 2 LEVER
35.726.31	02	VALVE INSTALL - SWING CUSHION (DAMPENING)
35.726.32		VALVE - SWING CUSHION (DAMPENING)
35.726.35		CONTROL - BACKHOE, AUXILIARY FOOT SWITCH
35.726.36	01	CONTROL - BACKHOE, WITH FOOT SWING (WITHOUT EXTENDABLE DIPPER)
35.726.36	02	CONTROL - BACKHOE, WITH FOOT SWING (WITHOUT EXTENDABLE DIPPER)
35.726.37	01	VALVE ASSY - HAMMER AUXILIARY (WITH MECHANICAL CONTROLS)
35.726.38	01	VALVE INSTALL - HAMMER (WITH MECHANICAL CONTROLS)
35.730.01	01	CYLINDER - BACKHOE DIPPER (580N)
35.730.01	02	CYLINDER - BACKHOE DIPPER(580SN, 580SN WT)
35.730.01	03	CYLINDER - BACKHOE DIPPER (590SN)
35.730.03	01	CYLINDER - BACKHOE BOOM (580N)
35.730.03	02	CYLINDER - BACKHOE BOOM (580SN, 580SN WT)
35.730.03	03	CYLINDER - BACKHOE BOOM (590SN)
35.730.04	01	BACKHOE - SWING TOWER AND SWING CYLINDERS (580N)
35.730.04	02	BACKHOE - SWING TOWER AND SWING CYLINDERS (580SN AND 580SN WT)
35.730.04	03	BACKHOE - SWING TOWER AND SWING CYLINDERS (590SN)
35.732.01	01	CYLINDER - BACKHOE STABILIZER (580N)
35.732.01	02	HYDRAULICS - CHECK VALVE INSTALL, STABILIZER (580N)
35.732.01	03	HYDRAULICS - CHECK VALVE INSTALL, STABILIZER CYLINDERS (580SN, 580SN
		WT, 590SN)
35.732.01	04	HYDRAULICS - BACKHOE STABILIZER
35.732.01	05	STABILIZER PADS
35.732.01	06	CYLINDER - BACKHOE STABILIZER (580SN)
35.732.01	07	CYLINDER - BACKHOE STABILIZER (580SN WT, 590SN)
35.736.02		CYLINDER - LOADER LIFT (580N)
35.736.03		CYLINDER - LOADER LIFT (580SN)
35.736.04		CYLINDER - LOADER LIFT (580SN WT, 590SN)
35.737.01	01	HYDRAULICS - BOOM INSTALL (580N)
35.737.01	02	HYDRAULICS - BOOM INSTALL (580SN, 580SN WT)
35.737.01	03	HYDRAULICS - BOOM INSTALL (590SN)
35.738.01	01	CYLINDER - LOADER BUCKET (580N)
35.738.01	02	CYLINDER - LOADER BUCKET (580SN, 580SN WT)
35.738.01	03	CYLINDER - LOADER BUCKET (590SN)

35.738.02	01	HYDRAULICS - BACKHOE ( 580SN, 580SN WT) (W/O EXTENDABLE DIPPER)
35.738.02	02	HYDRAULICS - BACKHOE (580SN, 580SN WT) (W/ EXTENDABLE DIPPER)
35.738.03	01	HYDRAULICS - BACKHOE (580N) (W/O EXTENDABLE DIPPER)
35.738.03	02	HYDRAULICS - BACKHOE (580N) (W/EXTENDABLE DIPPER)
35.738.04	01	CYLINDER - BACKHOE BUCKET (580SN, 580SN WT)
35.738.04	02	CYLINDER - BACKHOE BUCKET (590SN)
35.739.02		CYLINDER - BACKHOE SWING (580N)
35.739.03		CYLINDER - BACKHOE SWING (580SN, 580SN WT, 590SN)
35.739.04		HYDRAULICS - CYLINDER BACKHOE SWING / STABILIZER (580SN, 580SN WT, 590SN)
35.739.05		HYDRAULICS - CYLINDER BACKHOE SWING / STABILIZER (580N)
35.740.01	01	HYDRAULICS - BACKHOE EXTENDABLE DIPPER (580N,580SN, 580SN WT)
35.740.01	02	CYLINDER - BACKHOE EXTENDABLE DIPPER (580N, 580SN, 580SN WT)
35.740.02	01	HYDRAULICS - BACKHOE EXTENDABLE DIPPER (590SN)
35.740.02	02	HYDRAULICS - BACKHOE STANDARD DIPPER (590SN)
35.750.01		HYDRAULICS - TANK
35.750.02		HYDRAULICS - TANK, TOOL BOX
35.750.03		HYDRAULICS - FILTER
35.936.01		HYDRAULICS - EXTENDABLE DIPPER COUPLER (590SN)
37.000.00		PICTORIAL INDEX - TOWING HOOKS & BALLASTING
37.140.01		COUNTERWEIGHT, FRONT
39.000.00		PICTORIAL INDEX - FRAME COMPONENTS
39.100.01		CHASSIS - FRAME BUSHINGS (580N, 580SN, 580SN WT)
39.100.02		CHASSIS - FRAME BUSHINGS (590SN)
39.100.03		CHASSIS - CAB MOUNTS, BARRIER CURTAIN, AND AIR INTAKE SCREEN
39.105.06		BACKHOE - SWING TOWER (580N)
39.105.07		BACKHOE - BOOM AND SWING TOWER (580N)
39.105.08		BACKHOE - BOOM AND SWING TOWER, 14' HEAVY (580SN, 580SN WT)
39.105.09		BACKHOE - BOOM AND SWING TOWER (590SN)
39.121.01	01	BACKHOE - DIPPER, EXTENDABLE (OUTER) (580N, 580SN, 580SN WT)
39.121.01	02	BACKHOE - DIPPER, EXTENDABLE (INNER) (580N, 580SN, 580SN WT)
39.121.02	01	BACKHOE - DIPPER, EXTENDABLE (OUTER) (590SN)
39.121.02	02	BACKHOE - DIPPER, EXTENDABLE (INNER) (590SN)
39.121.03		BACKHOE - COUPLER AND BUCKET PINS (580N, 580SN, 580SN WT)
39.121.04		BACKHOE - COUPLER AND BUCKET PINS (590SN)
39.121.05		BACKHOE - LINK, STRAIGHT (580N, 580SN, 580SN WT)
39.121.06	01	BACKHOE - HYDRAULIC COUPLER (580SN, 580SN WT, 590SN)
39.121.06	02	BACKHOE - HYDRAULIC COUPLER LINK AND BUCKET PIN (580SN, 580SN WT, 590SN)
39.121.07		BACKHOE - DIPPER, STANDARD (580SN, 580SN WT)
39.121.08		BACKHOE - DIPPER, STANDARD CYLINDER PIN
39.121.09		BACKHOE - DIPPER, STANDARD WITH HYDRAULIC COUPLER(590SN)
39.121.10		BACKHOE - DIPPER, STANDARD (590SN)
39.121.11		BACKHOE - DIPPER, STANDARD (580N)
39.125.01		FRAME - LOADER LIFT
39.125.02		FRAME - LOADER LINKAGE
39.125.03		COUPLER, TOOL QUICK
41.000.00		PICTORIAL INDEX - STEERING
41.200.01	01	STEERING - COMFORT STEER (580N)
41.200.01	02	STEERING - COMFORT STEER (580SN, 580SN WT, 590SN)
41.200.02		HYDRAULICS - STEERING (580N)

41.200.03		HYDRAULICS - STEERING (580SN, 580SN WT, 590SN)
41.200.04		HYDRAULICS - STEERING
41.204.05		STEERING - COLUMN, TILT (580N)
41.204.08		STEERING - COLUMN (580N)
41.216.05	01	AXLE, FRONT - CYLINDER, STEERING (580SN, 580SN WT)
41.216.05	02	AXLE, FRONT - CYLINDER, STEERING HD ACP (580SN WT, 590SN)
41.216.06		AXLE, FRONT DRIVE - CYLINDER, STEERING STD ACP (580N,580SN)
44.000.00		PICTORIAL INDEX - AXLE & WHEELS
44.100.15	01	AXLE, FRONT - MOUNTING (580N, 580SN)
44.100.15	02	AXLE, FRONT - MOUNTING (590SN)
44.100.16	01	AXLE, FRONT - HOUSING (580N, 580SN)
44.100.16	02	AXLE, FRONT - HOUSING (580SN WT, 590SN)
44.100.17	01	AXLE, FRONT - HOUSING, SWIVEL (580N, 580SN)
44.101.04	01	AXLE, FRONT - HUB AND BEARINGS (580N, 580SN)
44.101.04	02	AXLE, FRONT - HUB AND BEARINGS (590SN)
44.511.08		WHEELS, FRONT - TIRES
44.520.03		WHEELS, REAR - TIRES
50.000.00		PICTORIAL INDEX - CAB CLIMATE CONTROL
50.104.01		CAB - HEATER
50.200.08	01	CAB - AIR CONDITIONING, COMPRESSOR (580N)
50.200.08	02	CAB - AIR CONDITIONING, COMPRESSOR (580SN, 580SN WT, 590SN)
50.200.17	01	CAB - AIR CONDITIONING, CONDENSER AND RECEIVER DRYER (580N)
50.200.17	02	CAB - AIR CONDITIONING, CONDENSER AND RECEIVER DRYER (580SN, 580SN
		WT, 590SN)
50.206.03		CAB - AIR CONDITIONING LINES, EVAPORATOR CORE
50.206.04		CAB - FILTER, AIR
50.206.05		CAB - BLOWER HOUSING, VENTILATION DUCTS, DRAIN LINES
55.000.00		PICTORIAL INDEX - ELECTRICAL SYSTEM
55.100.01	01	HARNESS, INSTALL - CHASSIS
55.100.02	01	HARNESS, INSTALL - TRANSMISSION
55.100.02	02	HARNESS - STANDARD TRANSMISSION (580N)
55.100.03		HARNESS - CHASSIS
55.100.06		HARNESS, INSTALL - ENGINE (580SN, 580SN WT, 590SN)
55.100.30		HARNESS, TRANSMISSION 2WD / 4WD POWERSHIFT - CONTROL VALVE
55.100.35		ELECTRICAL - TRANSMISSION, POWERSHIFT (580SN, 580SN WT, 590SN)
55.100.40		ELECTRICAL - TRANSMISSION, POWERSHIFT S TYPE (580SN, 580SN WT, 590SN)
55.201.03		STARTER
55.201.09		STARTER / ALTERNATOR MOUNTING
55.301.01		ALTERNATOR
55.301.07		BATTERY, DUAL - COLD START
55.301.08		BATTERY, SINGLE
55.404.01	01	ELECTRICAL - LAMPS, ROPS CANOPY
55.404.01	02	ELECTRICAL - LAMPS, ROPS CANOPY
55.408.01		BEACON, ROTATING (CAB OR CANOPY MODELS)
55.408.09		HORN - ALARM, BACKUP
55.440.01		FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL (580SN, 580SN WT,
		590SN)
55.510.01		RADIO
55.512.13		HARNESS INSTALL - FRONT CONSOLE, S AND H TYPE TRANSMISSION (580SN,
		580SN WT, 590SN )
55.512.14	01	HARNESS - FRONT CONSOLE, SWITCHES

55.512.14	02	HARNESS - FRONT CONSOLE, MOUNTING
55.512.14	03	HARNESS - FRONT CONSOLE
55.512.15	01	HARNESS, INSTALL - FRONT CONSOLE, STANDARD TRANSMISSION
55.512.15	02	HARNESS - FRONT CONSOLE, STANDARD TRANSMISSION
55.512.16	01	ELECTRICAL - SIDE CONSOLE, S AND H TYPE TRANSMISSION (580SN, 580SN WT,
00.012.10	01	590SN)
55.512.16	02	HARNESS INSTALL - SIDE CONSOLE, STANDARD TRANSMISSION
55.512.16	03	ELECTRICAL - SIDE CONSOLE, STANDARD TRANSMISSION (580N)
55.512.17	01	ELECTRICAL - SIDE CONSOLE, S-TYPE TRANSMISSION (580N)
55.512.17	02	HARNESS INSTALL - SIDE CONSOLE, S AND H TYPE TRANSMISSION
55.512.17	03	HARNESS - SIDE CONSOLE, S AND H TYPE TRANSMISSION (580SN, 580SN WT, 590SN)
55.512.18		HARNESS - BACKHOE DUAL AUXILLIARY HYDRAULIC WITH MECHANICAL CONTROLS
55.512.19		HARNESS - BACKHOE SINGLE AUXILLIARY HYDRAULIC, WITH PILOT CONTROLS
55.512.20		HARNESS - BACKHOE DUAL AUXILLIARY HYDRAULIC, WITH PILOT CONTROLS
55.512.21		HARNESS - BACKHOE, WITH PILOT CONTROLS
55.514.01		LAMPS - ROPS CAB
55.518.06		CAB - WIPERS
55.518.07		CANOPY, ROPS - WIPER, FRONT AND WINDSHIELD WASHER
55.524.01		BACKHOE HYDRAULIC COUPLER CONTROL SWITCHES
82.000.00		PICTORIAL INDEX - FRONT LOADER
82.100.01	01	BUCKET, LOADER LONG LIP (93 IN)
82.100.01	02	BUCKET, LOADER LONG LIP (96 IN)
82.100.01	02	BUCKET, LOADER 4-IN-1 (82 IN)
84.000.00	01	PICTORIAL INDEX - BACKHOE
84.100.01	01	BUCKET, BACKHOE (305 MM (12 INCH) WIDE)
84.100.01	03	BUCKET, BACKHOE (457 MM (18 INCH) WIDE)
84.100.01	03 04	BUCKET, BACKHOE (437 MM (10 MCH) WIDE) BUCKET, BACKHOE (610 MM (24 INCH) / 762 MM (30 INCH) WIDE)
84.100.01	04	BUCKET, BACKHOE- HIGH CAPACITY (610 MM (24 INCH) / 762 MM (30 INCH) WIDE)
84.100.01	06	BUCKET, BACKHOE (914 MM (36 INCH) WIDE)
84.120.01	00	BOOM LATCH
88.084.01		DIA - BOOM LATCH
90.000.00		PICTORIAL INDEX - PLATFORM, CAB, BODYWORK AND DECALS
90.100.02		HOOD - PANELS, SIDE
90.100.02		HOOD - GRILL
90.100.04		INSTRUMENT PANEL, FRONT - COVERS
90.100.09		INSTRUMENT PANEL, FROM - COVERS INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE)
90.100.10	01	DECALS
90.108.01	01	DECALS
90.108.09	01 02	DECALS - ENGLISH
90.108.09 90.108.17	02	DECALS - ENGLISH SLOW MOVING VEHICLE EMBLEM
90.116.08		FENDER EXTENSIONS
90.118.51	01	MIRROR, REAR VIEW - MOUNTING, CAB MODELS
90.120.01	01	SEAT - MOUNTING (MECHANICAL SUSPENSION)
90.120.01	02	SEAT - ADJUSTABLE HEIGHT PEDESTAL
90.120.05		SEAT - MOUNTING (AIR SUSPENSION)
90.120.10		TOOL BOX - RETRO FIT KIT (MECHANICAL COUPLER)
90.120.11	04	TOOL BOX - RETRO FIT KIT (HYDRAULIC COUPLER)
90.150.01	01	CAB - FLOOR MATS AND PLATES 580N AND 580SN

90.150.01	02	CAB - FLOOR MATS AND PLATES 580SN WT AND 590SN
90.150.02	01	CAB - FRAME
90.150.02	02	CAB - TRIM AND COVERS
90.150.03		CAB ROOF LIGHT PODS
90.150.09		CANOPY, ROPS - FRAME, COVERS, MIRROR, VISOR
90.150.10		CANOPY, ROPS - DELUXE
90.150.11		REAR ACCESS PANEL (WITH MECHANICAL CONTROLS)
90.154.02		CAB - DOORS
90.154.07		CAB - DOOR MOUNTING
90.156.02		CANOPY, ROPS - GLASS
90.156.03		CAB - WINDOW, REAR
90.156.04		CAB - WINDOW, RIGHT HAND, FOR SINGLE DOOR CAB FRAMES
90.156.05		CAB - GLASS, MIRROR AND HOLD OPEN
90.160.01		CAB - STANDARD INTERIOR TRIM
90.160.02		CAB - DELUXE INTERIOR TRIM (580N, 580SN)
90.160.03		CAB - DELUXE INTERIOR TRIM (580SN WT, 590SN)
90.160.04		CAB - DELUXE POST COVERS
90.160.05		HEADLINER

ALPHABETICAL INDEX	FIGURE	SEQ.
ACCESSORY DRIVE COVER (580SN, 580SN WT, 590SN) AIR CLEANER	10.102.06 10.202.03	
AIR CLEANER - AIR INTAKE PARTS	10.202.01	
AIR SUSPENSION SEAT - COMPRESSOR SERVICE KIT	90.120.06	
ALTERNATOR	55.301.01	
AXLE, FRONT - CYLINDER, STEERING (580SN, 580SN WT)	41.216.05	01
AXLE, FRONT - CYLINDER, STEERING HD ACP (580SN WT, 590SN)	41.216.05	02
AXLE, FRONT - HOUSING (580N, 580SN)	44.100.16	01
AXLE, FRONT - HOUSING (580SN WT, 590SN) AXLE, FRONT - HOUSING, SWIVEL (580N, 580SN)	44.100.16 44.100.17	02 01
AXLE, FRONT - HOUSING, SWIVEL (580N, 580SN) AXLE, FRONT - HOUSING, SWIVEL (590SN)	44.100.17	01
AXLE, FRONT - HUB AND BEARINGS (580N, 580SN)	44.101.04	02
AXLE, FRONT - HUB AND BEARINGS (590SN)	44.101.04	02
AXLE, FRONT - MOUNTING (580N, 580SN)	44.100.15	01
AXLE, FRONT - MOUNTING (590SN)	44.100.15	02
AXLE, FRONT DRIVE - ASSEMBLY	25.100.01	
AXLE, FRONT DRIVE - CYLINDER, STEERING STD ACP (580N,580SN)	41.216.06	
AXLE, FRONT DRIVE - DIFFERENTIAL	25.102.03	04
AXLE, FRONT DRIVE - DIFFERENTIAL HD ACP LS (580SN WT)	25.102.04	01
AXLE, FRONT DRIVE - DIFFERENTIAL HD ACP LS (580SN WT) AXLE, FRONT DRIVE - HOUSING (580N, 580SN)	25.102.04 25.100.08	02 01
AXLE, FRONT DRIVE - HOUSING (380N, 380SN) AXLE, FRONT DRIVE - HOUSING HD ACP (580SN WT, 590SN)	25.100.08	01
AXLE, FRONT DRIVE - HOUSING, SWIVEL (580N, 580SN)	25.108.01	01
AXLE, FRONT DRIVE - HOUSING, SWIVEL HD ACP (580SN WT, 590SN)	25.108.01	02
AXLE, FRONT DRIVE - MOUNTING (580N, 580SN)	25.100.02	01
AXLE, FRONT DRIVE - MOUNTING (580SN WT)	25.100.02	02
AXLE, FRONT DRIVE - MOUNTING (590SN)	25.100.02	03
AXLE, FRONT DRIVE - PLANETARY (580N, 580SN)	25.310.01	01
AXLE, FRONT DRIVE - PLANETARY HD ACP (580SN WT, 590SN)	25.310.01	02
AXLE, FRONT DRIVE - RING AND PINION (580N,580SN)	25.102.01	01
AXLE, FRONT DRIVE - RING AND PINION (590SN) AXLE, FRONT DRIVE - RING AND PINION HD ACP LS (580SN WT)	25.102.01 25.102.01	03 02
AXLE, FRONT DRIVE - SHAFT	25.100.16	02
AXLE, FRONT DRIVE - SHAFT HD ACP (580SN WT, 590SN)	25.100.16	02
AXLE, FRONT DRIVE - SHAFTS, AXLE (580N, 580SN)	25.300.02	
AXLE, FRONT DRIVE - SHAFTS, AXLE (580SN WT, 590SN)	25.300.02	
AXLE, REAR DRIVE - BRAKE, DIFFERENTIAL	27.100.11	
AXLE, REAR DRIVE - DIFFERENTIAL (580N, 580SN)	27.106.01	01
AXLE, REAR DRIVE - DIFFERENTIAL (580SN WT, 590SN)	27.106.01	02
AXLE, REAR DRIVE - DIFFERENTIAL LOCK	27.110.02	01
AXLE, REAR DRIVE - DIFFERENTIAL LOCK (580N, 580SN) AXLE, REAR DRIVE - DIFFERENTIAL LOCK (580SN WT, 590SN)	27.110.02 27.110.02	02 03
AXLE, REAR DRIVE - HOUSING (580N, 580SN)	27.100.02	03
AXLE, REAR DRIVE - HOUSING (580SN WT, 590SN)	27.100.10	
AXLE, REAR DRIVE - MOUNTING (580N, 580SN)	27.100.08	01
AXLE, REAR DRIVE - MOUNTING (580SN WT, 590SN)	27.100.08	02
AXLE, REAR DRIVE - PLANETARY (580N, 580SN)	27.120.02	01
AXLE, REAR DRIVE - PLANETARY (580SN WT, 590SN)	27.120.02	02
AXLE, REAR DRIVE - RING AND PINION (580N, 580SN)	27.106.02	01
AXLE, REAR DRIVE - RING AND PINION (580SN WT, 590SN)	27.106.02	02
BACKHOE - COUPLER AND BUCKET PINS (580N, 580SN, 580SN WT)	39.121.03	
BACKHOE - COUPLER AND BUCKET PINS (590SN) BACKHOE - BOOM AND SWING TOWER (580N)	39.121.04 39.105.07	
BACKHOE - BOOM AND SWING TOWER (580N) BACKHOE - BOOM AND SWING TOWER (590SN)	39.105.09	
BACKHOE - BOOM AND SWING TOWER, 14' HEAVY (580SN, 580SN WT)	39.105.08	
BACKHOE - DIPPER, EXTENDABLE (INNER) (580N, 580SN, 580SN WT)	39.121.01	02

BACKHOE - DIPPER, EXTENDABLE (INNER) (590SN) BACKHOE - DIPPER, EXTENDABLE (OUTER) (580N, 580SN, 580SN WT) BACKHOE - DIPPER, EXTENDABLE (OUTER) (590SN) BACKHOE - DIPPER, STANDARD (580N) BACKHOE - DIPPER, STANDARD (580SN, 580SN WT) BACKHOE - DIPPER, STANDARD (590SN) BACKHOE - DIPPER, STANDARD CYLINDER PIN BACKHOE - DIPPER, STANDARD WITH HYDRAULIC COUPLER(590SN)	39.121.02 39.121.01 39.121.02 39.121.11 39.121.07 39.121.10 39.121.08 39.121.09	02 01 01
BACKHOE - HYDRAULIC COUPLER (580SN, 580SN WT, 590SN) BACKHOE - HYDRAULIC COUPLER LINK AND BUCKET PIN (580SN, 580SN WT, 590SN)	39.121.06 39.121.06	01 02
BACKHOE - LINK, STRAIGHT (580N, 580SN, 580SN WT) BACKHOE - SWING TOWER (580N) BACKHOE - SWING TOWER AND SWING CYLINDERS (580N)	39.121.05 39.105.06 35.730.04	01
BACKHOE - SWING TOWER AND SWING CYLINDERS (580SN AND 580SN WT)	35.730.04	02
BACKHOE - SWING TOWER AND SWING CYLINDERS (590SN) BACKHOE HYDRAULIC COUPLER CONTROL SWITCHES BATTERY, DUAL - COLD START BATTERY, SINGLE BEACON, ROTATING (CAB OR CANOPY MODELS)	35.730.04 55.524.01 55.301.07 55.301.08 55.408.01	03
BOOM LATCH	84.120.01	
BRACKET - VARIABLE VALVE PUMP PRESSURE HOSES (580SN WT, 590SN)	35.726.21	03
BRACKET - VARIABLE VALVE PUMP PRESSURE HOSES (580SN) BRAKE - PEDALS BRAKE LINES TO AXLE BRAKE LINES TO TRANSMISSION - 2WD BRAKE LINES TO TRANSMISSION - 4WD BRAKE LINES TO TRANSMISSION - 4WD POWERSHIFT BREATHER - ENGINE (580N) BREATHER - ENGINE (580SN, 580SN WT, 590SN) BUCKET RETROFIT KIT BUCKET, BACKHOE (305 MM (12 INCH) WIDE)	35.726.21 33.202.03 33.202.10 33.202.11 33.202.12 33.202.13 10.101.04 10.101.04 05.001.01 84.100.01	02
BUCKET, BACKHOE (457 MM (18 INCH) WIDE) BUCKET, BACKHOE (610 MM (24 INCH) / 762 MM (30 INCH) WIDE)	84.100.01 84.100.01	03 04
BUCKET, BACKHOE (914 MM (36 INCH) / 762 MM (30 INCH) WIDE)	84.100.01	04
BUCKET, BACKHOE- HIGH CAPACITY (610 MM (24 INCH) / 762 MM (30 INCH) WIDE)	84.100.01	05
BUCKET, LOADER 4-IN-1 (82 IN) BUCKET, LOADER LONG LIP (93 IN)	82.100.02 82.100.01	01 01
BUCKET, LOADER LONG LIP (93 IN) BUCKET, LOADER LONG LIP (96 IN) CAB - AIR CONDITIONING LINES, EVAPORATOR CORE	82.100.01 82.100.01 50.206.03	02
CAB - AIR CONDITIONING, COMPRESSOR (580N) CAB - AIR CONDITIONING, COMPRESSOR (580SN, 580SN WT, 590SN) CAB - AIR CONDITIONING, CONDENSER AND RECEIVER DRYER	50.200.08 50.200.08 50.200.17	01 02 01
(580N) CAB - AIR CONDITIONING, CONDENSER AND RECEIVER DRYER (580SN, 580SN WT, 590SN)	50.200.17	02
CAB - BLOWER HOUSING, VENTILATION DUCTS, DRAIN LINES CAB - DELUXE INTERIOR TRIM (580N, 580SN) CAB - DELUXE INTERIOR TRIM (580SN WT, 590SN) CAB - DELUXE POST COVERS CAB - DOOR MOUNTING CAB - DOORS CAB - FILTER, AIR CAB - FLOOR MATS AND PLATES 580N AND 580SN CAB - FLOOR MATS AND PLATES 580SN WT AND 590SN	50.206.05 90.160.02 90.160.03 90.160.04 90.154.07 90.154.02 50.206.04 90.150.01 90.150.01	01 02

CAB - FRAME	90.150.02	01
CAB - GLASS, MIRROR AND HOLD OPEN	90.156.05	
CAB - HEATER	50.104.01	
CAB - STANDARD INTERIOR TRIM	90.160.01	
CAB - TRIM AND COVERS	90.150.02	02
CAB - WINDOW, REAR	90.156.03	
CAB - WINDOW, RIGHT HAND, FOR SINGLE DOOR CAB FRAMES	90.156.04	
CAB - WIPERS	55.518.06	
CAB ROOF LIGHT PODS	90.150.03	
CAMSHAFT - TIMING CONTROL (580SN, 580SN WT, 590SN)	10.106.07	
CAMSHAFT (580N)	10.106.07	
CANOPY, ROPS - DELUXE	90.150.10	
CANOPY, ROPS - FRAME, COVERS, MIRROR, VISOR	90.150.09	
CANOPY, ROPS - GLASS	90.156.02	
CANOPY, ROPS - WIPER, FRONT AND WINDSHIELD WASHER	55.518.07	
CHASSIS - CAB MOUNTS, BARRIER CURTAIN, AND AIR INTAKE	39.100.03	
SCREEN		
CHASSIS - FRAME BUSHINGS (580N, 580SN, 580SN WT)	39.100.01	
CHASSIS - FRAME BUSHINGS (590SN)	39.100.02	
COLD START / GRID HEATER (580SN, 580SN WT, 590SN)	10.254.12	
CONNECTING ROD (580N)	10.105.02	
CONTROL - BACKHOE, 2 LEVER	35.726.31	01
CONTROL - BACKHOE, AUXILIARY FOOT SWITCH	35.726.35	01
CONTROL - BACKHOE, WITH FOOT SWING (WITH EXTENDABLE	35.726.30	01
	35.720.30	01
	05 700 00	00
CONTROL - BACKHOE, WITH FOOT SWING (WITH EXTENDABLE	35.726.30	02
	05 300 00	
CONTROL - BACKHOE, WITH FOOT SWING (WITHOUT EXTENDABLE	35.726.36	01
DIPPER)		
CONTROL - BACKHOE, WITH FOOT SWING (WITHOUT EXTENDABLE	35.726.36	02
DIPPER)		
CONTROL - LOADER LIFT AND BUCKET	35.724.07	02
CONTROL, TOWER STRUCTURE	35.726.09	01
CONTROL, TOWER STRUCTURE	35.726.09	03
CONTROL, TOWER STRUCTURE	35.726.09	02
CONTROLS - LOADER CLAM	35.724.06	
CONTROLS - LOADER LIFT AND BUCKET	35.724.07	01
CONTROLS - LOADER LIFT AND BUCKET	35.724.03	01
CONTROLS - THROTTLE, FOOT	10.220.01	
CONTROLS - THROTTLE, HAND	10.220.02	
COOLER, CHARGE AIR AND HOSES (580SN, 580SN WT, 590SN)	10.408.07	
COOLING SYSTEM - ENGINE (580N)	10.400.03	
COOLING SYSTEM - ENGINE (580SN, 580SN WT, 590SN)	10.400.03	
COUNTERWEIGHT, FRONT	37.140.01	
COUPLER, TOOL QUICK	39.125.03	
CRANKCASE COVERS (580N)	10.102.03	01
CRANKCASE COVERS (580N)	10.102.03	02
CRANKCASE COVERS (580SN, 580SN WT, 590SN)	10.102.03	01
CRANKCASE COVERS (580SN, 580SN WT, 590SN)	10.102.03	02
CRANKSHAFT (580N)	10.103.01	
CRANKSHAFT (580SN, 580SN WT, 590SN)	10.103.01	
CYLINDER - BACKHOE BOOM (580N)	35.730.03	01
CYLINDER - BACKHOE BOOM (580SN, 580SN WT)	35.730.03	02
CYLINDER - BACKHOE BOOM (580SN, 580SN WT) CYLINDER - BACKHOE BOOM (590SN)	35.730.03	02
CYLINDER - BACKHOE BUCKET (580SN, 580SN WT)	35.738.04	03
	35.738.04	02
	35.730.01	01
CYLINDER - BACKHOE DIPPER (590SN)	35.730.01	03

CYLINDER - BACKHOE DIPPER(580SN, 580SN WT)	35.730.01	02
CYLINDER - BACKHOE EXTENDABLE DIPPER (580N, 580SN, 580SN WT)	35.740.01	02
CYLINDER - BACKHOE STABILIZER (580N)	35.732.01	01
CYLINDER - BACKHOE STABILIZER (580SN WT, 590SN)	35.732.01	07
CYLINDER - BACKHOE STABILIZER (580SN)	35.732.01	06
CYLINDER - BACKHOE SWING (580N)	35.739.02	
CYLINDER - BACKHOE SWING (580SN, 580SN WT, 590SN)	35.739.03	
CYLINDER - COUPLER, BACKHOE BUCKET	35.726.15	
CYLINDER - LOADER 4-IN-1	35.701.03	
CYLINDER - LOADER BUCKET (580N)	35.738.01	01
CYLINDER - LOADER BUCKET (580SN, 580SN WT)	35.738.01	02
CYLINDER - LOADER BUCKET (590SN)	35.738.01	03
CYLINDER - LOADER LIFT (580N)	35.736.02	
CYLINDER - LOADER LIFT (580SN WT, 590SN)	35.736.04	
CYLINDER - LOADER LIFT (580SN)	35.736.03	
CYLINDER ASSY - BRAKE MASTER	33.202.09	
CYLINDER BLOCK - COVERS (580N)	10.102.04	
CYLINDER BLOCK - COVERS (580SN, 580SN WT, 590SN)	10.102.04	
CYLINDER BLOCK (580N)	10.001.02	01
CYLINDER BLOCK (580N)	10.001.02	02
CYLINDER BLOCK (580SN, 580SN WT, 590SN)	10.001.02	01
CYLINDER BLOCK (580SN, 580SN WT, 590SN)	10.001.02	02
CYLINDER HEAD - COVERS (580N)	10.101.02	
CYLINDER HEAD (580N)	10.101.01	
CYLINDER HEAD (580SN, 580SN WT, 590SN)	10.101.01	
CYLINDER HEAD COVERS (580SN, 580SN WT, 590SN)	10.101.02	
		04
DEAERATION SYSTEM - MOUNTING	10.406.01	01
DECALS	90.108.01	01
DECALS	90.108.01	02
DECALS - ENGLISH	90.108.09	01
DECALS - ENGLISH	90.108.09	02
DIA - BOOM LATCH	88.084.01	
DRIVESHAFT - REAR AXLE (580N, 580SN)		
	21.300.00	
DRIVESHAFT - REAR AXLE (580SN WT, 590SN)	21.300.00	
DYNAMIC BALANCER, GEARS & SHAFTS (580N)	10.110.02	
DYNAMIC BALANCER, GEARS & SHAFTS (580SN, 580SN WT, 590SN)	10.110.02	
DYNAMIC BALANCER, HOUSING (580SN, 580SN WT, 590SN)	10.110.03	
ELECTRICAL - LAMPS, ROPS CANOPY	55.404.01	02
ELECTRICAL - LAMPS, ROPS CANOPY	55.404.01	01
ELECTRICAL - SIDE CONSOLE, S AND H TYPE TRANSMISSION (580SN,	55.512.16	01
580SN WT, 590SN)		
ELECTRICAL - SIDE CONSOLE, STANDARD TRANSMISSION (580N)	55.512.16	03
ELECTRICAL - SIDE CONSOLE, S-TYPE TRANSMISSION (580N)	55.512.17	01
ELECTRICAL - TRANSMISSION, POWERSHIFT (580SN, 580SN WT,	55.100.35	
590SN)		
	EE 100 10	
ELECTRICAL - TRANSMISSION, POWERSHIFT S TYPE (580SN, 580SN	55.100.40	
WT, 590SN)		
ENGINE	10.001.01	
ENGINE - BLOCK HEATER (580N)	10.254.03	
ENGINE - BLOCK HEATER (580SN, 580SN WT, 590SN)	10.254.03	
ENGINE - LIFT HOOK	10.012.05	
ENGINE - MOUNTING	10.012.03	
ENGINE - MOUNTING (580N)	10.012.03	
ENGINE (580N)	10.001.01	
ENGINE FAN - 7BLADE (NON VISCOUS)	10.414.01	02
ENGINE FAN - 9 BLADE (VISCOUS)	10.414.01	01
ENGINE OIL DIPSTICK (580N)	10.304.10	
ENGINE OIL DIPSTICK (580SN, 580SN WT, 590SN)	10.304.10	

EXHAUST MANIFOLD (580N)	10.254.10	
EXHAUST MANIFOLD (580SN, 580SN WT, 590SN)	10.254.10	
FAN DRIVE (580N)	10.414.02	
FAN DRIVE (580SN, 580SN WT, 590SN)	10.414.02	
FENDER EXTENSIONS	90.116.08	
FILTERS AND CAPACITIES	05.100.01	
FLYWHEEL - ENGINE (580N)	10.103.03	
FLYWHEEL - ENGINE (580SN, 580SN WT, 590SN)	10.103.03	
FRAME - LOADER LIFT	39.125.01	
FRAME - LOADER LINKAGE	39.125.02	
FUEL FILTER (580N)	10.206.01	01
FUEL FILTER (580SN, 580SN WT, 590SN)	10.206.01	02
FUEL INJECTION PUMP (580N)	10.246.01	01
FUEL INJECTION SYSTEM - INJECTOR (580N)	10.218.03	01
FUEL INJECTION SYSTEM - MODULE, ENGINE CONTROL (580SN,	55.440.01	
580SN WT, 590SN)		
FUEL INJECTION SYSTEM (580N)	10.218.05	03
FUEL INJECTION SYSTEM (580N)	10.246.01	02
FUEL LINES, RESERVOIR (580N)	10.214.01	01
FUEL LINES, RESERVOIR (580SN, 580SN WT, 590SN)	10.214.01	02
FUEL PUMP (580N)	10.210.01	
HANDLE, LOADER CONTROL - POWER SHIFT TRANSMISSION	35.724.05	
HANDLE, LOADER CONTROL - TRANSMISSION ASSY, 2WD, 4WD	35.724.04	
HARNESS - BACKHOE DUAL AUXILLIARY HYDRAULIC WITH	55.512.18	
MECHANICAL CONTROLS	00.012.10	
HARNESS - BACKHOE DUAL AUXILLIARY HYDRAULIC, WITH PILOT	55.512.20	
CONTROLS		
HARNESS - BACKHOE SINGLE AUXILLIARY HYDRAULIC, WITH PILOT	55.512.19	
CONTROLS		
HARNESS - BACKHOE, WITH PILOT CONTROLS	55.512.21	
HARNESS - CHASSIS		
	55.100.03	
HARNESS - FRONT CONSOLE	55.512.14	03
HARNESS - FRONT CONSOLE, MOUNTING	55.512.14	02
HARNESS - FRONT CONSOLE, STANDARD TRANSMISSION	55.512.15	02
HARNESS - FRONT CONSOLE, SWITCHES	55.512.14	01
HARNESS - SIDE CONSOLE, S AND H TYPE TRANSMISSION (580SN,	55.512.17	03
580SN WT, 590SN)	00.0.1	
HARNESS - STANDARD TRANSMISSION (580N)	55.100.02	02
		02
HARNESS INSTALL - FRONT CONSOLE, S AND H TYPE	55.512.13	
TRANSMISSION (580SN, 580SN WT, 590SN )		
HARNESS INSTALL - SIDE CONSOLE, S AND H TYPE TRANSMISSION	55.512.17	02
HARNESS INSTALL - SIDE CONSOLE, STANDARD TRANSMISSION	55.512.16	02
HARNESS, INSTALL - TRANSMISSION	55.100.02	01
HARNESS, INSTALL - CHASSIS	55.100.01	01
		01
HARNESS, INSTALL - ENGINE (580SN, 580SN WT, 590SN)	55.100.06	
HARNESS, INSTALL - FRONT CONSOLE, STANDARD TRANSMISSION	55.512.15	01
HARNESS, TRANSMISSION 2WD / 4WD POWERSHIFT - CONTROL	55.100.30	
VALVE		
HEADLINER	90.160.05	
	10.408.01	
HEAT EXCHANGER - ENGINE (580N)		
HOOD - GRILL	90.100.04	
HOOD - PANELS, SIDE	90.100.02	
HORN - ALARM, BACKUP	55.408.09	
HYDRAULICS - BACKHOE ( 580SN, 580SN WT) (W/O EXTENDABLE	35.738.02	01
HYDRAULICS - BACKHOE (580N) (W/EXTENDABLE DIPPER)	35.738.03	02
HYDRAULICS - BACKHOE (580N) (W/O EXTENDABLE DIPPER)	35.738.03	01

HYDRAULICS - BACKHOE (580SN, 580SN WT) (W/ EXTENDABLE	35.738.02	02
DIPPER)		
HYDRAULICS - BACKHOE AUXILIARY	35.726.10	01
HYDRAULICS - BACKHOE AUXILIARY (590SN)	35.726.11	01
HYDRAULICS - BACKHOE AUXILIARY, EXTENDABLE DIPPER (580N,	35.726.10	02
580SN, 580SN WT)		
HYDRAULICS - BACKHOE AUXILIARY, EXTENDABLE DIPPER (590SN)	35.726.11	02
HYDRAULICS - BACKHOE EXTENDABLE DIPPER (580N,580SN, 580SN	35.740.01	01
	05 740 00	04
HYDRAULICS - BACKHOE EXTENDABLE DIPPER (590SN)	35.740.02	01
HYDRAULICS - BACKHOE STABILIZER	35.732.01	04
HYDRAULICS - BACKHOE STANDARD DIPPER (590SN)	35.740.02	02
HYDRAULICS - BOOM INSTALL (580N)	35.737.01	01 02
HYDRAULICS - BOOM INSTALL (580SN, 580SN WT)	35.737.01	
HYDRAULICS - BOOM INSTALL (590SN) HYDRAULICS - BRAKE MASTER CYLINDER	35.737.01	03
HYDRAULICS - CHECK VALVE INSTALL, STABILIZER (580N)	33.202.14 35.732.01	02
HYDRAULICS - CHECK VALVE INSTALL, STABILIZER (380N) HYDRAULICS - CHECK VALVE INSTALL, STABILIZER CYLINDERS	35.732.01	02
(580SN, 580SN WT, 590SN)	33.732.01	03
HYDRAULICS - COUPLER VALVE TO BULKHEAD	35.726.12	02
HYDRAULICS - COUPLER, BACKHOE BUCKET (EXTENDABLE DIPPER)	35.726.12	02
HYDRAULICS - COUPLER, BACKHOE BUCKET (EXTENDABLE DIPPER) HYDRAULICS - COUPLER, BACKHOE BUCKET (EXTENDABLE	35.726.14	02
DIPPER)(590SN)	33.720.14	
HYDRAULICS - COUPLER, BACKHOE BUCKET (STANDARD DIPPER)	35.726.13	01
HYDRAULICS - COUPLER, BACKHOE BUCKET (STANDARD DIPPER) HYDRAULICS - COUPLER, LOADER TOOL QUICK	35.701.16	01
HYDRAULICS - CYLINDER BACKHOE SWING / STABILIZER (580N)	35.739.05	
HYDRAULICS - CYLINDER BACKHOE SWING / STABILIZER (580N) HYDRAULICS - CYLINDER BACKHOE SWING / STABILIZER (580SN,	35.739.04	
580SN WT, 590SN)	33.739.04	
HYDRAULICS - CYLINDER, LOADER BUCKET 4-IN-1	35.701.02	01
HYDRAULICS - CYLINDER, LOADER BUCKET 4-IN-1	35.701.02	02
HYDRAULICS - EXTENDABLE DIPPER COUPLER (590SN)	35.936.01	02
HYDRAULICS - FILTER	35.750.03	
HYDRAULICS - HEAVY LIFT (MECHANICAL CONTROL) (580SN, 580SN	35.726.28	01
WT, 590SN)	00.720.20	01
HYDRAULICS - HEAVY LIFT (PILOT CONTROL) (580SN,580SN WT,	35.726.27	01
590SN)	00.120.21	01
HYDRAULICS - LOADER	35.701.14	
HYDRAULICS - LOADER 4 IN 1	35.701.01	02
HYDRAULICS - LOADER 4 IN 1	35.701.01	01
HYDRAULICS - LOADER LIFT (580SN, 580SN WT, 590SN)	35.701.13	•
HYDRAULICS - LOADER LIFT CYLINDER (580SN WT, 590SN)	35.701.12	
HYDRAULICS - LOADER LIFT CYLINDER (580SN)	35.701.11	
HYDRAULICS - LOADER, 2 SPOOL (580N WITH PILOT CONTROLS)	35.701.06	01
(580SN, 580SN WT, 590SN WITHOUT PILOT CONTROLS)		-
HYDRAULICS - LOADER, 2 SPOOL (MECHANICAL CONTROLS) (580SN,	35.701.04	02
580SN WT, 590SN)		
HYDRAULICS - LOADER, 2 SPOOL (PILOT CONTROLS) (580SN, 580SN	35.701.04	01
WT, 590SN)		
HYDRAULICS - LOADER, 3 SPOOL (580N WITH PILOT CONTROLS)	35.701.06	02
(580SN, 580SN WT, 590SN WITHOUT PILOT CONTROLS)		
HYDRAULICS - LOADER, 3 SPOOL (MECHANICAL CONTROLS) (580SN,	35.701.05	02
580SN WT, 590SN)		
HYDRAULICS - LOADER, 3 SPOOL (PILOT CONTROLS) (580SN, 580SN	35.701.05	01
WT, 590SN)		
HYDRAULICS - PILOT CONTROL JOYSTICKS	35.726.09	04
HYDRAULICS - PILOT CONTROLS	35.726.08	01
HYDRAULICS - PILOT CONTROLS	35.726.08	02
HYDRAULICS - PILOT CONTROLS, DUAL AUX. (7 SPOOL)	35.726.08	03

HYDRAULICS - PUMP, EQUIPMENT (WITHOUT POWER LIFT) (580SN)      35.106.02      02        HYDRAULICS - STEERING      41.200.04        HYDRAULICS - STEERING (580N)      41.200.04        HYDRAULICS - STEERING (580N)      41.200.03        HYDRAULICS - STEERING (580N)      41.200.03        HYDRAULICS - STEERING (580SN, 580SN WT, 590SN)      41.200.03        HYDRAULICS - STEERING (580SN, 580SN WT, 590SN)      41.200.03        HYDRAULICS - TANK, TOOL BOX      35.750.01        WTHAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND)      35.150.16      03        WITHOUT EXTENDABLE DIPPER, 8 SPOOL      HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (LEFT-HAND)      35.150.15      03        WITH HORN B BI-DIRECTIONAL BUTTONS      HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (LEFT-HAND)      35.150.15      01        WITH HORN & BI-DIRECTIONAL BUTTONS      HYDRAULICS - VALVE, LOADER CONTROL (2 SPOOL) (580SN, 580SN      35.701.07      VT.790SN)        HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, MECHANICAL      35.701.08      02      02        CONTROLS (580SN, 580SN WT, 590SN)      HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.701.09      01        CONTROLS (580SN, 580SN WT, 590SN)      HYDRAULICS - VALVE, RESSURE REDUCING (3 SPOOL) (WITH PILOT      35.150.14 </th <th>HYDRAULICS - PILOT CONTROLS, DUAL AUX. (8 SPOOL) HYDRAULICS - PUMP INSTALL (580N) HYDRAULICS - PUMP INSTALL (580SN, 580SN WT, 590SN) HYDRAULICS - PUMP INSTALL (590SN) HYDRAULICS - PUMP, EQUIPMENT (590SN) HYDRAULICS - PUMP, EQUIPMENT (WITH POWER LIFT) (580SN, 580SN WT)</th> <th>35.726.08 35.106.01 35.106.01 35.106.01 35.106.01 35.106.02</th> <th>04 04 01 02 03 01</th>	HYDRAULICS - PILOT CONTROLS, DUAL AUX. (8 SPOOL) HYDRAULICS - PUMP INSTALL (580N) HYDRAULICS - PUMP INSTALL (580SN, 580SN WT, 590SN) HYDRAULICS - PUMP INSTALL (590SN) HYDRAULICS - PUMP, EQUIPMENT (590SN) HYDRAULICS - PUMP, EQUIPMENT (WITH POWER LIFT) (580SN, 580SN WT)	35.726.08 35.106.01 35.106.01 35.106.01 35.106.01 35.106.02	04 04 01 02 03 01
HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND)      35.150.16      02        WITHOUT EXTENDABLE DIPPER, 7 SPOOL      35.150.15      03        HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (LEFT-HAND)      35.150.15      02        WITH HORN      35.150.15      02        WITH HORN & BI-DIRECTIONAL BUTTONS      35.150.15      01        HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (LEFT-HAND)      35.150.15      01        WITH HORN & UNI-DIRECTIONAL BUTTONS      35.701.07      35.701.08        HYDRAULICS - VALVE, LOADER CONTROL (2 SPOOL) (580SN, 580SN      35.701.08      CONTROLS) (580SN, 580SN WT, 590SN)        HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.701.09      02        CONTROLS (580SN, 580SN WT, 590SN)      90      90      92        HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.150.14      01        CONTROLS (580SN, 580SN WT, 590SN)      90      90      92        HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT      35.150.14      01        CONTROLS)      S6500.00      01      101        CONTROLS)      HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT      35.150.14      03        CONTROLS)	HYDRAULICS - PUMP, EQUIPMENT (WITHOUT POWER LIFT) (580SN) HYDRAULICS - RIDE CONTROL HYDRAULICS - STEERING HYDRAULICS - STEERING (580N) HYDRAULICS - STEERING (580SN, 580SN WT, 590SN) HYDRAULICS - TANK HYDRAULICS - TANK, TOOL BOX HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND)	35.350.02 41.200.04 41.200.02 41.200.03 35.750.01 35.750.02	
HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (LEFT-HAND)35.150.1503WITH HORNA35.150.1502WITH HORN & BI-DIRECTIONAL BUTTONS35.150.1501WITH HORN & UNI-DIRECTIONAL BUTTONS35.150.1501WITH HORN & UNI-DIRECTIONAL BUTTONS35.701.07WT, \$90SN)HYDRAULICS - VALVE, LOADER CONTROL (2 SPOOL) (580SN, 580SN35.701.07WT, \$90SN)HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, MECHANICAL35.701.08CONTROLS) (580SN, 580SN WT, 590SN)HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT35.701.09HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT35.701.0901CONTROLS (580SN, 580SN WT, 590SN)HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT35.150.1401CONTROLS (580SN, 580SN WT, 590SN)HYDRAULICS - VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT35.150.1402CONTROLS)HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT35.150.1403CONTROLS)INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY05.500.0101INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY05.500.0102INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN)10.218.0501INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)10.218.0501INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)10.246.01INSTRUMENT PANEL, FRONT - COVERS90.100.0910.118.51INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)10.246.01INSTRUMENT PANEL, FRONT - COVERS90.100.0910.246.01INS	HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND)	35.150.16	02
HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (LEFT-HAND)      35.150.15      02        WITH HORN & BI-DIRECTIONAL BUTTONS      35.150.15      01        HYDRAULICS - VALVE, LOYSTICK (PILOT CONTROLS) (LEFT-HAND)      35.150.15      01        WITH HORN & UNI-DIRECTIONAL BUTTONS      35.701.07      35.701.07        WT, 590SN)      HYDRAULICS - VALVE, LOADER CONTROL (2 SPOOL, MECHANICAL      35.701.08        CONTROLS) (580SN, 580SN WT, 590SN)      35.701.09      02        HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.701.09      02        CONTROLS (580SN, 580SN WT, 590SN)      10      20        HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.150.14      01        CONTROLS (580SN, 580SN WT, 590SN)      10      25.150.14      01        WDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT      35.150.14      02        CONTROLS)      10      35.150.14      03      10      20        CONTROLS      VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT      35.150.14      03      10        CONTROLS)      INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY      05.500.00      01      10        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.	,	35.150.15	03
HYDRAULICS - VALVE, JOYSTICK (PILOT CONTROLS) (LEFT-HAND)      35.150.15      01        WITH HORN & UNI-DIRECTIONAL BUTTONS      HYDRAULICS - VALVE, LOADER CONTROL (2 SPOOL) (580SN, 580SN      35.701.07        HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, MECHANICAL      35.701.08      02        CONTROLS (580SN, 580SN WT, 590SN)      HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.701.09      02        CONTROLS (580SN, 580SN WT, 590SN)      HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.701.09      01        CONTROLS (580SN, 580SN WT, 590SN)      HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.701.09      01        CONTROLS (580SN, 580SN WT, 590SN)      HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT      35.150.14      01        CONTROLS      VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT      35.150.14      02        CONTROLS      VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT      35.150.14      03        CONTROLS      VITHAL STOCKING LIST "A" (ISL) - FOR NA ONLY      05.500.01      01        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      03        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      01        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      02 <td></td> <td>35.150.15</td> <td>02</td>		35.150.15	02
WITH HORN & UNI-DIRECTIONAL BUTTONS        HYDRAULICS - VALVE, LOADER CONTROL (2 SPOOL) (580SN, 580SN      35.701.07        WT, 590SN)      HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, MECHANICAL      35.701.08        CONTROLS) (580SN, 580SN WT, 590SN)      35.701.09      02        HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.701.09      01        CONTROLS (580SN, 580SN WT, 590SN)      HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.701.09      01        CONTROLS (580SN, 580SN WT, 590SN)      HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.150.14      01        CONTROLS (580SN, 580SN WT, 590SN)      HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT      35.150.14      02        CONTROLS)      HYDRAULICS - VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT      35.150.14      02        HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT      35.150.14      03        CONTROLS)      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      01        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      02      10        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      02      10      10      10        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY		35.150.15	01
WT, 590SN)    HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, MECHANICAL    35.701.08      CONTROLS) (580SN, 580SN WT, 590SN)    HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT    35.701.09    02      CONTROLS (580SN, 580SN WT, 590SN)    HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT    35.701.09    01      CONTROLS (580SN, 580SN WT, 590SN)    HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT    35.701.09    01      CONTROLS (580SN, 580SN WT, 590SN)    HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT    35.150.14    01      CONTROLS)    HYDRAULICS - VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT    35.150.14    02      HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT    35.150.14    03      CONTROLS)    HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT    35.150.14    03      INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY    05.500.01    01    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    02    02      INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN)    10.218.05    01      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    02      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    02      INJECTION POULP (5	WITH HORN & UNI-DIRECTIONAL BUTTONS		-
CONTROLS) (580SN, 580SN WT, 590SN)      35.701.09      02        HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.701.09      01        CONTROLS (580SN, 580SN WT, 590SN)      35.701.09      01        CONTROLS (580SN, 580SN WT, 590SN)      35.701.09      01        CONTROLS (580SN, 580SN WT, 590SN)      35.701.09      01        CONTROLS      VALVE, LOADER CONTROL (3 SPOOL) (WITH PILOT      35.150.14      01        CONTROLS)      HYDRAULICS - VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT      35.150.14      02        CONTROLS)      HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT      35.150.14      03        CONTROLS)      INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY      05.500.00      01        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      03        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      02        INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN)      10.218.03      11        INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)      10.218.05      01        INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)      10.218.05      02        INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)      10.246.01      10	WT, 590SN)		
CONTROLS (580SN, 580SN WT, 590SN)      35.701.09      01        HYDRAULICS - VALVE, LOADER CONTROL (3 SPOOL, PILOT      35.701.09      01        CONTROLS (580SN, 580SN WT, 590SN)      11      01        HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT      35.150.14      01        CONTROLS)      14      125.150.14      02        HYDRAULICS - VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT      35.150.14      02        CONTROLS)      14      10      05.500.00      01        HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT      35.150.14      03        CONTROLS)      11      10.200.00      11      11        HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT      35.150.14      03        CONTROLS)      11      10.216.01      03      10.11        INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY      05.500.01      01      11        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      02      11        INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN)      10.218.05      11        INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)      10.218.05      02	CONTROLS) (580SN, 580SN WT, 590SN)		00
CONTROLS (580SN, 580SN WT, 590SN)      35.150.14      01        HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT      35.150.14      02        CONTROLS)      35.150.14      02        HYDRAULICS - VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT      35.150.14      02        CONTROLS)      35.150.14      03        HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT      35.150.14      03        CONTROLS)      01      01      01        INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY      05.500.00      01        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      03        INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY      05.500.01      02        INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN)      10.218.03      01        INJECTION EQUIPMENT - PIPING (580N, 580SN WT, 590SN)      10.218.05      01        INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)      10.218.05      02        INJECTION PUMP (580SN, 580SN WT, 590SN)      10.246.01      01        INJECTION PUMP (580SN, 580SN WT, 590SN)      10.246.01      01        INSTRUMENT PANEL, FRONT - COVERS      90.100.10      01.00      01        L	CONTROLS (580SN, 580SN WT, 590SN)		
HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT    35.150.14    01      CONTROLS)    HYDRAULICS - VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT    35.150.14    02      CONTROLS)    HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT    35.150.14    03      INTIAL STOCKING LIST "A" (ISL) - FOR NA ONLY    05.500.00    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    03      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    02      INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN)    10.218.03    01      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    01      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.246.01    01      INSTRUMENT PANEL, FRONT - COVERS    90.100.01    01      LAMPS - ROPS CAB    55.514.01    02      LOCKABLE FUEL CAP    10.216.01    MANIFOLD - INTAKE (580N)    10.254.06      MANIFOLD - INTAKE (580N, 580SN WT, 590SN)    10.254.06		35.701.09	01
HYDRAULICS - VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT    35.150.14    02      CONTROLS)    HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT    35.150.14    03      CONTROLS)    INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY    05.500.00    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    03      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    02      INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN)    10.218.03    01      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    01      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    02      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    02      INJECTION PUMP (580SN, 580SN WT, 590SN)    10.218.05    02      INJECTION PUMP (580SN, 580SN WT, 590SN)    10.246.01    01      INSTRUMENT PANEL, FRONT - COVERS    90.100.09    01      INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE)    90.100.10    01      LAMPS - ROPS CAB    55.514.01    0254.06 <td< td=""><td>HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT</td><td>35.150.14</td><td>01</td></td<>	HYDRAULICS - VALVE, PRESSURE REDUCING (2 SPOOL) (WITH PILOT	35.150.14	01
HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT    35.150.14    03      CONTROLS)    INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY    05.500.00    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    03      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    02      INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN)    10.218.03    01      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    01      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    02      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    02      INJECTION PUMP (580SN, 580SN WT, 590SN)    10.218.05    02      INJECTION PUMP (580SN, 580SN WT, 590SN)    10.218.05    02      INSTRUMENT PANEL, FRONT - COVERS    90.100.09    90.100.09      INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE)    90.100.10    0.246.01      LOCKABLE FUEL CAP    10.216.01    MANIFOLD - INTAKE (580N)    10.254.06      MIRROR, REAR VIEW - MOUNTING, CAB MODELS    90.118.51    01.55	HYDRAULICS - VALVE, PRESSURE REDUCING (3 SPOOL) (WITH PILOT	35.150.14	02
INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY    05.500.00    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    03      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    01      INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY    05.500.01    02      INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN)    10.218.03      INJECTION EQUIPMENT - PIPING (580N)    10.218.05    01      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    01      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    02      INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN)    10.218.05    02      INJECTION PUMP (580SN, 580SN WT, 590SN)    10.246.01    01      INSTRUMENT PANEL, FRONT - COVERS    90.100.09    01      INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE)    90.100.10    01      LAMPS - ROPS CAB    55.514.01    02      LOCKABLE FUEL CAP    10.254.06    01      MANIFOLD - INTAKE (580N, 580SN WT, 590SN)    10.254.06      MIRROR, REAR VIEW - MOUNTING, CAB MODELS    90.118.51      MUFFLER - EXHAUST SYSTEM    10.254.11    01      OIL FILTERS - ENGINE (580N)    10.206.04 <td>HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT</td> <td>35.150.14</td> <td>03</td>	HYDRAULICS - VALVE, PRESSURE REDUCING (4 SPOOL) (WITH PILOT	35.150.14	03
OIL FILTERS - ENGINE (580N) 10.206.04 01	INITIAL STOCKING LIST "A" (ISL) - FOR NA ONLY INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY INITIAL STOCKING LIST "B" (ISL) - FOR NA ONLY INJECTION EQUIPMENT - INJECTOR (580SN, 580SN WT, 590SN) INJECTION EQUIPMENT - PIPING (580N) INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN) INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN) INJECTION EQUIPMENT - PIPING (580SN, 580SN WT, 590SN) INJECTION PUMP (580SN, 580SN WT, 590SN) INSTRUMENT PANEL, FRONT - COVERS INSTRUMENT PANEL, SIDE - COVERS (RIGHT-HAND SIDE) LAMPS - ROPS CAB LOCKABLE FUEL CAP MANIFOLD - INTAKE (580N) MANIFOLD - INTAKE (580SN, 580SN WT, 590SN) MIRROR, REAR VIEW - MOUNTING, CAB MODELS	05.500.01 05.500.01 10.218.03 10.218.05 10.218.05 10.218.05 10.246.01 90.100.09 90.100.10 55.514.01 10.254.06 10.254.06 90.118.51	03 01 02 01
	OIL FILTER AND COOLER (580SN, 580SN WT, 590SN) OIL FILTERS - ENGINE (580N)	10.408.01 10.206.04	

OIL PUMP - ENGINE (580N)	10.304.01	
OIL PUMP - ENGINE (580SN, 580SN WT, 590SN)	10.304.01	
OIL PUMP, PAN (580N)	10.304.01	
OIL PUMP, PAN (580SN, 580SN WT, 590SN)	10.102.01	
PICTORIAL INDEX - ACCESSORIES	00.000.88	
PICTORIAL INDEX - AXLE & WHEELS	44.000.00	
PICTORIAL INDEX - AXLE & WHEELS	00.000.44	
PICTORIAL INDEX - BACKHOE	00.000.84	
PICTORIAL INDEX - BACKHOE	84.000.00	
PICTORIAL INDEX - BRAKE & CONTROLS	33.000.00	
PICTORIAL INDEX - BRAKE & CONTROLS	00.000.33	
PICTORIAL INDEX - DRAKE & CONTROLS PICTORIAL INDEX - CAB CLIMATE CONTROL	00.000.50	
PICTORIAL INDEX - CAB CLIMATE CONTROL		
	50.000.00	
PICTORIAL INDEX - ELECTRICAL SYSTEM	55.000.00	
PICTORIAL INDEX - ELECTRICAL SYSTEM	00.000.55	
PICTORIAL INDEX - ENGINE	10.000.00	
PICTORIAL INDEX - ENGINE	00.000.10	
PICTORIAL INDEX - FRAME COMPONENTS	00.000.39	
PICTORIAL INDEX - FRAME COMPONENTS	39.000.00	
PICTORIAL INDEX - FRONT LOADER	00.000.82	
PICTORIAL INDEX - FRONT LOADER	82.000.00	
PICTORIAL INDEX - FRONT MECHANICAL DRIVE	25.000.00	
PICTORIAL INDEX - FRONT MECHANICAL DRIVE	00.000.25	
PICTORIAL INDEX - HYDRAULIC SYSTEMS	35.000.00	
PICTORIAL INDEX - HYDRAULIC SYSTEMS	00.000.35	
PICTORIAL INDEX - MAINTENANCE	00.000.00	
PICTORIAL INDEX - PLATFORM, CAB, BODYWORK AND DECALS	90.000.00	
PICTORIAL INDEX - PLATFORM, CAB, BODYWORK AND DECALS	00.000.90	
PICTORIAL INDEX - REAR DRIVE AXLE	27.000.00	
PICTORIAL INDEX - REAR DRIVE AXLE	00.000.27	
PICTORIAL INDEX - STEERING	41.000.00	
PICTORIAL INDEX - STEERING	00.000.41	
PICTORIAL INDEX - TOWING HOOKS & BALLASTING	37.000.00	
PICTORIAL INDEX - TOWING HOOKS & BALLISTING	00.000.37	
PICTORIAL INDEX - TRANSMISSION	21.000.00	
PICTORIAL INDEX - TRANSMISSION	00.000.21	
PIPING - ENGINE COOLING SYSTEM (580SN, 580SN WT, 590SN)	10.406.10	
PIPING - FUEL (580N)		
	10.218.04	
PIPING - FUEL (580SN, 580SN WT, 590SN)	10.218.04	
PISTON - ENGINE (580N)	10.105.01	
PISTON - ENGINE (580SN, 580SN WT, 590SN)	10.105.01	
PISTONS - CONNECTING ROD (580SN, 580SN WT, 590SN)	10.105.02	
PULLEY - CRANKSHAFT (580N)	10.103.06	
PULLEY - CRANKSHAFT (580SN, 580SN WT, 590SN)	10.103.06	~ <b>-</b>
PUMP, EQUIPMENT HYDRAULIC	35.106.01	05
RADIATOR - MOUNTING (580N)	10.406.04	01
RADIATOR - MOUNTING (580SN, 580SN WT, 590SN)	10.406.04	02
RADIATOR WRAPPER	10.406.06	
RADIO	55.510.01	
REAR ACCESS PANEL (WITH MECHANICAL CONTROLS)	90.150.11	
ROCKER SHAFT (580N)	10.106.04	
ROCKER SHAFT (580SN, 580SN WT, 590SN)	10.106.04	
SEAL KIT - LOADER CONTROL VALVE	35.724.09	03
SEAT - ADJUSTABLE HEIGHT PEDESTAL	90.120.01	02
SEAT - MOUNTING (AIR SUSPENSION)	90.120.05	
SEAT - MOUNTING (MECHANICAL SUSPENSION)	90.120.01	01
SLOW MOVING VEHICLE EMBLEM	90.108.17	
STABILIZER PADS	35.732.01	05

STARTER STARTER / ALTERNATOR MOUNTING STEERING - COLUMN (580N) STEERING - COLUMN, TILT (580N) STEERING - COMFORT STEER (580N) STEERING - COMFORT STEER (580SN, 580SN WT, 590SN)	55.201.03	
STARTER / ALTERNATOR MOUNTING	55.201.09	
STEERING - COLUMN (580N)	41.204.08	
STEERING - COLUMN, TILT (580N)	41.204.05	
STEERING - COMFORT STEER (580N)	41.200.01	
STEERING - COMFORT STEER (580SN, 580SN WT, 590SN)	41.200.01	
THERMOSTAT - ENGINE COOLING SYSTEM (580N)	10.402.09	
THERMOSTAT - ENGINE COOLING SYSTEM (580SN, 580SN WT,	10.402.09	
THROTTLE, HAND - THROTTLE, FOOT	10.220.03	
TOOL BOX - RETRO FIT KIT (HYDRAULIC COUPLER)	90.120.11	
TOOL BOX - RETRO FIT KIT (MECHANICAL COUPLER)	90.120.10	
590SN) THROTTLE, HAND - THROTTLE, FOOT TOOL BOX - RETRO FIT KIT (HYDRAULIC COUPLER) TOOL BOX - RETRO FIT KIT (MECHANICAL COUPLER) TRANSMISSION - 2WD - FILTER, OIL TRANSMISSION - 2WD - HOUSING TRANSMISSION - 2WD - PUMP, OIL TRANSMISSION - 2WD - SHAFT, INPUT & PTO TRANSMISSION - 2WD - SHAFT, REVERSE & PRIMARY TRANSMISSION - 2WD - SHAFT, SECONDARY TRANSMISSION - 2WD - SHIFTER MECHANISM TRANSMISSION - 2WD - SHIFTER MECHANISM TRANSMISSION - 2WD - VALVE, CONTROL TRANSMISSION - 2WD / 4WD - BRAKE, PARKING	21.104.03	
TRANSMISSION - 2WD - HOUSING	21.112.01	
TRANSMISSION - 2WD - PLIMP OIL	21.154.01	
TRANSMISSION = 2WD = SHAFT INPLIT & PTO	21.140.01	
	21.154.02	
TRANSMISSION - 200 - SHAFT, REVERSE & FRIMART TRANSMISSION - 200 - SHAFT SECONDARV	21.154.02	
TRANSMISSION - 2000 - SHAFT, SECONDART	21.100.07	
	21.133.02	
TRANSMISSION - 2WD - VALVE, CONTROL	21.134.01	
TRANSMISSION - 2WD / 4WD - BRAKE, PARKING	33.110.04	
TRANSMISSION - 2WD / 4WD POWERSHIFT H TYPE, SPS - SHAFT,	21.155.14	
INPUT & PTO		
TRANSMISSION - 2WD / 4WD POWERSHIFT H TYPE, SPS - SHAFT,	21.155.03	
REVERSE & PRIMARY		
TRANSMISSION - 2WD / 4WD POWERSHIFT S TYPE - SHIFTER	21.133.01	
MECHANISM		
TRANSMISSION - 2WD / 4WD POWERSHIFT S TYPE- SHAFT,	21.154.09	
SECONDARY		
TRANSMISSION - 2WD / 4WD POWERSHIFT S TYPE- VALVE, CONTROL	21.134.01	
TRANSMISSION - 2WD / 4WD, POWERSHIFT H TYPE / SPS - PUMP, OIL	21.155.01	
TRANSMISSION - 4WD - BRAKE, PARKING	33.110.05	
TRANSMISSION - 4WD - FILTER, OIL	21.104.03	
TRANSMISSION - 4WD - HOUSING	21.112.01	
TRANSMISSION - 4WD - PUMP, OIL	21.154.01	
TRANSMISSION - 4WD - SHAFT, INPUT & PTO	21.140.01	
TRANSMISSION - 4WD - SHAFT, OUTPUT	21.154.03	
TRANSMISSION - 4WD - SHAFT, REVERSE & PRIMARY	21.154.08	
TRANSMISSION - 4WD - SHAFT, SECONDARY	21.154.09	
TRANSMISSION - 4WD - SHIFTER MECHANISM	21.133.02	
TRANSMISSION - 4WD - VALVE, CONTROL	21.134.01	
TRANSMISSION - 4WD - VALVE, SOLENOID	21.134.01	
TRANSMISSION - 4WD - VALVE, SOLENOID TRANSMISSION - 4WD POWERSHIFT H TYPE - HOUSING & FILTER,	21.134.05	
	21.113.01	
	04 440 04	
TRANSMISSION - 4WD POWERSHIFT H TYPE - HOUSING, REAR &	21.113.01	
THERMOSTAT		
TRANSMISSION - 4WD POWERSHIFT H TYPE - SHAFT, OUTPUT	21.155.15	
TRANSMISSION - 4WD POWERSHIFT H TYPE - SHAFT, SECONDARY	21.155.08	
TRANSMISSION - 4WD POWERSHIFT H TYPE - VALVE, CONTROL	21.155.16	
TRANSMISSION - 4WD POWERSHIFT H TYPE, SPS - BRAKE, PARKING	33.110.06	
TRANSMISSION - 4WD POWERSHIFT S TYPE- HOUSING	21.113.01	
TRANSMISSION - 4WD POWERSHIFT S TYPE- SHAFT, OUTPUT	21.154.03	
POWERSHIFT		
TRANSMISSION - MOUNTING (MODELS WITH POWERSHIFT)	21.113.01	
TRANSMISSION - MOUNTING (MODELS WITHOUT POWERSHIFT)	21.112.04	
(580N)		
	21.112.04	
TRANSMISSION - MOUNTING (MODELS WITHOUT POWERSHIFT)	<u></u>	


TRANSMISSION- 2WD / 4WD POWERSHIFT S TYPE, SPS - FILTER, OIL	21.104.02	
TRANSMISSION ASSEMBLY	21.100.01	
TRANSMISSION- COOLING SYSTEM	21.109.02	
TURBOCHARGER (580N)	10.250.05	
TURBOCHARGER (580SN, 580SN WT, 590SN)	10.250.05	
TURBOCHARGER SYSTEM (580N)	10.250.06	
TURBOCHARGER SYSTEM (580SN, 580SN WT, 590SN)	10.250.06	
VALVE - BACKHOE CONTROL - SEAL KIT	35.726.26	
VALVE - BACKHOE CONTROL, 6 SPOOL (W/O EXT DIPPER, W/O AUX	35.726.16	02
HYDS, W/ PILOT CONTROLS)		
VALVE - BACKHOE CONTROL, 6 SPOOL (W/O EXT DIPPER, W/O AUX	35.726.16	01
HYDS, W/O PILOT CONTROLS)		•
VALVE - BACKHOE CONTROL, 7 SPOOL (W/ EXT DIPPER, W/O AUX,	35.726.17	04
W/ PILOT CONTROLS)		•
VALVE - BACKHOE CONTROL, 7 SPOOL (W/ EXT DIPPER, W/O AUX,	35.726.17	02
W/O PILOT CONTROLS)		
VALVE - BACKHOE CONTROL, 7 SPOOL (W/O EXT DIPPER, W/ AUX	35.726.17	03
HYDS, W/ PILOT CONTROLS)	00.720.17	00
VALVE - BACKHOE CONTROL, 7 SPOOL (W/O EXT DIPPER,W/ AUX	35.726.17	01
HYDS, W/O PILOT CONTROLS)	00.720.17	01
VALVE - BACKHOE CONTROL, 8 SPOOL (W/O EXT DIPPER, W/ AUX	35.726.18	02
HYDS, W/ PILOT CONTROLS)	55.720.10	02
VALVE - BACKHOE CONTROL, 8 SPOOL (W/O EXT DIPPER, W/O AUX	35.726.18	01
HYDS, W/O PILOT CONTROLS)	55.720.10	01
VALVE - HEAVY LIFT (MECHANICAL CONTROL) (580SN, 580SN WT,	35.726.28	02
	33.720.20	02
		00
VALVE - HEAVY LIFT (PILOT CONTROL) (580SN, 580SN WT, 590SN)	35.726.27	02
VALVE - LOADER CONTROL, 3 SPOOL (PILOT CONTROLS) (580SN,	35.114.02	
580SN WT, 590SN)	05 704 00	
	35.724.08	
VALVE - LOADER CONTROL, THREE SPOOL (580N)	35.724.10	01
VALVE - LOADER CONTROL, THREE SPOOL (MANUAL CONTROLS)	35.724.10	02
(580SN, 580SN WT, 590SN)		
VALVE - LOADER CONTROL, THREE SPOOL (PILOT CONTROLS)	35.724.11	
(580SN, 580SN WT, 590SN)		
VALVE - LOADER CONTROL, TWO SPOOL (580N)	35.724.09	01
VALVE - LOADER CONTROL, TWO SPOOL (580SN, 580SN WT, 590SN)	35.724.09	
VALVE - LOADER CONTROL, TWO SPOOL (MANUAL CONTROLS)	35.724.09	05
(580SN, 580SN WT, 590SN)		
VALVE - LOADER CONTROL, TWO SPOOL (PILOT CONTROLS) (580SN,	35.724.09	04
580SN WT, 590SN)		
VALVE - PILOT CONTROL AND JOYSTICKS (6 SPOOL, W/O EXT	35.726.02	
DIPPER, W/ AUX HYDS)		
VALVE - PILOT CONTROL AND JOYSTICKS (6 SPOOL, W/O EXT	35.726.03	02
DIPPER, W/O AUX HYDS)		
VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/ EXT DIPPER,	35.726.04	03
W/ AUX HYDS)		
VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/ EXT DIPPER,	35.726.04	01
W/ AUX HYDS) (580N)		
VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/ EXT DIPPER,	35.726.04	04
W/O AUX HYDS)		• •
VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/ EXT DIPPER,	35.726.04	02
W/O AUX HYDS) (580N)	0011 2010 1	02
VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/O EXT	35.726.05	
DIPPER W/ AUX HYDS) (580N)	00.720.00	
VALVE - PILOT CONTROL AND JOYSTICKS (7 SPOOL, W/O EXT	35.726.06	
DIPPER W/ AUX HYDS) (580SN, 580SN WT, 590SN)	55.720.00	
$\Box \cap \Box \cap \forall \forall i \land i \land$		

VALVE - PILOT CONTROL AND JOYSTICKS (8 SPOOL, W/ EHOE, W/	35.726.07	
AUX HYDS)		
VALVE - SWING CUSHION (DAMPENING)	35.726.32	
VALVE ASSY - AUXILIARY UNI-DIRECTIONAL (WITH PILOT CONTROLS)	35.726.09	05
VALVE ASSY - HAMMER AUXILIARY (WITH MECHANICAL CONTROLS)	35.726.37	01
VALVE INSTALL - BACKHOE CONTROL, 7 SPOOL (FOOT SWING)	35.726.19	03
VALVE INSTALL - BACKHOE CONTROL, 7 SPOOL (HAND SWING)	35.726.19	04
VALVE INSTALL - BACKHOE CONTROL, 8 SPOOL (FOOT SWING)	35.726.19	01
VALVE INSTALL - BACKHOE CONTROL, 8 SPOOL (HAND SWING)	35.726.19	02
VALVE INSTALL - BACKHOE CONTROL, BI-AUXILIARY (MECHANICAL	35.726.22	01
CONTROLS)	0011 20122	01
VALVE INSTALL - BACKHOE CONTROL, DUAL AUX (PILOT CONTROLS)	35.726.25	
GEAR PUMP ONLY (580N)	55.720.25	
VALVE INSTALL - BACKHOE CONTROL, DUAL AUXILIARY	35.726.24	
	33.720.24	
	05 700 00	
VALVE INSTALL - BACKHOE CONTROL, DUAL AUXILIARY (PILOT	35.726.23	
CONTROLS) VARIABLE VALVE PUMP (580SN, 580SN WT, 590SN)		
VALVE INSTALL - BACKHOE CONTROL, SINGLE AUX (MECHANICAL	35.726.20	02
CONTROLS)		
VALVE INSTALL - BACKHOE CONTROL, SINGLE AUX (PILOT	35.726.21	01
CONTROLS) VARIABLE VALVE PUMP (580SN, 580SN WT, 590SN)		
VALVE INSTALL - BACKHOE CONTROL, UNI AUX PILOT, GEAR PUMP	35.726.20	01
ONLY (580N)		
VALVE INSTALL - DUAL COUPLER (580SN, 580SN WT, 590SN)	35.726.12	06
VALVE INSTALL - HAMMER (PILOT CONTROLS) (580SN, 580SN WT,	35.726.22	02
590SN)		
VALVE INSTALL - HAMMER (WITH MECHANICAL CONTROLS)	35.726.38	01
VALVE INSTALL - SINGLE COUPLER	35.726.12	03
VALVE INSTALL - SWING CUSHION (DAMPENING)	35.726.31	02
VALVE SECTION - 4 IN 1 , LOADER (PILOT CONTROLS) (580SN, 580SN	35.724.16	02
WT, 590SN)	00.721.10	
VALVE SECTION - BACKHOE BLDIRECTIONAL	35 150 04	
VALVE SECTION - BACKHOE, BI-DIRECTIONAL	35.150.04	
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS)	35.150.02	
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS)	35.150.02 35.150.03	
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS)	35.150.02 35.150.03 35.150.09	
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT	35.150.02 35.150.03	
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS)	35.150.02 35.150.03 35.150.09 35.150.11	0.1
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N)	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01	01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN,	35.150.02 35.150.03 35.150.09 35.150.11	01 02
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN)	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01	
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05	02
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS)	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.08	02 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS)	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.08 35.150.08 35.150.06	02
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS)	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.08	02 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS)	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.08 35.150.08 35.150.06	02 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS)	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.08 35.150.08 35.150.06	02 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN)	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.08 35.150.06 35.724.17	02 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN)	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.08 35.150.06 35.724.17	02 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.08 35.150.06 35.724.17 35.724.12	02 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, NOTLER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN)	35.150.02 35.150.03 35.150.09 35.150.01 35.150.01 35.150.01 35.150.05 35.150.08 35.150.06 35.724.17 35.724.12 35.724.15	02 01 02
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE, DUAL COUPLER - LOADER TOOL AND BACKHOE (580SN,	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.08 35.150.06 35.724.17 35.724.12	02 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE, DUAL COUPLER - LOADER TOOL AND BACKHOE (580SN, 580SN WT, 590SN)	35.150.02 35.150.03 35.150.09 35.150.01 35.150.01 35.150.01 35.150.05 35.150.06 35.724.17 35.724.12 35.724.15 35.726.12	02 01 02 04
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE, DUAL COUPLER - LOADER TOOL AND BACKHOE (580SN, 580SN WT, 590SN) VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND) WITHOUT	35.150.02 35.150.03 35.150.09 35.150.01 35.150.01 35.150.01 35.150.05 35.150.08 35.150.06 35.724.17 35.724.12 35.724.15	02 01 02
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE, DUAL COUPLER - LOADER TOOL AND BACKHOE (580SN, 580SN WT, 590SN) VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND) WITHOUT EXTENDABLE DIPPER	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.06 35.724.17 35.724.12 35.724.12 35.726.12 35.150.16	02 01 02 04 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE, DUAL COUPLER - LOADER TOOL AND BACKHOE (580SN, 580SN WT, 590SN) VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND) WITHOUT EXTENDABLE DIPPER VALVE, SINGLE COUPLER - LOADER TOOL OR BACKHOE	35.150.02 35.150.03 35.150.09 35.150.11 35.150.01 35.150.01 35.150.05 35.150.06 35.724.17 35.724.12 35.724.12 35.724.12 35.726.12 35.150.16 35.726.12	02 01 02 04
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE, DUAL COUPLER - LOADER TOOL AND BACKHOE (580SN, 580SN WT, 590SN) VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND) WITHOUT EXTENDABLE DIPPER VALVE, SINGLE COUPLER - LOADER TOOL OR BACKHOE WATER PUMP - CONTROL (580N)	35.150.02 35.150.03 35.150.09 35.150.01 35.150.01 35.150.05 35.150.06 35.150.06 35.724.17 35.724.12 35.724.15 35.724.15 35.726.12 35.150.16 35.726.12 10.402.05	02 01 02 04 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE, DUAL COUPLER - LOADER TOOL AND BACKHOE (580SN, 580SN WT, 590SN) VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND) WITHOUT EXTENDABLE DIPPER VALVE, SINGLE COUPLER - LOADER TOOL OR BACKHOE WATER PUMP - CONTROL (580N) WATER PUMP - CONTROL (580SN, 580SN WT, 590SN)	35.150.02 35.150.03 35.150.09 35.150.01 35.150.01 35.150.01 35.150.05 35.150.06 35.724.17 35.724.12 35.724.12 35.724.15 35.726.12 35.150.16 35.726.12 10.402.05 10.402.05	02 01 02 04 01
VALVE SECTION - BACKHOE, BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, BUCKET (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, DIPPER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, EXTENDABLE BOOM (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580N) VALVE SECTION - BACKHOE, INLET (WITH PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - BACKHOE, OUTLET VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, STABILIZER (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BACKHOE, SWING (WITH PILOT CONTROLS) VALVE SECTION - BUCKET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - INLET, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE SECTION - LIFT, LOADER (PILOT CONTROLS) (580SN, 580SN WT, 590SN) VALVE, DUAL COUPLER - LOADER TOOL AND BACKHOE (580SN, 580SN WT, 590SN) VALVE, JOYSTICK (PILOT CONTROLS) (RIGHT-HAND) WITHOUT EXTENDABLE DIPPER VALVE, SINGLE COUPLER - LOADER TOOL OR BACKHOE WATER PUMP - CONTROL (580N)	35.150.02 35.150.03 35.150.09 35.150.01 35.150.01 35.150.05 35.150.06 35.150.06 35.724.17 35.724.12 35.724.15 35.724.15 35.726.12 35.150.16 35.726.12 10.402.05	02 01 02 04 01


## SECTION INDEX

### 00 - Top level


00.000.00	PICTORIAL INDEX - MAINTENANCE
00.000.10	PICTORIAL INDEX - ENGINE
00.000.21	PICTORIAL INDEX - TRANSMISSION
00.000.25	PICTORIAL INDEX - FRONT MECHANICAL DRIVE
00.000.27	PICTORIAL INDEX - REAR DRIVE AXLE
00.000.33	PICTORIAL INDEX - BRAKE & CONTROLS
00.000.35	PICTORIAL INDEX - HYDRAULIC SYSTEMS
00.000.37	PICTORIAL INDEX - TOWING HOOKS & BALLISTING
00.000.39	PICTORIAL INDEX - FRAME COMPONENTS
00.000.41	PICTORIAL INDEX - STEERING
00.000.44	PICTORIAL INDEX - AXLE & WHEELS
00.000.50	PICTORIAL INDEX - CAB CLIMATE CONTROL
00.000.55	PICTORIAL INDEX - ELECTRICAL SYSTEM
00.000.82	PICTORIAL INDEX - FRONT LOADER
00.000.84	PICTORIAL INDEX - BACKHOE
00.000.90	PICTORIAL INDEX - PLATFORM, CAB, BODYWORK AND DECALS




					00.000.00		p1	07/10	
PICTO	ORIAL INI	DEX - MAINTENANCE				1		1	
REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPT	ΓΙΟΝ			
					580N	5903 5903			
					580SN W	1 580	NIC		
1									




				]				
					00.000.10		р1	07/10
PICTO	ORIAL INI	DEX - ENGINE						
REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION			
					580N	590	SN	
					580SN W			




				[	00.000.21		<b>n</b> 1	07/10
					00.000.21		р1	07/10
	RIAL INI	DEX - TRANSMISSION						
REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTION			
ļ								
					580N	590		
					580SN W	F 580	SN	




					00.000.25		p1	06/11
РІСТО	RIAL INI	DEX - FRONT MECHANICA	L DRIVE	L. L				
REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPT	DESCRIPTION		
					580N	590	SN	
					580SN W			




				[	00.000.27		p1	07/10
PICTO	ORIAL INI	DEX - REAR DRIVE AXLE						
REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPT	ION		
					580N	5903 T 5903		
					580SN W	1 2003	DIN	



					00.000.33		p1	07/10
PICTO	RIAL INI	DEX - BRAKE & CONTROL	S	L			·	
REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPT	ION		
					580N	590	SN	
					580SN W			



					00.000.35		p1	07/10
PICTO	RIAL INI	DEX - HYDRAULIC SYSTE	MS					
REF	FN	PART NUMBER	YR/SN	QTY	DESCRIPTI	ON		
					580N	590	SN	
					580SN W			
						·		



This as a preview PDF file from **best-manuals.com** 



## Download full PDF manual at best-manuals.com